



Yamaha 15FWC 2002

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	5
BRACKET 2	8
CARBURETOR	10
CONTROL	13
CRANKSHAFT. PISTON	16
CYLINDER. CRANKCASE	19
ELECTRICAL 1	21
ELECTRICAL 2	22
FUEL	23
FUEL TANK	24
GENERATOR	25
INTAKE	26
LOWER CASING. DRIVE 1	28
LOWER CASING. DRIVE 2	32
REMOTE CONTROL ASSY	34
REMOTE CONTROL ATTACHMENT	39
REMOTE CONTROL BOX	41
REPAIR KIT 1	42
REPAIR KIT 2	44
STARTER	46
STARTING MOTOR	48
STEERING	50
STEERING GUIDE	53
TOP COWLING	54
UPPER CASING	55

Bottom Cowling




63V1300-2120

C5

Ref	Part	
1	63V--42711--03--4D Cowling, bottom	Buy now
2	682--42725--02 Grommet	Buy now
3	63V--42726--00 Grommet	Buy now
4	682--42727--00 Grommet	Buy now
5	6G1--42748--00 Grommet	Buy now
6	90480--06M19 Grommet (6e3)	Buy now
7	63V--42815--01--4D Lever, clamp	Buy now
8	6E7--42816--00 Lever, clamp 2	Buy now
9	90386--12M45 Bushing (6g1)	Buy now
10	90206--12052 Washer, wave (666)	Buy now
11	90201--06068 Washer, plate (6k8)	Buy now
12	97095--06025 Bolt	Buy now
13	95380--06700 Nut	Buy now
15	92995--06600 Washer, plain (646)	Buy now
16	90387--06034 Collar (6g1)	Buy now

Bottom Cowling




63V1300-2120

C5

Ref	Part	
17	90480--15M31 Grommet (6g1)	Buy now
18	63V--42716--02 Rubber, seal 1	Buy now
19	6H3--44391--01 Nipple, hose	Buy now
20	90465--25M57 Clamp(63v)	Buy now
21	6E7--42791--10 Mark 1	Buy now
22	6A14279201 Mark (100:1)	Buy now
23	6A1--28176--00 Label Caution	Buy now
24	6E3--8257H--00 Plate Mark	Buy now

Bracket 1





63W0664-1140

D4

Ref	Part	
1	63V43111054D Bracket, clamp 1	Buy now
2	63V43112064D Bracket, clamp 2	Buy now
3	66M--82148--00 Wire, lead 4	Buy now
4	97885--06008 Screw, pan head(6a3)	Buy now
5	97885--08010 Rivet	Buy now
6	6E0--43118--01 Handle, transom clamp	Buy now
7	90243--04M01 Pin(6a1)	Buy now
8	6E7--43116--00 Screw, transom clamp	Buy now
9	648--43114--01 Pad, transom clamp	Buy now
10	63W--43131--10 Bolt, clamp bracket	Buy now
11	90202--22M54 Washer, plate(63v)	Buy now
12	90386--22M94 Bush(63v)	Buy now
14	6J8--43113--01 Plate, clamp bracket	Buy now
15	90185--22043 Nut, self-locking	Buy now
16	90387--06M13 Collar(6h6)	Buy now

Bracket 1




63W0664-1140

D4


Ref	Part	
17	90101--06M29 Bolt, hexagon (682)	Buy now
18	92995--06600 Washer, plain (646)	Buy now
19	95380--06700 Nut	Buy now
20	6L2--43160--00 Tilt rod assembly	Buy now
21	63V--43311--03--4D Bracket, swivel 1	Buy now
22	66M--43630--01 Tilt lever assembly	Buy now
23	682--43318--01 Cover	Buy now
24	63V--43191--00 Shaft, stopper	Buy now
25	90202--07M60 Washer, plate	Buy now
26	90387--07M07 Collar	Buy now
27	90386--07M95 Bush(63v)	Buy now
28	66M--43350--01 Receiver assembly	Buy now
29	90507--20M00 Spring, tension(63v)	Buy now
30	63V--43641--01 Lever, tilt	Buy now
31	90157--05014 Screw, pan head	Buy now

Bracket 1



Ref	Part	
32	99080--05600 Circlip(22k)	Buy now
33	63V--43614--10 Plate, tilt lock	Buy now
34	90508--18M41 Spring, torsion	Buy now
35	66R--43615--00 Plate, tilt lock	Buy now
36	66R--43611--00 Shaft, tilt lock	Buy now
37	93430--04M03 Circlip (eu0)	Buy now
38	63V--43659--00 Shaft, reverse lock	Buy now
40	66R--43617--00 Rod, tilt lock	Buy now
41	63V--43656--00 Spring, reverse lock 1	Buy now
42	63V--43181--00 Lever, tilt stop 1	Buy now
43	90109--06M84 Bolt	Buy now

Bracket 2





63V0010-1160

D6

Ref	Part	
1	93700--06M03 Nipple, grease(6a1)	Buy now
2	63V--42528--00 Plate, friction	Buy now
3	689--43373--01 Seal, damper	Buy now
4	90105--06M07 Bolt (689)	Buy now
5	63V--82127--00 Wire, lead 2	Buy now
6	63V--42511--04--4D Bracket, steering	Buy now
7	90209--40008 Washer	Buy now
8	65F--42537--00 Bushing, pivot shaft	Buy now
9	90386--30048 Bush	Buy now
10	93210--29M94 O-ring(6h1)	Buy now
11	90386--30M60 Bush(6j8)	Buy now
12	90116--08M54 Bolt, stud(63v)	Buy now
13	63V44514015B Mount damper, upper side	Buy now
14	63V--44526--00 Plate	Buy now
15	95380--08600 Nut (661)	Buy now

Bracket 2




63V0010-1160

D6

Ref	Part	
16	90387--16002 Collar	Buy now
17	63V--44366--01 Damper, water seal 2	Buy now
18	63V45114A0 Gasket, upper casing	Buy now
19	97095--06018 Bolt (fj0)	Buy now
20	92995--06600 Washer, plain (646)	Buy now
21	63V--44551--01--4D Housing, lower mount rubber 1	Buy now
22	63V--44557--00 Mount damper, lower front	Buy now
23	682--44555--00 Mount damper, lower side	Buy now
24	9707506055 Bolt, hexagon w/w deep recess	Buy now
26	9707506075 Bolt, hexagon w/w deep recess	Buy now
28	90179--06M28 Nut(63v)	Buy now


Carburetor



B3

Ref	Part	
1	63V--14301--00 Carburetor assembly 1	Buy now
2	679--14923--00 Screw, pilot	Buy now
3	679--14555--00 Spring	Buy now
4	63V--14527--00 Plate	Buy now
5	63V--14126--00 Gasket	Buy now
6	97803--04010 Screw, pan head (e56)	Buy now
7	63V--14948--06 Jet (#48)	Buy now
8	679--14966--00 Rubber cap	Buy now
9	63V--14523--00 Screw, stop	Buy now
10	90501--10326 Spring coil(663)(carb)	Buy now
11	63V--14984--00 Gasket, float chamber	Buy now
12	63V--14980--00 Body, float chamber	Buy now
13	63V--14947--00 Jet, needle	Buy now
14	676--14943--29 Jet, main (#110)	Buy now
15	97980--04114 Screw, pan head(ga5)	Buy now

Carburetor




63V0010-5050

B3

Ref	Part	
16	6G1--14398--00 Washer	Buy now
17	6G1--14992--00 Screw, drain	Buy now
18	63V--14985--00 Float	Buy now
19	6G1--14546--00 Valve, needle	Buy now
20	676--14186--00 Pin, valve	Buy now
21	663--14159--00 Clip	Buy now
22	6H4--14548--00 Pin, float arm	Buy now
23	98580--04008 Screw, pan head (713)	Buy now
24	98980--03006 Screw, bind(6g1)	Buy now
25	95380--03600 Nut (6g8)	Buy now
26	97980--04125 Screw, with washer	Buy now
27	6G1--24452--00 Cover, pump	Buy now
28	63V--24411--00 Diaphragm	Buy now
29	6G1--24412--01 Body 1	Buy now
30	6G1--24411--00 Diaphragm	Buy now

Carburetor




63V0010-5050

B3


Ref	Part	
31	6G1--24431--01 Gasket, fuel pump 1	Buy now
32	6L5--24421--00 Valve, check	Buy now
33	98580--04006 Screw, pan head (7h3)	Buy now

Control




Ref	Part	
1	63V1449701 Stay, Throttle Wire	Buy now
2	689--44194--00 Cap	Buy now
3	90387--06M50 Collar(63v)	Buy now
4	95895--06065 Bolt, flange(63v)	Buy now
5	97095--06012 Bolt(gh1)	Buy now
6	92995--06600 Washer, plain (646)	Buy now
7	63V--41282--00 Stopper, free accel. link "9.9F" ONLY	Buy now
8	63V4163100 Lever, magneto control	Buy now
9	97885--06030 Screw, pan head(6e0)	Buy now
10	95380--06600 Nut(661)	Buy now
11	90501--12M16 Spring (6a1)	Buy now
12	688--44194--00 Cap	Buy now
13	63V--41238--00 Joint, link	Buy now
14	6H4--41237--00 Joint, link	Buy now
15	95380--05700 Nut (656)	Buy now

Control




Ref	Part	
16	90468--10005 Pin, hair 6264123500	Buy now
17	63V--41223--00 Washer, lock 1	Buy now
18	63V--41283--01 Lever, free accel.	Buy now
19	63V--41211--00 Link, accel.	Buy now
20	661--41262--02 Joint, choke lever	Buy now
21	63V--41638--00 Pulley	Buy now
22	90508--16M37 Spring, torsion(63v)	Buy now
23	90508--20M38 Spring, torsion(63v)	Buy now
24	63V--44123--01 Arm, shift rod	Buy now
25	63V--44121--01 Lever, shift rod	Buy now
26	90159--05M25 Screw,pan head (646)	Buy now
27	63V--44125--00 Lever, shift rod	Buy now
31	63V--44116--00 Spring	Buy now
32	63V--44122--01 Bushing, shift rod lever	Buy now
34	63V--44143--01 Rod, shift	Buy now

Control




Ref	Part	
35	95380--06700 Nut	Buy now
36	90170--06015 Connector, shift rod	Buy now
37	63V--15746--10 Arm	Buy now
38	90387--06M06 Collar (651)	Buy now
39	90508--08M39 Spring, torsion(63v)	Buy now
40	97095--06020 Bolt(7u8)	Buy now
42	6L2--15747--00 Link	Buy now
44	63V1577000 Cable comp., starter stop	Buy now
45	90480--10M16 Grommet(6j8)	Buy now

Crankshaft. Piston




Ref	Part	
1	63V153960194 Housing, oil seal	Buy now
2	93210--46M16 O-ring (688)	Buy now
3	93101--25018 Oil seal	Buy now
4	93102--25M48 Oil seal(63v)	Buy now
5	93101--13018 Oil seal	Buy now
6	97095--06016 Bolt, hexagon deep recess	Buy now
7	92995--06600 Washer, plain (646)	Buy now
8	63V--11400--01 Crankshaft assembly	Buy now
9	63V--11412--00 Crank 1	Buy now
10	63V--11422--00 Crank 2	Buy now
11	63V--11432--00 Crank 3	Buy now
12	63V--11442--00 Crank 4	Buy now
13	93306--205U7 Bearing(63v)	Buy now
14	63V--11515--02 Seal, labyrinth 1	Buy now
15	682--11681--00 Pin crank	Buy now

Crankshaft. Piston



Ref	Part	
16	650--11651--04 Rod, connecting	Buy now
17	93310--620V5 Bearing, big end (682)	Buy now
18	90209--20M23 Washer, crank pin (1h9)	Buy now
19	91609--20008 Pin, spring	Buy now
20	93440--52009 Circlip (168)	Buy now
21	6E7--11631--00--97 Piston (std)	Buy now
21	6E7--11635--00 Piston (1st o.s) AP	Buy now
21	6E7--11636--00 Piston (2nd o.s) AP	Buy now
22	682--11610--01 Piston ring set (std)	Buy now
22	682--11610--11 Piston ring set (1st o/s) AP	Buy now
22	682--11610--21 Piston ring set (2nd o/s) AP	Buy now
23	634--11633--00 Pin, piston	Buy now
24	93602--14104 Pin, dowel	Buy now
25	90201--14377 Washer, plate	Buy now
26	93450--15023 Circlip 131116340000	Buy now

Crankshaft. Piston




63V0010-1030

A7


Ref	Part	
27	93110--23M00 Oil seal (682)	Buy now
28	63V--11445--00 Spacer	Buy now
29	90201--46M29 Washer, plate(63v)	Buy now

Cylinder. Crankcase




Ref	Part	
3	624--14485--00 Pipe, joint	Buy now
4	6501448502 Pipe, joint	Buy now
5	90445--07M08 Hose (I390)	Buy now
7	90467--06016 Clip (655)	Buy now
8	682--11325--00 Anode 1	Buy now
9	98780--05015 Ybs53-516 screw,flat head	Buy now
10	93606--12019 Pin, dowel (614)	Buy now
11	90119--08M07 Bolt, with washer(63v)	Buy now
13	63V--41112--A0 Gasket, exhaust inner cover	Buy now
15	676--11372--00 Nipple, hose	Buy now
16	90445--09105 Hose (I420)	Buy now
17	97013--06030 Bolt	Buy now
18	92903--06600 Washer, plain (646)	Buy now
20	63V11181A1 Gasket, cylinder head 1	Buy now
21	90105--07M05 Bolt (682)	Buy now

Cylinder. Crankcase




Ref	Part	
23	6E5--12411--20 Thermostat	Buy now
24	90201--16M03 Washer, plate(63v)	Buy now
25	682--12414--A1 Gasket, cover	Buy now
26	97013--06020 Bolt(62y)	Buy now
28	94702--00271 Plug, spark (br7hs-10)	Buy now

Electrical 1



Ref	Part	
1	63V--85540--01 C.d.i. unit assembly	Buy now
2	97095--06020 Bolt(7u8)	Buy now
3	92995--06600 Washer, plain (646)	Buy now
4	90464--15M11 Clamp (3y2)	Buy now
5	90465--08M61 Clamp(63v)	Buy now
6	63V--85570--00 Ignition coil assembly	Buy now
7	97095--06018 Bolt (fj0)	Buy now
9	90480--25161 Grommet(656)	Buy now
10	6E3--82370--21 Plug cap assembly	Buy now
11	90464--08M02 Clamp	Buy now
12	97095--06012 Bolt(gh1)	Buy now
14	662--82519--00 Wire, earth lead	Buy now
17	682--84381--00 2p concent 1	Buy now
18	6J8--81960--00 Rectifier & regulator assembly	Buy now
19	97095--06016 Bolt, hexagon deep recess	Buy now


Electrical 2



C3

Ref	Part	
1	6E78211700 Wire, lead	Buy now
2	6E78210511 Battery cable	Buy now
3	682--82119--01 Cover, lead wire	Buy now
4	63V8259000 Wire Harness assembly	Buy now
5	663--82151--00 Fuse	Buy now
6	6824272450 Grommet	Buy now
7	6G1--81941--10 Starter relay	Buy now
8	6G1--81952--00 Holder, relay	Buy now
9	6E78194500 Plate, Switch Fitting	Buy now
10	97095--06014 Bolt(gj3)	Buy now
11	682--82151--00 Fuse	Buy now
12	664--81970--61 Rectifier assembly	Buy now
13	97880--05025 Screw, panhead (a93)	Buy now
14	92990--05600 Washer, plain (646)	Buy now

Fuel




63V0010-1060

B5

Ref	Part	
1	6G1--24304--02 Fuel pipe joint comp. 1	Buy now
2	97095--06020 Bolt(7u8)	Buy now
3	92995--06600 Washer, plain (646)	Buy now
4	61N--24560--00 Filter assembly	Buy now
5	61N--24563--00 Element, filter	Buy now
6	61N--24521--00 Cup, filter	Buy now
7	93210--32738 O-ring(1wg)	Buy now
8	95380--08600 Nut (661)	Buy now
9	90445--09M00 Hose (1180)	Buy now
10	90467--08004 Clip, pipe 6162435600	Buy now
11	682--24566--01 Bracket, filter	Buy now
12	97013--06010 Bolt(63v)	Buy now
13	63V--24396--01 Plate	Buy now
14	656--W2810--02 Tool kit	Buy now


Fuel Tank



E7

Ref	Part	
1	6YK--24201--01 Fuel Tank assembly (25L) AP PLASTIC, 25L,	Buy now
2	6YL--24268--01 Gasket, fuel meter	Buy now
3	6YK--24610--00 Cap assembly WITH INDICATOR	Buy now
4	6YL--24641--00 Gasket, cap 1	Buy now
5	6YK--24260--01 Fuel meter assembly	Buy now
6	90157--05M16 Screw, pan head	Buy now
7	6YL--24329--00 Seal	Buy now
8	6YL--24306--52 Fuel pipe comp. 1 AP	Buy now


Generator



C1

Ref	Part	
1	63V8555000 Rotor assembly	Buy now
1	63V8555010 Rotor assembly	Buy now
2	63V8558000 Coil, pulser	Buy now
3	63V8552000 Coil, charge	Buy now
4	63V--85533--00 Coil, lighting	Buy now
5	63V--41611--00 Retainer, magneto base	Buy now
6	90387--06M53 Collar (1m1)	Buy now
7	90105--06M68 Bolt, washer based(63v)	Buy now
8	90387--06M24 Collar(6r8)	Buy now
9	90105--06M69 Bolt, washer based(63v)	Buy now
10	90280--05013 Key, woodruff	Buy now
11	90170--12066 Nut, hexagon 6481155500	Buy now
12	90201--12472 Washer, plate (4n0)	Buy now

Intake




63V0010-5040

B2

Ref	Part	
1	63V--13610--10 Reed valve assembly	Buy now
1	63V1361000 Reed valve assembly 9.9F--FOR NORWAY	Buy now
1	63W--13610--00 Reed valve assembly	Buy now
2	682--W0004--00 Reed set	Buy now
3	97095--06020 Bolt(7u8)	Buy now
4	92995--06600 Washer, plain (646)	Buy now
5	63V--41253--00 Lever, choke	Buy now
6	91690--20010 Pin, spring	Buy now
7	63V--41262--00 Joint, choke lever	Buy now
8	63V--41257--00 Rod, choke 2	Buy now
9	63V--14440--00 Silencer assembly, intake	Buy now
10	90387--06M15 Collar(6g8)	Buy now
11	90480--12M25 Grommet (6e9)	Buy now
12	93210--35M86 O-ring(6l2)	Buy now
13	90119--06M94 Bolt, with washer	Buy now

Intake




63V0010-5040

B2


Ref	Part	
14	6H4--41271--01 Knob, choke	Buy now
15	63V--41256--00 Rod, choke 1	Buy now
16	689--41273--00 Grommet	Buy now
17	6J8--41274--00 Grommet 2	Buy now
18	63V--41252--00 Lever, choke 1	Buy now
19	661--41262--02 Joint, choke lever	Buy now
20	90201--05M09 Washer, plate(63v)	Buy now
21	90164--05M03 Screw, tapping(6g8)	Buy now

Lower Casing. Drive 1




Ref	Part	
1	63V--45300--03--4D Lower unit assembly S	Buy now
1	63V--45300--13--4D Lower unit assembly L	Buy now
2	63V--45311--01--4D Casing, lower	Buy now
3	93315--314V8 Bearing, needle (6e7)	Buy now
4	63V--45536--00 Sleeve, drive shaft	Buy now
5	93341--41414 Bearing	Buy now
6	6E8--45587--10--13 Shim (t:1.13mm) UR	Buy now
6	6E8--45587--10--20 Shim (t:1.20mm) UR	Buy now
7	93332--00005 Brg,cyl-cal roller 0.19g nt	Buy now
8	664--45567--01--10 Shim (t:0.10mm) UR	Buy now
8	664--45567--01--12 Shim (t:0.12mm) UR	Buy now
8	664--45567--01--15 Shim (t:0.15mm) UR	Buy now
8	664--45567--01--18 Shim (t:0.18mm) UR	Buy now
8	664--45567--01--30 Shim (t:0.30mm) UR	Buy now
8	664--45567--01--40 Shim (t:0.40mm) UR	Buy now

Lower Casing. Drive 1




Ref	Part	
8	664--45567--01--50 Shim (t:0.50mm) UR	Buy now
9	90340--08002 Plug, straight screw	Buy now
10	90430--08020 Gasket	Buy now
11	63V--44301--00 Water pump housing comp.	Buy now
12	63V--44322--00 Insert, cartridge	Buy now
13	647--44366--00 Damper, water seal 2	Buy now
14	63V--44352--01 Impeller	Buy now
15	63V--44338--00 Key, woodruff	Buy now
16	93210--44398 O-ring(55x)	Buy now
17	63V--44323--00 Outer plate, cartridge	Buy now
18	93604--12M07 Pin, dowel (688)	Buy now
19	97080--08045 Bolt, hexagon	Buy now
20	63V--44328--00 Plate	Buy now
21	63V--45331--00--5B Housing, bearing	Buy now
22	9038114020 Bushing, drive shaft 1	Buy now

Lower Casing. Drive 1




Ref	Part	
23	93101--20048 Oil seal (20x30x6-648)	Buy now
24	63V--45315--A0 Packing, lower casing	Buy now
25	93210--06ME6 O-ring	Buy now
26	97080--08025 Screw, bind(j36)	Buy now
27	63V--44150--00 Shift cam assembly S	Buy now
27	63V--44150--10 Shift cam assembly L	Buy now
28	63V--45510--01 Drive shaft assembly S	Buy now
28	63V--45510--11 Drive shaft assembly L	Buy now
29	63V--45551--00 Pinion	Buy now
30	90179--08M06 Nut (6e7)	Buy now
31	6E7--45560--01 Gear	Buy now
32	6E7--45571--00 Gear 2	Buy now
33	626--45577--00--01 Shim (t:0.10mm) UR	Buy now
33	626--45577--00--03 Shim (t:0.30mm) UR	Buy now
33	626--45577--00--05 Shim (t:0.50mm) UR	Buy now

Lower Casing. Drive 1



Ref	Part	
34	90201--17682 Washer, plate (2k7)	Buy now
35	683--45611--00 Shaft propeller	Buy now
36	650--45635--00 Plunger, shift	Buy now
37	682--45631--00 Clutch, dog	Buy now
38	90250--05010 Pin straight 648456320000	Buy now
39	648--45633--00 Ring, cross pin	Buy now
40	90501--14M06 Spring, compression	Buy now
41	683--45361--02--4D Cap, lower casing	Buy now
42	93306--00501 Bearing(1ff)	Buy now
43	93315--317U2 Brg,cyl-cal roller 14g (683)	Buy now
44	93101--17054 Oil seal (17x30x6-650)	Buy now
45	93210--57M09 O-ring (683)	Buy now
46	93210--56M80 O-ring(6j8)	Buy now
47	97095--06020 Bolt(7u8)	Buy now
48	92995--06600 Washer, plain (646)	Buy now


Lower Casing. Drive 2



E5


Ref	Part	
1	63V--44365--10 Damper, water seal 1	Buy now
2	63V--44368--00 Rubber, water seal 4	Buy now
3	63V--44361--01 Tube, water S	Buy now
3	63V--44361--11 Tube, water L	Buy now
4	93604--12M07 Pin, dowel (688)	Buy now
5	97075--08030 Bolt, hexagon (fj1)	Buy now
6	92995--08600 Washer, plain (663)	Buy now
7	6G1--45214--00 Cover, water inlet	Buy now
8	63V--45215--00 Cover, water inlet	Buy now
9	90152--05M04 Screw, countersunk	Buy now
10	90185--05002 Nut nylon (sus)(ex4)	Buy now
11	61N--45251--01 Anode	Buy now
12	95895--06030 Bolt, flange deep recess	Buy now
13	92990--06300 Washer, tooth	Buy now
14	63V--45375--00 Damper, seal	Buy now

Lower Casing. Drive 2



Ref	Part	
15	6E7--45987--01 Spacer	Buy now
16	90201--10M01 Washer, plate(6m7)	Buy now
17	90171--10M01 Nut castle (683)	Buy now
18	91490--30020 Pin cotter	Buy now
21	6E7--45986--00 Ring, deflector	Buy now
22	90171--10M07 Nut, castle(6g8)	Buy now
23	90201--10M02 Washer, plate(6g9)	Buy now


Remote Control Assy



F3

Ref	Part	
1	703--48203--15 Remote control assembly (7p) AP	Buy now
2	703--48261--01 Arm, throttle	Buy now
3	703--48153--00 Shaft, free accel.	Buy now
4	703--48235--00 Bushing	Buy now
5	703--48268--00 Spacer 3	Buy now
6	703--48264--00 Throttle, friction	Buy now
7	95380--05600 Nut, hexagon (663)	Buy now
8	97380--05025 28 -	Buy now
9	703--48265--00 Shaft Friction	Buy now
10	93430--06024 Circlip (701)	Buy now
11	703--48245--00 Plate, lock	Buy now
12	703--48252--00 Roller, cam	Buy now
13	701--48248--00 Roller, free accel	Buy now
14	703--48198--00 Washer, wave 3	Buy now
15	703--48243--00 Bushing 3	Buy now


Remote Control Assy



F3

Ref	Part	
16	703--48236--00 Bushing	Buy now
17	703--48189--00 Retainer	Buy now
18	703--48234--00 Roller, detent	Buy now
19	703--48345--01 Cable end, remote control 2	Buy now
20	703--48358--00 Anchor, cable	Buy now
21	703--48244--00 Spring, free accel.	Buy now
22	703--48238--00 Spring, detent	Buy now
23	703--48246--00 Spacer 1	Buy now
24	703--48227--00 Spring, neutral lock	Buy now
25	703--48226--00 Plate, stopper	Buy now
26	703--48222--00 Grip, control lever SINGLE	Buy now
27	703--48223--00 Lock, neutral	Buy now
28	703--48225--00 Cover	Buy now
29	703--48219--00 Cover, lead	Buy now
30	703--48281--00 Screw, flat head	Buy now


Remote Control Assy



F3

Ref	Part	
31	703--48282--00 Screw	Buy now
32	97380--08030 Bolt, hexagon (fj1)	Buy now
33	92990--08600 Washer, plain (663)	Buy now
34	98580--04010 Screw, pan head (e56)	Buy now
35	98580--04006 Screw, pan head (7h3)	Buy now
36	98580--05010 Screw, pan head(62x)	Buy now
37	98580--03015 Screw, pan head (n151)	Buy now
38	703--48291--10 Screw	Buy now
39	95380--06600 Nut(661)	Buy now
40	703--48293--10 Spacer, remote control SINGLE	Buy now
41	701--48287--00 Washer 1	Buy now
42	703--48215--00 Graphic	Buy now
43	703--82510--33 Main switch assembly	Buy now
44	703--82577--00 Cap, key	Buy now
45	703--82531--00 Wire, lead	Buy now


Remote Control Assy



F3

Ref	Part	
46	688--82575--01 Engine stop switch assembly	Buy now
47	682--82556--00 Lanyard, stop switch	Buy now
48	688--82586--21 Extension, wire harness L)5M (7P)	Buy now
49	703--82540--00 Neutral switch assembly	Buy now
50	703--83383--02 Buzzer	Buy now
51	703--48284--00 Grommet	Buy now
52	703--82591--00 Band	Buy now
53	703--82592--00 Band	Buy now
54	703--48224--00 Cover, control lever WITHOUT PT/T SW.	Buy now
55	703--48221--00 Grip	Buy now
56	703--48152--00 Knob, free accel	Buy now
57	703--48212--00 Rear housing	Buy now
58	703--48213--00 Back, panel	Buy now
59	703--48271--00 Arm, shift	Buy now
60	703--48211--01 Housing,1	Buy now


Remote Control Assy



F3

Ref	Part	
61	703--48232--00 Drive gear	Buy now

Remote Control Attachment






63V1100-2140

D3

Ref	Part	
1	63V--48501--00 Remote cont. attachment assembly AP	Buy now
2	63V--48531--00 Bracket, remote control 1	Buy now
3	682--48538--50 Clamp, cable	Buy now
4	91690--30012 Pin, spring	Buy now
5	97095--06016 Bolt, hexagon deep recess	Buy now
6	92995--06600 Washer, plain (646)	Buy now
7	95380--06600 Nut(661)	Buy now
8	663--48344--00 Cable end, remote control	Buy now
9	90468--18008 Clip 620436610000	Buy now
10	90201--08M12 Washer plate (682)	Buy now
11	63V--42154--00 Lever, throttle control	Buy now
12	90386--10025 Bushing (658)	Buy now
13	90206--10M04 Washer, wave (676)	Buy now
14	90201--10M02 Washer, plate(6g9)	Buy now
15	63V--42192--00 Rod 2	Buy now

Remote Control Attachment




63V1100-2140

D3


Ref	Part	
16	90201--04M06 Washer, plate(26h)	Buy now
17	91490--20010 Pin, cotter	Buy now
18	63V--48534--00 Throttle lever, control	Buy now
19	95780--08300 Nut, nylon (6j8)	Buy now
20	63V--48544--00 Lever, shiftcontrol	Buy now
21	90159--05M25 Screw,pan head (646)	Buy now
22	90386--10009 Bushing 6484418600	Buy now
23	63V--48511--01 Hook, steering AP	Buy now
24	97075--08035 Bolt(70w) AP	Buy now
25	92995--08600 Washer, plain (663) AP	Buy now
26	90185--08057 Nut, nylon (6j8) AP	Buy now

Remote Control Box




Ref	Part	
1	703--48203--15 Remote control assembly (7p) AP	Buy now
2	701--48310--80 Cable, Remote Control L=10F UR	Buy now
2	701--48310--90 Cable, Remote Control L=11F UR	Buy now
2	701--48320--00 Cable, Remote Control L=12F UR	Buy now

Repair Kit 1




Ref	Part	
1	63V--W0001--02 Gasket kit	Buy now
2	63V--41112--A0 Gasket, exhaust inner cover	Buy now
3	63V11181A1 Gasket, cylinder head 1	Buy now
4	682--12414--A1 Gasket, cover	Buy now
5	93210--46M16 O-ring (688)	Buy now
6	93101--25018 Oil seal	Buy now
7	93101--13018 Oil seal	Buy now
8	93102--25M48 Oil seal(63v)	Buy now
9	93110--23M00 Oil seal (682)	Buy now
10	63V--11445--00 Spacer	Buy now
11	90201--46M29 Washer, plate(63v)	Buy now
12	63V--W0093--00 Carburetor repair kit	Buy now
13	679--14923--00 Screw, pilot	Buy now
14	63V--14126--00 Gasket	Buy now
15	63V--14984--00 Gasket, float chamber	Buy now

Repair Kit 1




Ref	Part	
16	97980--04114 Screw, pan head(ga5)	Buy now
17	6G1--14398--00 Washer	Buy now
18	63V--14985--00 Float	Buy now
19	6G1--14546--00 Valve, needle	Buy now
20	676--14186--00 Pin, valve	Buy now
21	663--14159--00 Clip	Buy now
22	6H4--14548--00 Pin, float arm	Buy now

Repair Kit 2




Ref	Part	
1	63V--W0001--22 Lower unit gasket kit	Buy now
2	63V--45113--A1 Gasket, upper casing	Buy now
3	63V--41135--00 Gasket, exhaust manifold	Buy now
4	63V--41133--A1 Gasket, exhaust manifold 1	Buy now
5	90430--08020 Gasket	Buy now
6	93210--44398 O-ring(55x)	Buy now
7	63V--44323--00 Outer plate, cartridge	Buy now
8	93101--20048 Oil seal (20x30x6-648)	Buy now
9	63V--45315--A0 Packing, lower casing	Buy now
10	93210--06ME6 O-ring	Buy now
11	93101--17054 Oil seal (17x30x6-650)	Buy now
12	93210--57M09 O-ring (683)	Buy now
13	93210--56M80 O-ring(6j8)	Buy now
14	63V--44365--10 Damper, water seal 1	Buy now
15	63V--44368--00 Rubber, water seal 4	Buy now

Repair Kit 2



Ref	Part	
16	63V--W0078--01 Water pump repair kit	Buy now
17	647--44366--00 Damper, water seal 2	Buy now
18	97080--08045 Bolt, hexagon	Buy now
19	63V--44322--00 Insert, cartridge	Buy now
20	63V--44352--01 Impeller	Buy now
22	63V--44338--00 Key, woodruff	Buy now
23	63V--W0078--0A Water pump repair kit	Buy now
24	63V--44322--40 Insert, cartridge	Buy now
25	63V--44323--40 Outer plate, cartridge	Buy now

Starter




63V1100-2080

B6

Ref	Part	
1	63V1571012 Starter assembly WITH SAFETY DEVICE	Buy now
2	63V1571101 Case, starter	Buy now
3	63V--15795--01 Guide, rope	Buy now
4	90387--06M05 Collar(6h4)	Buy now
5	63V--15714--00 Drum, sheave	Buy now
6	63V--15741--00 Pawl, drive	Buy now
7	63V--15713--00 Spring, starter	Buy now
8	63V--15753--00 Bush	Buy now
9	63V--15716--00 Plate, drive	Buy now
10	63V--15705--01 Spring, drive pawl	Buy now
11	63V--15767--01 Spring	Buy now
12	63V--15784--01 Spring, return	Buy now
13	63V--15744--00 Circlip	Buy now
14	63V--15768--00 Screw	Buy now
15	63V--15764--00 Collar 1	Buy now

Starter




63V1100-2080

B6

Ref	Part	
16	63V--15793--00 Screw	Buy now
17	* item_description	Buy now
18	6G1--15755--00 Handle, starter	Buy now
19	6G1--15779--00 Cover	Buy now
20	63V--15794--00 Stopper	Buy now
21	63V--15748--00 Plunger, starter stop	Buy now
22	63V--15734--00 Spring, return	Buy now
23	63V--15726--00 Washer, flat	Buy now
24	91490--16018 Pin, cotter (e57)	Buy now
25	63V--15762--00 Seal, rubber 2	Buy now
26	97095--06020 Bolt(7u8)	Buy now
27	92995--06600 Washer, plain (646)	Buy now
28	6A1--83625--41 Mark 5	Buy now
29	6A1--83625--51 Mark 5	Buy now


Starting Motor



C4

Ref	Part	
1	6L28180011 Starting motor assembly	Buy now
2	6L28185011 Armature assembly	Buy now
3	6828180910 Washer kit	Buy now
4	6L28183310 Ring, stop	Buy now
5	6828181011 Stator assembly	Buy now
6	6L28182010 Rear bracket assembly	Buy now
7	6L28184010 Brush holder assembly	Buy now
8	6828181310 Spring, brush	Buy now
9	6L28181110 Brush 1	Buy now
10	6L28181210 Brush 2	Buy now
11	6828183210 Pinion assembly	Buy now
12	6828183010 Front Bracket assembly	Buy now
13	6828183100 Metal, front	Buy now
14	6828182610 Bolt	Buy now
15	6828184710 O-ring	Buy now


Starting Motor



C4

Ref	Part	
16	6828183410 Ring	Buy now
17	97013--08025 Bolt (682)	Buy now
18	92903--08600 Washer, plain (663)	Buy now
19	682818224394 Bracket, Electric Motor (682-81822-42-94)	Buy now
20	97075--06020 Bolt(7u8)	Buy now
21	92995--06600 Washer, plain (646)	Buy now
22	97075--06025 Bolt	Buy now
24	97075--06030 Bolt(jf7)	Buy now

Steering




63V1100-2120

C6

Ref	Part	
1	63V42111004D Handle, steering	Buy now
2	90386--34M97 Bush(63v)	Buy now
3	90206--36M21 Washer, wave(63v)	Buy now
4	90202--36M55 Washer, plate(63v)	Buy now
5	90386--33M96 Bush(63v)	Buy now
6	6G1--42131--01 Cover, handle steering	Buy now
7	97095--06020 Bolt(7u8)	Buy now
8	6G1--42125--01 Bolt, friction adjusting	Buy now
9	6G1--42126--00 Piece, friction	Buy now
10	91490--16010 Pin, cotter	Buy now
11	664--42119--00 Grip, steering handle	Buy now
12	6H2--42137--00 Indicator, throttle	Buy now
13	90269--02M09 Rivet(6l5)	Buy now
14	6G1--42177--00 Rubber, handle	Buy now
15	90149--05M13 Screw, countersunk	Buy now

Steering




63V1100-2120

C6

Ref	Part	
16	92903--10600 Washer, plate	Buy now
17	90501--23215 Spring (655)	Buy now
18	90386--08032 Bushing (650)	Buy now
19	6G1--42138--01 Lever, throttle	Buy now
20	6E0--42159--02 Stay	Buy now
21	97885--05012 Screw, pan head (646)	Buy now
22	6L22630100 Throttle cable assembly	Buy now
23	63V--44111--02 Handle, gear shift	Buy now
24	90119--06M05 Bolt, with washer(6l2)	Buy now
25	90387--06M86 Collar	Buy now
26	90206--15M18 Washer, wave(6l2)	Buy now
27	6E0--44191--11 Indicator, shift	Buy now
28	63V--44124--02 Link, shift rod	Buy now
29	90202--06009 Washer plate 626427510000	Buy now
30	90468--18008 Clip 620436610000	Buy now

Steering




63V1100-2120

C6

Ref	Part	
31	65W--82575--01 Engine stop switch assembly	Buy now
32	682--82556--00 Lanyard, stop switch	Buy now
33	689--8257Y--00 Cap	Buy now
34	6E0--83627--41 Label, caution 7	Buy now
35	6E0--83627--51 Label, Caution 7	Buy now

Steering Guide




63V0100-5210

F1

Ref	Part	
1	63V--61350--00 Steering guide attachment kit AP	Buy now
2	90201--10M20 Washer, plate (663)	Buy now
3	90185--09M01 Nut, nylon (663)	Buy now
4	90170--09M03 Nut (689)	Buy now
5	90387--10M42 Coller (688)	Buy now
6	6E5--61355--00 Bolt	Buy now
7	90201--10M63 Washer, plate	Buy now
8	6E5--43145--01 Cap, clamp bracket	Buy now
9	93210--16275 O-ring	Buy now

Top Cowling




FWD
63V1300-2010

A4

Ref	Part	
2	63V--42615--00 Seal	Buy now
3	6G1--42651--02 Hook	Buy now
4	90266--04M04 Rivet(6e7)	Buy now
5	6L2--42647--00 Holder, clamp band	Buy now
8	9016306002 Screw, tapping	Buy now
9	63VW007011 Graphic set	Buy now
10	63V4267720 Graphic, rear 9.9F	Buy now
10	63W4267720 Graphic, front 15F	Buy now
10	69542677C0 Graphic, front 13.5A	Buy now
11	63V4267810 Graphic, rear 9.9F	Buy now
11	63V42678B0 Graphic Rear 13.5A	Buy now
11	63W4267810 Graphic, front 15F	Buy now

Upper Casing




63V0100-1170

E1

Ref	Part	
1	63V45111044D Casing, Upper S	Buy now
1	63V45111144D Casing, Upper L	Buy now
2	63V4512600 Plate, seal damper	Buy now
3	90157--06M06 Screw, pan head(6m7)	Buy now
4	93606--12019 Pin, dowel (614)	Buy now
5	63V--45113--A1 Gasket, upper casing	Buy now
6	97095--08030 Bolt, hexagon (fj1)	Buy now
7	92995--08600 Washer, plain (663)	Buy now
8	65F41131005B Manifold, ext. 1	Buy now
9	63V--41135--00 Gasket, exhaust manifold	Buy now
10	63V--41133--A1 Gasket, exhaust manifold 1	Buy now
11	97095--06020 Bolt(7u8)	Buy now
12	92995--06600 Washer, plain (646)	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.