



Yamaha 200FETO 2010

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	9
CARBURETOR	12
CONTROL	14
CRANKSHAFT & PISTON	18
CYLINDER & CRANKCASE 1	21
CYLINDER & CRANKCASE 2	23
ELECTRICAL 1	25
ELECTRICAL 2	27
FUEL 1	30
FUEL 2	33
GENERATOR	34
INTAKE	36
LOWER CASING & DRIVE 1	39
LOWER CASING & DRIVE 2	46
LOWER CASING & DRIVE 3	49
LOWER CASING & DRIVE 4	56
METER	58
OIL PUMP	60
OIL TANK	62
POWER TRIM & TILT ASSY 1	66
POWER TRIM & TILT ASSY 2	69
REMOTE CONTROL ASSY 1	72
REMOTE CONTROL ASSY 2	77
REMOTE CONTROL BOX	82
REPAIR KIT 1	83
REPAIR KIT 2	85
STARTING MOTOR	87
STEERING GUIDE ATTACHMENT 1 DIRECTION GUIDE ACCESSOIRE 1	89
STEERING GUIDE ATTACHMENT 2 DIRECTION GUIDE ACCESSOIRE 2	90
SWITCH & PANEL	91
TOP COWLING	93
UPPER CASING	95

Bottom Cowling




Ref	Part	
1	64D42711018D Cowling, bottom	Buy now
2	9048006M19 Grommet (6e3)	Buy now
3	61A4272700 Grommet	Buy now
3	64G4272700 Grommet	Buy now
4	6H44274800 Grommet	Buy now
5	64D42815008D Lever, clamp	Buy now
6	64D42816008D Lever, clamp	Buy now
7	64D4283500 Pin, set1	Buy now
8	9709506040 Bolt (682)	Buy now
9	9020106068 Washer,plate (6k8)	Buy now
10	9038615M73 Bush(6I2)	Buy now
11	9020615M18 Washer, wave(6I2)	Buy now
12	64D4281820 Lever, clamp	Buy now
13	64D4281830 Lever, clamp	Buy now
14	64D4314400 Hook, spring	Buy now

Bottom Cowling




Ref	Part	
15	9709006012 Bolt(gh1)	Buy now
16	9299006600 Washer, plain (646)	Buy now
17	9050616M34 Spring, tension(64d)	Buy now
18	6E54439100 Nipple, hose	Buy now
19	64D4272530 Grommet	Buy now
20	64D42738008D Plate, fitting	Buy now
21	64D4273810 Plate, fitting	Buy now
22	9709506016 Bolt, hexagon deep recess	Buy now
23	9299506600 Washer, plain (646)	Buy now
24	9048022M15 Grommet (6e5)	Buy now
25	9038708M37 Coller (6e5)	Buy now
26	9020108M54 Washer, plate (6e5)	Buy now
27	9707508035 Bolt(70w)	Buy now
28	9011908M22 Bolt, with washer	Buy now
29	6884272610 Grommet	Buy now

Bottom Cowling




Ref	Part	
30	6E58258800 Plate	Buy now
31	9709506020 Bolt(7u8)	Buy now
33	6R342741028D Apron	Buy now
36	64D4271700 Rubber Seal 2	Buy now
37	6R342771018D Apron	Buy now
40	6E54271610 Rubber seal 1	Buy now
41	68F4275300 Fastner AP	Buy now
42	9046420258 Clamp AP	Buy now
43	6G54279110 Mark 1	Buy now
44	6AH4279440 Label, warning (ge	Buy now
45	6AH4279450 Label, warning (ge	Buy now

Bracket 1




Ref	Part	
1	64E43111028D Bracket, clamp	Buy now
2	6G54525102 Anode	Buy now
3	6G54452600 Plate	Buy now
4	9709506030 Bolt(jf7)	Buy now
5	9299506100 Washer(6a1)	Buy now
6	6E58214800 Wire, lead 5	Buy now
7	9709506010 Bolt	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	64E43112028D Bracket, clamp	Buy now
11	9788506012 Screw, pan head(62j)	Buy now
13	9370006M03 Nipple, grease(6a1)	Buy now
14	6634511900 Cap, grease nipple AP	Buy now
15	64E4313101 Bolt, clamp bracket	Buy now
16	9709508020 Bolt, hexagon	Buy now
17	9299508100 Ybs67-8 washer, spring	Buy now

Bracket 1




Ref	Part	
18	9038625M31 Bushing (6e5)	Buy now
19	9020126M59 Washer, plate (6e5)	Buy now
20	9018522M11 Nut, self-locking	Buy now
21	9046511M10 Clamp	Buy now
22	64E43311108D Bracket, swivel L(20.3")	Buy now
22	64E43311208D Bracket, swivel X(25.3")	Buy now
23	9046508M63 Clamp(61u)	Buy now
26	6E58214700 Wire, lead 5 L(20.3")	Buy now
26	6E58214720 Wire, lead 5 X(25.3")	Buy now
27	6G54314400 Hook, spring	Buy now
29	6G54318102 Lever, tilt stop 1	Buy now
30	6G54318502 Lever, tilt stop 2	Buy now
31	9038610M16 Bushing (688)	Buy now
32	6G54314800 Collar, distance	Buy now
33	9024906M19 Pin(6e5)	Buy now

Bracket 1




Ref	Part	
34	9038710M05 Collar(6e5)	Buy now
35	9169030020 Pin, spring (6h4)	Buy now
36	9050614M24 Spring, tension(6e5)	Buy now
37	64E4312600 Pin, upper shock mount	Buy now
38	9038622M98 Bush(61u)	Buy now
39	9341022M11 Circlip(61u)	Buy now
40	9010112M03 Bolt (l:115mm)	Buy now
41	9020113M01 Washer, plate(6e5)	Buy now
42	9020112M05 Washer, plate(663)	Buy now
43	9538012600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	64E4313910 Cam, trim sender	Buy now
2	9015905059 Screw, with washer	Buy now
3	67H8367201 Trim sender	Buy now
4	9788506016 Screw, pan head(6b0)	Buy now
5	9046511M10 Clamp	Buy now
6	9321037MH7 O-ring(61u)	Buy now
7	9020240M47 Washer, plate(61a)	Buy now
8	61A4337600 Bolt, thrust receiver	Buy now
9	9578010300 Nut, nylon (6e5)	Buy now
10	6E542510A18D Steering bracket assembly L(20.3")	Buy now
10	6E542510B18D Steering bracket assembly X(25.3")	Buy now
11	9020138M60 Washer, plate (6e5)	Buy now
12	9038638M32 Bush(6e5)	Buy now
13	6G544551018D Housing, lower mount rubber	Buy now
14	9341037M04 Circlip (6e5)	Buy now

Bracket 2



Ref	Part	
15	6E54457500 Damper, lower mount rubber	Buy now
16	6G5445550094 Mount damper, lower side	Buy now
17	9020232M19 Washer, plate (6e5)	Buy now
18	9020116M55 Washer, plate (6e5)	Buy now
19	6E58214900 Wire, lead 3	Buy now
20	9010914M34 Bolt(6e5)	Buy now
21	9020115M58 Washer, plate (6e5)	Buy now
22	9538014800 Nut, crown (6e5)	Buy now
23	9299514600 Washer (6e5)	Buy now
24	6E54455201CA Housing, lower mount rubber	Buy now
25	9709510045 Bolt(64d)	Buy now
26	9299510100 Ybs67-10 washer, spring	Buy now
27	6E544553018D Cover, lower mount	Buy now
28	9050116M28 Spring (6e5)	Buy now
30	9017906066 Nut(663)	Buy now


Bracket 2



6N68100-G180


Ref	Part	
31	6G5445140094 Mount damper, upper side	Buy now
32	9020126M57 Washer, plate (6e5)	Buy now
33	9020226M18 Washer, plate (6e5)	Buy now
34	9020114M56 Washer, plate (6e5)	Buy now
35	9010912007 Bolt	Buy now
36	9018512M12 Nut, self-locking(6e5)	Buy now
37	6634457500 Damper, lower mount rubber	Buy now
38	6E5445110094 Cover, upper mount	Buy now

Carburetor



Ref	Part	
1	64E1430102 Carburetor assembly 1 (64e-03)	Buy now
2	64E1430202 Carburetor assembly 2 (64E-03)	Buy now
3	64E1430302 Carburetor assembly 3 (64E-03)	Buy now
4	64D1438401 Gasket, float chamber	Buy now
5	64D1438100 Body, float chamber	Buy now
6	6E51438502 Float	Buy now
7	6E51454600 Valve, needle	Buy now
8	6E51415900 Clip	Buy now
9	6E51438602 Pin, float	Buy now
10	64D1492F42 Jet, air slow	Buy now
11	61U1495900 Gasket	Buy now
12	64D1439400 Valve, drain	Buy now
13	64D1492E75 Jet, main #1,2	Buy now
14	64D1492E76 Jet, main #3	Buy now
15	64D1492E77 Jet, main #1,2	Buy now


Carburetor



64E4200-D060


Ref	Part	
16	64D1492E79 Jet, main #3	Buy now
17	6E51439801 Gasket	Buy now
18	61A1492H12 Jet, slow air (#60)	Buy now
19	61A1438301 Screw, drain	Buy now
20	6E51432100 Screw, throttle #2	Buy now
21	6J81433400 Spring, throttle #2	Buy now
22	6E51432801 Plug	Buy now
23	6E51497900 Gasket	Buy now
24	6E51432303 Screw, air adjusting	Buy now
25	6E51422300 Spring, air adjusting	Buy now
26	9798005116 Screw, pan head	Buy now
27	6E51452701 Plate	Buy now
28	9798005108 Screw, with washer	Buy now
29	6E51432400 Screw, flat head	Buy now
30	6J81495900 Gasket, drin screw	Buy now

Control




Ref	Part	
1	64D4853100 Bracket, remote control 1	Buy now
2	64D4853200 Bracket, remote control 2	Buy now
3	6E54853800 Clamp, cable	Buy now
4	9169030012 Pin, spring	Buy now
5	9709508020 Bolt, hexagon	Buy now
6	9299508100 Ybs67-8 washer, spring	Buy now
7	61H41632021S Lever, magneto control	Buy now
8	6E54834400 Cable end, remote control	Buy now
9	9046818008 Clip 620436610000	Buy now
10	6G541631011S Lever, magneto control	Buy now
11	6638551800 Joint, ball	Buy now
12	9015706013 Screw, pan head(697)	Buy now
13	9050116M12 Spring, compression (688)	Buy now
14	9530306600 Nut(661)	Buy now
15	6884419400 Cap	Buy now

Control




Ref	Part	
16	9701308045 Bolt	Buy now
17	9020108M23 Washer, plate (6e5)	Buy now
18	9038612089 Bushing(663)	Buy now
19	9038708M16 Collar	Buy now
20	9038622M13 Bushing (688)	Buy now
21	9020212092 Washer, plate(663)	Buy now
22	9020108M13 Washer plate (682)	Buy now
23	9050829M12 Spring (6e5)	Buy now
24	6G54163601 Rod, magneto control	Buy now
25	9538005600 Nut, hexagon (663)	Buy now
26	6624123701 Joint, link	Buy now
27	9015706M00 Screw, pan head(6h4)	Buy now
30	6G54121101 Link, accel	Buy now
33	6G54121300 Cam, accel	Buy now
34	9038706M29 Collar (6a0)	Buy now

Control




Ref	Part	
35	9020610M04 Washer, wave (676)	Buy now
36	9709506025 Bolt	Buy now
37	6E5441170094 Bracket	Buy now
38	9011906MA2 Bolt, with washer	Buy now
39	68F4412100 Lever, shift rod	Buy now
40	6E54412200 Bushing, shift rod lever	Buy now
41	9020208M20 Washer, plate (6e5)	Buy now
44	9038606M12 Bushing (688)	Buy now
45	6E5441180194 Bracket 2	Buy now
46	9701308030 Bolt	Buy now
47	9290308600 Washer, plain (663)	Buy now
48	9350104M02 Ball (697)	Buy now
49	9050112082 Spring 6484411600	Buy now
50	6484271500 Bushing 2	Buy now
51	9370006M03 Nipple, grease(6a1)	Buy now

Control




Ref	Part	
52	6E54412003 Handle gear shift assembly L(20.3")	Buy now
52	6E54412023 Handle gear shift assembly X(25.3")	Buy now
53	9321009165 O-ring	Buy now
54	9038616M66 Bush(6e5)	Buy now
55	9020216061 Washer, plate(663)	Buy now
56	9341016006 Circlip	Buy now

Crankshaft & Piston




Ref	Part	
1	6G51141102 Crankshaft	Buy now
2	6E51144700 Seal, ring	Buy now
3	6R3151630015 Housing, bearing 1	Buy now
4	93311940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	9310240M14 Oil seal(61a)	Buy now
6	9321104001 O-ring	Buy now
7	9011906MA2 Bolt, with washer	Buy now
8	93310954U1 Bearing, cylindrical(64c)	Buy now
9	6R31153600 Gear, drive	Buy now
10	93306208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
11	9341040M03 Circlip(n02)	Buy now
12	6G5153590094 Housing, oil seal	Buy now
13	9310235M13 Oil seal (6e5)	Buy now
14	9310122M15 Oil seal (6e5)	Buy now
15	9321074M35 O-ring (6e5)	Buy now

Crankshaft & Piston




Ref	Part	
17	64D116310290 Piston (std)	Buy now
17	64D1163502 Piston (0.25mm o/s) AP	Buy now
17	64D1163602 Piston (0.50mm o/s) AP	Buy now
18	64D1160302 Piston ring set (std)	Buy now
18	64D1160402 Piston ring set (0.25mm o/s) AP	Buy now
18	64D1160502 Piston ring set (0.50mm o/s) AP	Buy now
19	64D116420290 Piston 2 (std)	Buy now
19	64D1164502 Piston 2 (0.25mm o/s) AP	Buy now
19	64D1164602 Piston 2 (0.50mm o/s) AP	Buy now
21	6R51163310 Pin, piston	Buy now
22	6R51163410 Clip, piston pin	Buy now
23	6R51165010 Connecting kit	Buy now
24	9010908022 Bolt	Buy now
25	9331032337 Bearing	Buy now
26	9020123M01 Washer, plate(6g6)	Buy now

Crankshaft & Piston




Ref	Part	
27	93310836V2 Brg, cyl-cal roller (6e5)	Buy now

Cylinder & Crankcase 1




Ref	Part	
1	64EW0090151S Crank Cylinder assembly	Buy now
2	64E15100011S Crankcase assembly	Buy now
3	6241137900 Valve, check	Buy now
4	9038406M07 Bush, bimetal formed(6r3)	Buy now
5	9038414M09 Bush, bimetal formed(6r3)	Buy now
6	6631151801 Lock, bearing	Buy now
7	6461137001 Check valve assembly	Buy now
8	9034014M00 Plug, straight screw(62y)	Buy now
9	9043014115 Gasket (663)	Buy now
10	9360812063 Pin, dowel (626)	Buy now
11	9010510M20 Bolt (6e5)	Buy now
12	9011908M94 Bolt, with washer	Buy now
13	9011608026 Bolt, stud (6e5)	Buy now
14	6E51132500 Anode	Buy now
15	9878004015 Screw, flat head(ga5)	Buy now

Cylinder & Crankcase 1




Ref	Part	
16	67H1111901 Hanger, engine	Buy now
17	9011908MA3 Bolt, with washer	Buy now
18	6K711371011S Cover	Buy now
19	6E511381A2 Gasket 1	Buy now
20	9011906MA2 Bolt, with washer	Buy now
21	6E542761001S Stopper	Buy now
22	6E542762001S Stopper	Buy now
23	68F4453301 Damper, upper mount rubber	Buy now

Cylinder & Crankcase 2




Ref	Part	
1	64E11111001S Head, cylinder 1	Buy now
2	6G511181A3 Gasket, cylinder head 1	Buy now
3	9011908MA8 Bolt, with washer	Buy now
4	6G511191001S Cover, cylinder head 1	Buy now
5	6G511193A2 Gasket, head cover 1	Buy now
6	9011906MA4 Bolt, with washer	Buy now
7	6E51241130 Thermostat	Buy now
8	6881241200 Seal, thermostat	Buy now
9	68812413001S Cover, thermostat	Buy now
10	68812414A1 Gasket, cover	Buy now
11	9011906MA6 Bolt, with washer	Buy now
12	64D41111001S Inner cover, exhaust	Buy now
13	6G541112A1 Gasket, exhaust inner cover	Buy now
14	6G541114A0 Gasket, exhaust inner cover	Buy now
15	6R341113001S Outer cover, exhaust	Buy now

Cylinder & Crankcase 2



Ref	Part	
16	6502437800 Pipe, joint 2	Buy now
17	9011906MA5 Bolt, with washer	Buy now
18	9044509097 Hose (I1500)	Buy now
19	60H1241600 Valve, pressure control	Buy now
20	9050116M11 Spring, compression (688)	Buy now
21	9048020M05 Grommet (688)	Buy now
22	6G511382A1 Gasket 2	Buy now
23	6G511372001S Cover, bypass 2	Buy now
24	9759506420 Bolt(7u8)	Buy now
25	6G51257600 Hose 1	Buy now
26	9046513M18 Clamp	Buy now
27	9046506M86 Clamp	Buy now
28	9470200247 Plug, spark (br8hs-10)	Buy now


Electrical 1




65N1300-2120

Ref	Part	
1	6R38196010 Rectifier & regulator assembly	Buy now
2	6R38215000 Fuse holder assembly	Buy now
3	7058215100 Fuse (30a)	Buy now
4	6G58215200 Holder, fuse	Buy now
5	64D8194200 Cover	Buy now
6	9038706M66 Collar (6h4)	Buy now
7	9701306055 Bolt(64d)	Buy now
8	9290306600 Washer, plain (646)	Buy now
9	9709506012 Bolt(gh1)	Buy now
10	9299506600 Washer, plain (646)	Buy now
11	9046506M88 Clamp	Buy now
12	9046415M11 Clamp (3y2)	Buy now
15	64D8554001 C.d.i. unit assembly	Buy now
16	9788006020 Screw pan head	Buy now
17	9299006600 Washer, plain (646)	Buy now


Electrical 1



65N1300-2120


Ref	Part	
18	9046505M87 Clamp	Buy now
19	6R385542031S Bracket	Buy now
20	9038706M03 Collar (676)	Buy now
21	9048009M12 Grommet (6a0)	Buy now
22	9011906M61 Bolt, with washer	Buy now
23	64D8553700 Cover	Buy now
24	9015906M11 Screw, with washer(6l2)	Buy now
25	6R38259E00 Switch assembly	Buy now
26	6628251900 Wire, earth lead	Buy now
27	6R38251900 Wire, earth lead	Buy now
30	60H85711A0 Mark, caution	Buy now

Electrical 2



Ref	Part	
1	6R38557001 Ignition coil assembly	Buy now
2	6E38237021 Plug cap assembly	Buy now
3	9709506020 Bolt(7u8)	Buy now
4	9299506600 Washer, plain (646)	Buy now
5	9048025161 Grommet(656)	Buy now
6	6E58253110 Wire, lead	Buy now
7	64D8259020 Wire harness assembly	Buy now
8	6638215100 Fuse	Buy now
9	7058215100 Fuse (30a)	Buy now
10	6888259400 Clamp	Buy now
11	9046505M87 Clamp	Buy now
12	9046508M89 Clamp	Buy now
13	9709506012 Bolt(gh1)	Buy now
15	6K78258800 Plate	Buy now
18	6888256010 Thermo switch assembly	Buy now


Electrical 2



64E8700-G180


Ref	Part	
19	61A8579000 Thermosensor assembly	Buy now
20	9299010600 Washer, plate	Buy now
21	9046506M86 Clamp	Buy now
24	64D8611001 Solenoid	Buy now
25	9709506016 Bolt, hexagon deep recess	Buy now
27	9321003261 O-ring (663)	Buy now
28	6R38256300 Trim & tilt switch assembly	Buy now
29	6E58258700 Gasket	Buy now
30	6R38361400 Bracket	Buy now
32	61A8194100 Starter relay assembly	Buy now
33	6898195210 Holder, starter relay	Buy now
34	6E58195000 Relay assembly	Buy now
35	6E58195A00 Relay assembly	Buy now
36	6G58714910 Connector	Buy now
37	6G58211900 Cover, lead wire	Buy now

Electrical 2




Ref	Part	
38	6E58211600 Wire, minus lead	Buy now
39	6G58194811 Bracket	Buy now
42	6E98355770 Tube	Buy now
43	9046513M18 Clamp	Buy now
44	6R38210502 Battery cable	Buy now
45	6E58211701 Wire, lead	Buy now
46	6E58258800 Plate	Buy now
49	9046512M25 Clamp (6e5)	Buy now
52	6G58215200 Holder, fuse	Buy now

Fuel 1




Ref	Part	
1	6R32431320 Pipe 3	Buy now
2	6R32437700 Pipe, joint 3	Buy now
3	9046511M10 Clamp	Buy now
5	6R32456000 Filter assembly	Buy now
6	6R32456300 Element, filter	Buy now
7	61N2452100 Cup, filter	Buy now
8	9321032738 O-ring(1wg)	Buy now
9	6482456602 Bracket, filter	Buy now
10	9701306014 Bolt(gj3)	Buy now
11	9290306100 Washer(6a1)	Buy now
12	9538008600 Nut (661)	Buy now
13	6G52431400 Pipe 4	Buy now
16	6E52437800 Pipe, joint 3	Buy now
17	6G52431500 Pipe 5	Buy now
18	6E52431500 Pipe 5	Buy now

Fuel 1




Ref	Part	
20	6E52441004 Fuel pump assembly	Buy now
21	6E52444401 Screw	Buy now
22	6E52441301 Body 2	Buy now
23	6E52447101 Diaphragm	Buy now
24	6E52443501 Gasket, body 2	Buy now
25	6E52441101 Diaphragm	Buy now
26	6482442400 Seat, spring	Buy now
27	6E52442300 Spring, diaphragm	Buy now
28	6E52441211 Body 1	Buy now
29	6A02442101 Valve, check	Buy now
30	6A01432500 Screw, pan head	Buy now
31	9538003600 Nut (6g8)	Buy now
32	6E52449200 Bush, fuel pump	Buy now
33	6E52448600 O-ring	Buy now
34	65024431A0 Gasket, fuel pump	Buy now

Fuel 1



Ref	Part	
35	9759506550 Bolt, hexagon w/w deep recess	Buy now
36	6G52431610 Pipe 6	Buy now
39	6G52437600 Pipe, joint 1	Buy now
40	6G52437700 Pipe, joint 2	Buy now
41	6G52431701 Pipe 7	Buy now
42	6G52431810 Hose (I90)	Buy now
43	6G52431910 Pipe 9	Buy now
46	9044615M07 Hose(6g4)	Buy now


Fuel 2




60X1300-3150

Ref	Part	
1	6YK2430742 Fuel pipe comp. 2 AP	Buy now
2	9045010M07 Hose, clamp AP	Buy now


Generator



64EA300-J110

Ref	Part	
1	64D8555002 Rotor assembly	Buy now
2	6R38551000 Stator assembly	Buy now
3	64D8558000 Coil, pulser	Buy now
4	9046506M86 Clamp	Buy now
5	6R58589501 Crank position sender	Buy now
6	9788505012 Screw, pan head (646)	Buy now
7	9046415M11 Clamp (3y2)	Buy now
8	9028005015 Key, woodruff	Buy now
9	9020121M18 Washer, plate (663)	Buy now
10	9017020137 Nut, hexagon(663)	Buy now
11	9701306070 Bolt(62j)	Buy now
12	9290306600 Washer, plain (646)	Buy now
13	6884161100 Retainer, magneto base 1	Buy now
14	6884161200 Retainer, magneto base 2	Buy now
15	9788006018 Screw, pan head(6e5)	Buy now


Generator



64EA300-J110


Ref	Part	
16	6E58133200 Plate, timing	Buy now
17	9798506210 Screw pan head	Buy now
18	64D8133710 Cover, flywheel	Buy now
19	6G58231700 Damper	Buy now
20	6638231701 Damper, ignition coil	Buy now
21	6G51448802 Label, caution	Buy now
22	6AH8199440 Label, safety	Buy now
23	6AH8199450 Label, safety	Buy now
24	6AH8199540 Label, warning	Buy now
25	6AH8199550 Label, warning	Buy now
26	6AG8199600 Mark	Buy now

Intake




Ref	Part	
1	6E51361000 Reed valve assembly	Buy now
2	6E5W000400 Reed set	Buy now
3	6E513621A1 Gasket, valve seat	Buy now
4	9788005016 Screw, pan head(6b0)	Buy now
5	9299005600 Washer, plain (646)	Buy now
6	6G513641111S Manifold 1	Buy now
7	6E51355201 Nozzle	Buy now
8	6241448500 Pipe, joint	Buy now
9	6E51137001 Check valve assembly	Buy now
10	9044507M28 Hose (I200)	Buy now
11	9044507M45 Hose (I390)	Buy now
12	9044507M46 Hose (I390)	Buy now
13	9044507M09 Hose (I390)	Buy now
14	9044507M59 Hose (I770)	Buy now
15	9046407M05 Clamp (6g5)	Buy now

Intake




Ref	Part	
16	9046510M91 Clamp	Buy now
17	9011606M30 Bolt, stud(6e5)	Buy now
18	6G513645A2 Gasket, manifold 1	Buy now
19	9011906MA3 Bolt, with washer	Buy now
20	6E514198A2 Gasket	Buy now
21	9017906M28 Nut(63v)	Buy now
22	6G54121701 Rod, accel. lever	Buy now
23	6E54125601 Rod, choke 1	Buy now
24	6614126202 Joint, choke lever	Buy now
25	6R34127100 Knob, choke	Buy now
26	6894127300 Grommet	Buy now
27	6R31444002 Silencer assembly, intake	Buy now
28	6G51441K00 Emblem	Buy now
29	9044507MA3 Hose (I200)	Buy now
30	6K71448300 Gasket	Buy now

Intake




Ref	Part	
31	9015906M14 Screw, with washer(6r3)	Buy now

Lower Casing & Drive 1




Ref	Part	
1	64E45300028D Lower unit assembly L(20.3"),RH	Buy now
1	64E45300228D Lower unit assembly X(25.3"),RH	Buy now
2	6J945301058D Casing, lower	Buy now
3	93311928U5 Bearing, needle (6g5)	Buy now
4	93332000V3 Bearing, taper roller (6g5)	Buy now
5	6G54556701 Shim (t:0.10mm) UR	Buy now
5	6G54556710 Shim (t:0.12mm) UR	Buy now
5	6G54556720 Shim (t:0.15mm) UR	Buy now
5	6G54556730 Shim (t:0.18mm) UR	Buy now
5	6G54556740 Shim (t:0.30mm) UR	Buy now
5	6G54556750 Shim (t:0.40mm) UR	Buy now
5	6G54556760 Shim (t:0.50mm) UR	Buy now
6	9034008002 Plug, straight screw	Buy now
7	6884534110 Plug, drain	Buy now
8	9043008020 Gasket	Buy now

Lower Casing & Drive 1




Ref	Part	
9	9020622M19 Washer, wave(61a)	Buy now
10	9020122M01 Washer, plate(61a)	Buy now
11	61A4552700 Collar, drive shaft	Buy now
12	61A4553800 Spacer, 1	Buy now
13	6G54553601 Sleeve, drive shaft	Buy now
14	64D453760094 Guide, seal damper X(25.3")	Buy now
14	663453760094 Guide, seal damper L(20.3")	Buy now
15	6884537500 Damper, seal 2	Buy now
16	6E54537800 Nipple, hose	Buy now
17	9044507ME8 Hose (I250) L(20.3")	Buy now
17	9044507ME9 Hose (I250) X(25.3")	Buy now
18	6E58355810 End, nipple	Buy now
19	6E54532100 Plate	Buy now
20	9321058144 O-ring(47x)	Buy now
21	9310609014 Oil seal	Buy now

Lower Casing & Drive 1




Ref	Part	
22	9011906M10 Bolt, with washer	Buy now
23	6G54415002 Shift cam assembly	Buy now
24	9900108600 Circlip(2r6)	Buy now
25	9050111M10 Spring, compression (663)	Buy now
26	61A4431101 Housing, water pump	Buy now
27	61A4432202 Insert, cartridge	Buy now
28	9321086M38 O-ring (6e5)	Buy now
29	9321037160 O-ring (6g8)	Buy now
30	6E54436500 Damper, water seal 1	Buy now
31	6E54431200 Cover, water pump housing	Buy now
32	6E54435201 Impeller	Buy now
33	9028004M05 Key, woodruff (6e5)	Buy now
34	6G54432300 Outer plate, cartridge	Buy now
35	6E544315A0 Gasket,water pump	Buy now
36	9360612019 Pin, dowel (614)	Buy now

Lower Casing & Drive 1




Ref	Part	
37	9011908M14 Bolt, with washer	Buy now
38	6E545331009S Housing, bearing	Buy now
39	9310128M16 Oil seal (6e5)	Buy now
40	93317330U2 Bearing, cylindrical(6k0)	Buy now
41	6E54558701 Shim (t:0.10mm) UR	Buy now
41	6E54558710 Shim (t:0.12mm) UR	Buy now
41	6E54558720 Shim (t:0.15mm) UR	Buy now
41	6E54558730 Shim (t:0.18mm) UR	Buy now
41	6E54558740 Shim (t:0.30mm) UR	Buy now
41	6E54558750 Shim (t:0.40mm) UR	Buy now
41	6E54558760 Shim (t:0.50mm) UR	Buy now
42	93341930V2 Bearing, thrust(64d)	Buy now
43	9321055M14 O-ring (70e)	Buy now
44	6E54534400 Cover, oil seal	Buy now
45	9709508025 Bolt (62g)	Buy now

Lower Casing & Drive 1




Ref	Part	
46	9299508600 Washer, plain (663)	Buy now
47	6G54550101 Drive shaft comp. L(20.3")	Buy now
47	6G54550121 Drive shaft comp. X(25.3")	Buy now
48	6G54555110 Pinion	Buy now
49	9017016M01 Nut, hexagon (688)	Buy now
50	6G54556010 Gear	Buy now
51	93315425V3 Bearing, needle (6g5)	Buy now
52	6J94561101 Shaft, propeller	Buy now
53	6E54564103 Shifter	Buy now
54	6E54563401 Slide, shift	Buy now
55	9050116M37 Spring (6g5)	Buy now
56	9350732009 Ball (12r)	Buy now
57	9351132017 Ball (498)	Buy now
58	9350316003 Ball	Buy now
59	9025008M07 Pin, straight (6g5)	Buy now

Lower Casing & Drive 1




Ref	Part	
60	6G54563110 Clutch, dog	Buy now
61	6E54563301 Ring, cross pin	Buy now
62	6J94533200CA Housing, bearing	Buy now
63	93306209U0 Bearing (6g5)	Buy now
64	6G54557102 Gear	Buy now
65	6G54557610 Washer, thrust 2	Buy now
66	9331543061 Bearing	Buy now
67	9310130M17 Oil seal (6e5)	Buy now
68	9321097M55 O-ring (6g5)	Buy now
69	6G54557702 Shim (t:0.10mm) UR	Buy now
69	6G54557710 Shim (t:0.12mm) UR	Buy now
69	6G54557720 Shim (t:0.15mm) UR	Buy now
69	6G54557730 Shim (t:0.18mm) UR	Buy now
69	6G54557740 Shim (t:0.30mm) UR	Buy now
69	6G54557750 Shim (t:0.40mm) UR	Buy now

Lower Casing & Drive 1




Ref	Part	
69	6G54557760 Shim (t:0.50mm) UR	Buy now
70	9020130M92 Washer (6g5)	Buy now
71	9028204M00 Key, straight(6g5)	Buy now
72	6G54538301 Washer, claw	Buy now
73	6G54538400 Nut	Buy now

Lower Casing & Drive 2




Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	6E54436100 Tube, water L(20.3")	Buy now
2	6E54436120 Tube, water X(25.3")	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	9360812M05 Pin, dowel b (6e5)	Buy now
5	9011910053 Bolt, hexagon w/w deep recess	Buy now
6	9011910M89 Bolt, with washer	Buy now
7	6J94521400 Cover, water inlet	Buy now
8	6J94521500 Cover, water inlet	Buy now
9	9015205M08 Screw, countersunk	Buy now
10	9018505002 Nut nylon (sus)(ex4)	Buy now
11	6J94537101 Tab-trim	Buy now
12	9010510M00 Bolt, hexagon (663)	Buy now
13	9044507M33 Hose (L1080)	Buy now
14	6E58355800 End, nipple	Buy now

Lower Casing & Drive 2



Ref	Part	
15	9046511M10 Clamp	Buy now
16	6E54598701 Spacer 1	Buy now
17	6884599701 Spacer 2	Buy now
18	9299018200 Washer (6e5)	Buy now
19	9017118M04 Nut, castle (6e5)	Buy now
20	9149040030 Pin, cotter (663)	Buy now
21	6G5459410098 Propeller (3x15-1/4x15"-m) UR	Buy now
21	6G5459430198 Propeller (3x13-3/4"x21"-m) UR	Buy now
21	6G5459450198 Propeller (3x14"x19"-m) UR	Buy now
21	6G5459470198 Propeller (3x14-1/2"x17"-m) UR	Buy now
21	6G5459490098 Propeller (3x13-1/2"x23"-m) UR	Buy now
21	6G5459520098 Propeller (3x14-5/8"x16"-m) UR	Buy now
21	6G5459300098 Propeller (ss 3x13-3/8"x25"-m) UR	Buy now
21	6G5459320098 Propeller (3x15-3/4"x13"-m) UR	Buy now
21	6G5459700298 Propeller (3x15-1/4 x15 -m) UR	Buy now


Lower Casing & Drive 2



68F9700-J290


Ref	Part	
21	6G5459720298 Propeller (3x13-3/4 x21 -m) UR	Buy now
21	6G5459740398 Propeller (3x13-3/4"x19"-m2) UR	Buy now
21	6G5459760198 Propeller (3x13-3/8"x23"-m) UR	Buy now
21	6G5459780398 Propeller (3x13-3/4"x17"-m2) UR	Buy now
21	6R445970A1 Propeller (3X15-1/4"X19"-M) UR	Buy now
21	6R445972A0 Propeller (3X14-7/8"X21"-M) UR	Buy now
21	6R445974A0 Propeller (3X14-1/2"X23"-M) UR	Buy now
21	6R445976A0 Propeller (3X14-1/2"X15"-M) UR	Buy now
21	6R445978A0 Propeller (3X15-1/4"X17"-M) UR	Buy now

Lower Casing & Drive 3




Ref	Part	
1	64H45300018D Lower Unit assembly L(20.3"),LH	Buy now
2	6J945301058D Casing, lower	Buy now
3	93311928U5 Bearing, needle (6g5)	Buy now
4	93390000U2 Bearing(6k0)	Buy now
5	93341465U4 Bearing, thrust (6k0)	Buy now
6	6G54556701 Shim (t:0.10mm) UR	Buy now
6	6G54556710 Shim (t:0.12mm) UR	Buy now
6	6G54556720 Shim (t:0.15mm) UR	Buy now
6	6G54556730 Shim (t:0.18mm) UR	Buy now
6	6G54556740 Shim (t:0.30mm) UR	Buy now
6	6G54556750 Shim (t:0.40mm) UR	Buy now
6	6G54556760 Shim (t:0.50mm) UR	Buy now
7	9034008002 Plug, straight screw	Buy now
8	6884534110 Plug, drain	Buy now
9	9043008020 Gasket	Buy now

Lower Casing & Drive 3




Ref	Part	
10	9020622M19 Washer, wave(61a)	Buy now
11	9020122M01 Washer, plate(61a)	Buy now
12	61A4552700 Collar, drive shaft	Buy now
13	61A4553800 Spacer, 1	Buy now
14	6G54553601 Sleeve, drive shaft	Buy now
15	663453760094 Guide, seal damper L(20.3")	Buy now
16	6884537500 Damper, seal 2	Buy now
17	6J84537800 Nipple, hose (plug)	Buy now
18	6E54532100 Plate	Buy now
19	9321058144 O-ring(47x)	Buy now
20	9310609014 Oil seal	Buy now
21	9011906M10 Bolt, with washer	Buy now
22	6K14415001 Shift cam assembly	Buy now
23	9900108600 Circlip(2r6)	Buy now
24	9050111M10 Spring, compression (663)	Buy now

Lower Casing & Drive 3




Ref	Part	
25	61A4431101 Housing, water pump	Buy now
26	61A4432202 Insert, cartridge	Buy now
27	9321086M38 O-ring (6e5)	Buy now
28	9321037160 O-ring (6g8)	Buy now
29	6E54436500 Damper, water seal 1	Buy now
30	6E54431200 Cover, water pump housing	Buy now
31	6E54435201 Impeller	Buy now
32	9028004M05 Key, woodruff (6e5)	Buy now
33	6G54432300 Outer plate, cartridge	Buy now
34	6E544315A0 Gasket, water pump	Buy now
35	9360612019 Pin, dowel (614)	Buy now
36	9011908M14 Bolt, with washer	Buy now
37	6E545331009S Housing, bearing	Buy now
38	9310128M16 Oil seal (6e5)	Buy now
39	93317330U2 Bearing, cylindrical(6k0)	Buy now

Lower Casing & Drive 3




Ref	Part	
40	6E54558701 Shim (t:0.10mm) UR	Buy now
40	6E54558710 Shim (t:0.12mm) UR	Buy now
40	6E54558720 Shim (t:0.15mm) UR	Buy now
40	6E54558730 Shim (t:0.18mm) UR	Buy now
40	6E54558740 Shim (t:0.30mm) UR	Buy now
40	6E54558750 Shim (t:0.40mm) UR	Buy now
40	6E54558760 Shim (t:0.50mm) UR	Buy now
41	93341930V2 Bearing, thrust(64d)	Buy now
42	9321055M14 O-ring (70e)	Buy now
43	6E54534400 Cover, oil seal	Buy now
44	9709508025 Bolt (62g)	Buy now
45	9299508600 Washer, plain (663)	Buy now
46	6G54550101 Drive shaft comp. L(20.3")	Buy now
47	6G54555110 Pinion	Buy now
48	9017016M01 Nut, hexagon (688)	Buy now

Lower Casing & Drive 3




Ref	Part	
49	6K14556001 Gear	Buy now
50	93315425V3 Bearing, needle (6g5)	Buy now
51	6K14561110 Shaft, propeller	Buy now
52	6K14564101 Shifter	Buy now
53	6E54563401 Slide, shift	Buy now
54	9050116M37 Spring (6g5)	Buy now
55	9350732009 Ball (12r)	Buy now
56	9351132017 Ball (498)	Buy now
57	9350316003 Ball	Buy now
58	9025008M07 Pin, straight (6g5)	Buy now
59	6G54563110 Clutch, dog	Buy now
60	6E54563301 Ring, cross pin	Buy now
61	6K14533201CA Housing, bearing	Buy now
62	9333200048 Bearing(6k0)	Buy now
63	6K14557020 Gear	Buy now

Lower Casing & Drive 3




Ref	Part	
64	6K14557600 Washer, thrust	Buy now
65	93341440U5 Bearing, thrust (6k0)	Buy now
66	9331543061 Bearing	Buy now
67	9310130M17 Oil seal (6e5)	Buy now
68	9321097M55 O-ring (6g5)	Buy now
69	6G54557702 Shim (t:0.10mm) UR	Buy now
69	6G54557710 Shim (t:0.12mm) UR	Buy now
69	6G54557720 Shim (t:0.15mm) UR	Buy now
69	6G54557730 Shim (t:0.18mm) UR	Buy now
69	6G54557740 Shim (t:0.30mm) UR	Buy now
69	6G54557750 Shim (t:0.40mm) UR	Buy now
69	6G54557760 Shim (t:0.50mm) UR	Buy now
70	9028204M00 Key, straight(6g5)	Buy now
71	6G54538301 Washer, claw	Buy now
72	6G54538400 Nut	Buy now

Lower Casing & Drive 3




Ref	Part	
73	6K14557801 Shim (t:0.10mm) UR	Buy now
73	6K14557810 Shim (t:0.12mm) UR	Buy now
73	6K14557820 Shim (t:0.15mm) UR	Buy now
73	6K14557830 Shim (t:0.18mm) UR	Buy now
73	6K14557840 Shim (t:0.30mm) UR	Buy now
73	6K14557850 Shim (t:0.40mm) UR	Buy now
73	6K14557860 Shim (t:0.50mm) UR	Buy now

Lower Casing & Drive 4




Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	6E54436100 Tube, water L(20.3")	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	9360812M05 Pin, dowel b (6e5)	Buy now
5	9011910053 Bolt, hexagon w/w deep recess	Buy now
6	9011910M89 Bolt, with washer	Buy now
7	6J94521400 Cover, water inlet	Buy now
8	6J94521500 Cover, water inlet	Buy now
9	9015205M08 Screw, countersunk	Buy now
10	9018505002 Nut nylon (sus)(ex4)	Buy now
11	6K14537102 Tab-trim	Buy now
12	9010510M00 Bolt, hexagon (663)	Buy now
13	6E54598701 Spacer 1	Buy now
14	6884599701 Spacer 2	Buy now
15	9299018200 Washer (6e5)	Buy now

Lower Casing & Drive 4




Ref	Part	
16	9017118M04 Nut, castle (6e5)	Buy now
17	9149040030 Pin, cotter (663)	Buy now
18	6K1459700198 Propeller (3x15-1/4"x15"-ml) UR	Buy now
18	6K1459720198 Propeller (3x13-3/4"x21"-ml) UR	Buy now
18	6K1459740298 Propeller (3x13-3/4"x19"-ml1) UR	Buy now
18	6K1459780298 Propeller (3x13-3/4"x17"-ml1) UR	Buy now
18	6R145970A1 Propeller (3X15-1/4"X19"-MI) UR	Buy now
18	6R145972A0 Propeller (3X14-7/8"X21"-MI) UR	Buy now
18	6R145974A0 Propeller (3X14-1/2"X23"-MI) UR	Buy now
18	6R145976A0 Propeller (3X15-1/4"X15"-MI) UR	Buy now
18	6R145978A0 Propeller (3X15-1/4"x17"-MI) UR	Buy now

Meter




Ref	Part	
1	6Y58350T90 Tachometer assembly AP	Buy now
2	9E45004533 Housing, f-4-w(5pcs) F-4-W	Buy now
3	9299004100 Ybs67-4 washer, spring	Buy now
4	9538004600 Nut,hex	Buy now
5	6Y58355XT1 Bracket, meter 1	Buy now
6	6Y583570S5 Speedometer assembly AP	Buy now
9	6Y583533T2 Grommet	Buy now
11	6Y587122S0 Cord assembly 1 AP	Buy now
12	6Y58355300 Wire, lead (l=2.5m) AP	Buy now
12	6Y583553M0 Wire, lead (l=2.5m) AP	Buy now
13	1E68215100 Fuse (10a) FOR 6Y5-83553-M0	Buy now
14	6Y58211700 Wire, lead AP	Buy now
15	6Y58365330 Wire, lead AP 4P,8M	Buy now
15	6Y58365340 Wire, lead AP 4P,9M	Buy now
16	6Y58355710 Tube (8m) AP	Buy now

Meter




Ref	Part	
17	9046511M10 Clamp AP	Buy now
18	6Y58350F00 Fuel meter movement assembly AP	Buy now
23	6Y583553F1 Wire, lead AP	Buy now
24	6Y58575202 Sender unit assembly, fuel meter AP	Buy now
25	9015806003 Screw, wood AP	Buy now
27	7038253100 Wire, lead AP	Buy now

Oil Pump




Ref	Part	
1	6E51427601 Lever	Buy now
2	9169030016 Pin, spring	Buy now
3	6R51320012 Oil injection pump assembly	Buy now
4	6R31347100 Screw	Buy now
5	6L21347500 Gasket, breather bolt	Buy now
6	9321019M82 O-ring(6j8)	Buy now
7	9010906M40 Bolt(6h0)	Buy now
8	6R31341600 Pipe, oil 1	Buy now
9	9046511M10 Clamp	Buy now
10	9044507M72 Hose (l390)	Buy now
11	9044507M89 Hose (l390)	Buy now
12	9044507M83 Hose (l200)	Buy now
13	6R31318310 Valve, check	Buy now
14	9044507M87 Hose(62t)	Buy now
15	9044507M96 Hose(62t)	Buy now

Oil Pump




Ref	Part	
16	9046407M05 Clamp (6g5)	Buy now
17	9046807M02 Clip (6e5)	Buy now
18	9046510M91 Clamp	Buy now
19	6R31153700 Gear, driven	Buy now
20	6R31311700 Collar, distance	Buy now
21	9321013M04 93210-13m04	Buy now
22	9020208M44 Washer, plate(6r3)	Buy now
23	6R34124100 Rod, link	Buy now
24	6H14123700 Joint, link	Buy now
25	9538005600 Nut, hexagon (663)	Buy now
26	6R54123700 Joint, link	Buy now
27	9046805M03 Clip(6j8)	Buy now
28	9020205088 Washer, plate (666)	Buy now

Oil Tank




Ref	Part	
1	61A2170820 Sub oil tank assembly.	Buy now
2	6E52173320 Sub tank, oil (10.5l)	Buy now
3	6E52177003 Oil tank cap assembly	Buy now
4	6E52432200 Pipe 11	Buy now
5	9046511M10 Clamp	Buy now
6	6462425102 Strainer 1	Buy now
7	6E52431901 Pipe, oil	Buy now
9	6E58190001 Oil feed pump assembly	Buy now
10	6E58192200 Grommet	Buy now
11	6E52432101 Pipe 10	Buy now
12	6E52437900 Pipe, joint 4	Buy now
13	9044511M26 Hose (l8000)	Buy now
15	6E58572006 Oil level gauge assembly	Buy now
16	6R38572180 Wire, lead (4P)	Buy now
17	9046513M11 Clamp (6e5)	Buy now

Oil Tank




Ref	Part	
18	6E5217340133 Holder, oil sub tank	Buy now
19	6E5217980133 Bracket, damper	Buy now
20	6E52174600 Damper	Buy now
21	9708006100 Bolt, hexagon	Buy now
22	9299006600 Washer, plain (646)	Buy now
23	9538006600 Nut(661)	Buy now
24	6E52175005 Oil tank assembly	Buy now
25	6E51344800 Cap, oil tank	Buy now
27	6R38573004 Oil level gauge assembly	Buy now
28	6E51341100 Strainer, oil	Buy now
29	6E51341400 Gasket, strainer cover	Buy now
30	9044505M02 Hose (I700)	Buy now
31	6A08231700 Damper, ignition coil	Buy now
32	9038706119 Collar	Buy now
33	9011906M65 Bolt, with washer	Buy now

Oil Tank




Ref	Part	
34	64E2432300 Pipe 12	Buy now
35	9044512207 Hose (I3000)	Buy now
40	9046413M34 Clamp(6r3)	Buy now
41	60H13437A0 Mark, caution	Buy now
42	656W281002 Tool kit	Buy now
43	64C281997FD0 Manual,owner's UR (NL)	Buy now
43	64C281997FE0 Manual,owner's UR (E)	Buy now
43	64C281997FF0 Manual,owner's UR (F)	Buy now
43	64C281997FG0 Manual,owner's UR (D)	Buy now
43	64C281997FH0 Manual,owner's UR (I)	Buy now
43	64C281997FS0 Manual,owner's UR (ES)	Buy now
44	64C281998FK0 Manual,owner's UR (DK)	Buy now
44	64C281998FL0 Manual,owner's UR (SF)	Buy now
44	64C281998FM0 Manual,owner's UR (S)	Buy now
44	64C281998FN0 Manual,owner's UR (N)	Buy now

Oil Tank




Ref	Part	
44	64C281998FP0 Manual,owner's UR (P)	Buy now
44	64C281998FR0 Manual,owner's UR (GR)	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
1	64E4380005 Power trim & tilt assembly	Buy now
2	64E4382503 Housing, trim & tilt	Buy now
3	6AW4388J00 Plug 2	Buy now
4	9321010M74 O-ring	Buy now
5	64E4381700 Filter 2	Buy now
6	64E4381002 Tilt piston sub assembly	Buy now
7	64E4381102 Screw, cylinder end	Buy now
8	64E4389800 Seal, dust 2	Buy now
9	64E4386700 O-ring 7	Buy now
10	64E4386600 O-ring 6	Buy now
11	6E54386200 O-ring 2	Buy now
12	64E4388300 O-ring 10	Buy now
13	6E54387200 Ring, back-up 2	Buy now
14	6E54381402 Piston, free	Buy now
16	64E4382002 Trim piston sub assembly	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
17	64E4382102 Screw, trim cylinder end	Buy now
18	64E4382200 Seal, trim dust	Buy now
19	64E4384J00 Seal, trim down	Buy now
20	6G54386400 O-ring 4	Buy now
21	6E54386400 O-ring 4	Buy now
22	6E54387401 Ring, back-up 4	Buy now
23	64E4382801 Body, reservoir	Buy now
24	64E4382901 Plug, reservoir	Buy now
25	64E4389700 O-ring	Buy now
26	64E4388E01 Bolt ,screw (l:14mm)	Buy now
27	64E4386900 O-ring 9	Buy now
28	64E4381G00 Pin 1	Buy now
29	6E54385800 Ball 1	Buy now
30	64E4382G00 Valve seat	Buy now
31	9020110060 Washer, plate	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
32	9757510530 Bolt, with washer	Buy now
33	6BC4381800 Pin, lower shock mount	Buy now
34	9038622M98 Bush(61u)	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
1	64E4388E11 Bolt ,screw (l:34.7mm)	Buy now
2	64E4383100 Connector, shaft	Buy now
3	64E4386800 O-ring 8	Buy now
4	64E4383001 Gear pump assembly	Buy now
5	72X4385800 Ball	Buy now
6	64E4384300 Screw, valve lock	Buy now
7	64E4384100 Piston, shuttle	Buy now
8	64E4380200 Valve sub assembly	Buy now
9	6E54389600 O-ring	Buy now
10	6G54386300 O-ring 3	Buy now
11	64E4385100 Seat, Relief Valve	Buy now
12	64E4385800 Ball	Buy now
13	64E4385900 Pin, Valve Support	Buy now
14	64E4385500 Spring, up relief	Buy now
15	64E4385000 Valve sub assembly	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
16	64E4386500 O-ring 10	Buy now
17	64E4381600 Filter 1	Buy now
19	64E4381711 Filter 2	Buy now
20	64E4386001 Manual valve sub-assembly	Buy now
21	72X85075L0 O-ring (nsd161)	Buy now
22	64E4382700 Ring set	Buy now
23	64E4387A00 O-ring	Buy now
24	64E4387300 Ring, back up	Buy now
25	6AW4387500 Ring, snap	Buy now
26	64E4387911 Screw, with washer	Buy now
27	64E4387901 Screw, with washer	Buy now
28	64E4388003 Motor assembly	Buy now
29	6H14386K10 Spring, brush	Buy now
30	64E4380J00 Holder Brush	Buy now
31	64E4389100 Brush 1	Buy now

Power Trim & Tilt Assy 2



Ref	Part	
32	9760704310 Screw, pan head(6g8)	Buy now
33	64E4380F00 Holder, brush 2	Buy now
34	64E4389200 Breaker comp. (brush 2)	Buy now
35	6G54386500 O-ring	Buy now
36	9310208M43 Oil seal(6b0)	Buy now
37	64E4380500 Armature assembly	Buy now
38	64E4384310 Screw valve lock	Buy now


Remote Control Assy 1



64L1100-2260


Ref	Part	
1	7034820517 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	7034826101 Arm, throttle	Buy now
3	7034815300 Shaft, free accel.	Buy now
4	7034823500 Bushing	Buy now
5	7034826800 Spacer 3	Buy now
6	7034826400 Throttle, friction	Buy now
7	9538005600 Nut, hexagon (663)	Buy now
8	9738005025 Bolt	Buy now
9	7034826500 Shaft Friction	Buy now
10	9343006024 Circlip (701)	Buy now
11	7034824500 Plate, lock	Buy now
12	7034825200 Roller, cam	Buy now
13	7014824800 Roller, free accel	Buy now
14	7034819800 Washer, wave 3	Buy now
15	7034824300 Bushing 3	Buy now

Remote Control Assy 1




Ref	Part	
16	7034823600 Bushing	Buy now
17	7034818900 Retainer	Buy now
18	7034823400 Roller, detent	Buy now
19	7034834501 Cable end, remote control 2	Buy now
20	7034835800 Anchor, cable	Buy now
21	7034824400 Spring, free accel.	Buy now
22	7034823800 Spring, detent	Buy now
23	7034824600 Spacer 1	Buy now
24	7034822700 Spring, neutral lock	Buy now
25	7038259400 Clamp WITH PT/T SW.	Buy now
26	7034822600 Plate, stopper	Buy now
27	7034822200 Grip, control lever SINGLE	Buy now
28	7034822300 Lock, neutral	Buy now
29	7034822500 Cover	Buy now
30	7034821900 Cover, lead	Buy now

Remote Control Assy 1




Ref	Part	
31	7034828100 Screw, flat head	Buy now
32	7034828200 Screw	Buy now
33	9738008030 Bolt, hexagon (fj1)	Buy now
34	9299008600 Washer, plain (663)	Buy now
35	9858004010 Screw, pan head (e56)	Buy now
36	9858004006 Screw, pan head (7h3)	Buy now
37	9858005010 Screw, pan head(62x)	Buy now
38	9858003015 Screw, pan head (n151)	Buy now
39	7034829110 Screw	Buy now
40	9538006600 Nut(661)	Buy now
41	7034829310 Spacer, remote control SINGLE	Buy now
42	7014828700 Washer 1	Buy now
43	7034821500 Graphic	Buy now
44	7038251043 Main switch assembly	Buy now
45	7038257700 Cap, key	Buy now

Remote Control Assy 1




Ref	Part	
46	7038253100 Wire, lead	Buy now
47	6888257501 Engine stop switch assembly	Buy now
48	6828255600 Lanyard, stop switch	Buy now
49	6888258A20 10p main harness mec 2m (6ft) (10P)	Buy now
50	7038254000 Neutral switch assembly	Buy now
51	7038338302 Buzzer	Buy now
52	7034828400 Grommet	Buy now
53	7038259100 Band	Buy now
54	7038259200 Band	Buy now
55	7038256302 Trim & tilt switch assembly WITH PT/T SW.	Buy now
56	7034822100 Grip	Buy now
57	7034815200 Knob, free accel	Buy now
58	7034821200 Rear housing	Buy now
59	7034821300 Back, panel	Buy now
60	7034827100 Arm, shift	Buy now

Remote Control Assy 1




Ref	Part	
61	7034821101 Housing,1	Buy now
62	7034823200 Drive gear	Buy now

Remote Control Assy 2




Ref	Part	
1	70448207P1 704 twin top mount (mec rc) AP WITH PT/T SW.	Buy now
2	7044812800 Screw, pan head	Buy now
3	EL84825100 Plate, cam	Buy now
4	7044826500 Shaft, friction	Buy now
5	7014824600 Spacer	Buy now
6	9343006024 Circlip (701)	Buy now
7	EL84825900 Circlip 1	Buy now
8	7044826200 Shaft, throttle	Buy now
9	7044826400 Friction, throttle	Buy now
10	7048254030 Neutral switch assembly	Buy now
11	EL84828100 Screw 1	Buy now
12	7044821530 Graphic	Buy now
13	7044828100 Screw1	Buy now
14	9789005025 Screw, panhead (a93)	Buy now
15	7044826100 Arm, throttle	Buy now

Remote Control Assy 2




Ref	Part	
16	EL84819100 Washer 1	Buy now
17	7044828300 Screw,panhead (eg9)	Buy now
18	9738006018 Bolt (fj0)	Buy now
19	7034834501 Cable end, remote control 2	Buy now
20	7044828700 Washer 1	Buy now
21	9538005600 Nut, hexagon (663)	Buy now
22	7044827100 Arm, shift	Buy now
23	EL84812700 Screw 1	Buy now
24	7034835800 Anchor, cable	Buy now
25	7044823100 Housing, gear	Buy now
26	EL84824100 Arm, drive	Buy now
27	EL84825400 Stopper Throttle Adjusting	Buy now
28	9278006020 Screw flat head	Buy now
29	9878005018 Screw (704)	Buy now
30	EL84824400 Spring, free accel.	Buy now

Remote Control Assy 2




Ref	Part	
31	EL84824500 Plate, lock	Buy now
32	70448222P0 Grip, control lever	Buy now
33	7048259400 Clamp	Buy now
34	7048256351 Trim & tilt switch assembly	Buy now
35	70448229P1 Grip, control lever	Buy now
36	9299005300 Washer, tooth	Buy now
37	9538006600 Nut(661)	Buy now
38	7014824800 Roller, free accel	Buy now
39	7044823800 Spring, detent	Buy now
40	70448232P1 Gear	Buy now
41	EL84816400 Pin 2	Buy now
42	7044824210 Shaft, drive	Buy now
43	6X34822520 Cover	Buy now
44	7044819200 Washer 2	Buy now
45	9789006018 Screw, pan head(6e5)	Buy now

Remote Control Assy 2




Ref	Part	
46	9299006300 Washer, tooth	Buy now
47	EL84827900 Circlip 2	Buy now
48	7044823400 Bushing 1	Buy now
49	70448219P0 Cover, lead	Buy now
50	7044814420 Plate, stopper 2	Buy now
51	7044817610 Grommet	Buy now
52	70448192P0 Washer 2	Buy now
53	7044823300 Gear 2	Buy now
54	7044823500 Bushing	Buy now
55	7044815300 Shaft, free accel.	Buy now
56	7044816600 Plug	Buy now
57	70448284P0 Grommet	Buy now
58	7048195010 Relay assembly	Buy now
59	7048259010 Wireharness assembly	Buy now
60	70448229R0 Grip, control lever	Buy now

Remote Control Assy 2



Ref	Part	
61	70482563H1 Trim & tilt switch assembly	Buy now
63	7044815600 Nut 1	Buy now
64	70482563J1 Trim & tilt switch assembly	Buy now
65	7044828510 Grommet 2	Buy now
66	7044817800 Plate, shift	Buy now
67	70448221P0 Lever, control	Buy now
68	7044811941 Cover	Buy now
69	7044816711 Plug	Buy now
70	9789005016 Screw, pan head(6b0)	Buy now


Remote Control Box




68V4100-D350

Ref	Part	
1	7034820517 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	70448207P1 704 twin top mount (mec rc) AP WITH PT/T SW.	Buy now
3	7014832050 Cable, Remote Control L=15F UR	Buy now
3	7014832060 Cable, Remote Control L=16F UR	Buy now
3	7014832080 Cable, Remote Control L=17F UR	Buy now
3	7014835000 Cable, Remote Control L=21F UR	Buy now
3	7014835020 Cable, Remote Control L=23F UR	Buy now


Repair Kit 1



64D0010-6230


Ref	Part	
1	64DW000101 Power head gasket kit	Buy now
2	6E511381A2 Gasket 1	Buy now
3	6G511181A3 Gasket, cylinder head 1	Buy now
4	6G511193A2 Gasket, head cover 1	Buy now
5	68812414A1 Gasket, cover	Buy now
6	6G541112A1 Gasket, exhaust inner cover	Buy now
7	6G541114A0 Gasket, exhaust inner cover	Buy now
8	6G511382A1 Gasket 2	Buy now
9	9310240M14 Oil seal(61a)	Buy now
10	9321104001 O-ring	Buy now
11	9310235M13 Oil seal (6e5)	Buy now
12	9310122M15 Oil seal (6e5)	Buy now
13	9321074M35 O-ring (6e5)	Buy now
14	6E513621A1 Gasket, valve seat	Buy now
15	6G513645A2 Gasket, manifold 1	Buy now

Repair Kit 1




Ref	Part	
16	6E514198A2 Gasket	Buy now
17	6K71448300 Gasket	Buy now
18	65024431A0 Gasket, fuel pump	Buy now
19	68F4511301 Gasket, upper casing	Buy now
20	64DW009301 Carburetor repair kit	Buy now
21	64D1438401 Gasket, float chamber	Buy now
22	6E51454600 Valve, needle	Buy now
23	6E51415900 Clip	Buy now
24	6E51438602 Pin, float	Buy now
25	61U1495900 Gasket	Buy now
26	64D1439400 Valve, drain	Buy now
27	6E51439801 Gasket	Buy now
28	6E51432801 Plug	Buy now
29	6E51497900 Gasket	Buy now
30	6J81495900 Gasket, drain screw	Buy now

Repair Kit 2




Ref	Part	
1	6G5W0001C1 Lower unit gasket kit	Buy now
2	6G541134A1 Gasket, exhaust manifold	Buy now
3	6G545114A1 Gasket, upper casing	Buy now
4	6E541135A0 Gasket, exhaust manifold	Buy now
5	9043008020 Gasket	Buy now
6	6E54512300 Gasket, muffler	Buy now
7	6E54436500 Damper, water seal 1	Buy now
8	6E54436600 Damper, water seal 2	Buy now
9	9321058144 O-ring(47x)	Buy now
10	9310609014 Oil seal	Buy now
11	9321086M38 O-ring (6e5)	Buy now
12	9321037160 O-ring (6g8)	Buy now
13	6E544315A0 Gasket,water pump	Buy now
14	9310128M16 Oil seal (6e5)	Buy now
15	9321055M14 O-ring (70e)	Buy now

Repair Kit 2




Ref	Part	
16	9321097M55 O-ring (6g5)	Buy now
17	9310130M17 Oil seal (6e5)	Buy now
18	61AW0078A3 Water pump repair kit	Buy now
19	61A4432202 Insert, cartridge	Buy now
22	6E54435201 Impeller	Buy now
23	6G54432300 Outer plate, cartridge	Buy now
25	9360612019 Pin, dowel (614)	Buy now
26	9011908M14 Bolt, with washer	Buy now
27	9028004M05 Key, woodruff (6e5)	Buy now
28	61AW00782A Chrome pump kit	Buy now
29	6R34432242 Insert, cartridge	Buy now
30	6G54432340 Outer plate, cartridge	Buy now

Starting Motor




Ref	Part	
1	6N78180010 Starting motor assembly	Buy now
2	6N78185010 Armature assembly	Buy now
3	61A8180900 Washer kit	Buy now
4	61A8182400 Washer 2	Buy now
5	6N78181000 Stator assembly	Buy now
6	6K78182G10 Bush, terminal	Buy now
7	6N78184000 Brush holder assembly	Buy now
8	6N78180100 Brush set	Buy now
9	6N78181300 Spring, brush	Buy now
10	6N78182010 Rear bracket assembly	Buy now
11	6N78180700 Gear assembly, starting motor	Buy now
12	6N78185700 Pinion stopper set	Buy now
13	6N78183000 Front bracket assembly	Buy now
14	6K78182611 Bolt	Buy now
15	6E58182E10 Washer, spring	Buy now

Starting Motor



Ref	Part	
16	6E58182F10 Washer,plain	Buy now
17	6E58182A10 Nut	Buy now
18	6E58182K10 Nut	Buy now
19	6R3818220094 Bracket, starting motor	Buy now
20	9011908M76 Bolt, with washer(6e5)	Buy now
21	9011908M77 Bolt, with washer(6e5)	Buy now
22	9011908M57 Bolt, with washer	Buy now
23	9299008600 Washer, plain (663)	Buy now
24	9709508016 Bolt, hexagon deep recess	Buy now
25	9299508600 Washer, plain (663)	Buy now


Steering Guide Attachment 1 Direction Guide Accessoire 1



67H0100-9290

Ref	Part	
1	6E56135002 Steering guide attachment kit AP	Buy now
2	6E56135101 Rod, steering link	Buy now
3	9038710M61 Collar (6e5)	Buy now
4	9056012M01 Spacer (6e5)	Buy now
5	6E56135500 Bolt	Buy now
6	9018509M01 Nut, nylon (663)	Buy now
7	9020110M20 Washer, plate (663)	Buy now
8	6E54314501 Cap, clamp bracket	Buy now
9	9321016275 O-ring	Buy now


Steering Guide Attachment 2 Direction Guide Accessoire 2



67H0100-0300


Ref	Part	
1	6E56130101 Tie bar assembly (l:600-800mm) AP	Buy now
2	6E56131300 Adjuster	Buy now
3	6E56131111 Tie bar	Buy now
4	6E56131500 Tie bar, 2	Buy now
5	6E56130300 Steering axle comp.	Buy now
6	9017014M06 Nut (6e5)	Buy now
7	9538014700 Nut (6e5)	Buy now
8	9020110M76 Washer, plate (6e5)	Buy now
9	9010109M70 Bolt (6e5)	Buy now
10	9017009M05 Nut, hexagon (6e5)	Buy now
11	9018509M01 Nut, nylon (663)	Buy now

Switch & Panel



Ref	Part	
1	6K18257008 Panel switch assembly AP	Buy now
2	6K18257102 Plate, panel switch	Buy now
3	6K18251006 Main switch assembly	Buy now
4	7038257700 Cap, key	Buy now
5	6K18253200 Cap	Buy now
6	6K18257500 Engine stop switch assembly	Buy now
7	6828255600 Lanyard, stop switch	Buy now
8	6K18361401 Bracket	Buy now
9	9898005010 Screw, bind(6k1)	Buy now
21	9299005100 Ybs67-5 washer, spring AP	Buy now
20	9538005600 Nut, hexagon (663) AP	Buy now
12	6888338311 Buzzer	Buy now
13	6K18583001 Control unit assembly	Buy now
14	9898006020 Screw, bind (j17)	Buy now
15	9538006600 Nut(661)	Buy now


Switch & Panel




68V3300-C380

Ref	Part	
16	9299006100 Washer(6a1)	Buy now
17	9299006600 Washer, plain (646)	Buy now
18	6K18198000 Diode assembly	Buy now
19	9014905M05 Screw(6k0) AP	Buy now
22	9299005600 Washer, plain (646) AP	Buy now
23	6K18258A40 Extension, wire harness AP (10P)	Buy now
24	61B8258A01 Extension, wire harness AP (10P)	Buy now


Top Cowling



64E8300-G010

Ref	Part	
1	64E42610508D Top Cowling assembly	Buy now
2	6R34264700 Holder, clamp band	Buy now
3	9299006100 Washer(6a1)	Buy now
4	9538006600 Nut(661)	Buy now
5	64D4266200 Damper	Buy now
6	64D4281400 Hook, clamp	Buy now
7	9709506012 Bolt(gh1)	Buy now
8	9299506600 Washer, plain (646)	Buy now
9	64D4261500 Seal	Buy now
10	64D42613008D Molding, air duct	Buy now
11	9017906M24 Nut(6j8)	Buy now
12	64E4267750 Graphic, Front	Buy now
13	64E4268730 Emblem, rear	Buy now
14	64DW007030 Graphic Set	Buy now
15	64C4268130 Mark, cowling	Buy now


Top Cowling



64E8300-G010


Ref	Part	
16	64C4268230 Mark, cowling	Buy now
17	64D4267A30 Graphic, rear 2	Buy now
18	64D4267830 Graphic, Rear	Buy now

Upper Casing



Ref	Part	
1	6E545111028D Casing, upper L(20.3")	Buy now
1	6E545111238D Casing, upper X(25.3")	Buy now
2	6R34279141 Mark 1	Buy now
3	6R34279241 Mark	Buy now
4	6E54515500 Cap	Buy now
5	6E54276900 Seal, rubber	Buy now
6	9709506010 Bolt	Buy now
7	9299506600 Washer, plain (646)	Buy now
8	9360812M05 Pin, dowel b (6e5)	Buy now
9	9011908078 Bolt, with washer	Buy now
10	6G54113702CA Guide, exhaust	Buy now
11	6E54272400 Grommet	Buy now
12	6G51258100 Joint, hose	Buy now
14	68F4511301 Gasket, upper casing	Buy now
15	9011908M79 Bolt, hexagon (fj1)	Buy now


Upper Casing



64C4300-D210

Ref	Part	
16	9011908077 Bolt, with washer	Buy now
17	9709508045 Bolt, hexagon	Buy now
18	9299508100 Ybs67-8 washer, spring	Buy now
19	9538008700 Nut(661)	Buy now
21	6G54113101CA Manifold, ext. 1	Buy now
22	6G545114A1 Gasket, upper casing	Buy now
23	9709508030 Bolt, hexagon (fj1)	Buy now
24	9299508600 Washer, plain (663)	Buy now
25	64D4113200CA Manifold, exhaust	Buy now
26	6G541134A1 Gasket, exhaust manifold	Buy now
29	6E51471101CA Muffler 1	Buy now
30	6E51473700 Damper, muffler	Buy now
31	9018305M02 Nut, spring (6e5)	Buy now
32	6E54512300 Gasket, muffler	Buy now
33	6E541135A0 Gasket, exhaust manifold	Buy now

Upper Casing



64C4300-D210

Ref	Part	
36	6E54531800 Bushing, drive shaft 3 X(25.3")	Buy now
37	9342036M01 Circlip (6a0) X(25.3")	Buy now
38	64D1472120CA Muffler 2 X(25.3")	Buy now
39	64D4512300 Gasket, muffler X(25.3")	Buy now
40	64D4537500 Damper, seal X(25.3")	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.