



Yamaha 2BMH 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BRACKET	3
CARBURETOR	5
COWLING . FUEL	8
CYLINDER. CRANKCASE	12
GENERATOR	15
LOWER CASING. DRIVE	17
REPAIR KIT	21
STARTER	24
UPPER CASING	25

Bracket




6A11300-2060

B6

Ref	Part	
1	6A1-43111-03-4D Bracket, clamp	Buy now
2	6A1-43112-00-4D Bracket, clamp	Buy now
3	6A1-43191-00 Shaft, stopper	Buy now
4	6A1-43192-00 Knob, stopper	Buy now
5	91690-30014 Pin, spring (647)	Buy now
6	6E0-43116-01 Screw, transom clamp	Buy now
7	6E0-43118-01 Handle, transom clamp	Buy now
8	90243-04M01 Pin(6a1)	Buy now
9	620-43114-00 Pad, transom clamp	Buy now
10	90101-08217 Bolt 6464313100	Buy now
11	90202-08022 Washer 6464313202	Buy now
12	6A1-43113-01 Plate, clamp bracket	Buy now
13	95380-08600 Nut (661)	Buy now
14	6A1-43311-02-4D Bracket, swivel 1	Buy now
15	6A1-43312-00-4D Bracket, swivel 2	Buy now

Bracket




6A11300-2060

B6

Ref	Part	
16	646-42537-01 Bushing, pivot shaft	Buy now
17	93210-46044 O-ring	Buy now
18	90119-06M98 Bolt, with washer	Buy now
19	95380-06600 Nut(661)	Buy now
20	93700-06M03 Nipple, grease(6a1)	Buy now
21	646-42528-00 Piece, friction	Buy now
22	90122-06004 Bolt, wing (646)	Buy now
23	90501-12272 Spring 6464252401	Buy now
24	6A1-43351-00 Receiver, thrust	Buy now
25	6A1-43371-00 Bolt, receiver	Buy now
26	90201-06040 Washer 6464337400	Buy now
27	90175-06008 Nut, Wing	Buy now
28	91690-20006 Pin, spring (647)	Buy now


Carburetor



B2

Ref	Part	
1	6A1-14301-03 Carburetor assembly 1	Buy now
2	646-14158-00 Top, mixing chamber	Buy now
3	6A1-14497-00 Stay, throttle wire	Buy now
4	646-14321-00 Screw, throttle	Buy now
5	646-14169-00 3-	Buy now
6	6A1-14314-00 Bar, throttle	Buy now
7	6A1-14163-00 Spacer	Buy now
8	646-14229-01 O-ring	Buy now
9	6A1-14384-00 Gasket, float chamber	Buy now
10	6A1-14341-01 Nozzle, main	Buy now
11	6A1-14343-48 Jet Main (#96)	Buy now
12	6A1-14381-02 Body, float chamber	Buy now
13	97890-05006 Screw,panhead (eg9)	Buy now
14	646-14198-01 Gasket	Buy now
15	6A1-14116-10 Needle	Buy now

Carburetor




6A10010-4030

B2

Ref	Part	
16	646-14137-00 Clip	Buy now
17	646-14136-00 Seat, spring	Buy now
18	646-14331-01 Spring,throttle valve	Buy now
19	646-14312-08 Valve, throttle	Buy now
20	6A1-14125-01 3-	Buy now
21	6A1-14127-01 Clip	Buy now
22	6A1-14358-01 Nut	Buy now
23	6A1-14212-00 Spring, Pilot Adjusting	Buy now
24	646-14211-02 Screw, pilot adjusting	Buy now
25	97980-04110 Screw, pan head (e56)	Buy now
26	6A1-14392-00 Valve, needle	Buy now
27	6A1-14386-00 Pin, float	Buy now
28	6A1-14385-00 Float	Buy now
29	98580-03005 Screw, pan head(78g)	Buy now
30	646-14358-00 Nut	Buy now


Carburetor



Ref	Part	
31	6A1-14356-00 Washer	Buy now
32	646-14357-00 Washer	Buy now
33	6A1-14448-00 Lever, choke valve	Buy now
34	6A1-14217-01 Valve Choke	Buy now
35	92990-05600 Washer, plain (646)	Buy now

B2


Cowling . Fuel



A4

Ref	Part	
1	6A1-14441-02 Silencer, intake 2	Buy now
2	90173-05M00 Nut, square (6a1)	Buy now
3	6A1-42677-10 Graphic Front	Buy now
4	6A1-14442-00 Spacer 1	Buy now
5	90151-04M04 Screw, countersunk	Buy now
6	6A1-41271-00 Knob, choke	Buy now
7	93210-08M29 O-ring (6a1)	Buy now
8	6A1-24110-01 Fuel tank assembly	Buy now
9	6A1-24198-00 Seat, rubber	Buy now
10	6A1-24610-01 Cap assembly	Buy now
11	6A1-24631-00 Screw, air	Buy now
12	90430-04005 Gasket 6112463200	Buy now
13	90430-14117 Gasket	Buy now
14	646-24615-01 Gasket, Plate 1	Buy now
15	90501-10374 Spring, Compression	Buy now


Cowling . Fuel



A4

Ref	Part	
16	92907-04200 Washer(6e1)	Buy now
17	90501-10260 Spring, safety 6152463500	Buy now
18	646-24241-00 Indicator	Buy now
19	97095-06018 Bolt (fj0)	Buy now
20	95380-06600 Nut(661)	Buy now
21	92995-06100 Washer(6a1)	Buy now
22	90201-06M30 Washer, plate (6a1)	Buy now
23	6A1-24181-00 Damper, locating	Buy now
24	6A1-24500-02 Fuel cock assembly 1	Buy now
25	6A1-24311-00 Pipe 1	Buy now
26	90467-08004 Clip, pipe 6162435600	Buy now
27	656-W2810-02 Tool kit	Buy now
28	6A1-42741-11 Apron	Buy now
29	6A1-W0070-14 Graphic set	Buy now
30	6A1-24153-50 Indicator, Cock	Buy now


Cowling . Fuel



A4

Ref	Part	
31	6A1-24154-50 Indicator, Shift	Buy now
32	6A1-42771-11 Apron	Buy now
33	98780-05012 Screw(617)	Buy now
34	90183-05M00 Nut, spring (6a1)	Buy now
35	97880-05010 Screw, pan head(62x)	Buy now
36	92990-05600 Washer, plain (646)	Buy now
37	97880-06040 Screw pan head	Buy now
38	92990-06100 Washer(6a1)	Buy now
39	92990-06600 Washer, plain (646)	Buy now
40	97880-06025 Screw, pan head(6b0)	Buy now
43	6A1-28176-00 Label Caution	Buy now
44	6A1-41212-01 Arm, accel.	Buy now
45	6A1-41211-00 Link,accel	Buy now
46	92990-05100 Ybs67-5 washer, spring	Buy now
47	97095-05010 Bolt (682)	Buy now


Cowling . Fuel



A4

Ref	Part	
48	6A1-14365-00 Pin, clevis	Buy now
49	99001-04600 Circlip (eu0)	Buy now
50	6A1-41637-00 Knob, magneto control	Buy now
51	98780-03010 Screw, flat head (e56)	Buy now
52	6A1-41223-00 Washer, lock 1	Buy now
53	97885-05025 Screw, pan head(62j)	Buy now
54	90501-12M16 Spring (6a1)	Buy now
55	6A1-82550-02 Stop switch assembly	Buy now
56	6A1-82541-00 Wire, Lead	Buy now
57	95380-08700 Nut(661)	Buy now
58	97880-05008 Screw, with washer	Buy now
59	6A1-82375-11 Cover, plug cap	Buy now
61	97880-05012 Screw,pan head (646)	Buy now
63	6A1-83625-41 Mark 5	Buy now
64	6A1-83625-51 Mark 5	Buy now


Cylinder. Crankcase



A7


Ref	Part	
3	90336-06001 Plug, blind 6551131300	Buy now
4	650-14485-03 Pipe, joint	Buy now
5	624-11379-00 Valve, check	Buy now
6	97013-06040 Bolt (682)	Buy now
7	92903-06600 Washer, plain (646)	Buy now
8	99530-10014 Pin, dowel	Buy now
10	6A1-11181-A1 Gasket, cylinder head 1	Buy now
11	97095-06025 Bolt	Buy now
12	92995-06600 Washer, plain (646)	Buy now
13	6A1-11400-00 Crankshaft assembly	Buy now
14	646-11412-01 Crank 1	Buy now
15	6A1-11422-00 Crank 2	Buy now
16	646-11681-00 Pin, crank 1	Buy now
17	93310-31439 Brg,cyl-cal roller 5g tm	Buy now
18	646-11651-02 Rod, connecting	Buy now

Cylinder. Crankcase



Ref	Part	
19	93306-00409 Brg,r-b 6004 42mm 69g nk	Buy now
20	93306-30204 Brg,r-b 6302 42mm 82g nk	Buy now
21	93310-210V1 Bearing (27v)	Buy now
22	93102-20070 Oil seal	Buy now
23	90201-35300 Washer, Plate	Buy now
24	646-11635-01 2- AP	Buy now
24	646-11636-01 Piston (0.50Mm O/s) AP	Buy now
24	93102-15M32 Oil seal(6a1)	Buy now
26	646-11601-01 Piston Ring Set (Std)	Buy now
26	646-11601-11 Piston Ring Set(1Sto/S) AP	Buy now
26	646-11601-21 2- AP	Buy now
27	646-11633-00 Pin,piston	Buy now
28	93450-11021 Circlip 101116340000	Buy now
29	90445-07254 Hose (I200)	Buy now
30	90467-06016 Clip (655)	Buy now


Cylinder. Crankcase



A7

Ref	Part	
31	6A1-13610-00 Reed valve assembly	Buy now
32	6A1-W0004-00 Reed set	Buy now
33	6A1-13621-A0 Gasket, valve seat	Buy now
34	6A1-24141-00 Protector, fuel tank	Buy now
35	95895-06010 Bolt, flange(7ht)	Buy now
36	94702-00249 Plug Spark (Br5Hs)	Buy now
37	90465-06M86 Clamp	Buy now
38	6A1-42678-12 Graphic, rear	Buy now
39	6A1-15771-01 Stay 1	Buy now
40	97013-06060 Bolt, hexagon	Buy now
41	678-42791-10 Mark 1	Buy now

Generator




6A1-85550-5050

B5

Ref	Part	
1	6A1-85550-00 Rotor assembly	Buy now
2	6A1-85560-00 Base assembly	Buy now
3	6A1-85520-00 Coil, charge	Buy now
4	97885-05020 Screw, pan head (e22)	Buy now
5	90280-04M06 Key, woodruff(6a1)	Buy now
6	6A1-81362-00 Cover, hole 1	Buy now
7	90170-10M33 Nut(6a1)	Buy now
8	92903-10100 Ybs67-10 washer, spring	Buy now
9	97013-06030 Bolt	Buy now
10	92903-06100 Washer(6a1)	Buy now
11	92903-06600 Washer, plain (646)	Buy now
12	6G1-82370-21 Plug cap assembly	Buy now
13	6A1-85540-01 C.d.i. unit assembly	Buy now
14	97885-06016 Screw, pan head(6b0)	Buy now
15	92995-06100 Washer(6a1)	Buy now


Generator



Ref	Part	
16	92995-06600 Washer, plain (646)	Buy now
17	6A1-85570-00 Ignition coil assembly	Buy now
18	97095-06020 Bolt(7u8)	Buy now
20	90464-08M07 Clamp	Buy now

B5


Lower Casing. Drive



C3


Ref	Part	
1	6A1-45300-03-4D Lower unit assembly	Buy now
2	6A1-45181-00-4D Plate	Buy now
3	6A1-45311-02-4D Casing Lower	Buy now
4	6L5-45251-03 Anode	Buy now
5	95895-06012 Bolt, flange deep recess	Buy now
6	92990-06300 Washer, tooth	Buy now
7	93103-11051 Oil seal (11x21x8-646)	Buy now
8	93306-00001 Brg,r-b 6000 26mm 19g ky	Buy now
9	90430-08020 Gasket	Buy now
10	90340-08002 Plug, straight screw	Buy now
11	93605-18M04 Pin, dowel b (6a1)	Buy now
12	97095-06030 Bolt(jf7)	Buy now
13	92995-06600 Washer, plain (646)	Buy now
14	6A1-44325-00 Protector, oil seal	Buy now
15	6A1-45361-01-4D Cap, lower casing	Buy now

Lower Casing. Drive



Ref	Part	
16	93103-10052 Oil seal (10x21x10-646)	Buy now
17	93210-42101 O-ring (183)	Buy now
18	97090-06014 Bolt(gj3)	Buy now
19	92990-06600 Washer, plain (646)	Buy now
20	6A1-44312-01-94 Cover,water pump housing	Buy now
21	93101-11M44 Oil seal(6a1)	Buy now
22	93210-19123 O-ring (646)	Buy now
23	93604-09068 Pin,dowel (646)	Buy now
24	646-44366-01 Damper, water seal 2	Buy now
25	646-44352-01 Impeller	Buy now
26	93604-09066 Pin, dowel	Buy now
27	646-44323-00 Outer plate,cartridge	Buy now
28	646-44322-00 Insert, cartridge	Buy now
29	97095-05016 Bolt(6a1)	Buy now
30	92995-05600 Washer, plain (646)	Buy now

Lower Casing. Drive




6F80200-4080

C3

Ref	Part	
31	6A1-44361-00 Tube, water	Buy now
32	646-44365-00 Damper, water seal 1	Buy now
33	6A1-45510-01 Drive shaft assembly	Buy now
34	90201-11M49 Washer, plate (6e0)	Buy now
35	646-45534-00-03 Shim (T)0.30Mm) UR	Buy now
35	646-45534-00-04 Shim (T)0.40Mm) UR	Buy now
35	646-45534-00-05 Shim (T)0.50Mm) UR	Buy now
36	646-45551-00 Pinion	Buy now
37	99001-06600 Circlip(53l)	Buy now
38	646-45560-00 Gear	Buy now
39	646-45567-00-03 Shim (t:0.30mm) UR	Buy now
39	646-45567-00-04 Shim (t:0.40mm) UR	Buy now
39	646-45567-00-05 Shim (t:0.50mm) UR	Buy now
40	90250-03M10 Pin, straight(6a1)	Buy now
41	91490-30040 Pin, cotter (am5)	Buy now


Lower Casing. Drive



Ref	Part	
42	646-45942-01-EL Propeller (3x7-1/4 x5-1/2 -a) UR	Buy now
42	646-45944-01-EL Propeller (3x7-1/4 x4-1/2 -a) UR	Buy now
42	6A1-45943-00 Propeller assembly (3x7-1/4"x4"-a) UR	Buy now
43	646-28193-00 Plug, Water Check AP	Buy now

C3


Repair Kit



C5

Ref	Part	
1	6A1-W0001-A2 Gasket kit, power unit	Buy now
2	93210-08M29 O-ring (6a1)	Buy now
3	6A1-11181-A1 Gasket, cylinder head 1	Buy now
4	6A1-13621-A0 Gasket, valve seat	Buy now
5	93102-15M32 Oil seal(6a1)	Buy now
6	93102-20070 Oil seal	Buy now
7	6A1-14613-A0 Gasket, exhaust 1	Buy now
8	646-14623-A1 Gasket, exhaust	Buy now
9	6A1-14384-00 Gasket, float chamber	Buy now
10	6A1-W0093-03 Carburetor repair kit	Buy now
12	6A1-14385-00 Float	Buy now
13	6A1-14386-00 Pin, float	Buy now
14	97980-04110 Screw, pan head (e56)	Buy now
15	6A1-14392-00 Valve, needle	Buy now
16	646-14211-02 Screw, pilot adjusting	Buy now


Repair Kit



C5

Ref	Part	
17	6A1-14116-10 Needle	Buy now
18	646-14137-00 Clip	Buy now
19	646-14169-00 3-	Buy now
20	646-14229-01 O-ring	Buy now
21	646-14198-01 Gasket	Buy now
22	6A1-W0001-23 Lower unit gasket kit	Buy now
23	90430-08020 Gasket	Buy now
24	93103-11051 Oil seal (11x21x8-646)	Buy now
25	93210-19123 O-ring (646)	Buy now
26	93210-42101 O-ring (183)	Buy now
27	93101-11M44 Oil seal(6a1)	Buy now
28	93103-10052 Oil seal (10x21x10-646)	Buy now
29	6A1-W0078-02 Water pump repair kit	Buy now
30	93604-09068 Pin,dowel (646)	Buy now
33	646-44323-00 Outer plate,cartridge	Buy now


Repair Kit



Ref	Part	
34	646-44352-01 Impeller	Buy now
35	646-44322-00 Insert, cartridge	Buy now
36	6A1-44325-00 Protector, oil seal	Buy now
37	97095-05016 Bolt(6a1)	Buy now
38	646-44366-01 Damper, water seal 2	Buy now

C5


Starter



B4

Ref	Part	
1	6A1-15710-00 Starter ass'y	Buy now
2	6A1-15711-00 Case, starter	Buy now
3	6A1-15714-00 Drum, sheave	Buy now
4	6A1-15767-00 Spring, return	Buy now
5	6A1-15741-00 Pawl, drive	Buy now
6	6A1-15713-00 Spring, starter	Buy now
7	6A1-15717-00 Plate, drive	Buy now
8	6A1-15705-00 Spring, drive pawl	Buy now
9	97322-06012 Bolt(gh1)	Buy now
10	6A1-15755-02 Handle, starter	Buy now
11	* item_description	Buy now
12	97095-06016 Bolt, hexagon deep recess	Buy now
13	92995-06600 Washer, plain (646)	Buy now
14	6A1-15723-00-94 Pulley, starter	Buy now
15	98703-06012 Screw, flat head(6a1)	Buy now

Upper Casing




6A11100-2070

C1

Ref	Part	
1	6A1-45111-02-4D Casing, upper	Buy now
2	6A1-45113-00 Pipe	Buy now
3	93605-15065 Pin, dowel	Buy now
4	97095-06025 Bolt	Buy now
5	92995-06600 Washer, plain (646)	Buy now
6	6A1-45151-00 Cover, upper casing	Buy now
7	6A1-45115-00 Gasket, upper casing	Buy now
8	97880-06016 Screw pan head	Buy now
9	92990-06600 Washer, plain (646)	Buy now
10	6A1-41137-00-5B Guide,exhaust	Buy now
11	6A1-14613-A0 Gasket,exhaust 1	Buy now
12	646-14623-A1 Gasket, exhaust	Buy now
13	93210-19123 O-ring (646)	Buy now
14	97095-06030 Bolt(jf7)	Buy now
16	6A1-42111-00-4D Handle, steering	Buy now

Upper Casing



 6A11100-2070

C1

Ref	Part	
17	646-42119-02 Grip, steering handle	Buy now
18	6A1-42181-00 Washer	Buy now
19	90201-09117 Washer 1 6154367300	Buy now
20	92990-08200 Ybs66-8 washer, plain	Buy now
21	92990-08100 Ybs67-8 washer, spring	Buy now
22	90101-08M11 Bolt(6a1)	Buy now
23	95380-08600 Nut (661)	Buy now
24	97095-06010 Bolt	Buy now
25	92995-06100 Washer(6a1)	Buy now
26	646-42591-00 Holder, shear pin	Buy now
27	646-42121-00-94 Bracket Carrying AP	Buy now
28	97095-06055 Bolt, hexagon w/w deep recess AP	Buy now
29	92990-06100 Washer(6a1) AP	Buy now
30	6A1-2415A-41 Label, caution	Buy now
31	6A1-2415A-51 Label Caution	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.