



Yamaha 3AMH 1996

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents


Boitier D'hélice, Transmission	3
Capot, Section D'alimentation	7
Control	9
Cylinder, Crankcase	11
Electric Parts	13
Generatrice	14
Intake	15
Kits De Réparation	18
Starter	20
Upper Casing . Bracket	21

Boitier Dhelice, Transmissio




Ref	Part	
1	6L545300014D Lower unit assembly	Buy now
2	6L545311004D Casing, lower	Buy now
3	6L5453170900 Bushing, d/shaft 2 90381-09m08	Buy now
4	6L5453160900 Bushing, d/shaft 1 90380-09m23	Buy now
5	6L5452510300 Anode	Buy now
6	9010106M1800 Bolt(6l5)	Buy now
7	929900630000 Washer, tooth	Buy now
8	9310309M4100 Oil seal	Buy now
9	93316003U000 Bearing, cylindrical(6l5)	Buy now
10	6L5455670000 Shim	Buy now
11	9360410M0300 Pin, dowel (688)	Buy now
12	970950603000 Bolt(jf7)	Buy now
13	929900660000 Washer, plain (646)	Buy now
14	903400800200 Plug, straight screw	Buy now
15	904300802000 Gasket	Buy now

Boitier Dhelice, Transmissio




Ref	Part	
16	6L54532100CA Plate	Buy now
17	6L545315A000 Packing, lower casing	Buy now
18	6L2441470000 Boot, shift rod	Buy now
19	6L545361004D Cap, lower casing	Buy now
20	9310113M1200 Oil seal	Buy now
21	932104821400 O-ring	Buy now
22	970950601600 Bolt, hexagon deep recess	Buy now
24	6L5443110000 Housing, water pump	Buy now
25	9321033M8500 O-ring(615)	Buy now
26	6L5443220000 Insert, cartridge	Buy now
27	6L5443230000 Outer plate, cartridge	Buy now
28	6E0443660000 Damper, water seal 2	Buy now
29	6L5443520000 Impeller	Buy now
30	9360407M1300 Pin, dowel(615)	Buy now
31	970950604000 Bolt (682)	Buy now

Boitier Dhelice, Transmissio




Ref	Part	
32	936041808000 Pin. dowel. (647)	Buy now
33	6L5443280000 Plate	Buy now
34	6L5443600100 Water tube assembly	Buy now
35	646443650000 Damper, water seal 1	Buy now
36	6L5455110000 Shaft, drive	Buy now
37	9046707M1200 Clip(6l5)	Buy now
38	6L5455510000 Pinion	Buy now
39	990090660000 Circlip(53l)	Buy now
40	6L5455333000 Shim (t:2.3mm)	Buy now
41	6L5455600000 Gear	Buy now
42	6L5456110000 Shaft, propeller	Buy now
43	905011006400 Spring, compression 6164563600	Buy now
44	6EGG56350000 Plunger, shift	Buy now
45	6L5456310000 Clutch, dog	Buy now
46	6L5459870100 Spacer 1	Buy now

Boitier Dhelice, Transmissio




Ref	Part	
47	902011319800 Washer 6474556600	Buy now
48	6EEG56160000 Nut, propeller	Buy now
49	914902503000 Pin, cotter(6l5)	Buy now
51	6L5459490000 Propeller (3x7-1/4 x5 -bs)	Buy now
53	6L5453180000 Bushing, drive shaft	Buy now
54	9342022M0300 Cir clip (6e0)	Buy now

Capot, Section Dalimentation




Ref	Part	
4	6L5427111100 Cowling, bottom	Buy now
5	6L5427121200 Cowling, bottom	Buy now
6	6L5427740000 Stay, apron 1	Buy now
7	6L5427750000 Stay, apron 2	Buy now
11	6L5426470000 Holder, clamp band	Buy now
12	6EGG28230000 Plate, stop	Buy now
15	6L5245910000 Emblem, Fuel Cock	Buy now
16	6L5426620000 Damper	Buy now
17	6L5426630000 Damper	Buy now
18	6L5241110200 Tank, fuel	Buy now
19	6L5246102100 Cap assembly	Buy now
20	6A0823170000 Damper, ignition coil	Buy now
21	624425420000 Collar	Buy now
23	6L5246410000 Gasket, cap 1	Buy now
24	6L5245006000 Fuel cock assembly 1	Buy now

Capot, Section Dalimentation




Ref	Part	
26	6L5441962000 Indicator 3	Buy now
27	6L5441972000 Indicator 4	Buy now
28	6L5242510000 Strainer 1	Buy now
29	6L5243110000 Pipe, fuel 2	Buy now
31	6L5243120000 Pipe 2	Buy now
33	656W28100200 Tool kit	Buy now

Control




Ref	Part	
1	6G142111044D Handle, Steering	Buy now
6	6G1421310100 Cover, handle steering	Buy now
8	664421190000 Grip, steering handle	Buy now
9	6G1421770000 Rubber, handle	Buy now
17	6G1421380100 Lever, throttle	Buy now
18	6E0421590200 Stay	Buy now
20	6L5421250000 Bolt, friction adjusting	Buy now
21	6G1421260000 Piece, friction	Buy now
23	6L5263010100 Throttle cable assembly	Buy now
24	6L5441110000 Handle, gear shift	Buy now
26	6L5441962000 Indicator 3	Buy now
27	6L5441972000 Indicator 4	Buy now
30	6L5441210000 Lever, shift rod	Buy now
33	6L5441430000 Rod, shift	Buy now
36	6E0441450000 Connector, shift rod 1	Buy now

Control




Ref	Part	
37	6E0441460000 Connector, shift rod 2	Buy now
39	6L5441441000 Rod, shift	Buy now
41	6L542731004D Carrying handle	Buy now
42	6L5427352000 Protector	Buy now

Cylinder. Crankcase




Ref	Part	
1	6L5W0090014D Crank cylinder assembly	Buy now
2	6L5151000094 Crankcase assembly	Buy now
3	624144850000 Pipe, joint	Buy now
4	6E5113720000 Nipple, hose	Buy now
10	6L5153960000 Housing, oil seal	Buy now
13	6L515369A000 Gasket, oil seal housing	Buy now
15	6L5111110094 Head, cylinder 1	Buy now
16	6L511181A200 Gasket, cylinder head 1	Buy now
19	6L511181A100 Gasket, cylinder head 1	Buy now
20	6L511193A100 Gasket, head cover	Buy now
24	6E5124110200 Thermostat	Buy now
25	6L512413009M Cover, thermostat	Buy now
26	6L512414A100 Gasket, cover	Buy now
28	6L5114000000 Crankshaft assembly	Buy now
29	6L5114120000 Crank 1	Buy now

Cylinder. Crankcase




Ref	Part	
30	6L5114220000 Crank 2	Buy now
31	6L5116510000 Rod, connecting	Buy now
32	6L5116810000 Pin, crank 1	Buy now
38	6L5116310096 Piston (std)	Buy now
39	6L5116100000 Piston ring set (std)	Buy now
41	6L5116330000 Pin, piston	Buy now
43	6L545113A100 Gasket, upper casing	Buy now

Electric Parts




Ref	Part	
1	6G1823702000 Plug cap assembly	Buy now
2	6L5823160000 Bracket, ignition coil	Buy now
5	6L585570N000 Ignition coil assembly	Buy now
8	6L585540M000 C.d.i. unit assembly	Buy now
12	6G9825500000 Stop switch assembly	Buy now




Ref	Part	
1	6L585550M000 Rotor assembly	Buy now
2	6L585560M100 Base assembly	Buy now
3	6E0855207000 Charge coil ass'y	Buy now
4	6L585595M000 Coil, pulser	Buy now
5	6L585592M000 Pulser coil assembly	Buy now
6	6E0813367000 Grommet	Buy now
7	6E0813287000 Clamp	Buy now
12	6L5157710194 Stay 1	Buy now

Intake




Ref	Part	
1	6L5136100200 Reed valve assembly	Buy now
2	6L5W00040200 Reed set	Buy now
3	6L513621A200 Gasket, valve seat	Buy now
5	6L5143010300 Carburetor assembly 1	Buy now
6	679149230000 Screw, pilot	Buy now
7	697145550000 Spring	Buy now
8	6G1149660000 Cap	Buy now
9	6G1145270000 Plate	Buy now
10	6G1141260000 Packing	Buy now
11	6L5149480300 Jet (#40)	Buy now
12	676149660000 Rubber cap	Buy now
16	6H1145230000 Screw, stop	Buy now
17	6G1149840000 Gasket, float chamber	Buy now
18	6G1149800100 Body, float chamber	Buy now
19	6L5149470100 Jet, needle	Buy now

Intake




Ref	Part	
20	676149431400 Jet, main (#68)	Buy now
22	6G1143980000 Washer	Buy now
23	65W149920000 Screw, drain	Buy now
24	6G1149850000 Float comp.	Buy now
25	6G1145460000 Valve, needle	Buy now
26	676141860000 Pin, valve	Buy now
27	633141590000 Clip	Buy now
29	688145480000 Pin, arm	Buy now
33	6G1244520000 Cover, pump	Buy now
34	6G1244320000 Packing	Buy now
35	6G1244710000 Diaphragm	Buy now
36	6G1244120100 Body 1	Buy now
37	6G1244110000 Diaphragm	Buy now
38	6G1244310100 Gasket, fuel pump 1	Buy now
39	6L5244210000 Valve, check	Buy now

Intake




Ref	Part	
40	6L514198A100 Gasket	Buy now
41	6L5144400000 Silencer assembly, intake	Buy now
44	6L5412712000 Knob, choke	Buy now
45	6L5412520000 Lever, choke 1	Buy now
47	689412730000 Grommet	Buy now
48	6J8412740000 Grommet 2	Buy now

Kits De Reparation




Ref	Part	
1	6L5W0001A100 Power head gasket kit	Buy now
4	6L515369A000 Gasket, oil seal housing	Buy now
5	6L511181A100 Gasket, cylinder head 1	Buy now
6	6L511193A100 Gasket, head cover	Buy now
7	6L512414A100 Gasket, cover	Buy now
9	6L513621A200 Gasket, valve seat	Buy now
10	6L514198A100 Gasket	Buy now
11	6G1143980000 Washer	Buy now
12	6L545113A100 Gasket, upper casing	Buy now
13	646443650000 Damper, water seal 1	Buy now
14	6G1W00930000 Carburetor repair kit	Buy now
15	679149230000 Screw, pilot	Buy now
16	6G1149660000 Cap	Buy now
17	6G1141260000 Packing	Buy now
18	676149660000 Rubber cap	Buy now

Kits De Reparation




Ref	Part	
19	6G1149840000 Gasket, float chamber	Buy now
21	6G1149850000 Float comp.	Buy now
22	6G1145460000 Valve, needle	Buy now
24	688145480000 Pin, arm	Buy now
28	6L545315A000 Packing, lower casing	Buy now
31	6L5W00780000 Water pump repair kit	Buy now
33	6L5443220000 Insert, cartridge	Buy now
34	6L5443230000 Outer plate, cartridge	Buy now
35	6E0443660000 Damper, water seal 2	Buy now
36	6L5443520000 Impeller	Buy now
39	6L5443280000 Plate	Buy now

Starter




Ref	Part	
1	6L515710000 Starter assembly	Buy now
2	6L515711000 Case, starter	Buy now
4	6L515714000 Drum, sheave	Buy now
5	6L515741000 Pawl, drive	Buy now
6	6L515713000 Spring, starter	Buy now
7	6L515716000 Plate, drive	Buy now
8	6A115705000 Spring, drive pawl	Buy now
10	6A115767000 Spring, return	Buy now
14	6L5157580098 Guide, rope	Buy now
16	6L515761000 Seal, rubber 1	Buy now
17	6L542677000 Graphic, front	Buy now
18	6L515755000 Handle, starter	Buy now
19	6L5157790000 Cover	Buy now
20	6L5157890000 Damper	Buy now

Upper Casing . Bracket



Ref	Part	
6	6L5451520000 Cover, upper casing 2	Buy now
7	6L545115A000 Gasket,upper casing 3	Buy now
9	647451510100 Cover, upper casing	Buy now
10	6L543111014D Bracket Clamp 1	Buy now
11	6GEG3112008D Bracket Clamp 2	Buy now
12	648431140100 Pad, transom clamp	Buy now
13	6E0431160100 Screw, transom clamp	Buy now
14	6EEG31180000 Handle, transom cl	Buy now
17	6G8431360000 Piece, friction	Buy now
18	6L5421210000 Bracket	Buy now
21	6A1431130100 Plate, clamp bracket	Buy now
26	6L543311014D Bracket, swivel 1	Buy now
27	6L544511008D Cover, upper mount	Buy now
28	6L544553004D Cover, lower mount	Buy now
31	6E0433130094 Bracket, swivel 3	Buy now


Upper Casing . Bracket



Ref	Part	
32	620431890000 Bushing	Buy now
34	6L5431810000 Lever, tilt stop 1	Buy now
35	6L5441962000 Indicator 3	Buy now
36	6L5441972000 Indicator 4	Buy now
39	6L5431600000 Tilt rod assembly	Buy now
40	6L5436140000 Plate, tilt lock	Buy now
43	6L5436590000 Shaft, reverse lock	Buy now
45	6L5425370000 Bushing, pivot shaft	Buy now
46	6L5425380000 Bushing, pivot shaft	Buy now
47	6L5425390000 Bushing, pivot shaft	Buy now
48	6L5425490000 Bushing, pivot shaft	Buy now
49	6E0425280300 Plate, friction	Buy now
50	6L5425290100 Screw, friction piece	Buy now
51	6L5425610000 Knob, steering lock	Buy now
55	6L5433181100 Cover	Buy now

Upper Casing . Bracket

Ref	Part	
57	6A1427920100 Mark (100:1)	Buy now



Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.