



# Yamaha 4ACMH 1987

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Control</b> .....	3
<b>Cowling</b> .....	6
<b>Cowling &amp; Fuel</b> .....	7
<b>Cylinder &amp; Crankcase</b> .....	9
<b>Electric Parts</b> .....	12
<b>Fuel</b> .....	13
<b>Intake</b> .....	14
<b>Lower Casing &amp; Drive</b> .....	18
<b>Magneto</b> .....	22
<b>Optional Parts</b> .....	24
<b>Repair Kit</b> .....	25
<b>Starter</b> .....	26
<b>Upper Casing &amp; Bracket</b> .....	28

# Control




Ref	Part	
2	<a href="#">6E0421290100</a> Bushing, rubber	<a href="#">Buy now</a>
3	<a href="#">9038626M3000</a> Bushing (6e0)	<a href="#">Buy now</a>
5	<a href="#">973130502000</a> Bolt, hexagon	<a href="#">Buy now</a>
6	<a href="#">6E0421250000</a> Bolt, friction adjust	<a href="#">Buy now</a>
7	<a href="#">6E0421340200</a> Cover, throttle lever	<a href="#">Buy now</a>
8	<a href="#">978900501200</a> Screw,pan head (646)	<a href="#">Buy now</a>
9	<a href="#">914901201000</a> Pin, cotter (6g8)	<a href="#">Buy now</a>
10	<a href="#">6E0421190000</a> Grip, steering handle	<a href="#">Buy now</a>
11	<a href="#">6E0421770000</a> Rubber, handle	<a href="#">Buy now</a>
12	<a href="#">6E0421371000</a> Indicator, throttle	<a href="#">Buy now</a>
14	<a href="#">905012321500</a> Spring (655)	<a href="#">Buy now</a>
15	<a href="#">902011011900</a> Washer, plain(735)	<a href="#">Buy now</a>
16	<a href="#">986800552500</a> Ybs53-525 screw,flat head	<a href="#">Buy now</a>
17	<a href="#">6E0421380100</a> Lever, throttle	<a href="#">Buy now</a>
18	<a href="#">6E0421590000</a> Stay	<a href="#">Buy now</a>

# Control




Ref	Part	
20	<a href="#">6E0263010100</a> Throttle wire assembly	<a href="#">Buy now</a>
21	<a href="#">6E0441110100</a> Handle, gear shift	<a href="#">Buy now</a>
22	<a href="#">932101232700</a> O-ring(3ld)	<a href="#">Buy now</a>
23	<a href="#">9020616M0600</a> Washer, wave (6e0)	<a href="#">Buy now</a>
24	<a href="#">6E0441160000</a> Spring	<a href="#">Buy now</a>
25	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
26	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
27	<a href="#">973950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
28	<a href="#">6E0441210000</a> Lever, shift rod 1	<a href="#">Buy now</a>
29	<a href="#">958950602500</a> Bolt, flange deep recess	<a href="#">Buy now</a>
30	<a href="#">6E0441430000</a> Rod, shift 1	<a href="#">Buy now</a>
31	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
32	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
33	<a href="#">6E0441450000</a> Connector, shift rod 1	<a href="#">Buy now</a>
34	<a href="#">6E0441460000</a> Connector, shift rod 2	<a href="#">Buy now</a>

## Control




Ref	Part	
35	<a href="#">958800602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
36	<a href="#">9038626M3300</a> Bushing (6e0)	<a href="#">Buy now</a>
37	<a href="#">929030560000</a> Washer, plain (646)	<a href="#">Buy now</a>
38	<a href="#">9020207M2200</a> Washer (6e0)	<a href="#">Buy now</a>

# Cowling




Ref	Part	
3	<a href="#">6E0426770100</a> Graphic Front	<a href="#">Buy now</a>
5	<a href="#">6E0426510000</a> Hook	<a href="#">Buy now</a>
6	<a href="#">6E0426470100</a> Holder, clamp band	<a href="#">Buy now</a>
7	<a href="#">9026604M0000</a> Rivet 2 (662)	<a href="#">Buy now</a>
8	<a href="#">6E0426150000</a> Seal	<a href="#">Buy now</a>
9	<a href="#">6E1426430000</a> Plate, Clamp	<a href="#">Buy now</a>
10	<a href="#">904641515200</a> Clamp(mf1)	<a href="#">Buy now</a>
11	<a href="#">6E1241820000</a> Damper, Locating 2	<a href="#">Buy now</a>
12	<a href="#">6G1243040100</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
13	<a href="#">646242510200</a> Strainer 1	<a href="#">Buy now</a>
14	<a href="#">904450906800</a> Hose (l420)	<a href="#">Buy now</a>
15	<a href="#">904450905700</a> Hose (l180)	<a href="#">Buy now</a>
16	<a href="#">904670800400</a> Clip, pipe 6162435600	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
3	<a href="#">6E0426770100</a> Graphic Front	<a href="#">Buy now</a>
5	<a href="#">6E0426510000</a> Hook	<a href="#">Buy now</a>
6	<a href="#">6E0426470100</a> Holder, clamp band	<a href="#">Buy now</a>
7	<a href="#">9026604M0000</a> Rivet 2 (662)	<a href="#">Buy now</a>
8	<a href="#">6E0426150000</a> Seal	<a href="#">Buy now</a>
10	<a href="#">6A1427920100</a> Mark (100:1)	<a href="#">Buy now</a>
11	<a href="#">6E04281500EJ</a> Lever Clamp 1	<a href="#">Buy now</a>
12	<a href="#">903861206900</a> Bush(666)	<a href="#">Buy now</a>
13	<a href="#">6L2428160000</a> Lever, clamp	<a href="#">Buy now</a>
14	<a href="#">902061205200</a> Washer, wave (666)	<a href="#">Buy now</a>
15	<a href="#">978900603000</a> Screw, pan head(6e0)	<a href="#">Buy now</a>
16	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
17	<a href="#">6E02411000EJ</a> Fuel Tank Comp	<a href="#">Buy now</a>
18	<a href="#">6E0246410000</a> Gasket, cap	<a href="#">Buy now</a>
19	<a href="#">6E0246100200</a> Cap assembly	<a href="#">Buy now</a>

## Cowling & Fuel




Ref	Part	
20	<a href="#">6E0241810000</a> Damper, locating 1	<a href="#">Buy now</a>
21	<a href="#">6E0241820000</a> Damper, locating 2	<a href="#">Buy now</a>
22	<a href="#">958950602500</a> Bolt, flange deep recess	<a href="#">Buy now</a>
23	<a href="#">6E0425420000</a> Pipe 1	<a href="#">Buy now</a>
24	<a href="#">6E0245000100</a> Fuel cock assembly 1	<a href="#">Buy now</a>
25	<a href="#">9044509M3700</a> Hose (l1500)	<a href="#">Buy now</a>
26	<a href="#">904670800400</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
27	<a href="#">6E0245720000</a> Shaft, fuel change	<a href="#">Buy now</a>
28	<a href="#">6E0245710000</a> Bushing	<a href="#">Buy now</a>
30	<a href="#">9020212M1700</a> Washer, plate (6e0)	<a href="#">Buy now</a>
31	<a href="#">6E0245750100</a> Lever, fuel change	<a href="#">Buy now</a>
32	<a href="#">9010506M1500</a> Bolt (6e0)	<a href="#">Buy now</a>
34	<a href="#">6A0825500100</a> Stop switch assembly	<a href="#">Buy now</a>
35	<a href="#">606425910000</a> Holder, shear pin	<a href="#">Buy now</a>
36	<a href="#">6E0281000100</a> Tool kit	<a href="#">Buy now</a>

# Cylinder & Crankcase




Ref	Part	
1	<a href="#">6E0W009002EJ</a> Crank Cylinder assembly	<a href="#">Buy now</a>
3	<a href="#">650113700000</a> Check valve assembly	<a href="#">Buy now</a>
4	<a href="#">624144850000</a> Pipe, joint	<a href="#">Buy now</a>
5	<a href="#">6E5113720000</a> Nipple, hose	<a href="#">Buy now</a>
6	<a href="#">9044507MA300</a> Hose (l200)	<a href="#">Buy now</a>
7	<a href="#">904670601600</a> Clip (655)	<a href="#">Buy now</a>
8	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
9	<a href="#">9010506M1600</a> Bolt (6e0)	<a href="#">Buy now</a>
10	<a href="#">9010506M1700</a> Bolt (6e0)	<a href="#">Buy now</a>
11	<a href="#">6E0243780000</a> Pipe, joint	<a href="#">Buy now</a>
12	<a href="#">9044507M5100</a> Hose (l200)	<a href="#">Buy now</a>
14	<a href="#">9010506M2400</a> Bolt (6g1)	<a href="#">Buy now</a>
16	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>
17	<a href="#">6E5124110000</a> Thermostat	<a href="#">Buy now</a>
18	<a href="#">6E041111019M</a> Inner cover, exhaust	<a href="#">Buy now</a>

# Cylinder & Crankcase



Ref	Part	
19	<a href="#">6E041112A100</a> Gasket,inner cover exhaust	<a href="#">Buy now</a>
20	<a href="#">6E041113019M</a> Outer cover, exhaust	<a href="#">Buy now</a>
21	<a href="#">6E0411140100</a> Gasket,outer cover exhaust	<a href="#">Buy now</a>
23	<a href="#">6E0114000000</a> Crank assembly	<a href="#">Buy now</a>
24	<a href="#">6E0114120000</a> Crank 1	<a href="#">Buy now</a>
25	<a href="#">6E0114220000</a> Crank 2	<a href="#">Buy now</a>
26	<a href="#">6E0116510100</a> Rod, connecting	<a href="#">Buy now</a>
27	<a href="#">93310418V100</a> Bearing (6e0)	<a href="#">Buy now</a>
28	<a href="#">6G1116810000</a> Pin, crank	<a href="#">Buy now</a>
29	<a href="#">902091811200</a> Washer 132116850000	<a href="#">Buy now</a>
30	<a href="#">933062041100</a> Bearing(6e0)	<a href="#">Buy now</a>
31	<a href="#">6E0116310098</a> Piston	<a href="#">Buy now</a>
32	<a href="#">6G1116100000</a> Piston ring set (std)	<a href="#">Buy now</a>
33	<a href="#">93310112V000</a> Bearing (6e0)	<a href="#">Buy now</a>
34	<a href="#">6G1116330000</a> Pin, piston	<a href="#">Buy now</a>


# Cylinder & Crankcase




Ref	Part	
35	<a href="#">934501302200</a> Circlip 132116340000	<a href="#">Buy now</a>
36	<a href="#">6E011191019M</a> Cover, cylinder head 1	<a href="#">Buy now</a>
37	<a href="#">6E0111930100</a> Gasket,head cover	<a href="#">Buy now</a>
39	<a href="#">9020132M4800</a> Shim (t:0.90mm)	<a href="#">Buy now</a>
40	<a href="#">9310220M0600</a> Oil seal(6j1)	<a href="#">Buy now</a>
41	<a href="#">6E015396019M</a> Housing, oil seal	<a href="#">Buy now</a>
42	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
43	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
44	<a href="#">9310111M2500</a> Oil seal(6e0)	<a href="#">Buy now</a>
45	<a href="#">932103111400</a> O-ring	<a href="#">Buy now</a>
46	<a href="#">947020027200</a> Plug, spark (br7hs)	<a href="#">Buy now</a>

## Electric Parts

Fig.1, Ref.No.46




Ref	Part	
1	<a href="#">6E0823160094</a> Bracket, ignition coil	<a href="#">Buy now</a>
2	<a href="#">6E0823170000</a> Damper	<a href="#">Buy now</a>
3	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
4	<a href="#">6E0855702100</a> Ignition Coil assembly	<a href="#">Buy now</a>
5	<a href="#">973130603000</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">6G1823702100</a> Plug cap assembly	<a href="#">Buy now</a>
7	<a href="#">973130601000</a> Bolt	<a href="#">Buy now</a>
8	<a href="#">6E0855407000</a> C.d.i. unit assembly	<a href="#">Buy now</a>
9	<a href="#">6E0855480000</a> Holder, wire harness	<a href="#">Buy now</a>
10	<a href="#">9010506M1500</a> Bolt (6e0)	<a href="#">Buy now</a>
11	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>



Ref	Part	
3	<a href="#">6Y1242558000</a> Graphic, Fuel Tank 8	<a href="#">Buy now</a>
5	<a href="#">647246100300</a> Cap assembly	<a href="#">Buy now</a>
7	<a href="#">6Y1243290000</a> Seal	<a href="#">Buy now</a>
8	<a href="#">978850501600</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
9	<a href="#">663242680000</a> Gasket, housing fuel meter	<a href="#">Buy now</a>
10	<a href="#">6Y0243060100</a> Fuel pipe comp. 1	<a href="#">Buy now</a>
11	<a href="#">9044511M8100</a> Hose (I3000)	<a href="#">Buy now</a>
12	<a href="#">6Y1243600200</a> Primer pump assembly	<a href="#">Buy now</a>
13	<a href="#">9044511M0500</a> Hose (I1000)	<a href="#">Buy now</a>
14	<a href="#">650243515100</a> Band 1	<a href="#">Buy now</a>
15	<a href="#">6G1243050000</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>
17	<a href="#">650243510100</a> Band 1	<a href="#">Buy now</a>




# Intake




Ref	Part	
1	<a href="#">6E0136100000</a> Reed valve assembly	<a href="#">Buy now</a>
2	<a href="#">6E0W00040000</a> Reed set	<a href="#">Buy now</a>
3	<a href="#">6E0136210000</a> Gasket, valve seat	<a href="#">Buy now</a>
4	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>
5	<a href="#">6E0143010200</a> Carburetor assembly 1	<a href="#">Buy now</a>
6	<a href="#">6E0141800000</a> Float chamber assembly	<a href="#">Buy now</a>
7	<a href="#">6E0143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
8	<a href="#">978030401600</a> Screw, panhead (796)	<a href="#">Buy now</a>
9	<a href="#">677143830000</a> Screw, drain	<a href="#">Buy now</a>
10	<a href="#">6A1143980000</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">6E7143850000</a> Float	<a href="#">Buy now</a>
12	<a href="#">647143861000</a> Pin, float	<a href="#">Buy now</a>
13	<a href="#">6E0143410100</a> Nozzle, main	<a href="#">Buy now</a>
14	<a href="#">648143434000</a> Jet, main (#80)	<a href="#">Buy now</a>
15	<a href="#">6G8143920000</a> Valve, needle	<a href="#">Buy now</a>

# Intake




Ref	Part	
16	<a href="#">6E0141570000</a> Cover, plate	<a href="#">Buy now</a>
17	<a href="#">6E0142270000</a> Gasket	<a href="#">Buy now</a>
18	<a href="#">985800400800</a> Screw, pan head (713)	<a href="#">Buy now</a>
19	<a href="#">647143230000</a> Screw, air adjusting	<a href="#">Buy now</a>
20	<a href="#">646142120100</a> Spring, pilot adjusting	<a href="#">Buy now</a>
21	<a href="#">648143210000</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
22	<a href="#">648143422300</a> Jet, pilot (#46)	<a href="#">Buy now</a>
23	<a href="#">647143260000</a> Screw, guide	<a href="#">Buy now</a>
24	<a href="#">985170402000</a> Screw, pan head	<a href="#">Buy now</a>
25	<a href="#">6E0244130000</a> Cover, pump	<a href="#">Buy now</a>
26	<a href="#">6E0244710000</a> Diaphragm	<a href="#">Buy now</a>
27	<a href="#">6E0244350000</a> Gasket, cover pump	<a href="#">Buy now</a>
28	<a href="#">6E0244120000</a> Body, pump	<a href="#">Buy now</a>
29	<a href="#">6E0244230000</a> Spring	<a href="#">Buy now</a>
30	<a href="#">6E0143460000</a> Plate	<a href="#">Buy now</a>

# Intake




Ref	Part	
31	<a href="#">6E0244110000</a> Diaphragm	<a href="#">Buy now</a>
32	<a href="#">6E0244340000</a> Gasket, body pump	<a href="#">Buy now</a>
33	<a href="#">6E0141980000</a> Gasket	<a href="#">Buy now</a>
34	<a href="#">953030670000</a> Nut	<a href="#">Buy now</a>
35	<a href="#">929030660000</a> Washer, plain (646)	<a href="#">Buy now</a>
36	<a href="#">6E0144170000</a> Cover 1	<a href="#">Buy now</a>
37	<a href="#">6E0144180000</a> Cover 2	<a href="#">Buy now</a>
38	<a href="#">978030502500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
39	<a href="#">929030560000</a> Washer, plain (646)	<a href="#">Buy now</a>
40	<a href="#">977804072000</a> Ybs81-420 screw,0.head tapping	<a href="#">Buy now</a>
41	<a href="#">6E0412560000</a> Rod, choke link	<a href="#">Buy now</a>
42	<a href="#">6E0412710100</a> Knob, choke	<a href="#">Buy now</a>
43	<a href="#">6E0412720000</a> Knob, choke 2	<a href="#">Buy now</a>
44	<a href="#">9020212M1600</a> Washer, plate (6e0)	<a href="#">Buy now</a>
45	<a href="#">661412620200</a> Joint, choke lever	<a href="#">Buy now</a>

## Intake




Ref	Part	
46	<a href="#">956210632500</a> Bolt, stud(6e0)	<a href="#">Buy now</a>
47	<a href="#">9011606M0800</a> Bolt, stud (689)	<a href="#">Buy now</a>

## Lower Casing & Drive




Ref	Part	
4	<a href="#">6E0453160900</a> Bushing	<a href="#">Buy now</a>
5	<a href="#">9310111M1400</a> Oil seal	<a href="#">Buy now</a>
6	<a href="#">6E0452510000</a> Anode	<a href="#">Buy now</a>
7	<a href="#">970800601200</a> Bolt(gh1)	<a href="#">Buy now</a>
8	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
9	<a href="#">903400801400</a> Plug, straight screw	<a href="#">Buy now</a>
10	<a href="#">970800603500</a> Bolt(j52)	<a href="#">Buy now</a>
11	<a href="#">6E045321019M</a> Plate	<a href="#">Buy now</a>
12	<a href="#">6E0453150000</a> Packing,lower casing	<a href="#">Buy now</a>
13	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
15	<a href="#">6E0441500000</a> Shift cam assembly	<a href="#">Buy now</a>
16	<a href="#">6G1441470000</a> Boot, shift rod	<a href="#">Buy now</a>
17	<a href="#">6E0443110000</a> Housing, water pump	<a href="#">Buy now</a>
18	<a href="#">6E0443150000</a> Gasket,water pump 1	<a href="#">Buy now</a>

## Lower Casing & Drive




Ref	Part	
19	<a href="#">6E0443224000</a> Insert, cartridge	<a href="#">Buy now</a>
20	<a href="#">6E0443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
21	<a href="#">6E0443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
22	<a href="#">6E0443520000</a> Impeller	<a href="#">Buy now</a>
23	<a href="#">970800604500</a> Bolt, hexagon	<a href="#">Buy now</a>
24	<a href="#">6E0443280000</a> Plate	<a href="#">Buy now</a>
25	<a href="#">936041808000</a> Pin, dowel. (647)	<a href="#">Buy now</a>
26	<a href="#">6E0443610000</a> Tube, water	<a href="#">Buy now</a>
27	<a href="#">646443650000</a> Damper, water seal 1	<a href="#">Buy now</a>
28	<a href="#">6E0455110000</a> Shaft, drive	<a href="#">Buy now</a>
30	<a href="#">936040906600</a> Pin, dowel	<a href="#">Buy now</a>
31	<a href="#">6E0455510000</a> Pinion (13t)	<a href="#">Buy now</a>
32	<a href="#">990010660000</a> Circlip(53l)	<a href="#">Buy now</a>
33	<a href="#">9020111M4900</a> Washer, plate (6e0)	<a href="#">Buy now</a>
35	<a href="#">6E0455600000</a> Gear 1 assembly (27t)	<a href="#">Buy now</a>

## Lower Casing & Drive




Ref	Part	
36	<a href="#">654456350000</a> Plunger, shift	<a href="#">Buy now</a>
37	<a href="#">905011006400</a> Spring, compression 6164563600	<a href="#">Buy now</a>
38	<a href="#">654456330000</a> Ring, cross pin	<a href="#">Buy now</a>
39	<a href="#">902500504600</a> Pin, straight	<a href="#">Buy now</a>
40	<a href="#">6E0456310000</a> Clutch, dog	<a href="#">Buy now</a>
41	<a href="#">6E0456110000</a> Shaft, Propeller	<a href="#">Buy now</a>
42	<a href="#">9020113M5000</a> Washer, plate (6e0)	<a href="#">Buy now</a>
43	<a href="#">6E0455700000</a> Gear 2 assembly (27t)	<a href="#">Buy now</a>
45	<a href="#">9310113M1200</a> Oil seal	<a href="#">Buy now</a>
46	<a href="#">932104821400</a> O-ring	<a href="#">Buy now</a>
47	<a href="#">6E04536109EJ</a> Cap, lower casing	<a href="#">Buy now</a>
48	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
49	<a href="#">902500500900</a> Pin, straight 6034561500	<a href="#">Buy now</a>
50	<a href="#">647456160200</a> Nut, propeller	<a href="#">Buy now</a>
51	<a href="#">914903003000</a> Pin, cotter	<a href="#">Buy now</a>

## Lower Casing & Drive




Ref	Part	
52	<a href="#">6E0459450000</a> Propeller (3x7-1/4 x7-1/4 -ba)	<a href="#">Buy now</a>
53	<a href="#">6E04533100CA</a> Housing, bearing	<a href="#">Buy now</a>
54	<a href="#">6E0453180100</a> Bushing, drive shaft 3	<a href="#">Buy now</a>
55	<a href="#">9342022M0300</a> Cir clip (6e0)	<a href="#">Buy now</a>
56	<a href="#">978900502500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
57	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>

# Magneto




Ref	Part	
1	<a href="#">6E0855507000</a> Rotor Assembly	<a href="#">Buy now</a>
2	<a href="#">6E0157230094</a> Pulley, Starter	<a href="#">Buy now</a>
3	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>
4	<a href="#">6E0855607000</a> Base assembly	<a href="#">Buy now</a>
5	<a href="#">6E0153590094</a> Housing, oil seal	<a href="#">Buy now</a>
6	<a href="#">6E0855207000</a> Charge coil ass'y	<a href="#">Buy now</a>
7	<a href="#">985070501600</a> Screw, pan head(jj6)	<a href="#">Buy now</a>
8	<a href="#">6E0855957000</a> Coil pulser assembly 1	<a href="#">Buy now</a>
9	<a href="#">985070401000</a> Screw, pan head(6g8)	<a href="#">Buy now</a>
10	<a href="#">6E0855927000</a> Pulser coil assembly 2	<a href="#">Buy now</a>
11	<a href="#">901590503700</a> Screw,w/washer	<a href="#">Buy now</a>
12	<a href="#">6E0813367000</a> Grommet	<a href="#">Buy now</a>
13	<a href="#">6E0813287000</a> Clamp	<a href="#">Buy now</a>
15	<a href="#">932104215900</a> O-ring (647)	<a href="#">Buy now</a>
16	<a href="#">9310220M1500</a> Oil seal (6e0)	<a href="#">Buy now</a>

# Magneto




Ref	Part	
18	<a href="#">6E0241830000</a> Damper, locating 3	<a href="#">Buy now</a>
19	<a href="#">901701011300</a> Nut, crank shaft (650)	<a href="#">Buy now</a>
20	<a href="#">90201102G900</a> Washer, plate (26h)	<a href="#">Buy now</a>
21	<a href="#">902800400600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
22	<a href="#">6E0813038000</a> Lighting coil assembly	<a href="#">Buy now</a>
23	<a href="#">901590504000</a> Screw, pan head(4my)	<a href="#">Buy now</a>

## Optional Parts




Ref	Part	
1	<a href="#">6G1243040100</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">646242510100</a> Strainer 1	<a href="#">Buy now</a>
3	<a href="#">688243780000</a> Pipe, joint	<a href="#">Buy now</a>
4	<a href="#">90445092K100</a> Hose (l420)	<a href="#">Buy now</a>
5	<a href="#">904450922000</a> Hose (l1500)	<a href="#">Buy now</a>
6	<a href="#">904670800400</a> Clip, pipe 6162435600	<a href="#">Buy now</a>
7	<a href="#">663819101000</a> Voltage Regulator assembly	<a href="#">Buy now</a>
8	<a href="#">676819700000</a> Rectifier assembly	<a href="#">Buy now</a>
9	<a href="#">663821510000</a> Fuse	<a href="#">Buy now</a>
10	<a href="#">985800552500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
11	<a href="#">929060560000</a> Washer(1rw)	<a href="#">Buy now</a>
13	<a href="#">6E0835532000</a> Wire, lead	<a href="#">Buy now</a>

# Repair Kit



Ref	Part	
1	<a href="#">6E0W00010200</a> Gasket kit, power unit	<a href="#">Buy now</a>
2	<a href="#">932104215900</a> O-ring (647)	<a href="#">Buy now</a>
3	<a href="#">9310220M1500</a> Oil seal (6e0)	<a href="#">Buy now</a>
4	<a href="#">6E041112A100</a> Gasket,inner cover exhaust	<a href="#">Buy now</a>
5	<a href="#">6E0411140100</a> Gasket,outer cover exhaust	<a href="#">Buy now</a>
12	<a href="#">6E0143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
13	<a href="#">6A1143980000</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">6E0451130000</a> Gasket,upper casing	<a href="#">Buy now</a>
24	<a href="#">6E0142270000</a> Gasket	<a href="#">Buy now</a>
25	<a href="#">647143230000</a> Screw, air adjusting	<a href="#">Buy now</a>
26	<a href="#">6E0244710000</a> Diaphragm	<a href="#">Buy now</a>
27	<a href="#">6E0244110000</a> Diaphragm	<a href="#">Buy now</a>
36	<a href="#">6E0443110000</a> Housing, water pump	<a href="#">Buy now</a>
37	<a href="#">6E0443150000</a> Gasket,water pump 1	<a href="#">Buy now</a>


# Starter




Ref	Part	
1	<a href="#">6E0157100494</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">6E4157117194</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">6E0157140100</a> Drum, sheave	<a href="#">Buy now</a>
4	<a href="#">9051008M0300</a> Spring, spiral (6g1)	<a href="#">Buy now</a>
5	<a href="#">6E0157170000</a> Shaft, starter	<a href="#">Buy now</a>
6	<a href="#">973130603500</a> Bolt(3rv)	<a href="#">Buy now</a>
7	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
8	<a href="#">677157410100</a> Pawl, drive	<a href="#">Buy now</a>
9	<a href="#">9343006M0200</a> Circlip (689)	<a href="#">Buy now</a>
12	<a href="#">6G1157550000</a> Handle, starter	<a href="#">Buy now</a>
13	<a href="#">6E0157580100</a> Guide, wire	<a href="#">Buy now</a>
14	<a href="#">6E0157610000</a> Seal, rubber 1	<a href="#">Buy now</a>
15	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>
16	<a href="#">9020106M3000</a> Washer, plate (6a1)	<a href="#">Buy now</a>
17	<a href="#">689157790100</a> Cover	<a href="#">Buy now</a>

## Starter

Ref	Part	
18	<a href="#">9010506M1500</a> Bolt (6e0)	<a href="#">Buy now</a>




# Upper Casing & Bracket




Ref	Part	
2	<a href="#">6E0451130000</a> Gasket,upper casing	<a href="#">Buy now</a>
3	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
4	<a href="#">973950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
5	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">973950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
8	<a href="#">9538R0670000</a> Nut	<a href="#">Buy now</a>
9	<a href="#">647451510100</a> Cover, upper casing	<a href="#">Buy now</a>
10	<a href="#">9048010M1300</a> Grommet (6e0)	<a href="#">Buy now</a>
13	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
14	<a href="#">6E0431160000</a> Screw, transom clamp	<a href="#">Buy now</a>
15	<a href="#">6EEG31180000</a> Handle, transom cl	<a href="#">Buy now</a>
16	<a href="#">9025404M0000</a> Pin(6a1)	<a href="#">Buy now</a>
18	<a href="#">9020108M4700</a> Washer, plate(6e0)	<a href="#">Buy now</a>
19	<a href="#">929900860000</a> Washer, plain (663)	<a href="#">Buy now</a>
20	<a href="#">957800830000</a> Nut, nylon (6j8)	<a href="#">Buy now</a>

# Upper Casing & Bracket



Ref	Part	
21	<a href="#">901010633500</a> Bolt, hexagon (624)	<a href="#">Buy now</a>
22	<a href="#">905600608800</a> Collar	<a href="#">Buy now</a>
24	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
27	<a href="#">958800603500</a> Bolt, flange(4nx)	<a href="#">Buy now</a>
29	<a href="#">6E0436320000</a> Knob, tilt	<a href="#">Buy now</a>
30	<a href="#">6E0433130094</a> Bracket, swivel 3	<a href="#">Buy now</a>
31	<a href="#">620431890000</a> Bushing	<a href="#">Buy now</a>
32	<a href="#">958950602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
33	<a href="#">905081602000</a> Spring 6474319800	<a href="#">Buy now</a>
34	<a href="#">905081602100</a> Spring 6474318800	<a href="#">Buy now</a>
36	<a href="#">916902001000</a> Pin, spring	<a href="#">Buy now</a>
37	<a href="#">953800860000</a> Nut (661)	<a href="#">Buy now</a>
38	<a href="#">6E0425280200</a> Plate, friction	<a href="#">Buy now</a>
39	<a href="#">6E0431600000</a> Tilt rod assembly	<a href="#">Buy now</a>
40	<a href="#">689431650000</a> Plate, tilt lock	<a href="#">Buy now</a>

## Upper Casing & Bracket



Ref	Part	
41	<a href="#">916903000800</a> Pin. spring(656)	<a href="#">Buy now</a>
42	<a href="#">6E043614009M</a> Plate, tilt lock	<a href="#">Buy now</a>
43	<a href="#">9050814M1000</a> Spring, torsion (6e0)	<a href="#">Buy now</a>
44	<a href="#">9050814M1100</a> Spring, torsion (6e0)	<a href="#">Buy now</a>
46	<a href="#">999990333100</a> Bushing, Pivot Shaft	<a href="#">Buy now</a>
47	<a href="#">958950601000</a> Bolt, flange(7ht)	<a href="#">Buy now</a>
48	<a href="#">937000600400</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
49	<a href="#">663451190000</a> Cap, grease nipple	<a href="#">Buy now</a>
50	<a href="#">6E0281930094</a> Plug, water check	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.