



# Yamaha 60FETO 2003

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

|                                   |    |
|-----------------------------------|----|
| <b>BOTTOM COWLING</b>             | 3  |
| <b>BRACKET 1</b>                  | 6  |
| <b>BRACKET 2</b>                  | 10 |
| <b>CARBURETOR</b>                 | 13 |
| <b>CONTROL</b>                    | 17 |
| <b>CRANKSHAFT. PISTON</b>         | 20 |
| <b>CYLINDER. CRANKCASE</b>        | 22 |
| <b>ELECTRICAL</b>                 | 25 |
| <b>FUEL</b>                       | 28 |
| <b>FUEL TANK</b>                  | 31 |
| <b>GENERATOR</b>                  | 32 |
| <b>INTAKE</b>                     | 34 |
| <b>LOWER CASING. DRIVE 1</b>      | 36 |
| <b>LOWER CASING. DRIVE 2</b>      | 42 |
| <b>LOWER CASING. DRIVE 3</b>      | 45 |
| <b>LOWER CASING. DRIVE 4</b>      | 51 |
| <b>METER</b>                      | 53 |
| <b>OIL PUMP</b>                   | 54 |
| <b>POWER TRIM &amp; TILT ASSY</b> | 58 |
| <b>REMOTE CONTROL ASSY</b>        | 64 |
| <b>REMOTE CONTROL BOX</b>         | 69 |
| <b>REPAIR KIT 1</b>               | 70 |
| <b>REPAIR KIT 2</b>               | 73 |
| <b>STARTING MOTOR</b>             | 76 |
| <b>STEERING GUIDE</b>             | 78 |
| <b>TOP COWLING</b>                | 79 |
| <b>UPPER CASING</b>               | 82 |

## Bottom Cowling




6H23300-2110

**D2**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H3-42711-24-4D</a><br>Cowling, bottom 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">6H3-44391-01</a><br>Nipple, hose         | <a href="#">Buy now</a> |
| 3   | <a href="#">6H3-42815-01-4D</a><br>Lever, clamp      | <a href="#">Buy now</a> |
| 4   | <a href="#">6H3-42817-01-4D</a><br>Lever, clamp      | <a href="#">Buy now</a> |
| 5   | <a href="#">90386-13M38</a><br>Bushing (697)         | <a href="#">Buy now</a> |
| 6   | <a href="#">90206-13M10</a><br>Washer, wave (6e5)    | <a href="#">Buy now</a> |
| 7   | <a href="#">6H3-42813-00</a><br>Spring, clamp lever  | <a href="#">Buy now</a> |
| 8   | <a href="#">90269-04M03</a><br>Rivet (6h3)           | <a href="#">Buy now</a> |
| 9   | <a href="#">6H3-42816-00</a><br>Lever, clamp 2       | <a href="#">Buy now</a> |
| 10  | <a href="#">6H3-42818-00</a><br>Lever, clamp 4       | <a href="#">Buy now</a> |
| 11  | <a href="#">90119-06M09</a><br>Bolt, with washer     | <a href="#">Buy now</a> |
| 12  | <a href="#">6H3-42716-02</a><br>Rubber, seal 1       | <a href="#">Buy now</a> |
| 13  | <a href="#">6K5-42717-00</a><br>Rubber, seal 2       | <a href="#">Buy now</a> |
| 14  | <a href="#">6E5-42724-00</a><br>Grommet              | <a href="#">Buy now</a> |
| 15  | <a href="#">6H3-42725-10</a><br>Grommet<br>UR        | <a href="#">Buy now</a> |

## Bottom Cowling




6H23300-2110

**D2**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 15  | <a href="#">6H3-42725-30</a><br>Grommet<br>UR            | <a href="#">Buy now</a> |
| 16  | <a href="#">6H3-42738-01-5B</a><br>Plate, fitting        | <a href="#">Buy now</a> |
| 17  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 18  | <a href="#">92995-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 19  | <a href="#">6H3-42727-00</a><br>Grommet                  | <a href="#">Buy now</a> |
| 20  | <a href="#">90480-09M12</a><br>Grommet (6a0)             | <a href="#">Buy now</a> |
| 21  | <a href="#">90387-06M69</a><br>Collar (688)              | <a href="#">Buy now</a> |
| 22  | <a href="#">90119-06M61</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 23  | <a href="#">6H3-42768-00</a><br>Damper                   | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-24367-01</a><br>Clamp, fuel pipe 2       | <a href="#">Buy now</a> |
| 25  | <a href="#">90157-06M01</a><br>Screw (6e5)               | <a href="#">Buy now</a> |
| 26  | <a href="#">92990-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 27  | <a href="#">688-42726-10</a><br>Grommet                  | <a href="#">Buy now</a> |
| 28  | <a href="#">90464-09M13</a><br>Clamp (6h1)               | <a href="#">Buy now</a> |
| 30  | <a href="#">6G1-42748-00</a><br>Grommet                  | <a href="#">Buy now</a> |

## Bottom Cowling




6H23300-2110

**D2**


| Ref | Part                                           |                         |
|-----|------------------------------------------------|-------------------------|
| 31  | <a href="#">6H3-42741-01-4D</a><br>Apron       | <a href="#">Buy now</a> |
| 32  | <a href="#">6H3-42771-01-4D</a><br>Apron       | <a href="#">Buy now</a> |
| 33  | <a href="#">97095-06025</a><br>Bolt            | <a href="#">Buy now</a> |
| 35  | <a href="#">97095-06020</a><br>Bolt(7u8)       | <a href="#">Buy now</a> |
| 39  | <a href="#">6H3-42718-00</a><br>Rubber, seal 3 | <a href="#">Buy now</a> |
| 40  | <a href="#">6G5-42791-10</a><br>Mark 1         | <a href="#">Buy now</a> |
| 41  | <a href="#">6A1-28176-00</a><br>Label Caution  | <a href="#">Buy now</a> |
| 42  | <a href="#">6E3-8257H-00</a><br>Plate Mark     | <a href="#">Buy now</a> |

# Bracket 1



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H1-43111-01-4D</a><br>Bracket, clamp 1      | <a href="#">Buy now</a> |
| 2   | <a href="#">6H1-45251-03</a><br>Anode                    | <a href="#">Buy now</a> |
| 3   | <a href="#">6H1-44526-00</a><br>Plate 2                  | <a href="#">Buy now</a> |
| 4   | <a href="#">90119-06M29</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 5   | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 6   | <a href="#">92995-06100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |
| 7   | <a href="#">92995-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 8   | <a href="#">6H1-82148-00</a><br>Wire, lead               | <a href="#">Buy now</a> |
| 9   | <a href="#">97095-06010</a><br>Bolt                      | <a href="#">Buy now</a> |
| 11  | <a href="#">6H1-43112-00-4D</a><br>Bracket, clamp 2      | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5-82148-00</a><br>Wire, lead 5             | <a href="#">Buy now</a> |
| 13  | <a href="#">97880-06012</a><br>Screw, pan head(62j)      | <a href="#">Buy now</a> |
| 14  | <a href="#">97095-10045</a><br>Bolt(64d)                 | <a href="#">Buy now</a> |
| 15  | <a href="#">92995-10100</a><br>Ybs67-10 washer, spring   | <a href="#">Buy now</a> |
| 16  | <a href="#">6H1-43311-01-4D</a><br>Bracket, swivel 1     | <a href="#">Buy now</a> |

# Bracket 1




6H30010-9151

**D6**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 17  | <a href="#">93700-06M03</a><br>Nipple, grease(6a1)       | <a href="#">Buy now</a> |
| 18  | <a href="#">663-45119-00</a><br>Cap, grease nipple<br>AP | <a href="#">Buy now</a> |
| 19  | <a href="#">90464-11M18</a><br>Clamp(6e5)                | <a href="#">Buy now</a> |
| 20  | <a href="#">90338-05M03</a><br>Plug (6h1)                | <a href="#">Buy now</a> |
| 21  | <a href="#">688-43131-03</a><br>Bolt, clamp bracket      | <a href="#">Buy now</a> |
| 22  | <a href="#">90386-22M15</a><br>Bushing (688)             | <a href="#">Buy now</a> |
| 23  | <a href="#">90201-22M67</a><br>Washer, plate (688)       | <a href="#">Buy now</a> |
| 24  | <a href="#">90185-22043</a><br>Nut, self-locking         | <a href="#">Buy now</a> |
| 25  | <a href="#">6G5-43145-01</a><br>Cap, clamp bracket       | <a href="#">Buy now</a> |
| 26  | <a href="#">6H1-43181-01</a><br>Lever, tilt stop 1       | <a href="#">Buy now</a> |
| 27  | <a href="#">6H1-43185-01</a><br>Lever, tilt stop 2       | <a href="#">Buy now</a> |
| 28  | <a href="#">90386-10M16</a><br>Bushing (688)             | <a href="#">Buy now</a> |
| 29  | <a href="#">90387-10M02</a><br>Collar(6e5)               | <a href="#">Buy now</a> |
| 30  | <a href="#">91690-30020</a><br>Pin, spring (6h4)         | <a href="#">Buy now</a> |
| 31  | <a href="#">688-43160-01</a><br>Tilt rod ass'y           | <a href="#">Buy now</a> |


# Bracket 1




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 32  | <a href="#">688-43165-00</a><br>Stopper, tilt rod      | <a href="#">Buy now</a> |
| 33  | <a href="#">91690-30012</a><br>Pin, spring             | <a href="#">Buy now</a> |
| 34  | <a href="#">90502-16M02</a><br>Spring, conical (688)   | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5-43126-02</a><br>Pin, upper shock mount | <a href="#">Buy now</a> |
| 36  | <a href="#">90386-18M63</a><br>Bush(6e5)               | <a href="#">Buy now</a> |
| 37  | <a href="#">90386-18M35</a><br>Bush (688)              | <a href="#">Buy now</a> |
| 38  | <a href="#">93410-18M02</a><br>Circlip (6f2)           | <a href="#">Buy now</a> |
| 39  | <a href="#">90249-06M19</a><br>Pin(6e5)                | <a href="#">Buy now</a> |
| 40  | <a href="#">6G5-43148-00</a><br>Collar, distance       | <a href="#">Buy now</a> |
| 41  | <a href="#">90506-14M24</a><br>Spring, tension(6e5)    | <a href="#">Buy now</a> |
| 42  | <a href="#">6G5-43144-00</a><br>Hook, spring           | <a href="#">Buy now</a> |
| 44  | <a href="#">90101-12M65</a><br>Bolt                    | <a href="#">Buy now</a> |
| 45  | <a href="#">92995-12200</a><br>Ybs66-12 washer,plain   | <a href="#">Buy now</a> |
| 46  | <a href="#">90201-12426</a><br>Washe, plate(663)       | <a href="#">Buy now</a> |
| 47  | <a href="#">95380-12600</a><br>Nut (707)               | <a href="#">Buy now</a> |

# Bracket 1

| Ref | Part                                     |                         |
|-----|------------------------------------------|-------------------------|
| 48  | <a href="#">90440-14M00</a><br>Pipe(6h4) | <a href="#">Buy now</a> |




## Bracket 2




| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H1-83672-12</a><br>Trim sender                      | <a href="#">Buy now</a> |
| 2   | <a href="#">97885-06016</a><br>Screw, pan head(6b0)              | <a href="#">Buy now</a> |
| 3   | <a href="#">6H3-42510-12-4D</a><br>Steering bracket assembly     | <a href="#">Buy now</a> |
| 4   | <a href="#">90201-30M00</a><br>Washer, plate(6h1)                | <a href="#">Buy now</a> |
| 5   | <a href="#">90386-30M78</a><br>Bush(6h0)                         | <a href="#">Buy now</a> |
| 6   | <a href="#">90386-30M77</a><br>Bush(6h0)                         | <a href="#">Buy now</a> |
| 7   | <a href="#">93210-29M94</a><br>O-ring(6h1)                       | <a href="#">Buy now</a> |
| 8   | <a href="#">90386-30M60</a><br>Bush(6j8)                         | <a href="#">Buy now</a> |
| 9   | <a href="#">6H3-44551-01-4D</a><br>Housing, lower mount rubber 1 | <a href="#">Buy now</a> |
| 10  | <a href="#">93410-28M06</a><br>Circlip (688)                     | <a href="#">Buy now</a> |
| 11  | <a href="#">687-44555-00-94</a><br>Mount damper, lower side      | <a href="#">Buy now</a> |
| 12  | <a href="#">90201-12M16</a><br>Washer, plate (679)               | <a href="#">Buy now</a> |
| 13  | <a href="#">90202-25M04</a><br>Washer, plate (663)               | <a href="#">Buy now</a> |
| 14  | <a href="#">90201-13M19</a><br>Washer, plate (663)               | <a href="#">Buy now</a> |
| 15  | <a href="#">90109-12M21</a><br>Bolt (6h3)                        | <a href="#">Buy now</a> |

## Bracket 2




| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 16  | <a href="#">663-44575-00</a><br>Damper, lower mount rubber     | <a href="#">Buy now</a> |
| 17  | <a href="#">95380-12800</a><br>Nut crown(663)                  | <a href="#">Buy now</a> |
| 18  | <a href="#">6H3-44552-03-94</a><br>Housing, lower mount rubber | <a href="#">Buy now</a> |
| 19  | <a href="#">97075-08025</a><br>Bolt, hexagon deep recess       | <a href="#">Buy now</a> |
| 20  | <a href="#">92995-08100</a><br>Ybs67-8 washer, spring          | <a href="#">Buy now</a> |
| 21  | <a href="#">90501-14M08</a><br>Spring, compression(64j)        | <a href="#">Buy now</a> |
| 22  | <a href="#">90179-06066</a><br>Nut(663)                        | <a href="#">Buy now</a> |
| 23  | <a href="#">6H3-44553-01-4D</a><br>Cover, lower mount          | <a href="#">Buy now</a> |
| 25  | <a href="#">688-82127-02</a><br>Wire, lead 2                   | <a href="#">Buy now</a> |
| 26  | <a href="#">688-44514-00-94</a><br>Mount damper, upper side    | <a href="#">Buy now</a> |
| 27  | <a href="#">90101-10M49</a><br>Bolt                            | <a href="#">Buy now</a> |
| 28  | <a href="#">90201-20M21</a><br>Washer, plate (688)             | <a href="#">Buy now</a> |
| 29  | <a href="#">90202-20M06</a><br>Washer, plate (688)             | <a href="#">Buy now</a> |
| 30  | <a href="#">90201-11M22</a><br>Washer, plate (688)             | <a href="#">Buy now</a> |
| 31  | <a href="#">90185-10051</a><br>Nut, self-locking               | <a href="#">Buy now</a> |

## Bracket 2



| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 33  | <a href="#">688-44511-00-94</a><br>Cover, upper mount                      | <a href="#">Buy now</a> |
| 34  | <a href="#">97075-08035</a><br>Bolt(70w)                                   | <a href="#">Buy now</a> |
| 36  | <a href="#">6H3-48511-51-4D</a><br>Hook, steering<br><b>STEERING GUIDE</b> | <a href="#">Buy now</a> |
| 37  | <a href="#">90116-10175</a><br>Bolt, stud                                  | <a href="#">Buy now</a> |
| 37  | <a href="#">90116-10M28</a><br>Bolt, stud                                  | <a href="#">Buy now</a> |
| 39  | <a href="#">6H1-43376-00</a><br>Bolt, thrust receiver                      | <a href="#">Buy now</a> |
| 40  | <a href="#">90185-08057</a><br>Nut, nylon (6j8)                            | <a href="#">Buy now</a> |
| 41  | <a href="#">90465-11M10</a><br>Clamp                                       | <a href="#">Buy now</a> |
| 42  | <a href="#">703-82119-00</a><br>Cover, lead wire                           | <a href="#">Buy now</a> |


# Carburetor



**B4**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">62F-14301-00</a><br>Carburetor assembly 1       | <a href="#">Buy now</a> |
| 1   | <a href="#">6H2-14301-0A</a><br>Carburetor assembly 1       | <a href="#">Buy now</a> |
| 1   | <a href="#">6H3-14301-0A</a><br>Carburetor assembly 1       | <a href="#">Buy now</a> |
| 2   | <a href="#">62F-14302-00</a><br>Carburetor assembly 2       | <a href="#">Buy now</a> |
| 2   | <a href="#">6H2-14302-0A</a><br>Carburetor assembly 2       | <a href="#">Buy now</a> |
| 2   | <a href="#">6H3-14302-0A</a><br>Carburetor assembly 2       | <a href="#">Buy now</a> |
| 3   | <a href="#">62F-14303-00</a><br>Carburetor assembly 3       | <a href="#">Buy now</a> |
| 3   | <a href="#">6H2-14303-0A</a><br>Carburetor assembly 3       | <a href="#">Buy now</a> |
| 3   | <a href="#">6H3-14303-0A</a><br>Carburetor assembly 3       | <a href="#">Buy now</a> |
| 4   | <a href="#">97980-04114</a><br>Screw, pan head(ga5)         | <a href="#">Buy now</a> |
| 5   | <a href="#">63V-14523-00</a><br>Screw, stop<br>#2           | <a href="#">Buy now</a> |
| 6   | <a href="#">90501-10326</a><br>Spring coil(663)(carb)<br>#2 | <a href="#">Buy now</a> |
| 7   | <a href="#">6H2-14578-00</a><br>Collar<br>#3                | <a href="#">Buy now</a> |
| 8   | <a href="#">6H4-14146-00</a><br>Plate<br>#1,3               | <a href="#">Buy now</a> |
| 9   | <a href="#">6H3-14146-10</a><br>Plate<br>#2                 | <a href="#">Buy now</a> |


# Carburetor



**B4**


| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 10  | <a href="#">6H4-14147-00</a><br>O-ring                | <a href="#">Buy now</a> |
| 11  | <a href="#">692-14923-00</a><br>Screw, adjusting      | <a href="#">Buy now</a> |
| 12  | <a href="#">679-14555-00</a><br>Spring                | <a href="#">Buy now</a> |
| 12  | <a href="#">697-14555-00</a><br>Spring                | <a href="#">Buy now</a> |
| 13  | <a href="#">93210-04228</a><br>O-ring (371)           | <a href="#">Buy now</a> |
| 14  | <a href="#">6H3-14590-01</a><br>Needle valve assembly | <a href="#">Buy now</a> |
| 14  | <a href="#">6H4-14590-01</a><br>Needle valve assembly | <a href="#">Buy now</a> |
| 15  | <a href="#">6H4-14548-00</a><br>Pin, float arm        | <a href="#">Buy now</a> |
| 16  | <a href="#">98580-04008</a><br>Screw, pan head (713)  | <a href="#">Buy now</a> |
| 17  | <a href="#">663-14159-00</a><br>Clip                  | <a href="#">Buy now</a> |
| 18  | <a href="#">676-14186-00</a><br>Pin, valve            | <a href="#">Buy now</a> |
| 19  | <a href="#">6H4-14985-01</a><br>Float                 | <a href="#">Buy now</a> |
| 20  | <a href="#">62F-14947-00</a><br>Jet, Needle           | <a href="#">Buy now</a> |
| 20  | <a href="#">6H2-14947-71</a><br>Jet, needle           | <a href="#">Buy now</a> |
| 20  | <a href="#">6H3-14947-71</a><br>Jet, needle           | <a href="#">Buy now</a> |

# Carburetor



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 21  | <a href="#">676-14943-32</a><br>Jet, main (#125)            | <a href="#">Buy now</a> |
| 21  | <a href="#">6H3-14943-35</a><br>Jet, main (#140)<br>#1,2    | <a href="#">Buy now</a> |
| 21  | <a href="#">6H3-14943-36</a><br>Jet, main (#145)<br>#3      | <a href="#">Buy now</a> |
| 21  | <a href="#">6H3-14943-37</a><br>Jet, main (#150)            | <a href="#">Buy now</a> |
| 22  | <a href="#">676-14966-00</a><br>Rubber cap                  | <a href="#">Buy now</a> |
| 23  | <a href="#">6H3-14948-13</a><br>Jet (#65)                   | <a href="#">Buy now</a> |
| 23  | <a href="#">6H3-14948-17</a><br>Jet (#75)                   | <a href="#">Buy now</a> |
| 23  | <a href="#">6H4-14948-13</a><br>Jet (#65)                   | <a href="#">Buy now</a> |
| 24  | <a href="#">6H4-14984-00</a><br>Gasket, float chamber       | <a href="#">Buy now</a> |
| 25  | <a href="#">6H3-14992-00</a><br>Screw, drain                | <a href="#">Buy now</a> |
| 26  | <a href="#">93210-04230</a><br>O-ring (371)                 | <a href="#">Buy now</a> |
| 27  | <a href="#">6H4-14980-00</a><br>Body, float chamber<br>#1,3 | <a href="#">Buy now</a> |
| 28  | <a href="#">6H3-14980-10</a><br>Body, float chamber<br>#2   | <a href="#">Buy now</a> |
| 29  | <a href="#">6H3-24452-10</a><br>Cover<br>#2                 | <a href="#">Buy now</a> |
| 30  | <a href="#">6H4-14567-00</a><br>Screw<br>#2                 | <a href="#">Buy now</a> |


# Carburetor



**B4**

| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 31  | <a href="#">6H3-14137-00</a><br>Clip<br>#2                   | <a href="#">Buy now</a> |
| 32  | <a href="#">6H3-14349-00</a><br>Pipe<br>#2                   | <a href="#">Buy now</a> |
| 33  | <a href="#">6H3-14380-00</a><br>Prime starter assembly<br>#2 | <a href="#">Buy now</a> |
| 34  | <a href="#">97803-04010</a><br>Screw, pan head (e56)<br>#2   | <a href="#">Buy now</a> |
| 35  | <a href="#">95380-03600</a><br>Nut (6g8)<br>#2               | <a href="#">Buy now</a> |
| 36  | <a href="#">98980-03006</a><br>Screw, bind(6g1)<br>#2        | <a href="#">Buy now</a> |
| 37  | <a href="#">6L5-24421-00</a><br>Valve, check<br>#2           | <a href="#">Buy now</a> |
| 38  | <a href="#">6H4-24413-00</a><br>Body 2<br>#2                 | <a href="#">Buy now</a> |
| 39  | <a href="#">6H4-24486-00</a><br>O-ring<br>#2                 | <a href="#">Buy now</a> |
| 40  | <a href="#">6H3-24411-10</a><br>Diaphragm<br>#2              | <a href="#">Buy now</a> |
| 41  | <a href="#">6H3-24434-10</a><br>Gasket, body<br>#2           | <a href="#">Buy now</a> |
| 42  | <a href="#">90465-18147</a><br>Clamp                         | <a href="#">Buy now</a> |
| 43  | <a href="#">97013-06012</a><br>Bolt(gh1)                     | <a href="#">Buy now</a> |
| 44  | <a href="#">92903-06600</a><br>Washer, plain (646)           | <a href="#">Buy now</a> |


# Control



**D4**


| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">689-42169-01</a><br>Joint                    | <a href="#">Buy now</a> |
| 2   | <a href="#">682-41237-00</a><br>Joint, link 2            | <a href="#">Buy now</a> |
| 3   | <a href="#">95380-05600</a><br>Nut, hexagon (663)        | <a href="#">Buy now</a> |
| 4   | <a href="#">6H3-41631-00</a><br>Lever, magneto control 1 | <a href="#">Buy now</a> |
| 5   | <a href="#">90157-06M13</a><br>Screw, pan head(6h4)      | <a href="#">Buy now</a> |
| 6   | <a href="#">95380-06600</a><br>Nut(661)                  | <a href="#">Buy now</a> |
| 7   | <a href="#">688-44194-00</a><br>Cap                      | <a href="#">Buy now</a> |
| 8   | <a href="#">90387-06M60</a><br>Collar (6h3)              | <a href="#">Buy now</a> |
| 9   | <a href="#">97095-06025</a><br>Bolt                      | <a href="#">Buy now</a> |
| 10  | <a href="#">6H3-41632-20</a><br>Lever, magneto control   | <a href="#">Buy now</a> |
| 11  | <a href="#">90508-26M35</a><br>Spring, torsion           | <a href="#">Buy now</a> |
| 12  | <a href="#">6H3-41633-10</a><br>Lever, magneto control   | <a href="#">Buy now</a> |
| 13  | <a href="#">90109-06M43</a><br>Bolt(6h4)                 | <a href="#">Buy now</a> |
| 14  | <a href="#">6H1-41237-00</a><br>Joint, link              | <a href="#">Buy now</a> |
| 15  | <a href="#">6F5-41237-00</a><br>Joint, link              | <a href="#">Buy now</a> |

# Control



| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6H3-41636-10-94</a><br>Rod, Magneto Control         | <a href="#">Buy now</a> |
| 18  | <a href="#">6H3-48344-00</a><br>Cable end, remote control       | <a href="#">Buy now</a> |
| 19  | <a href="#">90468-18008</a><br>Clip 620436610000                | <a href="#">Buy now</a> |
| 21  | <a href="#">6H4-41237-00</a><br>Joint, link                     | <a href="#">Buy now</a> |
| 23  | <a href="#">6H3-41213-10</a><br>Cam, accel.                     | <a href="#">Buy now</a> |
| 24  | <a href="#">90206-10M04</a><br>Washer, wave (676)               | <a href="#">Buy now</a> |
| 27  | <a href="#">6H3-44120-12</a><br>Handle gear shift assembly<br>L | <a href="#">Buy now</a> |
| 28  | <a href="#">648-42715-00</a><br>Bushing 2                       | <a href="#">Buy now</a> |
| 29  | <a href="#">93501-04M02</a><br>Ball (697)                       | <a href="#">Buy now</a> |
| 30  | <a href="#">90501-12082</a><br>Spring 6484411600                | <a href="#">Buy now</a> |
| 31  | <a href="#">6H3-44117-00-94</a><br>Bracket 1                    | <a href="#">Buy now</a> |
| 31  | <a href="#">6J2-44117-01-94</a><br>Bracket                      | <a href="#">Buy now</a> |
| 32  | <a href="#">97013-06020</a><br>Bolt(62y)                        | <a href="#">Buy now</a> |
| 33  | <a href="#">92903-06600</a><br>Washer, plain (646)              | <a href="#">Buy now</a> |
| 34  | <a href="#">90386-07M58</a><br>Bush(6h1)                        | <a href="#">Buy now</a> |


# Control



**D4**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 35  | <a href="#">92990-08200</a><br>Ybs66-8 washer, plain      | <a href="#">Buy now</a> |
| 36  | <a href="#">91490-20012</a><br>Pin, cotter (648)          | <a href="#">Buy now</a> |
| 37  | <a href="#">6H3-44121-01</a><br>Lever, shift rod          | <a href="#">Buy now</a> |
| 39  | <a href="#">90202-07M07</a><br>Washer, plate (688)        | <a href="#">Buy now</a> |
| 40  | <a href="#">688-44122-00</a><br>Bushing, shift rod lever  | <a href="#">Buy now</a> |
| 41  | <a href="#">663-48344-00</a><br>Cable end, remote control | <a href="#">Buy now</a> |
| 42  | <a href="#">6H3-48538-00</a><br>Clamp, cable              | <a href="#">Buy now</a> |

## Crankshaft. Piston




6H30010-9030

**B1**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H3-15359-00-94</a><br>Housing, oil seal      | <a href="#">Buy now</a> |
| 2   | <a href="#">93102-30M23</a><br>Oil seal (6h3)             | <a href="#">Buy now</a> |
| 3   | <a href="#">93106-18M01</a><br>Oil seal (6h3)             | <a href="#">Buy now</a> |
| 4   | <a href="#">93210-65M50</a><br>O-ring                     | <a href="#">Buy now</a> |
| 5   | <a href="#">97095-06020</a><br>Bolt(7u8)                  | <a href="#">Buy now</a> |
| 6   | <a href="#">92995-06600</a><br>Washer, plain (646)        | <a href="#">Buy now</a> |
| 7   | <a href="#">6H3-11400-10</a><br>Crankshaft assembly       | <a href="#">Buy now</a> |
| 8   | <a href="#">93311-636U6</a><br>Bearing, needle (6h3)      | <a href="#">Buy now</a> |
| 9   | <a href="#">93102-36M24</a><br>Oil seal(52w)              | <a href="#">Buy now</a> |
| 10  | <a href="#">93440-49M04</a><br>Circlip (6h3)              | <a href="#">Buy now</a> |
| 11  | <a href="#">93306-306V1</a><br>Bearing(6h2)               | <a href="#">Buy now</a> |
| 12  | <a href="#">6H3-11536-00</a><br>Gear, drive               | <a href="#">Buy now</a> |
| 13  | <a href="#">93210-46M16</a><br>O-ring (688)               | <a href="#">Buy now</a> |
| 14  | <a href="#">6H3-11631-01-96</a><br>Piston (std)           | <a href="#">Buy now</a> |
| 14  | <a href="#">6H3-11635-01</a><br>Piston (0.25mm o/s)<br>AP | <a href="#">Buy now</a> |

# Crankshaft. Piston




6H30010-9030

**B1**


| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 14  | <a href="#">6H3-11636-01</a><br>Piston (0.50mm o/s)<br>AP       | <a href="#">Buy now</a> |
| 15  | <a href="#">6K5-11601-02</a><br>Piston ring set (std)           | <a href="#">Buy now</a> |
| 15  | <a href="#">6K5-11601-12</a><br>Piston ring set (1st o/s)<br>AP | <a href="#">Buy now</a> |
| 15  | <a href="#">6K5-11601-22</a><br>Piston ring set (2nd o/s)<br>AP | <a href="#">Buy now</a> |
| 16  | <a href="#">6H3-11633-00</a><br>Pin, piston                     | <a href="#">Buy now</a> |
| 17  | <a href="#">688-11634-10</a><br>Clip, piston pin                | <a href="#">Buy now</a> |
| 18  | <a href="#">93603-18M09</a><br>Pin, dowel b (6h3)               | <a href="#">Buy now</a> |
| 19  | <a href="#">90201-20417</a><br>Washer, plate(663)               | <a href="#">Buy now</a> |

# Cylinder. Crankcase




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 3   | <a href="#">688-11370-01</a><br>Check valve assembly | <a href="#">Buy now</a> |
| 4   | <a href="#">650-11370-01</a><br>Check valve assembly | <a href="#">Buy now</a> |
| 5   | <a href="#">624-14485-00</a><br>Pipe, joint          | <a href="#">Buy now</a> |
| 6   | <a href="#">650-24378-00</a><br>Pipe, joint 2        | <a href="#">Buy now</a> |
| 7   | <a href="#">93608-12063</a><br>Pin, dowel (626)      | <a href="#">Buy now</a> |
| 8   | <a href="#">90119-10005</a><br>Bolt, with washer     | <a href="#">Buy now</a> |
| 9   | <a href="#">90119-08M64</a><br>Bolt, with washer     | <a href="#">Buy now</a> |
| 10  | <a href="#">90445-07M44</a><br>Hose (I390)           | <a href="#">Buy now</a> |
| 11  | <a href="#">90467-06016</a><br>Clip (655)            | <a href="#">Buy now</a> |
| 12  | <a href="#">90445-07M02</a><br>Hose (I200)           | <a href="#">Buy now</a> |
| 13  | <a href="#">90445-07M45</a><br>Hose (I390)           | <a href="#">Buy now</a> |
| 14  | <a href="#">90445-07M82</a><br>Hose (I770)           | <a href="#">Buy now</a> |
| 16  | <a href="#">90464-07M05</a><br>Clamp (6g5)           | <a href="#">Buy now</a> |
| 17  | <a href="#">6H3-11325-01</a><br>Anode                | <a href="#">Buy now</a> |
| 19  | <a href="#">6H3-11328-00</a><br>Grommet, anode       | <a href="#">Buy now</a> |

# Cylinder. Crankcase



| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 20  | <a href="#">90119-06023</a><br>Bolt, with washer          | <a href="#">Buy now</a> |
| 21  | <a href="#">688-11119-01</a><br>Hanger, engine            | <a href="#">Buy now</a> |
| 22  | <a href="#">90101-08002</a><br>Bolt                       | <a href="#">Buy now</a> |
| 23  | <a href="#">90340-14M00</a><br>Plug, straight screw(62y)  | <a href="#">Buy now</a> |
| 24  | <a href="#">90430-14115</a><br>Gasket (663)               | <a href="#">Buy now</a> |
| 25  | <a href="#">62F-11111-00-1S</a><br>Head, Cylinder 1       | <a href="#">Buy now</a> |
| 26  | <a href="#">6H3-11181-A1</a><br>Gasket, cylinder head 1   | <a href="#">Buy now</a> |
| 27  | <a href="#">6H3-11191-00-1S</a><br>Cover, cylinder head 1 | <a href="#">Buy now</a> |
| 28  | <a href="#">6H3-11193-A1</a><br>Gasket, head cover 1      | <a href="#">Buy now</a> |
| 29  | <a href="#">90119-08MA5</a><br>Bolt, with washer          | <a href="#">Buy now</a> |
| 30  | <a href="#">90116-08M69</a><br>Bolt, stud                 | <a href="#">Buy now</a> |
| 31  | <a href="#">90179-08M34</a><br>Nut                        | <a href="#">Buy now</a> |
| 32  | <a href="#">6H3-12411-10</a><br>Thermostat                | <a href="#">Buy now</a> |
| 33  | <a href="#">6H3-12413-00-1S</a><br>Cover, thermostat      | <a href="#">Buy now</a> |
| 34  | <a href="#">6H3-12414-A1</a><br>Gasket, cover             | <a href="#">Buy now</a> |


# Cylinder. Crankcase



**A6**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 35  | <a href="#">90119-06MA3</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 36  | <a href="#">6H3-41111-01-1S</a><br>Inner cover, exhaust     | <a href="#">Buy now</a> |
| 37  | <a href="#">6H3-41112-A0</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 38  | <a href="#">6H3-41113-02-1S</a><br>Outer cover, exhaust     | <a href="#">Buy now</a> |
| 39  | <a href="#">6H3-41114-A0</a><br>Gasket, exhaust outer cover | <a href="#">Buy now</a> |
| 40  | <a href="#">90119-06MA5</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 41  | <a href="#">663-24312-01</a><br>Pipe 1                      | <a href="#">Buy now</a> |
| 42  | <a href="#">90467-08004</a><br>Clip, pipe 6162435600        | <a href="#">Buy now</a> |
| 43  | <a href="#">94702-00247</a><br>Plug, spark (br8hs-10)       | <a href="#">Buy now</a> |


# Electrical



**C6**


| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H3-85542-11-94</a><br>Bracket                     | <a href="#">Buy now</a> |
| 2   | <a href="#">90105-06M14</a><br>Bolt (6e0)                      | <a href="#">Buy now</a> |
| 3   | <a href="#">90387-06M43</a><br>Coller (6e9)                    | <a href="#">Buy now</a> |
| 4   | <a href="#">90480-13M54</a><br>Grommet(6h2)                    | <a href="#">Buy now</a> |
| 5   | <a href="#">6H2-85540-12</a><br>C.d.i. unit assembly           | <a href="#">Buy now</a> |
| 6   | <a href="#">703-82119-00</a><br>Cover, lead wire               | <a href="#">Buy now</a> |
| 7   | <a href="#">97095-06045</a><br>Bolt, hexagon                   | <a href="#">Buy now</a> |
| 8   | <a href="#">92995-06600</a><br>Washer, plain (646)             | <a href="#">Buy now</a> |
| 9   | <a href="#">97013-06012</a><br>Bolt(gh1)                       | <a href="#">Buy now</a> |
| 10  | <a href="#">92903-06600</a><br>Washer, plain (646)             | <a href="#">Buy now</a> |
| 11  | <a href="#">6H2-81960-10</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 12  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess       | <a href="#">Buy now</a> |
| 14  | <a href="#">90464-05M16</a><br>Clamp(6j8)                      | <a href="#">Buy now</a> |
| 15  | <a href="#">6H3-81916-10</a><br>Cover, terminal                | <a href="#">Buy now</a> |
| 16  | <a href="#">90159-06M01</a><br>Screw, with washer (6f5)        | <a href="#">Buy now</a> |

# Electrical



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 17  | <a href="#">6G5-82152-00</a><br>Holder, fuse                | <a href="#">Buy now</a> |
| 18  | <a href="#">90464-23M22</a><br>Clamp                        | <a href="#">Buy now</a> |
| 19  | <a href="#">90465-13M11</a><br>Clamp (6e5)                  | <a href="#">Buy now</a> |
| 20  | <a href="#">697-85570-00</a><br>Ignition coil assembly      | <a href="#">Buy now</a> |
| 21  | <a href="#">97013-06020</a><br>Bolt(62y)                    | <a href="#">Buy now</a> |
| 23  | <a href="#">6G1-82370-21</a><br>Plug cap assembly           | <a href="#">Buy now</a> |
| 24  | <a href="#">688-81950-10</a><br>Relay assembly              | <a href="#">Buy now</a> |
| 25  | <a href="#">97013-06016</a><br>Bolt, hexagon deep recess    | <a href="#">Buy now</a> |
| 27  | <a href="#">6H3-82164-00</a><br>Case 2                      | <a href="#">Buy now</a> |
| 28  | <a href="#">90464-15M11</a><br>Clamp (3y2)                  | <a href="#">Buy now</a> |
| 29  | <a href="#">6H3-82105-01</a><br>Battery cable               | <a href="#">Buy now</a> |
| 30  | <a href="#">6H3-82117-00</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 31  | <a href="#">6H2-82590-13</a><br>Wire harness assembly (10p) | <a href="#">Buy now</a> |
| 32  | <a href="#">663-82151-00</a><br>Fuse                        | <a href="#">Buy now</a> |
| 37  | <a href="#">688-82594-00</a><br>Clamp                       | <a href="#">Buy now</a> |


# Electrical



**C6**


| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 38  | <a href="#">688-82560-10</a><br>Thermo switch assembly      | <a href="#">Buy now</a> |
| 39  | <a href="#">61A-81950-00</a><br>Relay assembly              | <a href="#">Buy now</a> |
| 40  | <a href="#">97095-06025</a><br>Bolt                         | <a href="#">Buy now</a> |
| 42  | <a href="#">6H3-82154-11</a><br>Case                        | <a href="#">Buy now</a> |
| 43  | <a href="#">6H2-81949-11</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 44  | <a href="#">6H2-81949-01</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 45  | <a href="#">682-82119-01</a><br>Cover, lead wire            | <a href="#">Buy now</a> |
| 46  | <a href="#">6H1-82563-10</a><br>Trim & tilt switch assembly | <a href="#">Buy now</a> |
| 47  | <a href="#">6E5-82587-00</a><br>Gasket                      | <a href="#">Buy now</a> |
| 48  | <a href="#">6E5-83614-01</a><br>Bracket                     | <a href="#">Buy now</a> |
| 50  | <a href="#">90464-18M14</a><br>Clamp(6h1)                   | <a href="#">Buy now</a> |
| 51  | <a href="#">6R5-85711-60</a><br>Mark, caution               | <a href="#">Buy now</a> |

# Fuel




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G1-24304-02</a><br>Fuel pipe joint comp. 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">97095-06025</a><br>Bolt                     | <a href="#">Buy now</a> |
| 3   | <a href="#">92995-06600</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 4   | <a href="#">90445-09M75</a><br>Hose (I1500)             | <a href="#">Buy now</a> |
| 5   | <a href="#">90467-08004</a><br>Clip, pipe 6162435600    | <a href="#">Buy now</a> |
| 6   | <a href="#">61N-24560-00</a><br>Filter assembly         | <a href="#">Buy now</a> |
| 7   | <a href="#">61N-24563-00</a><br>Element, filter         | <a href="#">Buy now</a> |
| 8   | <a href="#">61N-24521-00</a><br>Cup, filter             | <a href="#">Buy now</a> |
| 9   | <a href="#">93210-32738</a><br>O-ring(1wg)              | <a href="#">Buy now</a> |
| 10  | <a href="#">648-24566-02</a><br>Bracket, filter         | <a href="#">Buy now</a> |
| 11  | <a href="#">95380-08600</a><br>Nut (661)                | <a href="#">Buy now</a> |
| 12  | <a href="#">97013-06014</a><br>Bolt(gj3)                | <a href="#">Buy now</a> |
| 13  | <a href="#">90445-09072</a><br>Hose (I1500)             | <a href="#">Buy now</a> |
| 15  | <a href="#">692-24410-00</a><br>Fuel pump assembly      | <a href="#">Buy now</a> |
| 16  | <a href="#">6A0-24413-00</a><br>Cover, pump             | <a href="#">Buy now</a> |

# Fuel




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 17  | <a href="#">692-24411-00</a><br>Diaphragm              | <a href="#">Buy now</a> |
| 18  | <a href="#">648-24434-01</a><br>Gasket, body           | <a href="#">Buy now</a> |
| 19  | <a href="#">95380-03600</a><br>Nut (6g8)               | <a href="#">Buy now</a> |
| 20  | <a href="#">663-24411-00</a><br>Diaphragm              | <a href="#">Buy now</a> |
| 21  | <a href="#">648-24435-02</a><br>Gasket, body 2         | <a href="#">Buy now</a> |
| 22  | <a href="#">98503-05028</a><br>Ybs86-530 screw,panhead | <a href="#">Buy now</a> |
| 23  | <a href="#">92990-05100</a><br>Ybs67-5 washer, spring  | <a href="#">Buy now</a> |
| 24  | <a href="#">6A0-24421-01</a><br>Valve, check           | <a href="#">Buy now</a> |
| 25  | <a href="#">6A0-14325-00</a><br>Screw, pan head        | <a href="#">Buy now</a> |
| 26  | <a href="#">6A0-24412-02</a><br>Body 1                 | <a href="#">Buy now</a> |
| 27  | <a href="#">650-24431-A0</a><br>Gasket,fuel pump       | <a href="#">Buy now</a> |
| 28  | <a href="#">97095-06040</a><br>Bolt (682)              | <a href="#">Buy now</a> |
| 32  | <a href="#">688-24378-00</a><br>Pipe, joint            | <a href="#">Buy now</a> |
| 33  | <a href="#">6H3-24313-00</a><br>Pipe, fuel 2           | <a href="#">Buy now</a> |
| 34  | <a href="#">90445-09220</a><br>Hose (l1500)            | <a href="#">Buy now</a> |

# Fuel




| Ref | Part                                                                              |                         |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 35  | <a href="#">6H3-24314-00</a><br>Pipe 4                                            | <a href="#">Buy now</a> |
| 37  | <a href="#">90446-10M01</a><br>Tube (6e5)                                         | <a href="#">Buy now</a> |
| 38  | <a href="#">656-W2810-02</a><br>Tool kit                                          | <a href="#">Buy now</a> |
| 39  | <a href="#">6E0-28193-00-94</a><br>Plug, water check<br>AP D)12.5MM               | <a href="#">Buy now</a> |
| 40  | <a href="#">6H2-28199-7P-A0</a><br>O/m 50geto/60feto/70beto/75/90<br>UR (E,F,S)   | <a href="#">Buy now</a> |
| 40  | <a href="#">6H2-28199-7P-B0</a><br>O/m 50geto/60feto/70beto/75/90<br>UR (D,NL,I)  | <a href="#">Buy now</a> |
| 41  | <a href="#">6H2-28199-8P-A0</a><br>O/m 50geto/60feto/70beto/7 '03<br>UR (DK,P,GR) | <a href="#">Buy now</a> |
| 41  | <a href="#">6H2-28199-8P-B0</a><br>O/m 50geto/60feto/70beto/7 '03<br>UR (N,S,SS)  | <a href="#">Buy now</a> |

# Fuel Tank



| Ref | Part                                                                        |                         |
|-----|-----------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YK-24201-01</a><br>Fuel Tank assembly (25L)<br>AP PLASTIC, 25L | <a href="#">Buy now</a> |
| 2   | <a href="#">6YL-24268-01</a><br>Gasket, fuel meter                          | <a href="#">Buy now</a> |
| 3   | <a href="#">6YK-24610-00</a><br>Cap assembly<br>WITH INDICATOR              | <a href="#">Buy now</a> |
| 4   | <a href="#">6YL-24641-00</a><br>Gasket, cap 1                               | <a href="#">Buy now</a> |
| 5   | <a href="#">6YK-24260-01</a><br>Fuel meter assembly                         | <a href="#">Buy now</a> |
| 6   | <a href="#">90157-05M16</a><br>Screw, pan head                              | <a href="#">Buy now</a> |
| 7   | <a href="#">6YL-24329-00</a><br>Seal                                        | <a href="#">Buy now</a> |
| 8   | <a href="#">6YL-24306-52</a><br>Fuel pipe comp. 1<br>AP                     | <a href="#">Buy now</a> |


# Generator



**C5**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H2-85550-00</a><br>Rotor assembly        | <a href="#">Buy now</a> |
| 2   | <a href="#">6H2-85520-01</a><br>Coil, charge          | <a href="#">Buy now</a> |
| 3   | <a href="#">6H2-85533-01</a><br>Coil, lighting        | <a href="#">Buy now</a> |
| 4   | <a href="#">6H2-85580-01</a><br>Coil, pulser          | <a href="#">Buy now</a> |
| 5   | <a href="#">6H2-85582-00</a><br>Attachment, pulser    | <a href="#">Buy now</a> |
| 6   | <a href="#">6H2-85895-01</a><br>Crank position sender | <a href="#">Buy now</a> |
| 7   | <a href="#">97095-05012</a><br>Bolt, hexagon          | <a href="#">Buy now</a> |
| 8   | <a href="#">97095-06035</a><br>Bolt(j52)              | <a href="#">Buy now</a> |
| 9   | <a href="#">92995-06600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 10  | <a href="#">97095-06025</a><br>Bolt                   | <a href="#">Buy now</a> |
| 12  | <a href="#">90280-05015</a><br>Key, woodruff          | <a href="#">Buy now</a> |
| 13  | <a href="#">90170-20137</a><br>Nut, hexagon(663)      | <a href="#">Buy now</a> |
| 14  | <a href="#">90201-21M18</a><br>Washer, plate (663)    | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5-81332-00</a><br>Plate, timing         | <a href="#">Buy now</a> |
| 16  | <a href="#">97885-06010</a><br>Screw pan head         | <a href="#">Buy now</a> |


# Generator



**C5**


| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 18  | <a href="#">6H3-81337-01</a><br>Cover, flywheel        | <a href="#">Buy now</a> |
| 19  | <a href="#">90159-06M23</a><br>Screw, with washer(6b0) | <a href="#">Buy now</a> |
| 20  | <a href="#">6H3-14488-00</a><br>Label Caution          | <a href="#">Buy now</a> |
| 21  | <a href="#">6H3-13437-21</a><br>Mark, caution          | <a href="#">Buy now</a> |

# Intake



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H2-13610-00</a><br>Reed valve assembly      | <a href="#">Buy now</a> |
| 1   | <a href="#">6H3-13610-00</a><br>Reed valve assembly      | <a href="#">Buy now</a> |
| 2   | <a href="#">688-W0004-00</a><br>Reed set                 | <a href="#">Buy now</a> |
| 3   | <a href="#">97880-05016</a><br>Screw, pan head(6b0)      | <a href="#">Buy now</a> |
| 4   | <a href="#">92990-05600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 5   | <a href="#">62F-13641-10-94</a><br>Manifold 1            | <a href="#">Buy now</a> |
| 5   | <a href="#">6H3-13641-13-94</a><br>Manifold, intake 1    | <a href="#">Buy now</a> |
| 6   | <a href="#">6H1-14485-00</a><br>Pipe, joint              | <a href="#">Buy now</a> |
| 7   | <a href="#">6H3-13621-A1</a><br>Gasket, valve seat       | <a href="#">Buy now</a> |
| 8   | <a href="#">6H3-13624-00-94</a><br>Plate, reed valve     | <a href="#">Buy now</a> |
| 9   | <a href="#">6H3-13622-A1</a><br>Gasket, valve seat       | <a href="#">Buy now</a> |
| 10  | <a href="#">90119-06MA3</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 11  | <a href="#">97095-06095</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 12  | <a href="#">6H4-14198-01</a><br>Gasket                   | <a href="#">Buy now</a> |
| 12  | <a href="#">93210-39ME4</a><br>O-ring(6h2)               | <a href="#">Buy now</a> |


# Intake



**B2**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 13  | <a href="#">6H3-41217-00</a><br>Rod, accel lever          | <a href="#">Buy now</a> |
| 14  | <a href="#">90445-07255</a><br>Hose (I200)                | <a href="#">Buy now</a> |
| 15  | <a href="#">90467-06016</a><br>Clip (655)                 | <a href="#">Buy now</a> |
| 16  | <a href="#">6H3-14349-00</a><br>Pipe                      | <a href="#">Buy now</a> |
| 17  | <a href="#">90467-08004</a><br>Clip, pipe 6162435600      | <a href="#">Buy now</a> |
| 18  | <a href="#">6H3-14413-10</a><br>Stay                      | <a href="#">Buy now</a> |
| 19  | <a href="#">6H3-14440-02</a><br>Silencer assembly, intake | <a href="#">Buy now</a> |
| 20  | <a href="#">6H3-14457-01</a><br>Seal                      | <a href="#">Buy now</a> |
| 21  | <a href="#">97885-06045</a><br>Screw, pan head(6b0)       | <a href="#">Buy now</a> |
| 22  | <a href="#">90209-06M05</a><br>Washer (688)               | <a href="#">Buy now</a> |
| 23  | <a href="#">6H1-85711-60</a><br>Mark, caution             | <a href="#">Buy now</a> |
| 24  | <a href="#">6A1-83625-41</a><br>Mark 5                    | <a href="#">Buy now</a> |
| 25  | <a href="#">6A1-83625-51</a><br>Mark 5                    | <a href="#">Buy now</a> |


# Lower Casing. Drive 1



E7

| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H3-45300-15-4D</a><br>Lower unit assembly<br>L  | <a href="#">Buy now</a> |
| 2   | <a href="#">6H1-45301-03-4D</a><br>Lower casing set          | <a href="#">Buy now</a> |
| 3   | <a href="#">93315-325V1</a><br>Bearing, needle (688)         | <a href="#">Buy now</a> |
| 4   | <a href="#">688-45536-01</a><br>Sleeve, drive shaft          | <a href="#">Buy now</a> |
| 5   | <a href="#">688-45587-01-10</a><br>Shim (t:0.10mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">688-45587-01-12</a><br>Shim (t:0.12mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">688-45587-01-15</a><br>Shim (t:0.15mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">688-45587-01-18</a><br>Shim (t:0.18mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">688-45587-01-30</a><br>Shim (t:0.30mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">688-45587-01-40</a><br>Shim (t:0.40mm)<br>UR     | <a href="#">Buy now</a> |
| 5   | <a href="#">688-45587-01-50</a><br>Shim (t:0.50mm)<br>UR     | <a href="#">Buy now</a> |
| 6   | <a href="#">93332-000U3</a><br>Brg,tapered roller 50mm (688) | <a href="#">Buy now</a> |
| 7   | <a href="#">688-45567-01-10</a><br>Shim (t:0.10mm)<br>UR     | <a href="#">Buy now</a> |
| 7   | <a href="#">688-45567-01-12</a><br>Shim (t:0.12mm)<br>UR     | <a href="#">Buy now</a> |
| 7   | <a href="#">688-45567-01-15</a><br>Shim (t:0.15mm)<br>UR     | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



E7

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 7   | <a href="#">688-45567-01-18</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 7   | <a href="#">688-45567-01-30</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 7   | <a href="#">688-45567-01-40</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 7   | <a href="#">688-45567-01-50</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 8   | <a href="#">93332-000W7</a><br>Bearing(6b0)              | <a href="#">Buy now</a> |
| 9   | <a href="#">90340-08002</a><br>Plug, straight screw      | <a href="#">Buy now</a> |
| 10  | <a href="#">688-45341-10</a><br>Plug, drain              | <a href="#">Buy now</a> |
| 11  | <a href="#">90430-08020</a><br>Gasket                    | <a href="#">Buy now</a> |
| 12  | <a href="#">6H1-45214-00</a><br>Cover, water inlet       | <a href="#">Buy now</a> |
| 13  | <a href="#">6H1-45215-00</a><br>Cover, water inlet       | <a href="#">Buy now</a> |
| 14  | <a href="#">90151-05M00</a><br>Screw, countersunk(692)   | <a href="#">Buy now</a> |
| 15  | <a href="#">90185-05002</a><br>Nut nylon (sus)(ex4)      | <a href="#">Buy now</a> |
| 16  | <a href="#">688-45321-00</a><br>Plate                    | <a href="#">Buy now</a> |
| 17  | <a href="#">93210-49046</a><br>O-ring (620)              | <a href="#">Buy now</a> |
| 18  | <a href="#">93106-09014</a><br>Oil seal                  | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



**E7**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 19  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess   | <a href="#">Buy now</a> |
| 20  | <a href="#">92995-06600</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5-45378-00</a><br>Nipple, hose               | <a href="#">Buy now</a> |
| 22  | <a href="#">90445-07ME9</a><br>Hose (I250)<br>L            | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-83558-10</a><br>End, nipple                | <a href="#">Buy now</a> |
| 24  | <a href="#">90465-11M10</a><br>Clamp                       | <a href="#">Buy now</a> |
| 25  | <a href="#">6H3-44311-00</a><br>Housing, water pump 1      | <a href="#">Buy now</a> |
| 26  | <a href="#">663-44322-00</a><br>Insert, cartridge          | <a href="#">Buy now</a> |
| 27  | <a href="#">6H3-44315-A0</a><br>Gasket, water pump 1       | <a href="#">Buy now</a> |
| 28  | <a href="#">6H3-44352-00</a><br>Impellar                   | <a href="#">Buy now</a> |
| 29  | <a href="#">90280-03M03</a><br>Key, woodruff (697)         | <a href="#">Buy now</a> |
| 30  | <a href="#">6H3-44341-00-94</a><br>Housing, water pump set | <a href="#">Buy now</a> |
| 31  | <a href="#">93101-23070</a><br>Oil seal (663)              | <a href="#">Buy now</a> |
| 32  | <a href="#">93210-46044</a><br>O-ring                      | <a href="#">Buy now</a> |
| 33  | <a href="#">688-44316-A0</a><br>Gasket, water pump 2       | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



**E7**

| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 34  | <a href="#">6H3-44323-00</a><br>Outer plate, cartridge       | <a href="#">Buy now</a> |
| 35  | <a href="#">6H3-44324-A0</a><br>Gasket, cartridge Out, plate | <a href="#">Buy now</a> |
| 36  | <a href="#">93604-10M03</a><br>Pin, dowel (688)              | <a href="#">Buy now</a> |
| 37  | <a href="#">90119-08M33</a><br>Bolt, with washer(6b0)        | <a href="#">Buy now</a> |
| 38  | <a href="#">90119-08M14</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 39  | <a href="#">6H3-45501-10</a><br>Drive Shaft Comp<br>L        | <a href="#">Buy now</a> |
| 40  | <a href="#">6K5-45551-00</a><br>Pinion                       | <a href="#">Buy now</a> |
| 41  | <a href="#">90170-16M01</a><br>Nut, hexagon (688)            | <a href="#">Buy now</a> |
| 42  | <a href="#">6K5-45560-00</a><br>Gear                         | <a href="#">Buy now</a> |
| 43  | <a href="#">6H1-45611-01</a><br>Shaft, propeller             | <a href="#">Buy now</a> |
| 44  | <a href="#">6H1-45631-01</a><br>Clutch, dog                  | <a href="#">Buy now</a> |
| 45  | <a href="#">93603-12M11</a><br>Pin, dowel(6h1)               | <a href="#">Buy now</a> |
| 46  | <a href="#">6H1-45634-02</a><br>Slide, shift                 | <a href="#">Buy now</a> |
| 47  | <a href="#">90501-16M65</a><br>Spring, compression(6h1)      | <a href="#">Buy now</a> |
| 48  | <a href="#">93503-16003</a><br>Ball                          | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



**E7**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 49  | <a href="#">6H1-45668-00</a><br>Shaft, free 1           | <a href="#">Buy now</a> |
| 50  | <a href="#">6H1-45635-00</a><br>Plunger, shift          | <a href="#">Buy now</a> |
| 51  | <a href="#">90501-12M48</a><br>Spring (6h1)             | <a href="#">Buy now</a> |
| 52  | <a href="#">90201-03313</a><br>Washer, plate 8077743700 | <a href="#">Buy now</a> |
| 53  | <a href="#">90183-02M03</a><br>Nut, spring (6h1)        | <a href="#">Buy now</a> |
| 54  | <a href="#">90250-07M02</a><br>Pin, straight (688)      | <a href="#">Buy now</a> |
| 55  | <a href="#">688-45633-00</a><br>Ping, cross pin         | <a href="#">Buy now</a> |
| 56  | <a href="#">6H1-45641-01</a><br>Shifter                 | <a href="#">Buy now</a> |
| 57  | <a href="#">6H1-44151-00</a><br>Cam, shift              | <a href="#">Buy now</a> |
| 58  | <a href="#">6H1-44144-00</a><br>Rod, shift 2            | <a href="#">Buy now</a> |
| 59  | <a href="#">93210-07003</a><br>O-ring (11m)             | <a href="#">Buy now</a> |
| 60  | <a href="#">99001-08600</a><br>Circlip(2r6)             | <a href="#">Buy now</a> |
| 61  | <a href="#">93450-07M00</a><br>Circlip (6e5)            | <a href="#">Buy now</a> |
| 62  | <a href="#">6H3-45571-00</a><br>Gear 2                  | <a href="#">Buy now</a> |
| 63  | <a href="#">688-45331-00-94</a><br>Housing, bearing     | <a href="#">Buy now</a> |


## Lower Casing. Drive 1



E7


| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 64  | <a href="#">93306-207U0</a><br>Brg,r-b 6207 72mm 280g (688) | <a href="#">Buy now</a> |
| 65  | <a href="#">688-45577-01-10</a><br>Shim (t:0.10mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">688-45577-01-12</a><br>Shim (t:0.12mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">688-45577-01-15</a><br>Shim (t:0.15mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">688-45577-01-18</a><br>Shim (t:0.18mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">688-45577-01-30</a><br>Shim (t:0.30mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">688-45577-01-40</a><br>Shim (t:0.40mm)<br>UR    | <a href="#">Buy now</a> |
| 65  | <a href="#">688-45577-01-50</a><br>Shim (t:0.50mm)<br>UR    | <a href="#">Buy now</a> |
| 66  | <a href="#">688-45576-00</a><br>Washer, thrust 2            | <a href="#">Buy now</a> |
| 67  | <a href="#">93210-85M97</a><br>O-ring(6h1)                  | <a href="#">Buy now</a> |
| 68  | <a href="#">93317-325U0</a><br>Brg,needle                   | <a href="#">Buy now</a> |
| 69  | <a href="#">93101-25M03</a><br>Oil seal                     | <a href="#">Buy now</a> |
| 70  | <a href="#">90282-04010</a><br>Key, strait(663)             | <a href="#">Buy now</a> |
| 71  | <a href="#">688-45383-02</a><br>Washer, claw                | <a href="#">Buy now</a> |
| 72  | <a href="#">688-45384-00</a><br>Nut                         | <a href="#">Buy now</a> |

## Lower Casing. Drive 2




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">663-44367-00</a><br>Damper, water seal 3          | <a href="#">Buy now</a> |
| 2   | <a href="#">6H3-44361-10</a><br>Tube, water<br>L              | <a href="#">Buy now</a> |
| 3   | <a href="#">90202-12060</a><br>Washer, plate(663)             | <a href="#">Buy now</a> |
| 4   | <a href="#">90430-12072</a><br>Gasket                         | <a href="#">Buy now</a> |
| 5   | <a href="#">93606-12019</a><br>Pin, dowel (614)               | <a href="#">Buy now</a> |
| 6   | <a href="#">97075-10040</a><br>Bolt, hexagon deep recess<br>L | <a href="#">Buy now</a> |
| 7   | <a href="#">92990-10100</a><br>Ybs67-10 washer, spring        | <a href="#">Buy now</a> |
| 8   | <a href="#">92990-10600</a><br>Washer, plate                  | <a href="#">Buy now</a> |
| 9   | <a href="#">90119-08M84</a><br>Bolt, with washer<br>L         | <a href="#">Buy now</a> |
| 10  | <a href="#">663-45376-00-94</a><br>Guide, seal damper         | <a href="#">Buy now</a> |
| 11  | <a href="#">688-45375-00</a><br>Damper, seal 2                | <a href="#">Buy now</a> |
| 12  | <a href="#">688-45371-02</a><br>Tab-trim                      | <a href="#">Buy now</a> |
| 13  | <a href="#">90105-10M67</a><br>Bolt, hexagon (663)            | <a href="#">Buy now</a> |
| 14  | <a href="#">90445-07MF1</a><br>Hose (I570)                    | <a href="#">Buy now</a> |
| 15  | <a href="#">6E5-83558-00</a><br>End, nipple                   | <a href="#">Buy now</a> |

## Lower Casing. Drive 2




| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">663-44366-00</a><br>Damper, water seal 2                 | <a href="#">Buy now</a> |
| 17  | <a href="#">688-45987-01</a><br>Spacer                               | <a href="#">Buy now</a> |
| 18  | <a href="#">688-45997-01</a><br>Spacer 2                             | <a href="#">Buy now</a> |
| 19  | <a href="#">90201-17M00</a><br>Washer, plate(6h1)                    | <a href="#">Buy now</a> |
| 20  | <a href="#">90171-16011</a><br>Nut, castle (663)                     | <a href="#">Buy now</a> |
| 21  | <a href="#">91490-40025</a><br>Pin, cotter (663)                     | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45941-00-EL</a><br>Propeller (3x13x19-k)<br>UR       | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45943-00-EL</a><br>Propeller (3x12-5/8"x21"-k)<br>UR | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45945-01-EL</a><br>Propeller (3x13-1/4x17-k)<br>UR   | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45947-00-EL</a><br>Propeller (3x13-1/2x15-k)<br>UR   | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45949-00-EL</a><br>Propeller (3x13-5/8"x13"-k)<br>UR | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45952-00-EL</a><br>Propeller (3x13"x23"-k)<br>UR     | <a href="#">Buy now</a> |
| 22  | <a href="#">688-45930-02-98</a><br>Propeller (3x13x17)<br>UR         | <a href="#">Buy now</a> |
| 22  | <a href="#">688-45932-60-98</a><br>Propeller (3x13-1/2"x14"-k)<br>UR | <a href="#">Buy now</a> |
| 22  | <a href="#">688-45970-03-98</a><br>Propeller (3x13"x19"-k)<br>UR     | <a href="#">Buy now</a> |

## Lower Casing. Drive 2




| Ref | Part                                                                   |                         |
|-----|------------------------------------------------------------------------|-------------------------|
| 22  | <a href="#">688-45972-02-98</a><br>Propeller (3x13"x21"-k)<br>UR       | <a href="#">Buy now</a> |
| 22  | <a href="#">688-45974-02-98</a><br>Propeller (3x13"x23"-k)<br>UR       | <a href="#">Buy now</a> |
| 22  | <a href="#">688-45976-01-98</a><br>Propeller (ss 3x13"x25"-k)<br>UR    | <a href="#">Buy now</a> |
| 22  | <a href="#">688-45978-60-98</a><br>Propeller (3x13-1/2"x16"-k)<br>UR   | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45954-00-EL</a><br>Propeller (3x14"x11"-k)<br>UR       | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5-45956-00-EL</a><br>Propeller (3x13"x25"-k)<br>UR       | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-45970-10</a><br>Propeller (ss 3x14"x20"-p)<br>UR       | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-45972-10</a><br>Propeller (ss 3x14"x24"-p)<br>UR       | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-45974-10</a><br>Propeller (ss 3x14"x28"-p)<br>UR       | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-45976-10</a><br>Propeller assembly (3x14"x22"-p)<br>UR | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5-45978-10</a><br>Propeller assembly (3x14"x26"-p)<br>UR | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5-45994-10</a><br>Plate, tooth                           | <a href="#">Buy now</a> |
| 25  | <a href="#">6E5-45371-10</a><br>Tab-trim                               | <a href="#">Buy now</a> |

# Lower Casing. Drive 3




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">62F-45300-10-4D</a><br>Lower Unit assembly<br>L | <a href="#">Buy now</a> |
| 2   | <a href="#">697-45311-02-4D</a><br>Casing, lower            | <a href="#">Buy now</a> |
| 3   | <a href="#">93315-322V2</a><br>Bearing Needle (698)         | <a href="#">Buy now</a> |
| 4   | <a href="#">698-45536-00</a><br>Sleeve Drive Shaft          | <a href="#">Buy now</a> |
| 5   | <a href="#">663-45587-01-10</a><br>Shim (t:0.10mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-45587-01-12</a><br>Shim (t:0.12mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-45587-01-15</a><br>Shim (t:0.15mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-45587-01-18</a><br>Shim (t:0.18mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-45587-01-30</a><br>Shim (t:0.30mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-45587-01-40</a><br>Shim (t:0.40mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-45587-01-50</a><br>Shim (t:0.50mm)<br>UR    | <a href="#">Buy now</a> |
| 6   | <a href="#">93332-00001</a><br>Brg, tapered roller (409)    | <a href="#">Buy now</a> |
| 7   | <a href="#">663-45567-01-10</a><br>Shim (t:0.10mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">663-45567-01-12</a><br>Shim (t:0.12mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">663-45567-01-15</a><br>Shim (t:0.15mm)<br>UR    | <a href="#">Buy now</a> |

## Lower Casing. Drive 3




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 7   | <a href="#">663-45567-01-18</a><br>Shim (t:0.18mm)<br>UR  | <a href="#">Buy now</a> |
| 7   | <a href="#">663-45567-01-30</a><br>Shim (t:0.30mm)<br>UR  | <a href="#">Buy now</a> |
| 7   | <a href="#">663-45567-01-40</a><br>Shim (t:0.40mm)<br>UR  | <a href="#">Buy now</a> |
| 7   | <a href="#">663-45567-01-50</a><br>Shim (t:0.50mm)<br>UR  | <a href="#">Buy now</a> |
| 8   | <a href="#">93332-00003</a><br>Brg,cyl-cal roller 318g ky | <a href="#">Buy now</a> |
| 9   | <a href="#">90340-08002</a><br>Plug, straight screw       | <a href="#">Buy now</a> |
| 10  | <a href="#">688-45341-10</a><br>Plug, drain               | <a href="#">Buy now</a> |
| 11  | <a href="#">90430-08020</a><br>Gasket                     | <a href="#">Buy now</a> |
| 12  | <a href="#">663-45376-00-94</a><br>Guide, seal damper     | <a href="#">Buy now</a> |
| 13  | <a href="#">663-45375-00</a><br>Rubber, seal 2            | <a href="#">Buy now</a> |
| 14  | <a href="#">663-45321-00</a><br>Plate                     | <a href="#">Buy now</a> |
| 15  | <a href="#">93210-49046</a><br>O-ring (620)               | <a href="#">Buy now</a> |
| 16  | <a href="#">93106-09014</a><br>Oil seal                   | <a href="#">Buy now</a> |
| 17  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess  | <a href="#">Buy now</a> |
| 18  | <a href="#">92995-06600</a><br>Washer, plain (646)        | <a href="#">Buy now</a> |

## Lower Casing. Drive 3



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 19  | <a href="#">663-44311-02</a><br>Housing, water pump          | <a href="#">Buy now</a> |
| 20  | <a href="#">663-44322-00</a><br>Insert, cartridge            | <a href="#">Buy now</a> |
| 21  | <a href="#">663-44315-A0</a><br>Gasket,water pump 1          | <a href="#">Buy now</a> |
| 22  | <a href="#">663-44366-00</a><br>Damper, water seal 2         | <a href="#">Buy now</a> |
| 23  | <a href="#">6H3-44352-00</a><br>Impellar                     | <a href="#">Buy now</a> |
| 24  | <a href="#">90280-03M03</a><br>Key, woodruff (697)           | <a href="#">Buy now</a> |
| 25  | <a href="#">663-44341-00-94</a><br>Housing, water pump       | <a href="#">Buy now</a> |
| 26  | <a href="#">93101-23070</a><br>Oil seal (663)                | <a href="#">Buy now</a> |
| 27  | <a href="#">93210-41042</a><br>O-ring (132)                  | <a href="#">Buy now</a> |
| 28  | <a href="#">663-44316-A0</a><br>Gasket,water pump 2          | <a href="#">Buy now</a> |
| 29  | <a href="#">663-44323-00</a><br>Outer plate, cartridge       | <a href="#">Buy now</a> |
| 30  | <a href="#">663-44324-A0</a><br>Gasket,cartridge outer plate | <a href="#">Buy now</a> |
| 31  | <a href="#">93604-08062</a><br>Pin,dowel (626)               | <a href="#">Buy now</a> |
| 32  | <a href="#">97095-08055</a><br>Bolt, hexagon                 | <a href="#">Buy now</a> |
| 33  | <a href="#">92995-08600</a><br>Washer, plain (663)           | <a href="#">Buy now</a> |


## Lower Casing. Drive 3



**F6**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 34  | <a href="#">97095-08045</a><br>Bolt, hexagon           | <a href="#">Buy now</a> |
| 36  | <a href="#">663-45552-00</a><br>Bearing, plain         | <a href="#">Buy now</a> |
| 37  | <a href="#">62F-45501-10</a><br>Drive Shaft Comp.<br>L | <a href="#">Buy now</a> |
| 38  | <a href="#">675-45551-00</a><br>Pinion (14T)           | <a href="#">Buy now</a> |
| 39  | <a href="#">90170-12138</a><br>Nut hexagon(663)        | <a href="#">Buy now</a> |
| 40  | <a href="#">675-45560-00</a><br>Gear (24T)             | <a href="#">Buy now</a> |
| 41  | <a href="#">697-45611-00</a><br>Shaft, propeller       | <a href="#">Buy now</a> |
| 42  | <a href="#">663-45631-01</a><br>Clutch, dog            | <a href="#">Buy now</a> |
| 43  | <a href="#">663-45634-00</a><br>Slide, shift           | <a href="#">Buy now</a> |
| 44  | <a href="#">90501-16233</a><br>Spring compression(663) | <a href="#">Buy now</a> |
| 45  | <a href="#">688-45635-00</a><br>Plunger, shift         | <a href="#">Buy now</a> |
| 46  | <a href="#">90250-06023</a><br>Pin, strait (663)       | <a href="#">Buy now</a> |
| 47  | <a href="#">663-45633-00</a><br>Ring, cross pin        | <a href="#">Buy now</a> |
| 48  | <a href="#">663-44151-00</a><br>Cam, shift             | <a href="#">Buy now</a> |
| 49  | <a href="#">6K5-44144-00</a><br>Rod, shift             | <a href="#">Buy now</a> |


## Lower Casing. Drive 3



F6

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 50  | <a href="#">93210-07003</a><br>O-ring (11m)              | <a href="#">Buy now</a> |
| 51  | <a href="#">99001-08600</a><br>Circlip(2r6)              | <a href="#">Buy now</a> |
| 52  | <a href="#">90201-22429</a><br>Washer, plate(663)        | <a href="#">Buy now</a> |
| 53  | <a href="#">675-45571-01</a><br>Gear 2                   | <a href="#">Buy now</a> |
| 54  | <a href="#">663-45331-00-94</a><br>Housing, bearing      | <a href="#">Buy now</a> |
| 55  | <a href="#">93306-00702</a><br>Brg,r-b 6007 62mm 150g ky | <a href="#">Buy now</a> |
| 56  | <a href="#">663-45577-01-10</a><br>Shim (t:0.10mm)<br>UR | <a href="#">Buy now</a> |
| 56  | <a href="#">663-45577-01-12</a><br>Shim (t:0.12mm)<br>UR | <a href="#">Buy now</a> |
| 56  | <a href="#">663-45577-01-15</a><br>Shim (t:0.15mm)<br>UR | <a href="#">Buy now</a> |
| 56  | <a href="#">663-45577-01-18</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 56  | <a href="#">663-45577-01-30</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 56  | <a href="#">663-45577-01-40</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 56  | <a href="#">663-45577-01-50</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 57  | <a href="#">663-45576-00</a><br>Washer, thrust 2         | <a href="#">Buy now</a> |
| 58  | <a href="#">93210-66M98</a><br>O-ring(6h4)               | <a href="#">Buy now</a> |


## Lower Casing. Drive 3



**F6**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 59  | <a href="#">93317-22204</a><br>Brg,cyl-cal roller 25.5g nt | <a href="#">Buy now</a> |
| 60  | <a href="#">93101-22067</a><br>Oil seal (22x36x6-663)      | <a href="#">Buy now</a> |
| 61  | <a href="#">90282-04010</a><br>Key, strait(663)            | <a href="#">Buy now</a> |
| 62  | <a href="#">90214-48M03</a><br>Washer, claw(697)           | <a href="#">Buy now</a> |
| 63  | <a href="#">697-45384-00</a><br>Nut                        | <a href="#">Buy now</a> |

## Lower Casing. Drive 4




62F0300-0230

**A5**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">663-44367-00</a><br>Damper, water seal 3     | <a href="#">Buy now</a> |
| 2   | <a href="#">6H3-44361-10</a><br>Tube, water<br>L         | <a href="#">Buy now</a> |
| 3   | <a href="#">90202-12060</a><br>Washer, plate(663)        | <a href="#">Buy now</a> |
| 4   | <a href="#">90430-12072</a><br>Gasket                    | <a href="#">Buy now</a> |
| 5   | <a href="#">93606-12019</a><br>Pin, dowel (614)          | <a href="#">Buy now</a> |
| 6   | <a href="#">97075-10040</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 7   | <a href="#">92990-10100</a><br>Ybs67-10 washer, spring   | <a href="#">Buy now</a> |
| 8   | <a href="#">92990-10600</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 9   | <a href="#">90119-08M84</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 10  | <a href="#">688-45214-02</a><br>Cover, water inlet       | <a href="#">Buy now</a> |
| 11  | <a href="#">688-45215-02</a><br>Cover, water inlet       | <a href="#">Buy now</a> |
| 12  | <a href="#">90152-05M05</a><br>Screw, countersunk        | <a href="#">Buy now</a> |
| 13  | <a href="#">90185-05002</a><br>Nut nylon (sus)(ex4)      | <a href="#">Buy now</a> |
| 14  | <a href="#">679-45371-00</a><br>Tab trim                 | <a href="#">Buy now</a> |
| 15  | <a href="#">90105-10M67</a><br>Bolt, hexagon (663)       | <a href="#">Buy now</a> |

# Lower Casing. Drive 4




  
62F0300-0230

**A5**


| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">663-45987-02</a><br>Spacer                               | <a href="#">Buy now</a> |
| 17  | <a href="#">670-45997-02</a><br>Spacer                               | <a href="#">Buy now</a> |
| 18  | <a href="#">92990-16200</a><br>958-58204-00 washer,plain             | <a href="#">Buy now</a> |
| 19  | <a href="#">90171-16011</a><br>Nut, castle (663)                     | <a href="#">Buy now</a> |
| 20  | <a href="#">91490-40025</a><br>Pin, cotter (663)                     | <a href="#">Buy now</a> |
| 21  | <a href="#">663-45970-60-98</a><br>Propeller (3x11-3/4"x12"-g)<br>UR | <a href="#">Buy now</a> |
| 21  | <a href="#">663-45972-60-98</a><br>Propeller (3x12"x11"-g)<br>UR     | <a href="#">Buy now</a> |
| 21  | <a href="#">663-45974-60-98</a><br>Propeller (3x11-1/2"x13"-g)<br>UR | <a href="#">Buy now</a> |
| 21  | <a href="#">663-45978-00-98</a><br>Propeller (3x10-1/4"x16"-g)<br>UR | <a href="#">Buy now</a> |

Meter



| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6Y5-8350T-02</a><br>Digital tachometer assembly<br>AP  | <a href="#">Buy now</a> |
| 2   | <a href="#">9E450-04433</a><br>Housing, connector (m-4-w)<br>M-4-W | <a href="#">Buy now</a> |
| 3   | <a href="#">9E450-04533</a><br>Housing, f-4-w(5pcs)<br>F-4-W       | <a href="#">Buy now</a> |
| 4   | <a href="#">92990-04100</a><br>Ybs67-4 washer, spring              | <a href="#">Buy now</a> |
| 5   | <a href="#">95380-04600</a><br>Nut,hex                             | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y5-83553-00</a><br>Wire, lead (l=2.5m)<br>AP          | <a href="#">Buy now</a> |
| 7   | <a href="#">1E6-82151-00</a><br>Fuse (10a)                         | <a href="#">Buy now</a> |
| 8   | <a href="#">68F-82553-70</a><br>Extension, wire lead (7m)<br>AP    | <a href="#">Buy now</a> |
| 9   | <a href="#">6H4-81315-11</a><br>Lead wire assembly<br>AP           | <a href="#">Buy now</a> |


# Oil Pump



**B7**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">62F-13200-00</a><br>Oil Injection Pump assembly | <a href="#">Buy now</a> |
| 1   | <a href="#">6H3-13200-02</a><br>Oil injection pump assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">93210-19MA7</a><br>O-ring(6r0)                  | <a href="#">Buy now</a> |
| 3   | <a href="#">90109-06M39</a><br>Bolt(6h0)                    | <a href="#">Buy now</a> |
| 4   | <a href="#">90109-06M40</a><br>Bolt(6h0)                    | <a href="#">Buy now</a> |
| 5   | <a href="#">90464-07M05</a><br>Clamp (6g5)                  | <a href="#">Buy now</a> |
| 6   | <a href="#">90445-07M44</a><br>Hose (I390)                  | <a href="#">Buy now</a> |
| 7   | <a href="#">90445-07M23</a><br>Hose (I570)                  | <a href="#">Buy now</a> |
| 8   | <a href="#">90445-07M87</a><br>Hose(62t)                    | <a href="#">Buy now</a> |
| 9   | <a href="#">90465-06M86</a><br>Clamp                        | <a href="#">Buy now</a> |
| 10  | <a href="#">6E9-13183-70</a><br>Valve check                 | <a href="#">Buy now</a> |
| 11  | <a href="#">90468-07M02</a><br>Clip (6e5)                   | <a href="#">Buy now</a> |
| 15  | <a href="#">6H3-11537-01</a><br>Gear, driven                | <a href="#">Buy now</a> |
| 16  | <a href="#">90201-08M93</a><br>Washer, plate (6g5)          | <a href="#">Buy now</a> |
| 17  | <a href="#">6H1-13117-01</a><br>Collar, distance            | <a href="#">Buy now</a> |


# Oil Pump



**B7**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 18  | <a href="#">93210-13M04</a><br>93210-13m04               | <a href="#">Buy now</a> |
| 19  | <a href="#">6H3-41241-01</a><br>Rod, link                | <a href="#">Buy now</a> |
| 20  | <a href="#">6H1-41237-00</a><br>Joint, link              | <a href="#">Buy now</a> |
| 21  | <a href="#">90202-05088</a><br>Washer, plate (666)       | <a href="#">Buy now</a> |
| 22  | <a href="#">90468-05M03</a><br>Clip(6j8)                 | <a href="#">Buy now</a> |
| 23  | <a href="#">95380-05600</a><br>Nut, hexagon (663)        | <a href="#">Buy now</a> |
| 24  | <a href="#">6E9-41237-00</a><br>Joint, link              | <a href="#">Buy now</a> |
| 25  | <a href="#">6H3-21707-06</a><br>Oil tank comp.           | <a href="#">Buy now</a> |
| 26  | <a href="#">90445-11M03</a><br>Hose (l360)               | <a href="#">Buy now</a> |
| 27  | <a href="#">90465-11M27</a><br>Clamp(6h1)                | <a href="#">Buy now</a> |
| 28  | <a href="#">90467-11M08</a><br>Clip(72x)                 | <a href="#">Buy now</a> |
| 29  | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 30  | <a href="#">90387-06M31</a><br>Collar (6a0)              | <a href="#">Buy now</a> |
| 31  | <a href="#">6H3-21752-00</a><br>Tube, filler 1           | <a href="#">Buy now</a> |
| 32  | <a href="#">90465-13M30</a><br>Clamp                     | <a href="#">Buy now</a> |


# Oil Pump



**B7**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 33  | <a href="#">63D-2176M-00</a><br>Hook                   | <a href="#">Buy now</a> |
| 34  | <a href="#">63D-2175R-00</a><br>Hook, band             | <a href="#">Buy now</a> |
| 35  | <a href="#">6H4-21770-00</a><br>Oil tank cap assembly  | <a href="#">Buy now</a> |
| 36  | <a href="#">6J8-21758-00</a><br>Washer, special 2      | <a href="#">Buy now</a> |
| 37  | <a href="#">6H1-21757-00</a><br>Washer, special 1      | <a href="#">Buy now</a> |
| 38  | <a href="#">6H1-24633-00</a><br>Chain, Ball            | <a href="#">Buy now</a> |
| 39  | <a href="#">6J8-13411-00</a><br>Strainer, oil          | <a href="#">Buy now</a> |
| 40  | <a href="#">6J8-13414-00</a><br>Gasket, strainer cover | <a href="#">Buy now</a> |
| 41  | <a href="#">6H1-13435-00</a><br>Nipple                 | <a href="#">Buy now</a> |
| 42  | <a href="#">90445-08M01</a><br>Hose (I30)              | <a href="#">Buy now</a> |
| 43  | <a href="#">6H1-21766-01</a><br>Pipe, oil              | <a href="#">Buy now</a> |
| 44  | <a href="#">90467-08004</a><br>Clip, pipe 6162435600   | <a href="#">Buy now</a> |
| 45  | <a href="#">90467-12M11</a><br>Clip(6k8)               | <a href="#">Buy now</a> |
| 46  | <a href="#">6A0-82317-00</a><br>Damper, ignition coil  | <a href="#">Buy now</a> |
| 47  | <a href="#">624-42542-00</a><br>Collar                 | <a href="#">Buy now</a> |


# Oil Pump



**B7**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 48  | <a href="#">90119-06M65</a><br>Bolt, with washer          | <a href="#">Buy now</a> |
| 49  | <a href="#">90119-06M88</a><br>Bolt, with washer          | <a href="#">Buy now</a> |
| 50  | <a href="#">90445-11M21</a><br>Hose (I70)                 | <a href="#">Buy now</a> |
| 51  | <a href="#">90467-10M04</a><br>Clip, pipe 1 (6e9)         | <a href="#">Buy now</a> |
| 52  | <a href="#">6J8-21744-00</a><br>Breather                  | <a href="#">Buy now</a> |
| 53  | <a href="#">90445-11M15</a><br>Hose (I360)                | <a href="#">Buy now</a> |
| 54  | <a href="#">6E5-24378-00</a><br>Pipe, joint 3             | <a href="#">Buy now</a> |
| 55  | <a href="#">90446-10M01</a><br>Tube (6e5)                 | <a href="#">Buy now</a> |
| 56  | <a href="#">90445-11M02</a><br>Hose (I100)                | <a href="#">Buy now</a> |
| 57  | <a href="#">90464-11M23</a><br>Clamp(6h4)                 | <a href="#">Buy now</a> |
| 59  | <a href="#">6H3-85720-16</a><br>Oil level gauge assembly  | <a href="#">Buy now</a> |
| 60  | <a href="#">6R5-82582-B0</a><br>Cover, wire harness<br>AP | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy



E3

| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">62F-43800-04-4D</a><br>Power trim & tilt assembly | <a href="#">Buy now</a> |
| 1   | <a href="#">6H1-43800-17-4D</a><br>Power trim & tilt assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6H1-43880-02</a><br>Motor assembly                | <a href="#">Buy now</a> |
| 3   | <a href="#">6H1-43805-10</a><br>Armature assembly             | <a href="#">Buy now</a> |
| 4   | <a href="#">6H1-43804-10</a><br>Stator assembly               | <a href="#">Buy now</a> |
| 5   | <a href="#">6H1-43891-10</a><br>Brush                         | <a href="#">Buy now</a> |
| 6   | <a href="#">6H1-43892-10</a><br>Breaker comp. (brush 2)       | <a href="#">Buy now</a> |
| 7   | <a href="#">6H1-4380F-10</a><br>Plate, brush holder           | <a href="#">Buy now</a> |
| 8   | <a href="#">6H1-4380J-10</a><br>Holder, brush                 | <a href="#">Buy now</a> |
| 9   | <a href="#">6H1-4386K-10</a><br>Spring, brush                 | <a href="#">Buy now</a> |
| 10  | <a href="#">97885-05016</a><br>Screw, pan head(6b0)           | <a href="#">Buy now</a> |
| 11  | <a href="#">97607-04310</a><br>Screw, pan head(6g8)           | <a href="#">Buy now</a> |
| 12  | <a href="#">6H1-43881-10</a><br>Frame, end                    | <a href="#">Buy now</a> |
| 13  | <a href="#">6H1-4380H-10</a><br>Metal                         | <a href="#">Buy now</a> |
| 14  | <a href="#">93102-08M43</a><br>Oil seal(6b0)                  | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy



E3

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 15  | <a href="#">6H1-4380G-10</a><br>Plate                    | <a href="#">Buy now</a> |
| 16  | <a href="#">6H1-43865-10</a><br>O-ring                   | <a href="#">Buy now</a> |
| 17  | <a href="#">6H1-43840-11</a><br>Power tilt assembly      | <a href="#">Buy now</a> |
| 18  | <a href="#">6H1-43861-10</a><br>O-ring                   | <a href="#">Buy now</a> |
| 19  | <a href="#">6H1-43814-11</a><br>Piston, free             | <a href="#">Buy now</a> |
| 20  | <a href="#">6H1-43810-11</a><br>Tilt piston sub assembly | <a href="#">Buy now</a> |
| 21  | <a href="#">6H1-43861-00</a><br>O-ring                   | <a href="#">Buy now</a> |
| 23  | <a href="#">6H1-43871-10</a><br>Ring, back up            | <a href="#">Buy now</a> |
| 24  | <a href="#">6H1-43812-00</a><br>Seal dast                | <a href="#">Buy now</a> |
| 25  | <a href="#">6H1-43872-10</a><br>Ring, back up            | <a href="#">Buy now</a> |
| 26  | <a href="#">93210-18397</a><br>O-ring (6g5)              | <a href="#">Buy now</a> |
| 27  | <a href="#">6H1-43813-10</a><br>Cylinder, tilt           | <a href="#">Buy now</a> |
| 28  | <a href="#">93210-64488</a><br>93210-64488               | <a href="#">Buy now</a> |
| 29  | <a href="#">6H1-43835-10</a><br>Pipe                     | <a href="#">Buy now</a> |
| 30  | <a href="#">6H1-43828-10</a><br>Body, reservoir          | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy



E3

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 31  | <a href="#">90386-18M14</a><br>Bushing (6e5)           | <a href="#">Buy now</a> |
| 32  | <a href="#">6E5-43818-00</a><br>Pin, lower shock mount | <a href="#">Buy now</a> |
| 33  | <a href="#">6H1-43833-10</a><br>Pipe                   | <a href="#">Buy now</a> |
| 34  | <a href="#">6H1-43834-00</a><br>Pipe                   | <a href="#">Buy now</a> |
| 35  | <a href="#">97595-06420</a><br>Bolt(7u8)               | <a href="#">Buy now</a> |
| 36  | <a href="#">6H1-43829-00</a><br>Plug, reservoir        | <a href="#">Buy now</a> |
| 37  | <a href="#">93210-09165</a><br>O-ring                  | <a href="#">Buy now</a> |
| 38  | <a href="#">93210-064A5</a><br>O-ring(61a)             | <a href="#">Buy now</a> |
| 39  | <a href="#">67F-43802-00</a><br>Valve sub assembly     | <a href="#">Buy now</a> |
| 40  | <a href="#">6H1-43866-00</a><br>O-ring                 | <a href="#">Buy now</a> |
| 41  | <a href="#">6H1-43867-00</a><br>O-ring                 | <a href="#">Buy now</a> |
| 42  | <a href="#">6H1-43841-11</a><br>Piston, shuttle        | <a href="#">Buy now</a> |
| 43  | <a href="#">6H1-43856-10</a><br>Spring, down relief    | <a href="#">Buy now</a> |
| 44  | <a href="#">6H1-43844-10</a><br>Pin, valve support     | <a href="#">Buy now</a> |
| 45  | <a href="#">6H1-4384G-11</a><br>Seal, relief valve     | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy




6H30010-4190

E3

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 46  | <a href="#">6H1-4384F-10</a><br>Seal, main valve         | <a href="#">Buy now</a> |
| 47  | <a href="#">6H1-43817-01</a><br>Filter 2                 | <a href="#">Buy now</a> |
| 48  | <a href="#">6H1-43831-10</a><br>Connector, shaft         | <a href="#">Buy now</a> |
| 49  | <a href="#">6H1-43830-11</a><br>Gear pump assembly       | <a href="#">Buy now</a> |
| 50  | <a href="#">6H1-43847-00</a><br>Seat, manual valve       | <a href="#">Buy now</a> |
| 51  | <a href="#">6H1-43899-00</a><br>Spring, manual release   | <a href="#">Buy now</a> |
| 52  | <a href="#">6H1-4382A-10</a><br>Adaptor 1                | <a href="#">Buy now</a> |
| 53  | <a href="#">6H1-43854-00</a><br>Spring, manual release   | <a href="#">Buy now</a> |
| 54  | <a href="#">93210-10M74</a><br>O-ring                    | <a href="#">Buy now</a> |
| 55  | <a href="#">6H1-43845-00</a><br>Screw, manual release    | <a href="#">Buy now</a> |
| 56  | <a href="#">93210-18M75</a><br>O-ring (6e5)              | <a href="#">Buy now</a> |
| 57  | <a href="#">6H1-43875-00</a><br>Ring, snap               | <a href="#">Buy now</a> |
| 58  | <a href="#">6H1-43822-10</a><br>Seal, trim dust          | <a href="#">Buy now</a> |
| 59  | <a href="#">6H1-43821-11</a><br>Screw, trim cylinder end | <a href="#">Buy now</a> |
| 61  | <a href="#">6H1-4384E-20</a><br>Spring, trim             | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy




6H30010-4190

E3

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 62  | <a href="#">98501-05010</a><br>Screw, pan head(62x)  | <a href="#">Buy now</a> |
| 63  | <a href="#">92901-05200</a><br>Ybs66-5 washer, plain | <a href="#">Buy now</a> |
| 64  | <a href="#">6H1-43820-11</a><br>Piston sub assembly  | <a href="#">Buy now</a> |
| 65  | <a href="#">6H1-43864-00</a><br>O-ring               | <a href="#">Buy now</a> |
| 66  | <a href="#">91318-08016</a><br>Bolt, socket          | <a href="#">Buy now</a> |
| 67  | <a href="#">6H1-43874-00</a><br>Ring, back up        | <a href="#">Buy now</a> |
| 68  | <a href="#">6H1-43816-00</a><br>Filter 1             | <a href="#">Buy now</a> |
| 69  | <a href="#">6H1-43896-00</a><br>O-ring (2h7)         | <a href="#">Buy now</a> |
| 70  | <a href="#">6H1-43895-12</a><br>Seat, relief valve   | <a href="#">Buy now</a> |
| 71  | <a href="#">62F-43855-00</a><br>Spring, up relief    | <a href="#">Buy now</a> |
| 71  | <a href="#">6H1-43855-11</a><br>Spring, up relief    | <a href="#">Buy now</a> |
| 72  | <a href="#">6H1-43843-11</a><br>Screw, valve lock    | <a href="#">Buy now</a> |
| 73  | <a href="#">6H1-4388E-11</a><br>Plug, taper screw    | <a href="#">Buy now</a> |
| 74  | <a href="#">6H1-43868-00</a><br>O-ring               | <a href="#">Buy now</a> |
| 75  | <a href="#">98501-04025</a><br>Screw, pan head       | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy



E3

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 76  | <a href="#">92901-04100</a><br>Ybs67-4 washer, spring | <a href="#">Buy now</a> |
| 77  | <a href="#">6H1-4387J-00</a><br>Washer, special 2     | <a href="#">Buy now</a> |
| 78  | <a href="#">6H1-4385H-00</a><br>Spring, seal          | <a href="#">Buy now</a> |
| 79  | <a href="#">93505-32038</a><br>Ball(7fk)              | <a href="#">Buy now</a> |


# Remote Control Assy



**B3**

| Ref | Part                                                                           |                         |
|-----|--------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">703-48207-17</a><br>703 mec rc side mount push<br>AP WITH PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">703-48261-01</a><br>Arm, throttle                                  | <a href="#">Buy now</a> |
| 3   | <a href="#">703-48153-00</a><br>Shaft, free accel.                             | <a href="#">Buy now</a> |
| 4   | <a href="#">703-48235-00</a><br>Bushing                                        | <a href="#">Buy now</a> |
| 5   | <a href="#">703-48268-00</a><br>Spacer 3                                       | <a href="#">Buy now</a> |
| 6   | <a href="#">703-48264-00</a><br>Throttle, friction                             | <a href="#">Buy now</a> |
| 7   | <a href="#">95380-05600</a><br>Nut, hexagon (663)                              | <a href="#">Buy now</a> |
| 8   | <a href="#">97380-05025</a><br>Bolt                                            | <a href="#">Buy now</a> |
| 9   | <a href="#">703-48265-00</a><br>Shaft Friction                                 | <a href="#">Buy now</a> |
| 10  | <a href="#">93430-06024</a><br>Circlip (701)                                   | <a href="#">Buy now</a> |
| 11  | <a href="#">703-48245-00</a><br>Plate, lock                                    | <a href="#">Buy now</a> |
| 12  | <a href="#">703-48252-00</a><br>Roller, cam                                    | <a href="#">Buy now</a> |
| 13  | <a href="#">701-48248-00</a><br>Roller, free accel                             | <a href="#">Buy now</a> |
| 14  | <a href="#">703-48198-00</a><br>Washer, wave 3                                 | <a href="#">Buy now</a> |
| 15  | <a href="#">703-48243-00</a><br>Bushing 3                                      | <a href="#">Buy now</a> |


# Remote Control Assy



**B3**

| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 16  | <a href="#">703-48236-00</a><br>Bushing                       | <a href="#">Buy now</a> |
| 17  | <a href="#">703-48189-00</a><br>Retainer                      | <a href="#">Buy now</a> |
| 18  | <a href="#">703-48234-00</a><br>Roller, detent                | <a href="#">Buy now</a> |
| 19  | <a href="#">703-48345-01</a><br>Cable end, remote control 2   | <a href="#">Buy now</a> |
| 20  | <a href="#">703-48358-00</a><br>Anchor, cable                 | <a href="#">Buy now</a> |
| 21  | <a href="#">703-48244-00</a><br>Spring, free accel.           | <a href="#">Buy now</a> |
| 22  | <a href="#">703-48238-00</a><br>Spring, detent                | <a href="#">Buy now</a> |
| 23  | <a href="#">703-48246-00</a><br>Spacer 1                      | <a href="#">Buy now</a> |
| 24  | <a href="#">703-48227-00</a><br>Spring, neutral lock          | <a href="#">Buy now</a> |
| 25  | <a href="#">703-82594-00</a><br>Clamp<br>WITH PT/T SW.        | <a href="#">Buy now</a> |
| 26  | <a href="#">703-48226-00</a><br>Plate, stopper                | <a href="#">Buy now</a> |
| 27  | <a href="#">703-48222-00</a><br>Grip, control lever<br>SINGLE | <a href="#">Buy now</a> |
| 28  | <a href="#">703-48223-00</a><br>Lock, neutral                 | <a href="#">Buy now</a> |
| 29  | <a href="#">703-48225-00</a><br>Cover                         | <a href="#">Buy now</a> |
| 30  | <a href="#">703-48219-00</a><br>Cover, lead                   | <a href="#">Buy now</a> |


# Remote Control Assy



**B3**

| Ref | Part                                                                    |                         |
|-----|-------------------------------------------------------------------------|-------------------------|
| 31  | <a href="#">703-48281-00</a><br>Screw, flat head                        | <a href="#">Buy now</a> |
| 32  | <a href="#">703-48282-00</a><br>Screw                                   | <a href="#">Buy now</a> |
| 33  | <a href="#">97380-08030</a><br>Bolt, hexagon (fj1)                      | <a href="#">Buy now</a> |
| 34  | <a href="#">92990-08600</a><br>Washer, plain (663)                      | <a href="#">Buy now</a> |
| 35  | <a href="#">98580-04010</a><br>Screw, pan head (e56)                    | <a href="#">Buy now</a> |
| 36  | <a href="#">98580-04006</a><br>Screw, pan head (7h3)                    | <a href="#">Buy now</a> |
| 37  | <a href="#">98580-05010</a><br>Screw, pan head(62x)                     | <a href="#">Buy now</a> |
| 38  | <a href="#">98580-03015</a><br>Screw, pan head (n151)                   | <a href="#">Buy now</a> |
| 39  | <a href="#">703-48291-10</a><br>Screw                                   | <a href="#">Buy now</a> |
| 40  | <a href="#">95380-06600</a><br>Nut(661)                                 | <a href="#">Buy now</a> |
| 41  | <a href="#">703-48293-10</a><br>Spacer, remote control<br><b>SINGLE</b> | <a href="#">Buy now</a> |
| 42  | <a href="#">701-48287-00</a><br>Washer 1                                | <a href="#">Buy now</a> |
| 43  | <a href="#">703-48215-00</a><br>Graphic                                 | <a href="#">Buy now</a> |
| 44  | <a href="#">703-82510-43</a><br>Main switch assembly                    | <a href="#">Buy now</a> |
| 45  | <a href="#">703-82577-00</a><br>Cap, key                                | <a href="#">Buy now</a> |


# Remote Control Assy



**B3**

| Ref | Part                                                                        |                         |
|-----|-----------------------------------------------------------------------------|-------------------------|
| 46  | <a href="#">703-82531-00</a><br>Wire, lead                                  | <a href="#">Buy now</a> |
| 47  | <a href="#">688-82575-01</a><br>Engine stop switch assembly                 | <a href="#">Buy now</a> |
| 48  | <a href="#">682-82556-00</a><br>Lanyard, stop switch                        | <a href="#">Buy now</a> |
| 49  | <a href="#">688-8258A-20</a><br>10p main harness mec 2m (6ft)<br>L)5M (10P) | <a href="#">Buy now</a> |
| 50  | <a href="#">703-82540-00</a><br>Neutral switch assembly                     | <a href="#">Buy now</a> |
| 51  | <a href="#">703-83383-A0</a><br>Buzzer                                      | <a href="#">Buy now</a> |
| 52  | <a href="#">703-48284-10</a><br>Grommet                                     | <a href="#">Buy now</a> |
| 53  | <a href="#">703-82591-00</a><br>Band                                        | <a href="#">Buy now</a> |
| 54  | <a href="#">703-82592-00</a><br>Band                                        | <a href="#">Buy now</a> |
| 55  | <a href="#">703-82563-12</a><br>Trim & tilt switch assembly                 | <a href="#">Buy now</a> |
| 56  | <a href="#">703-48221-00</a><br>Grip                                        | <a href="#">Buy now</a> |
| 57  | <a href="#">703-48152-00</a><br>Knob, free accel                            | <a href="#">Buy now</a> |
| 58  | <a href="#">703-48212-00</a><br>Rear housing                                | <a href="#">Buy now</a> |
| 59  | <a href="#">703-48213-00</a><br>Back, panel                                 | <a href="#">Buy now</a> |
| 60  | <a href="#">703-48271-00</a><br>Arm, shift                                  | <a href="#">Buy now</a> |


# Remote Control Assy



**B3**


| Ref | Part                                       |                         |
|-----|--------------------------------------------|-------------------------|
| 61  | <a href="#">703-48211-01</a><br>Housing,1  | <a href="#">Buy now</a> |
| 62  | <a href="#">703-48232-00</a><br>Drive gear | <a href="#">Buy now</a> |

# Remote Control Box



| Ref | Part                                                                           |                         |
|-----|--------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">703-48207-17</a><br>703 mec rc side mount push<br>AP WITH PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-00</a><br>Cable, Remote Control L=12F<br>UR              | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-20</a><br>Cable, Remote Control L=13F<br>UR              | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-30</a><br>Cable, Remote Control L=14F<br>UR              | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-50</a><br>Cable, Remote Control L=15F<br>UR              | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-60</a><br>Cable, Remote Control L=16F<br>UR              | <a href="#">Buy now</a> |
| 2   | <a href="#">701-48320-80</a><br>Cable, Remote Control L=17F<br>UR              | <a href="#">Buy now</a> |

# Repair Kit 1




6H30010-4230

**B7**

| Ref | Part                                                                |                         |
|-----|---------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">62F-W0001-01</a><br>Power Head Gasket Kit               | <a href="#">Buy now</a> |
| 1   | <a href="#">6H3-W0001-02</a><br>Power head gasket kit<br>AUTO CHOKE | <a href="#">Buy now</a> |
| 2   | <a href="#">6H3-11181-A1</a><br>Gasket, cylinder head 1             | <a href="#">Buy now</a> |
| 3   | <a href="#">90430-14115</a><br>Gasket (663)                         | <a href="#">Buy now</a> |
| 4   | <a href="#">6H3-11193-A1</a><br>Gasket, head cover 1                | <a href="#">Buy now</a> |
| 5   | <a href="#">6H3-12414-A1</a><br>Gasket, cover                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6H3-41112-A0</a><br>Gasket, exhaust inner cover         | <a href="#">Buy now</a> |
| 7   | <a href="#">6H3-41114-A0</a><br>Gasket, exhaust outer cover         | <a href="#">Buy now</a> |
| 8   | <a href="#">93102-36M24</a><br>Oil seal(52w)                        | <a href="#">Buy now</a> |
| 9   | <a href="#">93210-46M16</a><br>O-ring (688)                         | <a href="#">Buy now</a> |
| 10  | <a href="#">93102-30M23</a><br>Oil seal (6h3)                       | <a href="#">Buy now</a> |
| 11  | <a href="#">93106-18M01</a><br>Oil seal (6h3)                       | <a href="#">Buy now</a> |
| 12  | <a href="#">93210-65M50</a><br>O-ring                               | <a href="#">Buy now</a> |
| 13  | <a href="#">6H3-13621-A1</a><br>Gasket, valve seat                  | <a href="#">Buy now</a> |
| 14  | <a href="#">6H4-14198-01</a><br>Gasket                              | <a href="#">Buy now</a> |

# Repair Kit 1




6H30010-4230

**B7**


| Ref | Part                                                                       |                         |
|-----|----------------------------------------------------------------------------|-------------------------|
| 14  | <a href="#">93210-39ME4</a><br>O-ring(6h2)                                 | <a href="#">Buy now</a> |
| 15  | <a href="#">6H4-14984-00</a><br>Gasket, float chamber                      | <a href="#">Buy now</a> |
| 16  | <a href="#">93210-32738</a><br>O-ring(1wg)                                 | <a href="#">Buy now</a> |
| 17  | <a href="#">650-24431-A0</a><br>Gasket,fuel pump                           | <a href="#">Buy now</a> |
| 18  | <a href="#">6H3-45113-A0</a><br>Gasket, upper casing                       | <a href="#">Buy now</a> |
| 19  | <a href="#">6H3-13622-A1</a><br>Gasket, valve seat                         | <a href="#">Buy now</a> |
| 20  | <a href="#">62F-W0093-00</a><br>Carburetor Repair Kit                      | <a href="#">Buy now</a> |
| 20  | <a href="#">6H2-W0093-10</a><br>Carburetor repair kit<br><b>AUTO CHOKE</b> | <a href="#">Buy now</a> |
| 21  | <a href="#">6H4-14147-00</a><br>O-ring                                     | <a href="#">Buy now</a> |
| 22  | <a href="#">93210-04228</a><br>O-ring (371)                                | <a href="#">Buy now</a> |
| 23  | <a href="#">6H3-14590-01</a><br>Needle valve assembly                      | <a href="#">Buy now</a> |
| 23  | <a href="#">6H4-14590-01</a><br>Needle valve assembly                      | <a href="#">Buy now</a> |
| 24  | <a href="#">6H4-14548-00</a><br>Pin, float arm                             | <a href="#">Buy now</a> |
| 25  | <a href="#">663-14159-00</a><br>Clip                                       | <a href="#">Buy now</a> |
| 26  | <a href="#">676-14186-00</a><br>Pin, valve                                 | <a href="#">Buy now</a> |

# Repair Kit 1




| Ref | Part                                        |                         |
|-----|---------------------------------------------|-------------------------|
| 27  | <a href="#">676-14966-00</a><br>Rubber cap  | <a href="#">Buy now</a> |
| 29  | <a href="#">93210-04230</a><br>O-ring (371) | <a href="#">Buy now</a> |

## Repair Kit 2




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">62F-W0001-20</a><br>Lower unit gasket kit        | <a href="#">Buy now</a> |
| 1   | <a href="#">6H3-W0001-22</a><br>Lower unit gasket kit        | <a href="#">Buy now</a> |
| 2   | <a href="#">6H3-45114-A1</a><br>Gasket, upper casing         | <a href="#">Buy now</a> |
| 3   | <a href="#">6H3-45123-00</a><br>Gasket, muffler              | <a href="#">Buy now</a> |
| 4   | <a href="#">90430-08020</a><br>Gasket                        | <a href="#">Buy now</a> |
| 5   | <a href="#">93210-49046</a><br>O-ring (620)                  | <a href="#">Buy now</a> |
| 6   | <a href="#">93106-09014</a><br>Oil seal                      | <a href="#">Buy now</a> |
| 7   | <a href="#">663-44315-A0</a><br>Gasket,water pump 1          | <a href="#">Buy now</a> |
| 7   | <a href="#">6H3-44315-A0</a><br>Gasket,water pump 1          | <a href="#">Buy now</a> |
| 8   | <a href="#">663-44324-A0</a><br>Gasket,cartridge outer plate | <a href="#">Buy now</a> |
| 8   | <a href="#">6H3-44324-A0</a><br>Gasket,cartridge Out,plate   | <a href="#">Buy now</a> |
| 9   | <a href="#">663-44316-A0</a><br>Gasket,water pump 2          | <a href="#">Buy now</a> |
| 9   | <a href="#">688-44316-A0</a><br>Gasket,water pump 2          | <a href="#">Buy now</a> |
| 10  | <a href="#">93210-41042</a><br>O-ring (132)                  | <a href="#">Buy now</a> |
| 10  | <a href="#">93210-46044</a><br>O-ring                        | <a href="#">Buy now</a> |

## Repair Kit 2




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 11  | <a href="#">93101-23070</a><br>Oil seal (663)          | <a href="#">Buy now</a> |
| 12  | <a href="#">93101-22067</a><br>Oil seal (22x36x6-663)  | <a href="#">Buy now</a> |
| 12  | <a href="#">93101-25M03</a><br>Oil seal                | <a href="#">Buy now</a> |
| 13  | <a href="#">93210-66M98</a><br>O-ring(6h4)             | <a href="#">Buy now</a> |
| 13  | <a href="#">93210-85M97</a><br>O-ring(6h1)             | <a href="#">Buy now</a> |
| 14  | <a href="#">663-44366-00</a><br>Damper, water seal 2   | <a href="#">Buy now</a> |
| 15  | <a href="#">62F-W0078-00</a><br>Water pump repair kit  | <a href="#">Buy now</a> |
| 15  | <a href="#">6H3-W0078-02</a><br>Water pump repair kit  | <a href="#">Buy now</a> |
| 16  | <a href="#">663-44322-00</a><br>Insert, cartridge      | <a href="#">Buy now</a> |
| 17  | <a href="#">6H3-44352-00</a><br>Impellar               | <a href="#">Buy now</a> |
| 19  | <a href="#">663-44323-00</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |
| 19  | <a href="#">6H3-44323-00</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |
| 23  | <a href="#">90119-08M14</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 23  | <a href="#">97095-08045</a><br>Bolt, hexagon           | <a href="#">Buy now</a> |
| 24  | <a href="#">90119-08M33</a><br>Bolt, with washer(6b0)  | <a href="#">Buy now</a> |

# Repair Kit 2



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 24  | <a href="#">97095-08055</a><br>Bolt, hexagon           | <a href="#">Buy now</a> |
| 25  | <a href="#">90280-03M03</a><br>Key, woodruff (697)     | <a href="#">Buy now</a> |
| 26  | <a href="#">6H3-W0078-1A</a><br>Chrome pump kit        | <a href="#">Buy now</a> |
| 27  | <a href="#">663-44322-40</a><br>Insert, cartridge      | <a href="#">Buy now</a> |
| 28  | <a href="#">6H3-44323-40</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |


# Starting Motor



**D1**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H3-81800-11</a><br>Starting motor assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">689-81857-11</a><br>Pinion stopper set      | <a href="#">Buy now</a> |
| 3   | <a href="#">6H3-81807-10</a><br>Pinion assembly         | <a href="#">Buy now</a> |
| 4   | <a href="#">6H3-81830-10</a><br>Front cover assembly    | <a href="#">Buy now</a> |
| 5   | <a href="#">689-81831-00</a><br>Metal, front            | <a href="#">Buy now</a> |
| 6   | <a href="#">689-81847-11</a><br>O-ring                  | <a href="#">Buy now</a> |
| 7   | <a href="#">689-81809-11</a><br>Washer kit              | <a href="#">Buy now</a> |
| 8   | <a href="#">689-81850-12</a><br>Armature assembly       | <a href="#">Buy now</a> |
| 9   | <a href="#">6H3-81810-10</a><br>Stator assembly         | <a href="#">Buy now</a> |
| 10  | <a href="#">689-81840-11</a><br>Brush holder assembly   | <a href="#">Buy now</a> |
| 11  | <a href="#">689-81812-11</a><br>Brush 2                 | <a href="#">Buy now</a> |
| 12  | <a href="#">689-81811-11</a><br>Brush 1                 | <a href="#">Buy now</a> |
| 13  | <a href="#">689-81813-10</a><br>Spring, brush           | <a href="#">Buy now</a> |
| 14  | <a href="#">6H3-81820-11</a><br>Rear cover assembly     | <a href="#">Buy now</a> |
| 15  | <a href="#">689-81826-10</a><br>Bolt                    | <a href="#">Buy now</a> |


# Starting Motor



**D1**

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">97013-08035</a><br>Bolt                | <a href="#">Buy now</a> |
| 17  | <a href="#">92903-08600</a><br>Washer, plain (663) | <a href="#">Buy now</a> |
| 18  | <a href="#">97013-06025</a><br>Bolt(62y)           | <a href="#">Buy now</a> |
| 19  | <a href="#">92903-06600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 20  | <a href="#">97013-08016</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |

# Steering Guide




6880700-9190

**B1**

| Ref | Part                                                                |                         |
|-----|---------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">688-61350-10</a><br>Steering guide attachment kit<br>AP | <a href="#">Buy now</a> |
| 2   | <a href="#">688-61351-10</a><br>Rod, steering link                  | <a href="#">Buy now</a> |
| 3   | <a href="#">90201-10M20</a><br>Washer, plate (663)                  | <a href="#">Buy now</a> |
| 4   | <a href="#">90185-09M01</a><br>Nut, nylon (663)                     | <a href="#">Buy now</a> |
| 5   | <a href="#">90170-09M03</a><br>Nut (689)                            | <a href="#">Buy now</a> |
| 6   | <a href="#">90387-10M42</a><br>Coller (688)                         | <a href="#">Buy now</a> |
| 7   | <a href="#">90201-10M63</a><br>Washer, plate                        | <a href="#">Buy now</a> |
| 8   | <a href="#">6E5-61355-00</a><br>Bolt                                | <a href="#">Buy now</a> |
| 9   | <a href="#">6E5-43145-01</a><br>Cap, clamp bracket                  | <a href="#">Buy now</a> |
| 10  | <a href="#">93210-16275</a><br>O-ring                               | <a href="#">Buy now</a> |


# Top Cowling



A4

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">62F-42610-40-4D</a><br>Top Cowling assembly  | <a href="#">Buy now</a> |
| 1   | <a href="#">6H2-42610-80-4D</a><br>Top Cowling assembly  | <a href="#">Buy now</a> |
| 1   | <a href="#">6H3-42610-50-4D</a><br>Top Cowling assembly  | <a href="#">Buy now</a> |
| 2   | <a href="#">63D-2177H-00</a><br>Disk cap 2               | <a href="#">Buy now</a> |
| 3   | <a href="#">6H3-42647-00-94</a><br>Holder, clamp band    | <a href="#">Buy now</a> |
| 4   | <a href="#">6H3-42649-00-94</a><br>Holder, clamp band    | <a href="#">Buy now</a> |
| 5   | <a href="#">663-42662-00</a><br>Damper                   | <a href="#">Buy now</a> |
| 6   | <a href="#">6H3-42652-00</a><br>Hook 2                   | <a href="#">Buy now</a> |
| 7   | <a href="#">97095-06016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 8   | <a href="#">92995-06100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |
| 9   | <a href="#">92995-06600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 10  | <a href="#">90266-06009</a><br>Rivet (697)               | <a href="#">Buy now</a> |
| 11  | <a href="#">6H3-42613-01-4D</a><br>Molding air duct      | <a href="#">Buy now</a> |
| 14  | <a href="#">6H3-42615-00</a><br>Seal                     | <a href="#">Buy now</a> |
| 15  | <a href="#">62F-42677-40</a><br>Graphic, front           | <a href="#">Buy now</a> |

# Top Cowling




6H23300-2010

A4

| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 15  | <a href="#">6H2-42677-50</a><br>Graphic, rear    | <a href="#">Buy now</a> |
| 15  | <a href="#">6H3-42677-50</a><br>Graphic, rear    | <a href="#">Buy now</a> |
| 16  | <a href="#">62F-42678-30</a><br>Graphic, front   | <a href="#">Buy now</a> |
| 16  | <a href="#">6H2-42678-30</a><br>Graphic, front   | <a href="#">Buy now</a> |
| 16  | <a href="#">6H3-42678-30</a><br>Graphic, rear    | <a href="#">Buy now</a> |
| 17  | <a href="#">6H3-W0070-30</a><br>Graphic set      | <a href="#">Buy now</a> |
| 18  | <a href="#">6H3-13436-00</a><br>Mark             | <a href="#">Buy now</a> |
| 18  | <a href="#">6H3-13436-40</a><br>Mark             | <a href="#">Buy now</a> |
| 19  | <a href="#">6H3-42617-10</a><br>Damper, Form     | <a href="#">Buy now</a> |
| 20  | <a href="#">6H3-42619-00</a><br>Damper (350x640) | <a href="#">Buy now</a> |
| 21  | <a href="#">6H3-42627-00</a><br>Damper (350x640) | <a href="#">Buy now</a> |
| 22  | <a href="#">6H3-42637-00</a><br>Damper, Form     | <a href="#">Buy now</a> |
| 23  | <a href="#">6H1-42694-00</a><br>Band             | <a href="#">Buy now</a> |
| 24  | <a href="#">6H3-21732-00</a><br>Seal 1           | <a href="#">Buy now</a> |
| 25  | <a href="#">6H3-21735-00</a><br>Seal 2           | <a href="#">Buy now</a> |

## Top Cowling




6H23300-2010

A4

| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 26  | <a href="#">90338-05M03</a><br>Plug (6h1)       | <a href="#">Buy now</a> |
| 27  | <a href="#">90183-05M06</a><br>Nut, spring(6h4) | <a href="#">Buy now</a> |
| 28  | <a href="#">6H3-42681-30</a><br>Mark, cowling   | <a href="#">Buy now</a> |
| 29  | <a href="#">6H3-42682-30</a><br>Mark, cowling   | <a href="#">Buy now</a> |


## Upper Casing



**E6**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6H3-45111-11-4D</a><br>Casing, upper<br>L | <a href="#">Buy now</a> |
| 2   | <a href="#">93606-12019</a><br>Pin, dowel (614)       | <a href="#">Buy now</a> |
| 3   | <a href="#">6H3-45155-00</a><br>Cap                   | <a href="#">Buy now</a> |
| 4   | <a href="#">90119-08M81</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 5   | <a href="#">6H3-41137-01-94</a><br>Guide, exhaust     | <a href="#">Buy now</a> |
| 7   | <a href="#">6H3-45113-A0</a><br>Gasket, upper casing  | <a href="#">Buy now</a> |
| 8   | <a href="#">90119-08M79</a><br>Bolt, hexagon (fj1)    | <a href="#">Buy now</a> |
| 9   | <a href="#">97075-08035</a><br>Bolt(70w)              | <a href="#">Buy now</a> |
| 10  | <a href="#">92995-08100</a><br>Ybs67-8 washer, spring | <a href="#">Buy now</a> |
| 11  | <a href="#">6H2-41131-00-5B</a><br>Manifold, ext. 1   | <a href="#">Buy now</a> |
| 11  | <a href="#">6H3-41131-00-5B</a><br>Manifold, ext      | <a href="#">Buy now</a> |
| 12  | <a href="#">97075-08030</a><br>Bolt, hexagon (fj1)    | <a href="#">Buy now</a> |
| 14  | <a href="#">6H3-14711-10-5B</a><br>Muffler 1<br>L     | <a href="#">Buy now</a> |
| 15  | <a href="#">6H3-45127-00</a><br>Seal 1                | <a href="#">Buy now</a> |
| 16  | <a href="#">6H3-45123-00</a><br>Gasket, muffler       | <a href="#">Buy now</a> |

## Upper Casing



**E6**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 17  | <a href="#">6H3-45114-A1</a><br>Gasket, upper casing | <a href="#">Buy now</a> |
| 20  | <a href="#">6H3-14737-10</a><br>Damper, muffler<br>L | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.