



# Yamaha Boat Lan Guage 2005

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

<b>ALTERNATE 1</b> .....	3
<b>ALTERNATE 2</b> .....	4
<b>ALTERNATE 3</b> .....	5
<b>ALTERNATE 4</b> .....	6
<b>ELECTRICAL 1</b> .....	7
<b>METER</b> .....	10

## Alternate 1




Ref	Part	
1	<a href="#">6Y88368801</a> Transom Mount Triducer	<a href="#">Buy now</a>
2	<a href="#">6Y88368811</a> Plastic Thru-Hull Triducer	<a href="#">Buy now</a>
3	<a href="#">6Y88368820</a> Bronze Thru-Hull Triducer	<a href="#">Buy now</a>
4	<a href="#">6Y88252101</a> 1ft pigtail bus UR	<a href="#">Buy now</a>
4	<a href="#">6Y88252111</a> Pigtail bus wire 0.6m-2ft UR	<a href="#">Buy now</a>
4	<a href="#">6Y88252121</a> Pigtail bus wire 0.9m-3ft UR	<a href="#">Buy now</a>
4	<a href="#">6Y88252131</a> Pigtail bus wire 1.8m-6ft UR	<a href="#">Buy now</a>
4	<a href="#">6Y88252141</a> 9ft pigtail bus UR	<a href="#">Buy now</a>
4	<a href="#">6Y88252151</a> Pigtail bus wire 3.6m-12ft UR	<a href="#">Buy now</a>

## Alternate 2

### Cooling water pressure sensor

Models: F50, T50, F60, T60, F75, F90, (L)F115, (L)Z150, VZ150, (V)Z175, (L)Z200, VZ200, VZ225, (L)Z250, VZ250, (L)Z300, VZ300




6Y82110-E040

Ref	Part	
1	<a href="#">60V8A4L001</a> Sensor, module LM	<a href="#">Buy now</a>
2	<a href="#">60V8366D00</a> Adaptor, input	<a href="#">Buy now</a>
3	<a href="#">9589506025</a> Bolt, flange deep recess EXCEPT F50/T50/F60/T60	<a href="#">Buy now</a>
4	<a href="#">60V8366700</a> Sender, water pressure	<a href="#">Buy now</a>
5	<a href="#">9043014115</a> Gasket (663)	<a href="#">Buy now</a>
6	<a href="#">9044507018</a> Hose (l:1457)	<a href="#">Buy now</a>
7	<a href="#">9044707015</a> Hose, cover (l: 1300mm)	<a href="#">Buy now</a>
8	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
9	<a href="#">6Y58366B00</a> Sensor, water pressure	<a href="#">Buy now</a>
10	<a href="#">60V8257V00</a> Plate, connector HPDI MODELS	<a href="#">Buy now</a>
11	<a href="#">9709506016</a> Bolt, hexagon deep recess F50/T50/F60/T60	<a href="#">Buy now</a>
12	<a href="#">9299506600</a> Washer, plain (646) F50/T50/F60/T60	<a href="#">Buy now</a>

## Alternate 3

### *Cooling water pressure sensor*

Models: (L)F150, (L)F200, (L)F225, (L)F250




6Y82110-E050

Ref	Part	
1	<a href="#">69J8A4L000</a> Water pressure sensor kit LM	<a href="#">Buy now</a>
2	<a href="#">6Y58366B00</a> Sensor, water pressure	<a href="#">Buy now</a>
3	<a href="#">69J8366C00</a> Adaptor, input FOR (L)F200/(L)F225	<a href="#">Buy now</a>
4	<a href="#">63P8366C00</a> Adaptor, input FOR (L)F150/(L)F250	<a href="#">Buy now</a>
5	<a href="#">9043014115</a> Gasket (663)	<a href="#">Buy now</a>

## Alternate 4

### Speed sensor


All models



6Y82110-E060


Ref	Part	
1	<a href="#">60V8A4L101</a> Sensor, module 1 LM	<a href="#">Buy now</a>
2	<a href="#">6Y58366B00</a> Sensor, water pressure	<a href="#">Buy now</a>
3	<a href="#">60V8366D00</a> Adaptor, input	<a href="#">Buy now</a>
4	<a href="#">9010906M81</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">9044507017</a> Hose (I550)	<a href="#">Buy now</a>
7	<a href="#">9044707013</a> Hose, cover (l: 700mm)	<a href="#">Buy now</a>
8	<a href="#">60V4262900</a> Seal	<a href="#">Buy now</a>
9	<a href="#">9709506016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
10	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
1	<a href="#">6Y88356N01</a> Lead, fuel tank & gps sender	<a href="#">Buy now</a>
2	<a href="#">6Y88192001</a> Multi-hub UN	<a href="#">Buy now</a>
3	<a href="#">6Y88537101</a> End of line resister	<a href="#">Buy now</a>
4	<a href="#">6Y88192011</a> Single-hub	<a href="#">Buy now</a>
5	<a href="#">6Y88258201</a> Red cap 1 (2pin) UN	<a href="#">Buy now</a>
6	<a href="#">6Y88258211</a> White cap 1 (4pin) UN	<a href="#">Buy now</a>
7	<a href="#">6Y88255301</a> Main bus wire 0.3m-1ft UR	<a href="#">Buy now</a>
7	<a href="#">6Y88255311</a> Main bus wire 4.6m (15ft) UR	<a href="#">Buy now</a>
7	<a href="#">6Y88255321</a> Main bus wire 6.1m (20ft) UR	<a href="#">Buy now</a>
7	<a href="#">6Y88255331</a> Main bus wire 7.6m (25ft) UR	<a href="#">Buy now</a>
7	<a href="#">6Y88255341</a> Main bus wire 9.1m (30ft) UR	<a href="#">Buy now</a>
7	<a href="#">6Y88255350</a> Main bus wire 3.0m-10ft UR	<a href="#">Buy now</a>
8	<a href="#">6Y88252101</a> 1ft pigtail bus UR	<a href="#">Buy now</a>
8	<a href="#">6Y88252111</a> Pigtail bus wire 0.6m-2ft UR	<a href="#">Buy now</a>
8	<a href="#">6Y88252121</a> Pigtail bus wire 0.9m-3ft UR	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
8	<a href="#">6Y88252131</a> Pigtail bus wire 1.8m-6ft UR	<a href="#">Buy now</a>
8	<a href="#">6Y88252141</a> 9ft pigtail bus UR	<a href="#">Buy now</a>
8	<a href="#">6Y88252151</a> Pigtail bus wire 3.6m-12ft UR	<a href="#">Buy now</a>
9	<a href="#">6Y88355301</a> 8ft power wire	<a href="#">Buy now</a>
10	<a href="#">6G18215100</a> Fuse (10a)	<a href="#">Buy now</a>
11	<a href="#">6Y88257001</a> Panel switch assembly	<a href="#">Buy now</a>
12	<a href="#">6Y88257101</a> Plate, panel switch	<a href="#">Buy now</a>
13	<a href="#">6Y88251001</a> Main switch assembly	<a href="#">Buy now</a>
14	<a href="#">6768257700</a> Cap, key	<a href="#">Buy now</a>
15	<a href="#">6K18257500</a> Engine stop switch assembly	<a href="#">Buy now</a>
16	<a href="#">6828255600</a> Lanyard, stop switch	<a href="#">Buy now</a>
17	<a href="#">6R58338300</a> Buzzer	<a href="#">Buy now</a>
18	<a href="#">68V8195000</a> Relay assembly	<a href="#">Buy now</a>
19	<a href="#">6Y88250700</a> Lead, ignition switch relay	<a href="#">Buy now</a>
20	<a href="#">64D8258100</a> Stay, cord clamp	<a href="#">Buy now</a>

# Electrical 1



Ref	Part	
21	<a href="#">9730305012</a> Bolt, hexagon	<a href="#">Buy now</a>
22	<a href="#">9290305100</a> Ybs67-5 washer, spring	<a href="#">Buy now</a>
23	<a href="#">9530305700</a> Nut (656)	<a href="#">Buy now</a>
24	<a href="#">6K18257102</a> Plate, panel switch	<a href="#">Buy now</a>

# Meter



Ref	Part	
1	<a href="#">6Y88350T01</a> Tachometer, sq	<a href="#">Buy now</a>
2	<a href="#">6Y88336300</a> Bezel, square	<a href="#">Buy now</a>
3	<a href="#">6Y88438300</a> Nut, ring	<a href="#">Buy now</a>
4	<a href="#">6Y88350S01</a> Speedometer Sq	<a href="#">Buy now</a>
7	<a href="#">6Y88350F01</a> Fl mgt meter, sq <b>FUEL MANAGEMENT</b>	<a href="#">Buy now</a>
10	<a href="#">6Y88350001</a> S&fm meter, sq <b>SPEED &amp; FUEL</b>	<a href="#">Buy now</a>
13	<a href="#">6Y88350T11</a> Tachometer, rd	<a href="#">Buy now</a>
15	<a href="#">6Y88350011</a> S & fm meter, rd <b>SPEED &amp; FUEL</b>	<a href="#">Buy now</a>
17	<a href="#">6Y88351400</a> Plate, fitting <b>UN</b>	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.