



# Yamaha E40XMH 2001

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


|                                   |    |
|-----------------------------------|----|
| <b>Bottom Cowling</b>             | 3  |
| <b>Bracket 1</b>                  | 5  |
| <b>Bracket 3</b>                  | 9  |
| <b>Carburetor</b>                 | 11 |
| <b>Control</b>                    | 13 |
| <b>Crankshaft &amp; Piston</b>    | 15 |
| <b>Cylinder &amp; Crankcase</b>   | 17 |
| <b>Electrical 1</b>               | 20 |
| <b>Fuel</b>                       | 22 |
| <b>Fuel Tank</b>                  | 24 |
| <b>Fuel Tank 2</b>                | 25 |
| <b>Generator</b>                  | 26 |
| <b>Intake</b>                     | 28 |
| <b>Lower Casing &amp; Drive 1</b> | 30 |
| <b>Lower Casing &amp; Drive 2</b> | 34 |
| <b>Remo Con Attachment</b>        | 36 |
| <b>Repair Kit 1</b>               | 37 |
| <b>Repair Kit 2</b>               | 39 |
| <b>Repair Kit 3</b>               | 41 |
| <b>Starter</b>                    | 42 |
| <b>Steering</b>                   | 45 |
| <b>Top Cowling</b>                | 48 |
| <b>Upper Casing</b>               | 49 |

## Bottom Cowling




| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T42710014D</a><br>Bottom cowling assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">9011906M6100</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 3   | <a href="#">9048009M2100</a><br>Grommet (6e9)           | <a href="#">Buy now</a> |
| 4   | <a href="#">903870603500</a><br>Collar (6e9)            | <a href="#">Buy now</a> |
| 5   | <a href="#">66T427160000</a><br>Rubber, seal 1          | <a href="#">Buy now</a> |
| 6   | <a href="#">66T4273800CA</a><br>Plate, fitting          | <a href="#">Buy now</a> |
| 7   | <a href="#">9010906M8100</a><br>Bolt                    | <a href="#">Buy now</a> |
| 8   | <a href="#">66T427250000</a><br>Grommet                 | <a href="#">Buy now</a> |
| 9   | <a href="#">66T42815014D</a><br>Lever, clamp            | <a href="#">Buy now</a> |
| 10  | <a href="#">9038612M3700</a><br>Bushing (6f5)           | <a href="#">Buy now</a> |
| 11  | <a href="#">9038612MA200</a><br>Bush                    | <a href="#">Buy now</a> |
| 12  | <a href="#">902061205200</a><br>Washer, wave (666)      | <a href="#">Buy now</a> |
| 13  | <a href="#">66T428160000</a><br>Lever, clamp            | <a href="#">Buy now</a> |
| 14  | <a href="#">66T431440000</a><br>Hook, spring            | <a href="#">Buy now</a> |
| 15  | <a href="#">9010906M8600</a><br>Bolt                    | <a href="#">Buy now</a> |

## Bottom Cowling



| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">9050616M3400</a><br>Spring, tension(64d)      | <a href="#">Buy now</a> |
| 17  | <a href="#">9011906M7300</a><br>Bolt(gh1)                 | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5443910000</a><br>Nipple, hose              | <a href="#">Buy now</a> |
| 19  | <a href="#">65W263260000</a><br>Grommet                   | <a href="#">Buy now</a> |
| 20  | <a href="#">676427270000</a><br>Grommet 4                 | <a href="#">Buy now</a> |
| 21  | <a href="#">6H4427260000</a><br>Grommet                   | <a href="#">Buy now</a> |
| 22  | <a href="#">66T243290000</a><br>Seal                      | <a href="#">Buy now</a> |
| 23  | <a href="#">65W427260000</a><br>Grommet                   | <a href="#">Buy now</a> |
| 24  | <a href="#">9046525M5700</a><br>Clamp(63v)                | <a href="#">Buy now</a> |
| 25  | <a href="#">9033805M0300</a><br>Plug (6h1)                | <a href="#">Buy now</a> |
| 26  | <a href="#">66T427410000</a><br>Apron                     | <a href="#">Buy now</a> |
| 27  | <a href="#">970950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 28  | <a href="#">929950660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 29  | <a href="#">9010906M8000</a><br>Bolt                      | <a href="#">Buy now</a> |


# Bracket 1



  
66T0010-1180

| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66T43111014D</a><br>Bracket, clamp 1       | <a href="#">Buy now</a> |
| 2   | <a href="#">9014914M1200</a><br>Screw(6h4)             | <a href="#">Buy now</a> |
| 3   | <a href="#">66343118014D</a><br>Handle, transom clamp  | <a href="#">Buy now</a> |
| 4   | <a href="#">648431140100</a><br>Pad, transom clamp     | <a href="#">Buy now</a> |
| 5   | <a href="#">902430400700</a><br>Pin (663)              | <a href="#">Buy now</a> |
| 6   | <a href="#">66T43112014D</a><br>Bracket, clamp 2       | <a href="#">Buy now</a> |
| 11  | <a href="#">9038708M2900</a><br>Collar                 | <a href="#">Buy now</a> |
| 12  | <a href="#">9010108M7600</a><br>Bolt                   | <a href="#">Buy now</a> |
| 13  | <a href="#">988800810000</a><br>Nut, hex.              | <a href="#">Buy now</a> |
| 14  | <a href="#">929900810000</a><br>Ybs67-8 washer, spring | <a href="#">Buy now</a> |
| 15  | <a href="#">65W43311118D</a><br>Bracket, swivel 1      | <a href="#">Buy now</a> |
| 16  | <a href="#">9370006M0300</a><br>Nipple, grease(6a1)    | <a href="#">Buy now</a> |
| 17  | <a href="#">63D431310100</a><br>Bolt, clamp bracket    | <a href="#">Buy now</a> |
| 18  | <a href="#">9038622M1500</a><br>Bushing (688)          | <a href="#">Buy now</a> |
| 19  | <a href="#">9020122M0300</a><br>Washer, plate(64j)     | <a href="#">Buy now</a> |


# Bracket 1



  
 66T0010-1180

| Ref | Part   |                         |
|-----|--|-------------------------|
| 20  | <a href="#">6J8431130100</a><br>Plate, clamp bracket     | <a href="#">Buy now</a> |
| 21  | <a href="#">901852200700</a><br>Nut, self-locking        | <a href="#">Buy now</a> |
| 22  | <a href="#">6G5431450100</a><br>Cap, clamp bracket       | <a href="#">Buy now</a> |
| 23  | <a href="#">66T436270000</a><br>Stopper                  | <a href="#">Buy now</a> |
| 24  | <a href="#">9038612M9800</a><br>Bush                     | <a href="#">Buy now</a> |
| 25  | <a href="#">902021203100</a><br>Washer, plate 6484412600 | <a href="#">Buy now</a> |
| 26  | <a href="#">9020612M0000</a><br>Washer, wave (676)       | <a href="#">Buy now</a> |
| 27  | <a href="#">9010908M9000</a><br>Bolt                     | <a href="#">Buy now</a> |
| 28  | <a href="#">9020108M0700</a><br>Washer, plate            | <a href="#">Buy now</a> |
| 29  | <a href="#">957800830000</a><br>Nut, nylon (6j8)         | <a href="#">Buy now</a> |
| 30  | <a href="#">9024912M3400</a><br>Pin                      | <a href="#">Buy now</a> |
| 31  | <a href="#">9038712M0400</a><br>Collar                   | <a href="#">Buy now</a> |
| 32  | <a href="#">9024912M3900</a><br>Pin                      | <a href="#">Buy now</a> |
| 33  | <a href="#">9038112M1100</a><br>Bush, solid              | <a href="#">Buy now</a> |
| 34  | <a href="#">9343010M0000</a><br>Circlip                  | <a href="#">Buy now</a> |


# Bracket 1



| Ref | Part  |                         |
|-----|---|-------------------------|
| 35  | <a href="#">682433180100</a><br>Cover               | <a href="#">Buy now</a> |
| 36  | <a href="#">65W436301100</a><br>Tilt lever assembly | <a href="#">Buy now</a> |
| 37  | <a href="#">9038610M9900</a><br>Bush                | <a href="#">Buy now</a> |
| 38  | <a href="#">9038607MA200</a><br>Bush                | <a href="#">Buy now</a> |
| 39  | <a href="#">9024910M3100</a><br>Pin                 | <a href="#">Buy now</a> |
| 40  | <a href="#">9038707M0500</a><br>Collar              | <a href="#">Buy now</a> |
| 41  | <a href="#">990800860000</a><br>Circlip             | <a href="#">Buy now</a> |
| 42  | <a href="#">66T433500200</a><br>Receiver assembly   | <a href="#">Buy now</a> |
| 43  | <a href="#">9050620M3700</a><br>Spring, tension     | <a href="#">Buy now</a> |
| 44  | <a href="#">66T436311100</a><br>Lever, tilt         | <a href="#">Buy now</a> |
| 45  | <a href="#">9014905M1700</a><br>Screw, pan head     | <a href="#">Buy now</a> |
| 46  | <a href="#">65W436160000</a><br>Rod, tilt lock      | <a href="#">Buy now</a> |
| 47  | <a href="#">65W436140100</a><br>Plate, tilt lock    | <a href="#">Buy now</a> |
| 48  | <a href="#">65W436150100</a><br>Plate, tilt lock    | <a href="#">Buy now</a> |
| 49  | <a href="#">65W436130000</a><br>Arm, tilt lock      | <a href="#">Buy now</a> |



# Bracket 1




66T0010-1180

| Ref | Part  |                         |
|-----|---|-------------------------|
| 50  | <a href="#">9024907M3200</a><br>Pin                   | <a href="#">Buy now</a> |
| 51  | <a href="#">9038707M2900</a><br>Collar                | <a href="#">Buy now</a> |
| 52  | <a href="#">9024907M3300</a><br>Pin                   | <a href="#">Buy now</a> |
| 53  | <a href="#">9050630M0000</a><br>Spring, tension (676) | <a href="#">Buy now</a> |
| 54  | <a href="#">914902001500</a><br>Pin, cotter (648)     | <a href="#">Buy now</a> |
| 55  | <a href="#">9010108M2800</a><br>Bolt                  | <a href="#">Buy now</a> |
| 56  | <a href="#">9050210M0600</a><br>Spring, conical(6g1)  | <a href="#">Buy now</a> |
| 57  | <a href="#">901850805700</a><br>Nut, nylon (6j8)      | <a href="#">Buy now</a> |
| 58  | <a href="#">9010110M5800</a><br>Bolt                  | <a href="#">Buy now</a> |
| 59  | <a href="#">929951060000</a><br>Washer, plate         | <a href="#">Buy now</a> |
| 60  | <a href="#">902011242600</a><br>Washer, plate(663)    | <a href="#">Buy now</a> |
| 61  | <a href="#">953801060000</a><br>Nut(624)              | <a href="#">Buy now</a> |




## Bracket 3




| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">648425280000</a><br>Plate, friction          | <a href="#">Buy now</a> |
| 2   | <a href="#">65W433730000</a><br>Seal, damper             | <a href="#">Buy now</a> |
| 3   | <a href="#">9010508M7600</a><br>Bolt, washer based       | <a href="#">Buy now</a> |
| 4   | <a href="#">901851005100</a><br>Nut, self-locking        | <a href="#">Buy now</a> |
| 5   | <a href="#">9011610M2800</a><br>Bolt, stud               | <a href="#">Buy now</a> |
| 6   | <a href="#">65W42511118D</a><br>Bracket, steering        | <a href="#">Buy now</a> |
| 7   | <a href="#">9020952M0000</a><br>Washer (676)             | <a href="#">Buy now</a> |
| 8   | <a href="#">9038652M0200</a><br>Bushing (676)            | <a href="#">Buy now</a> |
| 9   | <a href="#">9038644M0300</a><br>Bushing (676)            | <a href="#">Buy now</a> |
| 10  | <a href="#">9321043MJ000</a><br>O-ring                   | <a href="#">Buy now</a> |
| 11  | <a href="#">9038644M9900</a><br>Bush                     | <a href="#">Buy now</a> |
| 12  | <a href="#">901850804500</a><br>Nut, self-locking        | <a href="#">Buy now</a> |
| 13  | <a href="#">929070820000</a><br>Washer(6tc)              | <a href="#">Buy now</a> |
| 14  | <a href="#">9010108M8600</a><br>Bolt (6h4)               | <a href="#">Buy now</a> |
| 15  | <a href="#">66T44514004D</a><br>Mount damper, upper side | <a href="#">Buy now</a> |

## Bracket 3




| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">66T445260000</a><br>Plate                         | <a href="#">Buy now</a> |
| 17  | <a href="#">970750803000</a><br>Bolt, hexagon (fj1)           | <a href="#">Buy now</a> |
| 18  | <a href="#">929950810000</a><br>Ybs67-8 washer, spring        | <a href="#">Buy now</a> |
| 19  | <a href="#">65W44551004D</a><br>Housing, lower mount rubber 1 | <a href="#">Buy now</a> |
| 20  | <a href="#">65W445551000</a><br>Mount damper, lower side      | <a href="#">Buy now</a> |
| 21  | <a href="#">66T445750000</a><br>Damper, lower mount rubber    | <a href="#">Buy now</a> |
| 22  | <a href="#">970751007000</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 23  | <a href="#">929951060000</a><br>Washer, plate                 | <a href="#">Buy now</a> |
| 24  | <a href="#">9011910M0400</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 25  | <a href="#">9017910M3300</a><br>Nut                           | <a href="#">Buy now</a> |

# Carburetor




| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T143010200</a><br>Carburetor assembly 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">66T145780000</a><br>Collar                | <a href="#">Buy now</a> |
| 3   | <a href="#">66T145840000</a><br>Stopper               | <a href="#">Buy now</a> |
| 4   | <a href="#">6J8145920100</a><br>Screw                 | <a href="#">Buy now</a> |
| 5   | <a href="#">929900560000</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 6   | <a href="#">66T143840100</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 7   | <a href="#">66T145360100</a><br>Gasket                | <a href="#">Buy now</a> |
| 8   | <a href="#">66T145270000</a><br>Plate                 | <a href="#">Buy now</a> |
| 9   | <a href="#">979800411200</a><br>Screw, pan head (686) | <a href="#">Buy now</a> |
| 10  | <a href="#">66T145230000</a><br>Screw, stop           | <a href="#">Buy now</a> |
| 11  | <a href="#">6J8143340000</a><br>Spring, throttle      | <a href="#">Buy now</a> |
| 12  | <a href="#">6E5143230300</a><br>Screw, air adjusting  | <a href="#">Buy now</a> |
| 13  | <a href="#">6E5142230000</a><br>Spring, air adjusting | <a href="#">Buy now</a> |
| 14  | <a href="#">66T149450200</a><br>Spacer assembly (#38) | <a href="#">Buy now</a> |
| 15  | <a href="#">61A1492E8500</a><br>Jet, main (#170)      | <a href="#">Buy now</a> |

Carburetor



| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">6E5145460000</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 17  | <a href="#">6E5141590000</a><br>Clip                  | <a href="#">Buy now</a> |
| 18  | <a href="#">6E5143850200</a><br>Float                 | <a href="#">Buy now</a> |
| 19  | <a href="#">6E5143860200</a><br>Pin, float            | <a href="#">Buy now</a> |
| 20  | <a href="#">66T1492F3500</a><br>Jet, air slow (#70)   | <a href="#">Buy now</a> |
| 21  | <a href="#">66T149840000</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 22  | <a href="#">66T149920000</a><br>Plug                  | <a href="#">Buy now</a> |
| 23  | <a href="#">66T149810000</a><br>Body, float chamber   | <a href="#">Buy now</a> |
| 24  | <a href="#">66T149910000</a><br>Plug, drain           | <a href="#">Buy now</a> |
| 25  | <a href="#">66T149590000</a><br>Gasket                | <a href="#">Buy now</a> |
| 26  | <a href="#">979800512500</a><br>Screw, panhead (a93)  | <a href="#">Buy now</a> |


## Control



66T0010-1160

| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66T416380000</a><br>Pulley                   | <a href="#">Buy now</a> |
| 2   | <a href="#">66T421670000</a><br>Spring 1                 | <a href="#">Buy now</a> |
| 3   | <a href="#">9038708M1600</a><br>Collar                   | <a href="#">Buy now</a> |
| 4   | <a href="#">66T416310100</a><br>Lever, magneto control   | <a href="#">Buy now</a> |
| 5   | <a href="#">66T412370000</a><br>Joint, link              | <a href="#">Buy now</a> |
| 6   | <a href="#">9050110M8400</a><br>Spring, compression      | <a href="#">Buy now</a> |
| 7   | <a href="#">978850603500</a><br>Screw, pan head(6h4)     | <a href="#">Buy now</a> |
| 8   | <a href="#">953800670000</a><br>Nut                      | <a href="#">Buy now</a> |
| 9   | <a href="#">688441940000</a><br>Cap                      | <a href="#">Buy now</a> |
| 10  | <a href="#">66T144970000</a><br>Stay, throttle wire      | <a href="#">Buy now</a> |
| 11  | <a href="#">9020108M5400</a><br>Washer, plate (6e5)      | <a href="#">Buy now</a> |
| 12  | <a href="#">970950804500</a><br>Bolt, hexagon            | <a href="#">Buy now</a> |
| 13  | <a href="#">970800601400</a><br>Bolt(gj3)                | <a href="#">Buy now</a> |
| 14  | <a href="#">66T441210000</a><br>Lever, shift rod         | <a href="#">Buy now</a> |
| 15  | <a href="#">66M441220000</a><br>Bushing, shift rod lever | <a href="#">Buy now</a> |


## Control



66T0010-1160

| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">9025403M0500</a><br>Pin, spring       | <a href="#">Buy now</a> |
| 17  | <a href="#">6F5416620000</a><br>Bracket 2         | <a href="#">Buy now</a> |
| 18  | <a href="#">9010906M8100</a><br>Bolt              | <a href="#">Buy now</a> |
| 19  | <a href="#">682441160100</a><br>Spring            | <a href="#">Buy now</a> |
| 20  | <a href="#">9010906M8600</a><br>Bolt              | <a href="#">Buy now</a> |
| 21  | <a href="#">66T441430000</a><br>Rod, shift        | <a href="#">Buy now</a> |
| 22  | <a href="#">914901601200</a><br>Pin, cotter (e57) | <a href="#">Buy now</a> |
| 25  | <a href="#">66T441250100</a><br>Lever, shift rod  | <a href="#">Buy now</a> |
| 26  | <a href="#">9025403M0400</a><br>Pin, spring (6h3) | <a href="#">Buy now</a> |


## Crankshaft & Piston



| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66T114000100</a><br>Crankshaft assembly          | <a href="#">Buy now</a> |
| 2   | <a href="#">66T114120000</a><br>Crank 1                      | <a href="#">Buy now</a> |
| 3   | <a href="#">66T114220000</a><br>Crank 2                      | <a href="#">Buy now</a> |
| 4   | <a href="#">66T114320000</a><br>Crank 3                      | <a href="#">Buy now</a> |
| 5   | <a href="#">66T114420000</a><br>Crank 4                      | <a href="#">Buy now</a> |
| 6   | <a href="#">93306307U000</a><br>Brg,r-b 6307 80mm 449g (6f5) | <a href="#">Buy now</a> |
| 7   | <a href="#">93332000UE00</a><br>Bearing                      | <a href="#">Buy now</a> |
| 8   | <a href="#">93306306V500</a><br>Bearing                      | <a href="#">Buy now</a> |
| 9   | <a href="#">6F5115150000</a><br>Seal, labyrinth 1            | <a href="#">Buy now</a> |
| 10  | <a href="#">6F5116510000</a><br>Rod, connecting              | <a href="#">Buy now</a> |
| 11  | <a href="#">66T116810000</a><br>Pin, crank 1                 | <a href="#">Buy now</a> |
| 12  | <a href="#">9020927M0700</a><br>Washer                       | <a href="#">Buy now</a> |
| 13  | <a href="#">93310727U000</a><br>Bearing                      | <a href="#">Buy now</a> |
| 14  | <a href="#">9344068M0300</a><br>Circlip (6f5)                | <a href="#">Buy now</a> |
| 15  | <a href="#">66T116310093</a><br>Piston (std)                 | <a href="#">Buy now</a> |




## Crankshaft & Piston




| Ref | Part   |                         |
|-----|--|-------------------------|
| 16  | <a href="#">66T116050000</a><br>Piston ring set (0.50mm o/s) | <a href="#">Buy now</a> |
| 17  | <a href="#">6F5116330000</a><br>Pin, piston                  | <a href="#">Buy now</a> |
| 18  | <a href="#">663116340000</a><br>Clip, piston pin             | <a href="#">Buy now</a> |
| 19  | <a href="#">936032111100</a><br>Pin, dowel(663)              | <a href="#">Buy now</a> |
| 20  | <a href="#">902012041700</a><br>Washer, plate(663)           | <a href="#">Buy now</a> |

# Cylinder & Crankcase




| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66TW0090024D</a><br>Crank cylinder assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">66T151000294</a><br>Crankcase assembly      | <a href="#">Buy now</a> |
| 3   | <a href="#">6E5135520000</a><br>Nozzle                  | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5135520100</a><br>Nozzle                  | <a href="#">Buy now</a> |
| 5   | <a href="#">624144850000</a><br>Pipe, joint             | <a href="#">Buy now</a> |
| 6   | <a href="#">936081206300</a><br>Pin, dowel (626)        | <a href="#">Buy now</a> |
| 7   | <a href="#">901191000500</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 8   | <a href="#">66T153960194</a><br>Housing, oil seal       | <a href="#">Buy now</a> |
| 9   | <a href="#">9310230M5600</a><br>Oil seal                | <a href="#">Buy now</a> |
| 10  | <a href="#">931011600100</a><br>Oil seal                | <a href="#">Buy now</a> |
| 11  | <a href="#">9321065M5000</a><br>O-ring                  | <a href="#">Buy now</a> |
| 12  | <a href="#">970950602000</a><br>Bolt(7u8)               | <a href="#">Buy now</a> |
| 13  | <a href="#">929950660000</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 14  | <a href="#">66T115650000</a><br>Washer, bearing cover   | <a href="#">Buy now</a> |
| 15  | <a href="#">676452510000</a><br>Anode                   | <a href="#">Buy now</a> |

# Cylinder & Crankcase




| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">970800602000</a><br>Bolt(7u8)               | <a href="#">Buy now</a> |
| 18  | <a href="#">676113250000</a><br>Anode                   | <a href="#">Buy now</a> |
| 19  | <a href="#">9014106M0000</a><br>Screw, countersunk      | <a href="#">Buy now</a> |
| 20  | <a href="#">66T111190000</a><br>Hanger, engine          | <a href="#">Buy now</a> |
| 21  | <a href="#">901010800200</a><br>Bolt                    | <a href="#">Buy now</a> |
| 22  | <a href="#">66T111110194</a><br>Head, cylinder 1        | <a href="#">Buy now</a> |
| 23  | <a href="#">66T11181A200</a><br>Gasket, cylinder head 1 | <a href="#">Buy now</a> |
| 24  | <a href="#">9011908MA500</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 25  | <a href="#">66T11191009M</a><br>Cover, Cylinder Head 1  | <a href="#">Buy now</a> |
| 26  | <a href="#">66T11193A300</a><br>Gasket, head cover 1    | <a href="#">Buy now</a> |
| 27  | <a href="#">9011906MA300</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 28  | <a href="#">6E5124110100</a><br>Thermostat              | <a href="#">Buy now</a> |
| 29  | <a href="#">67612413009M</a><br>Cover, thermostat       | <a href="#">Buy now</a> |
| 30  | <a href="#">67612414A100</a><br>Gasket, cover           | <a href="#">Buy now</a> |
| 31  | <a href="#">9011906MA500</a><br>Bolt, with washer       | <a href="#">Buy now</a> |

## Cylinder & Crankcase



| Ref | Part  |                         |
|-----|---|-------------------------|
| 32  | <a href="#">66T41113009M</a><br>Outer Cover, Exhaust        | <a href="#">Buy now</a> |
| 33  | <a href="#">676113720000</a><br>Nipple, hose                | <a href="#">Buy now</a> |
| 34  | <a href="#">66T41114A000</a><br>Gasket, exhaust outer cover | <a href="#">Buy now</a> |
| 36  | <a href="#">90445092K100</a><br>Hose (I420)                 | <a href="#">Buy now</a> |
| 37  | <a href="#">9044507M0800</a><br>Hose (I390)                 | <a href="#">Buy now</a> |
| 38  | <a href="#">947020027200</a><br>Plug, spark (br7hs)         | <a href="#">Buy now</a> |



# Electrical 1



| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66T8554B0194</a><br>Bracket                | <a href="#">Buy now</a> |
| 2   | <a href="#">6A0823170000</a><br>Damper, ignition coil  | <a href="#">Buy now</a> |
| 3   | <a href="#">624425420000</a><br>Collar                 | <a href="#">Buy now</a> |
| 4   | <a href="#">9011906M6500</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 5   | <a href="#">66T855400100</a><br>C.d.i. unit assembly   | <a href="#">Buy now</a> |
| 6   | <a href="#">9010906M8100</a><br>Bolt                   | <a href="#">Buy now</a> |
| 7   | <a href="#">9010906M8000</a><br>Bolt                   | <a href="#">Buy now</a> |
| 8   | <a href="#">66T819160100</a><br>Cover, terminal        | <a href="#">Buy now</a> |
| 10  | <a href="#">66T855700000</a><br>Ignition coil assembly | <a href="#">Buy now</a> |
| 11  | <a href="#">904802516100</a><br>Grommet(656)           | <a href="#">Buy now</a> |
| 12  | <a href="#">9044603MA300</a><br>Hose                   | <a href="#">Buy now</a> |
| 14  | <a href="#">970950602500</a><br>Bolt                   | <a href="#">Buy now</a> |
| 15  | <a href="#">929950660000</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 16  | <a href="#">6E3823702100</a><br>Plug cap assembly      | <a href="#">Buy now</a> |
| 17  | <a href="#">970800601200</a><br>Bolt(gh1)              | <a href="#">Buy now</a> |




# Electrical 1



| Ref | Part   |                         |
|-----|--|-------------------------|
| 19  | <a href="#">688825601000</a><br>Thermo switch assembly | <a href="#">Buy now</a> |
| 20  | <a href="#">66T825190000</a><br>Wire, earth lead       | <a href="#">Buy now</a> |
| 21  | <a href="#">6G1427250000</a><br>Grommet                | <a href="#">Buy now</a> |

# Fuel




66T0010-1060

| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">6G1243040200</a><br>Fuel pipe joint comp. 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">970950603000</a><br>Bolt(jf7)               | <a href="#">Buy now</a> |
| 3   | <a href="#">929950660000</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 4   | <a href="#">904450902100</a><br>Hose (l865)             | <a href="#">Buy now</a> |
| 5   | <a href="#">904670800400</a><br>Clip, pipe 6162435600   | <a href="#">Buy now</a> |
| 6   | <a href="#">61N245600000</a><br>Filter assembly         | <a href="#">Buy now</a> |
| 7   | <a href="#">61N245631000</a><br>Element, filter         | <a href="#">Buy now</a> |
| 8   | <a href="#">61N245210000</a><br>Cup, filter             | <a href="#">Buy now</a> |
| 9   | <a href="#">932103273800</a><br>O-ring(1wg)             | <a href="#">Buy now</a> |
| 10  | <a href="#">648245660200</a><br>Bracket, filter         | <a href="#">Buy now</a> |
| 11  | <a href="#">988800810000</a><br>Nut, hex.               | <a href="#">Buy now</a> |
| 12  | <a href="#">970130601400</a><br>Bolt(gj3)               | <a href="#">Buy now</a> |
| 13  | <a href="#">904450908600</a><br>Hose (l1500)            | <a href="#">Buy now</a> |
| 15  | <a href="#">692244100000</a><br>Fuel pump assembly      | <a href="#">Buy now</a> |
| 16  | <a href="#">6A0244130000</a><br>Cover, pump             | <a href="#">Buy now</a> |




# Fuel



66T0010-1060


| Ref | Part  |                         |
|-----|---|-------------------------|
| 17  | <a href="#">692244110000</a><br>Diaphragm               | <a href="#">Buy now</a> |
| 18  | <a href="#">648244340100</a><br>Gasket, body            | <a href="#">Buy now</a> |
| 19  | <a href="#">953800360000</a><br>Nut (6g8)               | <a href="#">Buy now</a> |
| 20  | <a href="#">663244110000</a><br>Diaphragm               | <a href="#">Buy now</a> |
| 21  | <a href="#">648244350200</a><br>Gasket, body 2          | <a href="#">Buy now</a> |
| 22  | <a href="#">985030502800</a><br>Ybs86-530 screw,panhead | <a href="#">Buy now</a> |
| 23  | <a href="#">929900510000</a><br>Ybs67-5 washer, spring  | <a href="#">Buy now</a> |
| 24  | <a href="#">62Y244210100</a><br>Valve, check            | <a href="#">Buy now</a> |
| 25  | <a href="#">6A0143250000</a><br>Screw, pan head         | <a href="#">Buy now</a> |
| 26  | <a href="#">6A0244120200</a><br>Body 1                  | <a href="#">Buy now</a> |
| 27  | <a href="#">65024431A000</a><br>Gasket,fuel pump        | <a href="#">Buy now</a> |
| 28  | <a href="#">970950604000</a><br>Bolt (682)              | <a href="#">Buy now</a> |
| 29  | <a href="#">929900660000</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 32  | <a href="#">676W28100100</a><br>Tool kit                | <a href="#">Buy now</a> |

# Fuel Tank




| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">6YK242010100</a><br>Fuel Tank assembly (25L) | <a href="#">Buy now</a> |
| 2   | <a href="#">6YL242680100</a><br>Gasket, fuel meter       | <a href="#">Buy now</a> |
| 3   | <a href="#">6YK246100000</a><br>Cap assembly             | <a href="#">Buy now</a> |
| 4   | <a href="#">6YL246410000</a><br>Gasket, cap 1            | <a href="#">Buy now</a> |
| 5   | <a href="#">6YK242600100</a><br>Fuel meter assembly      | <a href="#">Buy now</a> |
| 6   | <a href="#">9015705M1600</a><br>Screw, pan head          | <a href="#">Buy now</a> |
| 7   | <a href="#">6YL243290000</a><br>Seal                     | <a href="#">Buy now</a> |
| 8   | <a href="#">6YL243065200</a><br>Fuel pipe comp. 1        | <a href="#">Buy now</a> |

Fuel Tank 2




| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">6YJ242010000</a><br>Fuel tank comp.         | <a href="#">Buy now</a> |
| 2   | <a href="#">6YJ246100100</a><br>Cap assembly            | <a href="#">Buy now</a> |
| 3   | <a href="#">6YJ242600000</a><br>Fuel meter assembly     | <a href="#">Buy now</a> |
| 4   | <a href="#">9015705M1900</a><br>Screw, pan head         | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y1243290000</a><br>Seal                    | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y1242680000</a><br>Gasket, fuel meter      | <a href="#">Buy now</a> |
| 7   | <a href="#">6YJ241670000</a><br>Strainer                | <a href="#">Buy now</a> |
| 8   | <a href="#">61J243060200</a><br>Fuel pipe comp. 1       | <a href="#">Buy now</a> |
| 9   | <a href="#">9044511M8100</a><br>Hose (I3000)            | <a href="#">Buy now</a> |
| 10  | <a href="#">61J243600000</a><br>Primer pump assembly    | <a href="#">Buy now</a> |
| 11  | <a href="#">9044511M0500</a><br>Hose (I1000)            | <a href="#">Buy now</a> |
| 12  | <a href="#">650243515100</a><br>Band 1                  | <a href="#">Buy now</a> |
| 13  | <a href="#">6G1243050500</a><br>Fuel pipe joint comp. 2 | <a href="#">Buy now</a> |
| 14  | <a href="#">932100828700</a><br>O-ring (655)            | <a href="#">Buy now</a> |
| 15  | <a href="#">6Y1243050400</a><br>Fuel pipe joint comp. 2 | <a href="#">Buy now</a> |

# Generator




| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66T855501000</a><br>Rotor assembly             | <a href="#">Buy now</a> |
| 2   | <a href="#">66T855600100</a><br>Base assembly              | <a href="#">Buy now</a> |
| 3   | <a href="#">66T855610000</a><br>Base, magneto              | <a href="#">Buy now</a> |
| 4   | <a href="#">931023500800</a><br>Oil seal                   | <a href="#">Buy now</a> |
| 5   | <a href="#">66T855800000</a><br>Pulser coil assembly       | <a href="#">Buy now</a> |
| 6   | <a href="#">66T855960000</a><br>Coil, pulser 1             | <a href="#">Buy now</a> |
| 7   | <a href="#">66T855820000</a><br>Attachment, pulser         | <a href="#">Buy now</a> |
| 8   | <a href="#">66T855150000</a><br>Lead wire assembly         | <a href="#">Buy now</a> |
| 9   | <a href="#">979020410800</a><br>Screw, with washer         | <a href="#">Buy now</a> |
| 10  | <a href="#">66T855200000</a><br>Coil, charge               | <a href="#">Buy now</a> |
| 11  | <a href="#">66T416110000</a><br>Retainer, magneto base     | <a href="#">Buy now</a> |
| 12  | <a href="#">9E4710430500</a><br>Housing, connector (f-4-b) | <a href="#">Buy now</a> |
| 13  | <a href="#">66T813280000</a><br>Clamp                      | <a href="#">Buy now</a> |
| 14  | <a href="#">66T855330000</a><br>Coil, lighting             | <a href="#">Buy now</a> |
| 15  | <a href="#">985170602500</a><br>Screw, pan head (76t)      | <a href="#">Buy now</a> |

# Generator




| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">978020400600</a><br>Screw, pan head(3xp)      | <a href="#">Buy now</a> |
| 17  | <a href="#">9321075M5100</a><br>O-ring (6f5)              | <a href="#">Buy now</a> |
| 18  | <a href="#">970950604000</a><br>Bolt (682)                | <a href="#">Buy now</a> |
| 19  | <a href="#">929950660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 20  | <a href="#">902800504900</a><br>Key, woodruff (12r)       | <a href="#">Buy now</a> |
| 21  | <a href="#">901702013700</a><br>Nut, hexagon(663)         | <a href="#">Buy now</a> |
| 22  | <a href="#">9020121M1800</a><br>Washer, plate (663)       | <a href="#">Buy now</a> |
| 23  | <a href="#">9046515M7400</a><br>Clamp                     | <a href="#">Buy now</a> |
| 24  | <a href="#">970950601600</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 26  | <a href="#">9048010M7100</a><br>Grommet                   | <a href="#">Buy now</a> |

# Intake



| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T136100000</a><br>Reed valve assembly       | <a href="#">Buy now</a> |
| 2   | <a href="#">66TW00040000</a><br>Reed set                  | <a href="#">Buy now</a> |
| 4   | <a href="#">6E5135520000</a><br>Nozzle                    | <a href="#">Buy now</a> |
| 5   | <a href="#">650113720000</a><br>Nipple, hose              | <a href="#">Buy now</a> |
| 6   | <a href="#">970130603500</a><br>Bolt(3rv)                 | <a href="#">Buy now</a> |
| 7   | <a href="#">929900660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 8   | <a href="#">9044507M2400</a><br>Hose (I390)               | <a href="#">Buy now</a> |
| 9   | <a href="#">9044507MA400</a><br>Hose (I390)               | <a href="#">Buy now</a> |
| 10  | <a href="#">904670601600</a><br>Clip (655)                | <a href="#">Buy now</a> |
| 11  | <a href="#">9321046M1600</a><br>O-ring (688)              | <a href="#">Buy now</a> |
| 12  | <a href="#">9011908M0300</a><br>Bolt (689)                | <a href="#">Buy now</a> |
| 13  | <a href="#">66T144401000</a><br>Silencer assembly, intake | <a href="#">Buy now</a> |
| 14  | <a href="#">9321054M5400</a><br>O-ring (6g1)              | <a href="#">Buy now</a> |
| 15  | <a href="#">978850604000</a><br>Screw pan head            | <a href="#">Buy now</a> |
| 16  | <a href="#">929950660000</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |


# Intake



| Ref | Part   |                         |
|-----|--|-------------------------|
| 17  | <a href="#">9038706M8000</a><br>Collar             | <a href="#">Buy now</a> |
| 18  | <a href="#">6H4412710200</a><br>Knob, choke        | <a href="#">Buy now</a> |
| 19  | <a href="#">689412730000</a><br>Grommet            | <a href="#">Buy now</a> |
| 20  | <a href="#">6J8412740000</a><br>Grommet 2          | <a href="#">Buy now</a> |
| 21  | <a href="#">66T412560000</a><br>Rod, choke 1       | <a href="#">Buy now</a> |
| 22  | <a href="#">661412620200</a><br>Joint, choke lever | <a href="#">Buy now</a> |
| 23  | <a href="#">66T412520000</a><br>Lever, choke 1     | <a href="#">Buy now</a> |
| 24  | <a href="#">916904003200</a><br>Pin, spring (6f5)  | <a href="#">Buy now</a> |
| 25  | <a href="#">66T412570000</a><br>Rod, choke 2       | <a href="#">Buy now</a> |




## Lower Casing & Drive 1




| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T45300014D</a><br>Lower unit assembly         | <a href="#">Buy now</a> |
| 2   | <a href="#">66T45311014D</a><br>Casing, lower               | <a href="#">Buy now</a> |
| 3   | <a href="#">6H4455360000</a><br>Sleeve, drive shaft         | <a href="#">Buy now</a> |
| 4   | <a href="#">903400800200</a><br>Plug, straight screw        | <a href="#">Buy now</a> |
| 5   | <a href="#">904300802000</a><br>Gasket                      | <a href="#">Buy now</a> |
| 6   | <a href="#">688453410000</a><br>Plug, drain                 | <a href="#">Buy now</a> |
| 7   | <a href="#">63D452140000</a><br>Cover, water inlet          | <a href="#">Buy now</a> |
| 8   | <a href="#">63D452150000</a><br>Cover, water inlet          | <a href="#">Buy now</a> |
| 9   | <a href="#">901520501000</a><br>Screw, countersunk          | <a href="#">Buy now</a> |
| 10  | <a href="#">953800560000</a><br>Nut, hexagon (663)          | <a href="#">Buy now</a> |
| 11  | <a href="#">933153222400</a><br>Brg,cyl-cal roller 42.2g nk | <a href="#">Buy now</a> |
| 12  | <a href="#">66T443110000</a><br>Housing, water pump         | <a href="#">Buy now</a> |
| 13  | <a href="#">63D443220000</a><br>Insert, cartridge           | <a href="#">Buy now</a> |
| 14  | <a href="#">66T443234000</a><br>Outer plate, cartridge      | <a href="#">Buy now</a> |
| 15  | <a href="#">9321059MG700</a><br>O-ring                      | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">63D443160000</a><br>Gasket, water pump      | <a href="#">Buy now</a> |
| 17  | <a href="#">9028003M0300</a><br>Key, woodruff (697)     | <a href="#">Buy now</a> |
| 18  | <a href="#">6H4443520200</a><br>Impeller                | <a href="#">Buy now</a> |
| 19  | <a href="#">999990391600</a><br>Housing, water pump set | <a href="#">Buy now</a> |
| 20  | <a href="#">9310122M6000</a><br>Oil seal                | <a href="#">Buy now</a> |
| 21  | <a href="#">66T453440100</a><br>Cover, oil seal         | <a href="#">Buy now</a> |
| 22  | <a href="#">9321048MG800</a><br>O-ring                  | <a href="#">Buy now</a> |
| 23  | <a href="#">9020127M0000</a><br>Washer, plate(62x)      | <a href="#">Buy now</a> |
| 24  | <a href="#">936040806200</a><br>Pin,dowel (626)         | <a href="#">Buy now</a> |
| 25  | <a href="#">9011908M1500</a><br>Bolt, with washer(62w)  | <a href="#">Buy now</a> |
| 26  | <a href="#">66T441500100</a><br>Shift cam assembly      | <a href="#">Buy now</a> |
| 27  | <a href="#">61N441460000</a><br>Connector, shift rod    | <a href="#">Buy now</a> |
| 28  | <a href="#">953800670000</a><br>Nut                     | <a href="#">Buy now</a> |
| 29  | <a href="#">66T453210000</a><br>Plate                   | <a href="#">Buy now</a> |
| 30  | <a href="#">9321033MG400</a><br>O-ring                  | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part   |                         |
|-----|--|-------------------------|
| 31  | <a href="#">9321006ME600</a><br>O-ring                     | <a href="#">Buy now</a> |
| 32  | <a href="#">929900660000</a><br>Washer, plain (646)        | <a href="#">Buy now</a> |
| 33  | <a href="#">66T455010100</a><br>Drive shaft comp.          | <a href="#">Buy now</a> |
| 34  | <a href="#">933320000100</a><br>Brg, tapered roller (409)  | <a href="#">Buy now</a> |
| 35  | <a href="#">663455870130</a><br>Shim (t:0,30mm)            | <a href="#">Buy now</a> |
| 36  | <a href="#">66T455510000</a><br>Pinion                     | <a href="#">Buy now</a> |
| 37  | <a href="#">901701213800</a><br>Nut hexagon(663)           | <a href="#">Buy now</a> |
| 38  | <a href="#">66T455600100</a><br>Gear                       | <a href="#">Buy now</a> |
| 39  | <a href="#">933320000300</a><br>Brg,cyl-cal roller 318g ky | <a href="#">Buy now</a> |
| 40  | <a href="#">663455676000</a><br>Shim (t:0.50mm)            | <a href="#">Buy now</a> |
| 41  | <a href="#">66T455710000</a><br>Gear                       | <a href="#">Buy now</a> |
| 42  | <a href="#">902012242900</a><br>Washer, plate(663)         | <a href="#">Buy now</a> |
| 43  | <a href="#">63D455776000</a><br>Shim (t:0.50mm)            | <a href="#">Buy now</a> |
| 44  | <a href="#">63D45361024D</a><br>Cap, lower casing          | <a href="#">Buy now</a> |
| 45  | <a href="#">93306001U100</a><br>Bearing(62x)               | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part  |                         |
|-----|---|-------------------------|
| 46  | <a href="#">9321069MG600</a><br>O-ring                      | <a href="#">Buy now</a> |
| 47  | <a href="#">932107477500</a><br>O-ring (xea)                | <a href="#">Buy now</a> |
| 48  | <a href="#">933172220400</a><br>Brg,cyl-cal roller 25.5g nt | <a href="#">Buy now</a> |
| 49  | <a href="#">9310122M0000</a><br>Oil seal (22x36x6-663)      | <a href="#">Buy now</a> |
| 50  | <a href="#">9010508M6100</a><br>Bolt, washer based(62x)     | <a href="#">Buy now</a> |
| 51  | <a href="#">66T456310000</a><br>Clutch, dog                 | <a href="#">Buy now</a> |
| 52  | <a href="#">9050115M0100</a><br>Spring, compression         | <a href="#">Buy now</a> |
| 53  | <a href="#">902500602300</a><br>Pin, strait (663)           | <a href="#">Buy now</a> |
| 54  | <a href="#">663456330000</a><br>Ring, cross pin             | <a href="#">Buy now</a> |
| 55  | <a href="#">66T456350000</a><br>Plunger, shift              | <a href="#">Buy now</a> |
| 56  | <a href="#">66T456110000</a><br>Shaft, propeller            | <a href="#">Buy now</a> |

## Lower Casing & Drive 2



| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T443610000</a><br>Tube, water               | <a href="#">Buy now</a> |
| 2   | <a href="#">902021206000</a><br>Washer, plate(663)        | <a href="#">Buy now</a> |
| 3   | <a href="#">904301207200</a><br>Gasket                    | <a href="#">Buy now</a> |
| 4   | <a href="#">663443670000</a><br>Damper, water seal 3      | <a href="#">Buy now</a> |
| 5   | <a href="#">9011908M4400</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 6   | <a href="#">663453760000</a><br>Guide, seal damper        | <a href="#">Buy now</a> |
| 7   | <a href="#">63D453750000</a><br>Damper, seal              | <a href="#">Buy now</a> |
| 8   | <a href="#">664453710100</a><br>Tab-trim                  | <a href="#">Buy now</a> |
| 9   | <a href="#">970950802500</a><br>Bolt (62g)                | <a href="#">Buy now</a> |
| 10  | <a href="#">929900810000</a><br>Ybs67-8 washer, spring    | <a href="#">Buy now</a> |
| 11  | <a href="#">936061201900</a><br>Pin, dowel (614)          | <a href="#">Buy now</a> |
| 12  | <a href="#">970751004000</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 13  | <a href="#">929951010000</a><br>Ybs67-10 washer, spring   | <a href="#">Buy now</a> |
| 14  | <a href="#">929901060000</a><br>Washer, plate             | <a href="#">Buy now</a> |
| 15  | <a href="#">67C452510000</a><br>Anode                     | <a href="#">Buy now</a> |


## Lower Casing & Drive 2



| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">970950803500</a><br>Bolt(70w)                   | <a href="#">Buy now</a> |
| 17  | <a href="#">929950810000</a><br>Ybs67-8 washer, spring      | <a href="#">Buy now</a> |
| 18  | <a href="#">663443660000</a><br>Damper, water seal 2        | <a href="#">Buy now</a> |
| 19  | <a href="#">63D443120000</a><br>Cover, water pump housing   | <a href="#">Buy now</a> |
| 20  | <a href="#">663459870200</a><br>Spacer                      | <a href="#">Buy now</a> |
| 21  | <a href="#">66T459970000</a><br>Spacer 2                    | <a href="#">Buy now</a> |
| 22  | <a href="#">9038922M0100</a><br>Bush                        | <a href="#">Buy now</a> |
| 23  | <a href="#">901711601100</a><br>Nut, castle (663)           | <a href="#">Buy now</a> |
| 24  | <a href="#">914903002500</a><br>Pin cotter                  | <a href="#">Buy now</a> |
| 25  | <a href="#">663459760098</a><br>Propeller (3x10-1/4"x15"-g) | <a href="#">Buy now</a> |
| 26  | <a href="#">66T443621000</a><br>Tube, water 2               | <a href="#">Buy now</a> |
| 27  | <a href="#">9048025M7000</a><br>Grommet                     | <a href="#">Buy now</a> |
| 28  | <a href="#">9048030M7100</a><br>Grommet                     | <a href="#">Buy now</a> |



## Remo Con Attachment




66T0010-1170

| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T485010100</a><br>Remote cont. attachment assembly. | <a href="#">Buy now</a> |
| 2   | <a href="#">663483440000</a><br>Cable end, remote control         | <a href="#">Buy now</a> |
| 3   | <a href="#">904681800800</a><br>Clip 620436610000                 | <a href="#">Buy now</a> |
| 4   | <a href="#">6H3485380000</a><br>Clamp, cable                      | <a href="#">Buy now</a> |
| 5   | <a href="#">9025403M0400</a><br>Pin, spring (6h3)                 | <a href="#">Buy now</a> |
| 6   | <a href="#">66T441250100</a><br>Lever, shift rod                  | <a href="#">Buy now</a> |
| 7   | <a href="#">65W485110100</a><br>Hook, steering                    | <a href="#">Buy now</a> |
| 8   | <a href="#">902011012000</a><br>Washer, plate                     | <a href="#">Buy now</a> |
| 9   | <a href="#">66T427253000</a><br>Grommet                           | <a href="#">Buy now</a> |
| 10  | <a href="#">65W263261000</a><br>Grommet                           | <a href="#">Buy now</a> |
| 11  | <a href="#">65W427261000</a><br>Grommet                           | <a href="#">Buy now</a> |




# Repair Kit 1




| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66TW00010100</a><br>Power head gasket kit       | <a href="#">Buy now</a> |
| 2   | <a href="#">9310230M5600</a><br>Oil seal                    | <a href="#">Buy now</a> |
| 3   | <a href="#">931011600100</a><br>Oil seal                    | <a href="#">Buy now</a> |
| 4   | <a href="#">9321065M5000</a><br>O-ring                      | <a href="#">Buy now</a> |
| 5   | <a href="#">66T11181A200</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 6   | <a href="#">66T11193A300</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 7   | <a href="#">67612414A000</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 8   | <a href="#">66T41114A000</a><br>Gasket, exhaust outer cover | <a href="#">Buy now</a> |
| 9   | <a href="#">9321046M1600</a><br>O-ring (688)                | <a href="#">Buy now</a> |
| 10  | <a href="#">9321054M5400</a><br>O-ring (6g1)                | <a href="#">Buy now</a> |
| 11  | <a href="#">932103273800</a><br>O-ring(1wg)                 | <a href="#">Buy now</a> |
| 12  | <a href="#">65024431A000</a><br>Gasket,fuel pump            | <a href="#">Buy now</a> |
| 13  | <a href="#">66T45113A000</a><br>Gasket, upper casing        | <a href="#">Buy now</a> |
| 14  | <a href="#">931023500800</a><br>Oil seal                    | <a href="#">Buy now</a> |
| 15  | <a href="#">9321075M5100</a><br>O-ring (6f5)                | <a href="#">Buy now</a> |

# Repair Kit 1




| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">66TW00930100</a><br>Carburetor repair kit | <a href="#">Buy now</a> |
| 19  | <a href="#">66T143840100</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 20  | <a href="#">66T145360000</a><br>Gasket                | <a href="#">Buy now</a> |
| 21  | <a href="#">6E5143230300</a><br>Screw, air adjusting  | <a href="#">Buy now</a> |
| 22  | <a href="#">6E5145460000</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 23  | <a href="#">6E5143850200</a><br>Float                 | <a href="#">Buy now</a> |
| 24  | <a href="#">6E5143860200</a><br>Pin, float            | <a href="#">Buy now</a> |
| 25  | <a href="#">66T149840000</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 26  | <a href="#">66T149920000</a><br>Plug                  | <a href="#">Buy now</a> |
| 27  | <a href="#">66T149590000</a><br>Gasket                | <a href="#">Buy now</a> |
| 28  | <a href="#">979800512500</a><br>Screw, panhead (a93)  | <a href="#">Buy now</a> |

## Repair Kit 2




| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66TW00012000</a><br>Lower unit gasket kit      | <a href="#">Buy now</a> |
| 2   | <a href="#">66T41133A000</a><br>Gasket, exhaust manifold 1 | <a href="#">Buy now</a> |
| 3   | <a href="#">66T45114A000</a><br>Gasket, upper casing       | <a href="#">Buy now</a> |
| 4   | <a href="#">904300802000</a><br>Gasket                     | <a href="#">Buy now</a> |
| 5   | <a href="#">9321059MG700</a><br>O-ring                     | <a href="#">Buy now</a> |
| 6   | <a href="#">63D443160000</a><br>Gasket, water pump         | <a href="#">Buy now</a> |
| 7   | <a href="#">9310122M6000</a><br>Oil seal                   | <a href="#">Buy now</a> |
| 8   | <a href="#">9321048MG800</a><br>O-ring                     | <a href="#">Buy now</a> |
| 9   | <a href="#">9321033MG400</a><br>O-ring                     | <a href="#">Buy now</a> |
| 10  | <a href="#">9321006ME600</a><br>O-ring                     | <a href="#">Buy now</a> |
| 11  | <a href="#">9321069MG600</a><br>O-ring                     | <a href="#">Buy now</a> |
| 12  | <a href="#">9321074MG500</a><br>O-ring (sea)               | <a href="#">Buy now</a> |
| 13  | <a href="#">931012206700</a><br>Oil seal (22x36x6-663)     | <a href="#">Buy now</a> |
| 14  | <a href="#">66TW00780000</a><br>Water pump repair kit      | <a href="#">Buy now</a> |
| 15  | <a href="#">63D443220000</a><br>Insert, cartridge          | <a href="#">Buy now</a> |

## Repair Kit 2



| Ref | Part  |                         |
|-----|---|-------------------------|
| 16  | <a href="#">66T443230000</a><br>Outer plate, cartridge    | <a href="#">Buy now</a> |
| 19  | <a href="#">9028003M0300</a><br>Key, woodruff (697)       | <a href="#">Buy now</a> |
| 20  | <a href="#">6H4443520200</a><br>Impeller                  | <a href="#">Buy now</a> |
| 21  | <a href="#">9011908M1500</a><br>Bolt, with washer(62w)    | <a href="#">Buy now</a> |
| 22  | <a href="#">663443660000</a><br>Damper, water seal 2      | <a href="#">Buy now</a> |
| 23  | <a href="#">63D443120000</a><br>Cover, water pump housing | <a href="#">Buy now</a> |
| 24  | <a href="#">66TW00780A00</a><br>Chrome pump kit           | <a href="#">Buy now</a> |
| 25  | <a href="#">63D443224000</a><br>Insert, cartridge         | <a href="#">Buy now</a> |
| 26  | <a href="#">66T443234000</a><br>Outer plate, cartridge    | <a href="#">Buy now</a> |


## Repair Kit 3



  
66T0010-8270

| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66T813030000</a><br>Lighting coil assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">66T855330000</a><br>Coil, lighting         | <a href="#">Buy now</a> |
| 3   | <a href="#">979020612500</a><br>Screw, pan head (76t)  | <a href="#">Buy now</a> |
| 4   | <a href="#">978020400600</a><br>Screw, pan head(3xp)   | <a href="#">Buy now</a> |


# Starter



| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T157100000</a><br>Starter assembly          | <a href="#">Buy now</a> |
| 2   | <a href="#">66T157110000</a><br>Case, starter             | <a href="#">Buy now</a> |
| 3   | <a href="#">66T157140000</a><br>Drum, sheave              | <a href="#">Buy now</a> |
| 4   | <a href="#">63V157410000</a><br>Pawl, drive               | <a href="#">Buy now</a> |
| 5   | <a href="#">66T157130000</a><br>Spring, starter           | <a href="#">Buy now</a> |
| 6   | <a href="#">66T157160000</a><br>Plate, drive              | <a href="#">Buy now</a> |
| 7   | <a href="#">66T157050000</a><br>Spring, drive pawl        | <a href="#">Buy now</a> |
| 8   | <a href="#">66T157670000</a><br>Spring                    | <a href="#">Buy now</a> |
| 9   | <a href="#">66T157840000</a><br>Spring, return            | <a href="#">Buy now</a> |
| 10  | <a href="#">63V157440000</a><br>Circlip                   | <a href="#">Buy now</a> |
| 11  | <a href="#">68T157930000</a><br>Screw                     | <a href="#">Buy now</a> |
| 13  | <a href="#">66T157940000</a><br>Stopper                   | <a href="#">Buy now</a> |
| 14  | <a href="#">66T157340000</a><br>Spring, return            | <a href="#">Buy now</a> |
| 15  | <a href="#">66T157700000</a><br>Cable comp., starter stop | <a href="#">Buy now</a> |
| 16  | <a href="#">66T157310000</a><br>Retainer, spring          | <a href="#">Buy now</a> |




# Starter




| Ref | Part  |                         |
|-----|---|-------------------------|
| 17  | <a href="#">6F5157910000</a><br>Washer, lock        | <a href="#">Buy now</a> |
| 18  | <a href="#">6F5157520000</a><br>Roller, wire        | <a href="#">Buy now</a> |
| 19  | <a href="#">6F5157530000</a><br>Bushing 1           | <a href="#">Buy now</a> |
| 20  | <a href="#">6F5157680000</a><br>Bolt                | <a href="#">Buy now</a> |
| 21  | <a href="#">689157550100</a><br>Handle, starter     | <a href="#">Buy now</a> |
| 22  | <a href="#">6F5157790200</a><br>Cover               | <a href="#">Buy now</a> |
| 23  | <a href="#">697157890000</a><br>Damper              | <a href="#">Buy now</a> |
| 24  | <a href="#">66T157580100</a><br>Guide, rope         | <a href="#">Buy now</a> |
| 25  | <a href="#">970800603500</a><br>Bolt(j52)           | <a href="#">Buy now</a> |
| 26  | <a href="#">929950660000</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 27  | <a href="#">9038706M6600</a><br>Collar (6h4)        | <a href="#">Buy now</a> |
| 28  | <a href="#">66T157620100</a><br>Seal, rubber 2      | <a href="#">Buy now</a> |
| 29  | <a href="#">66T157230000</a><br>Pulley, starter     | <a href="#">Buy now</a> |
| 30  | <a href="#">970850601000</a><br>Bolt                | <a href="#">Buy now</a> |
| 32  | <a href="#">9011908M1000</a><br>Bolt, with washer   | <a href="#">Buy now</a> |

# Starter




| Ref | Part  |                         |
|-----|---|-------------------------|
| 33  | <a href="#">9011908M5100</a><br>Bolt, with washer   | <a href="#">Buy now</a> |
| 34  | <a href="#">9038512M0400</a><br>Bushing (6f5)       | <a href="#">Buy now</a> |
| 35  | <a href="#">9038708M0500</a><br>Collar (663)        | <a href="#">Buy now</a> |
| 36  | <a href="#">66T157710094</a><br>Stay 1              | <a href="#">Buy now</a> |
| 37  | <a href="#">970130603000</a><br>Bolt                | <a href="#">Buy now</a> |
| 38  | <a href="#">929900660000</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 39  | <a href="#">66T157720094</a><br>Stay 2              | <a href="#">Buy now</a> |
| 41  | <a href="#">929030660000</a><br>Washer, plain (646) | <a href="#">Buy now</a> |

# Steering




| Ref | Part   |                         |
|-----|--|-------------------------|
| 1   | <a href="#">66TW0084024D</a><br>Handle steering assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">66T441110200</a><br>Handle, gear shift       | <a href="#">Buy now</a> |
| 3   | <a href="#">9038706M8600</a><br>Collar                   | <a href="#">Buy now</a> |
| 4   | <a href="#">970950605000</a><br>Bolt(jf7)                | <a href="#">Buy now</a> |
| 5   | <a href="#">929900660000</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 6   | <a href="#">9020112M0700</a><br>Washer, plate            | <a href="#">Buy now</a> |
| 7   | <a href="#">902061205200</a><br>Washer, wave (666)       | <a href="#">Buy now</a> |
| 8   | <a href="#">66T421230000</a><br>Bolt, handle joint       | <a href="#">Buy now</a> |
| 9   | <a href="#">957800630000</a><br>Nut, nylon (6g1)         | <a href="#">Buy now</a> |
| 10  | <a href="#">929950620000</a><br>Ybs66-6 washer, plain    | <a href="#">Buy now</a> |
| 11  | <a href="#">66T441240000</a><br>Link, shift rod          | <a href="#">Buy now</a> |
| 12  | <a href="#">929900620000</a><br>Ybs66-6 washer, plain    | <a href="#">Buy now</a> |
| 13  | <a href="#">904681800800</a><br>Clip 620436610000        | <a href="#">Buy now</a> |
| 14  | <a href="#">6E0441911100</a><br>Indicator, shift         | <a href="#">Buy now</a> |
| 15  | <a href="#">65W42101014D</a><br>Handle, steering         | <a href="#">Buy now</a> |

# Steering



| Ref | Part   |                         |
|-----|--|-------------------------|
| 16  | <a href="#">9010906M8600</a><br>Bolt                     | <a href="#">Buy now</a> |
| 17  | <a href="#">65W421380000</a><br>Lever, throttle          | <a href="#">Buy now</a> |
| 18  | <a href="#">65W421590000</a><br>Stay                     | <a href="#">Buy now</a> |
| 19  | <a href="#">6G1421260000</a><br>Piece, friction          | <a href="#">Buy now</a> |
| 20  | <a href="#">65W421250000</a><br>Bolt, friction adjusting | <a href="#">Buy now</a> |
| 21  | <a href="#">914902001000</a><br>Pin, cotter              | <a href="#">Buy now</a> |
| 22  | <a href="#">6F642177A000</a><br>Rubber, handle           | <a href="#">Buy now</a> |
| 23  | <a href="#">664421190000</a><br>Grip, steering handle    | <a href="#">Buy now</a> |
| 24  | <a href="#">6G1421371000</a><br>Indicator, throttle      | <a href="#">Buy now</a> |
| 25  | <a href="#">9026902M0900</a><br>Rivet(6I5)               | <a href="#">Buy now</a> |
| 26  | <a href="#">9014905M1300</a><br>Screw, countersunk       | <a href="#">Buy now</a> |
| 27  | <a href="#">929031060000</a><br>Washer, plate            | <a href="#">Buy now</a> |
| 28  | <a href="#">905012321500</a><br>Spring (655)             | <a href="#">Buy now</a> |
| 29  | <a href="#">903860803200</a><br>Bushing (650)            | <a href="#">Buy now</a> |
| 30  | <a href="#">66T263010000</a><br>Throttle cable assembly  | <a href="#">Buy now</a> |


# Steering



| Ref | Part  |                         |
|-----|---|-------------------------|
| 31  | <a href="#">9044610M8700</a><br>Hose                        | <a href="#">Buy now</a> |
| 32  | <a href="#">9044610M8600</a><br>Hose                        | <a href="#">Buy now</a> |
| 33  | <a href="#">66R421710000</a><br>Bushing                     | <a href="#">Buy now</a> |
| 34  | <a href="#">9020143M0000</a><br>Washer, plate               | <a href="#">Buy now</a> |
| 35  | <a href="#">9020643M2200</a><br>Washer, wave                | <a href="#">Buy now</a> |
| 36  | <a href="#">9020243M5700</a><br>Washer, plate               | <a href="#">Buy now</a> |
| 37  | <a href="#">9038640M9900</a><br>Bush                        | <a href="#">Buy now</a> |
| 38  | <a href="#">65W421310100</a><br>Cover, handle steering      | <a href="#">Buy now</a> |
| 39  | <a href="#">953801070000</a><br>Nut (682)                   | <a href="#">Buy now</a> |
| 40  | <a href="#">957801030000</a><br>Nut, nylon (6e5)            | <a href="#">Buy now</a> |
| 41  | <a href="#">65W42121014D</a><br>Bracket                     | <a href="#">Buy now</a> |
| 42  | <a href="#">66T412730000</a><br>Grommet                     | <a href="#">Buy now</a> |
| 43  | <a href="#">66T825750100</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 44  | <a href="#">682825560000</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 45  | <a href="#">6898257Y0000</a><br>Cap                         | <a href="#">Buy now</a> |




## Top Cowling



| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T42610114D</a><br>Top cowling assembly          | <a href="#">Buy now</a> |
| 2   | <a href="#">66T426130100</a><br>Molding, air duct             | <a href="#">Buy now</a> |
| 3   | <a href="#">977805061600</a><br>Screw, pan head tapping (ak5) | <a href="#">Buy now</a> |
| 4   | <a href="#">6E0426510200</a><br>Hook                          | <a href="#">Buy now</a> |
| 5   | <a href="#">9026604M0400</a><br>Rivet(6e7)                    | <a href="#">Buy now</a> |
| 6   | <a href="#">6F5426520100</a><br>Hook                          | <a href="#">Buy now</a> |
| 7   | <a href="#">9026604M0100</a><br>Rivet (689)                   | <a href="#">Buy now</a> |
| 8   | <a href="#">66T426150200</a><br>Seal                          | <a href="#">Buy now</a> |
| 9   | <a href="#">68842677C000</a><br>Graphic, front                | <a href="#">Buy now</a> |
| 10  | <a href="#">63D426781100</a><br>Graphic, rear                 | <a href="#">Buy now</a> |
| 11  | <a href="#">63DW00701000</a><br>Graphic set                   | <a href="#">Buy now</a> |
| 12  | <a href="#">63D426811000</a><br>Mark, cowling                 | <a href="#">Buy now</a> |
| 13  | <a href="#">63D426821000</a><br>Mark, cowling                 | <a href="#">Buy now</a> |



## Upper Casing



| Ref | Part  |                         |
|-----|---|-------------------------|
| 1   | <a href="#">66T411370094</a><br>Guide, exhaust                | <a href="#">Buy now</a> |
| 2   | <a href="#">9011908M7900</a><br>Bolt, hexagon (fj1)           | <a href="#">Buy now</a> |
| 3   | <a href="#">936061201900</a><br>Pin, dowel (614)              | <a href="#">Buy now</a> |
| 4   | <a href="#">66T41131105B</a><br>Manifold, ext. 1              | <a href="#">Buy now</a> |
| 5   | <a href="#">66T41133A000</a><br>Gasket, exhaust manifold 1    | <a href="#">Buy now</a> |
| 6   | <a href="#">970750803000</a><br>Bolt, hexagon (fj1)           | <a href="#">Buy now</a> |
| 7   | <a href="#">929950860000</a><br>Washer, plain (663)           | <a href="#">Buy now</a> |
| 8   | <a href="#">66T45111104D</a><br>Casing, upper                 | <a href="#">Buy now</a> |
| 9   | <a href="#">63D451550000</a><br>Cap                           | <a href="#">Buy now</a> |
| 10  | <a href="#">975750854500</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 12  | <a href="#">66T45114A000</a><br>Gasket, upper casing          | <a href="#">Buy now</a> |
| 13  | <a href="#">66T45113A000</a><br>Gasket, upper casing          | <a href="#">Buy now</a> |
| 15  | <a href="#">9011908M4200</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 16  | <a href="#">679453180000</a><br>Bushing, drive shaft 3        | <a href="#">Buy now</a> |
| 17  | <a href="#">934203004200</a><br>Circlip (650)                 | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.