



Yamaha F100DET 2005

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

| | |
|-------------------------------------|----|
| BOTTOM COWLING | 3 |
| BRACKET 1 | 7 |
| BRACKET 2 | 10 |
| CONTROL | 13 |
| CRANKSHAFT & PISTON | 16 |
| CYLINDER & CRANKCASE 1 | 18 |
| CYLINDER & CRANKCASE 2 | 21 |
| ELECTRICAL 1 | 24 |
| ELECTRICAL 2 | 26 |
| ELECTRICAL 3 | 28 |
| ELECTRICAL 4 | 30 |
| FUEL 1 | 31 |
| FUEL 2 | 34 |
| FUEL INJECTION PUMP 1 | 35 |
| FUEL INJECTION PUMP 2 | 37 |
| GENERATOR | 39 |
| INTAKE 1 | 41 |
| INTAKE 2 | 43 |
| INTAKE 3 | 45 |
| LOWER CASING & DRIVE 1 | 47 |
| LOWER CASING & DRIVE 2 | 53 |
| METER | 56 |
| OIL PAN | 58 |
| OPTIONAL PARTS 1 | 60 |
| OPTIONAL PARTS 2 | 61 |
| POWER TRIM & TILT ASSY 1 | 62 |
| POWER TRIM & TILT ASSY 2 | 68 |
| REMOTE CONTROL ASSY | 70 |
| REMOTE CONTROL BOX | 75 |
| REPAIR KIT 1 | 76 |
| REPAIR KIT 2 | 77 |
| STARTING MOTOR | 79 |
| STEERING 1 | 82 |
| STEERING 2 | 86 |
| STEERING FRICTION | 90 |
| STEERING GUIDE | 92 |
| TOP COWLING | 93 |
| UPPER CASING | 95 |
| VALVE | 97 |


Bottom Cowling



E3


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D842710004D Bottom cowling assembly | Buy now |
| 2 | 9011908M22 Bolt, with washer | Buy now |
| 3 | 9048022M15 Grommet (6e5) | Buy now |
| 4 | 9038708M37 Coller (6e5) | Buy now |
| 5 | 67F42815004D Lever, clamp | Buy now |
| 6 | 67F42816004D Lever, clamp | Buy now |
| 7 | 67F42828005B Plate, clamp | Buy now |
| 8 | 9010906M82 Bolt | Buy now |
| 9 | 68V4281801 Lever, clamp | Buy now |
| 10 | 9038615M73 Bush(6l2) | Buy now |
| 11 | 9020615M18 Washer, wave(6l2) | Buy now |
| 12 | 9020106068 Washer,plate (6k8) | Buy now |
| 13 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 14 | 64D4314400 Hook, spring | Buy now |
| 34 | 9010906M86 Bolt FLUSHING KIT | Buy now |

Bottom Cowling




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9050616M34 Spring, tension(64d) | Buy now |
| 17 | 67F42738005B Plate, fitting | Buy now |
| 18 | 9010906M96 Bolt | Buy now |
| 19 | 68V4272500 Grommet | Buy now |
| 20 | 6D84275600 Stay, clamp | Buy now |
| 21 | 6D84271700 Rubber, seal 2 | Buy now |
| 23 | 6H14272621 Grommet | Buy now |
| 24 | 69D4439100 Nipple, hose | Buy now |
| 25 | 6H44274800 Grommet | Buy now |
| 26 | 67F4271700 Rubber, seal 2 | Buy now |
| 27 | 6E58258800 Plate | Buy now |
| 28 | 9010906M81 Bolt | Buy now |
| 29 | 9046508M23 Clamp (6h3) | Buy now |
| 31 | 68T1257200 Adapter FLUSHING KIT | Buy now |
| 32 | 67F1253500 Plate FLUSHING KIT | Buy now |

Bottom Cowling



| Ref | Part | |
|-----|---|-------------------------|
| 33 | 9016706002 Screw, tapping FLUSHING KIT | Buy now |
| 35 | 6R31258100 Joint, hose 1 FLUSHING KIT | Buy now |
| 36 | 6R31258200 Joint, hose 2 FLUSHING KIT | Buy now |
| 37 | 6R31258300 Gasket, hose joint FLUSHING KIT | Buy now |
| 38 | 6F2431200 Pipe 2 FLUSHING KIT | Buy now |
| 39 | 9046511M10 Clamp FLUSHING KIT | Buy now |
| 40 | 61A4271600 Rubber seal 1 | Buy now |
| 41 | 67F42741018D Apron | Buy now |
| 42 | 9538006600 Nut(661) | Buy now |
| 43 | 9015906M28 Screw, with washer | Buy now |
| 44 | 9010906M80 Bolt | Buy now |
| 45 | 9048013M24 Grommet (6e9) | Buy now |
| 46 | 9038706M43 Coller (6e9) | Buy now |
| 47 | 68F4275300 Fastner AP | Buy now |
| 48 | 9046420258 Clamp AP | Buy now |


Bottom Cowling



E3


| Ref | Part | |
|-----|--|-------------------------|
| 49 | 67F8237700 Label (sparkplug mark) | Buy now |
| 50 | 6A12817600 Label Caution | Buy now |
| 51 | 6E38257H00 Plate Mark | Buy now |

Bracket 1



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 67F43111004D Bracket, clamp 1 | Buy now |
| 2 | 9046510M77 Clamp | Buy now |
| 3 | 9709506010 Bolt | Buy now |
| 4 | 67F43112004D Bracket, clamp 2 | Buy now |
| 5 | 6E58214800 Wire, lead 5 | Buy now |
| 6 | 9788006012 Screw, pan head(62j) | Buy now |
| 7 | 6D843311004D Bracket, swivel 1 | Buy now |
| 8 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 9 | 9046508M63 Clamp(61u) | Buy now |
| 11 | 67F8212700 Wire, lead 2 | Buy now |
| 12 | 64E4313101 Bolt, clamp bracket | Buy now |
| 13 | 9038625M31 Bushing (6e5) | Buy now |
| 14 | 9020126M59 Washer, plate (6e5) | Buy now |
| 15 | 9018522M11 Nut, self-locking | Buy now |
| 16 | 9709508020 Bolt, hexagon | Buy now |


Bracket 1



F6

| Ref | Part | |
|-----|--|-------------------------|
| 17 | 9299508100 Ybs67-8 washer, spring | Buy now |
| 18 | 6D84318100 Lever, tilt stop 1 | Buy now |
| 19 | 6D84318500 Lever, tilt stop 2 | Buy now |
| 20 | 9038610M16 Bushing (688) | Buy now |
| 21 | 6G54314800 Collar, distance | Buy now |
| 22 | 9169030020 Pin, spring (6h4) | Buy now |
| 23 | 9024906M19 Pin(6e5) | Buy now |
| 24 | 66T4314400 Hook, spring | Buy now |
| 26 | 9050614M24 Spring, tension(6e5) | Buy now |
| 27 | 6D88214800 Wire, lead 4 | Buy now |
| 29 | 9299506600 Washer, plain (646) | Buy now |
| 30 | 6D84312600 Pin, upper shock mount | Buy now |
| 31 | 9038618M35 Bush (688) | Buy now |
| 32 | 9038618001 Bush | Buy now |
| 33 | 9341018M05 Circlip (6f2) | Buy now |


Bracket 1



F6


| Ref | Part | |
|-----|---|-------------------------|
| 34 | 67F4381800 Pin, lower shock mount | Buy now |
| 35 | 9038718M01 Collar | Buy now |
| 36 | 9038618MA0 Bush | Buy now |
| 37 | 9038722M01 Collar | Buy now |
| 39 | 6H14525103 Anode | Buy now |
| 40 | 9011906M81 Bolt, with washer | Buy now |
| 41 | 6H14452600 Plate 2 | Buy now |
| 42 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 43 | 9299506100 Washer(6a1) | Buy now |
| 45 | 9010112M03 Bolt (l:115mm) | Buy now |
| 46 | 9020113M01 Washer, plate(6e5) | Buy now |
| 47 | 9020112M05 Washe, plate(663) | Buy now |
| 48 | 9538012600 Nut (707) | Buy now |

Bracket 2



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 64E8367202 Trim sender | Buy now |
| 2 | 9788506016 Screw, pan head(6b0) | Buy now |
| 3 | 7038211900 Cover, lead wire | Buy now |
| 4 | 9046508M63 Clamp(61u) | Buy now |
| 5 | 64E4313902 Cam, trim sender (with screw) | Buy now |
| 6 | 9778060525 Screw, tapping(65j) | Buy now |
| 7 | 9046511M10 Clamp | Buy now |
| 9 | 67F42510114D Steering bracket assembly | Buy now |
| 10 | 9020130M00 Washer, plate(6h1) | Buy now |
| 11 | 9038630M78 Bush(6h0) | Buy now |
| 12 | 9321029M94 O-ring(6h1) | Buy now |
| 13 | 9038630M77 Bush(6h0) | Buy now |
| 14 | 9038630M60 Bush(6j8) | Buy now |
| 15 | 67F44551004D Housing, lower mount rubber | Buy now |
| 16 | 9341028M06 Circlip (688) | Buy now |


Bracket 2



A4


| Ref | Part | |
|-----|---|-------------------------|
| 17 | 67F445140094 Mount damper, upper side | Buy now |
| 18 | 9757508445 Bolt, hexagon w/w deep recess | Buy now |
| 19 | 9010912007 Bolt | Buy now |
| 20 | 67F4452600 Plate | Buy now |
| 21 | 9020112M16 Washer, plate (679) | Buy now |
| 22 | 9020113M01 Washer, plate(6e5) | Buy now |
| 23 | 67F4453300 Damper, upper mount rubber | Buy now |
| 24 | 9578012300 Nut, nylon (6f2) | Buy now |
| 25 | 67F445550094 Mount damper, lower side | Buy now |
| 26 | 9020113M03 Washer, plate (688) | Buy now |
| 27 | 9010912006 Bolt UR | Buy now |
| 27 | 9010912012 Bolt UR 6D9)1001305- | Buy now |
| 29 | 9020124M02 Washer, plate(61x) | Buy now |
| 30 | 9020225M04 Washer, plate (663) | Buy now |
| 31 | 9020113M19 Washer, plate (663) | Buy now |

Bracket 2



A4

| Ref | Part | |
|-----|---|-------------------------|
| 32 | 9538012700 Nut(6t4) UR | Buy now |
| 32 | 9538012800 Nut crown(663) UR 6D9)1001305- | Buy now |
| 33 | 67F4457500 Damper, lower mount rubber | Buy now |
| 34 | 67F44553004D Cover, lower mount | Buy now |
| 35 | 9707510040 Bolt, hexagon deep recess | Buy now |
| 36 | 9299510100 Ybs67-10 washer, spring | Buy now |
| 37 | 67F48511004D Hook, steering | Buy now |
| 38 | 9011610175 Bolt, stud | Buy now |
| 39 | 9018510051 Nut, self-locking | Buy now |




6D81100-D230

F4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 67F4853800 Clamp, cable 1 | Buy now |
| 2 | 9010906M86 Bolt | Buy now |
| 3 | 6634834400 Cable end, remote control | Buy now |
| 4 | 9046818008 Clip 620436610000 | Buy now |
| 5 | 6D84411700 Bracket | Buy now |
| 6 | 9759506550 Bolt, hexagon w/w deep recess | Buy now |
| 7 | 9046210027 Clamp | Buy now |
| 8 | 68V4412201 Bushing, shift rod lever | Buy now |
| 9 | 9020207M07 Washer, plate (688) | Buy now |
| 11 | 67F4412100 Lever, shift rod | Buy now |
| 12 | 9038606M12 Bushing (688) | Buy now |
| 14 | 67F4412010 Handle gear shift assembly L | Buy now |
| 15 | 9038690M90 Bush(61a) | Buy now |
| 16 | 9020109M02 Washer, plate(61a) | Buy now |
| 17 | 9149020015 Pin, cotter (648) | Buy now |


Control



6D81100-D230

F4

| Ref | Part | |
|-----|---|-------------------------|
| 18 | 67F4411800 Bracket | Buy now |
| 19 | 9707506025 Bolt | Buy now |
| 20 | 9299506600 Washer, plain (646) | Buy now |
| 21 | 9350104M02 Ball (697) | Buy now |
| 22 | 9050112082 Spring 6484411600 | Buy now |
| 23 | 6484271500 Bushing 2 | Buy now |
| 26 | 6D84215400 Lever, throttle control | Buy now |
| 27 | 9038706M21 Collar | Buy now |
| 28 | 9020106M31 Washer (6a0) | Buy now |
| 29 | 9020110M02 Washer, plate(6g9) | Buy now |
| 30 | 9020610M04 Washer, wave (676) | Buy now |
| 31 | 67F4413500 Spring | Buy now |
| 32 | 9709506035 Bolt(j52) | Buy now |
| 33 | 9299506100 Washer(6a1) | Buy now |
| 35 | 6D84215700 Lever, throttle | Buy now |




6D81100-D230

F4

| Ref | Part | |
|-----|--|-------------------------|
| 36 | 68V4217100 Bushing | Buy now |
| 37 | 9038706013 Collar | Buy now |
| 41 | 9709506025 Bolt | Buy now |
| 43 | 6D84123700 Joint, link | Buy now |
| 44 | 6824123700 Joint, link 2 | Buy now |
| 45 | 9538005600 Nut, hexagon (663) | Buy now |
| 46 | 60V8259F00 Switch assembly | Buy now |
| 47 | 61A8258801 Plate | Buy now |
| 48 | 9788504016 Screw, panhead (796) | Buy now |
| 49 | 9299504100 Ybs67-4 washer, spring | Buy now |

Crankshaft & Piston




6D81100-D030

A7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D81141100 Crankshaft | Buy now |
| 2 | 67F1141600 Plane bearing, crankshaft 1 UR GREEN | Buy now |
| 2 | 67F1141610 Plane bearing, crankshaft 1 UR BLUE | Buy now |
| 2 | 67F1141620 Plane bearing, crankshaft 1 UR RED | Buy now |
| 3 | 67F1141700 Plane bearing, crankshaft 2 UR YELLOW | Buy now |
| 3 | 67F1141710 Plane bearing, crankshaft 2 UR GREEN | Buy now |
| 3 | 67F1141720 Plane bearing, crankshaft 2 UR BLUE | Buy now |
| 3 | 67F1141730 Plane bearing, crankshaft 2 UR RED | Buy now |
| 4 | 67F1141800 Plane bearing, crankshaft 3 UR GREEN | Buy now |
| 4 | 67F1141810 Plane bearing, crankshaft 3 UR BLUE | Buy now |
| 4 | 67F1141820 Plane bearing, crankshaft 3 UR RED | Buy now |
| 5 | 6D8W116400 Piston/con-rod assembly(std) | Buy now |
| 5 | 6D8W116410 Piston/con-rod assembly(0.25mm os) AP | Buy now |
| 6 | 67F1165400 Bolt, connecting rod | Buy now |
| 7 | 6D81160300 Piston ring set (std) | Buy now |


Crankshaft & Piston



| Ref | Part | |
|-----|--|-------------------------|
| 7 | 6D81160400 Piston ring set (0.25mm o/s) AP | Buy now |
| 8 | 6D81165600 Plane bearing, connecting rod UR YELLOW | Buy now |
| 8 | 6D81165610 Plane bearing, connecting rod UR GREEN | Buy now |
| 8 | 6D81165620 Plane bearing, connecting rod UR BLUE | Buy now |
| 8 | 6D81165630 Plane bearing, connecting rod UR RED | Buy now |
| 9 | 9310248008 Oil seal | Buy now |
| 10 | 9310148001 Oil seal | Buy now |

A7


Cylinder & Crankcase 1



A5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D8W009B001S Cylinder block assembly (6d8-07) | Buy now |
| 2 | 6D815100001S Crankcase assembly | Buy now |
| 3 | 9360612019 Pin, dowel (614) | Buy now |
| 4 | 9011910M88 Bolt, with washer | Buy now |
| 5 | 9011908M66 Bolt, with washer | Buy now |
| 6 | 9034014M06 Plug, straight screw(62y) | Buy now |
| 7 | 9043014115 Gasket (663) | Buy now |
| 8 | 62Y1111900 Hanger, engine | Buy now |
| 9 | 9709506020 Bolt(7u8) | Buy now |
| 10 | 9299506600 Washer, plain (646) | Buy now |
| 11 | 67F1514200 Guide 1 | Buy now |
| 12 | 6D841113001S Outer cover, exhaust | Buy now |
| 13 | 9034018M09 Plug, straight screw | Buy now |
| 14 | 9043018130 Gasket (1j7) | Buy now |
| 15 | 6E51132500 Anode | Buy now |


Cylinder & Crankcase 1



A5

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9878004016 Screw, flat head(ga5) | Buy now |
| 17 | 67F41114A1 Gasket, exhaust outer cover | Buy now |
| 18 | 9011906MA4 Bolt, with washer | Buy now |
| 19 | 9046511M10 Clamp | Buy now |
| 20 | 6G51241600 Valve, pressure control | Buy now |
| 21 | 9050116M11 Spring, compression (688) | Buy now |
| 22 | 9048020M05 Grommet (688) | Buy now |
| 23 | 67F1246A001S Cover 1 | Buy now |
| 24 | 67F12435A0 Gasket | Buy now |
| 25 | 9011906MA2 Bolt, with washer | Buy now |
| 26 | 68V1132501 Anode | Buy now |
| 27 | 69J113270094 Anode cover assembly | Buy now |
| 28 | 9707506020 Bolt(7u8) | Buy now |
| 30 | 67F1132800 Grommet, anode | Buy now |
| 31 | 9757508540 Bolt, hexagon w/w deep recess | Buy now |


Cylinder & Crankcase 1



A5

| Ref | Part | |
|-----|---|-------------------------|
| 32 | 67F1243A00 Hose 1 | Buy now |
| 34 | 9046720M15 Clip | Buy now |
| 35 | 68V1135100 Gasket, cylinder | Buy now |
| 36 | 5GH1344000 Element assembly, oil cleaner | Buy now |
| 37 | 9040120145 Bolt, union | Buy now |


Cylinder & Crankcase 2



B1


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D9W009A001S Cylinder head complete | Buy now |
| 2 | 6D8W1110209S Head, Cylinder With Ex Valve | Buy now |
| 3 | 67F1113310 Guide, intake valve | Buy now |
| 4 | 9034451019 Plug, taper screw | Buy now |
| 5 | 9011907235 Bolt, with washer | Buy now |
| 6 | 9180908006 Pin, dowel | Buy now |
| 7 | K0FA990420 Bolt, with washer | Buy now |
| 8 | 68V1132501 Anode | Buy now |
| 9 | 69J113270094 Anode cover assembly | Buy now |
| 10 | 9707506020 Bolt(7u8) | Buy now |
| 11 | 9299506600 Washer, plain (646) | Buy now |
| 12 | 67F1132800 Grommet, anode | Buy now |
| 13 | 9757508540 Bolt, hexagon w/w deep recess | Buy now |
| 14 | 67F1118102 Gasket, cylinder head 1 | Buy now |
| 15 | 9038710M08 Pin, dowel | Buy now |

Cylinder & Crankcase 2



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9010510M89 Bolt, washer based | Buy now |
| 17 | 9011908M91 Bolt, with washer | Buy now |
| 18 | 6D811191001S Cover, cylinder head 1 | Buy now |
| 19 | 67F1116800 Cover, breather | Buy now |
| 20 | 9850704008 Screw, pan head(jg1) | Buy now |
| 21 | 9290704600 Washer(jf2) | Buy now |
| 22 | 9048012072 Grommet(53y) | Buy now |
| 23 | 6D81135600 Seal, cylinder 2 | Buy now |
| 24 | 9709506030 Bolt(jf7) | Buy now |
| 26 | 67F1119201 Cover, cylinder head 2 | Buy now |
| 27 | 9015906M29 Screw, with washer | Buy now |
| 28 | 6D91241100 Thermostat | Buy now |
| 29 | 68V12413001S Cover, thermostat | Buy now |
| 30 | 9709506025 Bolt | Buy now |
| 32 | 6G81536300 Plug, oil | Buy now |


Cylinder & Crankcase 2



B1

| Ref | Part | |
|-----|--|-------------------------|
| 33 | 9321024M79 O-ring | Buy now |
| 34 | 6D88362600 Mark 6 | Buy now |
| 35 | 9470200391 Plug, spark (lfr5a-11) | Buy now |


Electrical 1



D2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D98591A00 Engine control unit assembly | Buy now |
| 2 | 68V8231700 Damper, ignition coil | Buy now |
| 3 | 6244254200 Collar | Buy now |
| 4 | 9011906M59 Bolt, with washer | Buy now |
| 5 | 63P8231001 Ignition coil assembly | Buy now |
| 6 | 67F8234100 Cord, high tension 1 #1 | Buy now |
| 7 | 67F8234200 Cord, high tension 2 #2 | Buy now |
| 8 | 67F8236100 Clamp, cord | Buy now |
| 9 | 67F8236200 Clamp, cord 2 | Buy now |
| 10 | 67F8234300 Cord, high tension 3 #3 | Buy now |
| 11 | 67F8234400 Cord, high tension 4 #4 | Buy now |
| 14 | 9709506025 Bolt | Buy now |
| 15 | 9299506100 Washer(6a1) | Buy now |
| 16 | 9299506600 Washer, plain (646) | Buy now |
| 17 | 6D88238800 Plate | Buy now |


Electrical 1



| Ref | Part | |
|-----|--|-------------------------|
| 18 | 9046411121 Clamp(4gy) | Buy now |
| 19 | 9048014329 Grommet (16r) | Buy now |
| 20 | 9046508M23 Clamp (6h3) | Buy now |
| 21 | 9709506014 Bolt(gj3) | Buy now |
| 23 | 68V8196000 Rectifier & regulator assembly | Buy now |
| 27 | 9709506020 Bolt(7u8) | Buy now |


D2

Electrical 2



D4


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68V8210500 Battery cable | Buy now |
| 2 | 9701306020 Bolt(62y) | Buy now |
| 3 | 9290306100 Washer(6a1) | Buy now |
| 4 | 9290306600 Washer, plain (646) | Buy now |
| 5 | 60E8195000 Relay assembly | Buy now |
| 6 | 9778060625 Screw, tapping(65j) | Buy now |
| 7 | 68V8194A00 Relay | Buy now |
| 8 | 68V8195300 Stay, relay | Buy now |
| 9 | 9778060620 Screw, tapping(6k8) | Buy now |
| 10 | 9709506010 Bolt | Buy now |
| 11 | 9299506100 Washer(6a1) | Buy now |
| 12 | 9299506600 Washer, plain (646) | Buy now |
| 13 | 6G58211900 Cover, lead wire | Buy now |
| 14 | 63P8195000 Relay assembly | Buy now |
| 20 | 61A8194900 Wire, lead | Buy now |



D4

| Ref | Part | |
|-----|---|-------------------------|
| 21 | 68V8194801 Bracket | Buy now |
| 22 | 6A08231700 Damper, ignition coil | Buy now |
| 23 | 6244254200 Collar | Buy now |
| 24 | 9011906M59 Bolt, with washer | Buy now |
| 25 | 68V8259400 Clamp | Buy now |
| 26 | 9046412M58 Clamp | Buy now |
| 27 | 68V8194202 Cover | Buy now |
| 28 | 67F2812A00 Puller, fuse | Buy now |
| 29 | 6828211901 Cover, lead wire | Buy now |
| 31 | 68V8191900 Graphic, regulator | Buy now |
| 32 | 6D88191900 Graphic, regulator | Buy now |


Electrical 3



De


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D88259010 Wire Harness assembly | Buy now |
| 2 | 67F8215100 Fuse | Buy now |
| 3 | 67F8215110 Fuse | Buy now |
| 4 | 67F8215B10 Cap (yellow) | Buy now |
| 5 | 67F8215B20 Cap (green) | Buy now |
| 6 | 9046476001 Clamp | Buy now |
| 7 | 9709506020 Bolt(7u8) | Buy now |
| 8 | 9299506100 Washer(6a1) | Buy now |
| 9 | 9299506600 Washer, plain (646) | Buy now |
| 10 | 6D88258800 Plate | Buy now |
| 11 | 9709506012 Bolt(gh1) | Buy now |
| 13 | 6D88258100 Stay, cord clamp | Buy now |
| 14 | 9709506014 Bolt(gj3) | Buy now |
| 16 | 6D88238900 Plate 2 | Buy now |
| 19 | 6D88239800 Plate 3 | Buy now |

| Ref | Part | |
|-----|-------------------------------------|-------------------------|
| 22 | 9046513M18 Clamp | Buy now |



De


Electrical 4



D7


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D88132G00 Plate | Buy now |
| 2 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 3 | 9299506600 Washer, plain (646) | Buy now |
| 4 | 67F8579000 Thermosensor assembly | Buy now |
| 5 | 67F8575700 Retainer | Buy now |
| 6 | 68V8575300 Gasket, sender unit | Buy now |
| 9 | 9046506M86 Clamp | Buy now |
| 10 | 9709506010 Bolt | Buy now |
| 11 | 68V8250400 Oil pressure switch assembly | Buy now |
| 12 | 63D8256310 Trim & tilt switch assembly | Buy now |
| 13 | 6E58258700 Gasket | Buy now |
| 14 | 67F8361400 Bracket | Buy now |
| 15 | 9010906M86 Bolt | Buy now |
| 16 | 9046430003 Clamp | Buy now |

Fuel 1



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6898554700 Damper | Buy now |
| 2 | 9044513M37 Hose (I2300) | Buy now |
| 3 | 68V2456001 Filter assembly | Buy now |
| 4 | 68V2452101 Cup, filter | Buy now |
| 5 | 68V2456300 Element, filter | Buy now |
| 6 | 9321032738 O-ring(1wg) | Buy now |
| 7 | 68V2446901 Float, water level | Buy now |
| 8 | 9046511M10 Clamp | Buy now |
| 9 | 6D82456600 Bracket, filter | Buy now |
| 10 | 9538008600 Nut (661) | Buy now |
| 11 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 12 | 9299506600 Washer, plain (646) | Buy now |
| 13 | 6D82431100 Pipe, fuel 1 | Buy now |
| 14 | 6D82441010 Fuel pump assembly | Buy now |
| 15 | 68V2441200 Body 1 | Buy now |


Fuel 1



C5

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 68V2445400 Spring | Buy now |
| 17 | 63P1313100 Plunger | Buy now |
| 18 | 68V2442300 Spring, diaphragm | Buy now |
| 19 | 68V2441100 Diaphragm | Buy now |
| 20 | 68V2437400 Pin | Buy now |
| 21 | 68V2441300 Body 2 | Buy now |
| 22 | 6D82441400 Body 3 | Buy now |
| 23 | 68V2444400 Screw | Buy now |
| 24 | 68V2414900 Nut | Buy now |
| 26 | 9321030682 O-ring (371) | Buy now |
| 27 | 9011906M83 Bolt, with washer | Buy now |
| 28 | 61H2819R31 Tag Warning | Buy now |
| 29 | 67F2810001 Tool kit | Buy now |
| 30 | 6D72819970D0 Om f80b/f100d '05 UR (NL) | Buy now |
| 30 | 6D72819970E0 Om f80b/f100d '05 UR (E) | Buy now |

Fuel 1




C5

| Ref | Part | |
|-----|--|-------------------------|
| 30 | 6D72819970F0 Om f80b/f100d '05 UR (F) | Buy now |
| 30 | 6D72819970G0 Om f80b/f100d '05 UR (D) | Buy now |
| 30 | 6D72819970H0 Om f80b/f100d '05 UR (I) | Buy now |
| 30 | 6D72819970S0 Om f80b/f100d '05 UR (ES) | Buy now |
| 31 | 6D72819980K0 Om f80b/f100d '05 UR (DK) | Buy now |
| 31 | 6D72819980L0 Om f80b/f100d '05 UR (SF) | Buy now |
| 31 | 6D72819980M0 Om f80b/f100d '05 UR (S) | Buy now |
| 31 | 6D72819980N0 Om f80b/f100d '05 UR (N) | Buy now |
| 31 | 6D72819980P0 Om f80b/f100d '05 UR (P) | Buy now |
| 31 | 6D72819980R0 Om f80b/f100d '05 UR (GR) | Buy now |
| 32 | 68V2447110 Diaphragm | Buy now |

Fuel 2


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6YK2430643 Fuel pipe comp. 1 AP | Buy now |



67F3300-C110

C7


Fuel Injection Pump 1



C3

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D81418000 Float chamber assembly | Buy now |
| 2 | 6D81418200 Cover, float chamber | Buy now |
| 3 | 6C51498500 Float | Buy now |
| 4 | 6C51454600 Valve, needle | Buy now |
| 5 | 6C51438600 Pin, float | Buy now |
| 6 | 6C52441R00 Plate, baffle 1 | Buy now |
| 7 | 6C52441T00 Plate, baffle 2 | Buy now |
| 8 | 6C52445300 Screw | Buy now |
| 9 | 6C51390600 Regulator, pressure | Buy now |
| 10 | 6C52459200 Bolt | Buy now |
| 11 | 6C58722600 Wire harness assembly | Buy now |
| 12 | 6D81496000 Body assembly | Buy now |
| 13 | 6C51419100 Plug, drain | Buy now |
| 14 | 6C51439700 O-ring | Buy now |
| 15 | 6C51456700 Screw | Buy now |


Fuel Injection Pump 1



| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6C51391000 Fuel pump assembly | Buy now |
| 17 | 6C51390700 Fuel pump comp. | Buy now |
| 18 | 6C51412700 Clip | Buy now |
| 19 | 6C51391500 Filter | Buy now |
| 20 | 6C51359300 Damper | Buy now |
| 21 | 6C51378100 Damper, pump | Buy now |
| 22 | 6C51371600 Collar | Buy now |
| 23 | 6C51498400 Gasket, float chamber | Buy now |
| 24 | 6C52133700 Clamp, cable | Buy now |
| 25 | 6C51422500 Cap | Buy now |
| 26 | 9038706M69 Collar (688) | Buy now |
| 27 | 9048009M12 Grommet (6a0) | Buy now |

C3

Fuel Injection Pump 2




6D81100-D100

C4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D81354600 Hose 2 | Buy now |
| 2 | 6D81354200 Hose, vacuum sensing 1 | Buy now |
| 3 | 6C52432100 Pipe 10 | Buy now |
| 4 | 6C52432200 Pipe 11 | Buy now |
| 5 | 6C52432300 Pipe 12 | Buy now |
| 6 | 6D82432400 Pipe 13 | Buy now |
| 7 | 6D82432500 Pipe 14 (L500) | Buy now |
| 8 | 6C51414900 Pipe (L200) | Buy now |
| 9 | 6C52444400 Screw | Buy now |
| 10 | 6C51357700 Clip | Buy now |
| 11 | 6C52184100 Cooler | Buy now |
| 12 | 6C51425100 Nipple | Buy now |
| 13 | 6C52411M00 Clip | Buy now |
| 14 | 6D81414800 Pipe | Buy now |
| 15 | 6C52438700 Clip | Buy now |

Fuel Injection Pump 2




6D81100-D100

C4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6D81397400 Pipe, fuel 4 | Buy now |
| 17 | 9046511M10 Clamp | Buy now |
| 18 | 6C52437900 Pipe, joint 4 | Buy now |
| 19 | 6C51354500 Hose 1 | Buy now |
| 20 | 6C52425100 Strainer 1 | Buy now |
| 21 | 6D82451B00 Hose, fuel inlet | Buy now |
| 22 | 6C51373900 O-ring | Buy now |


Generator



D1

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D88145000 Rotor assembly | Buy now |
| 2 | 6D88146000 Base assembly | Buy now |
| 3 | 6D88558000 Coil, pulser | Buy now |
| 4 | 6D88141000 Stator assembly | Buy now |
| 5 | 63D8134520 Screw, pan | Buy now |
| 6 | 9760704110 Screw, pan head with washer (s) | Buy now |
| 7 | 4458132820 Clamp, read | Buy now |
| 8 | 68V8167300 Rotor | Buy now |
| 9 | 9953008012 Pin, dowel(6g8) | Buy now |
| 10 | 9709506030 Bolt(jf7) | Buy now |
| 11 | 9299506100 Washer(6a1) | Buy now |
| 12 | 9299506600 Washer, plain (646) | Buy now |
| 13 | 9028005015 Key, woodruff | Buy now |
| 14 | 9020124014 Washer, plate | Buy now |
| 15 | 9017924002 Nut | Buy now |


Generator



D1

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6D88133200 Plate, timing | Buy now |
| 17 | 9788506010 Screw pan head | Buy now |
| 19 | 6D88133700 Cover, flywheel | Buy now |
| 20 | 9048012072 Grommet(53y) | Buy now |
| 21 | 6D88554700 Damper | Buy now |
| 22 | 6638231701 Damper, ignition coil | Buy now |
| 23 | 67F1213860 Mark Caution | Buy now |
| 24 | 68V1343760 Mark, caution | Buy now |
| 25 | 6A18362541 Mark 5 | Buy now |
| 26 | 6A18362551 Mark 5 | Buy now |


Intake 1



Be

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D81420000 Intake assembly | Buy now |
| 2 | 6D81364100 Manifold, intake 1 | Buy now |
| 3 | 6D81364500 Gasket, manifold 1 | Buy now |
| 4 | 6D81355700 Gasket | Buy now |
| 5 | 6D81375000 Throttle body assembly | Buy now |
| 6 | 6C58588500 Throttle sensor assembly | Buy now |
| 7 | 6C58114500 Screw 1 | Buy now |
| 8 | 6C58182L00 O-ring 1 | Buy now |
| 9 | 6C51449600 Bolt | Buy now |
| 10 | 6D81310500 Control valve assembly | Buy now |
| 11 | 6C51319C00 O-ring | Buy now |
| 12 | 6C58114600 Screw 2 | Buy now |
| 13 | 6D81316100 Pipe, delivery 1 | Buy now |
| 14 | 6C51444600 Bolt | Buy now |
| 15 | 6D81376100 Injector assembly | Buy now |


Intake 1



| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6C51410B00 Packing kit | Buy now |
| 17 | 68F8368800 Sensor assembly | Buy now |
| 18 | 9046418246 Clamp(4tr) | Buy now |

B6


Intake 2



B7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9011908069 Bolt, with washer | Buy now |
| 2 | 9038708033 Collar | Buy now |
| 3 | 9011908M03 Bolt (689) | Buy now |
| 4 | 9169050014 Pin, spring (647) | Buy now |
| 5 | 6D8142910094 Bracket 1 | Buy now |
| 6 | 9709506030 Bolt(jf7) | Buy now |
| 7 | 9299506600 Washer, plain (646) | Buy now |
| 8 | 9011906087 Bolt, with washer | Buy now |
| 9 | 6D8142920094 Bracket 2 | Buy now |
| 10 | 9709506020 Bolt(7u8) | Buy now |
| 13 | 6D91444000 Silencer assembly, intake | Buy now |
| 14 | 9038608001 Bush | Buy now |
| 15 | 9038707013 Collar | Buy now |
| 16 | 9011906113 Bolt, with washer | Buy now |
| 17 | 6D81441J00 Pipe, Silencer | Buy now |


Intake 2



B7

| Ref | Part | |
|-----|--|-------------------------|
| 18 | 9046476001 Clamp | Buy now |
| 19 | 6D81537300 Pipe, breather | Buy now |
| 20 | 9046511M59 Clamp(63m) | Buy now |
| 21 | 9046720M15 Clip | Buy now |
| 22 | 9046512M03 Clamp, cord (688) | Buy now |
| 23 | 9709506012 Bolt(gh1) | Buy now |
| 25 | 6D88254400 Clamp | Buy now |
| 26 | 9589506025 Bolt, flange deep recess | Buy now |


Intake 3



C1

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9011906M08 Bolt, with washer | Buy now |
| 2 | 9046415007 Clamp | Buy now |
| 3 | 6D81342800 Bracket, strainer 1 | Buy now |
| 4 | 9709506012 Bolt(gh1) | Buy now |
| 5 | 9299506600 Washer, plain (646) | Buy now |
| 6 | 6D82431400 Pipe 4 | Buy now |
| 7 | 9046511M10 Clamp | Buy now |
| 8 | 69J2417000 Canister assembly | Buy now |
| 9 | 6D82431500 Pipe 5 | Buy now |
| 11 | 6D82417H00 Clamp 1 | Buy now |
| 12 | 9709506010 Bolt | Buy now |
| 14 | 69J2450200 Filter, fuel | Buy now |
| 15 | 6D82431600 Pipe 6 | Buy now |
| 17 | 9046709M03 Clip(6k8) | Buy now |
| 18 | 69J4439100 Nipple, hose | Buy now |


Intake 3



C1

| Ref | Part | |
|-----|---|-------------------------|
| 19 | 6D82413X00 Plate | Buy now |
| 20 | 6D82431700 Pipe 7 | Buy now |
| 22 | 69J2419A00 Holder | Buy now |
| 23 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 25 | 6D82134X00 Bracket, canister | Buy now |
| 26 | 9048010M23 Grommet(6k7) | Buy now |
| 27 | 9038706M60 Collar (6h3) | Buy now |
| 28 | 9011906M59 Bolt, with washer | Buy now |


Lower Casing & Drive 1



C2


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D945300104D Lower unit assembly L | Buy now |
| 2 | 67F45301004D Casing, lower | Buy now |
| 3 | 9034008002 Plug, straight screw | Buy now |
| 4 | 6884534110 Plug, drain | Buy now |
| 5 | 9043008020 Gasket | Buy now |
| 6 | 6E54537800 Nipple, hose | Buy now |
| 7 | 9044507M31 Hose (l200) L | Buy now |
| 8 | 6E58355810 End, nipple | Buy now |
| 9 | 9046511M10 Clamp | Buy now |
| 10 | 67F4550110 Drive shaft comp. L | Buy now |
| 11 | 6D94555100 Pinion (13T) | Buy now |
| 12 | 9017016M01 Nut, hexagon (688) | Buy now |
| 13 | 9331552563 Bearing | Buy now |
| 14 | 6884553601 Sleeve, drive shaft | Buy now |
| 15 | 93332000U3 Brg,tapered roller 50mm (688) | Buy now |

Lower Casing & Drive 1



| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6884558701 Shim (t:0.10mm) UR | Buy now |
| 16 | 6884558710 Shim (t:0.12mm) UR | Buy now |
| 16 | 6884558720 Shim (t:0.15mm) UR | Buy now |
| 16 | 6884558730 Shim (t:0.18mm) UR | Buy now |
| 16 | 6884558740 Shim (t:0.30mm) UR | Buy now |
| 16 | 6884558750 Shim (t:0.40mm) UR | Buy now |
| 16 | 6884558760 Shim (t:0.50mm) UR | Buy now |
| 17 | 67F4431100 Housing, water pump | Buy now |
| 18 | 9360410M03 Pin, dowel (688) | Buy now |
| 19 | 9011908M87 Bolt, with washer | Buy now |
| 20 | 9011908M13 Bolt, with washer(6h0) | Buy now |
| 21 | 6634436600 Damper, water seal 2 | Buy now |
| 22 | 9048019M06 Grommet (688) | Buy now |
| 23 | 9778040512 Screw, pan head tapping | Buy now |
| 24 | 67F4432200 Insert, cartridge | Buy now |


Lower Casing & Drive 1



C2

| Ref | Part | |
|-----|--|-------------------------|
| 25 | 67F4435200 Impeller | Buy now |
| 26 | 9028004M04 Key, woodruff (688) | Buy now |
| 27 | 68844315A0 Gasket,water pump 1 | Buy now |
| 28 | 67F4432300 Outer plate, cartridge | Buy now |
| 29 | 68844324A0 Gasket,cartridge Outer plate | Buy now |
| 30 | 6D84434100 Housing, water pump set | Buy now |
| 31 | 9310125M03 Oil seal | Buy now |
| 32 | 9321046044 O-ring | Buy now |
| 33 | 68844316A0 Gasket,water pump 2 | Buy now |
| 34 | 6884532100 Plate | Buy now |
| 35 | 9310609014 Oil seal | Buy now |
| 36 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 37 | 9299506600 Washer, plain (646) | Buy now |
| 38 | 9321049046 O-ring (620) | Buy now |
| 39 | 67F4415000 Shift cam assembly | Buy now |


Lower Casing & Drive 1



C2

| Ref | Part | |
|-----|--|-------------------------|
| 40 | 9321007003 O-ring (11m) | Buy now |
| 41 | 9900108600 Circlip(2r6) | Buy now |
| 42 | 9350316003 Ball | Buy now |
| 43 | 67F4563400 Slide, shift | Buy now |
| 44 | 6H14566800 Shaft, free 1 | Buy now |
| 45 | 6H14563500 Plunger, shift | Buy now |
| 46 | 9050112M48 Spring (6h1) | Buy now |
| 47 | 9020103313 Washer, plate 8077743700 | Buy now |
| 48 | 9018302M03 Nut, spring (6h1) | Buy now |
| 49 | 67F4563100 Clutch, dog | Buy now |
| 50 | 9025007M02 Pin, straight (688) | Buy now |
| 51 | 6884563300 Ping, cross pin | Buy now |
| 52 | 67F4556000 Gear 1 (30T) | Buy now |
| 53 | 93317322V0 Bearing | Buy now |
| 54 | 93332000UD Bearing | Buy now |


Lower Casing & Drive 1



C2

| Ref | Part | |
|-----|--|-------------------------|
| 55 | 6884556701 Shim (t:0.10mm) UR | Buy now |
| 55 | 6884556710 Shim (t:0.12mm) UR | Buy now |
| 55 | 6884556720 Shim (t:0.15mm) UR | Buy now |
| 55 | 6884556730 Shim (t:0.18mm) UR | Buy now |
| 55 | 6884556740 Shim (t:0.30mm) UR | Buy now |
| 55 | 6884556750 Shim (t:0.40mm) UR | Buy now |
| 55 | 6884556760 Shim (t:0.50mm) UR | Buy now |
| 56 | 6D94557100 Gear 2 (30T) | Buy now |
| 57 | 93306207U0 Brg,r-b 6207 72mm 280g (688) | Buy now |
| 58 | 9020125M05 Washer, plate | Buy now |
| 59 | 67F4561101 Shaft, propeller | Buy now |
| 60 | 67F453310094 Housing, bearing | Buy now |
| 61 | 93317325U0 Brg,needle | Buy now |
| 63 | 9321086M39 O-ring (6e5) | Buy now |
| 64 | 67F4557600 Washer, thrust 2 | Buy now |


Lower Casing & Drive 1



| Ref | Part | |
|-----|--|-------------------------|
| 65 | 9028204010 Key, strait(663) | Buy now |
| 66 | 6884538302 Washer, claw | Buy now |
| 67 | 6884538400 Nut | Buy now |


C2

Lower Casing & Drive 2



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6634436700 Damper, water seal 3 | Buy now |
| 2 | 6D84436100 Tube, water 1 L | Buy now |
| 3 | 6D84431400 Spacer | Buy now |
| 4 | 67F4436500 Damper, water seal | Buy now |
| 5 | 9360612019 Pin, dowel (614) | Buy now |
| 6 | 9707510040 Bolt, hexagon deep recess L | Buy now |
| 7 | 9299510100 Ybs67-10 washer, spring L | Buy now |
| 8 | 9299510600 Washer, plate L | Buy now |
| 9 | 9011908M84 Bolt, with washer L | Buy now |
| 10 | 6H14521400 Cover, water inlet | Buy now |
| 11 | 6H14521500 Cover, water inlet | Buy now |
| 12 | 9015105M00 Screw, countersunk(692) | Buy now |
| 13 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 14 | 67F4537100 Tab-trim | Buy now |
| 15 | 9010510M67 Bolt, hexagon (663) | Buy now |


Lower Casing & Drive 2



C5

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9044507ME0 Hose (I1457) | Buy now |
| 17 | 6E58355800 End, nipple | Buy now |
| 18 | 6884537500 Damper, seal 2 | Buy now |
| 19 | 663453760094 Guide, seal damper | Buy now |
| 20 | 6884598701 Spacer | Buy now |
| 21 | 67F4599700 Spacer 2 | Buy now |
| 22 | 9038925M00 Bush | Buy now |
| 23 | 9017116011 Nut, castle (663) | Buy now |
| 24 | 9149040025 Pin, cotter (663) | Buy now |
| 25 | 6E54594100EL Propeller (3x13x19-k) UR | Buy now |
| 25 | 6E54594300EL Propeller (3x12-5/8"x21"-k) UR | Buy now |
| 25 | 6E54594501EL Propeller (3x13-1/4x17-k) UR | Buy now |
| 25 | 688459300298 Propeller (3x13x17) UR | Buy now |
| 25 | 688459326098 Propeller (3x13-1/2"x14"-k) UR | Buy now |
| 25 | 688459700398 Propeller (3x13"x19"-k) | Buy now |

Lower Casing & Drive 2




6D81100-D320

C5

| Ref | Part | |
|-----|--|-------------------------|
| 25 | 688459720298 Propeller (3x13"x21"-k) UR | Buy now |
| 25 | 688459740298 Propeller (3x13"x23"-k) UR | Buy now |
| 25 | 688459760198 Propeller (ss 3x13"x25"-k) UR | Buy now |
| 25 | 688459786098 Propeller (3x13-1/2"x16"-k) UR | Buy now |
| 25 | 6E54594700EL Propeller (3x13-1/2x15-k) UR | Buy now |
| 25 | 6E54594900EL Propeller (3x13-5/8"x13"-k) UR | Buy now |
| 25 | 6E54595200EL Propeller (3x13"x23"-k) UR | Buy now |
| 25 | 6E54595400EL Propeller (3x14"x11"-k) UR | Buy now |
| 25 | 6E54595600EL Propeller (3x13"x25"-k) UR | Buy now |

Meter




61A1700-2290

D5

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6Y58350T03 Digital tachometer assembly AP | Buy now |
| 2 | 9E45004433 Housing, connector (m-4-w) M-4-W | Buy now |
| 3 | 9E45004533 Housing, f-4-w(5pcs) F-4-W | Buy now |
| 4 | 9299004100 Ybs67-4 washer, spring | Buy now |
| 5 | 9538004600 Nut,hex | Buy now |
| 6 | 6Y583500S5 Meter assembly AP | Buy now |
| 7 | 6Y583570S5 Speedometer assembly | Buy now |
| 10 | 6Y583533T2 Grommet | Buy now |
| 11 | 6Y58355731 Tube | Buy now |
| 12 | 6Y58372800 Connector assembly | Buy now |
| 20 | 9046511M10 Clamp AP | Buy now |
| 14 | 6Y587122S0 Cord assembly 1 AP | Buy now |
| 15 | 6Y583553M0 Wire, lead (l=2.5m) AP | Buy now |
| 16 | 1E68215100 Fuse (10a) | Buy now |
| 17 | 6Y58211700 Wire, lead AP | Buy now |

Meter




61A1700-2290

D5

| Ref | Part | |
|-----|---|-------------------------|
| 18 | 68F8255380 Extension, wire lead (8m) AP | Buy now |
| 19 | 6Y58355710 Tube (8m) AP | Buy now |


Oil Pan



B7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 67F15311035B Oil pan | Buy now |
| 2 | 63P1531600 Damper 1 | Buy now |
| 3 | 9034014M06 Plug, straight screw(62y) | Buy now |
| 4 | 9043014M09 Gasket | Buy now |
| 5 | 9707506025 Bolt | Buy now |
| 6 | 9299506600 Washer, plain (646) | Buy now |
| 7 | 9360612019 Pin, dowel (614) | Buy now |
| 8 | 68V1531200 Gasket, oil pan | Buy now |
| 9 | 67F1341100 Strainer, oil | Buy now |
| 10 | 9702706025 Bolt, hexagon | Buy now |
| 11 | 9290706600 Washer(6ta) | Buy now |
| 12 | 9038706M64 Collar | Buy now |
| 13 | 67F1341500 Seal, oil strainer | Buy now |
| 14 | 67F1330010 Oil pump assembly | Buy now |
| 15 | 67F1331402 Shaft, pump | Buy now |


Oil Pan



B7

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67F1347301 O-ring | Buy now |
| 17 | 67F1332900 Gasket, pump cover | Buy now |
| 18 | 67F1349500 Screw | Buy now |
| 19 | 67F1311901 Oil seal | Buy now |
| 20 | 67F1376900 O-ring | Buy now |
| 21 | 67F1391400 Housing, pump | Buy now |
| 22 | 67F1363103 Oil seal | Buy now |
| 23 | 67F1314900 Oil seal | Buy now |
| 24 | 67F1333900 Gasket, pump cover | Buy now |
| 25 | 67F1333800 Seal | Buy now |
| 26 | 9709506045 Bolt, hexagon | Buy now |
| 28 | 9360412M07 Pin, dowel (688) | Buy now |
| 29 | 9321019MJ1 O-ring | Buy now |
| 30 | 6D81536200 Plug, oil level | Buy now |

Optional Parts 1




67F0100-0240

A6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 67F45180004D Plate, Splash AP | Buy now |
| 2 | 9020112M01 Washer, plate(6t4) AP | Buy now |
| 3 | 9538012700 Nut(6t4) AP | Buy now |
| 4 | 9011012M00 Bolt, hexagon socket head AP | Buy now |
| 5 | 9020112M16 Washer, plate (679) AP | Buy now |
| 6 | 9578012300 Nut, nylon (6f2) AP | Buy now |

Optional Parts 2




6C11010-D330

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6C5W818600 Variable trolling rpm switch ki AP | Buy now |
| 2 | 6C58186000 Switch assembly | Buy now |
| 3 | 6C52344800 Spacer | Buy now |
| 4 | 6C52344810 Spacer | Buy now |
| 5 | 9015906018 Screw, With Washer | Buy now |
| 6 | 9578006300 Nut, nylon (6g1) | Buy now |
| 7 | 9046506M86 Clamp | Buy now |
| 8 | 9020106028 Washer, plate | Buy now |
| 9 | 9788506016 Screw, pan head(6b0) | Buy now |
| 10 | 9046513M24 Band, switch cord | Buy now |


De

Power Trim & Tilt Assy 1



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D843800004D Power trim & tilt assembly | Buy now |
| 2 | 67F4381001 Tilt piston sub assembly | Buy now |
| 3 | 67F4380R00 Cylinder end sub assembly | Buy now |
| 4 | 6H14387210 Ring, back up | Buy now |
| 5 | 9321018397 O-ring (6g5) | Buy now |
| 6 | 67F4381100 Cylinder end sub assembly | Buy now |
| 7 | 67F4385A01 Piston, tilt | Buy now |
| 8 | 9321029375 O-ring (j10) | Buy now |
| 9 | 62X4387100 Ring, back up | Buy now |
| 10 | 9350108001 Ball | Buy now |
| 11 | 9360207244 Pin, dowel | Buy now |
| 12 | 67F2243500 Plate, valve 2 | Buy now |
| 13 | 67F4387500 Ring, snap | Buy now |
| 14 | 6H14381200 Seal dast | Buy now |
| 15 | 67F4382100 Screw, trim cylinder end | Buy now |


Power Trim & Tilt Assy 1



A7

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67F4386100 O-ring | Buy now |
| 19 | 62X4386200 O-ring | Buy now |
| 21 | 65W4386A00 Pin, absorber valve | Buy now |
| 22 | 6884386F00 Pin, straight | Buy now |
| 23 | 65W4385300 Spring, absorber valve | Buy now |
| 24 | 67F4389300 Washer | Buy now |
| 25 | 9350316003 Ball | Buy now |
| 26 | 67F4386300 O-ring | Buy now |
| 28 | 67F4389900 Plate stopper | Buy now |
| 29 | 67F4381600 Filter 1 | Buy now |
| 30 | 67F4386200 O-ring | Buy now |
| 31 | 67F4387100 Ring, back up | Buy now |
| 32 | 62X4386500 O-ring | Buy now |
| 33 | 67F4388A00 Piston, trim | Buy now |
| 34 | 6T44386A00 Pin, absorber valve | Buy now |


Power Trim & Tilt Assy 1



A7

| Ref | Part | |
|-----|---|-------------------------|
| 35 | 67F4385700 Spring, absorber valve | Buy now |
| 36 | 67F4381J00 Plate | Buy now |
| 37 | 67F2247101 Cylinder, shock absorber | Buy now |
| 38 | 67F4381B00 Free piston sub assembly | Buy now |
| 39 | 62X4389900 Plate stopper | Buy now |
| 40 | 62X4384H00 Spring | Buy now |
| 41 | 1UF2243400 Plate, valve 1 | Buy now |
| 42 | 62X4387500 Ring, snap | Buy now |
| 43 | 6D84380K00 Cylinder, tilt sub assembly | Buy now |
| 44 | 6C64381700 Filter 2 | Buy now |
| 45 | 69J4389J00 O-ring | Buy now |
| 46 | 6C54381600 Filter 1 | Buy now |
| 47 | 6C54380G00 Plate | Buy now |
| 48 | 9131705045 Bolt, socket | Buy now |
| 49 | 6D84383000 Gear pump assembly | Buy now |


Power Trim & Tilt Assy 1



A7

| Ref | Part | |
|-----|--|-------------------------|
| 50 | 6C64384100 Piston, shuttle | Buy now |
| 51 | 6H14388300 O-ring | Buy now |
| 52 | 6C64389400 Spring, shuttle return | Buy now |
| 53 | 6C64382E00 Adaptor 2 | Buy now |
| 54 | 9350532038 Ball(7fk) | Buy now |
| 55 | 6C64385300 Spring, main valve | Buy now |
| 56 | 6C64387G00 Washer | Buy now |
| 58 | 6C54385100 Seat, relief valve | Buy now |
| 59 | 6C54389300 Washer | Buy now |
| 60 | 6D84385500 Spring, up relief | Buy now |
| 61 | 6C64389300 Washer | Buy now |
| 62 | 6C54381K00 Holder | Buy now |
| 63 | 6D84385600 Spring, down relief | Buy now |
| 64 | 6C54382K00 Cap, relief valve | Buy now |
| 65 | 6C54382L00 Cap, relief valve | Buy now |


Power Trim & Tilt Assy 1



A7

| Ref | Part | |
|-----|--|-------------------------|
| 66 | 6C54389500 Seat, relief valve | Buy now |
| 67 | 6C54385400 Spring, manual release | Buy now |
| 68 | 92A0803110 Screw set | Buy now |
| 69 | 9530703600 Nut(7rc) | Buy now |
| 70 | 9131705030 Bolt, socket | Buy now |
| 71 | 6C64387800 Bolt, socket | Buy now |
| 72 | 62Y4387G00 Washer | Buy now |
| 73 | 9131704030 Bolt | Buy now |
| 74 | 9131703016 Bolt | Buy now |
| 75 | 6C64388E00 Plug, taper screw | Buy now |
| 76 | 6C64388F00 Spacer | Buy now |
| 77 | 6C64386G00 Pin, straight 2 | Buy now |
| 78 | 6C64386E00 Lever 1 | Buy now |
| 79 | 9160950028 Pin spring (am2) | Buy now |
| 80 | 9131703005 Bolt Socket | Buy now |


Power Trim & Tilt Assy 1



A7


| Ref | Part | |
|-----|--|-------------------------|
| 81 | 9131705025 Bolt, socket | Buy now |
| 82 | 6C54384100 Piston, shuttle | Buy now |
| 83 | 6C54387200 Ring, back up | Buy now |
| 84 | 6D84381G00 Pin 1 | Buy now |
| 85 | 92A0803012 Screw set | Buy now |
| 87 | 6H14387500 Ring, snap | Buy now |
| 88 | 6D84384500 Screw, manual release | Buy now |
| 89 | 9321009165 O-ring | Buy now |
| 90 | 6H14382900 Plug, reservoir | Buy now |
| 91 | 6C54383100 Connector, shaft | Buy now |
| 92 | 9321064488 93210-64488 | Buy now |
| 93 | 65W4388800 Bolt, hexagon socket head(1jk) | Buy now |
| 94 | 9131705050 Bolt, socket | Buy now |
| 95 | 6D84388000 Motor assembly (with connector) REFER TO FIG.28 | Buy now |

Power Trim & Tilt Assy 2



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D84388000 Motor assembly (with connector) | Buy now |
| 2 | 6D84380500 Armature assembly | Buy now |
| 3 | 6D84380400 Stator assembly | Buy now |
| 4 | 6H14389111 Brush 1 | Buy now |
| 5 | 6H14389211 Brush 2 | Buy now |
| 6 | 6H18218110 Circuit breaker comp. | Buy now |
| 7 | 62X4380700 Wire sub assembly | Buy now |
| 8 | 6H14380F11 Plate, brush holder | Buy now |
| 9 | 62X4386K00 Spring, brush | Buy now |
| 10 | 9798005225 Screw, with washer | Buy now |
| 11 | 9760704216 Screw, pan head with washer | Buy now |
| 13 | 6H14388211 Oil seal | Buy now |
| 14 | 90201121J9 Washer, plane (xd1) | Buy now |
| 15 | 93210554A9 O-ring | Buy now |
| 16 | 6D84388008 Motor assembly (with connector) | Buy now |


Power Trim & Tilt Assy 2



B4

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 6D84380502 - | Buy now |
| 18 | 6EK4380411 Stator assembly | Buy now |
| 19 | 6EK4389200 Brush 2 | Buy now |
| 20 | 63P8218120 Circuit breaker comp. | Buy now |
| 21 | 6EK4380F00 Plate, brush holder | Buy now |
| 23 | 63P4387910 Screw, with washer | Buy now |
| 24 | 9760204316 Screw, pan head with washer | Buy now |
| 25 | 6D84388109 Frame, End | Buy now |
| 26 | 6LH4388200 Oil seal | Buy now |
| 27 | 9020614086 Washer, wave(6t4) | Buy now |
| 28 | 6EK4386201 O-ring | Buy now |


Remote Control Assy



D2


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 7034820517 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 7034826101 Arm, throttle | Buy now |
| 3 | 7034815300 Shaft, free accel. | Buy now |
| 4 | 7034823500 Bushing | Buy now |
| 5 | 7034826800 Spacer 3 | Buy now |
| 6 | 7034826400 Throttle, friction | Buy now |
| 7 | 9538005600 Nut, hexagon (663) | Buy now |
| 8 | 9738005025 Bolt | Buy now |
| 9 | 7034826500 Shaft Friction | Buy now |
| 10 | 9343006024 Circlip (701) | Buy now |
| 11 | 7034824500 Plate, lock | Buy now |
| 12 | 7034825200 Roller, cam | Buy now |
| 13 | 7014824800 Roller, free accel | Buy now |
| 14 | 7034819800 Washer, wave 3 | Buy now |
| 15 | 7034824300 Bushing 3 | Buy now |

Remote Control Assy



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 7034823600 Bushing | Buy now |
| 17 | 7034818900 Retainer | Buy now |
| 18 | 7034823400 Roller, detent | Buy now |
| 19 | 7034834501 Cable end, remote control 2 | Buy now |
| 20 | 7034835800 Anchor, cable | Buy now |
| 21 | 7034824400 Spring, free accel. | Buy now |
| 22 | 7034823800 Spring, detent | Buy now |
| 23 | 7034824600 Spacer 1 | Buy now |
| 24 | 7034822700 Spring, neutral lock | Buy now |
| 25 | 7038259400 Clamp WITH PT/T SW. | Buy now |
| 26 | 7034822600 Plate, stopper | Buy now |
| 27 | 7034822200 Grip, control lever SINGLE | Buy now |
| 28 | 7034822300 Lock, neutral | Buy now |
| 29 | 7034822500 Cover | Buy now |
| 30 | 7034821900 Cover, lead | Buy now |


Remote Control Assy



D2

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 7034828100 Screw, flat head | Buy now |
| 32 | 7034828200 Screw | Buy now |
| 33 | 9738008030 Bolt, hexagon (fj1) | Buy now |
| 34 | 9299008600 Washer, plain (663) | Buy now |
| 35 | 9858004010 Screw, pan head (e56) | Buy now |
| 36 | 9858004006 Screw, pan head (7h3) | Buy now |
| 37 | 9858005010 Screw, pan head(62x) | Buy now |
| 38 | 9858003015 Screw, pan head (n151) | Buy now |
| 39 | 7034829110 Screw | Buy now |
| 40 | 9538006600 Nut(661) | Buy now |
| 41 | 7034829310 Spacer, remote control SINGLE | Buy now |
| 42 | 7014828700 Washer 1 | Buy now |
| 43 | 7034821500 Graphic | Buy now |
| 44 | 7038251043 Main switch assembly | Buy now |
| 45 | 7038257700 Cap, key | Buy now |


Remote Control Assy



D2

| Ref | Part | |
|-----|---|-------------------------|
| 46 | 7038253100 Wire, lead | Buy now |
| 47 | 6888257501 Engine stop switch assembly | Buy now |
| 48 | 6828255600 Lanyard, stop switch | Buy now |
| 49 | 6888258A20 10p main harness mec 2m (6ft) L)5M (10P) | Buy now |
| 50 | 7038254000 Neutral switch assembly | Buy now |
| 51 | 7038338302 Buzzer | Buy now |
| 52 | 7034828400 Grommet | Buy now |
| 53 | 7038259100 Band | Buy now |
| 54 | 7038259200 Band | Buy now |
| 55 | 7038256302 Trim & tilt switch assembly WITH PT/T SW. | Buy now |
| 56 | 7034822100 Grip | Buy now |
| 57 | 7034815200 Knob, free accel | Buy now |
| 58 | 7034821200 Rear housing | Buy now |
| 59 | 7034821300 Back, panel | Buy now |
| 60 | 7034827100 Arm, shift | Buy now |


Remote Control Assy



D2

| Ref | Part | |
|-----|--|-------------------------|
| 61 | 7034821101 Housing,1 | Buy now |
| 62 | 7034823200 Drive gear | Buy now |

Remote Control Box




67M0100-8280

D1

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 7034820517 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 7014832030 Cable, Remote Control L=14F UR | Buy now |
| 2 | 7014832040 Cable, Remote Control L=19F UR | Buy now |
| 2 | 7014832050 Cable, Remote Control L=15F UR | Buy now |
| 2 | 7014832060 Cable, Remote Control L=16F UR | Buy now |
| 2 | 7014832080 Cable, Remote Control L=17F UR | Buy now |
| 2 | 7014835000 Cable, Remote Control L=21F UR | Buy now |

Repair Kit 1




6D81100-D380

D7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D8W000100 Power head gasket kit | Buy now |
| 2 | 9321024M79 O-ring | Buy now |
| 3 | 67F1118102 Gasket, cylinder head 1 | Buy now |
| 4 | 9310238M59 Oil seal | Buy now |
| 5 | 9043014115 Gasket (663) | Buy now |
| 6 | 67F12435A0 Gasket | Buy now |
| 7 | 68V8575300 Gasket, sender unit | Buy now |
| 8 | 67F41114A1 Gasket, exhaust outer cover | Buy now |
| 9 | 9310248008 Oil seal | Buy now |
| 10 | 9310148001 Oil seal | Buy now |
| 11 | 9043018130 Gasket (1j7) | Buy now |
| 12 | 68V1135100 Gasket, cylinder | Buy now |
| 13 | 9321030682 O-ring (371) | Buy now |
| 14 | 6D81135600 Seal, cylinder 2 | Buy now |


Repair Kit 2



E1

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 67FW000121 Lower unit gasket kit | Buy now |
| 2 | 9043008020 Gasket | Buy now |
| 3 | 68844315A0 Gasket,water pump 1 | Buy now |
| 4 | 68844324A0 Gasket,cartridge Outer plate | Buy now |
| 5 | 9310125M03 Oil seal | Buy now |
| 6 | 9321046044 O-ring | Buy now |
| 7 | 68844316A0 Gasket,water pump 2 | Buy now |
| 8 | 9310609014 Oil seal | Buy now |
| 9 | 9321049046 O-ring (620) | Buy now |
| 10 | 9321007003 O-ring (11m) | Buy now |
| 11 | 9321086M39 O-ring (6e5) | Buy now |
| 12 | 9043014M09 Gasket | Buy now |
| 13 | 68V1531200 Gasket, oil pan | Buy now |
| 14 | 67F1341500 Seal, oil strainer | Buy now |
| 15 | 9321019MJ1 O-ring | Buy now |


Repair Kit 2



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67F41133A1 Gasket, exhaust manifold 1 | Buy now |
| 17 | 67F41134A0 Gasket, exhaust manifold | Buy now |
| 18 | 67F4113800 Seal, ext. 1 | Buy now |
| 19 | 67F4512700 Seal | Buy now |
| 20 | 67F4512300 Gasket, muffler | Buy now |
| 21 | 67F4511300 Gasket, upper casing | Buy now |
| 22 | 67FW007800 Water pump repair kit | Buy now |
| 23 | 67F4432200 Insert, cartridge | Buy now |
| 24 | 67F4435200 Impeller | Buy now |
| 26 | 67F4432300 Outer plate, cartridge | Buy now |
| 30 | 9011908M87 Bolt, with washer | Buy now |
| 31 | 9011908M13 Bolt, with washer(6h0) | Buy now |
| 32 | 9028004M04 Key, woodruff (688) | Buy now |

E1


Starting Motor



E1

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68V8180001 Starting motor assembly | Buy now |
| 2 | 67F8185000 Armature assembly | Buy now |
| 3 | 67F8181000 Stator assembly | Buy now |
| 4 | 68F8184000 Brush holder assembly | Buy now |
| 5 | 67F8180100 Brush set | Buy now |
| 6 | 67F8181300 Spring, brush | Buy now |
| 7 | 68F8182000 Rear bracket assembly | Buy now |
| 8 | 67F8180800 Pinion assembly | Buy now |
| 9 | 67F8185700 Pinion stopper set | Buy now |
| 10 | 67F8180700 Gear assembly, starting motor | Buy now |
| 11 | 67F8183200 Clutch, over run | Buy now |
| 12 | 67F8183600 Shaft, pinion | Buy now |
| 13 | 67F8182100 Bracket, center 1 | Buy now |
| 14 | 67F8184100 Bearing | Buy now |
| 15 | 67F8189100 Gear, ring | Buy now |


Starting Motor



E1

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67F8183R00 Gasket | Buy now |
| 17 | 67F8183000 Bracket, center 2 | Buy now |
| 18 | 60V8183T00 Gear, idler | Buy now |
| 19 | 67F8180900 Washer kit | Buy now |
| 20 | 67F8184200 Cover | Buy now |
| 21 | 67F8183900 Lever assembly | Buy now |
| 22 | 68V8194101 Starter relay assembly | Buy now |
| 23 | 67F8186900 Cover, dust | Buy now |
| 24 | 6K78182610 Bolt | Buy now |
| 25 | 67F8182800 Bolt 2 | Buy now |
| 26 | 67F8184600 Screw | Buy now |
| 27 | 9017908003 Nut | Buy now |
| 28 | 60V8192500 Terminal | Buy now |
| 29 | 68F8258200 Cover, wire harness | Buy now |
| 30 | 9701308045 Bolt | Buy now |


Starting Motor



| Ref | Part | |
|-----|--|-------------------------|
| 31 | 9290308600 Washer, plain (663) | Buy now |
| 32 | 9533308600 Nut(6l2) | Buy now |
| 33 | 9290308100 Ybs67-8 washer, spring | Buy now |
| 34 | 67F8362701 Label, caution 7 | Buy now |

E1


Steering 1



E5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 67GW0084144D Handle steering assembly AP | Buy now |
| 2 | 67G42111024D Handle, Steering | Buy now |
| 3 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 4 | 6644211900 Grip, steering handle | Buy now |
| 5 | 6G14217700 Rubber, handle | Buy now |
| 6 | 6H24213700 Indicator, throttle | Buy now |
| 7 | 9026902M09 Rivet(6l5) | Buy now |
| 8 | 9014905M13 Screw, countersunk | Buy now |
| 9 | 9290310600 Washer, plate | Buy now |
| 10 | 9050123215 Spring (655) | Buy now |
| 11 | 9038608032 Bushing (650) | Buy now |
| 12 | 63D4212600 Friction, steering handle grip | Buy now |
| 13 | 63D4815400 Knob, Throttle | Buy now |
| 14 | 9538006600 Nut(661) | Buy now |
| 15 | 9149020010 Pin, cotter | Buy now |


Steering 1



E5

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 67G4410010 Shift Link assembly | Buy now |
| 17 | 67G4410400 Plate Comp | Buy now |
| 18 | 67G4826100 Arm, Throttle | Buy now |
| 19 | 67G4211510 Shaft, Steering Handle | Buy now |
| 20 | 650421520094 Gear | Buy now |
| 21 | 9169030025 Pin, spring | Buy now |
| 22 | 67G4215900 Stay | Buy now |
| 23 | 67G4411300 Cam Plate, Handle | Buy now |
| 24 | 63D4823600 Roller, detent | Buy now |
| 25 | 63D4811900 Cover | Buy now |
| 26 | 67G4215300 Shaft, Throttle Control | Buy now |
| 27 | 67G4413200 Bushing | Buy now |
| 28 | 63D4823700 Adaptor | Buy now |
| 29 | 9878505014 Screw 3 | Buy now |
| 30 | 63D4823800 Spring, detent | Buy now |


Steering 1



E5

| Ref | Part | |
|-----|--|-------------------------|
| 31 | 9709508040 Bolt, hexagon | Buy now |
| 32 | 9299508600 Washer, plain (663) | Buy now |
| 33 | 9709506030 Bolt(jf7) | Buy now |
| 34 | 9299506600 Washer, plain (646) | Buy now |
| 35 | 9709506014 Bolt(gj3) | Buy now |
| 37 | 67G4832110 Cable | Buy now |
| 38 | 67G4853100 Bracket Remote Control 1 | Buy now |
| 40 | 9046810005 Pin, hair 6264123500 | Buy now |
| 41 | 67G2630110 Throttle cable assembly | Buy now |
| 42 | 66R4853800 Clamp, cable 1 | Buy now |
| 44 | 63D4853800 Clamp, cable 1 | Buy now |
| 46 | 67G44159004D Handle Gear Shift | Buy now |
| 47 | 67G4417300 Lever, Shift Control | Buy now |
| 48 | 9015906M18 Screw, with washer(6b0) | Buy now |
| 49 | 6G84419100 Indicator, shift | Buy now |


Steering 1




E5

| Ref | Part | |
|-----|--|-------------------------|
| 50 | 9038626MA3 Bush | Buy now |
| 51 | 67G4213100 Cover Handle Steering | Buy now |
| 52 | 9788506040 Screw pan head | Buy now |
| 54 | 9788506016 Screw, pan head(6b0) | Buy now |
| 56 | 63D4272500 Grommet | Buy now |
| 57 | 9033807180 Plug(1nl) | Buy now |
| 58 | 63D42121304D Bracket | Buy now |
| 59 | 9010112014 Bolt | Buy now |
| 60 | 9299012200 Ybs66-12 washer,plain | Buy now |
| 61 | 9020612M22 Washer, wave(6b0) | Buy now |
| 62 | 9038712M02 Collar(6b0) | Buy now |
| 63 | 9038612M93 Bush(6b0) | Buy now |
| 64 | 9299012600 Washer, plate(663) | Buy now |
| 65 | 9018512M12 Nut, self-locking(6e5) | Buy now |

Steering 2




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9044624M79 Hose AP | Buy now |
| 2 | 6K38355700 Tube AP | Buy now |
| 3 | 67G4273500 Protector AP | Buy now |
| 4 | 6888254011 Neutral switch assembly AP | Buy now |
| 5 | 67G8255401 Stay Neutral Switch AP | Buy now |
| 6 | 62Y8255500 Damper Main Switch 1 AP | Buy now |
| 7 | 9709506014 Bolt(gj3) AP | Buy now |
| 8 | 9299506600 Washer, plain (646) AP | Buy now |
| 9 | 67G8251050 Main Switch assembly AP | Buy now |
| 10 | 6768257700 Cap, key | Buy now |
| 11 | 63D8252E014D Cover, main switch 1 AP | Buy now |
| 12 | 63D8252F014D Cover, main switch 2 AP | Buy now |
| 13 | 63D2436700 Clamp, fuel pipe 2 AP | Buy now |
| 14 | 63D2436400 Stay AP | Buy now |
| 15 | 9709506025 Bolt AP | Buy now |



| Ref | Part | |
|-----|---|-------------------------|
| 17 | 9709506020 Bolt(7u8) AP | Buy now |
| 19 | 9709506030 Bolt(jf7) AP | Buy now |
| 21 | 69W8257500 Engine stop switch assembly AP | Buy now |
| 22 | 6828255600 Lanyard, stop switch | Buy now |
| 23 | 6898257Y00 Cap | Buy now |
| 24 | 9046513M11 Clamp (6e5) AP | Buy now |
| 25 | 67G8256300 Trim & tilt switch assembly AP | Buy now |
| 26 | 9788506016 Screw, pan head(6b0) AP | Buy now |
| 28 | 63D8372800 Connector assembly AP | Buy now |
| 29 | 9046513M24 Band, switch cord AP | Buy now |
| 30 | 9046513M30 Clamp AP | Buy now |
| 31 | 6H58355312 Wire, lead AP | Buy now |
| 32 | 63D8258601 Extension, wire harness AP | Buy now |
| 33 | 67G4272501 Grommet AP | Buy now |
| 34 | 6888338311 Buzzer AP | Buy now |

Steering 2




6D81100-D210

F1

| Ref | Part | |
|-----|---|-------------------------|
| 35 | 6H58338600 Buzzer Stay AP | Buy now |


Steering Friction



F3

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 67G4250800 Steering friction assembly AP | Buy now |
| 2 | 9011908M74 Bolt, with washer(61a) | Buy now |
| 3 | 9020108M01 Washer, plate(6l2) | Buy now |
| 4 | 67G4254100 Pipe 1 | Buy now |
| 5 | 67G4254600 Nut | Buy now |
| 6 | 63D4252700 Plate, friction | Buy now |
| 7 | 67G4254110 Pipe 1 | Buy now |
| 8 | 6824331801 Cover | Buy now |
| 9 | 9018510M14 Nut, self-locking | Buy now |
| 10 | 9020110M76 Washer, plate (6e5) | Buy now |
| 11 | 67G4252600 Plate Friction | Buy now |
| 12 | 9709508025 Bolt (62g) | Buy now |
| 13 | 9299508600 Washer, plain (663) | Buy now |
| 14 | 9018508057 Nut, nylon (6j8) | Buy now |
| 15 | 67G4256100 Knob, steering lock | Buy now |

Steering Friction




67F1100-2200

F3

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67G4256200 Shaft, steering lock | Buy now |
| 17 | 63D4252800 Plate, friction | Buy now |

Steering Guide




67F0010-9250

C7


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 67F6135000 Steering guide attachment kit AP | Buy now |
| 2 | 9020110M20 Washer, plate (663) | Buy now |
| 3 | 9018509M01 Nut, nylon (663) | Buy now |
| 4 | 9017009M03 Nut (689) | Buy now |
| 5 | 9038710M42 Coller (688) | Buy now |
| 6 | 9020110M63 Washer, plate | Buy now |
| 7 | 9010109M01 Bolt(62x) | Buy now |
| 8 | 6E54314501 Cap, clamp bracket | Buy now |
| 9 | 9321016275 O-ring | Buy now |

Top Cowling



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D942610004D Top Cowling assembly | Buy now |
| 2 | 67F4264700 Holder, clamp band | Buy now |
| 3 | 9299006100 Washer(6a1) | Buy now |
| 4 | 9538006600 Nut(661) | Buy now |
| 5 | 68V4265200 Hook | Buy now |
| 6 | 9709506012 Bolt(gh1) | Buy now |
| 7 | 9299506600 Washer, plain (646) | Buy now |
| 8 | 67F4264900 Holder, clamp band | Buy now |
| 9 | 67F4266200 Damper | Buy now |
| 10 | 67F42613004D Molding, air duct | Buy now |
| 11 | 9017906M24 Nut(6j8) | Buy now |
| 12 | 61N4262800 Seal | Buy now |
| 13 | 67F4261500 Seal | Buy now |
| 14 | 67F4267710 Graphic, front | Buy now |
| 15 | 6D94267800 Graphic, front | Buy now |


Top Cowling



A4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67FW007010 Graphic set | Buy now |
| 17 | 67F4268110 Mark, cowling | Buy now |
| 18 | 67F4268210 Mark, cowling | Buy now |
| 19 | 67F4262800 Seal | Buy now |
| 20 | 67F1343402 Label, Caution | Buy now |


Upper Casing



B5

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6D8411370094 Guide, exhaust | Buy now |
| 2 | 9757508540 Bolt, hexagon w/w deep recess | Buy now |
| 3 | 9360816M16 Pin, dowel(6t4) | Buy now |
| 4 | 6G14272700 Grommet | Buy now |
| 5 | 67F41131015B Manifold, ext. 1 | Buy now |
| 6 | 67F41133A1 Gasket, exhaust manifold 1 | Buy now |
| 7 | 9707506070 Bolt(4kg) | Buy now |
| 8 | 9299506600 Washer, plain (646) | Buy now |
| 9 | 67F14711005B Muffler 1 | Buy now |
| 10 | 9707506030 Bolt(jf7) | Buy now |
| 12 | 9707506050 Bolt(jf7) | Buy now |
| 14 | 9360619M23 Pin, dowel | Buy now |
| 15 | 67F41134A0 Gasket, exhaust manifold | Buy now |
| 16 | 67F45181005B Plate | Buy now |
| 17 | 67F4113800 Seal, ext. 1 | Buy now |


Upper Casing



B5


| Ref | Part | |
|-----|---|-------------------------|
| 18 | 67F4512700 Seal | Buy now |
| 19 | 67F4512300 Gasket, muffler | Buy now |
| 20 | 67F45111114D Casing, upper | Buy now |
| 21 | 9011910M08 Bolt, with washer | Buy now |
| 23 | 67F4531800 Bushing, drive shaft | Buy now |
| 24 | 9342036M01 Circlip (6a0) | Buy now |
| 25 | 67F4515100 Cover, upper casing | Buy now |
| 26 | 9788006016 Screw pan head | Buy now |
| 27 | 9299006600 Washer, plain (646) | Buy now |
| 28 | 67F4515500 Cap | Buy now |
| 29 | 67F4511300 Gasket, upper casing | Buy now |
| 30 | 9709508016 Bolt, hexagon deep recess | Buy now |
| 31 | 9299508100 Ybs67-8 washer, spring | Buy now |
| 32 | 9011908M58 Bolt, with washer | Buy now |
| 33 | 67F4272400 Grommet | Buy now |

Valve




| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68V1211100 Valve, intake | Buy now |
| 2 | 68V1212100 Valve, exhaust | Buy now |
| 3 | 67F1211600 Seat, valve spring | Buy now |
| 4 | 67F1211400 Spring, valve outer | Buy now |
| 5 | 67F1211700 Retainer, valve spring | Buy now |
| 6 | 67F1211800 Cotter, valve | Buy now |
| 7 | KOAA372100 Seal, valve stem | Buy now |
| 8 | KOAA372200 Seal, valve stem 2 | Buy now |
| 9 | 67F1215300 Lifter, valve | Buy now |
| 10 | 67F1216800 Pad, adjusting (2.000) UR | Buy now |
| 10 | 67F1216810 Pad, adjusting (2.025) UR | Buy now |
| 10 | 67F1216820 Pad, adjusting (2.050) UR | Buy now |
| 10 | 67F1216830 Pad, adjusting (2.075) UR | Buy now |
| 10 | 67F1216840 Pad, adjusting (2.100) UR | Buy now |
| 10 | 67F1216850 Pad, adjusting (2.125) UR | Buy now |

Valve




| Ref | Part | |
|-----|---|-------------------------|
| 10 | 67F1216860 Pad, adjusting (2.150) UR | Buy now |
| 10 | 67F1216870 Pad, adjusting (2.175) UR | Buy now |
| 10 | 67F1216880 Pad, adjusting (2.200) UR | Buy now |
| 10 | 67F12168A0 Pad, adjusting (2.225) UR | Buy now |
| 10 | 67F12168B0 Pad, adjusting (2.250) UR | Buy now |
| 10 | 67F12168C0 Pad, adjusting (2.275) UR | Buy now |
| 10 | 67F12168D0 Pad, adjusting (2.300) UR | Buy now |
| 10 | 67F12168E0 Pad, adjusting (2.325) UR | Buy now |
| 10 | 67F12168F0 Pad, adjusting (2.350) UR | Buy now |
| 10 | 67F12168G0 Pad, adjusting (2.375) UR | Buy now |
| 10 | 67F12168H0 Pad, adjusting (2.400) UR | Buy now |
| 10 | 67F12168J0 Pad, adjusting (2.425) UR | Buy now |
| 10 | 67F12168K0 Pad, adjusting (2.450) UR | Buy now |
| 10 | 67F12168L0 Pad, adjusting (2.475) UR | Buy now |
| 10 | 67F12168M0 Pad, adjusting (2.500) UR | Buy now |

Valve



| Ref | Part | |
|-----|---|-------------------------|
| 10 | 67F12168N0 Pad, adjusting (2.525) UR | Buy now |
| 10 | 67F12168P0 Pad, adjusting (2.550) UR | Buy now |
| 10 | 67F12168R0 Pad, adjusting (2.575) UR | Buy now |
| 10 | 67F12168S0 Pad, adjusting (2.600) UR | Buy now |
| 10 | 67F12168T0 Pad, adjusting (2.625) UR | Buy now |
| 10 | 67F12168U0 Pad, adjusting (2.650) UR | Buy now |
| 10 | 67F12168V0 Pad, adjusting (2.675) UR | Buy now |
| 10 | 67F12168W0 Pad, adjusting (2.700) UR | Buy now |
| 10 | 67F12168X0 Pad, adjusting (2.725) UR | Buy now |
| 10 | 67F12168Y0 Pad, adjusting (2.750) UR | Buy now |
| 11 | 67F1216900 Pad, adjusting (2.775) UR | Buy now |
| 11 | 67F1216910 Pad, adjusting (2.800) UR | Buy now |
| 11 | 67F1216920 Pad, adjusting (2.825) UR | Buy now |
| 11 | 67F1216930 Pad, adjusting (2.850) UR | Buy now |
| 11 | 67F1216940 Pad, adjusting (2.875) UR | Buy now |

Valve




6D81100-D050

B3


| Ref | Part | |
|-----|--|-------------------------|
| 11 | <u>67F1216950</u> Pad, adjusting (2.900) UR | Buy now |
| 11 | <u>67F1216960</u> Pad, adjusting (2.925) UR | Buy now |
| 11 | <u>67F1216970</u> Pad, adjusting (2.950) UR | Buy now |
| 11 | <u>67F1216980</u> Pad, adjusting (2.975) UR | Buy now |
| 11 | <u>67F12169A0</u> Pad, adjusting (3.000) UR | Buy now |
| 11 | <u>67F12169B0</u> Pad, adjusting (3.025) UR | Buy now |
| 11 | <u>67F12169C0</u> Pad, adjusting (3.050) UR | Buy now |
| 11 | <u>67F12169D0</u> Pad, adjusting (3.075) UR | Buy now |
| 11 | <u>67F12169E0</u> Pad, adjusting (3.100) UR | Buy now |
| 11 | <u>67F12169F0</u> Pad, adjusting (3.125) UR | Buy now |
| 11 | <u>67F12169G0</u> Pad, adjusting (3.150) UR | Buy now |
| 11 | <u>67F12169H0</u> Pad, adjusting (3.175) UR | Buy now |
| 11 | <u>67F12169J0</u> Pad, adjusting (3.200) UR | Buy now |
| 11 | <u>67F12169K0</u> Pad, adjusting (3.225) UR | Buy now |
| 11 | <u>67F12169L0</u> Pad, adjusting (3.250) UR | Buy now |

Valve



| Ref | Part | |
|-----|--|-------------------------|
| 11 | 67F12169M0 Pad, adjusting (3.275) UR | Buy now |
| 11 | 67F12169N0 Pad, adjusting (3.300) UR | Buy now |
| 12 | 6D91217100 Camshaft 1 | Buy now |
| 13 | 67F1218100 Camshaft 2 | Buy now |
| 14 | 9360510108 Pin, dowel (8g8) | Buy now |
| 15 | 67F1153700 Gear, driven | Buy now |
| 16 | 9011910M06 Bolt | Buy now |
| 17 | 67F4624100 Belt | Buy now |
| 18 | 67F1159000 Tensioner assembly | Buy now |
| 19 | 9050616M39 Spring, tension | Buy now |
| 20 | 9044515M03 Hose (I23) | Buy now |
| 21 | 67F1159500 Plate, valve | Buy now |
| 22 | 9011910M72 Bolt, with washer(6m6) | Buy now |
| 23 | 6D81153600 Gear, drive | Buy now |
| 24 | 9017040003 Nut | Buy now |

Valve



6D81100-D050

B3

| Ref | Part | |
|-----|---|-------------------------|
| 25 | 9028004008 Key woodruff 604115450000 | Buy now |
| 26 | 9310238M59 Oil seal | Buy now |

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.