



# Yamaha F20BMH 2018

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>SCHEDULED SERVICE PARTS</b>	3
<b>BOTTOM COWLING</b>	4
<b>BRACKET 1</b>	8
<b>BRACKET 2</b>	11
<b>BRACKET 3</b>	14
<b>CARBURETOR</b>	17
<b>CONTROL 1</b>	20
<b>CONTROL 2</b>	22
<b>CRANKSHAFT &amp; PISTON</b>	25
<b>CYLINDER &amp; CRANKCASE 1</b>	27
<b>CYLINDER &amp; CRANKCASE 2</b>	29
<b>ELECTRICAL 1</b>	31
<b>ELECTRICAL 2</b>	34
<b>ELECTRICAL 3</b>	36
<b>ELECTRICAL 4</b>	37
<b>ELECTRICAL 5</b>	39
<b>FUEL</b>	40
<b>FUEL TANK 1</b>	44
<b>FUEL TANK 2</b>	45
<b>GENERATOR</b>	46
<b>INTAKE</b>	47
<b>LOWER CASING &amp; DRIVE 1</b>	48
<b>LOWER CASING &amp; DRIVE 2</b>	53
<b>OIL PAN</b>	55
<b>OIL PUMP</b>	56
<b>POWER TILT ASSY</b>	58
<b>REMO CON ATTACHMENT</b>	63
<b>REMOTE CONTROL ASSY 1</b>	65
<b>REMOTE CONTROL ASSY 2</b>	69
<b>REMOTE CONTROL BOX</b>	74
<b>REPAIR KIT 1</b>	75
<b>REPAIR KIT 2</b>	77
<b>REPAIR KIT 3</b>	78
<b>STARTER</b>	80
<b>STARTING MOTOR</b>	83
<b>STEERING</b>	85
<b>STEERING FRICTION</b>	88
<b>STEERING GUIDE</b>	90
<b>TOP COWLING</b>	91
<b>UPPER CASING</b>	93
<b>VALVE</b>	95

## Scheduled Service Parts




Ref	Part	
1	<a href="#">6G81132500</a> Anode	<a href="#">Buy now</a>
2	<a href="#">6AH1241100</a> Thermostat	<a href="#">Buy now</a>
3	<a href="#">6AH1241400</a> Gasket, cover	<a href="#">Buy now</a>
5	<a href="#">6E51132500</a> Anode	<a href="#">Buy now</a>
6	<a href="#">5GH1344060</a> Element assembly, oil cleaner	<a href="#">Buy now</a>
8	<a href="#">9470200418</a> Plug, spark (dpr6eb-9)	<a href="#">Buy now</a>
9	<a href="#">61N2456310</a> Element, filter	<a href="#">Buy now</a>
10	<a href="#">9321032738</a> O-ring(1wg)	<a href="#">Buy now</a>
11	<a href="#">65W4525100</a> Anode	<a href="#">Buy now</a>
12	<a href="#">9043014M09</a> Gasket	<a href="#">Buy now</a>
13	<a href="#">9043008003</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">6AH4525100</a> Anode	<a href="#">Buy now</a>
15	<a href="#">6AHW007800</a> Water pump repair kit	<a href="#">Buy now</a>

## Bottom Cowling




Ref	Part	
1	<a href="#">6AH42710008D</a> Bottom cowling assembly	<a href="#">Buy now</a>
1	<a href="#">6AH42710108D</a> Bottom cowling assembly	<a href="#">Buy now</a>
2	<a href="#">68F8511900</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">9048021M82</a> Grommet	<a href="#">Buy now</a>
4	<a href="#">9038706176</a> Collar	<a href="#">Buy now</a>
5	<a href="#">6AH4271600</a> Rubber, seal 1	<a href="#">Buy now</a>
6	<a href="#">6AH42738008D</a> Plate, fitting	<a href="#">Buy now</a>
7	<a href="#">6AH4271800</a> Rubber, seal 3	<a href="#">Buy now</a>
8	<a href="#">9010906M82</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">6AH4272500</a> Grommet	<a href="#">Buy now</a>
9	<a href="#">6AH4272510</a> Grommet	<a href="#">Buy now</a>
9	<a href="#">6AH4272520</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">6AH4272400</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">6AH4272410</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">6AH4280100</a> Cowling clamp comp.	<a href="#">Buy now</a>

# Bottom Cowling




Ref	Part	
12	<a href="#">9759506512</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
13	<a href="#">6BL4439100</a> Nipple, hose	<a href="#">Buy now</a>
14	<a href="#">6AH2632600</a> Grommet	<a href="#">Buy now</a>
14	<a href="#">6AH2632610</a> Grommet	<a href="#">Buy now</a>
15	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
16	<a href="#">6AH4272700</a> Grommet	<a href="#">Buy now</a>
17	<a href="#">65W4272600</a> Grommet	<a href="#">Buy now</a>
17	<a href="#">65W4272610</a> Grommet	<a href="#">Buy now</a>
18	<a href="#">9048016007</a> Grommet	<a href="#">Buy now</a>
19	<a href="#">6AH4272600</a> Grommet	<a href="#">Buy now</a>
20	<a href="#">6AH2431401</a> Pipe 4	<a href="#">Buy now</a>
21	<a href="#">9044515003</a> Hose (I230)	<a href="#">Buy now</a>
23	<a href="#">6DR1257200</a> Adapter	<a href="#">Buy now</a>
24	<a href="#">6R31258100</a> Joint, hose 1	<a href="#">Buy now</a>
25	<a href="#">6R31258200</a> Joint, hose 2	<a href="#">Buy now</a>

# Bottom Cowling




Ref	Part	
26	<a href="#">6R31258300</a> Gasket, hose joint	<a href="#">Buy now</a>
27	<a href="#">6AH1253500</a> Plate	<a href="#">Buy now</a>
28	<a href="#">9016706002</a> Screw, tapping	<a href="#">Buy now</a>
29	<a href="#">9759506510</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
30	<a href="#">9046412M58</a> Clamp	<a href="#">Buy now</a>
31	<a href="#">65W4271700</a> Rubber, seal 2	<a href="#">Buy now</a>
32	<a href="#">6AH4274300</a> Bracket	<a href="#">Buy now</a>
33	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>
34	<a href="#">6AH42761A0</a> Stopper	<a href="#">Buy now</a>
35	<a href="#">6AH42762A0</a> Stopper	<a href="#">Buy now</a>
36	<a href="#">9707506012</a> Bolt(gh1)	<a href="#">Buy now</a>
37	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
38	<a href="#">6AH4274100</a> Apron	<a href="#">Buy now</a>
39	<a href="#">9788506030</a> Screw, pan head(6e0)	<a href="#">Buy now</a>
40	<a href="#">9299506100</a> Washer(6a1)	<a href="#">Buy now</a>

# Bottom Cowling




Ref	Part	
42	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
43	<a href="#">6AH4271700</a> Rubber, seal 2	<a href="#">Buy now</a>
44	<a href="#">6AH1577400</a> Stay 4	<a href="#">Buy now</a>
46	<a href="#">9046508M82</a> Clamp	<a href="#">Buy now</a>
47	<a href="#">6EE4279440</a> Label, warning (general)	<a href="#">Buy now</a>
48	<a href="#">6EE4279450</a> Label, warning (general)	<a href="#">Buy now</a>

## Bracket 1




Ref	Part	
1	<a href="#">6AH4311008D</a> Bracket, clamp 1	<a href="#">Buy now</a>
2	<a href="#">6E04311801</a> Handle, transom clamp	<a href="#">Buy now</a>
3	<a href="#">9024304M01</a> Pin(6a1)	<a href="#">Buy now</a>
4	<a href="#">6E74311600</a> Screw, transom clamp	<a href="#">Buy now</a>
5	<a href="#">6484311401</a> Pad, transom clamp	<a href="#">Buy now</a>
6	<a href="#">6AH43112008D</a> Bracket, clamp 2	<a href="#">Buy now</a>
11	<a href="#">69A4313100</a> Bolt, clamp bracket <b>FOR REMOTE CONTROL</b>	<a href="#">Buy now</a>
12	<a href="#">9038622MA4</a> Bush	<a href="#">Buy now</a>
13	<a href="#">66R4311300</a> Plate, clamp bracket	<a href="#">Buy now</a>
14	<a href="#">9018522043</a> Nut, self-locking	<a href="#">Buy now</a>
15	<a href="#">9038706M13</a> Collar(6h6)	<a href="#">Buy now</a>
16	<a href="#">9010106M18</a> Bolt(6l5)	<a href="#">Buy now</a>
17	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">9538006700</a> Nut	<a href="#">Buy now</a>
19	<a href="#">6L24316001</a> Tilt rod assembly	<a href="#">Buy now</a>

## Bracket 1




Ref	Part	
20	<a href="#">6894316500</a> Plate, tilt lock	<a href="#">Buy now</a>
21	<a href="#">9169030008</a> Pin. spring(656)	<a href="#">Buy now</a>
22	<a href="#">9050210M07</a> Spring, conical(6k3)	<a href="#">Buy now</a>
23	<a href="#">6AH43311008D</a> Bracket, swivel 1 S(17.1")	<a href="#">Buy now</a>
23	<a href="#">6AH43311108D</a> Bracket, swivel 1 L(22.1")	<a href="#">Buy now</a>
24	<a href="#">6DR4363100</a> Lever, tilt	<a href="#">Buy now</a>
25	<a href="#">6DR4361600</a> Rod, tilt lock	<a href="#">Buy now</a>
26	<a href="#">6AH4364610</a> Shaft, lever	<a href="#">Buy now</a>
27	<a href="#">6DR4364100</a> Lever, tilt	<a href="#">Buy now</a>
28	<a href="#">6AH4319110</a> Shaft, stopper	<a href="#">Buy now</a>
29	<a href="#">9908005600</a> Circlip(22k)	<a href="#">Buy now</a>
30	<a href="#">6AH4361700</a> Rod, tilt lock	<a href="#">Buy now</a>
32	<a href="#">6AH4335000</a> Receiver assembly	<a href="#">Buy now</a>
33	<a href="#">9050618014</a> Spring, tension	<a href="#">Buy now</a>
34	<a href="#">6AH4361400</a> Plate, tilt lock	<a href="#">Buy now</a>

## Bracket 1



Ref	Part	
35	<a href="#">9050620020</a> Spring, tension	<a href="#">Buy now</a>
36	<a href="#">6AH4361500</a> Plate, tilt lock	<a href="#">Buy now</a>
37	<a href="#">68T4361100</a> Shaft, tilt lock	<a href="#">Buy now</a>
38	<a href="#">9038706138</a> Collar	<a href="#">Buy now</a>
39	<a href="#">9343004M03</a> Circlip (eu0)	<a href="#">Buy now</a>
40	<a href="#">68T4365900</a> Shaft, reverse lock	<a href="#">Buy now</a>
42	<a href="#">6AH4362700</a> Stopper	<a href="#">Buy now</a>
43	<a href="#">9010906M84</a> Bolt	<a href="#">Buy now</a>
44	<a href="#">9020610M24</a> Washer, wave	<a href="#">Buy now</a>


## Bracket 2



 6AGB100-Q240

Ref	Part	
1	<a href="#">69A43111018D</a> Bracket, clamp 1	<a href="#">Buy now</a>
2	<a href="#">6E04311801</a> Handle, transom clamp	<a href="#">Buy now</a>
3	<a href="#">9024304M01</a> Pin(6a1)	<a href="#">Buy now</a>
4	<a href="#">6E74311600</a> Screw, transom clamp	<a href="#">Buy now</a>
5	<a href="#">6484311401</a> Pad, transom clamp	<a href="#">Buy now</a>
6	<a href="#">69A43112028D</a> Bracket, clamp 2	<a href="#">Buy now</a>
11	<a href="#">9038622MA4</a> Bush	<a href="#">Buy now</a>
12	<a href="#">9018522043</a> Nut, self-locking	<a href="#">Buy now</a>
13	<a href="#">65W4319200</a> Knob, stopper	<a href="#">Buy now</a>
14	<a href="#">65W4319100</a> Shaft, stopper	<a href="#">Buy now</a>
15	<a href="#">9169030018</a> 926-51502-00 pin, spring (700)	<a href="#">Buy now</a>
16	<a href="#">9038614MA1</a> Bush	<a href="#">Buy now</a>
17	<a href="#">9010906MA1</a> Bolt	<a href="#">Buy now</a>
18	<a href="#">69A43311118D</a> Bracket, swivel 1 L(22.1")	<a href="#">Buy now</a>
18	<a href="#">6AH43311208D</a> Bracket, swivel 1 S(17.1")	<a href="#">Buy now</a>

## Bracket 2




6A9B100-Q310

6AGB100-Q240

Ref	Part	
19	<u>69A4313100</u> Bolt, clamp bracket <b>FOR REMOTE CONTROL</b>	<a href="#">Buy now</a>
20	<u>69A4311300</u> Plate, clamp bracket	<a href="#">Buy now</a>
21	<u>6G54314501</u> Cap, clamp bracket	<a href="#">Buy now</a>
22	<u>9044614MH7</u> Hose	<a href="#">Buy now</a>
23	<u>69A4315500</u> Mark 1	<a href="#">Buy now</a>
24	<u>9046513M97</u> Clamp	<a href="#">Buy now</a>
25	<u>69G4381800</u> Pin, lower shock mount	<a href="#">Buy now</a>
26	<u>9038616MA7</u> Bush	<a href="#">Buy now</a>
27	<u>9038616MA8</u> Bush	<a href="#">Buy now</a>
28	<u>9038716M02</u> Collar	<a href="#">Buy now</a>
29	<u>9020108M00</u> Washer, plate(6e0)	<a href="#">Buy now</a>
30	<u>9708008016</u> Bolt	<a href="#">Buy now</a>
31	<u>9024912M36</u> Pin	<a href="#">Buy now</a>
32	<u>9038112M10</u> Bush, solid	<a href="#">Buy now</a>
33	<u>9038112M11</u> Bush, solid	<a href="#">Buy now</a>


## Bracket 2



6AGB100-Q240


Ref	Part	
34	<a href="#">9908010600</a> Circlip	<a href="#">Buy now</a>
35	<a href="#">9011008081</a> Bolt, hexagon socket head	<a href="#">Buy now</a>
36	<a href="#">9018508057</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
37	<a href="#">9299008600</a> Washer, plain (663)	<a href="#">Buy now</a>
38	<a href="#">9033808M19</a> Plug <b>S(17.1")</b>	<a href="#">Buy now</a>
39	<a href="#">65W4525100</a> Anode	<a href="#">Buy now</a>
40	<a href="#">9010106020</a> Bolt	<a href="#">Buy now</a>
41	<a href="#">63V8212700</a> Wire, lead 2	<a href="#">Buy now</a>
42	<a href="#">9759506510</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>

## Bracket 3




Ref	Part	
1	<a href="#">6AH42510008D</a> Steering bracket assembly S(17.1")	<a href="#">Buy now</a>
1	<a href="#">6AH42510108D</a> Steering bracket assembly L(22.1")	<a href="#">Buy now</a>
2	<a href="#">9020940008</a> Washer	<a href="#">Buy now</a>
3	<a href="#">9038640001</a> Bush	<a href="#">Buy now</a>
4	<a href="#">9038630048</a> Bush	<a href="#">Buy now</a>
5	<a href="#">9321029M94</a> O-ring(6h1)	<a href="#">Buy now</a>
6	<a href="#">9038630M60</a> Bush(6j8)	<a href="#">Buy now</a>
7	<a href="#">9011610033</a> Bolt, stud	<a href="#">Buy now</a>
8	<a href="#">6AH4451400</a> Mount damper, upper side	<a href="#">Buy now</a>
9	<a href="#">6AH4452600</a> Plate	<a href="#">Buy now</a>
10	<a href="#">9538010600</a> Nut(624)	<a href="#">Buy now</a>
11	<a href="#">9011908094</a> Bolt, with washer	<a href="#">Buy now</a>
12	<a href="#">6AH44551A08D</a> Housing, lower mount rubber 1	<a href="#">Buy now</a>
13	<a href="#">6AH4455700</a> Mount damper, lower front	<a href="#">Buy now</a>
14	<a href="#">6AH4455500</a> Mount damper, lower side	<a href="#">Buy now</a>

## Bracket 3




Ref	Part	
15	<a href="#">6AH4457400</a> Stopper, lower mount rubber	<a href="#">Buy now</a>
16	<a href="#">9011908M45</a> Bolt, with washer	<a href="#">Buy now</a>
17	<a href="#">9011908M46</a> Bolt, with washer	<a href="#">Buy now</a>
18	<a href="#">9017908M34</a> Nut	<a href="#">Buy now</a>
19	<a href="#">9370006M03</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
20	<a href="#">6AH8212700</a> Wire, lead 2 EP-S(17.1")	<a href="#">Buy now</a>
20	<a href="#">6AH8212711</a> Wire, lead 2 L(22.1")	<a href="#">Buy now</a>
21	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>
22	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
23	<a href="#">6AH42532B0</a> Cover	<a href="#">Buy now</a>
24	<a href="#">9011106072</a> Bolt,hex. socket button	<a href="#">Buy now</a>
25	<a href="#">9778060520</a> Screw, tapping(6k8)	<a href="#">Buy now</a>
26	<a href="#">6AH8377300</a> Bracket, switch	<a href="#">Buy now</a>
27	<a href="#">9759506530</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
28	<a href="#">6AH4851101</a> Hook, steering	<a href="#">Buy now</a>

## Bracket 3




# Carburetor




Ref	Part	
1	<a href="#">6AG14301J0</a> Carburetor assembly 1 <b>F15C</b>	<a href="#">Buy now</a>
1	<a href="#">6AG14301K0</a> Carburetor assembly 1 <b>F15C</b>	<a href="#">Buy now</a>
1	<a href="#">6AH14301B0</a> Carburetor assembly 1 <b>F20B</b>	<a href="#">Buy now</a>
1	<a href="#">6AH14301F0</a> Carburetor assembly 1 <b>F20B</b>	<a href="#">Buy now</a>
2	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
3	<a href="#">65W1457200</a> Plate	<a href="#">Buy now</a>
4	<a href="#">65W1412610</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">9798004110</a> Screw, pan head (e56)	<a href="#">Buy now</a>
6	<a href="#">6761494805</a> Jet (#45) <b>FOR 6AH-14301-F0</b>	<a href="#">Buy now</a>
6	<a href="#">6AG1494802</a> Jet (#38) <b>FOR 6AG-14301-J0</b>	<a href="#">Buy now</a>
6	<a href="#">6AG1494805</a> Jet (#45) <b>FOR 6AH-14301-B0</b>	<a href="#">Buy now</a>
6	<a href="#">6AH1494802</a> Jet (#38) <b>FOR 6AG-14301-K0</b>	<a href="#">Buy now</a>
7	<a href="#">6791496600</a> Rubber cap	<a href="#">Buy now</a>
8	<a href="#">9050110326</a> Spring coil(663)(carb)	<a href="#">Buy now</a>
9	<a href="#">63V1452300</a> Screw, stop	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
10	<a href="#">6AH1494700</a> Jet, needle <b>F20B</b>	<a href="#">Buy now</a>
10	<a href="#">6AH1494710</a> Jet, needle <b>F15C</b>	<a href="#">Buy now</a>
11	<a href="#">65W1494329</a> Jet, main (#112) <b>F20B</b>	<a href="#">Buy now</a>
11	<a href="#">6761494319</a> Jet, main (#80) <b>F15C</b>	<a href="#">Buy now</a>
12	<a href="#">6AH1498500</a> Float	<a href="#">Buy now</a>
13	<a href="#">6AH1454600</a> Valve, needle	<a href="#">Buy now</a>
14	<a href="#">6331415900</a> Clip	<a href="#">Buy now</a>
15	<a href="#">9858004008</a> Screw, pan head (713)	<a href="#">Buy now</a>
16	<a href="#">6H41454800</a> Pin, float arm	<a href="#">Buy now</a>
17	<a href="#">65W1437302</a> Cover, plunger cap	<a href="#">Buy now</a>
18	<a href="#">6AH1437900</a> Rod, starter <b>F15C</b>	<a href="#">Buy now</a>
18	<a href="#">6AH1437910</a> Rod, starter <b>F20B</b>	<a href="#">Buy now</a>
19	<a href="#">6AH1492320</a> Screw, pilot	<a href="#">Buy now</a>
20	<a href="#">67F1439810</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">67C1455500</a> Spring	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
22	<a href="#">65W1433500</a> Spring, plunger <b>F15C</b>	<a href="#">Buy now</a>
22	<a href="#">6AH1433500</a> Spring, plunger <b>F20B</b>	<a href="#">Buy now</a>
23	<a href="#">6AH1437100</a> Plunger, starter	<a href="#">Buy now</a>
24	<a href="#">6AH1438400</a> Gasket, float chamber	<a href="#">Buy now</a>
25	<a href="#">6AH1498000</a> Body, float chamber	<a href="#">Buy now</a>
26	<a href="#">65W1439800</a> Washer	<a href="#">Buy now</a>
27	<a href="#">65W1499200</a> Screw, drain	<a href="#">Buy now</a>
28	<a href="#">9798004114</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
29	<a href="#">6AH1438001</a> Prime starter assembly <b>M-SPEC</b>	<a href="#">Buy now</a>
29	<a href="#">6AH1438011</a> Prime starter assembly <b>E-SPEC</b>	<a href="#">Buy now</a>
30	<a href="#">9798004108</a> Screw, with washer(6m6)	<a href="#">Buy now</a>
31	<a href="#">6AH1434600</a> Plate	<a href="#">Buy now</a>
32	<a href="#">67C1456700</a> Screw	<a href="#">Buy now</a>
33	<a href="#">65W1434600</a> Plate	<a href="#">Buy now</a>
34	<a href="#">65W1439G00</a> Clip 1	<a href="#">Buy now</a>

# Control 1




Ref	Part	
1	<a href="#">6AH4412300</a> Arm, shift rod	<a href="#">Buy now</a>
2	<a href="#">9025403M05</a> Pin, spring	<a href="#">Buy now</a>
3	<a href="#">6AH4412101</a> Lever, shift rod	<a href="#">Buy now</a>
4	<a href="#">6AH2636400</a> End, cable 2	<a href="#">Buy now</a>
5	<a href="#">6G1416620194</a> Bracket	<a href="#">Buy now</a>
6	<a href="#">9759506520</a> Bolt(7u8)	<a href="#">Buy now</a>
7	<a href="#">6AH4412500</a> Lever, shift rod	<a href="#">Buy now</a>
9	<a href="#">65W4411600</a> Spring	<a href="#">Buy now</a>
10	<a href="#">66R4411400</a> Stopper	<a href="#">Buy now</a>
11	<a href="#">9589506014</a> Bolt, flange deep recess	<a href="#">Buy now</a>
12	<a href="#">6AH4414300</a> Rod, shift <b>S(17.1")</b>	<a href="#">Buy now</a>
12	<a href="#">6AH4414310</a> Rod, shift <b>L(22.1")</b>	<a href="#">Buy now</a>
13	<a href="#">9017006015</a> Connector, shift rod	<a href="#">Buy now</a>
14	<a href="#">9538006700</a> Nut	<a href="#">Buy now</a>
15	<a href="#">6AH4163800</a> Pulley	<a href="#">Buy now</a>

# Control 1




Ref	Part	
16	<a href="#">9050820M44</a> Spring, torsion	<a href="#">Buy now</a>
17	<a href="#">65W4128300</a> Lever, free accel.	<a href="#">Buy now</a>
18	<a href="#">6J84126200</a> Joint, choke lever	<a href="#">Buy now</a>
19	<a href="#">6AH4121100</a> Link, accel.	<a href="#">Buy now</a>
20	<a href="#">9038706139</a> Collar	<a href="#">Buy now</a>
21	<a href="#">9020106M31</a> Washer (6a0)	<a href="#">Buy now</a>
22	<a href="#">9759506555</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
23	<a href="#">9709506014</a> Bolt(gj3)	<a href="#">Buy now</a>
24	<a href="#">6AH1457100</a> Bracket, throttle	<a href="#">Buy now</a>
25	<a href="#">6AH4416710</a> Plunger, shift cam	<a href="#">Buy now</a>
26	<a href="#">62Y4217100</a> Bushing	<a href="#">Buy now</a>
27	<a href="#">9020105M04</a> Washer, plate	<a href="#">Buy now</a>
28	<a href="#">9046810005</a> Pin, hair 6264123500	<a href="#">Buy now</a>
29	<a href="#">6AH1449700</a> Stay, throttle wire	<a href="#">Buy now</a>
30	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>

## Control 2




Ref	Part	
1	<a href="#">6AH4412300</a> Arm, shift rod	<a href="#">Buy now</a>
2	<a href="#">9025403M05</a> Pin, spring	<a href="#">Buy now</a>
3	<a href="#">6AH4412101</a> Lever, shift rod	<a href="#">Buy now</a>
4	<a href="#">6AH2636400</a> End, cable 2	<a href="#">Buy now</a>
5	<a href="#">6G1416620194</a> Bracket	<a href="#">Buy now</a>
6	<a href="#">9759506520</a> Bolt(7u8)	<a href="#">Buy now</a>
7	<a href="#">6AH4412500</a> Lever, shift rod	<a href="#">Buy now</a>
9	<a href="#">65W4411600</a> Spring	<a href="#">Buy now</a>
10	<a href="#">66R4411400</a> Stopper	<a href="#">Buy now</a>
11	<a href="#">9589506014</a> Bolt, flange deep recess	<a href="#">Buy now</a>
12	<a href="#">6AH4414300</a> Rod, shift <b>S(17.1")</b>	<a href="#">Buy now</a>
12	<a href="#">6AH4414310</a> Rod, shift <b>L(22.1")</b>	<a href="#">Buy now</a>
13	<a href="#">9017006015</a> Connector, shift rod	<a href="#">Buy now</a>
14	<a href="#">9538006700</a> Nut	<a href="#">Buy now</a>
15	<a href="#">6AH4853200</a> Bracket, remote control 2	<a href="#">Buy now</a>

## Control 2




Ref	Part	
16	<a href="#">9048019031</a> Grommet(75v)	<a href="#">Buy now</a>
17	<a href="#">6824853850</a> Clamp, cable	<a href="#">Buy now</a>
18	<a href="#">9169030012</a> Pin, spring	<a href="#">Buy now</a>
19	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>
20	<a href="#">6FM4834400</a> Cable end, remote control	<a href="#">Buy now</a>
21	<a href="#">9046818008</a> Clip 620436610000	<a href="#">Buy now</a>
22	<a href="#">6AH4163800</a> Pulley	<a href="#">Buy now</a>
23	<a href="#">9050820M44</a> Spring, torsion	<a href="#">Buy now</a>
24	<a href="#">65W4128300</a> Lever, free accel.	<a href="#">Buy now</a>
25	<a href="#">6J84126200</a> Joint, choke lever	<a href="#">Buy now</a>
26	<a href="#">6AH4121100</a> Link, accel.	<a href="#">Buy now</a>
27	<a href="#">9038706139</a> Collar	<a href="#">Buy now</a>
28	<a href="#">9020106M31</a> Washer (6a0)	<a href="#">Buy now</a>
29	<a href="#">9759506555</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
30	<a href="#">9709506014</a> Bolt(gj3)	<a href="#">Buy now</a>

## Control 2



Ref	Part	
31	<a href="#">6AH1457100</a> Bracket, throttle	<a href="#">Buy now</a>
32	<a href="#">6AH4853100</a> Bracket, remote control 1	<a href="#">Buy now</a>
33	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>

# Crankshaft & Piston




6AH100-F030


Ref	Part	
1	<a href="#">6AH1141100</a> Crankshaft	<a href="#">Buy now</a>
2	<a href="#">6AH1141600</a> Plane bearing, crankshaft 1 <b>UR BROWN</b>	<a href="#">Buy now</a>
2	<a href="#">6AH1141610</a> Plane bearing, crankshaft 1 <b>UR BLACK</b>	<a href="#">Buy now</a>
2	<a href="#">6AH1141620</a> Plane bearing, crankshaft 1 <b>UR BLUE</b>	<a href="#">Buy now</a>
3	<a href="#">6AH1165010</a> Connecting rod assembly	<a href="#">Buy now</a>
4	<a href="#">6AH1165400</a> Bolt, connecting rod	<a href="#">Buy now</a>
5	<a href="#">6AH1163100</a> Piston (std)	<a href="#">Buy now</a>
5	<a href="#">6AH1163500</a> Piston (0.25mm o/s) <b>AP</b>	<a href="#">Buy now</a>
5	<a href="#">6AH1163600</a> Piston (0.50mm o/s) <b>AP</b>	<a href="#">Buy now</a>
6	<a href="#">6AH1160300</a> Piston ring set (std)	<a href="#">Buy now</a>
6	<a href="#">6AH1160400</a> Piston ring set (0.25mm o/s) <b>AP</b>	<a href="#">Buy now</a>
6	<a href="#">6AH1160500</a> Piston ring set (0.50mm o/s) <b>AP</b>	<a href="#">Buy now</a>
7	<a href="#">1371163310</a> Pin, piston	<a href="#">Buy now</a>
8	<a href="#">9345017129</a> Circlip(1ar)	<a href="#">Buy now</a>
9	<a href="#">9310237004</a> Oil seal	<a href="#">Buy now</a>

## Crankshaft & Piston

Ref	Part	
10	<a href="#">9310225014</a> Oil seal	<a href="#">Buy now</a>




# Cylinder & Crankcase 1



6AGD100-S030

Ref	Part	
1	<a href="#">6AHW009B021S</a> Cylinder block assembly	<a href="#">Buy now</a>
2	<a href="#">6AH1510000</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">9360612019</a> Pin, dowel (614)	<a href="#">Buy now</a>
4	<a href="#">9011908093</a> Bolt, with washer	<a href="#">Buy now</a>
5	<a href="#">9701306040</a> Bolt (682)	<a href="#">Buy now</a>
6	<a href="#">9290306600</a> Washer, plain (646)	<a href="#">Buy now</a>
7	<a href="#">6AH1135110</a> Gasket, cylinder	<a href="#">Buy now</a>
8	<a href="#">6AH41113011S</a> Outer cover, exhaust	<a href="#">Buy now</a>
9	<a href="#">6E92437800</a> Pipe, Joint 4	<a href="#">Buy now</a>
10	<a href="#">6H11137200</a> Nipple, hose	<a href="#">Buy now</a>
11	<a href="#">6G81132500</a> Anode	<a href="#">Buy now</a>
12	<a href="#">9898005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
13	<a href="#">6G811197A0</a> Plug, blind	<a href="#">Buy now</a>
14	<a href="#">9321013M63</a> O-ring (6g8)	<a href="#">Buy now</a>
15	<a href="#">6AH4111400</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>


# Cylinder & Crankcase 1



6AGD100-S030


Ref	Part	
16	<a href="#">9011906MA3</a> Bolt, with washer	<a href="#">Buy now</a>
17	<a href="#">6AH1241100</a> Thermostat	<a href="#">Buy now</a>
18	<a href="#">6881241200</a> Seal, thermostat	<a href="#">Buy now</a>
19	<a href="#">6AH12413001S</a> Cover, thermostat	<a href="#">Buy now</a>
20	<a href="#">6AH1241400</a> Gasket, cover	<a href="#">Buy now</a>
24	<a href="#">6AH1248100</a> Pipe 1	<a href="#">Buy now</a>
25	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
26	<a href="#">6E51132500</a> Anode	<a href="#">Buy now</a>
27	<a href="#">9878004016</a> Screw, flat head(ga5)	<a href="#">Buy now</a>
28	<a href="#">5GH1344060</a> Element assembly, oil cleaner	<a href="#">Buy now</a>
29	<a href="#">6C51285800</a> Bolt, union	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
1	<a href="#">6AHW009A011S</a> Cylinder head complete	<a href="#">Buy now</a>
2	<a href="#">6AH1111101S</a> Head, cylinder 1	<a href="#">Buy now</a>
3	<a href="#">6AH1113310</a> Guide, valve 1	<a href="#">Buy now</a>
4	<a href="#">6AG1118110</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
5	<a href="#">9360612019</a> Pin, dowel (614)	<a href="#">Buy now</a>
6	<a href="#">9010509006</a> Bolt, flange	<a href="#">Buy now</a>
7	<a href="#">9011906MA3</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">6AH11191001S</a> Cover, cylinder head 1	<a href="#">Buy now</a>
9	<a href="#">6AH1137200</a> Nipple, hose	<a href="#">Buy now</a>
10	<a href="#">6AH1135600</a> Seal, cylinder 2	<a href="#">Buy now</a>
11	<a href="#">9759506520</a> Bolt(7u8)	<a href="#">Buy now</a>
12	<a href="#">6AH1116800</a> Cover, breather	<a href="#">Buy now</a>
13	<a href="#">6AH1116900</a> Gasket, breather cover	<a href="#">Buy now</a>
14	<a href="#">9760704210</a> Screw, pan head with washer	<a href="#">Buy now</a>
15	<a href="#">6G81132500</a> Anode	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
16	<a href="#">9898005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
17	<a href="#">6G811197A0</a> Plug, blind	<a href="#">Buy now</a>
18	<a href="#">9321013M63</a> O-ring (6g8)	<a href="#">Buy now</a>
19	<a href="#">6G81536300</a> Plug, oil	<a href="#">Buy now</a>
20	<a href="#">9321024M79</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">9046508059</a> Clamp	<a href="#">Buy now</a>
22	<a href="#">9470200418</a> Plug, spark (dpr6eb-9)	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
1	<a href="#">6AH8554000</a> C.d.i. unit assembly <b>F15C</b>	<a href="#">Buy now</a>
1	<a href="#">6AH8554010</a> C.d.i. unit assembly <b>F20B</b>	<a href="#">Buy now</a>
2	<a href="#">9759506520</a> Bolt(7u8)	<a href="#">Buy now</a>
3	<a href="#">9709506030</a> Bolt(jf7)	<a href="#">Buy now</a>
4	<a href="#">9038706M74</a> Collar	<a href="#">Buy now</a>
5	<a href="#">6AH8194800</a> Bracket	<a href="#">Buy now</a>
6	<a href="#">9046513M18</a> Clamp	<a href="#">Buy now</a>
7	<a href="#">9011906M88</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">9038706289</a> Collar	<a href="#">Buy now</a>
9	<a href="#">9048010M23</a> Grommet(6k7)	<a href="#">Buy now</a>
10	<a href="#">6AH8252200</a> Clamp, coupler	<a href="#">Buy now</a>
11	<a href="#">9788006010</a> Screw pan head	<a href="#">Buy now</a>
12	<a href="#">9020106M05</a> Washer, plate(6e3)	<a href="#">Buy now</a>
13	<a href="#">6F58557013</a> Ignition coil assembly	<a href="#">Buy now</a>
14	<a href="#">9048025003</a> Grommet	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
15	<a href="#">67F8236100</a> Clamp, cord	<a href="#">Buy now</a>
16	<a href="#">9759506525</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
17	<a href="#">6AH8237000</a> Plug cap assembly	<a href="#">Buy now</a>
18	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>
19	<a href="#">6AH8554200</a> Bracket	<a href="#">Buy now</a>
20	<a href="#">9046407M56</a> Clamp	<a href="#">Buy now</a>
21	<a href="#">64J8250400</a> Oil pressure switch assembly	<a href="#">Buy now</a>
22	<a href="#">62Y8430100</a> Pilot light assembly 1	<a href="#">Buy now</a>
23	<a href="#">6FM8358900</a> Gasket	<a href="#">Buy now</a>
24	<a href="#">9798506212</a> Screw, with washer(6h3)	<a href="#">Buy now</a>
25	<a href="#">6AH8238800</a> Plate	<a href="#">Buy now</a>
26	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>
27	<a href="#">6AH8256000</a> Thermo switch assembly	<a href="#">Buy now</a>
28	<a href="#">6AH8258800</a> Plate	<a href="#">Buy now</a>
30	<a href="#">6AH8254001</a> Neutral switch assembly	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
30	<a href="#">6AH8255400</a> Stay, neutral switch	<a href="#">Buy now</a>
31	<a href="#">9759506516</a> Bolt, with washer(6r6)	<a href="#">Buy now</a>
32	<a href="#">9046418246</a> Clamp(4tr)	<a href="#">Buy now</a>
34	<a href="#">9046410M32</a> Clamp(6m7)	<a href="#">Buy now</a>
35	<a href="#">68T8187000</a> Starting switch assembly	<a href="#">Buy now</a>
35	<a href="#">6G14272500</a> Grommet	<a href="#">Buy now</a>
36	<a href="#">9046416001</a> Clamp	<a href="#">Buy now</a>
36	<a href="#">9046416003</a> Clamp	<a href="#">Buy now</a>
37	<a href="#">6AH8238900</a> Plate 2	<a href="#">Buy now</a>
39	<a href="#">6AH8255300</a> Extension, wire lead	<a href="#">Buy now</a>
39	<a href="#">6AH8255310</a> Extension, wire lead	<a href="#">Buy now</a>
40	<a href="#">67C8541500</a> Mark, signal lamp	<a href="#">Buy now</a>

## Electrical 2




Ref	Part	
31	<a href="#">6AH8196000</a> Rectifier & regulator assembly AP	<a href="#">Buy now</a>
32	<a href="#">7038211900</a> Cover, lead wire AP	<a href="#">Buy now</a>
33	<a href="#">9898006030</a> Screw, bind(j39) AP	<a href="#">Buy now</a>
34	<a href="#">9038706M70</a> Collar (6h5) AP	<a href="#">Buy now</a>
35	<a href="#">9048013M24</a> Grommet (6e9) AP	<a href="#">Buy now</a>
36	<a href="#">9578006500</a> Nut, flange(7nb) AP	<a href="#">Buy now</a>
7	<a href="#">6AH8194500</a> Plate, switch fitting	<a href="#">Buy now</a>
37	<a href="#">9759506514</a> Bolt(gj3) AP	<a href="#">Buy now</a>
9	<a href="#">9046408004</a> Clamp	<a href="#">Buy now</a>
10	<a href="#">68T8194000</a> Starter relay assembly	<a href="#">Buy now</a>
11	<a href="#">9759506610</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
12	<a href="#">6AH8211700</a> Wire, lead	<a href="#">Buy now</a>
13	<a href="#">6AH8210501</a> Battery cable	<a href="#">Buy now</a>
15	<a href="#">9046416001</a> Clamp	<a href="#">Buy now</a>
16	<a href="#">6AH8215000</a> Fuse holder assembly	<a href="#">Buy now</a>

## Electrical 2




Ref	Part	
17	<a href="#">67F8215B10</a> Cap (yellow)	<a href="#">Buy now</a>
18	<a href="#">67F8215100</a> Fuse	<a href="#">Buy now</a>
19	<a href="#">6AH8215700</a> Damper	<a href="#">Buy now</a>
20	<a href="#">67F2812A00</a> Puller, fuse	<a href="#">Buy now</a>
21	<a href="#">6AH8239800</a> Plate 3	<a href="#">Buy now</a>
22	<a href="#">9046418246</a> Clamp(4tr)	<a href="#">Buy now</a>
23	<a href="#">9046513M18</a> Clamp	<a href="#">Buy now</a>
24	<a href="#">9046409010</a> Clamp	<a href="#">Buy now</a>
25	<a href="#">9759508525</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
26	<a href="#">9759508516</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
27	<a href="#">6AH8194900</a> Wire, lead AP	<a href="#">Buy now</a>
29	<a href="#">67F8215B00</a> Cap (black)	<a href="#">Buy now</a>
30	<a href="#">9046406001</a> Clamp AP	<a href="#">Buy now</a>

## Electrical 3




Ref	Part	
1	<a href="#">6AH8259011</a> Wire harness assembly	<a href="#">Buy now</a>
1	<a href="#">6AH8259M01</a> Wire harness assembly 2	<a href="#">Buy now</a>
1	<a href="#">6AH8259M11</a> Wire harness assembly 2	<a href="#">Buy now</a>
2	<a href="#">9046513M18</a> Clamp	<a href="#">Buy now</a>
3	<a href="#">6AH8552A00</a> Housing	<a href="#">Buy now</a>
4	<a href="#">6AH8552E00</a> Cover, case	<a href="#">Buy now</a>
5	<a href="#">6AH8553700</a> Cover	<a href="#">Buy now</a>
6	<a href="#">9048019368</a> Grommet(75v)	<a href="#">Buy now</a>
7	<a href="#">6AH8554700</a> Damper	<a href="#">Buy now</a>
8	<a href="#">9046420181</a> Clamp(4ap)	<a href="#">Buy now</a>
9	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>
10	<a href="#">9798506214</a> Screw, with washer	<a href="#">Buy now</a>

## Electrical 4



Ref	Part	
1	<a href="#">6H58192500</a> Terminal	<a href="#">Buy now</a>
2	<a href="#">6AH8192901</a> Bracket, terminal	<a href="#">Buy now</a>
3	<a href="#">9038706182</a> Collar	<a href="#">Buy now</a>
4	<a href="#">6AH8231700</a> Damper, ignition coil	<a href="#">Buy now</a>
5	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>
6	<a href="#">9017006M30</a> Nut(62x)	<a href="#">Buy now</a>
7	<a href="#">9020406M00</a> Washer, spring(62x)	<a href="#">Buy now</a>
8	<a href="#">6G58211900</a> Cover, lead wire	<a href="#">Buy now</a>
9	<a href="#">6AH8195000</a> Relay assembly	<a href="#">Buy now</a>
10	<a href="#">9038706M03</a> Collar (676)	<a href="#">Buy now</a>
11	<a href="#">9010906MA2</a> Bolt	<a href="#">Buy now</a>
12	<a href="#">9020106416</a> Washer, plate(663)	<a href="#">Buy now</a>
13	<a href="#">6AH8238800</a> Plate	<a href="#">Buy now</a>
14	<a href="#">6AH8259001</a> Wire harness assembly	<a href="#">Buy now</a>
15	<a href="#">9046513M18</a> Clamp	<a href="#">Buy now</a>


# Electrical 4



Ref	Part	
16	<a href="#">6AH8552A10</a> Housing	<a href="#">Buy now</a>
18	<a href="#">9044507025</a> Hose	<a href="#">Buy now</a>
19	<a href="#">9044507026</a> Hose	<a href="#">Buy now</a>
20	<a href="#">9044507027</a> Hose	<a href="#">Buy now</a>
21	<a href="#">9046412001</a> Clamp	<a href="#">Buy now</a>
22	<a href="#">6AH8552E10</a> Cover, case	<a href="#">Buy now</a>
23	<a href="#">6AH4273510</a> Protector	<a href="#">Buy now</a>
24	<a href="#">6AH4273520</a> Protector	<a href="#">Buy now</a>
25	<a href="#">6AH8553710</a> Cover	<a href="#">Buy now</a>
26	<a href="#">9048019368</a> Grommet(75v)	<a href="#">Buy now</a>
27	<a href="#">6AH8554710</a> Damper	<a href="#">Buy now</a>
29	<a href="#">9798506214</a> Screw, with washer	<a href="#">Buy now</a>
30	<a href="#">6AH8552510</a> Plate	<a href="#">Buy now</a>
32	<a href="#">9020106068</a> Washer,plate (6k8)	<a href="#">Buy now</a>
33	<a href="#">9046476001</a> Clamp	<a href="#">Buy now</a>


## Electrical 5

Ref	Part	
1	<a href="#">6AH8256300</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
2	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
3	<a href="#">9798506220</a> Screw, with washer(64x)	<a href="#">Buy now</a>




6AG4300-J160

## Fuel




Ref	Part	
1	<a href="#">6G12430410</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">61N2432900</a> Seal	<a href="#">Buy now</a>
3	<a href="#">9589506020</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
4	<a href="#">6AH2431100</a> Pipe, fuel 1	<a href="#">Buy now</a>
5	<a href="#">61N2456010</a> Filter assembly	<a href="#">Buy now</a>
6	<a href="#">61N2452100</a> Cup, filter	<a href="#">Buy now</a>
7	<a href="#">61N2456310</a> Element, filter	<a href="#">Buy now</a>
8	<a href="#">9321032738</a> O-ring(1wg)	<a href="#">Buy now</a>
9	<a href="#">6AH2456600</a> Bracket, filter	<a href="#">Buy now</a>
10	<a href="#">9538008600</a> Nut (661)	<a href="#">Buy now</a>
11	<a href="#">9011108055</a> Bolt,hex. socket button	<a href="#">Buy now</a>
12	<a href="#">6AH2431200</a> Pipe 2	<a href="#">Buy now</a>
13	<a href="#">9046709M17</a> Clip(6k8)	<a href="#">Buy now</a>
14	<a href="#">6AH2441000</a> Fuel pump assembly	<a href="#">Buy now</a>
15	<a href="#">6AH2441300</a> Body 2	<a href="#">Buy now</a>

## Fuel




Ref	Part	
16	<a href="#">6A02442101</a> Valve, check	<a href="#">Buy now</a>
17	<a href="#">66M2441111</a> Diaphragm	<a href="#">Buy now</a>
18	<a href="#">66M2442300</a> Spring, diaphragm	<a href="#">Buy now</a>
19	<a href="#">66M1313110</a> Plunger	<a href="#">Buy now</a>
20	<a href="#">66M2445400</a> Spring	<a href="#">Buy now</a>
21	<a href="#">66M2444400</a> Screw	<a href="#">Buy now</a>
22	<a href="#">66M2447101</a> Diaphragm	<a href="#">Buy now</a>
23	<a href="#">6E71432500</a> Screw, pan head	<a href="#">Buy now</a>
24	<a href="#">9538004600</a> Nut,hex	<a href="#">Buy now</a>
25	<a href="#">66M2437400</a> Pin	<a href="#">Buy now</a>
26	<a href="#">9010106032</a> Bolt	<a href="#">Buy now</a>
27	<a href="#">9038706M17</a> Collar, lever 1	<a href="#">Buy now</a>
28	<a href="#">9020106106</a> Washer, plate	<a href="#">Buy now</a>
29	<a href="#">9321020M65</a> O-ring	<a href="#">Buy now</a>
30	<a href="#">6AH2431300</a> Pipe 3	<a href="#">Buy now</a>

## Fuel




Ref	Part	
32	<a href="#">6AH2432100</a> Pipe 10	<a href="#">Buy now</a>
33	<a href="#">6AH2432200</a> Pipe 11	<a href="#">Buy now</a>
34	<a href="#">9044509026</a> Hose (I420)	<a href="#">Buy now</a>
35	<a href="#">6AH2432300</a> Pipe 12	<a href="#">Buy now</a>
36	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
37	<a href="#">6AH2432400</a> Pipe 13	<a href="#">Buy now</a>
38	<a href="#">6882437800</a> Pipe, joint	<a href="#">Buy now</a>
39	<a href="#">6C52437800</a> Pipe, joint 4	<a href="#">Buy now</a>
40	<a href="#">9046409018</a> Clamp	<a href="#">Buy now</a>
41	<a href="#">62Y2810000</a> Tool kit AP	<a href="#">Buy now</a>
42	<a href="#">6AG281997CD0</a> Manual,owner's UR (NL)	<a href="#">Buy now</a>
42	<a href="#">6AG281997CE0</a> Manual,owner's UR (E)	<a href="#">Buy now</a>
42	<a href="#">6AG281997CF0</a> Manual,owner's UR (F)	<a href="#">Buy now</a>
42	<a href="#">6AG281997CG0</a> Manual,owner's UR (D)	<a href="#">Buy now</a>
42	<a href="#">6AG281997CH0</a> Manual,owner's UR (I)	<a href="#">Buy now</a>

# Fuel




Ref	Part	
42	<a href="#">6AG281997CS0</a> Manual,owner's UR (ES)	<a href="#">Buy now</a>
43	<a href="#">6AG281998CK0</a> Manual,owner's UR (DK)	<a href="#">Buy now</a>
43	<a href="#">6AG281998CL0</a> Manual,owner's UR (SF)	<a href="#">Buy now</a>
43	<a href="#">6AG281998CM0</a> Manual,owner's UR (S)	<a href="#">Buy now</a>
43	<a href="#">6AG281998CN0</a> Manual,owner's UR (N)	<a href="#">Buy now</a>
43	<a href="#">6AG281998CP0</a> Manual,owner's UR (P)	<a href="#">Buy now</a>
43	<a href="#">6AG281998CR0</a> Manual,owner's UR (GR)	<a href="#">Buy now</a>

# Fuel Tank 1




Ref	Part	
1	<a href="#">6YK2420104</a> Fuel tank comp. <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
2	<a href="#">6YK2461002</a> Cap assembly	<a href="#">Buy now</a>
3	<a href="#">6YK2426010</a> Fuel meter assembly	<a href="#">Buy now</a>
4	<a href="#">6YL2426801</a> Gasket, fuel meter	<a href="#">Buy now</a>
5	<a href="#">6YL2432900</a> Seal	<a href="#">Buy now</a>
6	<a href="#">9015705M16</a> Screw, pan head	<a href="#">Buy now</a>
7	<a href="#">6YL2430654</a> Fuel pipe comp. 1 <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>

## Fuel Tank 2




Ref	Part	
1	<a href="#">6YJ2420120</a> Fuel tank comp. <b>AP FOR RUS</b>	<a href="#">Buy now</a>
2	<a href="#">6YJ2461001</a> Cap assembly	<a href="#">Buy now</a>
3	<a href="#">6YJ2426010</a> Fuel meter assembly	<a href="#">Buy now</a>
4	<a href="#">9015705M19</a> Screw, pan head	<a href="#">Buy now</a>
5	<a href="#">6Y12432900</a> Seal	<a href="#">Buy now</a>
6	<a href="#">6Y12426800</a> Gasket, fuel meter	<a href="#">Buy now</a>
7	<a href="#">6YJ2416700</a> Strainer	<a href="#">Buy now</a>
8	<a href="#">61J2430604</a> Fuel pipe comp. 1 <b>AP FOR RUS</b>	<a href="#">Buy now</a>
9	<a href="#">9044511M06</a> Hose (l3000)	<a href="#">Buy now</a>
10	<a href="#">61J2436000</a> Primer pump assembly	<a href="#">Buy now</a>
11	<a href="#">9044511M05</a> Hose (l1000)	<a href="#">Buy now</a>
12	<a href="#">6502435151</a> Band 1	<a href="#">Buy now</a>
13	<a href="#">6G12430505</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>
14	<a href="#">9321008287</a> O-ring (655)	<a href="#">Buy now</a>
15	<a href="#">6Y12430506</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>

# Generator




Ref	Part	
1	<a href="#">6AH8555000</a> Rotor assembly	<a href="#">Buy now</a>
1	<a href="#">6AH8555010</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">6AH8551000</a> Stator assembly	<a href="#">Buy now</a>
3	<a href="#">6AH8558000</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">7038211900</a> Cover, lead wire	<a href="#">Buy now</a>
5	<a href="#">9709505012</a> Bolt, hexagon	<a href="#">Buy now</a>
6	<a href="#">9589506030</a> Bolt, flange deep recess	<a href="#">Buy now</a>
7	<a href="#">9028005013</a> Key, woodruff	<a href="#">Buy now</a>
8	<a href="#">9017916M05</a> Nut (689)	<a href="#">Buy now</a>
9	<a href="#">9020116M44</a> Washer (689)	<a href="#">Buy now</a>

# Intake




Ref	Part	
1	<a href="#">6AH136410094</a> Manifold 1	<a href="#">Buy now</a>
2	<a href="#">6AH1364500</a> Gasket, manifold 1	<a href="#">Buy now</a>
3	<a href="#">9759506555</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
4	<a href="#">9169050014</a> Pin, spring (647)	<a href="#">Buy now</a>
5	<a href="#">9046508M83</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">9759506512</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
7	<a href="#">6AH1364600</a> Gasket, manifold 2	<a href="#">Buy now</a>
8	<a href="#">6AH1427100</a> Insulator	<a href="#">Buy now</a>
9	<a href="#">6AH1444000</a> Silencer assembly, intake	<a href="#">Buy now</a>
10	<a href="#">9321035M86</a> O-ring(6l2)	<a href="#">Buy now</a>
11	<a href="#">9589506100</a> Bolt, flange deep recess	<a href="#">Buy now</a>
12	<a href="#">6AH1537300</a> Pipe, breather	<a href="#">Buy now</a>
13	<a href="#">9010906MA1</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">9048016616</a> Grommet	<a href="#">Buy now</a>
15	<a href="#">9046513M18</a> Clamp	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
1	<a href="#">6AH45300008D</a> Lower unit assembly <b>S(17.1")</b>	<a href="#">Buy now</a>
1	<a href="#">6AH45300108D</a> Lower unit assembly <b>L(22.1")</b>	<a href="#">Buy now</a>
2	<a href="#">6AH4531108D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93315314V8</a> Bearing, needle (6e7)	<a href="#">Buy now</a>
4	<a href="#">63V4553600</a> Sleeve, drive shaft	<a href="#">Buy now</a>
5	<a href="#">9020914011</a> Washer	<a href="#">Buy now</a>
6	<a href="#">9020115017</a> Washer, plate	<a href="#">Buy now</a>
7	<a href="#">6E84558710</a> Shim (t:1.13mm) <b>UR</b>	<a href="#">Buy now</a>
7	<a href="#">6E84558730</a> Shim (t:1.20mm) <b>UR</b>	<a href="#">Buy now</a>
8	<a href="#">9333200005</a> Brg,cyl-cal roller 0.19g nt	<a href="#">Buy now</a>
9	<a href="#">9034008002</a> Plug, straight screw	<a href="#">Buy now</a>
10	<a href="#">9043008003</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">6AH4431100</a> Housing, water pump	<a href="#">Buy now</a>
12	<a href="#">63V4432200</a> Insert, cartridge	<a href="#">Buy now</a>
13	<a href="#">6L24436700</a> Damper, water seal 3	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
14	<a href="#">63V4435201</a> Impeller	<a href="#">Buy now</a>
15	<a href="#">6644433800</a> Key, woodruff	<a href="#">Buy now</a>
16	<a href="#">9321049046</a> O-ring (620)	<a href="#">Buy now</a>
17	<a href="#">68T4432300</a> Outer plate, cartridge	<a href="#">Buy now</a>
18	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
19	<a href="#">9709508045</a> Bolt, hexagon	<a href="#">Buy now</a>
20	<a href="#">63V4432801</a> Plate	<a href="#">Buy now</a>
21	<a href="#">69G4533101CA</a> Housing, bearing	<a href="#">Buy now</a>
22	<a href="#">6264531609</a> Bushing, drive shaft 1	<a href="#">Buy now</a>
23	<a href="#">9310120001</a> Oil seal	<a href="#">Buy now</a>
24	<a href="#">69G45315A0</a> Packing, lower casing	<a href="#">Buy now</a>
25	<a href="#">9321006ME6</a> O-ring	<a href="#">Buy now</a>
26	<a href="#">9708008025</a> Screw, bind(j36)	<a href="#">Buy now</a>
27	<a href="#">6AH4415000</a> Shift cam assembly S(17.1")	<a href="#">Buy now</a>
27	<a href="#">6AH4415010</a> Shift cam assembly L(22.1")	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
28	<a href="#">6AH4551000</a> Drive shaft assembly <b>S(17.1")</b>	<a href="#">Buy now</a>
28	<a href="#">6AH4551010</a> Drive shaft assembly <b>L(22.1")</b>	<a href="#">Buy now</a>
29	<a href="#">63V4555100</a> Pinion	<a href="#">Buy now</a>
30	<a href="#">9017908M06</a> Nut (6e7)	<a href="#">Buy now</a>
31	<a href="#">6E74556001</a> Gear	<a href="#">Buy now</a>
32	<a href="#">6E74557100</a> Gear 2	<a href="#">Buy now</a>
33	<a href="#">6264557700</a> Shim (t:0.10mm) <b>UR</b>	<a href="#">Buy now</a>
33	<a href="#">6264557710</a> Shim (t:0.20mm) <b>UR</b>	<a href="#">Buy now</a>
33	<a href="#">6264557720</a> Shim (t:0.30mm) <b>UR</b>	<a href="#">Buy now</a>
33	<a href="#">6264557730</a> Shim (t:0.40mm) <b>UR</b>	<a href="#">Buy now</a>
33	<a href="#">6264557740</a> Shim (t:0.50mm) <b>UR</b>	<a href="#">Buy now</a>
34	<a href="#">9020117682</a> Washer, plate (2k7)	<a href="#">Buy now</a>
35	<a href="#">6834561100</a> Shaft propeller	<a href="#">Buy now</a>
36	<a href="#">6504563500</a> Plunger, shift	<a href="#">Buy now</a>
37	<a href="#">6824563100</a> Clutch, dog	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
38	<a href="#">9025005010</a> Pin straight 648456320000	<a href="#">Buy now</a>
39	<a href="#">6484563311</a> Ring, cross pin	<a href="#">Buy now</a>
40	<a href="#">90501150AO</a> Spring, compression	<a href="#">Buy now</a>
41	<a href="#">68345361028D</a> Cap, lower casing	<a href="#">Buy now</a>
42	<a href="#">9330600501</a> Bearing(1ff)	<a href="#">Buy now</a>
43	<a href="#">93315317U2</a> Brg,cyl-cal roller 14g (683)	<a href="#">Buy now</a>
44	<a href="#">9310117054</a> Oil seal (17x30x6-650)	<a href="#">Buy now</a>
45	<a href="#">9321057M09</a> O-ring (683)	<a href="#">Buy now</a>
46	<a href="#">9321056M80</a> O-ring(6j8)	<a href="#">Buy now</a>
47	<a href="#">9757506520</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
48	<a href="#">6644556701</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
48	<a href="#">6644556710</a> Shim (t:0.12mm) UR	<a href="#">Buy now</a>
48	<a href="#">6644556720</a> Shim (t:0.15mm) UR	<a href="#">Buy now</a>
48	<a href="#">6644556730</a> Shim (t:0.18mm) UR	<a href="#">Buy now</a>
48	<a href="#">6644556740</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
48	<a href="#">6644556750</a> Shim (t:0.40mm) UR	<a href="#">Buy now</a>
48	<a href="#">6644556760</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
1	<a href="#">6AH4436101</a> Tube, water 1 <b>S(17.1")</b>	<a href="#">Buy now</a>
1	<a href="#">6AH4436111</a> Tube, water 1 <b>L(22.1")</b>	<a href="#">Buy now</a>
2	<a href="#">6AH4436500</a> Damper, water seal 1	<a href="#">Buy now</a>
3	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
4	<a href="#">6AH4436800</a> Rubber, water seal 4	<a href="#">Buy now</a>
5	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
6	<a href="#">9757508530</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
7	<a href="#">6G14521400</a> Cover, water inlet	<a href="#">Buy now</a>
8	<a href="#">63V4521500</a> Cover, water inlet	<a href="#">Buy now</a>
9	<a href="#">9015205011</a> Screw, countersunk	<a href="#">Buy now</a>
10	<a href="#">9018505002</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
11	<a href="#">6AH4525100</a> Anode	<a href="#">Buy now</a>
12	<a href="#">9589506035</a> Bolt, flange(4nx)	<a href="#">Buy now</a>
13	<a href="#">9299006300</a> Washer, tooth	<a href="#">Buy now</a>
14	<a href="#">63V4537500</a> Damper, seal	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
15	<a href="#">6E74598701</a> Spacer	<a href="#">Buy now</a>
16	<a href="#">9020110M01</a> Washer, plate(6m7)	<a href="#">Buy now</a>
17	<a href="#">9017110M01</a> Nut castle (683)	<a href="#">Buy now</a>
18	<a href="#">9149030020</a> Pin cotter	<a href="#">Buy now</a>
19	<a href="#">6AH45371A08D</a> Tab-trim	<a href="#">Buy now</a>
20	<a href="#">9011906M88</a> Bolt, with washer	<a href="#">Buy now</a>
21	<a href="#">63V4594310</a> Propeller (3x9-1/4 x11 -j1) UR	<a href="#">Buy now</a>
21	<a href="#">63V4594510</a> Propeller (3x9-1/4 x9 -j1) UR	<a href="#">Buy now</a>
21	<a href="#">63V4595210</a> Propeller (3x9-1/4 x10 -j1) UR	<a href="#">Buy now</a>
21	<a href="#">6834594100</a> Propeller (3x9-1/4"x12"-j) UR	<a href="#">Buy now</a>
21	<a href="#">6834594300</a> Propeller (3x9-1/4"x10-1/2"-j) UR	<a href="#">Buy now</a>
21	<a href="#">6834595200</a> Propeller (3X9-1/4"x9-3/4"-J) UR	<a href="#">Buy now</a>
21	<a href="#">63V4594110</a> Propeller (3x9-1/4 x12 -j1) UR	<a href="#">Buy now</a>

# Oil Pan



Ref	Part	
1	<a href="#">6AH1531100CA</a> Oil pan	<a href="#">Buy now</a>
2	<a href="#">6AH1531210</a> Gasket, oil pan	<a href="#">Buy now</a>
3	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
4	<a href="#">6AH1531600</a> Damper, engine mount 1	<a href="#">Buy now</a>
5	<a href="#">9034014M06</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
6	<a href="#">9043014M09</a> Gasket	<a href="#">Buy now</a>
7	<a href="#">6AH1341100</a> Strainer, oil	<a href="#">Buy now</a>
8	<a href="#">9751306516</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
9	<a href="#">6AH1536210</a> Plug, oil level	<a href="#">Buy now</a>
10	<a href="#">9011908103</a> Bolt, with washer	<a href="#">Buy now</a>
11	<a href="#">9757508530</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
12	<a href="#">6AH4512600</a> Plate, seal damper	<a href="#">Buy now</a>
13	<a href="#">6AH4511500</a> Gasket, upper casing	<a href="#">Buy now</a>
14	<a href="#">6AH4513500</a> Pipe	<a href="#">Buy now</a>


# Oil Pump



6AH2100-G080


Ref	Part	
1	<a href="#">6AH1217000</a> Camshaft assembly 1	<a href="#">Buy now</a>
2	<a href="#">6AH1153700</a> Gear, driven	<a href="#">Buy now</a>
3	<a href="#">90105081A7</a> Bolt, washer based(jn9)	<a href="#">Buy now</a>
4	<a href="#">9020108784</a> Washer, plate (3l7)	<a href="#">Buy now</a>
5	<a href="#">9020115423</a> Washer, plate(663)	<a href="#">Buy now</a>
6	<a href="#">6AH1153600</a> Gear, drive	<a href="#">Buy now</a>
7	<a href="#">6AH1155700</a> Washer 1	<a href="#">Buy now</a>
8	<a href="#">9017030003</a> Nut	<a href="#">Buy now</a>
9	<a href="#">9028003M01</a> Key woodruff 146115450000	<a href="#">Buy now</a>
10	<a href="#">6AH4624100</a> Belt	<a href="#">Buy now</a>
11	<a href="#">6AH4629700</a> Cover, dust	<a href="#">Buy now</a>
12	<a href="#">9048010627</a> Grommet	<a href="#">Buy now</a>
13	<a href="#">6AH4261700</a> Damper, form	<a href="#">Buy now</a>
14	<a href="#">9048006M19</a> Grommet (6e3)	<a href="#">Buy now</a>
15	<a href="#">6AH1330000</a> Oil pump assembly	<a href="#">Buy now</a>

# Oil Pump




Ref	Part	
16	<a href="#">6AH1332910</a> Gasket, pump cover	<a href="#">Buy now</a>
17	<a href="#">9010506035</a> Bolt, flange	<a href="#">Buy now</a>
18	<a href="#">9310222010</a> Oil seal	<a href="#">Buy now</a>
19	<a href="#">6AH1343761</a> Mark, caution	<a href="#">Buy now</a>
20	<a href="#">6EE8199440</a> Label, safety	<a href="#">Buy now</a>
21	<a href="#">6EE8199450</a> Label, safety	<a href="#">Buy now</a>

# Power Tilt Assy




# Power Tilt Assy



6AGC100-R260


Ref	Part	
18	<a href="#">6AH4387800</a> Bolt, socket	<a href="#">Buy now</a>
19	<a href="#">6AH4385700</a> Spring, absorber valve	<a href="#">Buy now</a>
20	<a href="#">6AH4380100</a> Rod	<a href="#">Buy now</a>
21	<a href="#">6AH4381100</a> Screw, cylinder end	<a href="#">Buy now</a>
22	<a href="#">6H14386601</a> O-ring	<a href="#">Buy now</a>
23	<a href="#">69A4387100</a> Ring, back up	<a href="#">Buy now</a>
24	<a href="#">69A4381200</a> Seal, dust	<a href="#">Buy now</a>
25	<a href="#">62X4386200</a> O-ring	<a href="#">Buy now</a>
26	<a href="#">6AH4383000</a> Gear pump assembly	<a href="#">Buy now</a>
27	<a href="#">69A4384100</a> Piston, shuttle	<a href="#">Buy now</a>
28	<a href="#">69A4384M00</a> Piston, shuttle 2	<a href="#">Buy now</a>
29	<a href="#">62Y4389400</a> Spring, shuttle return	<a href="#">Buy now</a>
30	<a href="#">69A4384F00</a> Seal, main valve	<a href="#">Buy now</a>
31	<a href="#">6H14388300</a> O-ring	<a href="#">Buy now</a>
32	<a href="#">9900203600</a> Circlip(615)	<a href="#">Buy now</a>

# Power Tilt Assy




Ref	Part	
33	<a href="#">69G4382G00</a> Valve seat	<a href="#">Buy now</a>
34	<a href="#">9321012N52</a> O-ring	<a href="#">Buy now</a>
35	<a href="#">6T44380800</a> Seat valve comp. 1	<a href="#">Buy now</a>
36	<a href="#">69G4385300</a> Spring, main valve	<a href="#">Buy now</a>
37	<a href="#">69G4388F00</a> Spacer	<a href="#">Buy now</a>
38	<a href="#">69J4381C00</a> Filter 3	<a href="#">Buy now</a>
39	<a href="#">6H14384G11</a> Seal, relief valve	<a href="#">Buy now</a>
40	<a href="#">6H14384410</a> Pin, valve support	<a href="#">Buy now</a>
41	<a href="#">6F24385500</a> Spring, up relief	<a href="#">Buy now</a>
42	<a href="#">6H14385610</a> Spring, down relief	<a href="#">Buy now</a>
44	<a href="#">69A4386A00</a> Pin, absorber valve	<a href="#">Buy now</a>
45	<a href="#">69A4382400</a> Spring, down relief 2	<a href="#">Buy now</a>
46	<a href="#">69A4384810</a> Rod, manual release	<a href="#">Buy now</a>
47	<a href="#">9360215250</a> Pin, dowel	<a href="#">Buy now</a>
48	<a href="#">9321006001</a> O-ring (26h)	<a href="#">Buy now</a>

# Power Tilt Assy




Ref	Part	
49	<a href="#">6AH4385400</a> Spring, manual release	<a href="#">Buy now</a>
50	<a href="#">69A4381G00</a> Pin 1	<a href="#">Buy now</a>
53	<a href="#">69A4384H00</a> Spring	<a href="#">Buy now</a>
54	<a href="#">9360614081</a> Pin,dowel(296)	<a href="#">Buy now</a>
55	<a href="#">9131205025</a> Bolt	<a href="#">Buy now</a>
57	<a href="#">6AH4381J00</a> Plate	<a href="#">Buy now</a>
58	<a href="#">N354386210</a> O-ring	<a href="#">Buy now</a>
59	<a href="#">69A2312900</a> Gasket, drain plug	<a href="#">Buy now</a>
60	<a href="#">69A4387800</a> Bolt, socket	<a href="#">Buy now</a>
61	<a href="#">6AH4388000</a> Motor assembly	<a href="#">Buy now</a>
62	<a href="#">6AH4380400</a> Stator assembly	<a href="#">Buy now</a>
63	<a href="#">67C4387910</a> Screw, with washer	<a href="#">Buy now</a>
64	<a href="#">67C4380510</a> Armature assembly	<a href="#">Buy now</a>
65	<a href="#">67C4386210</a> O-ring	<a href="#">Buy now</a>
66	<a href="#">67C8218110</a> Circuit breaker comp.	<a href="#">Buy now</a>

## Power Tilt Assy




Ref	Part	
67	<a href="#">67C4389210</a> Brush 2	<a href="#">Buy now</a>
68	<a href="#">67C4386K10</a> Spring, brush	<a href="#">Buy now</a>
69	<a href="#">67C4380F10</a> Plate, brush holder	<a href="#">Buy now</a>
70	<a href="#">9760204316</a> Screw, pan head with washer	<a href="#">Buy now</a>
71	<a href="#">6AH4388100</a> Frame, end	<a href="#">Buy now</a>
72	<a href="#">67C4388210</a> Oil seal	<a href="#">Buy now</a>

# Remo Con Attachment




Ref	Part	
1	<a href="#">6AH4850100</a> Remote cont. attachment assembly. <b>AP</b>	<a href="#">Buy now</a>
2	<a href="#">6AH4272410</a> Grommet	<a href="#">Buy now</a>
3	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
4	<a href="#">65W4272610</a> Grommet	<a href="#">Buy now</a>
5	<a href="#">6AH8377300</a> Bracket, switch	<a href="#">Buy now</a>
6	<a href="#">9759506530</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
7	<a href="#">6AH4853200</a> Bracket, remote control 2	<a href="#">Buy now</a>
8	<a href="#">9048019031</a> Grommet(75v)	<a href="#">Buy now</a>
9	<a href="#">6824853850</a> Clamp, cable	<a href="#">Buy now</a>
10	<a href="#">9169030012</a> Pin, spring	<a href="#">Buy now</a>
11	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>
12	<a href="#">6FM4834400</a> Cable end, remote control	<a href="#">Buy now</a>
13	<a href="#">9046818008</a> Clip 620436610000	<a href="#">Buy now</a>
14	<a href="#">6AH4853100</a> Bracket, remote control 1	<a href="#">Buy now</a>
15	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>

## Remo Con Attachment




Ref	Part	
18	<a href="#">9046513M18</a> Clamp	<a href="#">Buy now</a>
19	<a href="#">6D58434000</a> Socket cord assembly 1	<a href="#">Buy now</a>
20	<a href="#">6AH4851101</a> Hook, steering AP	<a href="#">Buy now</a>
21	<a href="#">9759508525</a> Bolt, hexagon deep recess AP	<a href="#">Buy now</a>
22	<a href="#">9018508057</a> Nut, nylon (6j8) AP	<a href="#">Buy now</a>
23	<a href="#">6AH4419400</a> Cap AP	<a href="#">Buy now</a>

# Remote Control Assy 1




Ref	Part	
1	<a href="#">70348201B1</a> Remote control assembly (10p) AP WITHOUT PT/T SW.	<a href="#">Buy now</a>
2	<a href="#">7034823200</a> Drive gear	<a href="#">Buy now</a>
3	<a href="#">7034827100</a> Arm, shift	<a href="#">Buy now</a>
4	<a href="#">7034826101</a> Arm, throttle	<a href="#">Buy now</a>
5	<a href="#">7034823500</a> Bushing	<a href="#">Buy now</a>
6	<a href="#">7034815210</a> Knob, free accel.	<a href="#">Buy now</a>
7	<a href="#">7034826800</a> Spacer 3	<a href="#">Buy now</a>
8	<a href="#">7034826400</a> Throttle, friction	<a href="#">Buy now</a>
9	<a href="#">9538005600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
10	<a href="#">9738005025</a> Bolt	<a href="#">Buy now</a>
11	<a href="#">7034826510</a> Shaft, friction	<a href="#">Buy now</a>
12	<a href="#">9343006024</a> Circlip (701)	<a href="#">Buy now</a>
13	<a href="#">7034824500</a> Plate, lock	<a href="#">Buy now</a>
14	<a href="#">7034825200</a> Roller, cam	<a href="#">Buy now</a>
15	<a href="#">7014824800</a> Roller, free accel	<a href="#">Buy now</a>

# Remote Control Assy 1




Ref	Part	
16	<a href="#">7034819800</a> Washer, wave 3	<a href="#">Buy now</a>
17	<a href="#">7034824300</a> Bushing 3	<a href="#">Buy now</a>
18	<a href="#">7034823600</a> Bushing	<a href="#">Buy now</a>
19	<a href="#">7034818900</a> Retainer	<a href="#">Buy now</a>
20	<a href="#">7034823400</a> Roller, detent	<a href="#">Buy now</a>
21	<a href="#">7034834501</a> Cable end, remote control 2	<a href="#">Buy now</a>
22	<a href="#">7034835800</a> Anchor, cable	<a href="#">Buy now</a>
23	<a href="#">7034824400</a> Spring, free accel.	<a href="#">Buy now</a>
24	<a href="#">7034823800</a> Spring, detent	<a href="#">Buy now</a>
25	<a href="#">7034821110</a> Housing,1	<a href="#">Buy now</a>
26	<a href="#">7034821210</a> Back plate 1	<a href="#">Buy now</a>
27	<a href="#">7034821310</a> Back plate 2	<a href="#">Buy now</a>
28	<a href="#">7034822110</a> Lever, control	<a href="#">Buy now</a>
29	<a href="#">7034824600</a> Spacer 1	<a href="#">Buy now</a>
30	<a href="#">7034822700</a> Spring, neutral lock	<a href="#">Buy now</a>

# Remote Control Assy 1




Ref	Part	
31	<a href="#">7034822230</a> Grip, control lever <b>SINGLE</b>	<a href="#">Buy now</a>
32	<a href="#">7034822310</a> Lock, neutral	<a href="#">Buy now</a>
33	<a href="#">7034822510</a> Cover	<a href="#">Buy now</a>
34	<a href="#">7034821910</a> Cover, lead	<a href="#">Buy now</a>
35	<a href="#">7034828100</a> Screw, flat head	<a href="#">Buy now</a>
36	<a href="#">7034418920</a> Screw	<a href="#">Buy now</a>
37	<a href="#">9738008030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
38	<a href="#">9299008600</a> Washer, plain (663)	<a href="#">Buy now</a>
39	<a href="#">7034812810</a> Screw 2	<a href="#">Buy now</a>
40	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
41	<a href="#">7034812900</a> Screw 3	<a href="#">Buy now</a>
42	<a href="#">7034418930</a> Screw	<a href="#">Buy now</a>
43	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
44	<a href="#">7034829310</a> Spacer, remote control <b>SINGLE</b>	<a href="#">Buy now</a>
45	<a href="#">7014828700</a> Washer 1	<a href="#">Buy now</a>

# Remote Control Assy 1




Ref	Part	
46	<a href="#">7034821510</a> Graphic	<a href="#">Buy now</a>
47	<a href="#">6X34419100</a> Indicator, shift	<a href="#">Buy now</a>
48	<a href="#">7038251013</a> Main switch assembly <b>PRIME START</b>	<a href="#">Buy now</a>
49	<a href="#">6768257701</a> Cap, key	<a href="#">Buy now</a>
50	<a href="#">7038253200</a> Cap	<a href="#">Buy now</a>
51	<a href="#">7038253100</a> Wire, lead	<a href="#">Buy now</a>
52	<a href="#">6888257502</a> Engine stop switch assembly	<a href="#">Buy now</a>
53	<a href="#">6828255600</a> Lanyard, stop switch	<a href="#">Buy now</a>
54	<a href="#">6888258A20</a> 10p main harness mec 2m (6ft) <b>(10P)</b>	<a href="#">Buy now</a>
55	<a href="#">7038254000</a> Neutral switch assembly	<a href="#">Buy now</a>
56	<a href="#">7038338311</a> Buzzer	<a href="#">Buy now</a>
57	<a href="#">7034828400</a> Grommet	<a href="#">Buy now</a>
58	<a href="#">7038259100</a> Band	<a href="#">Buy now</a>
59	<a href="#">7038259200</a> Band	<a href="#">Buy now</a>
60	<a href="#">7034815300</a> Shaft, free accel.	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
1	<a href="#">70348205B2</a> Remote control assembly (10p, ptt) AP WITH PT/T SW.	<a href="#">Buy now</a>
2	<a href="#">7034823200</a> Drive gear	<a href="#">Buy now</a>
3	<a href="#">7034827100</a> Arm, shift	<a href="#">Buy now</a>
4	<a href="#">7034826101</a> Arm, throttle	<a href="#">Buy now</a>
5	<a href="#">7034823500</a> Bushing	<a href="#">Buy now</a>
6	<a href="#">7034815210</a> Knob, free accel.	<a href="#">Buy now</a>
7	<a href="#">7034826800</a> Spacer 3	<a href="#">Buy now</a>
8	<a href="#">7034826400</a> Throttle, friction	<a href="#">Buy now</a>
9	<a href="#">9538005600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
10	<a href="#">9738005025</a> Bolt	<a href="#">Buy now</a>
11	<a href="#">7034826510</a> Shaft, friction	<a href="#">Buy now</a>
12	<a href="#">9343006024</a> Circlip (701)	<a href="#">Buy now</a>
13	<a href="#">7034824500</a> Plate, lock	<a href="#">Buy now</a>
14	<a href="#">7034825200</a> Roller, cam	<a href="#">Buy now</a>
15	<a href="#">7014824800</a> Roller, free accel	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
16	<a href="#">7034819800</a> Washer, wave 3	<a href="#">Buy now</a>
17	<a href="#">7034824300</a> Bushing 3	<a href="#">Buy now</a>
18	<a href="#">7034823600</a> Bushing	<a href="#">Buy now</a>
19	<a href="#">7034818900</a> Retainer	<a href="#">Buy now</a>
20	<a href="#">7034823400</a> Roller, detent	<a href="#">Buy now</a>
21	<a href="#">7034834501</a> Cable end, remote control 2	<a href="#">Buy now</a>
22	<a href="#">7034835800</a> Anchor, cable	<a href="#">Buy now</a>
23	<a href="#">7034824400</a> Spring, free accel.	<a href="#">Buy now</a>
24	<a href="#">7034823800</a> Spring, detent	<a href="#">Buy now</a>
25	<a href="#">7034821110</a> Housing,1	<a href="#">Buy now</a>
26	<a href="#">7034821210</a> Back plate 1	<a href="#">Buy now</a>
27	<a href="#">7034821310</a> Back plate 2	<a href="#">Buy now</a>
28	<a href="#">7034822110</a> Lever, control	<a href="#">Buy now</a>
29	<a href="#">7034824600</a> Spacer 1	<a href="#">Buy now</a>
30	<a href="#">7034822700</a> Spring, neutral lock	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
31	<a href="#">7034822220</a> Grip, control lever <b>SINGLE</b>	<a href="#">Buy now</a>
32	<a href="#">7034822310</a> Lock, neutral	<a href="#">Buy now</a>
33	<a href="#">7034822510</a> Cover	<a href="#">Buy now</a>
34	<a href="#">7034821910</a> Cover, lead	<a href="#">Buy now</a>
35	<a href="#">7034828100</a> Screw, flat head	<a href="#">Buy now</a>
36	<a href="#">7034418920</a> Screw	<a href="#">Buy now</a>
37	<a href="#">9738008030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
38	<a href="#">9299008600</a> Washer, plain (663)	<a href="#">Buy now</a>
39	<a href="#">7034812810</a> Screw 2	<a href="#">Buy now</a>
40	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
41	<a href="#">7034812900</a> Screw 3	<a href="#">Buy now</a>
42	<a href="#">7034418930</a> Screw	<a href="#">Buy now</a>
43	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
44	<a href="#">7034829310</a> Spacer, remote control <b>SINGLE</b>	<a href="#">Buy now</a>
45	<a href="#">7014828700</a> Washer 1	<a href="#">Buy now</a>

## Remote Control Assy 2





Ref	Part	
46	<a href="#">7034821510</a> Graphic	<a href="#">Buy now</a>
47	<a href="#">6X34419100</a> Indicator, shift	<a href="#">Buy now</a>
48	<a href="#">7038251013</a> Main switch assembly <b>PRIME START</b>	<a href="#">Buy now</a>
49	<a href="#">6768257701</a> Cap, key	<a href="#">Buy now</a>
50	<a href="#">7038253200</a> Cap	<a href="#">Buy now</a>
51	<a href="#">7038253100</a> Wire, lead	<a href="#">Buy now</a>
52	<a href="#">6888257502</a> Engine stop switch assembly	<a href="#">Buy now</a>
53	<a href="#">6828255600</a> Lanyard, stop switch	<a href="#">Buy now</a>
54	<a href="#">6888258A20</a> 10p main harness mec 2m (6ft) (10P)	<a href="#">Buy now</a>
55	<a href="#">7038254000</a> Neutral switch assembly	<a href="#">Buy now</a>
56	<a href="#">7038338311</a> Buzzer	<a href="#">Buy now</a>
57	<a href="#">7038256331</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
58	<a href="#">7034828400</a> Grommet	<a href="#">Buy now</a>
59	<a href="#">7038259100</a> Band	<a href="#">Buy now</a>
60	<a href="#">7038259200</a> Band	<a href="#">Buy now</a>

## Remote Control Assy 2



Ref	Part	
61	<a href="#">7034815300</a> Shaft, free accel.	<a href="#">Buy now</a>


## Remote Control Box



6FX1300-P340


Ref	Part	
1	<a href="#">70348201B1</a> Remote control assembly (10p) <b>AP WITHOUT PT/T SW.</b>	<a href="#">Buy now</a>
2	<a href="#">70348205B2</a> Remote control assembly (10p, ptt) <b>AP WITH PT/T SW.</b>	<a href="#">Buy now</a>
3	<a href="#">7014831090</a> Cable, Remote Control L=11F <b>UR</b>	<a href="#">Buy now</a>
3	<a href="#">7014832000</a> Cable, Remote Control L=12F <b>UR</b>	<a href="#">Buy now</a>
3	<a href="#">7014832020</a> Cable, Remote Control L=13F <b>UR</b>	<a href="#">Buy now</a>
3	<a href="#">7014832050</a> Cable, Remote Control L=15F <b>UR</b>	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
1	<a href="#">6AGW000100</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310222010</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">6AG1118110</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
4	<a href="#">6AH1135600</a> Seal, cylinder 2	<a href="#">Buy now</a>
5	<a href="#">6AH1116900</a> Gasket, breather cover	<a href="#">Buy now</a>
6	<a href="#">9321013M63</a> O-ring (6g8)	<a href="#">Buy now</a>
7	<a href="#">9310237004</a> Oil seal	<a href="#">Buy now</a>
8	<a href="#">9310225014</a> Oil seal	<a href="#">Buy now</a>
9	<a href="#">6AH1135110</a> Gasket, cylinder	<a href="#">Buy now</a>
11	<a href="#">6AH4111400</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
12	<a href="#">6AH1241400</a> Gasket, cover	<a href="#">Buy now</a>
13	<a href="#">6AH1364500</a> Gasket, manifold 1	<a href="#">Buy now</a>
14	<a href="#">6AH1364600</a> Gasket, manifold 2	<a href="#">Buy now</a>
15	<a href="#">9321035M86</a> O-ring(6l2)	<a href="#">Buy now</a>
16	<a href="#">6AH1332910</a> Gasket, pump cover	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
17	<a href="#">9321024M79</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">9321020M65</a> O-ring	<a href="#">Buy now</a>

## Repair Kit 2




Ref	Part	
1	<a href="#">6AHW009301</a> Carburetor repair kit	<a href="#">Buy now</a>
2	<a href="#">65W1412610</a> Gasket	<a href="#">Buy now</a>
3	<a href="#">6AH1454600</a> Valve, needle	<a href="#">Buy now</a>
4	<a href="#">6H41454800</a> Pin, float arm	<a href="#">Buy now</a>
5	<a href="#">65W1437302</a> Cover, plunger cap	<a href="#">Buy now</a>
6	<a href="#">67F1439810</a> O-ring	<a href="#">Buy now</a>
7	<a href="#">6AH1438400</a> Gasket, float chamber	<a href="#">Buy now</a>
8	<a href="#">65W1439800</a> Washer	<a href="#">Buy now</a>
9	<a href="#">9798004114</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
10	<a href="#">6AH1498500</a> Float	<a href="#">Buy now</a>
11	<a href="#">6331415900</a> Clip	<a href="#">Buy now</a>

# Repair Kit 3




Ref	Part	
1	<a href="#">6AHW000120</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">6AH1531210</a> Gasket, oil pan	<a href="#">Buy now</a>
3	<a href="#">9043014M09</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">9310112M63</a> Oil seal	<a href="#">Buy now</a>
5	<a href="#">9043008143</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
6	<a href="#">6AH4113400</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
7	<a href="#">6AH4113800</a> Seal, ext. 1	<a href="#">Buy now</a>
8	<a href="#">6AH4512600</a> Plate, seal damper	<a href="#">Buy now</a>
9	<a href="#">6AH4511500</a> Gasket, upper casing	<a href="#">Buy now</a>
10	<a href="#">6AH4436500</a> Damper, water seal 1	<a href="#">Buy now</a>
11	<a href="#">6AH4436800</a> Rubber, water seal 4	<a href="#">Buy now</a>
12	<a href="#">9043008003</a> Gasket	<a href="#">Buy now</a>
13	<a href="#">6L24436700</a> Damper, water seal 3	<a href="#">Buy now</a>
14	<a href="#">9321049046</a> O-ring (620)	<a href="#">Buy now</a>
15	<a href="#">9310120001</a> Oil seal	<a href="#">Buy now</a>

# Repair Kit 3




Ref	Part	
16	<a href="#">69G45315A0</a> Packing, lower casing	<a href="#">Buy now</a>
17	<a href="#">9321006ME6</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">9310117054</a> Oil seal (17x30x6-650)	<a href="#">Buy now</a>
19	<a href="#">9321057M09</a> O-ring (683)	<a href="#">Buy now</a>
20	<a href="#">9321056M80</a> O-ring(6j8)	<a href="#">Buy now</a>
21	<a href="#">6AHW007800</a> Water pump repair kit	<a href="#">Buy now</a>
22	<a href="#">6AH4431100</a> Housing, water pump	<a href="#">Buy now</a>
23	<a href="#">63V4432200</a> Insert, cartridge	<a href="#">Buy now</a>
25	<a href="#">63V4435201</a> Impeller	<a href="#">Buy now</a>
26	<a href="#">6444433800</a> Key, woodruff	<a href="#">Buy now</a>
28	<a href="#">68T4432300</a> Outer plate, cartridge	<a href="#">Buy now</a>
29	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>
30	<a href="#">9709508045</a> Bolt, hexagon	<a href="#">Buy now</a>
31	<a href="#">63V4432801</a> Plate	<a href="#">Buy now</a>

# Starter




Ref	Part	
1	<a href="#">6AH1571002</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">6AH1571101</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">6BL1576400</a> Collar 1	<a href="#">Buy now</a>
4	<a href="#">6AH1579500</a> Guide, rope	<a href="#">Buy now</a>
5	<a href="#">63V1571400</a> Drum, sheave	<a href="#">Buy now</a>
6	<a href="#">6AH1574110</a> Pawl, drive	<a href="#">Buy now</a>
7	<a href="#">63V1571300</a> Spring, starter	<a href="#">Buy now</a>
8	<a href="#">68T1571600</a> Plate, drive	<a href="#">Buy now</a>
9	<a href="#">63V1570501</a> Spring, drive pawl	<a href="#">Buy now</a>
10	<a href="#">63V1576701</a> Spring	<a href="#">Buy now</a>
11	<a href="#">68T1578400</a> Spring, return	<a href="#">Buy now</a>
12	<a href="#">63V1579300</a> Screw	<a href="#">Buy now</a>
13	<a href="#">68T1579300</a> Screw	<a href="#">Buy now</a>
14	<a href="#">68T1576400</a> Collar 1	<a href="#">Buy now</a>
15	<a href="#">6891575501</a> Handle, starter	<a href="#">Buy now</a>

# Starter




Ref	Part	
16	* item_description *1	<a href="#">Buy now</a>
17	<a href="#">6F51577902</a> Cover	<a href="#">Buy now</a>
18	<a href="#">6A01578900</a> Damper	<a href="#">Buy now</a>
19	<a href="#">66T1579400</a> Stopper	<a href="#">Buy now</a>
20	<a href="#">66T1573400</a> Spring, return	<a href="#">Buy now</a>
21	<a href="#">6AH1578200</a> Cover, sheave	<a href="#">Buy now</a>
22	<a href="#">6AH1579300</a> Screw	<a href="#">Buy now</a>
23	<a href="#">6AH1577000</a> Cable comp., starter stop	<a href="#">Buy now</a>
24	<a href="#">66T1573100</a> Retainer, spring	<a href="#">Buy now</a>
25	<a href="#">9044606M90</a> Hose	<a href="#">Buy now</a>
26	<a href="#">9587506020</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
26	<a href="#">9759506520</a> Bolt(7u8)	<a href="#">Buy now</a>
27	<a href="#">9011906169</a> Bolt, with washer	<a href="#">Buy now</a>
28	<a href="#">6AH1576201</a> Seal, rubber 2	<a href="#">Buy now</a>
29	<a href="#">6AH2431600</a> Pipe 6	<a href="#">Buy now</a>

# Starter




Ref	Part	
30	<a href="#">6AH8133700</a> Cover, flywheel	<a href="#">Buy now</a>
31	<a href="#">6AH1442760</a> Label, instruction	<a href="#">Buy now</a>
32	<a href="#">6EE8199540</a> Label, warning	<a href="#">Buy now</a>
33	<a href="#">6EE8199550</a> Label, warning	<a href="#">Buy now</a>
34	<a href="#">6AG8199600</a> Mark	<a href="#">Buy now</a>

# Starting Motor




Ref	Part	
1	<a href="#">6AH8180001</a> Starting motor assembly	<a href="#">Buy now</a>
2	<a href="#">6898185011</a> Armature assembly	<a href="#">Buy now</a>
3	<a href="#">6898180911</a> Washer kit	<a href="#">Buy now</a>
4	<a href="#">6898181011</a> Stator ass'y	<a href="#">Buy now</a>
5	<a href="#">6898184711</a> O-ring	<a href="#">Buy now</a>
6	<a href="#">6898184011</a> Brush holder assembly	<a href="#">Buy now</a>
7	<a href="#">6898181111</a> Brush 1	<a href="#">Buy now</a>
8	<a href="#">6898181211</a> Brush 2	<a href="#">Buy now</a>
9	<a href="#">6898181310</a> Spring, brush	<a href="#">Buy now</a>
10	<a href="#">6AH8182001</a> Rear bracket assembly	<a href="#">Buy now</a>
11	<a href="#">6898180712</a> Pinion assembly	<a href="#">Buy now</a>
12	<a href="#">68T8185700</a> Pinion stopper set	<a href="#">Buy now</a>
13	<a href="#">6AH8183000</a> Front bracket assembly	<a href="#">Buy now</a>
14	<a href="#">6898182610</a> Bolt	<a href="#">Buy now</a>
15	<a href="#">9751308545</a> Bolt, with washer	<a href="#">Buy now</a>

# Starting Motor




Ref	Part	
16	<a href="#">9751308535</a> Bolt, with washer	<a href="#">Buy now</a>
17	<a href="#">9759508516</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
18	<a href="#">6AH8194200</a> Cover	<a href="#">Buy now</a>
19	<a href="#">6AH8258100</a> Stay, cord clamp	<a href="#">Buy now</a>
20	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>

# Steering



Ref	Part	
1	<a href="#">6AHW0084038D</a> Handle steering assembly	<a href="#">Buy now</a>
2	<a href="#">6AH42101028D</a> Handle, steering	<a href="#">Buy now</a>
3	<a href="#">9010906M86</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">6AH2628800</a> Grommet, cable	<a href="#">Buy now</a>
5	<a href="#">66M4211901</a> Grip, steering handle	<a href="#">Buy now</a>
6	<a href="#">67D4217700</a> Rubber, handle	<a href="#">Buy now</a>
7	<a href="#">65W4213800</a> Lever, throttle	<a href="#">Buy now</a>
8	<a href="#">9015205011</a> Screw, countersunk	<a href="#">Buy now</a>
9	<a href="#">65W4215900</a> Stay	<a href="#">Buy now</a>
10	<a href="#">6G14212600</a> Piece, friction	<a href="#">Buy now</a>
11	<a href="#">65W4212500</a> Bolt, friction adjusting	<a href="#">Buy now</a>
12	<a href="#">9149016010</a> Pin, cotter	<a href="#">Buy now</a>
13	<a href="#">6J04213710</a> Indicator, throttle	<a href="#">Buy now</a>
14	<a href="#">6X44418800</a> Washer	<a href="#">Buy now</a>
15	<a href="#">9050123215</a> Spring (655)	<a href="#">Buy now</a>


# Steering



6AGD300-S200


Ref	Part	
16	<a href="#">9038608004</a> Bush	<a href="#">Buy now</a>
17	<a href="#">6AH2631100</a> Cable, throttle 1	<a href="#">Buy now</a>
18	<a href="#">6AH4455400</a> Plate	<a href="#">Buy now</a>
19	<a href="#">9759506514</a> Bolt(gj3)	<a href="#">Buy now</a>
20	<a href="#">6AH2634E00</a> Protector 1	<a href="#">Buy now</a>
21	<a href="#">6AH4255100</a> Grommet	<a href="#">Buy now</a>
22	<a href="#">9038645001</a> Bush	<a href="#">Buy now</a>
23	<a href="#">9020139008</a> Washer, plate	<a href="#">Buy now</a>
24	<a href="#">9020639001</a> Washer, wave	<a href="#">Buy now</a>
25	<a href="#">9038120001</a> Bush, solid	<a href="#">Buy now</a>
26	<a href="#">6AH42131008D</a> Cover, handle steering	<a href="#">Buy now</a>
27	<a href="#">9759506555</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
28	<a href="#">6AH42532A0</a> Cover	<a href="#">Buy now</a>
29	<a href="#">9011106072</a> Bolt,hex. socket button	<a href="#">Buy now</a>
30	<a href="#">9778060520</a> Screw, tapping(6k8)	<a href="#">Buy now</a>

# Steering



Ref	Part	
31	<a href="#">6AH4411100</a> Handle, gear shift	<a href="#">Buy now</a>
32	<a href="#">9011906M05</a> Bolt, with washer(6l2)	<a href="#">Buy now</a>
33	<a href="#">9038706M86</a> Collar	<a href="#">Buy now</a>
34	<a href="#">9020615M18</a> Washer, wave(6l2)	<a href="#">Buy now</a>
35	<a href="#">6AH4412400</a> Link, shift rod	<a href="#">Buy now</a>
36	<a href="#">9299006200</a> Ybs66-6 washer, plain	<a href="#">Buy now</a>
37	<a href="#">9046818008</a> Clip 620436610000	<a href="#">Buy now</a>
38	<a href="#">6X34419100</a> Indicator, shift	<a href="#">Buy now</a>
39	<a href="#">6AH8257500</a> Engine stop switch assembly	<a href="#">Buy now</a>
40	<a href="#">6828255600</a> Lanyard, stop switch	<a href="#">Buy now</a>
41	<a href="#">6898257Y00</a> Cap	<a href="#">Buy now</a>


# Steering Friction



6AGD300-S210

Ref	Part	
1	<a href="#">6AH4250801</a> Steering friction assembly	<a href="#">Buy now</a>
2	<a href="#">68T4252501</a> Plate, friction	<a href="#">Buy now</a>
3	<a href="#">9011905018</a> Bolt, with washer	<a href="#">Buy now</a>
4	<a href="#">67C4256200</a> Shaft, steering lock	<a href="#">Buy now</a>
5	<a href="#">9020210M56</a> Washer, plate	<a href="#">Buy now</a>
6	<a href="#">68T4256100</a> Knob, steering lock	<a href="#">Buy now</a>
7	<a href="#">6894363300</a> Cover, tilt lever	<a href="#">Buy now</a>
8	<a href="#">65W4252800</a> Plate, friction	<a href="#">Buy now</a>
9	<a href="#">9038705053</a> Collar	<a href="#">Buy now</a>
10	<a href="#">9038705054</a> Collar	<a href="#">Buy now</a>
11	<a href="#">9759505520</a> Bolt, With Washer	<a href="#">Buy now</a>
12	<a href="#">9020910M26</a> Washer	<a href="#">Buy now</a>
13	<a href="#">9018510M14</a> Nut, self-locking	<a href="#">Buy now</a>
14	<a href="#">6AH4252700</a> Plate, friction	<a href="#">Buy now</a>
15	<a href="#">9010108022</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>


## Steering Friction



6AGD300-S210

Ref	Part	
16	<a href="#">9020108065</a> Washer, plate	<a href="#">Buy now</a>
17	<a href="#">68T4315500</a> Mark 1	<a href="#">Buy now</a>
18	<a href="#">90201106M5</a> Washer, plate(3gm)	<a href="#">Buy now</a>


# Steering Guide



6AH1100-F341


Ref	Part	
1	<a href="#">6AH6135000</a> Steering guide attachment kit AP	<a href="#">Buy now</a>
2	<a href="#">9020110M20</a> Washer, plate (663)	<a href="#">Buy now</a>
3	<a href="#">9018509M01</a> Nut, nylon (663)	<a href="#">Buy now</a>
4	<a href="#">9017009M03</a> Nut (689)	<a href="#">Buy now</a>
5	<a href="#">9038710M42</a> Coller (688)	<a href="#">Buy now</a>
6	<a href="#">6E56135500</a> Bolt	<a href="#">Buy now</a>
7	<a href="#">9020110M63</a> Washer, plate	<a href="#">Buy now</a>
8	<a href="#">6E54314501</a> Cap, clamp bracket	<a href="#">Buy now</a>
9	<a href="#">9321016275</a> O-ring	<a href="#">Buy now</a>

# Top Cowling




Ref	Part	
1	<a href="#">6AG4261063</a> Top cowling assembly F15C	<a href="#">Buy now</a>
1	<a href="#">6AG4261071</a> Top cowling assembly F15C	<a href="#">Buy now</a>
1	<a href="#">6AH4261073</a> Top cowling assembly F20B	<a href="#">Buy now</a>
1	<a href="#">6AH4261081</a> Top cowling assembly F20B	<a href="#">Buy now</a>
2	<a href="#">6AH4261A01</a> Top cowling w/o graphics	<a href="#">Buy now</a>
2	<a href="#">6AH4261A10</a> Top cowling w/o graphics	<a href="#">Buy now</a>
3	<a href="#">6AH4265100</a> Hook	<a href="#">Buy now</a>
4	<a href="#">902660M02</a> Rivet (697)	<a href="#">Buy now</a>
5	<a href="#">6AH4261500</a> Seal	<a href="#">Buy now</a>
6	<a href="#">60R4265200</a> Hook	<a href="#">Buy now</a>
7	<a href="#">9759505514</a> Bolt, w/ plain	<a href="#">Buy now</a>
8	<a href="#">6AH4264900</a> Holder, clamp band	<a href="#">Buy now</a>
9	<a href="#">6AH4269710</a> Tuning fork mark	<a href="#">Buy now</a>
10	<a href="#">6AH4273500</a> Protector	<a href="#">Buy now</a>
11	<a href="#">6AH4265600</a> Protector, rubber seal	<a href="#">Buy now</a>

## Top Cowling




Ref	Part	
12	<a href="#">6AG4267720</a> Graphic, front <b>F15C</b>	<a href="#">Buy now</a>
12	<a href="#">6AH4267700</a> Graphic, front <b>F20B</b>	<a href="#">Buy now</a>
13	<a href="#">6AG4267500</a> Graphic, side 1	<a href="#">Buy now</a>
14	<a href="#">6AG4267600</a> Graphic, side 2	<a href="#">Buy now</a>

# Upper Casing




Ref	Part	
1	<a href="#">6AH4113700CA</a> Guide, exhaust	<a href="#">Buy now</a>
2	<a href="#">9310112M63</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">65W4271700</a> Rubber, seal 2	<a href="#">Buy now</a>
4	<a href="#">9709508014</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">9043008143</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
6	<a href="#">9360619M23</a> Pin, dowel	<a href="#">Buy now</a>
7	<a href="#">6AH4113400</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
8	<a href="#">6AH1471100CA</a> Muffler 1 <b>S(17.1")</b>	<a href="#">Buy now</a>
8	<a href="#">6AH14711A0CA</a> Muffler 1 <b>L(22.1")</b>	<a href="#">Buy now</a>
9	<a href="#">9757506525</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
10	<a href="#">6AH4113800</a> Seal, ext. 1	<a href="#">Buy now</a>
11	<a href="#">6AH45111008D</a> Casing, upper <b>S(17.1")</b>	<a href="#">Buy now</a>
11	<a href="#">6AH45111108D</a> Casing, upper <b>L(22.1")</b>	<a href="#">Buy now</a>
12	<a href="#">9757508530</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
13	<a href="#">9360412M07</a> Pin, dowel (688)	<a href="#">Buy now</a>

## Upper Casing



Ref	Part	
14	<a href="#">9759505510</a> Bolt hex. head	<a href="#">Buy now</a>
15	<a href="#">68T4532100</a> Plate	<a href="#">Buy now</a>
16	<a href="#">9709506008</a> Bolt (fj1)	<a href="#">Buy now</a>
17	<a href="#">9048014M54</a> Grommet	<a href="#">Buy now</a>
18	<a href="#">6824531800</a> Bushing, drive shaft L(22.1")	<a href="#">Buy now</a>
19	<a href="#">9342030042</a> Circlip (650) L(22.1")	<a href="#">Buy now</a>

# Valve



6AH1100-F050

Ref	Part	
1	<a href="#">6AH1211100</a> Valve, intake	<a href="#">Buy now</a>
2	<a href="#">6AH1212110</a> Valve, exhaust	<a href="#">Buy now</a>
3	<a href="#">62Y1211600</a> Seat, valve spring	<a href="#">Buy now</a>
4	<a href="#">3YF1211300</a> Spring, valve inner	<a href="#">Buy now</a>
5	<a href="#">30X1211700</a> Retainer, valve spring	<a href="#">Buy now</a>
6	<a href="#">30X1211800</a> Cotter, valve	<a href="#">Buy now</a>
7	<a href="#">51Y1211900</a> Seal, valve stem	<a href="#">Buy now</a>
8	<a href="#">66M1214600</a> Shaft, rocker	<a href="#">Buy now</a>
9	<a href="#">6AH1227900</a> Plate	<a href="#">Buy now</a>
10	<a href="#">9701306012</a> Bolt(gh1)	<a href="#">Buy now</a>
11	<a href="#">9038713006</a> Collar	<a href="#">Buy now</a>
12	<a href="#">90501120A5</a> Spring, compression	<a href="#">Buy now</a>
13	<a href="#">6AH1215100</a> Arm, valve rocker	<a href="#">Buy now</a>
14	<a href="#">64J1215900</a> Screw, valve adjusting	<a href="#">Buy now</a>
15	<a href="#">62Y1215800</a> Nut, lock	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.