



# Yamaha F20GWH 2019

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539

Authorised Yamaha Dealers



# Contents

|                                   |    |
|-----------------------------------|----|
| <b>SCHEDULED SERVICE PARTS</b>    | 4  |
| <b>BOTTOM COWLING</b>             | 5  |
| <b>BRACKET 1</b>                  | 8  |
| <b>BRACKET 2</b>                  | 11 |
| <b>BRACKET 3</b>                  | 14 |
| <b>CONTROL 1</b>                  | 16 |
| <b>CONTROL 2</b>                  | 17 |
| <b>CRANKSHAFT &amp; PISTON</b>    | 19 |
| <b>CYLINDER &amp; CRANKCASE 1</b> | 21 |
| <b>CYLINDER &amp; CRANKCASE 2</b> | 23 |
| <b>ELECTRICAL 1</b>               | 25 |
| <b>ELECTRICAL 2</b>               | 27 |
| <b>ELECTRICAL 3</b>               | 29 |
| <b>ELECTRICAL 4</b>               | 30 |
| <b>ELECTRICAL 5</b>               | 32 |
| <b>ELECTRICAL 6</b>               | 34 |
| <b>FUEL 1</b>                     | 35 |
| <b>FUEL 2</b>                     | 39 |
| <b>FUEL INJECTION PUMP</b>        | 41 |
| <b>FUEL TANK 1</b>                | 43 |
| <b>FUEL TANK 2</b>                | 44 |
| <b>GENERATOR</b>                  | 45 |
| <b>INTAKE 1</b>                   | 46 |
| <b>INTAKE 2</b>                   | 47 |
| <b>LOWER CASING &amp; DRIVE 1</b> | 49 |
| <b>LOWER CASING &amp; DRIVE 2</b> | 53 |
| <b>OIL PAN</b>                    | 55 |
| <b>OIL PUMP</b>                   | 56 |
| <b>OPTIONAL PARTS 1</b>           | 58 |
| <b>OPTIONAL PARTS 2</b>           | 60 |
| <b>OPTIONAL PARTS 3</b>           | 61 |
| <b>OPTIONAL PARTS 4</b>           | 65 |
| <b>OPTIONAL PARTS 5</b>           | 67 |
| <b>OPTIONAL PARTS 6</b>           | 68 |
| <b>OPTIONAL PARTS 7</b>           | 69 |
| <b>POWER TRIM &amp; TILT ASSY</b> | 71 |
| <b>REMO CON ATTACHMENT</b>        | 76 |
| <b>REMOTE CONTROL ASSY</b>        | 78 |
| <b>REMOTE CONTROL BOX</b>         | 82 |
| <b>REPAIR KIT 1</b>               | 83 |
| <b>REPAIR KIT 2</b>               | 84 |
| <b>STARTER</b>                    | 86 |
| <b>STARTING MOTOR</b>             | 89 |
| <b>STEERING</b>                   | 90 |

**STEERING FRICTION** ..... 94


**STEERING GUIDE** ..... 96

**TOP COWLING** ..... 97

**UPPER CASING** ..... 99

**VALVE** ..... 101


## Scheduled Service Parts



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G81132500</a><br>Anode                         | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1241100</a><br>Thermostat                    | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM1241400</a><br>Gasket, cover                 | <a href="#">Buy now</a> |
| 6   | <a href="#">5GH1344060</a><br>Element assembly, oil cleaner | <a href="#">Buy now</a> |
| 7   | <a href="#">9470200418</a><br>Plug, spark (dpr6eb-9)        | <a href="#">Buy now</a> |
| 8   | <a href="#">6D82456300</a><br>Element, filter (with tag)    | <a href="#">Buy now</a> |
| 9   | <a href="#">6D82456400</a><br>Gasket                        | <a href="#">Buy now</a> |
| 10  | <a href="#">9043008143</a><br>Gasket (256-11198-00)         | <a href="#">Buy now</a> |
| 11  | <a href="#">9043014M09</a><br>Gasket                        | <a href="#">Buy now</a> |
| 12  | <a href="#">65W4525100</a><br>Anode                         | <a href="#">Buy now</a> |
| 13  | <a href="#">6644537101</a><br>Tab-trim                      | <a href="#">Buy now</a> |
| 14  | <a href="#">9043008003</a><br>Gasket                        | <a href="#">Buy now</a> |
| 15  | <a href="#">6FMW007801</a><br>Water pump repair kit         | <a href="#">Buy now</a> |




## Bottom Cowling




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM42710008D</a><br>Bottom cowling assembly     | <a href="#">Buy now</a> |
| 2   | <a href="#">68F8511900</a><br>Bolt                          | <a href="#">Buy now</a> |
| 3   | <a href="#">9048021M82</a><br>Grommet                       | <a href="#">Buy now</a> |
| 4   | <a href="#">9038706176</a><br>Collar                        | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM4271600</a><br>Rubber, seal 1                | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM4276100</a><br>Stopper                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM4276110</a><br>Stopper                       | <a href="#">Buy now</a> |
| 7   | <a href="#">9010906316</a><br>Bolt                          | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM4272400</a><br>Grommet                       | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM4272410</a><br>Grommet                       | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM4272500</a><br>Grommet                       | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM4272610</a><br>Grommet                       | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM4280100</a><br>Cowling clamp comp.           | <a href="#">Buy now</a> |
| 12  | <a href="#">97E9506512</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 13  | <a href="#">6BL4439100</a><br>Nipple, hose                  | <a href="#">Buy now</a> |

## Bottom Cowling




| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 14  | <a href="#">6AH4272700</a><br>Grommet             | <a href="#">Buy now</a> |
| 15  | <a href="#">6DR1257200</a><br>Adapter             | <a href="#">Buy now</a> |
| 16  | <a href="#">6R31258100</a><br>Joint, hose 1       | <a href="#">Buy now</a> |
| 17  | <a href="#">6R31258200</a><br>Joint, hose 2       | <a href="#">Buy now</a> |
| 18  | <a href="#">6R31258300</a><br>Gasket, hose joint  | <a href="#">Buy now</a> |
| 19  | <a href="#">9778060520</a><br>Screw, tapping(6k8) | <a href="#">Buy now</a> |
| 20  | <a href="#">9046511M10</a><br>Clamp               | <a href="#">Buy now</a> |
| 21  | <a href="#">9044511182</a><br>Hose (I370)         | <a href="#">Buy now</a> |
| 22  | <a href="#">6AH4272600</a><br>Grommet             | <a href="#">Buy now</a> |
| 23  | <a href="#">6H44272600</a><br>Grommet             | <a href="#">Buy now</a> |
| 24  | <a href="#">6BG4238400</a><br>Seal, cap           | <a href="#">Buy now</a> |
| 25  | <a href="#">6BG4272400</a><br>Grommet             | <a href="#">Buy now</a> |
| 27  | <a href="#">6H44274800</a><br>Grommet             | <a href="#">Buy now</a> |
| 28  | <a href="#">6FM4274100</a><br>Apron               | <a href="#">Buy now</a> |
| 29  | <a href="#">6FM4277100</a><br>Apron               | <a href="#">Buy now</a> |

## Bottom Cowling




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 30  | <a href="#">9015906062</a><br>Screw, with washer       | <a href="#">Buy now</a> |
| 31  | <a href="#">9048013M24</a><br>Grommet (6e9)            | <a href="#">Buy now</a> |
| 32  | <a href="#">6FM4273500</a><br>Protector                | <a href="#">Buy now</a> |
| 33  | <a href="#">90183061A8</a><br>Nut, spring              | <a href="#">Buy now</a> |
| 34  | <a href="#">9011106144</a><br>Bolt, hex. socket button | <a href="#">Buy now</a> |
| 36  | <a href="#">6P24439100</a><br>Nipple, hose             | <a href="#">Buy now</a> |
| 38  | <a href="#">6EE4279440</a><br>Label, warning (general) | <a href="#">Buy now</a> |
| 39  | <a href="#">6EE4279450</a><br>Label, warning (general) | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM43111008D</a><br>Bracket, clamp 1    | <a href="#">Buy now</a> |
| 2   | <a href="#">6E04311801</a><br>Handle, transom clamp | <a href="#">Buy now</a> |
| 3   | <a href="#">9024304M01</a><br>Pin(6a1)              | <a href="#">Buy now</a> |
| 4   | <a href="#">6E74311600</a><br>Screw, transom clamp  | <a href="#">Buy now</a> |
| 5   | <a href="#">6484311401</a><br>Pad, transom clamp    | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM43112008D</a><br>Bracket, clamp 2    | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM4313110</a><br>Bolt, clamp bracket   | <a href="#">Buy now</a> |
| 12  | <a href="#">9038622MA4</a><br>Bush                  | <a href="#">Buy now</a> |
| 13  | <a href="#">9018522043</a><br>Nut, self-locking     | <a href="#">Buy now</a> |
| 14  | <a href="#">9038706M13</a><br>Collar(6h6)           | <a href="#">Buy now</a> |
| 15  | <a href="#">9010106M18</a><br>Bolt(6l5)             | <a href="#">Buy now</a> |
| 16  | <a href="#">9299506600</a><br>Washer, plain (646)   | <a href="#">Buy now</a> |
| 17  | <a href="#">9538006700</a><br>Nut                   | <a href="#">Buy now</a> |
| 18  | <a href="#">6L24316001</a><br>Tilt rod assembly     | <a href="#">Buy now</a> |
| 19  | <a href="#">6894316500</a><br>Plate, tilt lock      | <a href="#">Buy now</a> |

# Bracket 1




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 20  | <a href="#">9169030008</a><br>Pin. spring(656)                | <a href="#">Buy now</a> |
| 21  | <a href="#">9050210M07</a><br>Spring, conical(6k3)            | <a href="#">Buy now</a> |
| 22  | <a href="#">6FM4273100</a><br>Carrying handle                 | <a href="#">Buy now</a> |
| 23  | <a href="#">9010908043</a><br>Bolt                            | <a href="#">Buy now</a> |
| 24  | <a href="#">6FM43311008D</a><br>Bracket, swivel 1<br>S(16.7") | <a href="#">Buy now</a> |
| 24  | <a href="#">6FM43311108D</a><br>Bracket, swivel 1<br>L(21.7") | <a href="#">Buy now</a> |
| 25  | <a href="#">9370006M03</a><br>Nipple, grease(6a1)             | <a href="#">Buy now</a> |
| 26  | <a href="#">6AH8212700</a><br>Wire, lead 2                    | <a href="#">Buy now</a> |
| 27  | <a href="#">6FM4363100</a><br>Lever, tilt                     | <a href="#">Buy now</a> |
| 28  | <a href="#">6FM4361600</a><br>Rod, tilt lock                  | <a href="#">Buy now</a> |
| 29  | <a href="#">6FM4364600</a><br>Shaft, lever                    | <a href="#">Buy now</a> |
| 30  | <a href="#">6FM4364100</a><br>Lever, tilt                     | <a href="#">Buy now</a> |
| 31  | <a href="#">9010908M87</a><br>Bolt                            | <a href="#">Buy now</a> |
| 32  | <a href="#">6FM4361700</a><br>Rod, tilt lock                  | <a href="#">Buy now</a> |
| 33  | <a href="#">6FM4335000</a><br>Receiver assembly               | <a href="#">Buy now</a> |

Bracket 1



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 34  | <a href="#">6FM4365600</a><br>Spring, reverse lock 1 | <a href="#">Buy now</a> |
| 35  | <a href="#">6FM4362400</a><br>Plate, tilt rock       | <a href="#">Buy now</a> |
| 36  | <a href="#">9038706321</a><br>Collar                 | <a href="#">Buy now</a> |
| 37  | <a href="#">6FM4365610</a><br>Spring, reverse lock 1 | <a href="#">Buy now</a> |
| 38  | <a href="#">6FM4361300</a><br>Arm, tilt lock         | <a href="#">Buy now</a> |
| 39  | <a href="#">6L24333610</a><br>Pin                    | <a href="#">Buy now</a> |
| 40  | <a href="#">9908005600</a><br>Circlip(22k)           | <a href="#">Buy now</a> |
| 41  | <a href="#">6J84361101</a><br>Shaft, tilt lock       | <a href="#">Buy now</a> |
| 43  | <a href="#">6FM4362700</a><br>Stopper                | <a href="#">Buy now</a> |
| 44  | <a href="#">9010906M84</a><br>Bolt                   | <a href="#">Buy now</a> |
| 45  | <a href="#">9020610M24</a><br>Washer, wave           | <a href="#">Buy now</a> |
| 46  | <a href="#">9010108M88</a><br>Bolt (6g8)             | <a href="#">Buy now</a> |
| 47  | <a href="#">9299008600</a><br>Washer, plain (663)    | <a href="#">Buy now</a> |
| 48  | <a href="#">9018508057</a><br>Nut, nylon (6j8)       | <a href="#">Buy now</a> |
| 49  | <a href="#">9020108MA4</a><br>Washer, plate (6g8)    | <a href="#">Buy now</a> |

## Bracket 2




  
6HY1100DT290

| Ref | Part                                                                           |                         |
|-----|--------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">69A43111018D</a><br>Bracket, clamp 1                               | <a href="#">Buy now</a> |
| 2   | <a href="#">6E04311801</a><br>Handle, transom clamp                            | <a href="#">Buy now</a> |
| 3   | <a href="#">9024304M01</a><br>Pin(6a1)                                         | <a href="#">Buy now</a> |
| 4   | <a href="#">6E74311600</a><br>Screw, transom clamp                             | <a href="#">Buy now</a> |
| 5   | <a href="#">6484311401</a><br>Pad, transom clamp                               | <a href="#">Buy now</a> |
| 6   | <a href="#">69A43112028D</a><br>Bracket, clamp 2                               | <a href="#">Buy now</a> |
| 11  | <a href="#">9038614MA1</a><br>Bush                                             | <a href="#">Buy now</a> |
| 12  | <a href="#">65W4319100</a><br>Shaft, stopper                                   | <a href="#">Buy now</a> |
| 13  | <a href="#">65W4319200</a><br>Knob, stopper                                    | <a href="#">Buy now</a> |
| 14  | <a href="#">9169030018</a><br>926-51502-00 pin, spring (700)                   | <a href="#">Buy now</a> |
| 15  | <a href="#">9010906MA1</a><br>Bolt                                             | <a href="#">Buy now</a> |
| 16  | <a href="#">69A4313100</a><br>Bolt, clamp bracket<br><b>FOR REMOTE CONTROL</b> | <a href="#">Buy now</a> |
| 17  | <a href="#">9038622MA4</a><br>Bush                                             | <a href="#">Buy now</a> |
| 18  | <a href="#">69A4311300</a><br>Plate, clamp bracket                             | <a href="#">Buy now</a> |
| 19  | <a href="#">6G54314501</a><br>Cap, clamp bracket                               | <a href="#">Buy now</a> |



## Bracket 2




  
6HY1100DT290

| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 20  | <a href="#">9018522043</a><br>Nut, self-locking               | <a href="#">Buy now</a> |
| 21  | <a href="#">6HY43311008D</a><br>Bracket, swivel 1<br>S(16.7") | <a href="#">Buy now</a> |
| 21  | <a href="#">6HY43311108D</a><br>Bracket, swivel 1<br>L(21.7") | <a href="#">Buy now</a> |
| 22  | <a href="#">9370006M03</a><br>Nipple, grease(6a1)             | <a href="#">Buy now</a> |
| 23  | <a href="#">6AH8212700</a><br>Wire, lead 2                    | <a href="#">Buy now</a> |
| 24  | <a href="#">9044614MH7</a><br>Hose                            | <a href="#">Buy now</a> |
| 25  | <a href="#">9046513M97</a><br>Clamp                           | <a href="#">Buy now</a> |
| 26  | <a href="#">69G4381800</a><br>Pin, lower shock mount          | <a href="#">Buy now</a> |
| 27  | <a href="#">69A4315500</a><br>Mark 1                          | <a href="#">Buy now</a> |
| 28  | <a href="#">9038616MA7</a><br>Bush                            | <a href="#">Buy now</a> |
| 29  | <a href="#">9038616MA8</a><br>Bush                            | <a href="#">Buy now</a> |
| 30  | <a href="#">9038716M02</a><br>Collar                          | <a href="#">Buy now</a> |
| 31  | <a href="#">9020108M00</a><br>Washer, plate(6e0)              | <a href="#">Buy now</a> |
| 32  | <a href="#">9708008016</a><br>Bolt                            | <a href="#">Buy now</a> |
| 33  | <a href="#">9024912M36</a><br>Pin                             | <a href="#">Buy now</a> |




## Bracket 2



  
6HY1100DT290


| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 34  | <a href="#">9038112M10</a><br>Bush, solid                   | <a href="#">Buy now</a> |
| 35  | <a href="#">9038112M11</a><br>Bush, solid                   | <a href="#">Buy now</a> |
| 36  | <a href="#">9908010600</a><br>Circlip                       | <a href="#">Buy now</a> |
| 37  | <a href="#">9011008121</a><br>Bolt, hexagon socket head     | <a href="#">Buy now</a> |
| 38  | <a href="#">9018508057</a><br>Nut, nylon (6j8)              | <a href="#">Buy now</a> |
| 39  | <a href="#">9299008600</a><br>Washer, plain (663)           | <a href="#">Buy now</a> |
| 40  | <a href="#">9033808M19</a><br>Plug<br>S(16.7")              | <a href="#">Buy now</a> |
| 41  | <a href="#">65W4525100</a><br>Anode                         | <a href="#">Buy now</a> |
| 42  | <a href="#">9010106020</a><br>Bolt                          | <a href="#">Buy now</a> |
| 43  | <a href="#">63V8212700</a><br>Wire, lead 2                  | <a href="#">Buy now</a> |
| 44  | <a href="#">97E9506510</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 45  | <a href="#">9010108M88</a><br>Bolt (6g8)                    | <a href="#">Buy now</a> |
| 48  | <a href="#">9020108MA4</a><br>Washer, plate (6g8)           | <a href="#">Buy now</a> |

## Bracket 3




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM42511008D</a><br>Bracket, steering<br>S(16.7") | <a href="#">Buy now</a> |
| 1   | <a href="#">6FM42511108D</a><br>Bracket, steering<br>L(21.7") | <a href="#">Buy now</a> |
| 2   | <a href="#">9038145001</a><br>Bush, solid                     | <a href="#">Buy now</a> |
| 3   | <a href="#">9038638M32</a><br>Bush(6e5)                       | <a href="#">Buy now</a> |
| 4   | <a href="#">9321037MH7</a><br>O-ring(61u)                     | <a href="#">Buy now</a> |
| 5   | <a href="#">9038638002</a><br>Bush                            | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM44514108D</a><br>Mount damper, upper side      | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM4453200</a><br>Stopper, upper mount            | <a href="#">Buy now</a> |
| 8   | <a href="#">9010908241</a><br>Bolt                            | <a href="#">Buy now</a> |
| 9   | <a href="#">9020108120</a><br>Washer, plate                   | <a href="#">Buy now</a> |
| 10  | <a href="#">9020109014</a><br>Washer, plate                   | <a href="#">Buy now</a> |
| 11  | <a href="#">9538008800</a><br>Nut crown (2g2)                 | <a href="#">Buy now</a> |
| 12  | <a href="#">97E7508530</a><br>Bolt, hexagon w/w deep recess   | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM44551008D</a><br>Housing, lower mount rubber 1 | <a href="#">Buy now</a> |
| 14  | <a href="#">6FM44552008D</a><br>Housing, lower mount rubber 2 | <a href="#">Buy now</a> |

## Bracket 3




| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 15  | <a href="#">97E7508545</a><br>Bolt, hexagon w/w deep recess          | <a href="#">Buy now</a> |
| 16  | <a href="#">6FM4455511</a><br>Mount damper, lower side               | <a href="#">Buy now</a> |
| 17  | <a href="#">9020110077</a><br>Washer, plate                          | <a href="#">Buy now</a> |
| 18  | <a href="#">9010108M02</a><br>Bolt, hexagon (676)                    | <a href="#">Buy now</a> |
| 19  | <a href="#">9299510600</a><br>Washer, plate                          | <a href="#">Buy now</a> |
| 20  | <a href="#">6E54457500</a><br>Damper, lower mount rubber<br>L(21.7") | <a href="#">Buy now</a> |
| 20  | <a href="#">6FM4457500</a><br>Damper, lower mount rubber<br>S(16.7") | <a href="#">Buy now</a> |
| 22  | <a href="#">9020108M08</a><br>Washer, plate (679)                    | <a href="#">Buy now</a> |
| 23  | <a href="#">6FM44553008D</a><br>Cover, lower mount                   | <a href="#">Buy now</a> |
| 25  | <a href="#">9011610064</a><br>Bolt, stud                             | <a href="#">Buy now</a> |
| 26  | <a href="#">65W4851101</a><br>Hook, steering                         | <a href="#">Buy now</a> |
| 27  | <a href="#">9018510027</a><br>Nut, self-locking                      | <a href="#">Buy now</a> |
| 28  | <a href="#">9020110049</a><br>Washer, plate                          | <a href="#">Buy now</a> |

## Control 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM4412100</a><br>Lever, shift rod          | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4414300</a><br>Rod, shift<br>S(16.7")    | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4414310</a><br>Rod, shift<br>L(21.7")    | <a href="#">Buy now</a> |
| 3   | <a href="#">9017006015</a><br>Connector, shift rod      | <a href="#">Buy now</a> |
| 4   | <a href="#">9538006700</a><br>Nut                       | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM4166100</a><br>Bracket 1                 | <a href="#">Buy now</a> |
| 6   | <a href="#">9010906M86</a><br>Bolt                      | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM4166200</a><br>Bracket 2                 | <a href="#">Buy now</a> |
| 9   | <a href="#">66R4411600</a><br>Spring                    | <a href="#">Buy now</a> |
| 10  | <a href="#">66R4411800</a><br>Bracket                   | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM4834400</a><br>Cable end, remote control | <a href="#">Buy now</a> |
| 13  | <a href="#">9046818008</a><br>Clip 620436610000         | <a href="#">Buy now</a> |
| 14  | <a href="#">63D4853800</a><br>Clamp, cable 1            | <a href="#">Buy now</a> |

## Control 2



| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM4412100</a><br>Lever, shift rod          | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4414300</a><br>Rod, shift<br>S(16.7")    | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4414310</a><br>Rod, shift<br>L(21.7")    | <a href="#">Buy now</a> |
| 3   | <a href="#">9017006015</a><br>Connector, shift rod      | <a href="#">Buy now</a> |
| 4   | <a href="#">9538006700</a><br>Nut                       | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM4166100</a><br>Bracket 1                 | <a href="#">Buy now</a> |
| 6   | <a href="#">9010906M86</a><br>Bolt                      | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM4166200</a><br>Bracket 2                 | <a href="#">Buy now</a> |
| 9   | <a href="#">66R4411600</a><br>Spring                    | <a href="#">Buy now</a> |
| 10  | <a href="#">66R4411800</a><br>Bracket                   | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM4834400</a><br>Cable end, remote control | <a href="#">Buy now</a> |
| 13  | <a href="#">9046818008</a><br>Clip 620436610000         | <a href="#">Buy now</a> |
| 14  | <a href="#">63D4853800</a><br>Clamp, cable 1            | <a href="#">Buy now</a> |
| 15  | <a href="#">6FM4412500</a><br>Lever, shift rod          | <a href="#">Buy now</a> |
| 16  | <a href="#">6FM4419200</a><br>Link, shift rod           | <a href="#">Buy now</a> |


## Control 2



6FM1100DR260


| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 18  | <a href="#">6824123750</a><br>Joint, link 2            | <a href="#">Buy now</a> |
| 19  | <a href="#">6H44123700</a><br>Joint, link              | <a href="#">Buy now</a> |
| 20  | <a href="#">9538005700</a><br>Nut (656)                | <a href="#">Buy now</a> |
| 21  | <a href="#">6FM4215700</a><br>Lever, throttle          | <a href="#">Buy now</a> |
| 22  | <a href="#">6FM4128300</a><br>Lever, free accel.       | <a href="#">Buy now</a> |
| 23  | <a href="#">9038706M59</a><br>Collar (6h3)             | <a href="#">Buy now</a> |
| 24  | <a href="#">9020106M62</a><br>Washer, plate (6e5)      | <a href="#">Buy now</a> |
| 25  | <a href="#">95D9506045</a><br>Bolt, flange deep recess | <a href="#">Buy now</a> |
| 26  | <a href="#">95D9506016</a><br>Bolt, flange deep recess | <a href="#">Buy now</a> |
| 27  | <a href="#">6FM1457100</a><br>Bracket, throttle        | <a href="#">Buy now</a> |
| 31  | <a href="#">6FM8239800</a><br>Plate 3                  | <a href="#">Buy now</a> |

# Crankshaft & Piston



| Ref | Part                                                                  |                         |
|-----|-----------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM1141100</a><br>Crankshaft                              | <a href="#">Buy now</a> |
| 2   | <a href="#">6AH1141600</a><br>Plane bearing, crankshaft 1<br>UR BROWN | <a href="#">Buy now</a> |
| 2   | <a href="#">6AH1141610</a><br>Plane bearing, crankshaft 1<br>UR BLACK | <a href="#">Buy now</a> |
| 2   | <a href="#">6AH1141620</a><br>Plane bearing, crankshaft 1<br>UR BLUE  | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1165001</a><br>Connecting rod assembly                 | <a href="#">Buy now</a> |
| 4   | <a href="#">6AH1165400</a><br>Bolt, connecting rod                    | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM1163100</a><br>Piston (std)                            | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM1163500</a><br>Piston (0.25mm o/s)<br>AP               | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM1163600</a><br>Piston (0.50mm o/s)<br>AP               | <a href="#">Buy now</a> |
| 6   | <a href="#">67C1160300</a><br>Piston ring set (std)                   | <a href="#">Buy now</a> |
| 6   | <a href="#">67C1160400</a><br>Piston ring set (0.25mm o/s)<br>AP      | <a href="#">Buy now</a> |
| 6   | <a href="#">67C1160500</a><br>Piston ring set (0.50mm o/s)<br>AP      | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM1163300</a><br>Pin, piston                             | <a href="#">Buy now</a> |
| 8   | <a href="#">9345017129</a><br>Circlip(1ar)                            | <a href="#">Buy now</a> |
| 9   | <a href="#">9310237004</a><br>Oil seal                                | <a href="#">Buy now</a> |

## Crankshaft & Piston




END  
6FM1100DR040

| Ref | Part                                   |                         |
|-----|----------------------------------------|-------------------------|
| 10  | <a href="#">9310225014</a><br>Oil seal | <a href="#">Buy now</a> |




## Cylinder & Crankcase 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FMW009B011S</a><br>Cylinder block assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM1510000</a><br>Crankcase assembly        | <a href="#">Buy now</a> |
| 3   | <a href="#">9953008012</a><br>Pin, dowel(6g8)           | <a href="#">Buy now</a> |
| 4   | <a href="#">9011908093</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 5   | <a href="#">9751306540</a><br>Bolt, with washer(6l2)    | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM1135100</a><br>Gasket, cylinder          | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM1111900</a><br>Hanger, engine            | <a href="#">Buy now</a> |
| 8   | <a href="#">9010506M07</a><br>Bolt (689)                | <a href="#">Buy now</a> |
| 9   | <a href="#">6G81132500</a><br>Anode                     | <a href="#">Buy now</a> |
| 10  | <a href="#">9898005025</a><br>Screw, panhead (a93)      | <a href="#">Buy now</a> |
| 11  | <a href="#">6G811197A0</a><br>Plug, blind               | <a href="#">Buy now</a> |
| 12  | <a href="#">9321013M63</a><br>O-ring (6g8)              | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM1241100</a><br>Thermostat                | <a href="#">Buy now</a> |
| 14  | <a href="#">6FM1241200</a><br>Seal, thermostat          | <a href="#">Buy now</a> |
| 15  | <a href="#">6FM12413001S</a><br>Cover, thermostat       | <a href="#">Buy now</a> |

# Cylinder & Crankcase 1




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6FM1241400</a><br>Gasket, cover                 | <a href="#">Buy now</a> |
| 17  | <a href="#">9011906MA3</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 20  | <a href="#">9046508M83</a><br>Clamp                         | <a href="#">Buy now</a> |
| 21  | <a href="#">95D9506016</a><br>Bolt, flange deep recess      | <a href="#">Buy now</a> |
| 22  | <a href="#">5GH1344060</a><br>Element assembly, oil cleaner | <a href="#">Buy now</a> |
| 23  | <a href="#">6C512858A0</a><br>Bolt, union                   | <a href="#">Buy now</a> |

## Cylinder & Crankcase 2




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6HYW009A001S</a><br>Cylinder head complete    | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM1111001S</a><br>Head, cylinder 1           | <a href="#">Buy now</a> |
| 3   | <a href="#">6AH1113310</a><br>Guide, valve 1              | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM1118100</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 5   | <a href="#">9953008012</a><br>Pin, dowel(6g8)             | <a href="#">Buy now</a> |
| 6   | <a href="#">9010509010</a><br>Bolt, flange                | <a href="#">Buy now</a> |
| 7   | <a href="#">9011906MA3</a><br>Bolt, with washer           | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM1119100</a><br>Cover, cylinder head 1      | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM1135600</a><br>Seal, cylinder 2            | <a href="#">Buy now</a> |
| 10  | <a href="#">9010506M07</a><br>Bolt (689)                  | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM1116800</a><br>Cover, breather             | <a href="#">Buy now</a> |
| 12  | <a href="#">9760704210</a><br>Screw, pan head with washer | <a href="#">Buy now</a> |
| 13  | <a href="#">6G81132500</a><br>Anode                       | <a href="#">Buy now</a> |
| 14  | <a href="#">9898005025</a><br>Screw, panhead (a93)        | <a href="#">Buy now</a> |
| 15  | <a href="#">6G811197A0</a><br>Plug, blind                 | <a href="#">Buy now</a> |

## Cylinder & Crankcase 2




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">9321013M63</a><br>O-ring (6g8)           | <a href="#">Buy now</a> |
| 17  | <a href="#">9046508059</a><br>Clamp                  | <a href="#">Buy now</a> |
| 18  | <a href="#">6HY1540700</a><br>Element 1              | <a href="#">Buy now</a> |
| 19  | <a href="#">6G81536300</a><br>Plug, oil              | <a href="#">Buy now</a> |
| 20  | <a href="#">9321024M79</a><br>O-ring                 | <a href="#">Buy now</a> |
| 21  | <a href="#">6FM2475H00</a><br>Bracket, seat lever 1  | <a href="#">Buy now</a> |
| 22  | <a href="#">9046513M18</a><br>Clamp                  | <a href="#">Buy now</a> |
| 23  | <a href="#">9470200418</a><br>Plug, spark (dpr6eb-9) | <a href="#">Buy now</a> |

# Electrical 1




| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6HY8591A00</a><br>Engine control unit assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM8554600</a><br>Band                         | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM8194800</a><br>Bracket                      | <a href="#">Buy now</a> |
| 4   | <a href="#">64J8551600</a><br>Spacer                       | <a href="#">Buy now</a> |
| 5   | <a href="#">69M4275801</a><br>Collar                       | <a href="#">Buy now</a> |
| 6   | <a href="#">9011906M56</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 7   | <a href="#">68V8554801</a><br>Holder                       | <a href="#">Buy now</a> |
| 8   | <a href="#">9778060620</a><br>Screw, tapping(6k8)          | <a href="#">Buy now</a> |
| 9   | <a href="#">9046420181</a><br>Clamp(4ap)                   | <a href="#">Buy now</a> |
| 10  | <a href="#">9046513M18</a><br>Clamp                        | <a href="#">Buy now</a> |
| 11  | <a href="#">9046513M11</a><br>Clamp (6e5)                  | <a href="#">Buy now</a> |
| 12  | <a href="#">9046513M97</a><br>Clamp                        | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM8196500</a><br>Condenser, smoothing         | <a href="#">Buy now</a> |
| 14  | <a href="#">64J8250400</a><br>Oil pressure switch assembly | <a href="#">Buy now</a> |
| 15  | <a href="#">68V8131500</a><br>Lead wire assembly           | <a href="#">Buy now</a> |

## Electrical 1




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 16  | <a href="#">6CJ8579000</a><br>Thermosensor assembly | <a href="#">Buy now</a> |
| 17  | <a href="#">9043014115</a><br>Gasket (663)          | <a href="#">Buy now</a> |

## Electrical 2



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6F58557013</a><br>Ignition coil assembly         | <a href="#">Buy now</a> |
| 2   | <a href="#">6AH8237000</a><br>Plug cap assembly              | <a href="#">Buy now</a> |
| 3   | <a href="#">9048025003</a><br>Grommet                        | <a href="#">Buy now</a> |
| 4   | <a href="#">9046407M41</a><br>Clamp(62y)                     | <a href="#">Buy now</a> |
| 5   | <a href="#">67F8236100</a><br>Clamp, cord                    | <a href="#">Buy now</a> |
| 6   | <a href="#">9046409018</a><br>Clamp                          | <a href="#">Buy now</a> |
| 7   | <a href="#">9046411121</a><br>Clamp(4gy)                     | <a href="#">Buy now</a> |
| 8   | <a href="#">95D9506020</a><br>Bolt, flange deep recess       | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM8231600</a><br>Bracket, ignition coil         | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM8153900</a><br>Plate, coil                    | <a href="#">Buy now</a> |
| 12  | <a href="#">95D9506016</a><br>Bolt, flange deep recess       | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM8196000</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM8196010</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 15  | <a href="#">6FM8711E00</a><br>Stay, rectifier                | <a href="#">Buy now</a> |
| 16  | <a href="#">9046511M10</a><br>Clamp                          | <a href="#">Buy now</a> |


## Electrical 2



| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 17  | <a href="#">6FM8253500</a><br>Grommet           | <a href="#">Buy now</a> |
| 18  | <a href="#">6FM8254500</a><br>Grommet           | <a href="#">Buy now</a> |
| 19  | <a href="#">9038706289</a><br>Collar            | <a href="#">Buy now</a> |
| 20  | <a href="#">9011906M88</a><br>Bolt, with washer | <a href="#">Buy now</a> |




## Electrical 3




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">9751308545</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 2   | <a href="#">9751308535</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM8194000</a><br>Starter relay assembly        | <a href="#">Buy now</a> |
| 4   | <a href="#">6AH8211700</a><br>Wire, lead                    | <a href="#">Buy now</a> |
| 5   | <a href="#">97E9506610</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 6   | <a href="#">68V8195000</a><br>Relay assembly                | <a href="#">Buy now</a> |
| 7   | <a href="#">9778060620</a><br>Screw, tapping(6k8)           | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM8210500</a><br>Battery cable (l: 2.0m)       | <a href="#">Buy now</a> |
| 9   | <a href="#">6P28211900</a><br>Cover, lead wire              | <a href="#">Buy now</a> |
| 10  | <a href="#">97E9508516</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 11  | <a href="#">63P8195000</a><br>Relay assembly                | <a href="#">Buy now</a> |
| 12  | <a href="#">95D9506020</a><br>Bolt, flange deep recess      | <a href="#">Buy now</a> |
| 14  | <a href="#">6P28183X00</a><br>Cap, terminal                 | <a href="#">Buy now</a> |
| 15  | <a href="#">9046513M11</a><br>Clamp (6e5)                   | <a href="#">Buy now</a> |
| 16  | <a href="#">67F2812A00</a><br>Puller, fuse                  | <a href="#">Buy now</a> |

## Electrical 4




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM8259001</a><br>Wire harness assembly         | <a href="#">Buy now</a> |
| 1   | <a href="#">6FM8259011</a><br>Wire harness assembly         | <a href="#">Buy now</a> |
| 1   | <a href="#">6FM8259021</a><br>Wire harness assembly         | <a href="#">Buy now</a> |
| 1   | <a href="#">6FM8259041</a><br>Wire harness assembly         | <a href="#">Buy now</a> |
| 2   | <a href="#">9046409M47</a><br>Clamp(65j)                    | <a href="#">Buy now</a> |
| 3   | <a href="#">9046412002</a><br>Clamp                         | <a href="#">Buy now</a> |
| 4   | <a href="#">6Y88258211</a><br>White cap 1 (4pin)            | <a href="#">Buy now</a> |
| 5   | <a href="#">67F8215100</a><br>Fuse                          | <a href="#">Buy now</a> |
| 6   | <a href="#">67F8215B10</a><br>Cap (yellow)                  | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM8258200</a><br>Cap 1 (3p)                    | <a href="#">Buy now</a> |
| 8   | <a href="#">97E9506516</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 9   | <a href="#">9046511M52</a><br>Clamp(6e7)                    | <a href="#">Buy now</a> |
| 10  | <a href="#">9046513M11</a><br>Clamp (6e5)                   | <a href="#">Buy now</a> |
| 11  | <a href="#">9046428003</a><br>Clamp                         | <a href="#">Buy now</a> |
| 12  | <a href="#">9046511M59</a><br>Clamp(63m)                    | <a href="#">Buy now</a> |

## Electrical 4




| Ref | Part                                         |                         |
|-----|----------------------------------------------|-------------------------|
| 13  | <a href="#">6FM8198000</a><br>Diode assembly | <a href="#">Buy now</a> |

## Electrical 5




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">62Y8430100</a><br>Pilot light assembly 1      | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM8358900</a><br>Gasket                      | <a href="#">Buy now</a> |
| 3   | <a href="#">9798506212</a><br>Screw, with washer(6h3)     | <a href="#">Buy now</a> |
| 4   | <a href="#">67C8541500</a><br>Mark, signal lamp           | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM8238800</a><br>Plate                       | <a href="#">Buy now</a> |
| 6   | <a href="#">9010906M86</a><br>Bolt                        | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM8235500</a><br>Grommet                     | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM1577400</a><br>Stay 4                      | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM8254000</a><br>Neutral switch assembly     | <a href="#">Buy now</a> |
| 10  | <a href="#">9046412183</a><br>Clamp(jn2)                  | <a href="#">Buy now</a> |
| 11  | <a href="#">65W8187000</a><br>Starting switch assembly    | <a href="#">Buy now</a> |
| 11  | <a href="#">6G14272500</a><br>Grommet                     | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM4272300</a><br>Cover, bottom               | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM8256301</a><br>Trim & tilt switch assembly | <a href="#">Buy now</a> |
| 13  | <a href="#">60V8259F00</a><br>Switch assembly             | <a href="#">Buy now</a> |

## Electrical 5




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 14  | <a href="#">6FM8258800</a><br>Plate                   | <a href="#">Buy now</a> |
| 15  | <a href="#">9038704001</a><br>Collar                  | <a href="#">Buy now</a> |
| 16  | <a href="#">9798504116</a><br>Screw, with washer(61b) | <a href="#">Buy now</a> |
| 17  | <a href="#">9046511M10</a><br>Clamp                   | <a href="#">Buy now</a> |
| 18  | <a href="#">9046413227</a><br>Clamp                   | <a href="#">Buy now</a> |

## Electrical 6




| Ref | Part                                          |                         |
|-----|-----------------------------------------------|-------------------------|
| 1   | <a href="#">6FM8186001</a><br>Switch assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4217600</a><br>Stay 2          | <a href="#">Buy now</a> |
| 3   | <a href="#">9044610M82</a><br>Hose            | <a href="#">Buy now</a> |
| 4   | <a href="#">9046410M59</a><br>Clamp           | <a href="#">Buy now</a> |
| 5   | <a href="#">9046416001</a><br>Clamp           | <a href="#">Buy now</a> |

# Fuel 1



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G12430410</a><br>Fuel pipe joint comp. 1    | <a href="#">Buy now</a> |
| 2   | <a href="#">61N2432900</a><br>Seal                       | <a href="#">Buy now</a> |
| 3   | <a href="#">95D9506020</a><br>Bolt, flange deep recess   | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM2431110</a><br>Pipe, fuel 1               | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM2456000</a><br>Filter assembly            | <a href="#">Buy now</a> |
| 6   | <a href="#">6D82456300</a><br>Element, filter (with tag) | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM2452100</a><br>Cup, filter                | <a href="#">Buy now</a> |
| 8   | <a href="#">6D82456400</a><br>Gasket                     | <a href="#">Buy now</a> |
| 9   | <a href="#">6D82446900</a><br>Float, water level         | <a href="#">Buy now</a> |
| 10  | <a href="#">6D82451900</a><br>Clip                       | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM2456600</a><br>Bracket, filter            | <a href="#">Buy now</a> |
| 12  | <a href="#">9538008600</a><br>Nut (661)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">95D7506016</a><br>Bolt, flange deep recess   | <a href="#">Buy now</a> |
| 14  | <a href="#">6FM2431210</a><br>Pipe 2                     | <a href="#">Buy now</a> |
| 15  | <a href="#">6AH2441070</a><br>Fuel pump assembly         | <a href="#">Buy now</a> |


# Fuel 1



| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 16  | <a href="#">6AH2441370</a><br>Body 2            | <a href="#">Buy now</a> |
| 17  | <a href="#">6A02442101</a><br>Valve, check      | <a href="#">Buy now</a> |
| 18  | <a href="#">66M2441111</a><br>Diaphragm         | <a href="#">Buy now</a> |
| 19  | <a href="#">66M2442300</a><br>Spring, diaphragm | <a href="#">Buy now</a> |
| 20  | <a href="#">66M1313110</a><br>Plunger           | <a href="#">Buy now</a> |
| 21  | <a href="#">66M2445400</a><br>Spring            | <a href="#">Buy now</a> |
| 22  | <a href="#">66M2444400</a><br>Screw             | <a href="#">Buy now</a> |
| 23  | <a href="#">66M2447101</a><br>Diaphragm         | <a href="#">Buy now</a> |
| 24  | <a href="#">6E71432500</a><br>Screw, pan head   | <a href="#">Buy now</a> |
| 25  | <a href="#">9538004600</a><br>Nut,hex           | <a href="#">Buy now</a> |
| 26  | <a href="#">66M2437400</a><br>Pin               | <a href="#">Buy now</a> |
| 27  | <a href="#">9010106032</a><br>Bolt              | <a href="#">Buy now</a> |
| 28  | <a href="#">9038706320</a><br>Collar            | <a href="#">Buy now</a> |
| 29  | <a href="#">9020106016</a><br>Washer, plate     | <a href="#">Buy now</a> |
| 30  | <a href="#">9321020M65</a><br>O-ring            | <a href="#">Buy now</a> |




# Fuel 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 31  | <a href="#">6FM2431310</a><br>Pipe 3                      | <a href="#">Buy now</a> |
| 32  | <a href="#">9046709M17</a><br>Clip(6k8)                   | <a href="#">Buy now</a> |
| 33  | <a href="#">9046710M04</a><br>Clip, pipe 1 (6e9)          | <a href="#">Buy now</a> |
| 34  | <a href="#">6FM2439600</a><br>Plate                       | <a href="#">Buy now</a> |
| 35  | <a href="#">62Y2810000</a><br>Tool kit<br>AP              | <a href="#">Buy now</a> |
| 36  | <a href="#">6HY2819970D0</a><br>Manual,owner's<br>UR (NL) | <a href="#">Buy now</a> |
| 36  | <a href="#">6HY2819970E0</a><br>Manual,owner's<br>UR (E)  | <a href="#">Buy now</a> |
| 36  | <a href="#">6HY2819970F0</a><br>Manual,owner's<br>UR (F)  | <a href="#">Buy now</a> |
| 36  | <a href="#">6HY2819970G0</a><br>Manual,owner's<br>UR (D)  | <a href="#">Buy now</a> |
| 36  | <a href="#">6HY2819970H0</a><br>Manual,owner's<br>UR (I)  | <a href="#">Buy now</a> |
| 36  | <a href="#">6HY2819970S0</a><br>Manual,owner's<br>UR (ES) | <a href="#">Buy now</a> |
| 37  | <a href="#">6HY2819980K0</a><br>Manual,owner's<br>UR (DK) | <a href="#">Buy now</a> |
| 37  | <a href="#">6HY2819980L0</a><br>Manual,owner's<br>UR (SF) | <a href="#">Buy now</a> |
| 37  | <a href="#">6HY2819980M0</a><br>Manual,owner's<br>UR (S)  | <a href="#">Buy now</a> |
| 37  | <a href="#">6HY2819980N0</a><br>Manual,owner's<br>UR (N)  | <a href="#">Buy now</a> |

# Fuel 1




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 37  | <a href="#">6HY2819980P0</a><br>Manual,owner's<br>UR (P)  | <a href="#">Buy now</a> |
| 37  | <a href="#">6HY2819980R0</a><br>Manual,owner's<br>UR (GR) | <a href="#">Buy now</a> |

## Fuel 2




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM2431000</a><br>Fuel pipe assembly    | <a href="#">Buy now</a> |
| 2   | <a href="#">9044509091</a><br>Hose (l135)           | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1249800</a><br>Protector             | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM1248201</a><br>Pipe 2                | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM1248300</a><br>Pipe 3                | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM1248400</a><br>Pipe 4                | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM1248501</a><br>Pipe 5                | <a href="#">Buy now</a> |
| 8   | <a href="#">9044509063</a><br>Hose (l1500)          | <a href="#">Buy now</a> |
| 9   | <a href="#">9044509012</a><br>Hose (l1500)          | <a href="#">Buy now</a> |
| 10  | <a href="#">6882437800</a><br>Pipe, joint           | <a href="#">Buy now</a> |
| 11  | <a href="#">6C52437800</a><br>Pipe, joint 4         | <a href="#">Buy now</a> |
| 12  | <a href="#">9046511M10</a><br>Clamp                 | <a href="#">Buy now</a> |
| 13  | <a href="#">9046708M10</a><br>Clip, pipe 6162435600 | <a href="#">Buy now</a> |
| 14  | <a href="#">90467110A1</a><br>Clip                  | <a href="#">Buy now</a> |
| 15  | <a href="#">6FM1475A00</a><br>Pipe 1                | <a href="#">Buy now</a> |

## Fuel 2




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">6FM1475E01</a><br>Pipe 2                 | <a href="#">Buy now</a> |
| 17  | <a href="#">6FM1475F00</a><br>Pipe 3                 | <a href="#">Buy now</a> |
| 18  | <a href="#">6E52174400</a><br>Breezer                | <a href="#">Buy now</a> |
| 19  | <a href="#">6FM1475G00</a><br>Pipe 4                 | <a href="#">Buy now</a> |
| 21  | <a href="#">6FM1243K00</a><br>Pipe, drain            | <a href="#">Buy now</a> |
| 22  | <a href="#">6FM1419100</a><br>Plug, drain            | <a href="#">Buy now</a> |
| 23  | <a href="#">6FM1443G00</a><br>Pipe, drain 2          | <a href="#">Buy now</a> |
| 25  | <a href="#">90467090A4</a><br>Clip                   | <a href="#">Buy now</a> |
| 26  | <a href="#">6FM1354200</a><br>Hose, vacuum sensing 1 | <a href="#">Buy now</a> |
| 27  | <a href="#">9046416001</a><br>Clamp                  | <a href="#">Buy now</a> |
| 30  | <a href="#">9046708092</a><br>Clip(41w)              | <a href="#">Buy now</a> |

# Fuel Injection Pump




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM1418000</a><br>Float chamber assembly 2 | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM1418200</a><br>Cover, float chamber     | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1418100</a><br>Body, float chamber 1    | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM1390600</a><br>Regulator, pressure      | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM1414600</a><br>Plate                    | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM1456500</a><br>Screw                    | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM1456700</a><br>Screw                    | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM1424300</a><br>Plate                    | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM1498400</a><br>Gasket, float chamber    | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM2184100</a><br>Cooler                   | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM1456200</a><br>O-ring                   | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM2425100</a><br>Strainer 1               | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM1454600</a><br>Valve, needle            | <a href="#">Buy now</a> |
| 14  | <a href="#">68V1498500</a><br>Float                    | <a href="#">Buy now</a> |
| 15  | <a href="#">6FM1438600</a><br>Pin, float               | <a href="#">Buy now</a> |

# Fuel Injection Pump




| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 17  | <a href="#">6FM1467400</a><br>Valve, plate       | <a href="#">Buy now</a> |
| 18  | <a href="#">6FM1391000</a><br>Fuel pump assembly | <a href="#">Buy now</a> |
| 19  | <a href="#">6FM1456100</a><br>O-ring             | <a href="#">Buy now</a> |
| 20  | <a href="#">6FM1391500</a><br>Filter             | <a href="#">Buy now</a> |
| 21  | <a href="#">6FM1469M00</a><br>Wire 1             | <a href="#">Buy now</a> |
| 22  | <a href="#">6FM1469N00</a><br>Wire 2             | <a href="#">Buy now</a> |
| 23  | <a href="#">6FM1413700</a><br>Clip               | <a href="#">Buy now</a> |
| 24  | <a href="#">6FM1378100</a><br>Damper, pump       | <a href="#">Buy now</a> |
| 25  | <a href="#">6FM1359300</a><br>Damper             | <a href="#">Buy now</a> |
| 26  | <a href="#">9038706M69</a><br>Collar (688)       | <a href="#">Buy now</a> |
| 27  | <a href="#">9038706176</a><br>Collar             | <a href="#">Buy now</a> |
| 28  | <a href="#">9011906M61</a><br>Bolt, with washer  | <a href="#">Buy now</a> |
| 29  | <a href="#">9010106032</a><br>Bolt               | <a href="#">Buy now</a> |
| 30  | <a href="#">67F1344800</a><br>Cap                | <a href="#">Buy now</a> |

# Fuel Tank 1



| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YK2420105</a><br>Fuel tank comp.<br>AP EXCEPT FOR RUS   | <a href="#">Buy now</a> |
| 2   | <a href="#">6YK2461010</a><br>Cap assembly<br>WITHOUT INDICATOR      | <a href="#">Buy now</a> |
| 3   | <a href="#">6YK2426020</a><br>Fuel meter assembly                    | <a href="#">Buy now</a> |
| 4   | <a href="#">6YL2426801</a><br>Gasket, fuel meter                     | <a href="#">Buy now</a> |
| 5   | <a href="#">6YL2432900</a><br>Seal                                   | <a href="#">Buy now</a> |
| 6   | <a href="#">9015705M16</a><br>Screw, pan head                        | <a href="#">Buy now</a> |
| 7   | <a href="#">6YL2430654</a><br>Fuel pipe comp. 1<br>AP EXCEPT FOR RUS | <a href="#">Buy now</a> |


## Fuel Tank 2



| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YJ2420120</a><br>Fuel tank comp.<br>AP FOR RUS   | <a href="#">Buy now</a> |
| 2   | <a href="#">6YJ2461001</a><br>Cap assembly                    | <a href="#">Buy now</a> |
| 3   | <a href="#">6YJ2426010</a><br>Fuel meter assembly             | <a href="#">Buy now</a> |
| 4   | <a href="#">9015705M19</a><br>Screw, pan head                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6Y12432900</a><br>Seal                            | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y12426800</a><br>Gasket, fuel meter              | <a href="#">Buy now</a> |
| 7   | <a href="#">6YJ2416700</a><br>Strainer                        | <a href="#">Buy now</a> |
| 8   | <a href="#">61J2430604</a><br>Fuel pipe comp. 1<br>AP FOR RUS | <a href="#">Buy now</a> |
| 9   | <a href="#">9044511M06</a><br>Hose (I3000)                    | <a href="#">Buy now</a> |
| 10  | <a href="#">61J2436000</a><br>Primer pump assembly            | <a href="#">Buy now</a> |
| 11  | <a href="#">9044511M05</a><br>Hose (I1000)                    | <a href="#">Buy now</a> |
| 12  | <a href="#">6502435151</a><br>Band 1                          | <a href="#">Buy now</a> |
| 13  | <a href="#">6G12430505</a><br>Fuel pipe joint comp. 2         | <a href="#">Buy now</a> |
| 14  | <a href="#">9321008287</a><br>O-ring (655)                    | <a href="#">Buy now</a> |
| 15  | <a href="#">6Y12430506</a><br>Fuel pipe joint comp. 2         | <a href="#">Buy now</a> |




# Generator



| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM8145001</a><br>Rotor assembly    | <a href="#">Buy now</a> |
| 1   | <a href="#">6FM8145011</a><br>Rotor assembly    | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM8141000</a><br>Stator assembly   | <a href="#">Buy now</a> |
| 3   | <a href="#">6CB8558000</a><br>Coil, pulser      | <a href="#">Buy now</a> |
| 4   | <a href="#">9028005013</a><br>Key, woodruff     | <a href="#">Buy now</a> |
| 5   | <a href="#">9017916M05</a><br>Nut (689)         | <a href="#">Buy now</a> |
| 6   | <a href="#">9020116M44</a><br>Washer (689)      | <a href="#">Buy now</a> |
| 7   | <a href="#">9502306030</a><br>Bolt, flange(4as) | <a href="#">Buy now</a> |
| 8   | <a href="#">9759505516</a><br>Bolt, with washer | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM8556101</a><br>Base, magneto     | <a href="#">Buy now</a> |
| 10  | <a href="#">9502306025</a><br>Bolt, flange(4kg) | <a href="#">Buy now</a> |


# Intake 1



6FM1100DR070


| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM1420000</a><br>Intake assembly        | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM1375000</a><br>Throttle body assembly | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1410H00</a><br>Solenoid valve         | <a href="#">Buy now</a> |
| 4   | <a href="#">1ST1416A00</a><br>O-ring                 | <a href="#">Buy now</a> |
| 5   | <a href="#">68V1421600</a><br>Screw                  | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM1364100</a><br>Manifold, intake 1     | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM1364500</a><br>Gasket, manifold 1     | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM1364600</a><br>Gasket, manifold 2     | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM1354300</a><br>Hose, air              | <a href="#">Buy now</a> |
| 10  | <a href="#">6P21444600</a><br>Bolt                   | <a href="#">Buy now</a> |

## Intake 2




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">9011906MA6</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 2   | <a href="#">9011906MA4</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 3   | <a href="#">95D9506020</a><br>Bolt, flange deep recess  | <a href="#">Buy now</a> |
| 4   | <a href="#">95D9506040</a><br>Bolt, flange deep recess  | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM1315201</a><br>Stay 2                    | <a href="#">Buy now</a> |
| 6   | <a href="#">95D9506025</a><br>Bolt, flange deep recess  | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM1444010</a><br>Silencer assembly, intake | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM1441J00</a><br>Pipe, silencer            | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM1537300</a><br>Pipe, breather            | <a href="#">Buy now</a> |
| 11  | <a href="#">9038706318</a><br>Collar                    | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM1378200</a><br>Stay                      | <a href="#">Buy now</a> |
| 13  | <a href="#">9046416240</a><br>Clamp                     | <a href="#">Buy now</a> |
| 14  | <a href="#">9046420181</a><br>Clamp(4ap)                | <a href="#">Buy now</a> |
| 15  | <a href="#">6FM1316100</a><br>Pipe, delivery 1          | <a href="#">Buy now</a> |
| 16  | <a href="#">6FM1376100</a><br>Injector                  | <a href="#">Buy now</a> |

## Intake 2




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 17  | <a href="#">68V1416A00</a><br>O-ring                  | <a href="#">Buy now</a> |
| 18  | <a href="#">6FM1376600</a><br>Rubber, injector        | <a href="#">Buy now</a> |
| 20  | <a href="#">6FM2417F00</a><br>Separator               | <a href="#">Buy now</a> |
| 21  | <a href="#">6FM2419F00</a><br>Bracket, canistor       | <a href="#">Buy now</a> |
| 22  | <a href="#">9048013M24</a><br>Grommet (6e9)           | <a href="#">Buy now</a> |
| 23  | <a href="#">9798006216</a><br>Screw, with washer(6h2) | <a href="#">Buy now</a> |
| 24  | <a href="#">9046407259</a><br>Clamp                   | <a href="#">Buy now</a> |
| 25  | <a href="#">6FM1449700</a><br>Stay, throttle wire     | <a href="#">Buy now</a> |
| 25  | <a href="#">6FM8238900</a><br>Plate 2                 | <a href="#">Buy now</a> |
| 26  | <a href="#">9138005012</a><br>Bolt,socket             | <a href="#">Buy now</a> |
| 27  | <a href="#">9046412015</a><br>Clamp                   | <a href="#">Buy now</a> |
| 28  | <a href="#">9046412183</a><br>Clamp(jn2)              | <a href="#">Buy now</a> |
| 29  | <a href="#">9046420006</a><br>Clamp                   | <a href="#">Buy now</a> |
| 30  | <a href="#">9046515011</a><br>Clamp                   | <a href="#">Buy now</a> |
| 31  | <a href="#">9046511M59</a><br>Clamp(63m)              | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM45300018D</a><br>Lower unit assembly<br>S(16.7") | <a href="#">Buy now</a> |
| 1   | <a href="#">6FM45300118D</a><br>Lower unit assembly<br>L(21.7") | <a href="#">Buy now</a> |
| 2   | <a href="#">6L245311028D</a><br>Casing, lower                   | <a href="#">Buy now</a> |
| 3   | <a href="#">9333200005</a><br>Brg,cyl-cal roller 0.19g nt       | <a href="#">Buy now</a> |
| 4   | <a href="#">6L24556700</a><br>Shim (t:1.0mm)<br>UR              | <a href="#">Buy now</a> |
| 4   | <a href="#">6L24556710</a><br>Shim (t:1.1mm)<br>UR              | <a href="#">Buy now</a> |
| 4   | <a href="#">6L24556720</a><br>Shim (t:1.2mm)<br>UR              | <a href="#">Buy now</a> |
| 4   | <a href="#">6L24556730</a><br>Shim (t:1.3mm)<br>UR              | <a href="#">Buy now</a> |
| 4   | <a href="#">6L24556740</a><br>Shim (t:1.4mm)<br>UR              | <a href="#">Buy now</a> |
| 5   | <a href="#">93315220V9</a><br>Bearing, cylindrical(6I2)         | <a href="#">Buy now</a> |
| 6   | <a href="#">6L24553600</a><br>Sleeve, drive shaft               | <a href="#">Buy now</a> |
| 7   | <a href="#">9034008002</a><br>Plug, straight screw              | <a href="#">Buy now</a> |
| 8   | <a href="#">9043008003</a><br>Gasket                            | <a href="#">Buy now</a> |
| 9   | <a href="#">6L24431101</a><br>Housing, water pump               | <a href="#">Buy now</a> |
| 10  | <a href="#">9321045161</a><br>O-ring                            | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 11  | <a href="#">6L24432200</a><br>Insert, cartridge              | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM4432301</a><br>Outer plate, cartridge         | <a href="#">Buy now</a> |
| 13  | <a href="#">6L24436710</a><br>Damper, water seal 3           | <a href="#">Buy now</a> |
| 14  | <a href="#">6L24435200</a><br>Impeller                       | <a href="#">Buy now</a> |
| 15  | <a href="#">97E9506540</a><br>Bolt, hexagon w/w deep recess  | <a href="#">Buy now</a> |
| 16  | <a href="#">6L24432800</a><br>Plate                          | <a href="#">Buy now</a> |
| 17  | <a href="#">6FM4533100CA</a><br>Housing, bearing             | <a href="#">Buy now</a> |
| 18  | <a href="#">9331522004</a><br>Brg,cyl-cal roller 21g nt      | <a href="#">Buy now</a> |
| 19  | <a href="#">9310120048</a><br>Oil seal (20x30x6-648)         | <a href="#">Buy now</a> |
| 20  | <a href="#">9321006ME6</a><br>O-ring                         | <a href="#">Buy now</a> |
| 21  | <a href="#">9360412M07</a><br>Pin, dowel (688)               | <a href="#">Buy now</a> |
| 22  | <a href="#">6L245315A0</a><br>Packing,lower casing           | <a href="#">Buy now</a> |
| 23  | <a href="#">9708006020</a><br>Bolt(7u8)                      | <a href="#">Buy now</a> |
| 24  | <a href="#">6L24537500</a><br>Damper, seal                   | <a href="#">Buy now</a> |
| 25  | <a href="#">6FM4415000</a><br>Shift cam assembly<br>S(16.7") | <a href="#">Buy now</a> |

# Lower Casing & Drive 1



| Ref | Part                                                           |                         |
|-----|----------------------------------------------------------------|-------------------------|
| 25  | <a href="#">6FM4415010</a><br>Shift cam assembly<br>L(21.7")   | <a href="#">Buy now</a> |
| 26  | <a href="#">6FM4551000</a><br>Drive shaft assembly<br>S(16.7") | <a href="#">Buy now</a> |
| 26  | <a href="#">6FM4551010</a><br>Drive shaft assembly<br>L(21.7") | <a href="#">Buy now</a> |
| 27  | <a href="#">9028003024</a><br>Key, woodruff(662)               | <a href="#">Buy now</a> |
| 28  | <a href="#">6L24555101</a><br>Pinion                           | <a href="#">Buy now</a> |
| 29  | <a href="#">9017910M14</a><br>Nut(6j8)                         | <a href="#">Buy now</a> |
| 30  | <a href="#">93341320U0</a><br>Bearing, thrust (6I2)            | <a href="#">Buy now</a> |
| 31  | <a href="#">6L24558700</a><br>Shim (t:1.5mm)<br>UR             | <a href="#">Buy now</a> |
| 31  | <a href="#">6L24558710</a><br>Shim (t:1.6mm)<br>UR             | <a href="#">Buy now</a> |
| 32  | <a href="#">6FM4556000</a><br>Gear                             | <a href="#">Buy now</a> |
| 33  | <a href="#">6FM4557100</a><br>Gear                             | <a href="#">Buy now</a> |
| 34  | <a href="#">9020120417</a><br>Washer, plate(663)               | <a href="#">Buy now</a> |
| 35  | <a href="#">6L24557700</a><br>Shim (t:1.0mm)<br>UR             | <a href="#">Buy now</a> |
| 35  | <a href="#">6L24557710</a><br>Shim (t:1.1mm)<br>UR             | <a href="#">Buy now</a> |
| 35  | <a href="#">6L24557720</a><br>Shim (t:1.2mm)<br>UR             | <a href="#">Buy now</a> |


## Lower Casing & Drive 1



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 35  | <a href="#">6L24557730</a><br>Shim (t:1.3mm)<br>UR           | <a href="#">Buy now</a> |
| 36  | <a href="#">65W4561100</a><br>Shaft, propeller               | <a href="#">Buy now</a> |
| 37  | <a href="#">9050110065</a><br>Spring compression648456360000 | <a href="#">Buy now</a> |
| 38  | <a href="#">6FM4563100</a><br>Clutch, dog                    | <a href="#">Buy now</a> |
| 39  | <a href="#">9025005010</a><br>Pin straight 648456320000      | <a href="#">Buy now</a> |
| 40  | <a href="#">6484563311</a><br>Ring, cross pin                | <a href="#">Buy now</a> |
| 41  | <a href="#">6484563500</a><br>Plunger,shift                  | <a href="#">Buy now</a> |
| 42  | <a href="#">6L245361038D</a><br>Cap, lower casing            | <a href="#">Buy now</a> |
| 43  | <a href="#">9330600612</a><br>Bearing(2hr)                   | <a href="#">Buy now</a> |
| 44  | <a href="#">9321060MA3</a><br>O-ring(6j8)                    | <a href="#">Buy now</a> |
| 46  | <a href="#">9310120M07</a><br>Oil seal                       | <a href="#">Buy now</a> |
| 47  | <a href="#">97E9506520</a><br>Bolt, hexagon w/w deep recess  | <a href="#">Buy now</a> |
| 48  | <a href="#">9321060M99</a><br>O-ring(6t3)                    | <a href="#">Buy now</a> |




## Lower Casing & Drive 2



6FM1100DR350

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM4436100</a><br>Tube, water 1<br>S(16.7") | <a href="#">Buy now</a> |
| 1   | <a href="#">6FM4436110</a><br>Tube, water 1<br>L(21.7") | <a href="#">Buy now</a> |
| 2   | <a href="#">6824436500</a><br>Damper, water seal 1      | <a href="#">Buy now</a> |
| 3   | <a href="#">6AH4436500</a><br>Damper, water seal 1      | <a href="#">Buy now</a> |
| 4   | <a href="#">6L24436800</a><br>Rubber, water seal 4      | <a href="#">Buy now</a> |
| 5   | <a href="#">9360412M07</a><br>Pin, dowel (688)          | <a href="#">Buy now</a> |
| 6   | <a href="#">9010510M12</a><br>Bolt (689)                | <a href="#">Buy now</a> |
| 7   | <a href="#">6644537101</a><br>Tab-trim                  | <a href="#">Buy now</a> |
| 8   | <a href="#">9010508M02</a><br>Bolt hexagon              | <a href="#">Buy now</a> |
| 9   | <a href="#">6L24521400</a><br>Cover, water inlet        | <a href="#">Buy now</a> |
| 10  | <a href="#">6L24521500</a><br>Cover, water inlet        | <a href="#">Buy now</a> |
| 11  | <a href="#">9015105M05</a><br>Screw, countersunk        | <a href="#">Buy now</a> |
| 12  | <a href="#">9018505002</a><br>Nut nylon (sus)(ex4)      | <a href="#">Buy now</a> |
| 13  | <a href="#">6L24598701</a><br>Spacer                    | <a href="#">Buy now</a> |
| 14  | <a href="#">6894599700</a><br>Spacer                    | <a href="#">Buy now</a> |


## Lower Casing & Drive 2



6FM1100DR350


| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 15  | <a href="#">9299014200</a><br>Washer, plain                        | <a href="#">Buy now</a> |
| 16  | <a href="#">9017114013</a><br>Nut(664)                             | <a href="#">Buy now</a> |
| 17  | <a href="#">9149030022</a><br>Pin, cotter                          | <a href="#">Buy now</a> |
| 18  | <a href="#">6644594500</a><br>Propeller (3x9-7/8 x10-1/2 -f)<br>UR | <a href="#">Buy now</a> |
| 18  | <a href="#">6644594701</a><br>Propeller (3x9-7/8 x11-1/4 -f)<br>UR | <a href="#">Buy now</a> |

# Oil Pan




| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM15311008D</a><br>Oil pan                     | <a href="#">Buy now</a> |
| 2   | <a href="#">9310113001</a><br>Oil seal                      | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1341100</a><br>Strainer, oil                 | <a href="#">Buy now</a> |
| 4   | <a href="#">9582206016</a><br>Bolt, flange                  | <a href="#">Buy now</a> |
| 5   | <a href="#">9360625M00</a><br>Pin, dowel b (676)            | <a href="#">Buy now</a> |
| 6   | <a href="#">97E7508555</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 7   | <a href="#">65W4271700</a><br>Rubber, seal 2                | <a href="#">Buy now</a> |
| 8   | <a href="#">97D9508014</a><br>Bolt, hexagon deep recess     | <a href="#">Buy now</a> |
| 9   | <a href="#">9043008143</a><br>Gasket (256-11198-00)         | <a href="#">Buy now</a> |
| 10  | <a href="#">9034014M06</a><br>Plug, straight screw(62y)     | <a href="#">Buy now</a> |
| 11  | <a href="#">9043014M09</a><br>Gasket                        | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM1536200</a><br>Plug, oil level               | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM1331710</a><br>Plate, baffle                 | <a href="#">Buy now</a> |
| 14  | <a href="#">9581706025</a><br>Bolt, flange                  | <a href="#">Buy now</a> |

Oil Pump




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6HY1217000</a><br>Camshaft assembly 1       | <a href="#">Buy now</a> |
| 2   | <a href="#">6AH1153701</a><br>Gear, driven              | <a href="#">Buy now</a> |
| 3   | <a href="#">9010508074</a><br>Bolt, flange              | <a href="#">Buy now</a> |
| 4   | <a href="#">9020108784</a><br>Washer, plate (317)       | <a href="#">Buy now</a> |
| 5   | <a href="#">9028205012</a><br>Key, straight             | <a href="#">Buy now</a> |
| 6   | <a href="#">6AH1153600</a><br>Gear, drive               | <a href="#">Buy now</a> |
| 7   | <a href="#">6AH1155700</a><br>Washer 1                  | <a href="#">Buy now</a> |
| 8   | <a href="#">9017030009</a><br>Nut                       | <a href="#">Buy now</a> |
| 9   | <a href="#">9028003M01</a><br>Key woodruff 146115450000 | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM4624100</a><br>Belt                      | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM4629700</a><br>Cover, dust               | <a href="#">Buy now</a> |
| 12  | <a href="#">9048010627</a><br>Grommet                   | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM4261700</a><br>Damper, form              | <a href="#">Buy now</a> |
| 14  | <a href="#">6FM8163900</a><br>Cover                     | <a href="#">Buy now</a> |
| 15  | <a href="#">6AH1330000</a><br>Oil pump assembly         | <a href="#">Buy now</a> |

# Oil Pump




| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 16  | <a href="#">6AH1332910</a><br>Gasket, pump cover | <a href="#">Buy now</a> |
| 17  | <a href="#">9010506035</a><br>Bolt, flange       | <a href="#">Buy now</a> |
| 18  | <a href="#">9310222010</a><br>Oil seal           | <a href="#">Buy now</a> |
| 19  | <a href="#">6FM1343761</a><br>Mark, caution      | <a href="#">Buy now</a> |

## Optional Parts 1




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FMW818001</a><br>Electric starter kit           | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM8196010</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 3   | <a href="#">6AH8180001</a><br>Starting motor assembly        | <a href="#">Buy now</a> |
| 4   | <a href="#">6898185011</a><br>Armature assembly              | <a href="#">Buy now</a> |
| 5   | <a href="#">6898180911</a><br>Washer kit                     | <a href="#">Buy now</a> |
| 6   | <a href="#">6898181011</a><br>Stator ass'y                   | <a href="#">Buy now</a> |
| 7   | <a href="#">6898184711</a><br>O-ring                         | <a href="#">Buy now</a> |
| 8   | <a href="#">6898184011</a><br>Brush holder assembly          | <a href="#">Buy now</a> |
| 9   | <a href="#">6898181111</a><br>Brush 1                        | <a href="#">Buy now</a> |
| 10  | <a href="#">6898181211</a><br>Brush 2                        | <a href="#">Buy now</a> |
| 11  | <a href="#">6898181310</a><br>Spring, brush                  | <a href="#">Buy now</a> |
| 12  | <a href="#">6AH8182001</a><br>Rear bracket assembly          | <a href="#">Buy now</a> |
| 13  | <a href="#">6898180712</a><br>Pinion assembly                | <a href="#">Buy now</a> |
| 14  | <a href="#">68T8185700</a><br>Pinion stopper set             | <a href="#">Buy now</a> |
| 15  | <a href="#">6AH8183000</a><br>Front bracket assembly         | <a href="#">Buy now</a> |

## Optional Parts 1



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6898182610</a><br>Bolt                          | <a href="#">Buy now</a> |
| 17  | <a href="#">9751308545</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 18  | <a href="#">9751308535</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 19  | <a href="#">6FM8194000</a><br>Starter relay assembly        | <a href="#">Buy now</a> |
| 20  | <a href="#">6AH8211700</a><br>Wire, lead                    | <a href="#">Buy now</a> |
| 21  | <a href="#">97E9506610</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 22  | <a href="#">6FM8210500</a><br>Battery cable (l: 2.0m)       | <a href="#">Buy now</a> |
| 23  | <a href="#">6P28211900</a><br>Cover, lead wire              | <a href="#">Buy now</a> |
| 24  | <a href="#">97E9508516</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 25  | <a href="#">6FM8197100</a><br>Wire, lead                    | <a href="#">Buy now</a> |
| 26  | <a href="#">67F8215100</a><br>Fuse                          | <a href="#">Buy now</a> |
| 27  | <a href="#">67F8215B10</a><br>Cap (yellow)                  | <a href="#">Buy now</a> |
| 28  | <a href="#">67F2812A00</a><br>Puller, fuse                  | <a href="#">Buy now</a> |
| 29  | <a href="#">6FM8254000</a><br>Neutral switch assembly       | <a href="#">Buy now</a> |
| 30  | <a href="#">65W8187000</a><br>Starting switch assembly      | <a href="#">Buy now</a> |


## Optional Parts 2



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM8196010</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM8194900</a><br>Wire, lead                     | <a href="#">Buy now</a> |
| 3   | <a href="#">67F8215100</a><br>Fuse                           | <a href="#">Buy now</a> |
| 4   | <a href="#">67F8215B10</a><br>Cap (yellow)                   | <a href="#">Buy now</a> |
| 5   | <a href="#">67F2812A00</a><br>Puller, fuse                   | <a href="#">Buy now</a> |




## Optional Parts 3




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">6X442111028D</a><br>Handle, steering    | <a href="#">Buy now</a> |
| 2   | <a href="#">9370006002</a><br>Nipple, grease        | <a href="#">Buy now</a> |
| 3   | <a href="#">6X44821500</a><br>Graphic               | <a href="#">Buy now</a> |
| 4   | <a href="#">6X44211901</a><br>Grip, steering handle | <a href="#">Buy now</a> |
| 5   | <a href="#">6X44217700</a><br>Rubber, handle        | <a href="#">Buy now</a> |
| 6   | <a href="#">6X44213700</a><br>Indicator, throttle   | <a href="#">Buy now</a> |
| 7   | <a href="#">6X44129100</a><br>Bushing               | <a href="#">Buy now</a> |
| 8   | <a href="#">6X44413901</a><br>Collar                | <a href="#">Buy now</a> |
| 9   | <a href="#">9015205007</a><br>Screw, countersunk    | <a href="#">Buy now</a> |
| 10  | <a href="#">9149020010</a><br>Pin, cotter           | <a href="#">Buy now</a> |
| 11  | <a href="#">6X44417700</a><br>Washer                | <a href="#">Buy now</a> |
| 12  | <a href="#">6X44212800</a><br>Collar, distance 1    | <a href="#">Buy now</a> |
| 13  | <a href="#">9050123215</a><br>Spring (655)          | <a href="#">Buy now</a> |
| 14  | <a href="#">6X44418800</a><br>Washer                | <a href="#">Buy now</a> |
| 15  | <a href="#">9038608032</a><br>Bushing (650)         | <a href="#">Buy now</a> |

## Optional Parts 3




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 16  | <a href="#">63D4212600</a><br>Friction, steering handle grip | <a href="#">Buy now</a> |
| 17  | <a href="#">6X44815400</a><br>Knob, throttle                 | <a href="#">Buy now</a> |
| 18  | <a href="#">9538006600</a><br>Nut(661)                       | <a href="#">Buy now</a> |
| 20  | <a href="#">6X44410001</a><br>Shift link assembly            | <a href="#">Buy now</a> |
| 21  | <a href="#">6X44211500</a><br>Shaft, steering handle         | <a href="#">Buy now</a> |
| 22  | <a href="#">6X44410200</a><br>Shift assist assembly.         | <a href="#">Buy now</a> |
| 23  | <a href="#">6X44773101</a><br>Gear, drive                    | <a href="#">Buy now</a> |
| 24  | <a href="#">6X44413200</a><br>Bushing                        | <a href="#">Buy now</a> |
| 25  | <a href="#">6X41413700</a><br>Clip                           | <a href="#">Buy now</a> |
| 26  | <a href="#">6X44826100</a><br>Arm, throttle                  | <a href="#">Buy now</a> |
| 27  | <a href="#">6X48254000</a><br>Neutral switch assembly        | <a href="#">Buy now</a> |
| 28  | <a href="#">7034812900</a><br>Screw 3                        | <a href="#">Buy now</a> |
| 29  | <a href="#">6X44282100</a><br>Band, clamp                    | <a href="#">Buy now</a> |
| 30  | <a href="#">97E9508540</a><br>Bolt, hexagon w/w deep recess  | <a href="#">Buy now</a> |
| 31  | <a href="#">97E9506530</a><br>Bolt, hexagon w/w deep recess  | <a href="#">Buy now</a> |

## Optional Parts 3




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 32  | <a href="#">6X44853800</a><br>Clamp, cable 1            | <a href="#">Buy now</a> |
| 33  | <a href="#">6X42636700</a><br>Protector                 | <a href="#">Buy now</a> |
| 34  | <a href="#">97D9506014</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 35  | <a href="#">6X44853810</a><br>Clamp, cable 1            | <a href="#">Buy now</a> |
| 38  | <a href="#">6X44215900</a><br>Stay                      | <a href="#">Buy now</a> |
| 39  | <a href="#">6X444159A08D</a><br>Handle, gear shift      | <a href="#">Buy now</a> |
| 40  | <a href="#">6X44417300</a><br>Lever, shift control      | <a href="#">Buy now</a> |
| 41  | <a href="#">9778060920</a><br>Screw, tapping            | <a href="#">Buy now</a> |
| 42  | <a href="#">6X34419100</a><br>Indicator, shift          | <a href="#">Buy now</a> |
| 43  | <a href="#">9038626MA3</a><br>Bush                      | <a href="#">Buy now</a> |
| 44  | <a href="#">6X44213111</a><br>Cover, handle steering    | <a href="#">Buy now</a> |
| 45  | <a href="#">9798506216</a><br>Screw, with washer(6h2)   | <a href="#">Buy now</a> |
| 46  | <a href="#">6X44272501</a><br>Grommet                   | <a href="#">Buy now</a> |
| 47  | <a href="#">63D42121228D</a><br>Bracket                 | <a href="#">Buy now</a> |
| 48  | <a href="#">9010112014</a><br>Bolt                      | <a href="#">Buy now</a> |

## Optional Parts 3




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 49  | <a href="#">9299012200</a><br>Ybs66-12 washer,plain  | <a href="#">Buy now</a> |
| 50  | <a href="#">9020612M22</a><br>Washer, wave(6b0)      | <a href="#">Buy now</a> |
| 51  | <a href="#">9038712M02</a><br>Collar(6b0)            | <a href="#">Buy now</a> |
| 52  | <a href="#">9020112035</a><br>Washer, plate          | <a href="#">Buy now</a> |
| 53  | <a href="#">9038612003</a><br>Bush                   | <a href="#">Buy now</a> |
| 54  | <a href="#">9299012600</a><br>Washer, plate(663)     | <a href="#">Buy now</a> |
| 55  | <a href="#">9018512M12</a><br>Nut, self-locking(6e5) | <a href="#">Buy now</a> |
| 56  | <a href="#">6X44272810</a><br>Cap                    | <a href="#">Buy now</a> |

## Optional Parts 4




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6X48251041</a><br>Main switch assembly        | <a href="#">Buy now</a> |
| 2   | <a href="#">6768257701</a><br>Cap, key                    | <a href="#">Buy now</a> |
| 3   | <a href="#">7038253200</a><br>Cap                         | <a href="#">Buy now</a> |
| 4   | <a href="#">9046408M07</a><br>Clamp                       | <a href="#">Buy now</a> |
| 5   | <a href="#">69W8257500</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 6   | <a href="#">6828255600</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 7   | <a href="#">6898257Y00</a><br>Cap                         | <a href="#">Buy now</a> |
| 8   | <a href="#">6X48256301</a><br>Trim & tilt switch assembly | <a href="#">Buy now</a> |
| 9   | <a href="#">9798006216</a><br>Screw, with washer(6h2)     | <a href="#">Buy now</a> |
| 10  | <a href="#">6X48338300</a><br>Buzzer                      | <a href="#">Buy now</a> |
| 11  | <a href="#">6X48338600</a><br>Stay, buzzer                | <a href="#">Buy now</a> |
| 12  | <a href="#">97D9506014</a><br>Bolt, hexagon deep recess   | <a href="#">Buy now</a> |
| 13  | <a href="#">6X48365320</a><br>Wire, lead (l: 700mm)       | <a href="#">Buy now</a> |
| 14  | <a href="#">6C58430100</a><br>Pilot light assembly 1      | <a href="#">Buy now</a> |
| 15  | <a href="#">6X44411400</a><br>Stopper                     | <a href="#">Buy now</a> |

## Optional Parts 4




| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 16  | <a href="#">9778060620</a><br>Screw, tapping(6k8) | <a href="#">Buy now</a> |
| 17  | <a href="#">6X44272700</a><br>Grommet             | <a href="#">Buy now</a> |
| 18  | <a href="#">6FM8358900</a><br>Gasket              | <a href="#">Buy now</a> |
| 19  | <a href="#">6X48541500</a><br>Mark, signal lamp   | <a href="#">Buy now</a> |
| 20  | <a href="#">6X48194201</a><br>Cover               | <a href="#">Buy now</a> |

## Optional Parts 5



| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">9018510027</a><br>Nut, self-locking            | <a href="#">Buy now</a> |
| 2   | <a href="#">63D4832111</a><br>Cable                        | <a href="#">Buy now</a> |
| 3   | <a href="#">63D4853800</a><br>Clamp, cable 1               | <a href="#">Buy now</a> |
| 4   | <a href="#">9046810005</a><br>Pin, hair 6264123500         | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM2630110</a><br>Throttle cable assembly      | <a href="#">Buy now</a> |
| 8   | <a href="#">9046409M42</a><br>Clamp(6b0)                   | <a href="#">Buy now</a> |
| 9   | <a href="#">6X48258610</a><br>Ext., wire harness (l:950mm) | <a href="#">Buy now</a> |
| 10  | <a href="#">6X48186000</a><br>Switch assembly              | <a href="#">Buy now</a> |
| 11  | <a href="#">9046513M39</a><br>Clamp(6e8)                   | <a href="#">Buy now</a> |
| 12  | <a href="#">6H34272700</a><br>Grommet                      | <a href="#">Buy now</a> |

## Optional Parts 6




6HY1100DT450

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM4250800</a><br>Steering friction assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4252700</a><br>Plate, friction            | <a href="#">Buy now</a> |
| 3   | <a href="#">9010908M91</a><br>Bolt, hexagon deep recess  | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM4256100</a><br>Knob, steering lock        | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM4252500</a><br>Plate, friction            | <a href="#">Buy now</a> |
| 6   | <a href="#">9759505520</a><br>Bolt, With Washer          | <a href="#">Buy now</a> |
| 7   | <a href="#">9038705054</a><br>Collar                     | <a href="#">Buy now</a> |
| 8   | <a href="#">9038705053</a><br>Collar                     | <a href="#">Buy now</a> |
| 9   | <a href="#">9018510M14</a><br>Nut, self-locking          | <a href="#">Buy now</a> |
| 10  | <a href="#">67C42562A0</a><br>Shaft, steering lock       | <a href="#">Buy now</a> |
| 11  | <a href="#">9020210M56</a><br>Washer, plate              | <a href="#">Buy now</a> |
| 12  | <a href="#">65W4252800</a><br>Plate, friction            | <a href="#">Buy now</a> |
| 13  | <a href="#">90201106M5</a><br>Washer, plate(3gm)         | <a href="#">Buy now</a> |
| 14  | <a href="#">9299508200</a><br>Ybs66-8 washer, plain      | <a href="#">Buy now</a> |
| 15  | <a href="#">6894363300</a><br>Cover, tilt lever          | <a href="#">Buy now</a> |




## Optional Parts 7



6CJ1100-K370

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6Y88626700</a><br>Case complete 1              | <a href="#">Buy now</a> |
| 2   | <a href="#">6Y88626003</a><br>Remote control unit assembly | <a href="#">Buy now</a> |
| 3   | <a href="#">6AA8626101</a><br>Xmtr. comp.                  | <a href="#">Buy now</a> |
| 4   | <a href="#">9798006216</a><br>Screw, with washer(6h2)      | <a href="#">Buy now</a> |
| 5   | <a href="#">6X48338300</a><br>Buzzer                       | <a href="#">Buy now</a> |
| 6   | <a href="#">6X48338600</a><br>Stay, buzzer                 | <a href="#">Buy now</a> |
| 7   | <a href="#">9778060620</a><br>Screw, tapping(6k8)          | <a href="#">Buy now</a> |
| 8   | <a href="#">6Y88250910</a><br>Wire, sub lead               | <a href="#">Buy now</a> |
| 9   | <a href="#">9321004279</a><br>O-ring (4a0)                 | <a href="#">Buy now</a> |
| 10  | <a href="#">9046511M10</a><br>Clamp                        | <a href="#">Buy now</a> |
| 11  | <a href="#">6Y88454G00</a><br>Patch 1                      | <a href="#">Buy now</a> |
| 12  | <a href="#">9016706M00</a><br>Screw, tapping (6h4)<br>UR   | <a href="#">Buy now</a> |
| 12  | <a href="#">9788006035</a><br>Screw, pan head(6h4)<br>UR   | <a href="#">Buy now</a> |
| 13  | <a href="#">9020106M30</a><br>Washer, plate (6a1)          | <a href="#">Buy now</a> |
| 14  | <a href="#">9578006300</a><br>Nut, nylon (6g1)             | <a href="#">Buy now</a> |


## Optional Parts 7



6CJ1100-K370


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 15  | <a href="#">6Y88252111</a><br>Pigtail bus wire 0.6m-2ft | <a href="#">Buy now</a> |
| 16  | <a href="#">6Y84827700</a><br>Sticker 1                 | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6HY43840008D</a><br>Power tilt assembly       | <a href="#">Buy now</a> |
| 2   | <a href="#">6HY4380K00</a><br>Cylinder, tilt sub assembly | <a href="#">Buy now</a> |
| 3   | <a href="#">6AH2247100</a><br>Cylinder, shock absorber    | <a href="#">Buy now</a> |
| 4   | <a href="#">93210320A7</a><br>O-ring                      | <a href="#">Buy now</a> |
| 5   | <a href="#">6H14388E11</a><br>Plug, tapper screw          | <a href="#">Buy now</a> |
| 6   | <a href="#">9321007003</a><br>O-ring (11m)                | <a href="#">Buy now</a> |
| 7   | <a href="#">6AH4381400</a><br>Piston, free                | <a href="#">Buy now</a> |
| 8   | <a href="#">9321024709</a><br>O-ring(1hx)                 | <a href="#">Buy now</a> |
| 9   | <a href="#">6C54387100</a><br>Ring, back up               | <a href="#">Buy now</a> |
| 10  | <a href="#">6AH4381000</a><br>Tilt piston sub assembly    | <a href="#">Buy now</a> |
| 11  | <a href="#">6AH4380D00</a><br>Piston comp.                | <a href="#">Buy now</a> |
| 14  | <a href="#">9350108001</a><br>Ball                        | <a href="#">Buy now</a> |
| 15  | <a href="#">6AH4386A00</a><br>Pin, absorber valve         | <a href="#">Buy now</a> |
| 16  | <a href="#">6AH4385E00</a><br>Plate, piston               | <a href="#">Buy now</a> |
| 17  | <a href="#">9290206200</a><br>Ybs66-6 washer, plain       | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 18  | <a href="#">6AH4387800</a><br>Bolt, socket           | <a href="#">Buy now</a> |
| 19  | <a href="#">6AH4385700</a><br>Spring, absorber valve | <a href="#">Buy now</a> |
| 20  | <a href="#">6AH4380100</a><br>Rod                    | <a href="#">Buy now</a> |
| 21  | <a href="#">6AH4381100</a><br>Screw, cylinder end    | <a href="#">Buy now</a> |
| 22  | <a href="#">6H14386601</a><br>O-ring                 | <a href="#">Buy now</a> |
| 23  | <a href="#">69A4387100</a><br>Ring, back up          | <a href="#">Buy now</a> |
| 24  | <a href="#">69A4381200</a><br>Seal, dust             | <a href="#">Buy now</a> |
| 25  | <a href="#">62X4386200</a><br>O-ring                 | <a href="#">Buy now</a> |
| 26  | <a href="#">6AH4383000</a><br>Gear pump assembly     | <a href="#">Buy now</a> |
| 27  | <a href="#">69A4384100</a><br>Piston, shuttle        | <a href="#">Buy now</a> |
| 28  | <a href="#">69A4384M00</a><br>Piston, shuttle 2      | <a href="#">Buy now</a> |
| 29  | <a href="#">62Y4389400</a><br>Spring, shuttle return | <a href="#">Buy now</a> |
| 30  | <a href="#">69A4384F00</a><br>Seal, main valve       | <a href="#">Buy now</a> |
| 31  | <a href="#">6H14388300</a><br>O-ring                 | <a href="#">Buy now</a> |
| 32  | <a href="#">9900203600</a><br>Circlip(6I5)           | <a href="#">Buy now</a> |

# Power Trim & Tilt Assy




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 33  | <a href="#">69G4382G00</a><br>Valve seat            | <a href="#">Buy now</a> |
| 34  | <a href="#">9321012N52</a><br>O-ring                | <a href="#">Buy now</a> |
| 35  | <a href="#">6T44380800</a><br>Seat valve comp. 1    | <a href="#">Buy now</a> |
| 36  | <a href="#">69G4385300</a><br>Spring, main valve    | <a href="#">Buy now</a> |
| 37  | <a href="#">69G4388F00</a><br>Spacer                | <a href="#">Buy now</a> |
| 38  | <a href="#">69J4381C00</a><br>Filter 3              | <a href="#">Buy now</a> |
| 39  | <a href="#">6H14384G11</a><br>Seal, relief valve    | <a href="#">Buy now</a> |
| 40  | <a href="#">6H14384410</a><br>Pin, valve support    | <a href="#">Buy now</a> |
| 41  | <a href="#">6F24385500</a><br>Spring, up relief     | <a href="#">Buy now</a> |
| 42  | <a href="#">6H14385610</a><br>Spring, down relief   | <a href="#">Buy now</a> |
| 44  | <a href="#">69A4386A00</a><br>Pin, absorber valve   | <a href="#">Buy now</a> |
| 45  | <a href="#">69A4382400</a><br>Spring, down relief 2 | <a href="#">Buy now</a> |
| 46  | <a href="#">69A4384810</a><br>Rod, manual release   | <a href="#">Buy now</a> |
| 47  | <a href="#">9360215250</a><br>Pin, dowel            | <a href="#">Buy now</a> |
| 48  | <a href="#">9321006001</a><br>O-ring (26h)          | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 49  | <a href="#">6AH4385400</a><br>Spring, manual release | <a href="#">Buy now</a> |
| 50  | <a href="#">69A4381G00</a><br>Pin 1                  | <a href="#">Buy now</a> |
| 53  | <a href="#">69A4384H00</a><br>Spring                 | <a href="#">Buy now</a> |
| 54  | <a href="#">9360614081</a><br>Pin,dowel(296)         | <a href="#">Buy now</a> |
| 55  | <a href="#">9131205025</a><br>Bolt                   | <a href="#">Buy now</a> |
| 57  | <a href="#">6AH4381J00</a><br>Plate                  | <a href="#">Buy now</a> |
| 58  | <a href="#">N354386210</a><br>O-ring                 | <a href="#">Buy now</a> |
| 59  | <a href="#">69A2312900</a><br>Gasket, drain plug     | <a href="#">Buy now</a> |
| 60  | <a href="#">69A4387800</a><br>Bolt, socket           | <a href="#">Buy now</a> |
| 61  | <a href="#">6HY4388000</a><br>Motor assembly         | <a href="#">Buy now</a> |
| 62  | <a href="#">6AH4380400</a><br>Stator assembly        | <a href="#">Buy now</a> |
| 63  | <a href="#">67C4387910</a><br>Screw, with washer     | <a href="#">Buy now</a> |
| 64  | <a href="#">67C4380510</a><br>Armature assembly      | <a href="#">Buy now</a> |
| 65  | <a href="#">67C4386210</a><br>O-ring                 | <a href="#">Buy now</a> |
| 66  | <a href="#">67C8218110</a><br>Circuit breaker comp.  | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy



| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 67  | <a href="#">67C4389210</a><br>Brush 2                     | <a href="#">Buy now</a> |
| 68  | <a href="#">67C4386K10</a><br>Spring, brush               | <a href="#">Buy now</a> |
| 69  | <a href="#">67C4380F10</a><br>Plate, brush holder         | <a href="#">Buy now</a> |
| 70  | <a href="#">9760204316</a><br>Screw, pan head with washer | <a href="#">Buy now</a> |
| 71  | <a href="#">6HY4388100</a><br>Frame, end                  | <a href="#">Buy now</a> |
| 72  | <a href="#">67C4388210</a><br>Oil seal                    | <a href="#">Buy now</a> |
| 73  | <a href="#">9044615003</a><br>Hose                        | <a href="#">Buy now</a> |


## Remo Con Attachment



| Ref | Part                                                                  |                         |
|-----|-----------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM4850101</a><br>Remote cont. attachment assembly.<br>AP | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4276110</a><br>Stopper                                 | <a href="#">Buy now</a> |
| 3   | <a href="#">9010906316</a><br>Bolt                                    | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM4272610</a><br>Grommet                                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM4412500</a><br>Lever, shift rod                        | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM4419200</a><br>Link, shift rod                         | <a href="#">Buy now</a> |
| 7   | <a href="#">9046818008</a><br>Clip 620436610000                       | <a href="#">Buy now</a> |
| 8   | <a href="#">6824123750</a><br>Joint, link 2                           | <a href="#">Buy now</a> |
| 9   | <a href="#">6H44123700</a><br>Joint, link                             | <a href="#">Buy now</a> |
| 10  | <a href="#">9538005700</a><br>Nut (656)                               | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM4215700</a><br>Lever, throttle                         | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM4128300</a><br>Lever, free accel.                      | <a href="#">Buy now</a> |
| 13  | <a href="#">9038706M59</a><br>Collar (6h3)                            | <a href="#">Buy now</a> |
| 14  | <a href="#">9020106M62</a><br>Washer, plate (6e5)                     | <a href="#">Buy now</a> |
| 15  | <a href="#">95D9506045</a><br>Bolt, flange deep recess                | <a href="#">Buy now</a> |




## Remo Con Attachment




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">95D9506016</a><br>Bolt, flange deep recess  | <a href="#">Buy now</a> |
| 17  | <a href="#">6FM1457100</a><br>Bracket, throttle         | <a href="#">Buy now</a> |
| 18  | <a href="#">6FM4834400</a><br>Cable end, remote control | <a href="#">Buy now</a> |
| 20  | <a href="#">63D4853800</a><br>Clamp, cable 1            | <a href="#">Buy now</a> |
| 21  | <a href="#">6D58434000</a><br>Socket cord assembly 1    | <a href="#">Buy now</a> |
| 22  | <a href="#">9044609M42</a><br>Hose(6n6)                 | <a href="#">Buy now</a> |
| 23  | <a href="#">7038211900</a><br>Cover, lead wire          | <a href="#">Buy now</a> |
| 24  | <a href="#">6FM8258200</a><br>Cap 1 (3p)                | <a href="#">Buy now</a> |
| 25  | <a href="#">65W4851101</a><br>Hook, steering<br>AP      | <a href="#">Buy now</a> |

# Remote Control Assy




| Ref | Part                                                                                   |                         |
|-----|----------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">70348201B1</a><br>Remote control assembly (10p)<br>AP RUS WITHOUT PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">7034823200</a><br>Drive gear                                               | <a href="#">Buy now</a> |
| 3   | <a href="#">7034827100</a><br>Arm, shift                                               | <a href="#">Buy now</a> |
| 4   | <a href="#">7034826101</a><br>Arm, throttle                                            | <a href="#">Buy now</a> |
| 5   | <a href="#">7034823500</a><br>Bushing                                                  | <a href="#">Buy now</a> |
| 6   | <a href="#">7034815210</a><br>Knob, free accel.                                        | <a href="#">Buy now</a> |
| 7   | <a href="#">7034826800</a><br>Spacer 3                                                 | <a href="#">Buy now</a> |
| 8   | <a href="#">7034826400</a><br>Throttle, friction                                       | <a href="#">Buy now</a> |
| 9   | <a href="#">9538005600</a><br>Nut, hexagon (663)                                       | <a href="#">Buy now</a> |
| 10  | <a href="#">9738005025</a><br>Bolt                                                     | <a href="#">Buy now</a> |
| 11  | <a href="#">7034826510</a><br>Shaft, friction                                          | <a href="#">Buy now</a> |
| 12  | <a href="#">9343006024</a><br>Circlip (701)                                            | <a href="#">Buy now</a> |
| 13  | <a href="#">7034824500</a><br>Plate, lock                                              | <a href="#">Buy now</a> |
| 14  | <a href="#">7034825200</a><br>Roller, cam                                              | <a href="#">Buy now</a> |
| 15  | <a href="#">7014824800</a><br>Roller, free accel                                       | <a href="#">Buy now</a> |

## Remote Control Assy




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 16  | <a href="#">7034819800</a><br>Washer, wave 3              | <a href="#">Buy now</a> |
| 17  | <a href="#">7034824300</a><br>Bushing 3                   | <a href="#">Buy now</a> |
| 18  | <a href="#">7034823600</a><br>Bushing                     | <a href="#">Buy now</a> |
| 19  | <a href="#">7034818900</a><br>Retainer                    | <a href="#">Buy now</a> |
| 20  | <a href="#">7034823400</a><br>Roller, detent              | <a href="#">Buy now</a> |
| 21  | <a href="#">7034834501</a><br>Cable end, remote control 2 | <a href="#">Buy now</a> |
| 22  | <a href="#">7034835800</a><br>Anchor, cable               | <a href="#">Buy now</a> |
| 23  | <a href="#">7034824400</a><br>Spring, free accel.         | <a href="#">Buy now</a> |
| 24  | <a href="#">7034823800</a><br>Spring, detent              | <a href="#">Buy now</a> |
| 25  | <a href="#">7034821110</a><br>Housing,1                   | <a href="#">Buy now</a> |
| 26  | <a href="#">7034821210</a><br>Back plate 1                | <a href="#">Buy now</a> |
| 27  | <a href="#">7034821310</a><br>Back plate 2                | <a href="#">Buy now</a> |
| 28  | <a href="#">7034822110</a><br>Lever, control              | <a href="#">Buy now</a> |
| 29  | <a href="#">7034824600</a><br>Spacer 1                    | <a href="#">Buy now</a> |
| 30  | <a href="#">7034822700</a><br>Spring, neutral lock        | <a href="#">Buy now</a> |

# Remote Control Assy





| Ref | Part                                                                  |                         |
|-----|-----------------------------------------------------------------------|-------------------------|
| 31  | <a href="#">7034822230</a><br>Grip, control lever<br><b>SINGLE</b>    | <a href="#">Buy now</a> |
| 32  | <a href="#">7034822310</a><br>Lock, neutral                           | <a href="#">Buy now</a> |
| 33  | <a href="#">7034822510</a><br>Cover                                   | <a href="#">Buy now</a> |
| 34  | <a href="#">7034821910</a><br>Cover, lead                             | <a href="#">Buy now</a> |
| 35  | <a href="#">7034828100</a><br>Screw, flat head                        | <a href="#">Buy now</a> |
| 36  | <a href="#">7034418920</a><br>Screw                                   | <a href="#">Buy now</a> |
| 37  | <a href="#">9738008030</a><br>Bolt, hexagon (fj1)                     | <a href="#">Buy now</a> |
| 38  | <a href="#">9299008600</a><br>Washer, plain (663)                     | <a href="#">Buy now</a> |
| 39  | <a href="#">7034812810</a><br>Screw 2                                 | <a href="#">Buy now</a> |
| 40  | <a href="#">9858004006</a><br>Screw, pan head (7h3)                   | <a href="#">Buy now</a> |
| 41  | <a href="#">7034812900</a><br>Screw 3                                 | <a href="#">Buy now</a> |
| 42  | <a href="#">7034418930</a><br>Screw                                   | <a href="#">Buy now</a> |
| 43  | <a href="#">9538006600</a><br>Nut(661)                                | <a href="#">Buy now</a> |
| 44  | <a href="#">7034829310</a><br>Spacer, remote control<br><b>SINGLE</b> | <a href="#">Buy now</a> |
| 45  | <a href="#">7014828700</a><br>Washer 1                                | <a href="#">Buy now</a> |

# Remote Control Assy



| Ref | Part                                                                        |                         |
|-----|-----------------------------------------------------------------------------|-------------------------|
| 46  | <a href="#">7034821510</a><br>Graphic                                       | <a href="#">Buy now</a> |
| 47  | <a href="#">6X34419100</a><br>Indicator, shift                              | <a href="#">Buy now</a> |
| 48  | <a href="#">7038251013</a><br>Main switch assembly<br><b>PRIME START</b>    | <a href="#">Buy now</a> |
| 49  | <a href="#">6768257701</a><br>Cap, key                                      | <a href="#">Buy now</a> |
| 50  | <a href="#">7038253200</a><br>Cap                                           | <a href="#">Buy now</a> |
| 51  | <a href="#">7038253100</a><br>Wire, lead                                    | <a href="#">Buy now</a> |
| 52  | <a href="#">6888257502</a><br>Engine stop switch assembly                   | <a href="#">Buy now</a> |
| 53  | <a href="#">6828255600</a><br>Lanyard, stop switch                          | <a href="#">Buy now</a> |
| 54  | <a href="#">6888258A20</a><br>10p main harness mec 2m (6ft)<br><b>(10P)</b> | <a href="#">Buy now</a> |
| 55  | <a href="#">7038254000</a><br>Neutral switch assembly                       | <a href="#">Buy now</a> |
| 56  | <a href="#">7038338311</a><br>Buzzer                                        | <a href="#">Buy now</a> |
| 57  | <a href="#">7034828400</a><br>Grommet                                       | <a href="#">Buy now</a> |
| 58  | <a href="#">7038259100</a><br>Band                                          | <a href="#">Buy now</a> |
| 59  | <a href="#">7038259200</a><br>Band                                          | <a href="#">Buy now</a> |
| 60  | <a href="#">7034815300</a><br>Shaft, free accel.                            | <a href="#">Buy now</a> |


## Remote Control Box



 6DR3300-P300


| Ref | Part                                                                                   |                         |
|-----|----------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">70348201B1</a><br>Remote control assembly (10p)<br>AP RUS WITHOUT PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">7014832050</a><br>Cable, Remote Control L=15F<br>UR                        | <a href="#">Buy now</a> |
| 2   | <a href="#">7014832060</a><br>Cable, Remote Control L=16F<br>UR                        | <a href="#">Buy now</a> |
| 2   | <a href="#">7014832080</a><br>Cable, Remote Control L=17F<br>UR                        | <a href="#">Buy now</a> |
| 2   | <a href="#">7014835000</a><br>Cable, Remote Control L=21F<br>UR                        | <a href="#">Buy now</a> |
| 2   | <a href="#">7014835020</a><br>Cable, Remote Control L=23F<br>UR                        | <a href="#">Buy now</a> |

# Repair Kit 1



| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FMW000100</a><br>Power head gasket kit   | <a href="#">Buy now</a> |
| 2   | <a href="#">9310222010</a><br>Oil seal                | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1118100</a><br>Gasket, cylinder head 1 | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM1135600</a><br>Seal, cylinder 2        | <a href="#">Buy now</a> |
| 5   | <a href="#">9321013M63</a><br>O-ring (6g8)            | <a href="#">Buy now</a> |
| 6   | <a href="#">9310237004</a><br>Oil seal                | <a href="#">Buy now</a> |
| 7   | <a href="#">9310225014</a><br>Oil seal                | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM1135100</a><br>Gasket, cylinder        | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM1241400</a><br>Gasket, cover           | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM1364500</a><br>Gasket, manifold 1      | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM1364600</a><br>Gasket, manifold 2      | <a href="#">Buy now</a> |
| 13  | <a href="#">1ST1416A00</a><br>O-ring                  | <a href="#">Buy now</a> |
| 14  | <a href="#">6AH1332910</a><br>Gasket, pump cover      | <a href="#">Buy now</a> |
| 15  | <a href="#">9321024M79</a><br>O-ring                  | <a href="#">Buy now</a> |
| 16  | <a href="#">9321020M65</a><br>O-ring                  | <a href="#">Buy now</a> |


## Repair Kit 2



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FMW000120</a><br>Lower unit gasket kit  | <a href="#">Buy now</a> |
| 2   | <a href="#">9310113001</a><br>Oil seal               | <a href="#">Buy now</a> |
| 3   | <a href="#">9043008143</a><br>Gasket (256-11198-00)  | <a href="#">Buy now</a> |
| 4   | <a href="#">9043014M09</a><br>Gasket                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6824436500</a><br>Damper, water seal 1   | <a href="#">Buy now</a> |
| 6   | <a href="#">6AH4436500</a><br>Damper, water seal 1   | <a href="#">Buy now</a> |
| 7   | <a href="#">6L24436800</a><br>Rubber, water seal 4   | <a href="#">Buy now</a> |
| 8   | <a href="#">9043008003</a><br>Gasket                 | <a href="#">Buy now</a> |
| 9   | <a href="#">9321045161</a><br>O-ring                 | <a href="#">Buy now</a> |
| 10  | <a href="#">6L24436710</a><br>Damper, water seal 3   | <a href="#">Buy now</a> |
| 11  | <a href="#">9310120048</a><br>Oil seal (20x30x6-648) | <a href="#">Buy now</a> |
| 12  | <a href="#">9321006ME6</a><br>O-ring                 | <a href="#">Buy now</a> |
| 13  | <a href="#">6L245315A0</a><br>Packing, lower casing  | <a href="#">Buy now</a> |
| 14  | <a href="#">9321060MA3</a><br>O-ring(6j8)            | <a href="#">Buy now</a> |
| 15  | <a href="#">9310120M07</a><br>Oil seal               | <a href="#">Buy now</a> |




## Repair Kit 2



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 16  | <a href="#">9321060M99</a><br>O-ring(6t3)                   | <a href="#">Buy now</a> |
| 17  | <a href="#">6FMW007801</a><br>Water pump repair kit         | <a href="#">Buy now</a> |
| 18  | <a href="#">6L24431101</a><br>Housing, water pump           | <a href="#">Buy now</a> |
| 20  | <a href="#">6L24432200</a><br>Insert, cartridge             | <a href="#">Buy now</a> |
| 21  | <a href="#">6FM4432301</a><br>Outer plate, cartridge        | <a href="#">Buy now</a> |
| 23  | <a href="#">6L24435200</a><br>Impeller                      | <a href="#">Buy now</a> |
| 24  | <a href="#">97E9506540</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 25  | <a href="#">6L24432800</a><br>Plate                         | <a href="#">Buy now</a> |
| 26  | <a href="#">9360412M07</a><br>Pin, dowel (688)              | <a href="#">Buy now</a> |
| 27  | <a href="#">9028003024</a><br>Key, woodruff(662)            | <a href="#">Buy now</a> |


# Starter



\*1: CUT FROM 50M ROLLS (PART NO. 90790-48193), CUTTING LENGTH: 1.95M  
 \*1: A PRELEVER SUR BOBINE 50M (REFERENCE 90790-48193),  
 LONGUEUR DE COUPE: 1.95M

| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM1571003</a><br>Starter assembly   | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM1571101</a><br>Case, starter      | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM1576400</a><br>Collar 1           | <a href="#">Buy now</a> |
| 4   | <a href="#">6AH1579500</a><br>Guide, rope        | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM1571300</a><br>Spring, starter    | <a href="#">Buy now</a> |
| 6   | <a href="#">6FM1571401</a><br>Drum, sheave       | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM1574100</a><br>Pawl, drive        | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM1573400</a><br>Spring, return     | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM1570500</a><br>Spring, drive pawl | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM1573501</a><br>Guide, cam         | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM1572600</a><br>Washer, flat       | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM1579300</a><br>Screw              | <a href="#">Buy now</a> |
| 13  | <a href="#">6G11575500</a><br>Handle, starter    | <a href="#">Buy now</a> |
| 14  | <a href="#">*</a><br>item_description<br>*1      | <a href="#">Buy now</a> |
| 15  | <a href="#">6G11577900</a><br>Cover              | <a href="#">Buy now</a> |


# Starter



\*1: CUT FROM 50M ROLLS (PART NO. 90790-48193), CUTTING LENGTH: 1.95M  
 \*1: A PRELEVER SUR BOBINE 50M (REFERENCE 90790-48193),  
 LONGUEUR DE COUPE: 1.95M

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6A01578900</a><br>Damper                        | <a href="#">Buy now</a> |
| 17  | <a href="#">6FM1572100</a><br>Shim                          | <a href="#">Buy now</a> |
| 18  | <a href="#">6FM1575300</a><br>Bush                          | <a href="#">Buy now</a> |
| 19  | <a href="#">6FM1575200</a><br>Roller, wire                  | <a href="#">Buy now</a> |
| 20  | <a href="#">6FM1576800</a><br>Bolt                          | <a href="#">Buy now</a> |
| 21  | <a href="#">63V1579400</a><br>Stopper                       | <a href="#">Buy now</a> |
| 22  | <a href="#">6FM1574800</a><br>Plunger, starter stop         | <a href="#">Buy now</a> |
| 23  | <a href="#">63V1573400</a><br>Spring, return                | <a href="#">Buy now</a> |
| 24  | <a href="#">6FM1579901</a><br>Clip                          | <a href="#">Buy now</a> |
| 25  | <a href="#">63V1572600</a><br>Washer, flat                  | <a href="#">Buy now</a> |
| 26  | <a href="#">6FM1576700</a><br>Spring                        | <a href="#">Buy now</a> |
| 27  | <a href="#">6FM8133700</a><br>Cover, flywheel               | <a href="#">Buy now</a> |
| 28  | <a href="#">9010506035</a><br>Bolt, flange                  | <a href="#">Buy now</a> |
| 28  | <a href="#">97E9506520</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 29  | <a href="#">6FM1576200</a><br>Seal, rubber 2                | <a href="#">Buy now</a> |

# Starter




6HY1300DT130

\*1: CUT FROM 50M ROLLS (PART NO. 90790-48193), CUTTING LENGTH: 1.95M  
 \*1: A PRELEVER SUR BOBINE 50M (REFERENCE 90790-48193),  
 LONGUEUR DE COUPE: 1.95M


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 30  | <a href="#">6FM1577008</a><br>Cable comp., starter stop | <a href="#">Buy now</a> |
| 31  | <a href="#">6EE8199540</a><br>Label, warning            | <a href="#">Buy now</a> |
| 32  | <a href="#">6EE8199550</a><br>Label, warning            | <a href="#">Buy now</a> |
| 33  | <a href="#">6EE8199440</a><br>Label, safety             | <a href="#">Buy now</a> |
| 34  | <a href="#">6EE8199450</a><br>Label, safety             | <a href="#">Buy now</a> |
| 35  | <a href="#">6AG8199600</a><br>Mark                      | <a href="#">Buy now</a> |

# Starting Motor




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6AH8180001</a><br>Starting motor assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6898185011</a><br>Armature assembly       | <a href="#">Buy now</a> |
| 3   | <a href="#">6898180911</a><br>Washer kit              | <a href="#">Buy now</a> |
| 4   | <a href="#">6898181011</a><br>Stator ass'y            | <a href="#">Buy now</a> |
| 5   | <a href="#">6898184711</a><br>O-ring                  | <a href="#">Buy now</a> |
| 6   | <a href="#">6898184011</a><br>Brush holder assembly   | <a href="#">Buy now</a> |
| 7   | <a href="#">6898181111</a><br>Brush 1                 | <a href="#">Buy now</a> |
| 8   | <a href="#">6898181211</a><br>Brush 2                 | <a href="#">Buy now</a> |
| 9   | <a href="#">6898181310</a><br>Spring, brush           | <a href="#">Buy now</a> |
| 10  | <a href="#">6AH8182001</a><br>Rear bracket assembly   | <a href="#">Buy now</a> |
| 11  | <a href="#">6898180712</a><br>Pinion assembly         | <a href="#">Buy now</a> |
| 12  | <a href="#">68T8185700</a><br>Pinion stopper set      | <a href="#">Buy now</a> |
| 13  | <a href="#">6AH8183000</a><br>Front bracket assembly  | <a href="#">Buy now</a> |
| 14  | <a href="#">6898182610</a><br>Bolt                    | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FMW0084018D</a><br>Handle steering assembly     | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM42111008D</a><br>Handle, steering             | <a href="#">Buy now</a> |
| 3   | <a href="#">6DR4213801</a><br>Lever, throttle                | <a href="#">Buy now</a> |
| 4   | <a href="#">65W4215900</a><br>Stay                           | <a href="#">Buy now</a> |
| 5   | <a href="#">9010506M07</a><br>Bolt (689)                     | <a href="#">Buy now</a> |
| 6   | <a href="#">6DR4212600</a><br>Friction, steering handle grip | <a href="#">Buy now</a> |
| 7   | <a href="#">65W4212500</a><br>Bolt, friction adjusting       | <a href="#">Buy now</a> |
| 8   | <a href="#">9149016010</a><br>Pin, cotter                    | <a href="#">Buy now</a> |
| 9   | <a href="#">67D4217700</a><br>Rubber, handle                 | <a href="#">Buy now</a> |
| 10  | <a href="#">67D4211901</a><br>Grip, steering handle          | <a href="#">Buy now</a> |
| 11  | <a href="#">6FM4213700</a><br>Indicator, throttle            | <a href="#">Buy now</a> |
| 12  | <a href="#">9015205011</a><br>Screw, countersunk             | <a href="#">Buy now</a> |
| 13  | <a href="#">9020110M02</a><br>Washer, plate(6g9)             | <a href="#">Buy now</a> |
| 14  | <a href="#">9050123215</a><br>Spring (655)                   | <a href="#">Buy now</a> |
| 15  | <a href="#">6FM4217100</a><br>Bushing                        | <a href="#">Buy now</a> |

# Steering



| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">9321010010</a><br>O-ring                  | <a href="#">Buy now</a> |
| 17  | <a href="#">6FM2630100</a><br>Throttle cable assembly | <a href="#">Buy now</a> |
| 18  | <a href="#">6FM2631600</a><br>Boot, throttle cable    | <a href="#">Buy now</a> |
| 19  | <a href="#">66R4217100</a><br>Bushing                 | <a href="#">Buy now</a> |
| 20  | <a href="#">9020143M00</a><br>Washer, plate           | <a href="#">Buy now</a> |
| 21  | <a href="#">9020643M22</a><br>Washer, wave            | <a href="#">Buy now</a> |
| 22  | <a href="#">9020243M57</a><br>Washer, plate           | <a href="#">Buy now</a> |
| 23  | <a href="#">9038640M99</a><br>Bush                    | <a href="#">Buy now</a> |
| 24  | <a href="#">65W4213101</a><br>Cover, handle steering  | <a href="#">Buy now</a> |
| 25  | <a href="#">9578010300</a><br>Nut, nylon (6e5)        | <a href="#">Buy now</a> |
| 26  | <a href="#">9538010700</a><br>Nut (682)               | <a href="#">Buy now</a> |
| 27  | <a href="#">6DR44111008D</a><br>Handle, gear shift    | <a href="#">Buy now</a> |
| 28  | <a href="#">6DR4417300</a><br>Lever, shift control    | <a href="#">Buy now</a> |
| 29  | <a href="#">6DR4212900</a><br>Bushing, rubber         | <a href="#">Buy now</a> |
| 30  | <a href="#">9778060920</a><br>Screw, tapping          | <a href="#">Buy now</a> |


# Steering



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 31  | <a href="#">97E9508535</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 32  | <a href="#">9038626MA3</a><br>Bush                          | <a href="#">Buy now</a> |
| 33  | <a href="#">9020626M25</a><br>Washer, wave                  | <a href="#">Buy now</a> |
| 34  | <a href="#">9020226M59</a><br>Washer, plate                 | <a href="#">Buy now</a> |
| 35  | <a href="#">6DR44113A0</a><br>Cam plate, handle             | <a href="#">Buy now</a> |
| 36  | <a href="#">6DR4411600</a><br>Spring                        | <a href="#">Buy now</a> |
| 37  | <a href="#">66R4411800</a><br>Bracket                       | <a href="#">Buy now</a> |
| 38  | <a href="#">95D9506014</a><br>Bolt, flange deep recess      | <a href="#">Buy now</a> |
| 39  | <a href="#">66R4853800</a><br>Clamp, cable 1                | <a href="#">Buy now</a> |
| 41  | <a href="#">63D4853800</a><br>Clamp, cable 1                | <a href="#">Buy now</a> |
| 42  | <a href="#">6DR4832100</a><br>Cable                         | <a href="#">Buy now</a> |
| 43  | <a href="#">9044620MF5</a><br>Hose                          | <a href="#">Buy now</a> |
| 44  | <a href="#">9908004600</a><br>Circlip (eu0)                 | <a href="#">Buy now</a> |
| 45  | <a href="#">6DR4411400</a><br>Stopper                       | <a href="#">Buy now</a> |
| 46  | <a href="#">9798006225</a><br>Screw, with washer            | <a href="#">Buy now</a> |




# Steering



| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 47  | <a href="#">6FM8257500</a><br>Engine stop switch assembly | <a href="#">Buy now</a> |
| 48  | <a href="#">6828255600</a><br>Lanyard, stop switch        | <a href="#">Buy now</a> |
| 49  | <a href="#">6898257Y00</a><br>Cap                         | <a href="#">Buy now</a> |


# Steering Friction



6FM2010DS240

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM4250800</a><br>Steering friction assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4252700</a><br>Plate, friction            | <a href="#">Buy now</a> |
| 3   | <a href="#">9010908M91</a><br>Bolt, hexagon deep recess  | <a href="#">Buy now</a> |
| 4   | <a href="#">6FM4256100</a><br>Knob, steering lock        | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM4252500</a><br>Plate, friction            | <a href="#">Buy now</a> |
| 6   | <a href="#">9759505520</a><br>Bolt, With Washer          | <a href="#">Buy now</a> |
| 7   | <a href="#">9038705054</a><br>Collar                     | <a href="#">Buy now</a> |
| 8   | <a href="#">9038705053</a><br>Collar                     | <a href="#">Buy now</a> |
| 9   | <a href="#">9018510M14</a><br>Nut, self-locking          | <a href="#">Buy now</a> |
| 10  | <a href="#">67C42562A0</a><br>Shaft, steering lock       | <a href="#">Buy now</a> |
| 11  | <a href="#">9020210M56</a><br>Washer, plate              | <a href="#">Buy now</a> |
| 12  | <a href="#">65W4252800</a><br>Plate, friction            | <a href="#">Buy now</a> |
| 13  | <a href="#">90201106M5</a><br>Washer, plate(3gm)         | <a href="#">Buy now</a> |
| 14  | <a href="#">9299508200</a><br>Ybs66-8 washer, plain      | <a href="#">Buy now</a> |
| 15  | <a href="#">6894363300</a><br>Cover, tilt lever          | <a href="#">Buy now</a> |


## Steering Friction



  
 6FM2010DS240

| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 16  | <a href="#">9011610064</a><br>Bolt, stud        | <a href="#">Buy now</a> |
| 17  | <a href="#">6FM42121018D</a><br>Bracket         | <a href="#">Buy now</a> |
| 18  | <a href="#">9018510027</a><br>Nut, self-locking | <a href="#">Buy now</a> |
| 19  | <a href="#">9020110049</a><br>Washer, plate     | <a href="#">Buy now</a> |


# Steering Guide



6FM1100-R380


| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM6135000</a><br>Steering guide attachment kit<br>AP | <a href="#">Buy now</a> |
| 2   | <a href="#">9020110M20</a><br>Washer, plate (663)                 | <a href="#">Buy now</a> |
| 3   | <a href="#">9018509M01</a><br>Nut, nylon (663)                    | <a href="#">Buy now</a> |
| 4   | <a href="#">9017009M03</a><br>Nut (689)                           | <a href="#">Buy now</a> |
| 5   | <a href="#">9038710M42</a><br>Coller (688)                        | <a href="#">Buy now</a> |
| 6   | <a href="#">9010109M01</a><br>Bolt(62x)                           | <a href="#">Buy now</a> |
| 7   | <a href="#">9020110M63</a><br>Washer, plate                       | <a href="#">Buy now</a> |
| 8   | <a href="#">6E54314501</a><br>Cap, clamp bracket                  | <a href="#">Buy now</a> |
| 9   | <a href="#">9321016275</a><br>O-ring                              | <a href="#">Buy now</a> |

# Top Cowling




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6GX4261011</a><br>Top cowling assembly     | <a href="#">Buy now</a> |
| 1   | <a href="#">6HY4261001</a><br>Top cowling assembly     | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4261A01</a><br>Top cowling w/o graphics | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4261A11</a><br>Top cowling w/o graphics | <a href="#">Buy now</a> |
| 3   | <a href="#">6FM4265100</a><br>Hook                     | <a href="#">Buy now</a> |
| 4   | <a href="#">9026604M01</a><br>Rivet (689)              | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM4264900</a><br>Holder, clamp band       | <a href="#">Buy now</a> |
| 6   | <a href="#">6BG4266200</a><br>Damper                   | <a href="#">Buy now</a> |
| 7   | <a href="#">6FM4261500</a><br>Seal                     | <a href="#">Buy now</a> |
| 8   | <a href="#">6FM4265200</a><br>Hook                     | <a href="#">Buy now</a> |
| 10  | <a href="#">6FM4264700</a><br>Holder, clamp band       | <a href="#">Buy now</a> |
| 11  | <a href="#">6AH4269710</a><br>Tuning fork mark         | <a href="#">Buy now</a> |
| 12  | <a href="#">6FM4268100</a><br>Mark, cowling            | <a href="#">Buy now</a> |
| 13  | <a href="#">6FM4267500</a><br>Graphic, side 1          | <a href="#">Buy now</a> |
| 14  | <a href="#">6FM4267600</a><br>Graphic, side 2          | <a href="#">Buy now</a> |

## Top Cowling




| Ref | Part                                         |                         |
|-----|----------------------------------------------|-------------------------|
| 15  | <a href="#">6DN4267710</a><br>Graphic, front | <a href="#">Buy now</a> |

## Upper Casing



| Ref | Part                                                                |                         |
|-----|---------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM14731008D</a><br>Chamber 1                           | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM4512600</a><br>Plate, seal damper                    | <a href="#">Buy now</a> |
| 3   | <a href="#">9798005216</a><br>Screw, pan w/ plain                   | <a href="#">Buy now</a> |
| 4   | <a href="#">9010506M07</a><br>Bolt (689)                            | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM45111008D</a><br>Casing, upper<br>S(16.7")           | <a href="#">Buy now</a> |
| 5   | <a href="#">6FM45111108D</a><br>Casing, upper<br>L(21.7")           | <a href="#">Buy now</a> |
| 5   | <a href="#">6HY45111008D</a><br>Casing, upper<br>S(16.7")           | <a href="#">Buy now</a> |
| 6   | <a href="#">97E7508530</a><br>Bolt, hexagon w/w deep recess         | <a href="#">Buy now</a> |
| 7   | <a href="#">9360410M03</a><br>Pin, dowel (688)                      | <a href="#">Buy now</a> |
| 8   | <a href="#">9759505510</a><br>Bolt hex. head                        | <a href="#">Buy now</a> |
| 9   | <a href="#">6FM1471100CA</a><br>Muffler 1                           | <a href="#">Buy now</a> |
| 11  | <a href="#">68T4532100</a><br>Plate<br>L(21.7")                     | <a href="#">Buy now</a> |
| 12  | <a href="#">97D9506008</a><br>Bolt, hexagon deep recess<br>L(21.7") | <a href="#">Buy now</a> |
| 13  | <a href="#">9048014M54</a><br>Grommet<br>L(21.7")                   | <a href="#">Buy now</a> |
| 14  | <a href="#">6L24531800</a><br>Bushing, drive shaft<br>L(21.7")      | <a href="#">Buy now</a> |


## Upper Casing



| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 15  | <a href="#">9342030042</a><br>Circlip (650)<br>L(21.7") | <a href="#">Buy now</a> |
| 16  | <a href="#">6FM4276900</a><br>Seal, rubber              | <a href="#">Buy now</a> |




# Valve



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6FM1211100</a><br>Valve, intake          | <a href="#">Buy now</a> |
| 2   | <a href="#">6FM1212100</a><br>Valve, exhaust         | <a href="#">Buy now</a> |
| 3   | <a href="#">62Y1211600</a><br>Seat, valve spring     | <a href="#">Buy now</a> |
| 4   | <a href="#">3YF1211300</a><br>Spring, valve inner    | <a href="#">Buy now</a> |
| 5   | <a href="#">30X1211700</a><br>Retainer, valve spring | <a href="#">Buy now</a> |
| 6   | <a href="#">30X1211800</a><br>Cotter, valve          | <a href="#">Buy now</a> |
| 7   | <a href="#">51Y1211900</a><br>Seal, valve stem       | <a href="#">Buy now</a> |
| 8   | <a href="#">66M1214600</a><br>Shaft, rocker          | <a href="#">Buy now</a> |
| 9   | <a href="#">9011906054</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 10  | <a href="#">9038713006</a><br>Collar                 | <a href="#">Buy now</a> |
| 11  | <a href="#">90501120A5</a><br>Spring, compression    | <a href="#">Buy now</a> |
| 12  | <a href="#">90201131M4</a><br>Washer, plate(3fc)     | <a href="#">Buy now</a> |
| 13  | <a href="#">6AH1215100</a><br>Arm, valve rocker      | <a href="#">Buy now</a> |
| 14  | <a href="#">64J1215900</a><br>Screw, valve adjusting | <a href="#">Buy now</a> |
| 15  | <a href="#">62Y1215800</a><br>Nut, lock              | <a href="#">Buy now</a> |

# Valve



| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">6FM1215100</a><br>Arm, valve rocker      | <a href="#">Buy now</a> |
| 17  | <a href="#">6C51215900</a><br>Screw, valve adjusting | <a href="#">Buy now</a> |
| 18  | <a href="#">6C51215800</a><br>Nut, lock              | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.