



# Yamaha F25AM 2000

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539

Authorised Yamaha Dealers



# Contents

<b>Bottom Cowling</b>	3
<b>Bracket 1</b>	5
<b>Bracket 3</b>	9
<b>Carburetor</b>	11
<b>Control</b>	14
<b>Crankshaft &amp; Piston</b>	16
<b>Cylinder &amp; Crankcase</b>	17
<b>Cylinder &amp; Crankcase 2</b>	19
<b>Electrical 1</b>	21
<b>Electrical 2</b>	23
<b>Electrical 3</b>	24
<b>Fuel</b>	25
<b>Fuel Tank</b>	27
<b>Generator</b>	28
<b>Intake</b>	30
<b>Lower Casing &amp; Drive 1</b>	32
<b>Lower Casing &amp; Drive 2</b>	36
<b>Oil Pan</b>	38
<b>Oil Pump</b>	39
<b>Remo Con Attachment</b>	40
<b>Repair Kit 1</b>	42
<b>Repair Kit 2</b>	44
<b>Repair Kit 3</b>	45
<b>Starting Motor</b>	47
<b>Steering</b>	48
<b>Top Cowling</b>	51
<b>Upper Casing</b>	52
<b>Valve</b>	53

## Bottom Cowling

Diagram not available

Ref	Part	
1	<a href="#">65W42710044D</a> Bottom Cowling assembly	<a href="#">Buy now</a>
2	<a href="#">9011906M0800</a> Bolt, with washer	<a href="#">Buy now</a>
3	<a href="#">9048009M1200</a> Grommet (6a0)	<a href="#">Buy now</a>
4	<a href="#">9038706M6900</a> Collar (688)	<a href="#">Buy now</a>
5	<a href="#">65W427170000</a> Rubber, seal 2	<a href="#">Buy now</a>
6	<a href="#">62Y427160000</a> Rubber seal 1	<a href="#">Buy now</a>
7	<a href="#">65W42738014D</a> Plate, fitting	<a href="#">Buy now</a>
8	<a href="#">9010906M8200</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">65W427251000</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">65W427270000</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">65W42815014D</a> Lever, clamp 1	<a href="#">Buy now</a>
12	<a href="#">9038612M3700</a> Bushing (6f5)	<a href="#">Buy now</a>
13	<a href="#">9038612MA200</a> Bush	<a href="#">Buy now</a>
14	<a href="#">902061205200</a> Washer, wave (666)	<a href="#">Buy now</a>
15	<a href="#">9020112M0700</a> Washer, plate	<a href="#">Buy now</a>

## Bottom Cowling

*Diagram not available*

Ref	Part	
16	<a href="#">65W428160300</a> Lever, Clamp	<a href="#">Buy now</a>
17	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
18	<a href="#">6H3443910100</a> Nipple, hose	<a href="#">Buy now</a>
19	<a href="#">65W263260000</a> Grommet	<a href="#">Buy now</a>
20	<a href="#">682427270000</a> Grommet	<a href="#">Buy now</a>
21	<a href="#">6H4427260000</a> Grommet	<a href="#">Buy now</a>
23	<a href="#">65W427260000</a> Grommet	<a href="#">Buy now</a>
24	<a href="#">9046525M5700</a> Clamp(63v)	<a href="#">Buy now</a>
25	<a href="#">65W427410100</a> Apron	<a href="#">Buy now</a>
26	<a href="#">970950601400</a> Bolt(gj3)	<a href="#">Buy now</a>
27	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
28	<a href="#">9010906M8100</a> Bolt	<a href="#">Buy now</a>
29	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
30	<a href="#">66T431440000</a> Hook, spring	<a href="#">Buy now</a>
31	<a href="#">9050616M3400</a> Spring, tension(64d)	<a href="#">Buy now</a>

# Bracket 1

Diagram not available

Ref	Part	
5	<a href="#">65W43111014D</a> Bracket, Clamp 1	<a href="#">Buy now</a>
6	<a href="#">9014914M1200</a> Screw(6h4)	<a href="#">Buy now</a>
7	<a href="#">66343118014D</a> Handle, transom clamp	<a href="#">Buy now</a>
8	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
9	<a href="#">902430400700</a> Pin (663)	<a href="#">Buy now</a>
10	<a href="#">65W43112014D</a> Bracket, Clamp 2	<a href="#">Buy now</a>
15	<a href="#">9038708M2900</a> Collar	<a href="#">Buy now</a>
16	<a href="#">9010108M7600</a> Bolt	<a href="#">Buy now</a>
17	<a href="#">988800810000</a> Nut, hex.	<a href="#">Buy now</a>
18	<a href="#">929900810000</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
19	<a href="#">65W43311118D</a> Bracket, swivel 1	<a href="#">Buy now</a>
20	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
21	<a href="#">63D431310100</a> Bolt, clamp bracket	<a href="#">Buy now</a>
22	<a href="#">9038622M1500</a> Bushing (688)	<a href="#">Buy now</a>
23	<a href="#">9020122M0300</a> Washer, plate(64j)	<a href="#">Buy now</a>

# Bracket 1

Diagram not available

Ref	Part	
24	<a href="#">6J8431130100</a> Plate, clamp bracket	<a href="#">Buy now</a>
25	<a href="#">63V431450000</a> Nut, self-locking	<a href="#">Buy now</a>
26	<a href="#">6G5431450000</a> Cap, clamp bracket	<a href="#">Buy now</a>
27	<a href="#">65W436270100</a> Stopper	<a href="#">Buy now</a>
28	<a href="#">9038612M9800</a> Bush	<a href="#">Buy now</a>
29	<a href="#">9020614M2300</a> Washer, Wave	<a href="#">Buy now</a>
30	<a href="#">9010908M8700</a> Bolt	<a href="#">Buy now</a>
31	<a href="#">9038712M0400</a> Collar	<a href="#">Buy now</a>
32	<a href="#">9024912M3400</a> Pin	<a href="#">Buy now</a>
33	<a href="#">9038612MA000</a> Bush, solid	<a href="#">Buy now</a>
35	<a href="#">990801060000</a> Circlip	<a href="#">Buy now</a>
36	<a href="#">682433180100</a> Cover	<a href="#">Buy now</a>
37	<a href="#">65W436301100</a> Tilt lever assembly	<a href="#">Buy now</a>
38	<a href="#">9038607MA200</a> Bush	<a href="#">Buy now</a>
39	<a href="#">9038707M0500</a> Collar	<a href="#">Buy now</a>

# Bracket 1

Diagram not available

Ref	Part	
40	<a href="#">9024910M3100</a> Pin	<a href="#">Buy now</a>
41	<a href="#">9038610M9900</a> Bush	<a href="#">Buy now</a>
42	<a href="#">990800860000</a> Circlip	<a href="#">Buy now</a>
43	<a href="#">66T433500100</a> Receiver assembly	<a href="#">Buy now</a>
44	<a href="#">9050620M3700</a> Spring, tension	<a href="#">Buy now</a>
45	<a href="#">66T436311100</a> Lever, tilt	<a href="#">Buy now</a>
46	<a href="#">9014905M1700</a> Screw, pan head	<a href="#">Buy now</a>
47	<a href="#">65W436160000</a> Rod, tilt lock	<a href="#">Buy now</a>
48	<a href="#">65W436140000</a> Plate, Tilt Lock	<a href="#">Buy now</a>
49	<a href="#">65W436150000</a> Plate, Tilt Lock	<a href="#">Buy now</a>
50	<a href="#">65W436130000</a> Arm, tilt lock	<a href="#">Buy now</a>
51	<a href="#">9024907M3200</a> Pin	<a href="#">Buy now</a>
52	<a href="#">9038707M2900</a> Collar	<a href="#">Buy now</a>
53	<a href="#">9024907M3300</a> Pin	<a href="#">Buy now</a>
54	<a href="#">9050630M0000</a> Spring, tension (676)	<a href="#">Buy now</a>

## Bracket 1

*Diagram not available*

Ref	Part	
55	<a href="#">914902001500</a> Pin, cotter (648)	<a href="#">Buy now</a>
56	<a href="#">65W431600000</a> Tilt rod assembly	<a href="#">Buy now</a>



## Bracket 3

Diagram not available

Ref	Part	
1	<a href="#">648425280000</a> Plate, friction	<a href="#">Buy now</a>
2	<a href="#">65W433730000</a> Seal, damper	<a href="#">Buy now</a>
3	<a href="#">9010508M7600</a> Bolt, washer based	<a href="#">Buy now</a>
4	<a href="#">901851005100</a> Nut, self-locking	<a href="#">Buy now</a>
5	<a href="#">9011610M2800</a> Bolt, stud	<a href="#">Buy now</a>
6	<a href="#">65W42511118D</a> Bracket, steering	<a href="#">Buy now</a>
7	<a href="#">9020952M0000</a> Washer (676)	<a href="#">Buy now</a>
8	<a href="#">9038652M0200</a> Bushing (676)	<a href="#">Buy now</a>
9	<a href="#">9038644M0300</a> Bushing (676)	<a href="#">Buy now</a>
10	<a href="#">9321043MJ000</a> O-ring	<a href="#">Buy now</a>
11	<a href="#">9038644M9900</a> Bush	<a href="#">Buy now</a>
12	<a href="#">901850804500</a> Nut, self-locking	<a href="#">Buy now</a>
13	<a href="#">929070820000</a> Washer(6tc)	<a href="#">Buy now</a>
14	<a href="#">9010108M8600</a> Bolt (6h4)	<a href="#">Buy now</a>
15	<a href="#">65W44514014D</a> Mount damper, upper side	<a href="#">Buy now</a>

## Bracket 3

*Diagram not available*

Ref	Part	
16	<a href="#">66T445263000</a> Plate	<a href="#">Buy now</a>
17	<a href="#">970800803000</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
18	<a href="#">929950810000</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
19	<a href="#">65W44551118D</a> Housing, lower mount rubber 1	<a href="#">Buy now</a>
20	<a href="#">65W445550000</a> Mount damper, lower side	<a href="#">Buy now</a>
21	<a href="#">65W445750100</a> Damper, lower mount rubber	<a href="#">Buy now</a>
22	<a href="#">970751008000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
23	<a href="#">929901060000</a> Washer, plate	<a href="#">Buy now</a>
24	<a href="#">9011910M1400</a> Bolt, with washer	<a href="#">Buy now</a>
25	<a href="#">9017910M3300</a> Nut	<a href="#">Buy now</a>
26	<a href="#">65W821271000</a> Wire, lead 2	<a href="#">Buy now</a>

# Carburetor

Diagram not available

Ref	Part	
1	<a href="#">65W149010000</a> Carburetor assembly 1	<a href="#">Buy now</a>
2	<a href="#">985800400600</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
3	<a href="#">65W145720000</a> Plate	<a href="#">Buy now</a>
4	<a href="#">65W141261000</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">978030401000</a> Screw, pan head (e56)	<a href="#">Buy now</a>
6	<a href="#">676149480700</a> Jet (#50)	<a href="#">Buy now</a>
7	<a href="#">679149660000</a> Rubber cap	<a href="#">Buy now</a>
8	<a href="#">905011032600</a> Spring coil(663)(carb)	<a href="#">Buy now</a>
9	<a href="#">63V145230000</a> Screw, stop	<a href="#">Buy now</a>
10	<a href="#">65W149470000</a> Jet Needle	<a href="#">Buy now</a>
11	<a href="#">65W149432900</a> Jet, main (#112)	<a href="#">Buy now</a>
12	<a href="#">63V149850000</a> Float	<a href="#">Buy now</a>
13	<a href="#">6G1145460000</a> Valve, needle	<a href="#">Buy now</a>
14	<a href="#">676141860000</a> Pin, valve	<a href="#">Buy now</a>
15	<a href="#">663141590000</a> Clip	<a href="#">Buy now</a>

# Carburetor

Diagram not available

Ref	Part	
16	<a href="#">985800400800</a> Screw, pan head (713)	<a href="#">Buy now</a>
17	<a href="#">6H4145480000</a> Pin, float arm	<a href="#">Buy now</a>
18	<a href="#">65W143730000</a> Cover, plunger cap	<a href="#">Buy now</a>
19	<a href="#">65W143790000</a> Rod, starter	<a href="#">Buy now</a>
20	<a href="#">65W1414F0000</a> Jet, pilot (# 52)	<a href="#">Buy now</a>
21	<a href="#">65W141470000</a> O-ring	<a href="#">Buy now</a>
22	<a href="#">65W143350000</a> Spring, plunger	<a href="#">Buy now</a>
23	<a href="#">65W143710000</a> Plunger, starter	<a href="#">Buy now</a>
24	<a href="#">65W143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
25	<a href="#">65W149800000</a> Body, float chamber	<a href="#">Buy now</a>
26	<a href="#">6G1143980000</a> Washer	<a href="#">Buy now</a>
27	<a href="#">65W149920000</a> Screw, drain	<a href="#">Buy now</a>
28	<a href="#">979800411400</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
29	<a href="#">65W143800000</a> Prime starter assembly	<a href="#">Buy now</a>
30	<a href="#">65W143460000</a> Plate	<a href="#">Buy now</a>

## Carburetor

*Diagram not available*

Ref	Part	
31	<a href="#">65W149231000</a> Screw, pilot	<a href="#">Buy now</a>
32	<a href="#">67C143970000</a> O-ring	<a href="#">Buy now</a>
33	<a href="#">67C145550000</a> Spring	<a href="#">Buy now</a>

# Control

Diagram not available

Ref	Part	
1	<a href="#">65W416380000</a> Pulley	<a href="#">Buy now</a>
2	<a href="#">65W412830000</a> Lever, free accel.	<a href="#">Buy now</a>
3	<a href="#">661412620200</a> Joint, choke lever	<a href="#">Buy now</a>
4	<a href="#">9038706M0800</a> Collar	<a href="#">Buy now</a>
5	<a href="#">65W412110000</a> Link Accel.	<a href="#">Buy now</a>
6	<a href="#">65W144970100</a> Stay, Throttle Wire	<a href="#">Buy now</a>
7	<a href="#">9020106M3100</a> Washer (6a0)	<a href="#">Buy now</a>
8	<a href="#">975950655500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
9	<a href="#">970950601000</a> Bolt	<a href="#">Buy now</a>
10	<a href="#">65W441210000</a> Lever, shift rod	<a href="#">Buy now</a>
11	<a href="#">65W441220000</a> Bushing, Shift Rod Lever	<a href="#">Buy now</a>
12	<a href="#">9025403M0500</a> Pin, spring	<a href="#">Buy now</a>
13	<a href="#">6F5416620000</a> Bracket 2	<a href="#">Buy now</a>
14	<a href="#">9010906M8100</a> Bolt	<a href="#">Buy now</a>
15	<a href="#">65W441160000</a> Spring	<a href="#">Buy now</a>

## Control

*Diagram not available*

Ref	Part	
16	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
17	<a href="#">65W441431000</a> Rod, shift	<a href="#">Buy now</a>
18	<a href="#">901700601500</a> Connector, shift rod	<a href="#">Buy now</a>
19	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
20	<a href="#">904681800800</a> Clip 620436610000	<a href="#">Buy now</a>

## Crankshaft & Piston

Diagram not available

Ref	Part	
1	<a href="#">9310243M4200</a> Oil seal(62y)	<a href="#">Buy now</a>
2	<a href="#">9310235M4700</a> Oil seal(62y)	<a href="#">Buy now</a>
3	<a href="#">65W114110100</a> Crankshaft	<a href="#">Buy now</a>
4	<a href="#">62Y114162000</a> Plane bearing, crankshaft 1	<a href="#">Buy now</a>
5	<a href="#">67C116500000</a> Connecting rod assembly	<a href="#">Buy now</a>
6	<a href="#">62Y116540000</a> Bolt, connecting rod	<a href="#">Buy now</a>
7	<a href="#">62Y116562000</a> Plane bearing, connecting rod	<a href="#">Buy now</a>
8	<a href="#">65W116310096</a> Piston (std)	<a href="#">Buy now</a>
9	<a href="#">67C116050000</a> Piston ring set (0.50mm o/s)	<a href="#">Buy now</a>
10	<a href="#">62Y116330000</a> Pin, piston	<a href="#">Buy now</a>
11	<a href="#">934501712900</a> Circlip(1ar)	<a href="#">Buy now</a>
12	<a href="#">65W116650000</a> Con-rod assembly, balance	<a href="#">Buy now</a>
13	<a href="#">65W116421100</a> Piston, Balance	<a href="#">Buy now</a>
14	<a href="#">901702013700</a> Nut, hexagon(663)	<a href="#">Buy now</a>



## Cylinder & Crankcase

Diagram not available

Ref	Part	
1	<a href="#">65WW009B004D</a> Cylinder Block assembly	<a href="#">Buy now</a>
2	<a href="#">65W151000094</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">995300801200</a> Pin, dowel(6g8)	<a href="#">Buy now</a>
4	<a href="#">9011908M0100</a> Bolt, with washer(62y)	<a href="#">Buy now</a>
5	<a href="#">975130653500</a> Bolt(3rv)	<a href="#">Buy now</a>
6	<a href="#">65W151210000</a> Crankcase 2	<a href="#">Buy now</a>
7	<a href="#">65W156630000</a> Seal	<a href="#">Buy now</a>
8	<a href="#">65W122280000</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">65W111680000</a> Cover Breather	<a href="#">Buy now</a>
10	<a href="#">65W111690000</a> Gasket, breather cover	<a href="#">Buy now</a>
12	<a href="#">65W111190000</a> Hanger Engine	<a href="#">Buy now</a>
13	<a href="#">9010508M8700</a> Bolt, washer based	<a href="#">Buy now</a>
14	<a href="#">9034014M0600</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
15	<a href="#">904301411500</a> Gasket (663)	<a href="#">Buy now</a>
16	<a href="#">65W113511000</a> Gasket, cylinder	<a href="#">Buy now</a>

## Cylinder & Crankcase

Diagram not available

Ref	Part	
17	<a href="#">6G8124110200</a> Thermostat	<a href="#">Buy now</a>
18	<a href="#">6H312413009M</a> Cover, thermostat	<a href="#">Buy now</a>
19	<a href="#">62Y124140000</a> Gasket, cover	<a href="#">Buy now</a>
20	<a href="#">65W132860000</a> Cleaner	<a href="#">Buy now</a>
21	<a href="#">9040120M0000</a> Bolt, union(62y)	<a href="#">Buy now</a>
22	<a href="#">5GH134400000</a> Element assembly, oil cleaner	<a href="#">Buy now</a>
23	<a href="#">65W41113101S</a> Outer cover, exhaust	<a href="#">Buy now</a>
24	<a href="#">62Y124810000</a> Pipe 1	<a href="#">Buy now</a>
25	<a href="#">65W411140000</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
26	<a href="#">970140603500</a> Bolt(3rv)	<a href="#">Buy now</a>
27	<a href="#">929030660000</a> Washer, plain (646)	<a href="#">Buy now</a>
28	<a href="#">904450925200</a> Hose (l420)	<a href="#">Buy now</a>

## Cylinder & Crankcase 2

Diagram not available

Ref	Part	
1	<a href="#">65WW009A124D</a> Cylinder Head Complete	<a href="#">Buy now</a>
2	<a href="#">65W111110294</a> Head, Cylinder 1	<a href="#">Buy now</a>
3	<a href="#">62Y111331000</a> Guide, valve 1	<a href="#">Buy now</a>
4	<a href="#">9345009M0100</a> Circlip (6g8)	<a href="#">Buy now</a>
5	<a href="#">62Y113250000</a> Anode	<a href="#">Buy now</a>
6	<a href="#">66M113280000</a> Grommet, anode	<a href="#">Buy now</a>
7	<a href="#">66M113270094</a> Cover, anode	<a href="#">Buy now</a>
8	<a href="#">66M125350000</a> Plate	<a href="#">Buy now</a>
9	<a href="#">975950551200</a> Bolt, hexagon	<a href="#">Buy now</a>
10	<a href="#">975130652000</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
11	<a href="#">904300601400</a> Gasket 256113960000	<a href="#">Buy now</a>
12	<a href="#">9010906M6500</a> Bolt(62y)	<a href="#">Buy now</a>
13	<a href="#">65W111813000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
14	<a href="#">995300801200</a> Pin, dowel(6g8)	<a href="#">Buy now</a>
15	<a href="#">9011909M0000</a> Bolt, with washer(62y)	<a href="#">Buy now</a>

## Cylinder & Crankcase 2

*Diagram not available*

Ref	Part	
16	<a href="#">975130652500</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
17	<a href="#">65W111910094</a> Cover Cylinder Head 1	<a href="#">Buy now</a>
18	<a href="#">65W113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
19	<a href="#">970240602000</a> Bolt(3dm)	<a href="#">Buy now</a>
20	<a href="#">970950801400</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
21	<a href="#">904300814300</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
22	<a href="#">6G8153630000</a> Plug, oil	<a href="#">Buy now</a>
23	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>
24	<a href="#">947010037500</a> Plug, spark (dpr6ea-9)(62y)	<a href="#">Buy now</a>

# Electrical 1

Diagram not available

Ref	Part	
1	<a href="#">65W855401100</a> C.d.i. unit assembly	<a href="#">Buy now</a>
2	<a href="#">65W861290000</a> Collar	<a href="#">Buy now</a>
3	<a href="#">65W8252V0000</a> Screw, special	<a href="#">Buy now</a>
4	<a href="#">65W855420000</a> Bracket	<a href="#">Buy now</a>
5	<a href="#">65W855470000</a> Damper	<a href="#">Buy now</a>
6	<a href="#">65W861291000</a> Collar	<a href="#">Buy now</a>
7	<a href="#">65W8252V1000</a> Screw, special	<a href="#">Buy now</a>
8	<a href="#">65W855700100</a> Ignition coil assembly	<a href="#">Buy now</a>
9	<a href="#">6G8823703000</a> Plug cap assembly	<a href="#">Buy now</a>
10	<a href="#">904802516100</a> Grommet(656)	<a href="#">Buy now</a>
11	<a href="#">975950653000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
12	<a href="#">9046407M0500</a> Clamp (6g5)	<a href="#">Buy now</a>
13	<a href="#">65W819410000</a> Starter relay assembly	<a href="#">Buy now</a>
14	<a href="#">65W8191C0000</a> Collar	<a href="#">Buy now</a>
15	<a href="#">65W819220000</a> Grommet	<a href="#">Buy now</a>

# Electrical 1

Diagram not available

Ref	Part	
16	<a href="#">65W8182A0000</a> Nut	<a href="#">Buy now</a>
17	<a href="#">65W8182B0000</a> Nut, special	<a href="#">Buy now</a>
18	<a href="#">975950652500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
19	<a href="#">65W821170000</a> Wire, lead	<a href="#">Buy now</a>
20	<a href="#">6G5821191000</a> Cover, lead wire	<a href="#">Buy now</a>
21	<a href="#">65W819601000</a> Rectifier & regulator assembly	<a href="#">Buy now</a>
22	<a href="#">6K3835570000</a> Tube	<a href="#">Buy now</a>
23	<a href="#">975950654000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
24	<a href="#">65W825040000</a> Oil pressure switch assembly	<a href="#">Buy now</a>
25	<a href="#">65W821270000</a> Wire, lead 2	<a href="#">Buy now</a>
26	<a href="#">703821190000</a> Cover, lead wire	<a href="#">Buy now</a>
27	<a href="#">65W8339X0000</a> Clamp, cord	<a href="#">Buy now</a>

## Electrical 2

Diagram not available

Ref	Part	
1	<a href="#">65W857900000</a> Thermosensor assembly	<a href="#">Buy now</a>
2	<a href="#">65W857570000</a> Retainer	<a href="#">Buy now</a>
3	<a href="#">975950651200</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
4	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
5	<a href="#">65W825900000</a> Wire Harness assembly	<a href="#">Buy now</a>
8	<a href="#">9046508M0800</a> Clamp (6e5)	<a href="#">Buy now</a>
9	<a href="#">9046506M8800</a> Clamp	<a href="#">Buy now</a>
10	<a href="#">6N7835570000</a> Tube	<a href="#">Buy now</a>
11	<a href="#">975950651600</a> Bolt, with washer(6r6)	<a href="#">Buy now</a>
12	<a href="#">975950551600</a> Bolt, with washer	<a href="#">Buy now</a>
13	<a href="#">65W821050000</a> Battery cable	<a href="#">Buy now</a>
14	<a href="#">6G8821500000</a> Fuse holder assembly	<a href="#">Buy now</a>
15	<a href="#">663821510000</a> Fuse	<a href="#">Buy now</a>
16	<a href="#">6G5821520000</a> Holder, fuse	<a href="#">Buy now</a>

## Electrical 3

*Diagram not available*

Ref	Part	
1	<a href="#">6H3825400000</a> Neutral switch assembly	<a href="#">Buy now</a>
2	<a href="#">6J8825540000</a> Stay, neutral switch	<a href="#">Buy now</a>
3	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">65W825750000</a> Engine stop switch assembly	<a href="#">Buy now</a>
5	<a href="#">682825560000</a> Lanyard, stop switch	<a href="#">Buy now</a>
6	<a href="#">6898257Y0000</a> Cap	<a href="#">Buy now</a>
7	<a href="#">975950651200</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
8	<a href="#">65W818700000</a> Starting switch assembly	<a href="#">Buy now</a>
9	<a href="#">65W825940000</a> Clamp	<a href="#">Buy now</a>
10	<a href="#">9016106M0000</a> Screw, tapping(6e7)	<a href="#">Buy now</a>



# Fuel

Diagram not available

Ref	Part	
1	<a href="#">62Y244100200</a> Fuel pump assembly	<a href="#">Buy now</a>
2	<a href="#">62Y244130000</a> Body 4	<a href="#">Buy now</a>
3	<a href="#">62Y244210100</a> Valve, check	<a href="#">Buy now</a>
4	<a href="#">62Y244110200</a> Diaphragm	<a href="#">Buy now</a>
5	<a href="#">62Y244230000</a> Spring, diaphragm	<a href="#">Buy now</a>
6	<a href="#">62Y131310100</a> Plunger	<a href="#">Buy now</a>
7	<a href="#">62Y244540000</a> Spring	<a href="#">Buy now</a>
8	<a href="#">62Y244440000</a> Screw	<a href="#">Buy now</a>
9	<a href="#">62Y244710000</a> Diaphragm	<a href="#">Buy now</a>
10	<a href="#">6A0143250000</a> Screw, pan head	<a href="#">Buy now</a>
11	<a href="#">953800360000</a> Nut (6g8)	<a href="#">Buy now</a>
12	<a href="#">62Y244520000</a> Packing	<a href="#">Buy now</a>
13	<a href="#">953800560000</a> Nut, hexagon (663)	<a href="#">Buy now</a>
14	<a href="#">62Y243740100</a> Pin	<a href="#">Buy now</a>
15	<a href="#">932102480000</a> O-ring	<a href="#">Buy now</a>

# Fuel

Diagram not available

Ref	Part	
16	<a href="#">65W244740000</a> Cover	<a href="#">Buy now</a>
17	<a href="#">975950653000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
18	<a href="#">65W242511000</a> Strainer 1	<a href="#">Buy now</a>
19	<a href="#">65W244810000</a> Plug	<a href="#">Buy now</a>
20	<a href="#">9044510M3300</a> Hose (I1040)	<a href="#">Buy now</a>
21	<a href="#">9044510M4300</a> Hose (I400)	<a href="#">Buy now</a>
23	<a href="#">6G1243040200</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
24	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">9046710M0400</a> Clip, pipe 1 (6e9)	<a href="#">Buy now</a>
26	<a href="#">9046709M0300</a> Clip(6k8)	<a href="#">Buy now</a>
27	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
28	<a href="#">9046513M1800</a> Clamp	<a href="#">Buy now</a>
29	<a href="#">62Y281000000</a> Tool kit	<a href="#">Buy now</a>

# Fuel Tank

Diagram not available

Ref	Part	
1	<a href="#">6YK242010100</a> Fuel Tank assembly (25L)	<a href="#">Buy now</a>
2	<a href="#">6YL242680100</a> Gasket, fuel meter	<a href="#">Buy now</a>
3	<a href="#">6YK246100000</a> Cap assembly	<a href="#">Buy now</a>
4	<a href="#">6YL246410000</a> Gasket, cap 1	<a href="#">Buy now</a>
5	<a href="#">6YK242600100</a> Fuel meter assembly	<a href="#">Buy now</a>
6	<a href="#">9015705M1600</a> Screw, pan head	<a href="#">Buy now</a>
7	<a href="#">6YL243290000</a> Seal	<a href="#">Buy now</a>
8	<a href="#">6YL243065100</a> Fuel pipe comp. 1	<a href="#">Buy now</a>

# Generator

Diagram not available

Ref	Part	
1	<a href="#">65W855500100</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">65W855100000</a> Stator assembly	<a href="#">Buy now</a>
3	<a href="#">65W855800000</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">67C853700000</a> Resistor assembly	<a href="#">Buy now</a>
5	<a href="#">9046513M1800</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">65W115450000</a> Key, woodruff	<a href="#">Buy now</a>
7	<a href="#">9020121M1800</a> Washer, plate (663)	<a href="#">Buy now</a>
8	<a href="#">901702013700</a> Nut, hexagon(663)	<a href="#">Buy now</a>
9	<a href="#">913800502500</a> Bolt, hex. socket head	<a href="#">Buy now</a>
10	<a href="#">975950551600</a> Bolt, with washer	<a href="#">Buy now</a>
12	<a href="#">9044610M8200</a> Hose	<a href="#">Buy now</a>
13	<a href="#">65W854100100</a> Emergency signal light assembly	<a href="#">Buy now</a>
14	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
15	<a href="#">65W813370000</a> Cover Flywheel	<a href="#">Buy now</a>
16	<a href="#">65W816390000</a> Cover	<a href="#">Buy now</a>

# Generator

Diagram not available

Ref	Part	
17	<a href="#">975950652500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
18	<a href="#">6G1427250000</a> Grommet	<a href="#">Buy now</a>
19	<a href="#">65W843420000</a> Seat, emblem	<a href="#">Buy now</a>
20	<a href="#">65W157581000</a> Guide Rope	<a href="#">Buy now</a>
21	<a href="#">65W157620000</a> Seal, rubber 2	<a href="#">Buy now</a>
22	<a href="#">65W157710000</a> Stay 1	<a href="#">Buy now</a>
23	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
24	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
25	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>

# Intake

Diagram not available

Ref	Part	
1	<a href="#">65W144400000</a> Silencer assembly, intake	<a href="#">Buy now</a>
2	<a href="#">65W136400000</a> Manifold	<a href="#">Buy now</a>
3	<a href="#">65W133230000</a> Insert	<a href="#">Buy now</a>
4	<a href="#">65W144960000</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">65W142710000</a> Insulator	<a href="#">Buy now</a>
6	<a href="#">65W141980000</a> Gasket	<a href="#">Buy now</a>
7	<a href="#">65W142620000</a> Flange	<a href="#">Buy now</a>
8	<a href="#">65W144571000</a> Seal	<a href="#">Buy now</a>
9	<a href="#">65W136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
10	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
11	<a href="#">65W243770000</a> Pipe, joint 3	<a href="#">Buy now</a>
12	<a href="#">65W153971000</a> Pipe	<a href="#">Buy now</a>
13	<a href="#">9046513M3600</a> Clamp(6h4)	<a href="#">Buy now</a>
14	<a href="#">9044624M8300</a> Hose	<a href="#">Buy now</a>
15	<a href="#">9046511M5200</a> Clamp(6e7)	<a href="#">Buy now</a>

# Intake

Diagram not available

Ref	Part	
16	<a href="#">65W153700000</a> Breather assembly	<a href="#">Buy now</a>
17	<a href="#">65W153701000</a> Breather assembly	<a href="#">Buy now</a>

## Lower Casing & Drive 1

Diagram not available

Ref	Part	
1	<a href="#">65W45300004D</a> Lower unit assembly	<a href="#">Buy now</a>
2	<a href="#">61N45311028D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93332000W500</a> Bearing(61n)	<a href="#">Buy now</a>
4	<a href="#">61N455874000</a> Shim (t:1.3mm)	<a href="#">Buy now</a>
5	<a href="#">61N455360000</a> Sleeve, drive shaft	<a href="#">Buy now</a>
6	<a href="#">93315220V700</a> Bearing, cylindrical(6j8)	<a href="#">Buy now</a>
7	<a href="#">61N443621000</a> Tube, water	<a href="#">Buy now</a>
8	<a href="#">932102216400</a> O-ring	<a href="#">Buy now</a>
9	<a href="#">932102624000</a> O-ring	<a href="#">Buy now</a>
10	<a href="#">65W443280000</a> Plate	<a href="#">Buy now</a>
11	<a href="#">61N443110100</a> Housing, water pump	<a href="#">Buy now</a>
12	<a href="#">6L2443670000</a> Damper, water seal 3	<a href="#">Buy now</a>
13	<a href="#">61N443220100</a> Insert, cartridge	<a href="#">Buy now</a>
14	<a href="#">6H4443520200</a> Impeller	<a href="#">Buy now</a>
15	<a href="#">932104516100</a> O-ring	<a href="#">Buy now</a>



## Lower Casing & Drive 1

Diagram not available

Ref	Part	
16	<a href="#">61N443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
17	<a href="#">970950604000</a> Bolt (682)	<a href="#">Buy now</a>
18	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
19	<a href="#">65W441760000</a> Bracket	<a href="#">Buy now</a>
20	<a href="#">9321006ME600</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
23	<a href="#">65W45331005B</a> Housing, bearing	<a href="#">Buy now</a>
24	<a href="#">9360410M0300</a> Pin, dowel (688)	<a href="#">Buy now</a>
25	<a href="#">61N451270000</a> Seal	<a href="#">Buy now</a>
26	<a href="#">61N453150000</a> Packing, lower casing	<a href="#">Buy now</a>
27	<a href="#">931012206700</a> Oil seal (22x36x6-663)	<a href="#">Buy now</a>
28	<a href="#">9034008M0400</a> Plug, straight screw	<a href="#">Buy now</a>
29	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
30	<a href="#">61N452510100</a> Anode	<a href="#">Buy now</a>
31	<a href="#">958950603500</a> Bolt, flange(4nx)	<a href="#">Buy now</a>

## Lower Casing & Drive 1

Diagram not available

Ref	Part	
32	<a href="#">929900630000</a> Washer, tooth	<a href="#">Buy now</a>
33	<a href="#">688453410000</a> Plug, drain	<a href="#">Buy now</a>
35	<a href="#">61N455101000</a> Drive shaft assembly	<a href="#">Buy now</a>
36	<a href="#">902800302400</a> Key, woodruff(662)	<a href="#">Buy now</a>
37	<a href="#">61N455510000</a> Pinion	<a href="#">Buy now</a>
38	<a href="#">9017910M1400</a> Nut(6j8)	<a href="#">Buy now</a>
39	<a href="#">933320000500</a> Brg,cyl-cal roller 0.19g nt	<a href="#">Buy now</a>
40	<a href="#">6L2455670013</a> Shim (t:1.3mm)	<a href="#">Buy now</a>
41	<a href="#">61N455601000</a> Gear	<a href="#">Buy now</a>
42	<a href="#">6L2456110000</a> Shaft, propeller	<a href="#">Buy now</a>
43	<a href="#">648456350000</a> Plunger,shift	<a href="#">Buy now</a>
44	<a href="#">6FM456310000</a> Clutch, dog	<a href="#">Buy now</a>
45	<a href="#">902500501000</a> Pin straight 648456320000	<a href="#">Buy now</a>
46	<a href="#">648456330000</a> Ring, cross pin	<a href="#">Buy now</a>
47	<a href="#">905011006500</a> Spring compression648456360000	<a href="#">Buy now</a>

## Lower Casing & Drive 1

Diagram not available

Ref	Part	
48	<a href="#">902012041700</a> Washer, plate(663)	<a href="#">Buy now</a>
49	<a href="#">61N455710000</a> Gear	<a href="#">Buy now</a>
50	<a href="#">6L2455773000</a> Shim (t:1.3mm)	<a href="#">Buy now</a>
51	<a href="#">61N45361014D</a> Cap, lower casing	<a href="#">Buy now</a>
52	<a href="#">933060061200</a> Bearing(2hr)	<a href="#">Buy now</a>
53	<a href="#">9321064ME700</a> O-ring	<a href="#">Buy now</a>
54	<a href="#">933152200400</a> Brg,cyl-cal roller 21g nt	<a href="#">Buy now</a>
55	<a href="#">9310120M0700</a> Oil seal	<a href="#">Buy now</a>
56	<a href="#">9321065M5000</a> O-ring	<a href="#">Buy now</a>
57	<a href="#">970750602000</a> Bolt(7u8)	<a href="#">Buy now</a>
59	<a href="#">65W441500000</a> Shift cam assembly	<a href="#">Buy now</a>

## Lower Casing & Drive 2

Diagram not available

Ref	Part	
1	<a href="#">65W443610000</a> Tube, water	<a href="#">Buy now</a>
2	<a href="#">902021206000</a> Washer, plate(663)	<a href="#">Buy now</a>
3	<a href="#">904301207200</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">9360611M2400</a> Pin, dowel	<a href="#">Buy now</a>
5	<a href="#">9010510M1200</a> Bolt (689)	<a href="#">Buy now</a>
6	<a href="#">929951060000</a> Washer, plate	<a href="#">Buy now</a>
7	<a href="#">61N453710000</a> Tab-trim	<a href="#">Buy now</a>
8	<a href="#">9011906M4800</a> Bolt, with washer(61n)	<a href="#">Buy now</a>
9	<a href="#">6L2452140000</a> Cover, water inlet	<a href="#">Buy now</a>
10	<a href="#">6L2452150000</a> Cover, water inlet	<a href="#">Buy now</a>
11	<a href="#">9015105M0500</a> Screw, countersunk	<a href="#">Buy now</a>
12	<a href="#">901850500200</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
13	<a href="#">6L2459870100</a> Spacer	<a href="#">Buy now</a>
14	<a href="#">689459970000</a> Spacer	<a href="#">Buy now</a>
15	<a href="#">929901420000</a> Washer, plain	<a href="#">Buy now</a>

## Lower Casing & Drive 2

*Diagram not available*

Ref	Part	
16	<a href="#">901711401300</a> Nut(664)	<a href="#">Buy now</a>
17	<a href="#">914903002200</a> Pin, cotter	<a href="#">Buy now</a>
18	<a href="#">6644595200EL</a> Propeller (3x9-7/8 x14 -f)	<a href="#">Buy now</a>

# Oil Pan

Diagram not available

Ref	Part	
1	<a href="#">65W153620100</a> Plug, oil level	<a href="#">Buy now</a>
2	<a href="#">62Y115750000</a> Relief valve ass'y	<a href="#">Buy now</a>
3	<a href="#">62Y134750000</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">975130652500</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
5	<a href="#">65W134110000</a> Strainer, oil	<a href="#">Buy now</a>
6	<a href="#">975130651600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
7	<a href="#">9360812M0500</a> Pin, dowel b (6e5)	<a href="#">Buy now</a>
8	<a href="#">65W1531103CA</a> Oil pan	<a href="#">Buy now</a>
9	<a href="#">62Y153120000</a> Gasket, oil pan	<a href="#">Buy now</a>
10	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
11	<a href="#">65W153160000</a> Damper 1	<a href="#">Buy now</a>
12	<a href="#">9034014M0600</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
13	<a href="#">9043014M0900</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">975750652500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>

# Oil Pump

Diagram not available

Ref	Part	
1	<a href="#">9310237M4000</a> Oil seal(62y)	<a href="#">Buy now</a>
2	<a href="#">65W121710000</a> Camshaft 1	<a href="#">Buy now</a>
3	<a href="#">65W115370100</a> Gear, driven	<a href="#">Buy now</a>
4	<a href="#">936051414300</a> Pin (2h7)	<a href="#">Buy now</a>
5	<a href="#">9020110M0600</a> Washer, plate(62y)	<a href="#">Buy now</a>
6	<a href="#">958951004000</a> Bolt, flange deep recess	<a href="#">Buy now</a>
7	<a href="#">65W462410000</a> Belt	<a href="#">Buy now</a>
8	<a href="#">65W115361000</a> Gear, drive	<a href="#">Buy now</a>
9	<a href="#">65W114760000</a> Spring	<a href="#">Buy now</a>
10	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
11	<a href="#">65W133000000</a> Oil pump assembly	<a href="#">Buy now</a>
12	<a href="#">9321033MH200</a> O-ring(62y)	<a href="#">Buy now</a>
13	<a href="#">9321012MG900</a> O-ring(62y)	<a href="#">Buy now</a>
14	<a href="#">932101451500</a> O-ring (11h)	<a href="#">Buy now</a>
15	<a href="#">975130653500</a> Bolt(3rv)	<a href="#">Buy now</a>

## Remo Con Attachment

Diagram not available

Ref	Part	
1	<a href="#">65W485010000</a> Remote cont. attachment assembly.	<a href="#">Buy now</a>
2	<a href="#">65W441420000</a> Joint	<a href="#">Buy now</a>
3	<a href="#">916903032000</a> Pin, spring	<a href="#">Buy now</a>
4	<a href="#">65W441250000</a> Lever, shift rod	<a href="#">Buy now</a>
5	<a href="#">9038706M2900</a> Coller (6a0)	<a href="#">Buy now</a>
6	<a href="#">9020106M3100</a> Washer (6a0)	<a href="#">Buy now</a>
7	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
8	<a href="#">65W441920000</a> Joint, rod 1	<a href="#">Buy now</a>
9	<a href="#">9020105M0600</a> Washer, plate(61u)	<a href="#">Buy now</a>
10	<a href="#">904681000500</a> Pin, hair 6264123500	<a href="#">Buy now</a>
11	<a href="#">904681800800</a> Clip 620436610000	<a href="#">Buy now</a>
12	<a href="#">6FM483440000</a> Cable end, remote control	<a href="#">Buy now</a>
14	<a href="#">6H3485380000</a> Clamp, cable	<a href="#">Buy now</a>
15	<a href="#">65W427252000</a> Grommet	<a href="#">Buy now</a>
16	<a href="#">62Y427270000</a> Grommet	<a href="#">Buy now</a>



## Remo Con Attachment

*Diagram not available*

Ref	Part	
17	<a href="#">65W263261000</a> Grommet	<a href="#">Buy now</a>
18	<a href="#">65W427261000</a> Grommet	<a href="#">Buy now</a>
19	<a href="#">65W485110000</a> Hook, steering	<a href="#">Buy now</a>
20	<a href="#">902011012000</a> Washer, plate	<a href="#">Buy now</a>

# Repair Kit 1

Diagram not available

Ref	Part	
1	<a href="#">65WW00010000</a> Power Head Gasket Kit	<a href="#">Buy now</a>
2	<a href="#">65W156630000</a> Seal	<a href="#">Buy now</a>
3	<a href="#">65W111690000</a> Gasket, breather cover	<a href="#">Buy now</a>
4	<a href="#">904301411500</a> Gasket (663)	<a href="#">Buy now</a>
5	<a href="#">65W113510000</a> Gasket, cylinder	<a href="#">Buy now</a>
6	<a href="#">62Y124140000</a> Gasket, cover	<a href="#">Buy now</a>
7	<a href="#">65W411140000</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
8	<a href="#">904300601400</a> Gasket 256113960000	<a href="#">Buy now</a>
9	<a href="#">65W111811000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
10	<a href="#">65W113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
11	<a href="#">932102480000</a> O-ring	<a href="#">Buy now</a>
12	<a href="#">9310243M4200</a> Oil seal(62y)	<a href="#">Buy now</a>
13	<a href="#">9310235M4700</a> Oil seal(62y)	<a href="#">Buy now</a>
14	<a href="#">65W141980000</a> Gasket	<a href="#">Buy now</a>
15	<a href="#">65W144571000</a> Seal	<a href="#">Buy now</a>

## Repair Kit 1

*Diagram not available*

Ref	Part	
16	<a href="#">65W136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
17	<a href="#">9310237M4000</a> Oil seal(62y)	<a href="#">Buy now</a>
18	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
19	<a href="#">9321033MH200</a> O-ring(62y)	<a href="#">Buy now</a>
20	<a href="#">9321012MG900</a> O-ring(62y)	<a href="#">Buy now</a>
21	<a href="#">932101451500</a> O-ring (11h)	<a href="#">Buy now</a>
22	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>

## Repair Kit 2

Diagram not available

Ref	Part	
1	<a href="#">65WW00930000</a> Carburetor repair kit	<a href="#">Buy now</a>
2	<a href="#">65W141260000</a> Gasket	<a href="#">Buy now</a>
3	<a href="#">6G1145460000</a> Valve, needle	<a href="#">Buy now</a>
4	<a href="#">676141860000</a> Pin, valve	<a href="#">Buy now</a>
5	<a href="#">6H4145480000</a> Pin, float arm	<a href="#">Buy now</a>
6	<a href="#">65W143730000</a> Cover, plunger cap	<a href="#">Buy now</a>
7	<a href="#">65W141470000</a> O-ring	<a href="#">Buy now</a>
8	<a href="#">65W143350000</a> Spring, plunger	<a href="#">Buy now</a>
9	<a href="#">65W143840000</a> Gasket, float chamber	<a href="#">Buy now</a>
10	<a href="#">65W143980000</a> Washer	<a href="#">Buy now</a>
11	<a href="#">979800411400</a> Screw, pan head(ga5)	<a href="#">Buy now</a>
12	<a href="#">63V149850000</a> Float	<a href="#">Buy now</a>
13	<a href="#">663141590000</a> Clip	<a href="#">Buy now</a>

## Repair Kit 3

Diagram not available

Ref	Part	
1	<a href="#">65WW00012000</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">62Y134750000</a> Gasket	<a href="#">Buy now</a>
3	<a href="#">62Y153120000</a> Gasket, oil pan	<a href="#">Buy now</a>
4	<a href="#">9043014M0900</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">9310116M3600</a> Oil seal(6a8)	<a href="#">Buy now</a>
6	<a href="#">62Y411330000</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
7	<a href="#">65W451280000</a> Seal 2	<a href="#">Buy now</a>
8	<a href="#">932102624000</a> O-ring	<a href="#">Buy now</a>
9	<a href="#">932102613000</a> O-ring	<a href="#">Buy now</a>
10	<a href="#">932102216400</a> O-ring	<a href="#">Buy now</a>
11	<a href="#">6L2443670000</a> Damper, water seal 3	<a href="#">Buy now</a>
12	<a href="#">932104516100</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">9321006ME600</a> O-ring	<a href="#">Buy now</a>
14	<a href="#">61N453150000</a> Packing, lower casing	<a href="#">Buy now</a>
15	<a href="#">931012206700</a> Oil seal (22x36x6-663)	<a href="#">Buy now</a>

## Repair Kit 3

Diagram not available

Ref	Part	
16	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
17	<a href="#">904300800300</a> Gasket	<a href="#">Buy now</a>
18	<a href="#">9321064ME700</a> O-ring	<a href="#">Buy now</a>
19	<a href="#">9310120M0700</a> Oil seal	<a href="#">Buy now</a>
20	<a href="#">9321065M5000</a> O-ring	<a href="#">Buy now</a>
21	<a href="#">904301207200</a> Gasket	<a href="#">Buy now</a>
22	<a href="#">61NW00781100</a> Water pump repair kit	<a href="#">Buy now</a>
23	<a href="#">61N443110100</a> Housing, water pump	<a href="#">Buy now</a>
25	<a href="#">61N443220100</a> Insert, cartridge	<a href="#">Buy now</a>
26	<a href="#">6H4443520200</a> Impeller	<a href="#">Buy now</a>
28	<a href="#">61N443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
29	<a href="#">970950604000</a> Bolt (682)	<a href="#">Buy now</a>
30	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
31	<a href="#">902800302400</a> Key, woodruff(662)	<a href="#">Buy now</a>

# Starting Motor

Diagram not available

Ref	Part	
1	<a href="#">65W818000100</a> Starting motor assembly	<a href="#">Buy now</a>
2	<a href="#">65W818260000</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">65W818570100</a> Retainer	<a href="#">Buy now</a>
4	<a href="#">65W818300000</a> Front Bracket assembly	<a href="#">Buy now</a>
5	<a href="#">65W818070000</a> Gear assembly, starting motor	<a href="#">Buy now</a>
6	<a href="#">65W818500100</a> Armature assembly	<a href="#">Buy now</a>
7	<a href="#">65W818200000</a> Rear bracket assembly	<a href="#">Buy now</a>
8	<a href="#">65W818010000</a> Brush set	<a href="#">Buy now</a>
9	<a href="#">65W818400000</a> Brush holder assembly	<a href="#">Buy now</a>
10	<a href="#">65W818250000</a> Screw	<a href="#">Buy now</a>
11	<a href="#">9011908M3900</a> Bolt, with washer	<a href="#">Buy now</a>
12	<a href="#">9010908M7700</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">9010908M7800</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">953800870000</a> Nut(661)	<a href="#">Buy now</a>
15	<a href="#">929900860000</a> Washer, plain (663)	<a href="#">Buy now</a>

# Steering

Diagram not available

Ref	Part	
1	<a href="#">65WW0084014D</a> Handle steering assembly	<a href="#">Buy now</a>
2	<a href="#">65W441110000</a> Handle, gear shift	<a href="#">Buy now</a>
3	<a href="#">9011906M8500</a> Bolt, with washer	<a href="#">Buy now</a>
4	<a href="#">9020612M0000</a> Washer, wave (676)	<a href="#">Buy now</a>
5	<a href="#">9020112M0700</a> Washer, plate	<a href="#">Buy now</a>
6	<a href="#">65W421230000</a> Bolt, handle joint	<a href="#">Buy now</a>
7	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
8	<a href="#">65W441240000</a> Link, shift rod	<a href="#">Buy now</a>
9	<a href="#">929900620000</a> Ybs66-6 washer, plain	<a href="#">Buy now</a>
10	<a href="#">904681800800</a> Clip 620436610000	<a href="#">Buy now</a>
11	<a href="#">6X3441910000</a> Indicator, shift	<a href="#">Buy now</a>
12	<a href="#">65W42101014D</a> Handle, steering	<a href="#">Buy now</a>
13	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">65W421380000</a> Lever, throttle	<a href="#">Buy now</a>
15	<a href="#">65W421590000</a> Stay	<a href="#">Buy now</a>



# Steering

Diagram not available

Ref	Part	
16	<a href="#">6EEG21260000</a> Friction, steering	<a href="#">Buy now</a>
17	<a href="#">65W421250000</a> Bolt, friction adjusting	<a href="#">Buy now</a>
18	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
19	<a href="#">66M421770000</a> Rubber, handle	<a href="#">Buy now</a>
20	<a href="#">66M421190000</a> Grip, steering handle	<a href="#">Buy now</a>
21	<a href="#">6J0421371000</a> Indicator, throttle	<a href="#">Buy now</a>
22	<a href="#">9026902M0900</a> Rivet(6I5)	<a href="#">Buy now</a>
23	<a href="#">9014905M1300</a> Screw, countersunk	<a href="#">Buy now</a>
24	<a href="#">929031060000</a> Washer, plate	<a href="#">Buy now</a>
25	<a href="#">905012321500</a> Spring (655)	<a href="#">Buy now</a>
26	<a href="#">903860803200</a> Bushing (650)	<a href="#">Buy now</a>
27	<a href="#">65W263110000</a> Cable, throttle 1	<a href="#">Buy now</a>
28	<a href="#">9044610M8600</a> Hose	<a href="#">Buy now</a>
29	<a href="#">9044614M8800</a> Hose	<a href="#">Buy now</a>
30	<a href="#">66R421710000</a> Bushing	<a href="#">Buy now</a>

## Steering

Diagram not available

Ref	Part	
31	<a href="#">9020143M0000</a> Washer, plate	<a href="#">Buy now</a>
32	<a href="#">9020643M2200</a> Washer, wave	<a href="#">Buy now</a>
33	<a href="#">9020243M5700</a> Washer, plate	<a href="#">Buy now</a>
34	<a href="#">9038640M9900</a> Bush	<a href="#">Buy now</a>
35	<a href="#">65W421310100</a> Cover, handle steering	<a href="#">Buy now</a>
36	<a href="#">957801030000</a> Nut, nylon (6e5)	<a href="#">Buy now</a>
37	<a href="#">953801070000</a> Nut (682)	<a href="#">Buy now</a>
38	<a href="#">65W42121014D</a> Bracket	<a href="#">Buy now</a>
39	<a href="#">65W441730000</a> Lever, shift control	<a href="#">Buy now</a>
40	<a href="#">9025403M0500</a> Pin, spring	<a href="#">Buy now</a>

## Top Cowling

Diagram not available

Ref	Part	
2	<a href="#">65W426130000</a> Molding Air Duct	<a href="#">Buy now</a>
3	<a href="#">977806052000</a> Screw, tapping(6k8)	<a href="#">Buy now</a>
5	<a href="#">9010906MA400</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">65W426520000</a> Hook	<a href="#">Buy now</a>
7	<a href="#">9026604M0400</a> Rivet(6e7)	<a href="#">Buy now</a>
8	<a href="#">65W426150100</a> Seal	<a href="#">Buy now</a>
9	<a href="#">65W426783000</a> Graphic, Rear	<a href="#">Buy now</a>
10	<a href="#">65WW00701000</a> Graphic Set	<a href="#">Buy now</a>
11	<a href="#">65W426811000</a> Emblem, yamaha	<a href="#">Buy now</a>
12	<a href="#">65W426821000</a> Emblem, yamaha	<a href="#">Buy now</a>
13	<a href="#">9020205M3800</a> Washer, plate(6l2)	<a href="#">Buy now</a>
14	<a href="#">956800610000</a> U-nut (6a5)	<a href="#">Buy now</a>

## Upper Casing

Diagram not available

Ref	Part	
1	<a href="#">65W411370394</a> Guide, Exhaust	<a href="#">Buy now</a>
2	<a href="#">9310416M0100</a> Oil seal(6a8)	<a href="#">Buy now</a>
3	<a href="#">65W411310094</a> Manifold, Ext. 1	<a href="#">Buy now</a>
4	<a href="#">62Y411330000</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
5	<a href="#">975750654500</a> Bolt, hexagon	<a href="#">Buy now</a>
6	<a href="#">6D545111108D</a> Casing, upper	<a href="#">Buy now</a>
7	<a href="#">9011908M7900</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
8	<a href="#">9011908M8200</a> Bolt, with washer(697)	<a href="#">Buy now</a>
9	<a href="#">65W451510000</a> Cover, upper casing	<a href="#">Buy now</a>
10	<a href="#">979800521600</a> Screw, pan w/ plain	<a href="#">Buy now</a>
11	<a href="#">9015706M0600</a> Screw, pan head(6m7)	<a href="#">Buy now</a>
12	<a href="#">65W451280000</a> Seal 2	<a href="#">Buy now</a>

# Valve

Diagram not available

Ref	Part	
1	<a href="#">67C121110000</a> Valve, intake	<a href="#">Buy now</a>
2	<a href="#">62Y121210000</a> Valve, exhaust	<a href="#">Buy now</a>
3	<a href="#">62Y121160000</a> Seat, valve spring	<a href="#">Buy now</a>
4	<a href="#">51Y121140000</a> Spring, valve outer	<a href="#">Buy now</a>
5	<a href="#">30X121170000</a> Retainer, valve spring	<a href="#">Buy now</a>
6	<a href="#">30X121180000</a> Cotter, valve	<a href="#">Buy now</a>
7	<a href="#">6EEE21190000</a> Seal, valve stem	<a href="#">Buy now</a>
8	<a href="#">65W121460000</a> Shaft Rocker	<a href="#">Buy now</a>
9	<a href="#">65W121510000</a> Arm, valve rocker	<a href="#">Buy now</a>
10	<a href="#">62Y121590000</a> Screw Valve Adjusting	<a href="#">Buy now</a>
11	<a href="#">62Y121580000</a> Nut, lock	<a href="#">Buy now</a>
12	<a href="#">62Y122380000</a> Plate Bolt Stopper	<a href="#">Buy now</a>
13	<a href="#">62Y122160000</a> Spring	<a href="#">Buy now</a>
14	<a href="#">9010908M6300</a> Bolt(62y)	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.