



# Yamaha F4AMH 1998

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Bottom Cowling</b>	3
<b>Bracket 1</b>	4
<b>Carburetor</b>	8
<b>Control</b>	10
<b>Crankshaft &amp; Piston</b>	11
<b>Cylinder &amp; Crankcase 1</b>	12
<b>Cylinder &amp; Crankcase 2</b>	14
<b>Fuel 1</b>	16
<b>Fuel 2</b>	17
<b>Fuel Tank</b>	20
<b>Generator</b>	21
<b>Intake</b>	22
<b>Lower Casing &amp; Drive 1</b>	23
<b>Lower Casing &amp; Drive 2</b>	26
<b>Repair Kit 1</b>	27
<b>Repair Kit 2</b>	29
<b>Starter</b>	30
<b>Steering</b>	32
<b>Top Cowling</b>	34
<b>Upper Casing</b>	35
<b>Valve</b>	36

## Bottom Cowling



Ref	Part	
1	<a href="#">67D427110000</a> Cowling, Bottom 1	<a href="#">Buy now</a>
2	<a href="#">67D426620000</a> Damper	<a href="#">Buy now</a>
4	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">6L5426470000</a> Holder, clamp band	<a href="#">Buy now</a>
7	<a href="#">6L5428230000</a> Plate, stop	<a href="#">Buy now</a>
8	<a href="#">9016703M0200</a> Screw, tapping(6I5)	<a href="#">Buy now</a>
9	<a href="#">9048022M7200</a> Grommet	<a href="#">Buy now</a>
10	<a href="#">67D427310000</a> Carring, handle	<a href="#">Buy now</a>
11	<a href="#">67D427350000</a> Protector	<a href="#">Buy now</a>
13	<a href="#">9011906M7900</a> Bolt, with washer	<a href="#">Buy now</a>
14	<a href="#">9046407M5000</a> Clamp	<a href="#">Buy now</a>
15	<a href="#">904640707800</a> Clamp(81k)	<a href="#">Buy now</a>


# Bracket 1



67DJA-8120

Ref	Part	
1	<a href="#">67D245910100</a> Emblem, Fuel Cock	<a href="#">Buy now</a>
2	<a href="#">6E043111024D</a> Bracket, clamp 1	<a href="#">Buy now</a>
3	<a href="#">6E043112014D</a> Bracket, clamp 2	<a href="#">Buy now</a>
4	<a href="#">620431140000</a> Pad, transom clamp	<a href="#">Buy now</a>
5	<a href="#">6E0431160100</a> Screw, transom clamp	<a href="#">Buy now</a>
6	<a href="#">6EEG31180000</a> Handle, transom cl	<a href="#">Buy now</a>
7	<a href="#">9024304M0100</a> Pin(6a1)	<a href="#">Buy now</a>
8	<a href="#">9010108M0700</a> Bolt(6e0)	<a href="#">Buy now</a>
9	<a href="#">9020208M5800</a> Washer, plate	<a href="#">Buy now</a>
10	<a href="#">6A1431130100</a> Plate, clamp bracket	<a href="#">Buy now</a>
11	<a href="#">901850805700</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
12	<a href="#">6EEG31220000</a> Collar	<a href="#">Buy now</a>
13	<a href="#">901010633500</a> Bolt, hexagon (624)	<a href="#">Buy now</a>
14	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
15	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>


# Bracket 1



67DJA-8120

Ref	Part	
16	<a href="#">67D43311004D</a> Bracket, swivel 1	<a href="#">Buy now</a>
17	<a href="#">6EEG3312008D</a> Bracket, swivel 2	<a href="#">Buy now</a>
18	<a href="#">958950603500</a> Bolt, flange(4nx)	<a href="#">Buy now</a>
19	<a href="#">6E0431810000</a> Lever, tilt stop 1	<a href="#">Buy now</a>
20	<a href="#">6E0436320000</a> Knob, tilt	<a href="#">Buy now</a>
21	<a href="#">6E0433130094</a> Bracket, swivel 3	<a href="#">Buy now</a>
22	<a href="#">620431890000</a> Bushing	<a href="#">Buy now</a>
23	<a href="#">958800602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
24	<a href="#">905081602000</a> Spring 6474319800	<a href="#">Buy now</a>
25	<a href="#">905081602100</a> Spring 6474318800	<a href="#">Buy now</a>
26	<a href="#">6E0431600100</a> Tilt rod assembly	<a href="#">Buy now</a>
28	<a href="#">916903000800</a> Pin. spring(656)	<a href="#">Buy now</a>
29	<a href="#">9050208M0500</a> Spring, conical(6e0)	<a href="#">Buy now</a>
30	<a href="#">6E043614005B</a> Plate, tilt lock	<a href="#">Buy now</a>
31	<a href="#">9050814M1000</a> Spring, torsion (6e0)	<a href="#">Buy now</a>


# Bracket 1



67DJA-8120

Ref	Part	
32	<a href="#">9050814M1100</a> Spring, torsion (6e0)	<a href="#">Buy now</a>
33	<a href="#">958950601000</a> Bolt, flange(7ht)	<a href="#">Buy now</a>
34	<a href="#">6EEG25370000</a> Bushing, pivot sha	<a href="#">Buy now</a>
35	<a href="#">67D425390000</a> Bushing, pivot sha	<a href="#">Buy now</a>
36	<a href="#">68DG25380000</a> Bush Pivot Shaft 2	<a href="#">Buy now</a>
37	<a href="#">68DG25490000</a> Bush, pivot shaft 4	<a href="#">Buy now</a>
38	<a href="#">6E0425280300</a> Plate, friction	<a href="#">Buy now</a>
39	<a href="#">6L5425290100</a> Screw, friction piece	<a href="#">Buy now</a>
40	<a href="#">6L5425610000</a> Knob, steering lock	<a href="#">Buy now</a>
41	<a href="#">6L5441960000</a> Indicator 3	<a href="#">Buy now</a>
42	<a href="#">6L5441970000</a> Indicator 4	<a href="#">Buy now</a>
43	<a href="#">9026604M0500</a> Rivet(6I5)	<a href="#">Buy now</a>
44	<a href="#">68DG2511004D</a> Bracket, Steering	<a href="#">Buy now</a>
45	<a href="#">970750803000</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
46	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>

# Bracket 1




  
 67DJA-8120

Ref	Part	
47	<a href="#">9360412M0700</a> Pin, dowel (688)	<a href="#">Buy now</a>
48	<a href="#">67D426620000</a> Damper	<a href="#">Buy now</a>



# Carburetor




67DUS-8060

Ref	Part	
1	<a href="#">67D143010000</a> Carburetor assembly 1	<a href="#">Buy now</a>
2	<a href="#">6E5143210000</a> Screw, throttle	<a href="#">Buy now</a>
3	<a href="#">6J8143340000</a> Spring, throttle	<a href="#">Buy now</a>
4	<a href="#">67D143850000</a> Float	<a href="#">Buy now</a>
5	<a href="#">67D149660000</a> Rubber cap	<a href="#">Buy now</a>
6	<a href="#">67D143860000</a> Pin, float	<a href="#">Buy now</a>
7	<a href="#">67D145460000</a> Valve, needle	<a href="#">Buy now</a>
8	<a href="#">67D1492E3400</a> Jet, main (#68)	<a href="#">Buy now</a>
9	<a href="#">67D1492F1800</a> Jet, air slow (#36)	<a href="#">Buy now</a>
10	<a href="#">67D1492A0000</a> Nozzle, main	<a href="#">Buy now</a>
11	<a href="#">67D149840000</a> Gasket, float chamber	<a href="#">Buy now</a>
12	<a href="#">67D149810000</a> Body, float chamber	<a href="#">Buy now</a>
13	<a href="#">6J8149590000</a> Gasket, drain screw	<a href="#">Buy now</a>
14	<a href="#">66T149910000</a> Plug, drain	<a href="#">Buy now</a>
15	<a href="#">985800401200</a> Screw, pan head (686)	<a href="#">Buy now</a>




# Carburetor



**FWD**  
67DUS-8060

Ref	Part	
16	<a href="#">67D143230000</a> Screw, air adjusting	<a href="#">Buy now</a>
17	<a href="#">67D145360000</a> Gasket	<a href="#">Buy now</a>
18	<a href="#">67D145270000</a> Plate	<a href="#">Buy now</a>
19	<a href="#">67D141260000</a> Plug	<a href="#">Buy now</a>


## Control



67DJA-8140


Ref	Part	
1	<a href="#">67D441110000</a> Handle, gear shift	<a href="#">Buy now</a>
2	<a href="#">986800552000</a> Ybs53-520 screw,flat head	<a href="#">Buy now</a>
3	<a href="#">67DWG411009M</a> Change shaft set	<a href="#">Buy now</a>
4	<a href="#">932101232700</a> O-ring(3ld)	<a href="#">Buy now</a>
5	<a href="#">905011227400</a> Spring 6554411600	<a href="#">Buy now</a>
6	<a href="#">935051602400</a> Ball	<a href="#">Buy now</a>
7	<a href="#">6E0441210000</a> Lever, shift rod 1	<a href="#">Buy now</a>
8	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">67D441430000</a> Rod Shift	<a href="#">Buy now</a>
11	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
13	<a href="#">67D441450000</a> Connector, shift rod 1	<a href="#">Buy now</a>
14	<a href="#">67D441460000</a> Connector, shift rod 2	<a href="#">Buy now</a>
15	<a href="#">958950602000</a> Bolt, flange(jk3)	<a href="#">Buy now</a>

## Crankshaft & Piston




Ref	Part	
1	<a href="#">67D114000000</a> Crankshaft assembly	<a href="#">Buy now</a>
2	<a href="#">90201266P200</a> Washer, plate(ja8)	<a href="#">Buy now</a>
3	<a href="#">67D116500000</a> Connecting rod kit	<a href="#">Buy now</a>
4	<a href="#">67D116540000</a> Bolt, connecting rod	<a href="#">Buy now</a>
5	<a href="#">67D116360000</a> Piston (0.50Mm O/s)	<a href="#">Buy now</a>
6	<a href="#">67D116030000</a> Piston ring (set)	<a href="#">Buy now</a>
7	<a href="#">67D116330000</a> Pin, Piston	<a href="#">Buy now</a>
8	<a href="#">934501408800</a> Circlip (22f)	<a href="#">Buy now</a>

## Cylinder & Crankcase 1




Ref	Part	
3	<a href="#">67D111331000</a> Guide, valve 1	<a href="#">Buy now</a>
4	<a href="#">970950801400</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">904300814300</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
6	<a href="#">9010508M8100</a> Bolt, Flange	<a href="#">Buy now</a>
8	<a href="#">9010506M2500</a> Bolt (6g1)	<a href="#">Buy now</a>
9	<a href="#">995101011400</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
10	<a href="#">67D11181A000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
11	<a href="#">67D111910000</a> Cover, cylinder head 1	<a href="#">Buy now</a>
13	<a href="#">9010506M1400</a> Bolt (6e0)	<a href="#">Buy now</a>
14	<a href="#">66M124110000</a> Thermostat	<a href="#">Buy now</a>
15	<a href="#">67D12413001S</a> Cover, thermostat	<a href="#">Buy now</a>
16	<a href="#">6EEF43770000</a> Pipe, joint 2	<a href="#">Buy now</a>
17	<a href="#">6G8113250000</a> Anode	<a href="#">Buy now</a>
18	<a href="#">978800502500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
19	<a href="#">67D12414A000</a> Gasket, cover	<a href="#">Buy now</a>

## Cylinder & Crankcase 1




Ref	Part	
20	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
21	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
22	<a href="#">9044509M0000</a> Hose (I180)	<a href="#">Buy now</a>
23	<a href="#">947020003900</a> Plug, spark (b6hs)	<a href="#">Buy now</a>

## Cylinder & Crankcase 2



Ref	Part	
1	<a href="#">68DE1311021S</a> Cylinder 1	<a href="#">Buy now</a>
2	<a href="#">650243780000</a> Pipe, joint 2	<a href="#">Buy now</a>
3	<a href="#">6H1144850000</a> Pipe, joint	<a href="#">Buy now</a>
4	<a href="#">9044507MA300</a> Hose (I200)	<a href="#">Buy now</a>
5	<a href="#">931022509000</a> Oil seal (25x40x5-256)	<a href="#">Buy now</a>
6	<a href="#">93306205U800</a> Bearing (6k8)	<a href="#">Buy now</a>
7	<a href="#">68DE5111001S</a> Crankcase 1	<a href="#">Buy now</a>
8	<a href="#">6EEF43770000</a> Pipe, joint 2	<a href="#">Buy now</a>
9	<a href="#">67D11351A000</a> Gasket, cylinder	<a href="#">Buy now</a>
10	<a href="#">975750855000</a> Bolt, with washer	<a href="#">Buy now</a>
11	<a href="#">995301011400</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
12	<a href="#">970950802000</a> Bolt, hexagon	<a href="#">Buy now</a>
13	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>
14	<a href="#">904300820900</a> Gasket(3gh)	<a href="#">Buy now</a>
15	<a href="#">6EEE539600CA</a> Housing, oil seal	<a href="#">Buy now</a>


## Cylinder & Crankcase 2



Ref	Part	
16	<a href="#">932103553700</a> O-ring	<a href="#">Buy now</a>
17	<a href="#">931022010800</a> Oil seal	<a href="#">Buy now</a>
18	<a href="#">9310110M2500</a> Oil seal(6e0)	<a href="#">Buy now</a>
21	<a href="#">68DE11680000</a> Cover, Breather	<a href="#">Buy now</a>
22	<a href="#">67D11169A000</a> Gasket, Breather Cover	<a href="#">Buy now</a>
23	<a href="#">975950651400</a> Bolt(gj3)	<a href="#">Buy now</a>
24	<a href="#">6G8153460000</a> Breather 1	<a href="#">Buy now</a>
25	<a href="#">985030400600</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
26	<a href="#">7LY131020000</a> Gear unit assembly	<a href="#">Buy now</a>
28	<a href="#">6EEE53620000</a> Plug, oil level	<a href="#">Buy now</a>
29	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>




# Fuel 1




Ref	Part	
1	<a href="#">67D241110000</a> Tank, Fuel	<a href="#">Buy now</a>
2	<a href="#">67D246100000</a> Cap assembly	<a href="#">Buy now</a>
3	<a href="#">905011026000</a> Spring, safety 6152463500	<a href="#">Buy now</a>
4	<a href="#">6J8217580000</a> Washer, special 2	<a href="#">Buy now</a>
6	<a href="#">6H1217570000</a> Washer, special 1	<a href="#">Buy now</a>
7	<a href="#">6L5246410000</a> Gasket, cap 1	<a href="#">Buy now</a>
8	<a href="#">6A0823170000</a> Damper, ignition coil	<a href="#">Buy now</a>
9	<a href="#">624425420000</a> Collar	<a href="#">Buy now</a>
10	<a href="#">9011906M8800</a> Bolt, with washer	<a href="#">Buy now</a>
11	<a href="#">6L5242510000</a> Strainer 1	<a href="#">Buy now</a>
12	<a href="#">67D243110000</a> Pipe, Fuel 1	<a href="#">Buy now</a>
13	<a href="#">9046713M1300</a> Clip(6m6)	<a href="#">Buy now</a>

## Fuel 2




Ref	Part	
1	<a href="#">6G1243040200</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">67D243120000</a> Pipe 2	<a href="#">Buy now</a>
5	<a href="#">9046709M0900</a> Clip(6k8)	<a href="#">Buy now</a>
6	<a href="#">67D245000000</a> Fuel cock assembly 1	<a href="#">Buy now</a>
7	<a href="#">9015906M1000</a> Screw, with washer(6I5)	<a href="#">Buy now</a>
8	<a href="#">67D243130000</a> Pipe 3	<a href="#">Buy now</a>
10	<a href="#">9046410M5200</a> Clamp	<a href="#">Buy now</a>
11	<a href="#">646242510200</a> Strainer 1	<a href="#">Buy now</a>
12	<a href="#">9044510M6700</a> Hose (I400)	<a href="#">Buy now</a>
13	<a href="#">9044614M1200</a> Hose(6tc)	<a href="#">Buy now</a>
15	<a href="#">67D244100300</a> Fuel pump assembly	<a href="#">Buy now</a>
16	<a href="#">67D244120000</a> Body 1	<a href="#">Buy now</a>
17	<a href="#">67D244130000</a> Body 2	<a href="#">Buy now</a>

Fuel 2




Ref	Part	
18	<a href="#">6A0244210100</a> Valve, check	<a href="#">Buy now</a>
19	<a href="#">6A0143250000</a> Screw, pan head	<a href="#">Buy now</a>
20	<a href="#">67D244110000</a> Diaphragm	<a href="#">Buy now</a>
21	<a href="#">67D244230000</a> Spring, diaphragm	<a href="#">Buy now</a>
22	<a href="#">67D131310000</a> Plunger	<a href="#">Buy now</a>
23	<a href="#">66M243740000</a> Pin	<a href="#">Buy now</a>
24	<a href="#">67D244540000</a> Spring	<a href="#">Buy now</a>
25	<a href="#">67D244140000</a> Body 3	<a href="#">Buy now</a>
26	<a href="#">66M244710000</a> Diaphragm	<a href="#">Buy now</a>
27	<a href="#">67D244440000</a> Screw	<a href="#">Buy now</a>
28	<a href="#">953800460000</a> Nut,hex	<a href="#">Buy now</a>
29	<a href="#">932102780600</a> O-ring	<a href="#">Buy now</a>
30	<a href="#">970950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
31	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
33	<a href="#">9044510M4300</a> Hose (I400)	<a href="#">Buy now</a>

Fuel 2



Ref	Part	
35	<a href="#">9046410M5300</a> Clamp	<a href="#">Buy now</a>


# Fuel Tank



66MUS-8110


Ref	Part	
1	<a href="#">6YL242010100</a> Fuel Tank assembly (12L)	<a href="#">Buy now</a>
2	<a href="#">6YL246100000</a> Cap Assembly	<a href="#">Buy now</a>
3	<a href="#">6YL246410000</a> Gasket, cap 1	<a href="#">Buy now</a>
4	<a href="#">6YL242600100</a> Fuel meter assembly	<a href="#">Buy now</a>
5	<a href="#">9015705M1600</a> Screw, pan head	<a href="#">Buy now</a>
6	<a href="#">6YL243290000</a> Seal	<a href="#">Buy now</a>
7	<a href="#">6YL242680100</a> Gasket, fuel meter	<a href="#">Buy now</a>
8	<a href="#">6Y1243065100</a> Fuel pipe comp. 1	<a href="#">Buy now</a>
9	<a href="#">9044511M8100</a> Hose (I3000)	<a href="#">Buy now</a>
10	<a href="#">6Y1243605100</a> Primer pump assembly	<a href="#">Buy now</a>
11	<a href="#">9044511M0500</a> Hose (I1000)	<a href="#">Buy now</a>
12	<a href="#">650243515100</a> Band 1	<a href="#">Buy now</a>
13	<a href="#">6G1243050500</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>
14	<a href="#">932100828700</a> O-ring (655)	<a href="#">Buy now</a>
15	<a href="#">6Y1243050200</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>

# Generator



Ref	Part	
1	<a href="#">67D856500000</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">67D856400000</a> T.c.i. unit assembly	<a href="#">Buy now</a>
3	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
4	<a href="#">9017010M3300</a> Nut(6a1)	<a href="#">Buy now</a>
5	<a href="#">90201105A200</a> Washer, plate (4x7)	<a href="#">Buy now</a>
6	<a href="#">67D157230000</a> Pulley Starter	<a href="#">Buy now</a>
7	<a href="#">9010506M2400</a> Bolt (6g1)	<a href="#">Buy now</a>
8	<a href="#">6E3823702100</a> Plug cap assembly	<a href="#">Buy now</a>
9	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
10	<a href="#">904802516100</a> Grommet(656)	<a href="#">Buy now</a>
11	<a href="#">67D825750000</a> Engine stop switch assembly	<a href="#">Buy now</a>
12	<a href="#">682825560000</a> Lanyard, stop switch	<a href="#">Buy now</a>
14	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
15	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>


# Intake



Ref	Part	
1	<a href="#">67D144400000</a> Silencer assembly, Intake	<a href="#">Buy now</a>
2	<a href="#">932103111400</a> O-ring	<a href="#">Buy now</a>
3	<a href="#">904641324900</a> Clamp	<a href="#">Buy now</a>
5	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">9048018M7400</a> Grommet	<a href="#">Buy now</a>
7	<a href="#">9044509M4100</a> Hose (L175)	<a href="#">Buy now</a>
8	<a href="#">9044507M2800</a> Hose (I200)	<a href="#">Buy now</a>
9	<a href="#">67D13646A000</a> Gasket Int. Manifold	<a href="#">Buy now</a>
10	<a href="#">67D136470000</a> Gasket, Manifold 3	<a href="#">Buy now</a>
11	<a href="#">68DE36410094</a> Manifold, Intake 1	<a href="#">Buy now</a>
12	<a href="#">67D13645A000</a> Gasket, Manifold 1	<a href="#">Buy now</a>
13	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
15	<a href="#">67D263300000</a> Wire starter	<a href="#">Buy now</a>




## Lower Casing & Drive 1




Ref	Part	
1	<a href="#">67D45300004D</a> Lower Unit assembly	<a href="#">Buy now</a>
3	<a href="#">6E0453170900</a> Bushing	<a href="#">Buy now</a>
4	<a href="#">6E0453160900</a> Bushing	<a href="#">Buy now</a>
5	<a href="#">9310110M1400</a> Oil seal	<a href="#">Buy now</a>
6	<a href="#">933060042300</a> Bearing (7k2)	<a href="#">Buy now</a>
7	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
8	<a href="#">9034008M0400</a> Plug, straight screw	<a href="#">Buy now</a>
9	<a href="#">6E045321015B</a> Plate	<a href="#">Buy now</a>
10	<a href="#">6L2441470000</a> Boot, shift rod	<a href="#">Buy now</a>
11	<a href="#">6E045315A000</a> Packing, lower casing	<a href="#">Buy now</a>
12	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">6E045361014D</a> Cap, lower casing	<a href="#">Buy now</a>
16	<a href="#">9310113M1200</a> Oil seal	<a href="#">Buy now</a>
17	<a href="#">932104821400</a> O-ring	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
18	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
19	<a href="#">6E0443110000</a> Housing, water pump	<a href="#">Buy now</a>
20	<a href="#">6E044315A000</a> Gasket,water pump 1	<a href="#">Buy now</a>
21	<a href="#">6E0443220200</a> Insert, cartridge	<a href="#">Buy now</a>
22	<a href="#">6E0443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
23	<a href="#">67D443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
24	<a href="#">6E0443520000</a> Impeller	<a href="#">Buy now</a>
25	<a href="#">936040906600</a> Pin, dowel	<a href="#">Buy now</a>
26	<a href="#">970950604500</a> Bolt, hexagon	<a href="#">Buy now</a>
27	<a href="#">936041808000</a> Pin. dowel. (647)	<a href="#">Buy now</a>
28	<a href="#">6E0443280000</a> Plate	<a href="#">Buy now</a>
29	<a href="#">6E0455110100</a> Shaft, drive	<a href="#">Buy now</a>
30	<a href="#">9046708M0100</a> Clip (6e0)	<a href="#">Buy now</a>
31	<a href="#">6E0455510000</a> Pinion (13t)	<a href="#">Buy now</a>
32	<a href="#">934300600500</a> Circlip(53l)	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
33	<a href="#">9020111M4900</a> Washer, plate (6e0)	<a href="#">Buy now</a>
34	<a href="#">67D455600000</a> Gear	<a href="#">Buy now</a>
35	<a href="#">67D455700000</a> Gear	<a href="#">Buy now</a>
36	<a href="#">67D455760000</a> Washer, thrust 2	<a href="#">Buy now</a>
37	<a href="#">67D456310000</a> Clutch, dog	<a href="#">Buy now</a>
38	<a href="#">905011006400</a> Spring, compression 6164563600	<a href="#">Buy now</a>
39	<a href="#">6EEG56350000</a> Plunger, shift	<a href="#">Buy now</a>
40	<a href="#">67D456110000</a> Shaft, propeller	<a href="#">Buy now</a>
41	<a href="#">67D441500000</a> Shift cam assembly	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
1	<a href="#">67D443600000</a> Water Tube assembly	<a href="#">Buy now</a>
2	<a href="#">6L5452510200</a> Anode	<a href="#">Buy now</a>
3	<a href="#">958950601200</a> Bolt, flange deep recess	<a href="#">Buy now</a>
4	<a href="#">929900630000</a> Washer, tooth	<a href="#">Buy now</a>
5	<a href="#">9011906M4000</a> Bolt, with washer	<a href="#">Buy now</a>
6	<a href="#">9038706M1400</a> Collar(6e0)	<a href="#">Buy now</a>
7	<a href="#">6L5459870100</a> Spacer 1	<a href="#">Buy now</a>
8	<a href="#">6L5456160000</a> Nut, propeller	<a href="#">Buy now</a>
9	<a href="#">914902503000</a> Pin, cotter(6l5)	<a href="#">Buy now</a>
11	<a href="#">6E04594101EL</a> Propeller (3x7-1/2 x8 -ba)	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
1	<a href="#">67DW00010000</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">904300814300</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
3	<a href="#">67D11181A000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
4	<a href="#">68DE1193A000</a> Gasket head cover	<a href="#">Buy now</a>
10	<a href="#">9310110M2500</a> Oil seal(6e0)	<a href="#">Buy now</a>
11	<a href="#">67D11169A000</a> Gasket, Breather Cover	<a href="#">Buy now</a>
12	<a href="#">67D12414A000</a> Gasket, cover	<a href="#">Buy now</a>
13	<a href="#">932103111400</a> O-ring	<a href="#">Buy now</a>
14	<a href="#">67D13646A000</a> Gasket Int. Manifold	<a href="#">Buy now</a>
15	<a href="#">67D13645A000</a> Gasket, Manifold 1	<a href="#">Buy now</a>
18	<a href="#">9321027ME300</a> O-ring	<a href="#">Buy now</a>
19	<a href="#">67DW00930000</a> Carburetor repair kit	<a href="#">Buy now</a>
20	<a href="#">67D143850000</a> Float	<a href="#">Buy now</a>
21	<a href="#">67D143860000</a> Pin, float	<a href="#">Buy now</a>
22	<a href="#">67D145460000</a> Valve, needle	<a href="#">Buy now</a>

## Repair Kit 1



Ref	Part	
23	<a href="#">67D149840000</a> Gasket, float chamber	<a href="#">Buy now</a>
25	<a href="#">979800411200</a> Screw, pan head (686)	<a href="#">Buy now</a>
26	<a href="#">67D145360000</a> Gasket	<a href="#">Buy now</a>


## Repair Kit 2



Ref	Part	
1	<a href="#">6E0W0001C100</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310110M1400</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">6E045315A000</a> Packing, lower casing	<a href="#">Buy now</a>
5	<a href="#">6E044315A000</a> Gasket, water pump 1	<a href="#">Buy now</a>
6	<a href="#">9310113M1200</a> Oil seal	<a href="#">Buy now</a>
7	<a href="#">932104821400</a> O-ring	<a href="#">Buy now</a>
8	<a href="#">68DWG0780000</a> Water Pump Repair Kit	<a href="#">Buy now</a>
9	<a href="#">6E0443110000</a> Housing, water pump	<a href="#">Buy now</a>
11	<a href="#">6E0443220200</a> Insert, cartridge	<a href="#">Buy now</a>
13	<a href="#">6EEG43660000</a> Damper, water seal 2	<a href="#">Buy now</a>
14	<a href="#">6E0443520000</a> Impeller	<a href="#">Buy now</a>
15	<a href="#">970950604500</a> Bolt, hexagon	<a href="#">Buy now</a>
16	<a href="#">936041808000</a> Pin. dowel. (647)	<a href="#">Buy now</a>




# Starter




Ref	Part	
1	<a href="#">67D157100000</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">67D157110000</a> Case, Starter	<a href="#">Buy now</a>
3	<a href="#">63V157950100</a> Guide, rope	<a href="#">Buy now</a>
4	<a href="#">67D157640000</a> Collar 1	<a href="#">Buy now</a>
5	<a href="#">67D157140000</a> Drum, sheave	<a href="#">Buy now</a>
6	<a href="#">67D157410000</a> Pawl, drive	<a href="#">Buy now</a>
7	<a href="#">67D157130000</a> Spring, starter	<a href="#">Buy now</a>
8	<a href="#">67D157050000</a> Spring, drive pawl	<a href="#">Buy now</a>
9	<a href="#">67D157670000</a> Spring	<a href="#">Buy now</a>
10	<a href="#">67D157350000</a> Guide, cam	<a href="#">Buy now</a>
11	<a href="#">67D157930000</a> Screw	<a href="#">Buy now</a>
12	<a href="#">63V157640000</a> Collar 1	<a href="#">Buy now</a>
13	<a href="#">67D157940000</a> Stopper	<a href="#">Buy now</a>
14	<a href="#">67D157340000</a> Spring, return	<a href="#">Buy now</a>
16	<a href="#">6G1157550000</a> Handle, starter	<a href="#">Buy now</a>

# Starter




Ref	Part	
17	<a href="#">6G1157790000</a> Cover	<a href="#">Buy now</a>
18	<a href="#">67D157390000</a> Washer, thrust	<a href="#">Buy now</a>
19	<a href="#">67D157620000</a> Seal Rubber 2	<a href="#">Buy now</a>
20	<a href="#">970950603500</a> Bolt(j52)	<a href="#">Buy now</a>
21	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
22	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
23	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
24	<a href="#">67D157720000</a> Stay 2	<a href="#">Buy now</a>
25	<a href="#">67D157700000</a> Cable comp., starter stop	<a href="#">Buy now</a>

# Steering



Ref	Part	
1	<a href="#">67D42111004D</a> Handle, Steering	<a href="#">Buy now</a>
2	<a href="#">67D421290000</a> Bushing, rubber	<a href="#">Buy now</a>
3	<a href="#">67D421710000</a> Bushing, 1	<a href="#">Buy now</a>
4	<a href="#">67D421720000</a> Bushing, 2	<a href="#">Buy now</a>
5	<a href="#">68DG21810000</a> Washer, 1	<a href="#">Buy now</a>
6	<a href="#">69MG21880000</a> Washer,wave	<a href="#">Buy now</a>
7	<a href="#">67D421820000</a> Washer, 2	<a href="#">Buy now</a>
8	<a href="#">68DG21310000</a> Cover, Handle Steering	<a href="#">Buy now</a>
9	<a href="#">970750802500</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
10	<a href="#">6G1421250100</a> Bolt, friction adjusting	<a href="#">Buy now</a>
11	<a href="#">6EEG21260000</a> Friction, steering	<a href="#">Buy now</a>
12	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
13	<a href="#">67D421190000</a> Grip, steering handle	<a href="#">Buy now</a>
15	<a href="#">9026902M0900</a> Rivet(615)	<a href="#">Buy now</a>
16	<a href="#">67D421770000</a> Rubber, handle	<a href="#">Buy now</a>


# Steering



67DJA-8130



Ref	Part	
17	<a href="#">9014905M1300</a> Screw, countersunk	<a href="#">Buy now</a>
18	<a href="#">929901060000</a> Washer, plate	<a href="#">Buy now</a>
19	<a href="#">905012321500</a> Spring (655)	<a href="#">Buy now</a>
20	<a href="#">903860803200</a> Bushing (650)	<a href="#">Buy now</a>
21	<a href="#">6G1421380100</a> Lever, throttle	<a href="#">Buy now</a>
22	<a href="#">6E0421590200</a> Stay	<a href="#">Buy now</a>
23	<a href="#">978850501200</a> Screw, pan head (646)	<a href="#">Buy now</a>

## Top Cowling




Ref	Part	
2	<a href="#">67D426130000</a> Molding,air duct	<a href="#">Buy now</a>
3	<a href="#">977804001200</a> Screw, trushead tapping (ge31)	<a href="#">Buy now</a>
4	<a href="#">67DW00701000</a> Graphic Set	<a href="#">Buy now</a>
5	<a href="#">67D426771100</a> Graphic, rear	<a href="#">Buy now</a>
6	<a href="#">67D426781000</a> Graphic, rear	<a href="#">Buy now</a>

## Upper Casing



Ref	Part	
1	<a href="#">67D45111004D</a> Casing, Upper	<a href="#">Buy now</a>
2	<a href="#">67D45113A000</a> Gasket, upper casing	<a href="#">Buy now</a>
3	<a href="#">9038706M1400</a> Collar(6e0)	<a href="#">Buy now</a>
4	<a href="#">970950603500</a> Bolt(j52)	<a href="#">Buy now</a>
5	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
7	<a href="#">647451510100</a> Cover, upper casing	<a href="#">Buy now</a>
8	<a href="#">9048010M1300</a> Grommet (6e0)	<a href="#">Buy now</a>
9	<a href="#">67D45211004D</a> Extension	<a href="#">Buy now</a>
11	<a href="#">9011906M7700</a> Bolt, with washer	<a href="#">Buy now</a>
12	<a href="#">6E0453180100</a> Bushing, drive shaft 3	<a href="#">Buy now</a>
13	<a href="#">9342022M0300</a> Cir clip (6e0)	<a href="#">Buy now</a>

# Valve



  
67DJA-8040

Ref	Part	
1	<a href="#">67D121700000</a> Cam shaft assembly	<a href="#">Buy now</a>
2	<a href="#">67D121110000</a> Valve, intake	<a href="#">Buy now</a>
3	<a href="#">67D121210000</a> Valve, exhaust	<a href="#">Buy now</a>
4	<a href="#">6EEE21190000</a> Seal, valve stem	<a href="#">Buy now</a>
5	<a href="#">6EGE21130000</a> Spring, valve inne	<a href="#">Buy now</a>
6	<a href="#">7NJ121170000</a> Retainer, valve spring	<a href="#">Buy now</a>
7	<a href="#">7NJ121180000</a> Cotter, valve	<a href="#">Buy now</a>
8	<a href="#">6EEE21510000</a> Arm, valve rocker	<a href="#">Buy now</a>
9	<a href="#">7FK121650000</a> Pivot, rocker arm	<a href="#">Buy now</a>
10	<a href="#">7FK121580000</a> Nut, lock	<a href="#">Buy now</a>
11	<a href="#">67D121570000</a> Bolt	<a href="#">Buy now</a>
12	<a href="#">67D121550000</a> Guide, Push Rod	<a href="#">Buy now</a>
13	<a href="#">7FK121540000</a> Rod, valve push	<a href="#">Buy now</a>
14	<a href="#">JA9121530000</a> Lifter, valve	<a href="#">Buy now</a>



# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.