



Yamaha F4AMH 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET	5
CARBURETOR	8
CONTROL	10
CRANKSHAFT. PISTON	11
CYLINDER. CRANKCASE 1	12
CYLINDER. CRANKCASE 2	14
FUEL 1	16
FUEL 2	17
GENERATOR	20
INTAKE	21
LOWER CASING. DRIVE 1	22
LOWER CASING. DRIVE 2	25
REPAIR KIT 1	26
REPAIR KIT 2	28
STARTER	29
STEERING	31
TOP COWLING	33
UPPER CASING	34
VALVE	35


Bottom Cowling



C4

Ref	Part	
1	68D-G2711-01 Cowling bottom 1	Buy now
2	68D-G2628-00 Seal rubber 1	Buy now
3	68D-G2712-01 Cowling bottom 2	Buy now
4	68D-G2629-00 Seal	Buy now
5	97095-06016 Bolt, hexagon deep recess	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	6L5-42647-00 Holder, clamp band	Buy now
8	6L5-42823-00 Plate, stop	Buy now
9	90167-03M02 Screw, tapping(615)	Buy now
10	90480-22M72 Grommet	Buy now
11	90161-05001 Screw, Tapping	Buy now
12	90480-10004 Grommet	Buy now
13	68D-G2731-00 Carring, handle	Buy now
14	68D-G2735-00 Protector	Buy now
15	67D-42662-00 Damper	Buy now


Bottom Cowling



Ref	Part	
16	90119-06M79 Bolt, with washer	Buy now
17	90464-07M50 Clamp	Buy now
18	90464-07078 Clamp(81k)	Buy now
19	67D-13444-50 Mark	Buy now
20	68D-E2138-60 12 –	Buy now
21	68D-H257H-00 Plate, Mark	Buy now
22	6G8-2415E-00 Label Caution FOR SAV	Buy now

C4

Bracket




 FWD
68D2010-2150

D1

Ref	Part	
1	68D-F4591-00 Emblem, Fuel Cock	Buy now
4	6M0-G3318-00 Cover	Buy now
5	620-43114-00 Pad, transom clamp	Buy now
6	6E0-43116-01 Screw, transom clamp	Buy now
7	6L8-G3118-01 Handle, transom cl	Buy now
8	90243-04M01 Pin(6a1)	Buy now
9	90101-08M07 Bolt(6e0)	Buy now
10	90202-08M58 Washer, plate	Buy now
11	68D-G3113-00 Plate, clamp bracket	Buy now
12	90185-08057 Nut, nylon (6j8)	Buy now
13	90387-06M11 Collar	Buy now
14	90101-06335 Bolt, hexagon (624)	Buy now
15	92990-06600 Washer, plain (646)	Buy now
16	95380-06600 Nut(661)	Buy now
19	95895-06035 Bolt, flange(4nx)	Buy now

Bracket




68D2010-2150



D1

Ref	Part	
20	6E0-43181-00 Lever, tilt stop 1	Buy now
21	6E0-43632-00 Knob, tilt	Buy now
23	620-43189-00 Bushing	Buy now
24	95895-06020 Bolt, flange(jk3)	Buy now
25	90508-16020 Spring 6474319800	Buy now
26	90508-16021 Spring 6474318800	Buy now
27	68D-G3160-00 Tilt rod assembly	Buy now
28	6N0-G3165-00 Plate, tilt lock	Buy now
29	91690-30008 Pin. spring(656)	Buy now
30	90502-08M05 Spring, conical(6e0)	Buy now
32	90508-14M10 Spring, torsion (6e0)	Buy now
33	90508-14M11 Spring, torsion (6e0)	Buy now
34	95895-06010 Bolt, flange(7ht)	Buy now
35	68D-G2537-00 Bushing, pivot sha	Buy now
36	68D-G2539-00 Bushing, pivot sha	Buy now

Bracket




68D2010-2150

D1

Ref	Part	
37	68D-G2538-00 Bush Pivot Shaft 2	Buy now
38	68D-G2549-00 Bush, pivot shaft 4	Buy now
39	6E0-42528-03 Plate, friction	Buy now
40	6L5-42529-01 Screw, friction piece	Buy now
41	68D-G2561-01 Knob, steering loc	Buy now
42	90266-04M05 Rivet(6I5)	Buy now
44	97075-08030 Bolt, hexagon (fj1)	Buy now
45	92995-08600 Washer, plain (663)	Buy now
46	93604-12M07 Pin, dowel (688)	Buy now


Carburetor



B4

Ref	Part	
1	67D-14301-01 Carburetor assembly 1 FOR STD	Buy now
1	67D-14301-20 Carburetor assembly 1 FOR SAV	Buy now
2	6E5-14321-00 Screw, throttle	Buy now
3	6J8-14334-00 Spring, throttle	Buy now
4	68T-14385-00 Float	Buy now
5	67D-14966-00 Rubber cap	Buy now
6	67D-14386-00 Pin, float	Buy now
7	67D-14546-00 Valve, needle	Buy now
8	67D-1492E-34 Jet, main (#68)	Buy now
9	67D-1492F-18 Jet, air slow (#36)	Buy now
10	67D-1492A-00 Nozzle, main	Buy now
11	67D-14984-00 Gasket, float chamber	Buy now
12	67D-14981-00 Body, float chamber	Buy now
13	6J8-14959-00 Gasket, drin screw	Buy now
14	66T-14991-00 Plug, drain	Buy now


Carburetor



67D0010-8070

B4


Ref	Part	
15	97980-04112 Screw, pan head (686)	Buy now
16	67D-14323-00 Screw, air adjusting FOR 67D-14301-01	Buy now
16	68T-14323-20 Screw Air Adjusting FOR 67D-14301-20	Buy now
17	67D-14536-00 Gasket	Buy now
18	67D-14527-00 Plate	Buy now
19	67D-14126-00 Plug	Buy now



C7

Ref	Part	
1	68D-G4111-00 Handle, gear shift	Buy now
2	98680-05520 Ybs53-520 screw,flat head	Buy now
3	68D-G4119-00 Shaft Change	Buy now
4	68D-G4122-01 Bushing, shift rod lever	Buy now
5	93210-09350 O-ring	Buy now
6	90501-12274 Spring 6554411600	Buy now
7	93505-16024 Ball	Buy now
8	68D-G4121-00 Lever Shift Rod 1	Buy now
9	90119-05M04 Bolt, with washer	Buy now
10	67D-44143-01 Rod Shift	Buy now
11	92990-05600 Washer, plain (646)	Buy now
12	91490-16010 Pin, cotter	Buy now
13	68D-G4145-00 Connector, shift rod 1	Buy now
14	68D-G4146-00 Connector, shift rod 2	Buy now
15	90119-06M00 Bolt, with washer	Buy now

Crankshaft. Piston




67D0010-8030

A6

Ref	Part	
1	67D-11400-00 Crankshaft assembly	Buy now
2	90201-266P2 Washer, plate(ja8)	Buy now
3	67D-11650-00 Connecting rod kit	Buy now
4	67D-11654-00 Bolt, connecting rod	Buy now
5	68D-E1631-00-96 Piston (std)	Buy now
5	68D-E1635-00 3- AP	Buy now
5	68D-E1636-00 3- AP	Buy now
6	68D-E1603-00 Piston ring (set)	Buy now
6	68D-E1604-00 3- AP	Buy now
6	68D-E1605-00 3- AP	Buy now
7	68D-E1633-00 3-	Buy now
8	93450-14088 Circlip (22f)	Buy now

Cylinder. Crankcase 1




68D3100-3020

A5

Ref	Part	
3	67D-11133-10 Guide, valve 1	Buy now
4	97095-08014 Bolt, hexagon deep recess	Buy now
5	90430-08800 Gasket (256-11198-00)	Buy now
6	90105-08M36 Bolt (6g8)	Buy now
7	90105-08046 Bolt, flange	Buy now
8	90105-06M25 Bolt (6g1)	Buy now
9	99510-10114 Pin, dowel(3vd)	Buy now
10	67D-11181-A0 Gasket, cylinder head 1	Buy now
11	67D-11191-00 Cover, cylinder head 1	Buy now
12	68D-E1193-A0 Gasket head cover	Buy now
13	90105-06M14 Bolt (6e0)	Buy now
14	66M-12411-00 Thermostat	Buy now
16	650-24378-00 Pipe, joint 2	Buy now
17	68D-E1325-00 Anode	Buy now
18	97880-05025 Screw, panhead (a93)	Buy now

Cylinder. Crankcase 1




68D3100-3020

Ref	Part	
19	68D-E2414-A0 Gasket, cover	Buy now
20	97095-06020 Bolt(7u8)	Buy now
21	92995-06600 Washer, plain (646)	Buy now
22	90445-09807 Hose (l180)	Buy now
23	94702-00248 Plug, spark (br6hs)	Buy now

A5


Cylinder. Crankcase 2



A7

Ref	Part	
1	68D-E1311-01-94 Cylinder 1	Buy now
2	650-24378-00 Pipe, joint 2	Buy now
3	6H1-14485-00 Pipe, joint	Buy now
4	90445-07806 Hose (l200)	Buy now
5	93102-25090 Oil seal (25x40x5-256)	Buy now
6	93306-205YD Bearing (6k8)	Buy now
7	68D-E5111-00-94 Crankcase 1	Buy now
9	68D-11351-A0 Gasket, cylinder	Buy now
10	97575-08550 Bolt, with washer	Buy now
11	99510-10114 Pin, dowel(3vd)	Buy now
12	97095-08020 Bolt, hexagon	Buy now
13	92995-08600 Washer, plain (663)	Buy now
14	90201-08818 Washer	Buy now
15	68D-E5396-00-5B Housing, oil seal	Buy now
16	93210-35537 O-ring	Buy now


Cylinder. Crankcase 2



Ref	Part	
17	93102-20108 Oil seal	Buy now
18	93102-10004 Oil seal	Buy now
21	68D-E1168-00 Cover, Breather	Buy now
22	68D-E1169-A0 4-	Buy now
23	90119-06M80 Bolt(gj3)	Buy now
24	68D-E5346-00 Breather 1	Buy now
25	98503-04006 Screw, pan head (7h3)	Buy now
26	68D-E3102-00 Gear unit assembly	Buy now
27	95817-06012 Bolt, flange	Buy now
28	68D-E5362-00 Plug, oil level	Buy now
29	93210-24M79 O-ring	Buy now

A7


Fuel 1



Ref	Part	
1	68D-F4111-00 Tank, Fuel	Buy now
2	67D-24610-02 Cap assembly	Buy now
3	90501-10260 Spring, safety 6152463500	Buy now
4	624-24634-00 Hook, chain ball	Buy now
5	69M-24633-00 Chain, ball	Buy now
6	6H1-21757-00 Washer, special 1	Buy now
7	6L5-24641-00 Gasket, cap 1	Buy now
8	6A0-82317-00 Damper, ignition coil	Buy now
9	624-42542-00 Collar	Buy now
10	90119-06M88 Bolt, with washer	Buy now
11	6L5-24251-00 Strainer 1	Buy now
12	68D-F4311-00 Pipe, Fuel 1	Buy now
13	90467-13M13 Clip(6m6)	Buy now

B5


Fuel 2



B6

Ref	Part	
1	6G1-24304-02 Fuel pipe joint comp. 1	Buy now
2	97095-06025 Bolt	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	68D-F4312-00 9-	Buy now
5	90467-09M09 Clip(6k8)	Buy now
6	68D-F4500-00 Fuel cock assembly 1	Buy now
7	90159-06M10 Screw, with washer(6l5)	Buy now
8	68D-F4313-00 Pipe 3	Buy now
10	90464-10M52 Clamp	Buy now
11	646-24251-02 Strainer 1	Buy now
12	90445-10804 Hose (l400)	Buy now
13	90446-14M12 Hose(6tc)	Buy now
15	67D-24410-02 Fuel pump assembly	Buy now
16	67D-24412-00 Body 1	Buy now
17	67D-24413-02 Body 2	Buy now


Fuel 2



B6

Ref	Part	
18	6A0-24421-01 Valve, check	Buy now
19	6E7-14325-00 Screw, pan head	Buy now
20	67D-24411-00 Diaphragm	Buy now
21	67D-24423-00 Spring, diaphragm	Buy now
22	67D-13131-00 Plunger	Buy now
23	66M-24374-00 Pin	Buy now
24	67D-24454-00 Spring	Buy now
25	67D-24414-01 Body 3	Buy now
26	66M-24471-00 Diaphragm	Buy now
27	67D-24444-00 Screw	Buy now
28	9538004600 Nut,hex	Buy now
29	93210-27ME3 O-ring	Buy now
30	97095-06030 Bolt(jf7)	Buy now
31	92995-06100 Washer(6a1)	Buy now
33	90445-10805 Hose (l400)	Buy now


Fuel 2



Ref	Part	
35	90464-10M53 Clamp	Buy now
37	68D-F8100-00 Tool Kit	Buy now
38	68D-F8199-72-A0 O/m f4a(68d) '03 e, f, s UR (E,F,S)	Buy now
38	68D-F8199-72-B0 O/m f4a(68d) '03 g, d, i UR (D,NL,I)	Buy now
39	68D-F8199-82-A0 O/m f4amh(68d3) '03 d,p,g UR (DK,P,GR)	Buy now
39	68D-F8199-82-B0 O/m f4amh(68d3) '03 n,s,f UR (N,S,SS)	Buy now

B6


Generator



C3

Ref	Part	
1	67D-85650-00 Rotor assembly	Buy now
2	67D-85640-00 T.c.i. unit assembly	Buy now
3	90280-04M06 Key, woodruff(6a1)	Buy now
4	90170-10M33 Nut(6a1)	Buy now
5	90201-105A2 Washer, plate (4x7)	Buy now
6	67D-15723-00 Pulley Starter	Buy now
7	90105-06M24 Bolt (6g1)	Buy now
8	6E3-82370-21 Plug cap assembly	Buy now
9	90480-25161 Grommet(656)	Buy now
10	67D-82575-00 Engine stop switch assembly	Buy now
11	682-82556-00 Lanyard, stop switch	Buy now
12	689-8257Y-00 Cap	Buy now
13	97095-06012 Bolt(gh1)	Buy now
14	92995-06600 Washer, plain (646)	Buy now


Intake



B3

Ref	Part	
1	68D-E4440-00 Silencer assembly, Intake	Buy now
2	93210-31MJ5 O-ring	Buy now
3	90464-13249 Clamp	Buy now
4	97095-06090 Bolt(62y)	Buy now
5	92995-06600 Washer, plain (646)	Buy now
6	90480-18M74 Grommet	Buy now
7	68D-F4314-00 Pipe 4	Buy now
8	90445-07805 Hose (I200)	Buy now
9	68D-E3646-A0 Gasket Int. Manifold	Buy now
10	68D-E3647-00 Gasket, Manifold 3	Buy now
11	68D-E3641-00-94 Manifold, Intake 1	Buy now
12	68D-E3645-A0 Gasket int. manifold	Buy now
13	97095-06025 Bolt	Buy now
15	68D-F6330-00 Wire starter	Buy now
16	90464-05122 Clamp	Buy now


Lower Casing. Drive 1



D4

Ref	Part	
3	6E0-45317-09 Bushing	Buy now
4	6E0-45316-09 Bushing	Buy now
5	93101-10M14 Oil seal	Buy now
6	93306-004YH Bearing (7k2)	Buy now
7	90430-08801 Gasket	Buy now
8	90340-08002 Plug, straight screw	Buy now
9	68D-G5321-00 Plate	Buy now
10	6L2-44147-00 Boot, shift rod	Buy now
11	68D-G5315-A0 Packing, lower cas	Buy now
12	97095-06025 Bolt	Buy now
13	92995-06600 Washer, plain (646)	Buy now
16	93101-13M12 Oil seal	Buy now
17	93210-48214 O-ring	Buy now
18	95895-06016 Bolt, flange deep recess	Buy now
19	68D-G4311-01 Housing water pump	Buy now


Lower Casing. Drive 1



D4

Ref	Part	
20	68D-G4315-A0 Gasket, water pump	Buy now
21	68D-G4322-00 Insert, cartridge	Buy now
22	6E0-44323-00 Outer plate, cartridge	Buy now
23	67D-44366-00 Damper, water seal 2	Buy now
24	6E0-44352-00 Impeller	Buy now
25	93604-09066 Pin, dowel	Buy now
26	97095-06045 Bolt, hexagon	Buy now
27	93604-18080 Pin. dowel. (647)	Buy now
28	68D-G4328-00 Plate	Buy now
29	68D-G5511-00 Shaft, drive S	Buy now
29	68D-G5511-10 Shaft, drive L	Buy now
30	90467-08M01 Clip (6e0)	Buy now
31	6E0-45551-00 Pinion (13t)	Buy now
32	99001-06600 Circlip(53l)	Buy now
33	90201-11M49 Washer, plate (6e0)	Buy now


Lower Casing. Drive 1



D4


Ref	Part	
34	67D-45560-00 Gear	Buy now
35	67D-45570-00 Gear	Buy now
36	67D-45576-00 Washer, thrust 2	Buy now
37	67D-45631-01 Clutch, dog	Buy now
38	90501-10064 Spring, compression 6164563600	Buy now
39	67D-45635-00 Plunger, shift	Buy now
40	68D-G5611-10 Shaft, propeller	Buy now
41	68D-G4150-00 Shift cam assembly S	Buy now
41	68D-G4150-10 Shift cam assembly L	Buy now

Lower Casing. Drive 2



Ref	Part	
1	68D-G4360-00 Water Tube assembly S	Buy now
1	68D-G4360-10 Water tube assembly L	Buy now
2	68D-G5251-00 Anode	Buy now
3	95895-06012 Bolt, flange deep recess	Buy now
4	92990-06300 Washer, tooth	Buy now
5	90119-06M40 Bolt, with washer S	Buy now
6	90387-06806 Collar(6e0)	Buy now
7	68D-G5987-00 Spacer 1	Buy now
8	6L5-45616-00 Nut, propeller	Buy now
9	91490-25030 Pin, cotter(6l5)	Buy now
10	90201-08M54 Washer, plate (6e5)	Buy now
11	6E0-45941-01-EL Propeller (3x7-1/2 x8 -ba) UR	Buy now
11	6E0-45943-01-EL Propeller (3x7-1/2"x7"-ba) UR	Buy now
11	6E0-45949-00-EL Propeller (3x7-1/4 x6-1/2 -ba) UR	Buy now


Repair Kit 1



D7

Ref	Part	
1	68D-WE001-00 Power head gasket kit	Buy now
2	90430-08800 Gasket (256-11198-00)	Buy now
3	67D-11181-A0 Gasket, cylinder head 1	Buy now
4	68D-E1193-A0 Gasket head cover	Buy now
5	93102-25090 Oil seal (25x40x5-256)	Buy now
6	68D-11351-A0 Gasket, cylinder	Buy now
7	90201-08818 Washer	Buy now
8	93210-35537 O-ring	Buy now
9	93102-20108 Oil seal	Buy now
10	93102-10004 Oil seal	Buy now
11	68D-E1169-A0 4-	Buy now
12	68D-E2414-A0 Gasket, cover	Buy now
13	93210-31MJ5 O-ring	Buy now
14	68D-E3646-A0 Gasket Int. Manifold	Buy now
15	68D-E3645-A0 Gasket int. manifold	Buy now


Repair Kit 1



Ref	Part	
16	93210-24M79 O-ring	Buy now
17	68D-G5113-A0 Gasket, upper casing	Buy now
18	93210-27ME3 O-ring	Buy now
19	67D-W0093-01 Carburetor repair kit	Buy now
20	68T-14385-00 Float	Buy now
21	67D-14386-00 Pin, float	Buy now
22	67D-14546-00 Valve, needle	Buy now
23	67D-14984-00 Gasket, float chamber	Buy now
24	6J8-14959-00 Gasket, drin screw	Buy now
25	97980-04112 Screw, pan head (686)	Buy now
26	67D-14536-00 Gasket	Buy now

D7


Repair Kit 2



E1


Ref	Part	
1	6E0-W0001-C1 Lower unit gasket kit	Buy now
2	93101-10M14 Oil seal	Buy now
3	90430-08801 Gasket	Buy now
4	68D-G5315-A0 Packing, lower cas	Buy now
5	68D-G4315-A0 Gasket, water pump	Buy now
6	93101-13M12 Oil seal	Buy now
7	93210-48214 O-ring	Buy now
8	68D-WG078-00 Water Pump Repair Kit	Buy now
9	68D-G4311-01 Housing water pump	Buy now
11	68D-G4322-00 Insert, cartridge	Buy now
12	6E0-44323-00 Outer plate, cartridge	Buy now
13	67D-44366-00 Damper, water seal 2	Buy now
14	6E0-44352-00 Impeller	Buy now
15	97095-06045 Bolt, hexagon	Buy now
16	93604-18080 Pin. dowel. (647)	Buy now

Starter



Ref	Part	
1	67D-15710-00 Starter assembly	Buy now
2	67D-15711-00 Case, Starter	Buy now
3	63V-15795-01 Guide, rope	Buy now
4	67D-15764-00 Collar 1	Buy now
5	67D-15714-00 Drum, sheave	Buy now
6	67D-15741-00 Pawl, drive	Buy now
7	67D-15713-00 Spring, starter	Buy now
8	67D-15705-00 Spring, drive pawl	Buy now
9	67D-15767-00 Spring	Buy now
10	67D-15735-00 Guide, cam	Buy now
11	67D-15793-00 Screw	Buy now
12	63V-15764-00 Collar 1	Buy now
13	67D-15794-00 Stopper	Buy now
14	67D-15734-00 Spring, return	Buy now
15	* item_description	Buy now


Starter



C1

Ref	Part	
16	6G1-15755-00 Handle, starter	Buy now
17	6G1-15779-00 Cover	Buy now
18	67D-15739-00 Washer, thrust	Buy now
19	67D-15762-00 Seal Rubber 2	Buy now
20	97095-06035 Bolt(j52)	Buy now
21	92995-06600 Washer, plain (646)	Buy now
22	97095-06020 Bolt(7u8)	Buy now
24	67D-15772-00 Stay 2	Buy now
25	67D-15770-00 Cable comp., starter stop	Buy now
26	67D-42791-10 Mark 1	Buy now
27	6A1-83625-41 Mark 5	Buy now
28	6A1-83625-51 Mark 5	Buy now
29	68D-13437-60 Mark, Caution	Buy now
30	67D-14427-60 Label, Instruction	Buy now


Steering



C5

Ref	Part	
1	68D-G2111-00-4D Handle, Steering	Buy now
2	67D-42129-00 Bushing, rubber	Buy now
3	68D-G2171-00 Bushing, 1	Buy now
4	68D-G2172-00 Bushing, 2	Buy now
5	68D-G2181-00 Washer, 1	Buy now
6	69M-G2188-00 Washer, wave	Buy now
7	68D-G2182-00 Washer, 2	Buy now
8	68D-G2131-01 Cover, Handle Steering	Buy now
9	97075-08025 Bolt, hexagon deep recess	Buy now
10	6G1-42125-01 Bolt, friction adjusting	Buy now
11	6N0-G2126-00 Piece, friction	Buy now
12	91490-16010 Pin, cotter	Buy now
13	68D-G2119-00 Grip, steering han	Buy now
14	68D-G2137-00 Indicator Throttle	Buy now
15	90269-02M09 Rivet(6I5)	Buy now


Steering



C5

Ref	Part	
16	67D-42177-00 Rubber, handle	Buy now
17	90149-05M13 Screw, countersunk	Buy now
18	92903-10600 Washer, plate	Buy now
19	90501-23215 Spring (655)	Buy now
20	90386-08032 Bushing (650)	Buy now
21	69M-G2138-00 Lever, throttle	Buy now
22	68D-G2159-00 Stay	Buy now
23	97885-05012 Screw, pan head (646)	Buy now
24	68D-F6301-00 Throttle cable	Buy now
25	6E0-83627-41 Label, caution 7	Buy now
26	6E0-83627-51 Label, Caution 7	Buy now
27	6A1-2415A-41 Label, caution	Buy now
28	6A1-2415A-51 Label Caution	Buy now
29	68D-E571Y-60 13 –	Buy now
30	6N0-F8176-00 Caution Sticker	Buy now


Top Cowling



Ref	Part	
2	68D-G2613-01 Molding,air duct	Buy now
3	97780-40012 Screw, trushead tapping (ge31)	Buy now
4	68D-WG070-00 Graphic set	Buy now
5	68D-G2677-00 Graphic, Front	Buy now
6	68D-G2678-00 Graphic Rear	Buy now
7	68D-42662-00 Damper	Buy now
8	67F-13434-02 Label, Caution	Buy now

A4


Upper Casing



Ref	Part	
2	68D-G5113-A0 Gasket, upper casing	Buy now
10	90387-06806 Collar(6e0) L	Buy now
4	97095-06035 Bolt(j52)	Buy now
5	92995-06600 Washer, plain (646)	Buy now
6	93700-06M03 Nipple, grease(6a1)	Buy now
7	647-45151-01 Cover, upper casing	Buy now
8	90480-10M13 Grommet (6e0)	Buy now
11	90119-06M77 Bolt, with washer L	Buy now
12	6E0-45318-01 Bushing, drive shaft 3 L	Buy now
13	93420-22M03 Cir clip (6e0) L	Buy now

D3

Valve



B2

Ref	Part	
1	68D-E2170-00 Cam shaft assembly	Buy now
2	67D-12111-00 Valve, intake	Buy now
3	67D-12121-00 Valve, exhaust	Buy now
4	51Y-12119-00 Seal, valve stem	Buy now
5	68T-12116-00 Seat, valve spring	Buy now
6	68D-E2113-00 Spring, valve inne	Buy now
7	7NJ-12117-00 Retainer, valve spring	Buy now
8	7NJ-12118-00 Cotter, valve	Buy now
9	67D-12151-00 Arm, valve rocker	Buy now
10	7FK-12165-00 Pivot, rocker arm	Buy now
11	7FK-12158-00 Nut, lock	Buy now
12	67D-12157-00 Bolt	Buy now
13	68D-E2155-00 Guide, Push Rod	Buy now
14	67D-12154-00 Rod, valve push	Buy now
15	JA9-12153-00 Lifter, valve	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.