



# Yamaha F5AMH 2011

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>BOTTOM COWLING</b>	3
<b>BRACKET</b>	4
<b>CARBURETOR</b>	7
<b>CONTROL</b>	9
<b>CRANKSHAFT &amp; PISTON</b>	11
<b>CYLINDER &amp; CRANKCASE 1</b>	12
<b>CYLINDER &amp; CRANKCASE 2</b>	14
<b>ELECTRICAL</b>	17
<b>FUEL 1</b>	18
<b>FUEL 2</b>	19
<b>GENERATOR</b>	23
<b>INTAKE</b>	24
<b>LOWER CASING &amp; DRIVE 1</b>	26
<b>LOWER CASING &amp; DRIVE 2</b>	29
<b>OPTIONAL PARTS</b>	31
<b>REPAIR KIT 1</b>	32
<b>REPAIR KIT 2</b>	34
<b>REPAIR KIT 3</b>	35
<b>STARTER</b>	36
<b>STEERING</b>	39
<b>TOP COWLING</b>	42
<b>UPPER CASING</b>	44
<b>VALVE</b>	45

## Bottom Cowling



Ref	Part	
1	<a href="#">6BXG2711004D</a> Cowling, bottom 1	<a href="#">Buy now</a>
2	<a href="#">68F8511900</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">9048021M82</a> Grommet	<a href="#">Buy now</a>
4	<a href="#">9038706176</a> Collar	<a href="#">Buy now</a>
5	<a href="#">9048014M14</a> Grommet (6e0)	<a href="#">Buy now</a>
6	<a href="#">68T4280100</a> Cowling clamp comp.	<a href="#">Buy now</a>
7	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
8	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">6BXG273100</a> Carrying handle	<a href="#">Buy now</a>
10	<a href="#">9709508020</a> Bolt, hexagon	<a href="#">Buy now</a>
11	<a href="#">9299508600</a> Washer, plain (663)	<a href="#">Buy now</a>
12	<a href="#">9538008600</a> Nut (661)	<a href="#">Buy now</a>
13	<a href="#">9048022M72</a> Grommet	<a href="#">Buy now</a>
14	<a href="#">6AH4279450</a> Label, warning (ge)	<a href="#">Buy now</a>


# Bracket



6BV1110-J160

Ref	Part	
1	<a href="#">6L8G3111014D</a> Bracket, clamp 1	<a href="#">Buy now</a>
2	<a href="#">6L8G3112004D</a> Bracket, clamp 2	<a href="#">Buy now</a>
3	<a href="#">6204311400</a> Pad, transom clamp	<a href="#">Buy now</a>
4	<a href="#">6E04311601</a> Screw, transom clamp	<a href="#">Buy now</a>
5	<a href="#">6L8G311801</a> Handle, transom cl	<a href="#">Buy now</a>
6	<a href="#">9024304M01</a> Pin(6a1)	<a href="#">Buy now</a>
7	<a href="#">9010108M07</a> Bolt(6e0)	<a href="#">Buy now</a>
8	<a href="#">9020208M58</a> Washer, plate	<a href="#">Buy now</a>
9	<a href="#">68DG311300</a> Plate, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">9018508057</a> Nut, nylon (6j8)	<a href="#">Buy now</a>
11	<a href="#">9038706M11</a> Collar	<a href="#">Buy now</a>
12	<a href="#">9010106335</a> Bolt, hexagon (624)	<a href="#">Buy now</a>
13	<a href="#">9299006600</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
15	<a href="#">68DG3311014D</a> Bracket, swivel 1	<a href="#">Buy now</a>


# Bracket



6BV1110-J160

Ref	Part	
16	<a href="#">68DG3312014D</a> Bracket, swivel 2	<a href="#">Buy now</a>
17	<a href="#">9589506035</a> Bolt, flange(4nx)	<a href="#">Buy now</a>
18	<a href="#">6BX4318100</a> Lever, tilt stop 1	<a href="#">Buy now</a>
19	<a href="#">6E04363200</a> Knob, tilt	<a href="#">Buy now</a>
20	<a href="#">6E0433130094</a> Bracket, swivel 3	<a href="#">Buy now</a>
21	<a href="#">6204318900</a> Bushing	<a href="#">Buy now</a>
22	<a href="#">9589506020</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
23	<a href="#">6BX4856100</a> Spring 1	<a href="#">Buy now</a>
24	<a href="#">6BXG331900</a> Plate	<a href="#">Buy now</a>
25	<a href="#">68DG316000</a> Tilt rod assembly	<a href="#">Buy now</a>
26	<a href="#">6N0G316500</a> Plate, tilt lock	<a href="#">Buy now</a>
27	<a href="#">9169030008</a> Pin. spring(656)	<a href="#">Buy now</a>
28	<a href="#">9050208M05</a> Spring, conical(6e0)	<a href="#">Buy now</a>
29	<a href="#">6BX4361400</a> Plate, tilt lock	<a href="#">Buy now</a>
30	<a href="#">6BX4318800</a> Spring	<a href="#">Buy now</a>


# Bracket



6BV1110-J160


Ref	Part	
31	<a href="#">6BX4319800</a> Spring 2	<a href="#">Buy now</a>
32	<a href="#">9010906M84</a> Bolt	<a href="#">Buy now</a>
33	<a href="#">68DG253700</a> Bushing, pivot sha	<a href="#">Buy now</a>
34	<a href="#">68DG253900</a> Bushing, pivot sha	<a href="#">Buy now</a>
35	<a href="#">6BXG253800</a> Bushing, pivot sha	<a href="#">Buy now</a>
36	<a href="#">6BXG254900</a> Bushing, pivot sha	<a href="#">Buy now</a>
37	<a href="#">6E04252803</a> Plate, friction	<a href="#">Buy now</a>
38	<a href="#">6L54252901</a> Screw, friction piece	<a href="#">Buy now</a>
39	<a href="#">68DG256101</a> Knob, steering loc	<a href="#">Buy now</a>
40	<a href="#">9026604M05</a> Rivet(6l5)	<a href="#">Buy now</a>
41	<a href="#">6BXF459100</a> Emblem, fuel cock	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
1	<a href="#">6BV1430101</a> Carburetor assembly 1	<a href="#">Buy now</a>
1	<a href="#">6BW1430101</a> Carburetor assembly 1	<a href="#">Buy now</a>
1	<a href="#">6BX1430100</a> Carburetor assembly 1	<a href="#">Buy now</a>
2	<a href="#">6BX1498500</a> Float	<a href="#">Buy now</a>
3	<a href="#">6BX1498000</a> Body, float chamber	<a href="#">Buy now</a>
4	<a href="#">6BX1498400</a> Gasket, float chamber	<a href="#">Buy now</a>
5	<a href="#">6BV1494700</a> Jet, needle	<a href="#">Buy now</a>
5	<a href="#">6BW1494700</a> Jet, needle	<a href="#">Buy now</a>
5	<a href="#">6BX1494700</a> Jet, needle	<a href="#">Buy now</a>
6	<a href="#">6BW1492320</a> Screw, pilot	<a href="#">Buy now</a>
6	<a href="#">6BX1492320</a> Screw, pilot	<a href="#">Buy now</a>
7	<a href="#">6BX1452300</a> Screw, stop	<a href="#">Buy now</a>
8	<a href="#">6BX1455500</a> Spring	<a href="#">Buy now</a>
9	<a href="#">6BX1493500</a> Spring	<a href="#">Buy now</a>
10	<a href="#">6BX1499100</a> Screw	<a href="#">Buy now</a>

# Carburetor




Ref	Part	
11	<a href="#">6BX1459200</a> Screw	<a href="#">Buy now</a>
12	<a href="#">4JH1456200</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">6BX1454600</a> Valve, needle	<a href="#">Buy now</a>
14	<a href="#">6BX1454800</a> Pin, float arm	<a href="#">Buy now</a>
15	<a href="#">6BX1493700</a> Clip	<a href="#">Buy now</a>
16	<a href="#">6BV1494311</a> Jet, main (#60)	<a href="#">Buy now</a>
16	<a href="#">6BW1494315</a> Jet, main (#70)	<a href="#">Buy now</a>
16	<a href="#">6BX1494317</a> Jet, main (#75)	<a href="#">Buy now</a>
17	<a href="#">6BV1494801</a> Jet (#35)	<a href="#">Buy now</a>
17	<a href="#">6BX1494804</a> Jet (#42)	<a href="#">Buy now</a>
18	<a href="#">6BX1455600</a> Spring	<a href="#">Buy now</a>
19	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>

# Control




Ref	Part	
1	<a href="#">6BXG411100</a> Handle, gear shift	<a href="#">Buy now</a>
2	<a href="#">6BXG367900</a> Cover	<a href="#">Buy now</a>
3	<a href="#">9010508046</a> Bolt, flange	<a href="#">Buy now</a>
4	<a href="#">6BXG411900CA</a> Shaft, change	<a href="#">Buy now</a>
5	<a href="#">6BXG412200</a> Bushing, shift rod lever	<a href="#">Buy now</a>
6	<a href="#">9321009350</a> O-ring	<a href="#">Buy now</a>
7	<a href="#">9050112802</a> Spring, compression	<a href="#">Buy now</a>
8	<a href="#">9350516024</a> Ball	<a href="#">Buy now</a>
9	<a href="#">6BXG412100</a> Lever, shift rod	<a href="#">Buy now</a>
10	<a href="#">9038706504</a> Collar(650)	<a href="#">Buy now</a>
11	<a href="#">9011905M04</a> Bolt, with washer	<a href="#">Buy now</a>
12	<a href="#">6BX4414300</a> Rod, shift	<a href="#">Buy now</a>
13	<a href="#">9299005600</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">9149016010</a> Pin, cotter	<a href="#">Buy now</a>
15	<a href="#">68DG414500</a> Connector, shift rod 1	<a href="#">Buy now</a>

## Control



Ref	Part	
16	<a href="#">68DG414600</a> Connector, shift rod 2	<a href="#">Buy now</a>
17	<a href="#">9011906256</a> Bolt, with washer	<a href="#">Buy now</a>


## Crankshaft & Piston



6BV1100-J030


Ref	Part	
1	<a href="#">6BXE141000</a> Crankshaft	<a href="#">Buy now</a>
2	<a href="#">90201266P2</a> Washer, plate(ja8)	<a href="#">Buy now</a>
3	<a href="#">6BX1165000</a> Connecting rod ass	<a href="#">Buy now</a>
4	<a href="#">67D1165400</a> Bolt, connecting rod	<a href="#">Buy now</a>
5	<a href="#">6BXE16310096</a> Piston (std)	<a href="#">Buy now</a>
5	<a href="#">6BXE163500</a> Pisron (0,25mm o/s) AP	<a href="#">Buy now</a>
5	<a href="#">6BXE163600</a> Piston (0.50mm o/s) AP	<a href="#">Buy now</a>
6	<a href="#">6BXE160300</a> Piston ring set (s)	<a href="#">Buy now</a>
6	<a href="#">6BXE160400</a> Piston ring set (0,25mm) AP	<a href="#">Buy now</a>
6	<a href="#">6BXE160500</a> Piston Ring Set (0 50Mm) AP	<a href="#">Buy now</a>
7	<a href="#">6BX1163300</a> Pin, piston	<a href="#">Buy now</a>
8	<a href="#">9345016068</a> Circlip (4g0)	<a href="#">Buy now</a>

# Cylinder & Crankcase 1




Ref	Part	
1	<a href="#">6BXWE090001S</a> Crank cylinder ass	<a href="#">Buy now</a>
2	<a href="#">6BXE1111001S</a> Head, cylinder with ex valve	<a href="#">Buy now</a>
3	<a href="#">67D1113310</a> Guide, valve 1	<a href="#">Buy now</a>
4	<a href="#">9010508M36</a> Bolt (6g8)	<a href="#">Buy now</a>
5	<a href="#">9951010114</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
6	<a href="#">6BX1118100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
7	<a href="#">6BXE1191005B</a> Cover, cylinder he	<a href="#">Buy now</a>
8	<a href="#">6BX1135600</a> Seal, cylinder 2	<a href="#">Buy now</a>
9	<a href="#">9709506020</a> Bolt(7u8)	<a href="#">Buy now</a>
10	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">66M1241101</a> Thermostat	<a href="#">Buy now</a>
12	<a href="#">6881241200</a> Seal, thermostat	<a href="#">Buy now</a>
13	<a href="#">68DE2413001S</a> Cover, thermostat	<a href="#">Buy now</a>
14	<a href="#">6502437800</a> Pipe, joint 2	<a href="#">Buy now</a>
15	<a href="#">68DE132500</a> Anode	<a href="#">Buy now</a>

# Cylinder & Crankcase 1




Ref	Part	
16	<a href="#">9788005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
17	<a href="#">68DE2414A0</a> Gasket, cover	<a href="#">Buy now</a>
20	<a href="#">6BXF432300</a> Pipe 12	<a href="#">Buy now</a>
21	<a href="#">9046409021</a> Clamp	<a href="#">Buy now</a>
22	<a href="#">9046506M86</a> Clamp	<a href="#">Buy now</a>
24	<a href="#">9046508371</a> Clamp(4km)	<a href="#">Buy now</a>
25	<a href="#">6G08251900</a> Wire, earth lead	<a href="#">Buy now</a>
26	<a href="#">9470200372</a> Plug, spark (cr6hsb)	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
1	<a href="#">6BXE1311001S</a> Cylinder 1	<a href="#">Buy now</a>
2	<a href="#">6E92437800</a> Pipe, joint 4	<a href="#">Buy now</a>
3	<a href="#">3Y61536100</a> Gauge, level	<a href="#">Buy now</a>
4	<a href="#">9310225022</a> Oil seal	<a href="#">Buy now</a>
5	<a href="#">93306205B2</a> Bearing	<a href="#">Buy now</a>
6	<a href="#">6BXE116800</a> Cover, breather	<a href="#">Buy now</a>
7	<a href="#">9701305010</a> Bolt, hexagon	<a href="#">Buy now</a>
8	<a href="#">6BX1135100</a> Gasket, cylinder	<a href="#">Buy now</a>
9	<a href="#">9951010114</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
10	<a href="#">6BXE5111001S</a> Crankcase 1	<a href="#">Buy now</a>
11	<a href="#">6502437800</a> Pipe, joint 2	<a href="#">Buy now</a>
12	<a href="#">6761137200</a> Nipple, hose	<a href="#">Buy now</a>
13	<a href="#">9701306050</a> Bolt, hexagon	<a href="#">Buy now</a>
14	<a href="#">9290306600</a> Washer, plain (646)	<a href="#">Buy now</a>
15	<a href="#">68DE5396005B</a> Housing, oil seal	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




## Cylinder & Crankcase 2




Ref	Part	
33	<a href="#">9020108818</a> Washer	<a href="#">Buy now</a>
34	<a href="#">9709506035</a> Bolt(j52)	<a href="#">Buy now</a>
35	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
36	<a href="#">9321024M79</a> O-ring	<a href="#">Buy now</a>
37	<a href="#">68DE536200</a> Plug, oil level	<a href="#">Buy now</a>

## Electrical




Ref	Part	
1	<a href="#">6BX8257500</a> Engine stop switch	<a href="#">Buy now</a>
2	<a href="#">6828255600</a> Lanyard, stop switch	<a href="#">Buy now</a>
3	<a href="#">6898257Y00</a> Cap	<a href="#">Buy now</a>
4	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
5	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">6BX8253100</a> Wire, lead	<a href="#">Buy now</a>
7	<a href="#">9046513M97</a> Clamp	<a href="#">Buy now</a>

# Fuel 1




Ref	Part	
1	<a href="#">6BXF411100</a> Tank, fuel	<a href="#">Buy now</a>
2	<a href="#">6BX2461000</a> Cap assembly	<a href="#">Buy now</a>
3	<a href="#">6BX2464100</a> Gasket, cap 1	<a href="#">Buy now</a>
4	<a href="#">6A08231700</a> Damper, ignition coil	<a href="#">Buy now</a>
5	<a href="#">9038706119</a> Collar	<a href="#">Buy now</a>
6	<a href="#">9048001559</a> Grommet(4bh)	<a href="#">Buy now</a>
7	<a href="#">6BX2416700</a> Strainer	<a href="#">Buy now</a>
8	<a href="#">6BXF431100</a> Pipe, fuel 1	<a href="#">Buy now</a>
9	<a href="#">9046709M09</a> Clip(6k8)	<a href="#">Buy now</a>

Fuel 2




Ref	Part	
1	<a href="#">6G12430402</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">60RF432900</a> Seal	<a href="#">Buy now</a>
3	<a href="#">9709506025</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">6BX2476U00</a> Protector,1	<a href="#">Buy now</a>
6	<a href="#">6BXF431200</a> Pipe 2	<a href="#">Buy now</a>
7	<a href="#">9046709M09</a> Clip(6k8)	<a href="#">Buy now</a>
8	<a href="#">6BX2450000</a> Fuel cock assembly 1	<a href="#">Buy now</a>
9	<a href="#">9015906M10</a> Screw, with washer(6l5)	<a href="#">Buy now</a>
10	<a href="#">6BXF431300</a> Pipe 3	<a href="#">Buy now</a>
12	<a href="#">9046412224</a> Clamp(4pe)	<a href="#">Buy now</a>
13	<a href="#">68T2425101</a> Strainer 1	<a href="#">Buy now</a>
14	<a href="#">6BXF247C00</a> Hose 3	<a href="#">Buy now</a>
16	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
17	<a href="#">6882437800</a> Pipe, joint	<a href="#">Buy now</a>

## Fuel 2




Ref	Part	
18	<a href="#">6BXF247D00</a> Hose 4	<a href="#">Buy now</a>
21	<a href="#">6BX2441000</a> Fuel pump assembly	<a href="#">Buy now</a>
22	<a href="#">67D2441200</a> Body 1	<a href="#">Buy now</a>
23	<a href="#">67D2441302</a> Body 2	<a href="#">Buy now</a>
24	<a href="#">6A02442101</a> Valve, check	<a href="#">Buy now</a>
25	<a href="#">6E71432500</a> Screw, pan head	<a href="#">Buy now</a>
26	<a href="#">6BX2441100</a> Diaphragm	<a href="#">Buy now</a>
27	<a href="#">67D2442300</a> Spring, diaphragm	<a href="#">Buy now</a>
28	<a href="#">6BX1313100</a> Plunger	<a href="#">Buy now</a>
29	<a href="#">66M2437400</a> Pin	<a href="#">Buy now</a>
30	<a href="#">6BX2445400</a> Spring	<a href="#">Buy now</a>
31	<a href="#">67D2441401</a> Body 3	<a href="#">Buy now</a>
32	<a href="#">66M2447101</a> Diaphragm	<a href="#">Buy now</a>
33	<a href="#">67D2444400</a> Screw	<a href="#">Buy now</a>
34	<a href="#">9538004600</a> Nut,hex	<a href="#">Buy now</a>

## Fuel 2




Ref	Part	
35	<a href="#">9321027ME3</a> O-ring	<a href="#">Buy now</a>
36	<a href="#">9709506030</a> Bolt(jf7)	<a href="#">Buy now</a>
37	<a href="#">9299506100</a> Washer(6a1)	<a href="#">Buy now</a>
39	<a href="#">6BXF247B00</a> Hose 2	<a href="#">Buy now</a>
41	<a href="#">6BX2436000</a> Primer pump assembly	<a href="#">Buy now</a>
42	<a href="#">6BX2413500</a> Clamp 1	<a href="#">Buy now</a>
43	<a href="#">6BX2413600</a> Clamp 2	<a href="#">Buy now</a>
44	<a href="#">9010906M80</a> Bolt	<a href="#">Buy now</a>
45	<a href="#">6BXF247A00</a> Hose 1	<a href="#">Buy now</a>
46	<a href="#">9046409021</a> Clamp	<a href="#">Buy now</a>
49	<a href="#">6BXE397100</a> Pipe, fuel 1	<a href="#">Buy now</a>
51	<a href="#">6BXF810000</a> Tool kit AP	<a href="#">Buy now</a>
52	<a href="#">6BVF819971E0</a> Om f4b/f5a/f6c'11 UR (E)	<a href="#">Buy now</a>
52	<a href="#">6BVF819971F0</a> Om f4b/f5a/f6c'11 UR (F)	<a href="#">Buy now</a>
52	<a href="#">6BVF819971S0</a> Om f4b/f5a/f6c'11 UR (ES)	<a href="#">Buy now</a>

## Fuel 2



Ref	Part	
52	<a href="#">6BVF819971D0</a> Om f4b/f5a/f6c"11 UR (NL)	<a href="#">Buy now</a>
52	<a href="#">6BVF819971G0</a> Om f4b/f5a/f6c"11 UR (D)	<a href="#">Buy now</a>
52	<a href="#">6BVF819971H0</a> Om f4b/f5a/f6c"11 UR (I)	<a href="#">Buy now</a>
53	<a href="#">6BVF819981K0</a> Om f4b/f5a/f6c"11 UR (DK)	<a href="#">Buy now</a>
53	<a href="#">6BVF819981L0</a> Om f4b/f5a/f6c"11 UR (SF)	<a href="#">Buy now</a>
53	<a href="#">6BVF819981M0</a> Om f4b/f5a/f6c"11 UR (S)	<a href="#">Buy now</a>
53	<a href="#">6BVF819981N0</a> Om f4b/f5a/f6c"11 UR (N)	<a href="#">Buy now</a>
53	<a href="#">6BVF819981P0</a> Om f4b/f5a/f6c"11 UR (P)	<a href="#">Buy now</a>
53	<a href="#">6BVF819981R0</a> Om f4b/f5a/f6c"11 UR (GR)	<a href="#">Buy now</a>


# Generator



6BV1100-J110


Ref	Part	
1	<a href="#">6BX8555000</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">6BV8557101</a> Ignition coil with cdi unit	<a href="#">Buy now</a>
2	<a href="#">6BW8557101</a> Ignition coil with cdi unit	<a href="#">Buy now</a>
2	<a href="#">6BX8557100</a> Ignition coil with cdi unit	<a href="#">Buy now</a>
3	<a href="#">9028004M06</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
4	<a href="#">9017012066</a> Nut, hexagon 6481155500	<a href="#">Buy now</a>
5	<a href="#">9020112472</a> Washer, plate (4n0)	<a href="#">Buy now</a>
6	<a href="#">6BX1572300</a> Pulley, starter	<a href="#">Buy now</a>
7	<a href="#">9010506037</a> Bolt, flange	<a href="#">Buy now</a>
8	<a href="#">6BX8237000</a> Plug cap assembly	<a href="#">Buy now</a>
9	<a href="#">9048025161</a> Grommet(656)	<a href="#">Buy now</a>
10	<a href="#">9046508361</a> Clamp(7mx)	<a href="#">Buy now</a>
11	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
12	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>

# Intake




Ref	Part	
1	<a href="#">6BX1444000</a> Silencer assembly, intake	<a href="#">Buy now</a>
2	<a href="#">9048018M74</a> Grommet	<a href="#">Buy now</a>
3	<a href="#">93210320A7</a> O-ring	<a href="#">Buy now</a>
4	<a href="#">6BXF431400</a> Pipe 4	<a href="#">Buy now</a>
5	<a href="#">6BXE316F00</a> Hose, oil 1	<a href="#">Buy now</a>
6	<a href="#">9046709M09</a> Clip(6k8)	<a href="#">Buy now</a>
7	<a href="#">6BXE364700</a> Gasket, manifold 3	<a href="#">Buy now</a>
8	<a href="#">6BXE364600</a> Gasket, manifold 2	<a href="#">Buy now</a>
9	<a href="#">9011006350</a> Bolt, hexagon socket head	<a href="#">Buy now</a>
10	<a href="#">9020106106</a> Washer, plate	<a href="#">Buy now</a>
11	<a href="#">6BXE36411094</a> Manifold, intake 1	<a href="#">Buy now</a>
12	<a href="#">6BXE364500</a> Gasket, manifold 1	<a href="#">Buy now</a>
13	<a href="#">9757506525</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
14	<a href="#">6BXF633001</a> Starter cable assembly	<a href="#">Buy now</a>
15	<a href="#">6BXF633300</a> Nut	<a href="#">Buy now</a>

## Intake




Ref	Part	
16	<a href="#">6BXE315100</a> Stay	<a href="#">Buy now</a>
17	<a href="#">9709505010</a> Bolt (682)	<a href="#">Buy now</a>
18	<a href="#">9299505600</a> Washer, plain (646)	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
1	<a href="#">6BXG5300004D</a> Lower unit assembly S(17.1")	<a href="#">Buy now</a>
1	<a href="#">6BXG5300104D</a> Lower unit assembly L(22.1")	<a href="#">Buy now</a>
2	<a href="#">68DG5311004D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">6E04531709</a> Bushing	<a href="#">Buy now</a>
4	<a href="#">6E04531609</a> Bushing	<a href="#">Buy now</a>
5	<a href="#">9310110M14</a> Oil seal	<a href="#">Buy now</a>
6	<a href="#">93306004YH</a> Bearing (7k2)	<a href="#">Buy now</a>
7	<a href="#">9043008020</a> Gasket	<a href="#">Buy now</a>
8	<a href="#">9034008002</a> Plug, straight screw	<a href="#">Buy now</a>
9	<a href="#">68DG532100</a> Plate	<a href="#">Buy now</a>
10	<a href="#">6L24414700</a> Boot, shift rod	<a href="#">Buy now</a>
11	<a href="#">68DG5315A0</a> Packing, lower cas	<a href="#">Buy now</a>
12	<a href="#">9709506025</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">68DG5361004D</a> Cap, lower casing	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
16	<a href="#">9310113M12</a> Oil seal	<a href="#">Buy now</a>
17	<a href="#">9321048214</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">9589506016</a> Bolt, flange deep recess	<a href="#">Buy now</a>
19	<a href="#">6BX4431100</a> Housing, water pump	<a href="#">Buy now</a>
20	<a href="#">6BXG431501</a> Gasket, water pump	<a href="#">Buy now</a>
21	<a href="#">6BX4432200</a> Insert, cartridge	<a href="#">Buy now</a>
22	<a href="#">6BX4432300</a> Outer plate, cartridge	<a href="#">Buy now</a>
23	<a href="#">67D4436600</a> Damper, water seal 2	<a href="#">Buy now</a>
24	<a href="#">6E04435200</a> Impeller	<a href="#">Buy now</a>
25	<a href="#">9360409066</a> Pin, dowel	<a href="#">Buy now</a>
26	<a href="#">9709506045</a> Bolt, hexagon	<a href="#">Buy now</a>
27	<a href="#">9360418080</a> Pin, dowel. (647)	<a href="#">Buy now</a>
28	<a href="#">68DG432800</a> Plate	<a href="#">Buy now</a>
29	<a href="#">68DG551100</a> Shaft, drive S(17.1")	<a href="#">Buy now</a>
29	<a href="#">68DG551110</a> Shaft, drive L(22.1")	<a href="#">Buy now</a>

# Lower Casing & Drive 1




Ref	Part	
30	<a href="#">9046708M01</a> Clip (6e0)	<a href="#">Buy now</a>
31	<a href="#">6BX4555100</a> Pinion	<a href="#">Buy now</a>
32	<a href="#">9900106600</a> Circlip(53l)	<a href="#">Buy now</a>
33	<a href="#">9020111M49</a> Washer, plate (6e0)	<a href="#">Buy now</a>
34	<a href="#">67D4556000</a> Gear	<a href="#">Buy now</a>
35	<a href="#">67D4557000</a> Gear	<a href="#">Buy now</a>
36	<a href="#">67D4557600</a> Washer, thrust 2	<a href="#">Buy now</a>
37	<a href="#">67D4563101</a> Clutch, dog	<a href="#">Buy now</a>
38	<a href="#">90501120A9</a> Spring, compression	<a href="#">Buy now</a>
39	<a href="#">67D4563500</a> Plunger, shift	<a href="#">Buy now</a>
40	<a href="#">68DG561110</a> Shaft, propeller	<a href="#">Buy now</a>
41	<a href="#">6BXG415000</a> Shift cam assembly <b>S(17.1")</b>	<a href="#">Buy now</a>
41	<a href="#">6BXG415010</a> Shift cam assembly <b>L(22.1")</b>	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
1	<a href="#">6BXG436000</a> Water tube assembly <b>S(17.1")</b>	<a href="#">Buy now</a>
1	<a href="#">6BXG436010</a> Water tube assembly <b>L(22.1")</b>	<a href="#">Buy now</a>
2	<a href="#">68DG525100</a> Anode	<a href="#">Buy now</a>
3	<a href="#">9589506012</a> Bolt, flange deep recess	<a href="#">Buy now</a>
4	<a href="#">9299006300</a> Washer, tooth	<a href="#">Buy now</a>
5	<a href="#">9011906253</a> Bolt, with washer <b>S(17.1")</b>	<a href="#">Buy now</a>
5	<a href="#">9011906254</a> Bolt, with washer <b>L(22.1")</b>	<a href="#">Buy now</a>
13	<a href="#">9038706806</a> Collar(6e0) <b>L(22.1")</b>	<a href="#">Buy now</a>
7	<a href="#">68DG598700</a> Spacer 1	<a href="#">Buy now</a>
8	<a href="#">6L54561600</a> Nut, propeller	<a href="#">Buy now</a>
9	<a href="#">9149025030</a> Pin, cotter(6l5)	<a href="#">Buy now</a>
10	<a href="#">9020108M54</a> Washer, plate (6e5)	<a href="#">Buy now</a>
11	<a href="#">6E04594101EL</a> Propeller (3x7-1/2 x8 -ba) <b>UR</b>	<a href="#">Buy now</a>
11	<a href="#">6E04594301EL</a> Propeller (3x7-1/2"x7"-ba) <b>UR</b>	<a href="#">Buy now</a>
11	<a href="#">6E04594900EL</a> Propeller (3x7-1/4 x6-1/2 -ba) <b>UR</b>	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
11	<a href="#">6E04595200EL</a> Propeller (3x7-1/4 x8-1/4 -ba) UR	<a href="#">Buy now</a>
11	<a href="#">6E04595400</a> Propeller (3x7-1/2 x9 -ba) AP	<a href="#">Buy now</a>
12	<a href="#">6BXG5211004D</a> Extension L(22.1")	<a href="#">Buy now</a>
14	<a href="#">6BX4531801</a> Bushing, drive shaft L(22.1")	<a href="#">Buy now</a>
15	<a href="#">9342022M03</a> Cir clip (6e0) L(22.1")	<a href="#">Buy now</a>

## Optional Parts




Ref	Part	
1	<a href="#">6BX85550A0</a> Rotor assembly <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
2	<a href="#">6BX85510A0</a> Lighting coil assembly <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
3	<a href="#">9759506520</a> Bolt(7u8) <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
4	<a href="#">6BX8196000</a> Rectifier & regulator assembly <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
5	<a href="#">9759506516</a> Bolt, with washer(6r6) <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
6	<a href="#">6BX8194900</a> Wire, lead <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
7	<a href="#">67F8215B00</a> Cap (black)	<a href="#">Buy now</a>
8	<a href="#">67F8215100</a> Fuse	<a href="#">Buy now</a>
9	<a href="#">9046430009</a> Clamp <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
10	<a href="#">6BX8258100</a> Stay, cord clamp <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
11	<a href="#">6BX8238800</a> Plate <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
12	<a href="#">9010906M80</a> Bolt <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>
13	<a href="#">9046508371</a> Clamp(4km) <b>AP EXCEPT FOR RUS</b>	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
1	<a href="#">6BXWE00100</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">6BX1118100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
3	<a href="#">6BX1135600</a> Seal, cylinder 2	<a href="#">Buy now</a>
4	<a href="#">9310225022</a> Oil seal	<a href="#">Buy now</a>
5	<a href="#">6BX1135100</a> Gasket, cylinder	<a href="#">Buy now</a>
6	<a href="#">9321035537</a> O-ring	<a href="#">Buy now</a>
7	<a href="#">9310220108</a> Oil seal	<a href="#">Buy now</a>
8	<a href="#">9310210004</a> Oil seal	<a href="#">Buy now</a>
9	<a href="#">9043008800</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
10	<a href="#">68DE2414A0</a> Gasket, cover	<a href="#">Buy now</a>
11	<a href="#">93210320A7</a> O-ring	<a href="#">Buy now</a>
12	<a href="#">6BXE364700</a> Gasket, manifold 3	<a href="#">Buy now</a>
13	<a href="#">6BXE364600</a> Gasket, manifold 2	<a href="#">Buy now</a>
14	<a href="#">6BXE364500</a> Gasket, manifold 1	<a href="#">Buy now</a>
15	<a href="#">6BXE347500</a> Gasket	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
16	<a href="#">9321024M79</a> O-ring	<a href="#">Buy now</a>
17	<a href="#">9321027ME3</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">6BX4511300</a> Gasket, upper casing	<a href="#">Buy now</a>

## Repair Kit 2




Ref	Part	
1	<a href="#">6BXW009300</a> Carburetor repair kit	<a href="#">Buy now</a>
2	<a href="#">6BX1498500</a> Float	<a href="#">Buy now</a>
3	<a href="#">6BX1498400</a> Gasket, float chamber	<a href="#">Buy now</a>
4	<a href="#">6BX1459200</a> Screw	<a href="#">Buy now</a>
5	<a href="#">4JH1456200</a> O-ring	<a href="#">Buy now</a>
6	<a href="#">6BX1454600</a> Valve, needle	<a href="#">Buy now</a>
7	<a href="#">6BX1454800</a> Pin, float arm	<a href="#">Buy now</a>
8	<a href="#">6BX1493700</a> Clip	<a href="#">Buy now</a>

# Repair Kit 3




Ref	Part	
1	<a href="#">6BXWG00120</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310110M14</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">9043008020</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">68DG5315A0</a> Packing, lower cas	<a href="#">Buy now</a>
5	<a href="#">6BXG431501</a> Gasket, water pump	<a href="#">Buy now</a>
6	<a href="#">9310113M12</a> Oil seal	<a href="#">Buy now</a>
7	<a href="#">9321048214</a> O-ring	<a href="#">Buy now</a>
8	<a href="#">6BXWG07800</a> Water pump repair kit	<a href="#">Buy now</a>
9	<a href="#">6BX4431100</a> Housing, water pum	<a href="#">Buy now</a>
11	<a href="#">6BX4432200</a> Insert, cartridge	<a href="#">Buy now</a>
12	<a href="#">6BX4432300</a> Outer plate, cartridge	<a href="#">Buy now</a>
13	<a href="#">67D4436600</a> Damper, water seal 2	<a href="#">Buy now</a>
14	<a href="#">6E04435200</a> Impeller	<a href="#">Buy now</a>
15	<a href="#">9709506045</a> Bolt, hexagon	<a href="#">Buy now</a>
16	<a href="#">9360418080</a> Pin. dowel. (647)	<a href="#">Buy now</a>

# Starter




Ref	Part	
1	<a href="#">6BX1571000</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">6BX1571100</a> Case, starter	<a href="#">Buy now</a>
3	<a href="#">63V1579501</a> Guide, rope	<a href="#">Buy now</a>
4	<a href="#">67D1576400</a> Collar 1	<a href="#">Buy now</a>
5	<a href="#">67D1571400</a> Drum, sheave	<a href="#">Buy now</a>
6	<a href="#">67D1574100</a> Pawl, drive	<a href="#">Buy now</a>
7	<a href="#">67D1571300</a> Spring, starter	<a href="#">Buy now</a>
8	<a href="#">6BX1570500</a> Spring, drive pawl	<a href="#">Buy now</a>
9	<a href="#">67D1576700</a> Spring	<a href="#">Buy now</a>
10	<a href="#">67D1573500</a> Guide, cam	<a href="#">Buy now</a>
11	<a href="#">67D1579300</a> Screw	<a href="#">Buy now</a>
12	<a href="#">63V1576400</a> Collar 1	<a href="#">Buy now</a>
13	<a href="#">67D1579401</a> Stopper	<a href="#">Buy now</a>
14	<a href="#">67D1573400</a> Spring, return	<a href="#">Buy now</a>
15	* item_description *1	<a href="#">Buy now</a>

# Starter




Ref	Part	
16	<a href="#">6G11575500</a> Handle, starter	<a href="#">Buy now</a>
17	<a href="#">6G11577900</a> Cover	<a href="#">Buy now</a>
18	<a href="#">67D1573900</a> Washer, thrust	<a href="#">Buy now</a>
19	<a href="#">67D1574400</a> Circlip	<a href="#">Buy now</a>
20	<a href="#">6BX1576200</a> Seal, rubber 2	<a href="#">Buy now</a>
21	<a href="#">9709506035</a> Bolt(j52)	<a href="#">Buy now</a>
22	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
23	<a href="#">9709506020</a> Bolt(7u8)	<a href="#">Buy now</a>
25	<a href="#">6BXE577000</a> Wire comp starter	<a href="#">Buy now</a>
26	<a href="#">9046407008</a> Clamp	<a href="#">Buy now</a>
27	<a href="#">6BX8237700</a> Label (Sparkplug Mark)	<a href="#">Buy now</a>
28	<a href="#">6AH8199540</a> Label, warning	<a href="#">Buy now</a>
29	<a href="#">6AH8199550</a> Label, warning	<a href="#">Buy now</a>
30	<a href="#">6BXE343760</a> Mark, caution	<a href="#">Buy now</a>
31	<a href="#">6BXE442760</a> Label, instruction	<a href="#">Buy now</a>

# Starter



Ref	Part	
32	<a href="#">6AH8199440</a> Label, safety	<a href="#">Buy now</a>
33	<a href="#">6AH8199450</a> Label, safety	<a href="#">Buy now</a>


# Steering



6BV1100-J140


Ref	Part	
1	<a href="#">6BXG2111004D</a> Handle, steering	<a href="#">Buy now</a>
2	<a href="#">6BX4212900</a> Bushing, rubber	<a href="#">Buy now</a>
3	<a href="#">6BXG217100</a> Bushing	<a href="#">Buy now</a>
4	<a href="#">6BXG217200</a> Bushing 2	<a href="#">Buy now</a>
5	<a href="#">6BXG218100</a> Washer	<a href="#">Buy now</a>
6	<a href="#">6BXG218800</a> Washer, wave	<a href="#">Buy now</a>
7	<a href="#">6BXG218200</a> Washer 2	<a href="#">Buy now</a>
8	<a href="#">6BX4213100</a> Cover, handle steering	<a href="#">Buy now</a>
9	<a href="#">9707508025</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
10	<a href="#">6G14212501</a> Bolt, friction adjusting	<a href="#">Buy now</a>
11	<a href="#">6G14212600</a> Piece, friction	<a href="#">Buy now</a>
12	<a href="#">9149016010</a> Pin, cotter	<a href="#">Buy now</a>
13	<a href="#">68DG211901</a> Grip, steering han	<a href="#">Buy now</a>
14	<a href="#">60PG213700</a> Indicator, thrott	<a href="#">Buy now</a>
15	<a href="#">9026902M09</a> Rivet(615)	<a href="#">Buy now</a>

# Steering




Ref	Part	
16	<a href="#">68DG217710</a> Rubber, handle	<a href="#">Buy now</a>
17	<a href="#">9015205011</a> Screw, countersunk	<a href="#">Buy now</a>
18	<a href="#">9020110M02</a> Washer, plate(6g9)	<a href="#">Buy now</a>
19	<a href="#">9050123215</a> Spring (655)	<a href="#">Buy now</a>
20	<a href="#">9038608032</a> Bushing (650)	<a href="#">Buy now</a>
21	<a href="#">6BX4213800</a> Lever, throttle	<a href="#">Buy now</a>
22	<a href="#">68DG215900</a> Stay	<a href="#">Buy now</a>
23	<a href="#">9788505012</a> Screw,pan head (646)	<a href="#">Buy now</a>
24	<a href="#">6BXF630100</a> Throttle cable ass	<a href="#">Buy now</a>
25	<a href="#">6BX4163800</a> Pulley	<a href="#">Buy now</a>
26	<a href="#">6BX4128300</a> Lever, free accel.	<a href="#">Buy now</a>
27	<a href="#">9038706252</a> Collar	<a href="#">Buy now</a>
28	<a href="#">6BX4121100</a> Link, accel.	<a href="#">Buy now</a>
29	<a href="#">6BXE449700</a> Stay, throttle wir	<a href="#">Buy now</a>
30	<a href="#">6614126202</a> Joint, choke lever	<a href="#">Buy now</a>

## Steering




Ref	Part	
31	<a href="#">9709506035</a> Bolt(j52)	<a href="#">Buy now</a>
32	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
33	<a href="#">9709506012</a> Bolt(gh1)	<a href="#">Buy now</a>
35	<a href="#">9020106M62</a> Washer, plate (6e5)	<a href="#">Buy now</a>
36	<a href="#">6471439560</a> Cap,over flow pipe	<a href="#">Buy now</a>
37	<a href="#">9046406006</a> Clamp	<a href="#">Buy now</a>
38	<a href="#">9046407M20</a> Clamp(6h0)	<a href="#">Buy now</a>
39	<a href="#">9046407M05</a> Clamp (6g5)	<a href="#">Buy now</a>
40	<a href="#">9046508395</a> Clamp	<a href="#">Buy now</a>
41	<a href="#">6AH4279440</a> Label, warning (ge	<a href="#">Buy now</a>

# Top Cowling




Ref	Part	
1	<a href="#">6BVG261000</a> Top cowling assembly (white)	<a href="#">Buy now</a>
1	<a href="#">6BVG261010</a> - FOR RUS	<a href="#">Buy now</a>
1	<a href="#">6BWG261000</a> Top Cowling assembly (White)	<a href="#">Buy now</a>
1	<a href="#">6BWG261010</a> - FOR RUS	<a href="#">Buy now</a>
1	<a href="#">6BXG261000</a> Top cowling assembly (white)	<a href="#">Buy now</a>
1	<a href="#">6BXG261010</a> - FOR RUS	<a href="#">Buy now</a>
2	<a href="#">6BXG261300</a> -	<a href="#">Buy now</a>
2	<a href="#">6BXG261310</a> Molding, air duct FOR RUS	<a href="#">Buy now</a>
3	<a href="#">9778040012</a> Screw, trushead tapping (ge31)	<a href="#">Buy now</a>
4	<a href="#">6BXG265100</a> Hook	<a href="#">Buy now</a>
5	<a href="#">9026604M04</a> Rivet(6e7)	<a href="#">Buy now</a>
6	<a href="#">6BX4261500</a> Seal	<a href="#">Buy now</a>
7	<a href="#">60R4265200</a> Hook	<a href="#">Buy now</a>
8	<a href="#">9759505514</a> Bolt, w/ plain	<a href="#">Buy now</a>
9	<a href="#">68T4264900</a> Holder, clamp band	<a href="#">Buy now</a>

# Top Cowling




Ref	Part	
10	<a href="#">6BXG213400</a> Cover	<a href="#">Buy now</a>
11	<a href="#">6BVW007000</a> Graphic Set	<a href="#">Buy now</a>
11	<a href="#">6BWW007000</a> Graphic Set	<a href="#">Buy now</a>
11	<a href="#">6BXW007000</a> Graphic Set	<a href="#">Buy now</a>
11	<a href="#">6BXW007010</a> Graphic Set FOR RUS	<a href="#">Buy now</a>
12	<a href="#">6BV4267700</a> Graphic, front FOR RUS	<a href="#">Buy now</a>
12	<a href="#">6BW4267700</a> Graphic, front FOR RUS	<a href="#">Buy now</a>
12	<a href="#">6BX4267700</a> Graphic Front FOR RUS	<a href="#">Buy now</a>
12	<a href="#">6BX4268100</a> Mark, cowling	<a href="#">Buy now</a>
13	<a href="#">6BX4269700</a> Tuning fork mark	<a href="#">Buy now</a>
13	<a href="#">6BX4269710</a> Tuning fork mark FOR RUS	<a href="#">Buy now</a>
14	<a href="#">9026604M00</a> Rivet 2 (662)	<a href="#">Buy now</a>
15	<a href="#">60RE343400</a> Label, Caution	<a href="#">Buy now</a>
16	<a href="#">6S74269840</a> Label, warning (fu)	<a href="#">Buy now</a>
17	<a href="#">6S74269850</a> Label, warning (fu)	<a href="#">Buy now</a>

## Upper Casing



Ref	Part	
1	<a href="#">6BXG5111004D</a> Upper casing & grease nipple	<a href="#">Buy now</a>
2	<a href="#">6BX1531600</a> Damper 1	<a href="#">Buy now</a>
3	<a href="#">6BXG532100</a> Plate	<a href="#">Buy now</a>
4	<a href="#">9709506014</a> Bolt(gj3)	<a href="#">Buy now</a>
5	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">6BX4511300</a> Gasket, upper casing	<a href="#">Buy now</a>
7	<a href="#">9038706806</a> Collar(6e0)	<a href="#">Buy now</a>
8	<a href="#">9757506540</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
9	<a href="#">9707506050</a> Bolt(jf7)	<a href="#">Buy now</a>
11	<a href="#">6474515101</a> Cover, upper casing	<a href="#">Buy now</a>
12	<a href="#">9048010M13</a> Grommet (6e0)	<a href="#">Buy now</a>
13	<a href="#">6BX4271600</a> Rubber, seal 1	<a href="#">Buy now</a>
14	<a href="#">6BXG272300</a> Cover, bottom	<a href="#">Buy now</a>

# Valve



 6BV1100-J050

Ref	Part	
1	<a href="#">6BXE217000</a> Camshaft assembly 1	<a href="#">Buy now</a>
2	<a href="#">6BX1211100</a> Valve, intake	<a href="#">Buy now</a>
3	<a href="#">6AU1212100</a> Valve, exhaust	<a href="#">Buy now</a>
4	<a href="#">51Y1211900</a> Seal, valve stem	<a href="#">Buy now</a>
5	<a href="#">60R1211300</a> Spring, valve inne	<a href="#">Buy now</a>
6	<a href="#">68T1211600</a> Seat, valve spring	<a href="#">Buy now</a>
7	<a href="#">7NJ1211700</a> Retainer, valve spring	<a href="#">Buy now</a>
8	<a href="#">7NJ1211800</a> Cotter, valve	<a href="#">Buy now</a>
9	<a href="#">67D1215100</a> Arm, valve rocker	<a href="#">Buy now</a>
10	<a href="#">7FK1216500</a> Pivot, rocker arm	<a href="#">Buy now</a>
11	<a href="#">7FK1215800</a> Nut, lock	<a href="#">Buy now</a>
12	<a href="#">67D1215700</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">6BXE215500</a> Guide, push rod	<a href="#">Buy now</a>
14	<a href="#">6BX1215400</a> Rod, valve push	<a href="#">Buy now</a>
15	<a href="#">JA91215300</a> Lifter, valve	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.