



# Yamaha F6AMH 2001

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Bottom Cowling</b>	3
<b>Bracket 1</b>	6
<b>Bracket 2</b>	9
<b>Carburetor</b>	11
<b>Control</b>	13
<b>Crankshaft &amp; Piston</b>	15
<b>Cylinder &amp; Crankcase</b>	16
<b>Cylinder &amp; Crankcase 2</b>	18
<b>Electrical 1</b>	20
<b>Electrical 2</b>	22
<b>Fuel</b>	23
<b>Fuel 2</b>	25
<b>Fuel Tank</b>	26
<b>Generator</b>	27
<b>Intake</b>	28
<b>Lower Casing &amp; Drive 1</b>	30
<b>Lower Casing &amp; Drive 2</b>	34
<b>Oil Pan</b>	36
<b>Oil Pump</b>	38
<b>Remo Con Attachment</b>	40
<b>Repair Kit 1</b>	41
<b>Repair Kit 2</b>	43
<b>Repair Kit 3</b>	44
<b>Starter</b>	46
<b>Steering</b>	48
<b>Steering Friction</b>	52
<b>Top Cowling</b>	53
<b>Upper Casing</b>	54
<b>Valve</b>	55

## Bottom Cowling




Ref	Part	
1	<a href="#">68T42710004D</a> Bottom Cowling assembly	<a href="#">Buy now</a>
2	<a href="#">68F851190000</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">9048021M8200</a> Grommet	<a href="#">Buy now</a>
4	<a href="#">68F861290000</a> Collar	<a href="#">Buy now</a>
5	<a href="#">68T427160000</a> Rubber, seal 1	<a href="#">Buy now</a>
6	<a href="#">68T428010000</a> Cowling clamp comp.	<a href="#">Buy now</a>
7	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
8	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">6H3443910100</a> Nipple, hose	<a href="#">Buy now</a>
10	<a href="#">682427270000</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">68T42738004D</a> Plate, fitting	<a href="#">Buy now</a>
12	<a href="#">9010906M8100</a> Bolt	<a href="#">Buy now</a>
13	<a href="#">68T427250000</a> Grommet	<a href="#">Buy now</a>
14	<a href="#">68T263930000</a> Holder	<a href="#">Buy now</a>
15	<a href="#">68T263670000</a> Protector	<a href="#">Buy now</a>

## Bottom Cowling




Ref	Part	
16	<a href="#">68T427242000</a> Grommet	<a href="#">Buy now</a>
17	<a href="#">9048006M1900</a> Grommet (6e3)	<a href="#">Buy now</a>
18	<a href="#">688427261000</a> Grommet	<a href="#">Buy now</a>
19	<a href="#">65W427170000</a> Rubber, seal 2	<a href="#">Buy now</a>
20	<a href="#">68T427410000</a> Apron	<a href="#">Buy now</a>
21	<a href="#">978850603000</a> Screw, pan head(6e0)	<a href="#">Buy now</a>
22	<a href="#">929900610000</a> Washer(6a1)	<a href="#">Buy now</a>
23	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
24	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
25	<a href="#">68T427170000</a> Rubber, seal 2	<a href="#">Buy now</a>
26	<a href="#">68T427710000</a> Apron	<a href="#">Buy now</a>
27	<a href="#">9033806M2000</a> Plug	<a href="#">Buy now</a>
28	<a href="#">65W843420000</a> Seat, emblem	<a href="#">Buy now</a>
29	<a href="#">6E5124810000</a> Pipe 1	<a href="#">Buy now</a>
30	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>

## Bottom Cowling



Ref	Part	
31	<a href="#">9044713M0000</a> Hose, with spring	<a href="#">Buy now</a>
32	<a href="#">6R3125820000</a> Joint, hose 2	<a href="#">Buy now</a>
33	<a href="#">6R3125830000</a> Gasket, hose joint	<a href="#">Buy now</a>
34	<a href="#">6R3125810000</a> Joint, hose 1	<a href="#">Buy now</a>
35	<a href="#">68T125720000</a> Adapter	<a href="#">Buy now</a>
36	<a href="#">977806052000</a> Screw, tapping(6k8)	<a href="#">Buy now</a>
37	<a href="#">68T125352000</a> Plate	<a href="#">Buy now</a>
38	<a href="#">970950601000</a> Bolt	<a href="#">Buy now</a>


# Bracket 1



  
 68R0010-0200

Ref	Part	
1	<a href="#">68T43111014D</a> Bracket clamp + screw	<a href="#">Buy now</a>
2	<a href="#">68T43112014D</a> Bracket clamp + screw	<a href="#">Buy now</a>
3	<a href="#">6EEG31180000</a> Handle, transom cl	<a href="#">Buy now</a>
4	<a href="#">9024304M0100</a> Pin(6a1)	<a href="#">Buy now</a>
5	<a href="#">677431160100</a> Screw, transom clamp.	<a href="#">Buy now</a>
6	<a href="#">648431140100</a> Pad, transom clamp	<a href="#">Buy now</a>
7	<a href="#">63V431310000</a> Bolt, Clamp Bracket	<a href="#">Buy now</a>
8	<a href="#">9038622MA400</a> Bush	<a href="#">Buy now</a>
9	<a href="#">66R431130000</a> Plate, clamp bracket	<a href="#">Buy now</a>
10	<a href="#">63V431450000</a> Nut, self-locking	<a href="#">Buy now</a>
11	<a href="#">9038706M1300</a> Collar(6h6)	<a href="#">Buy now</a>
12	<a href="#">9010106M1800</a> Bolt(6I5)	<a href="#">Buy now</a>
13	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
14	<a href="#">9538R0670000</a> Nut	<a href="#">Buy now</a>
15	<a href="#">6L2431600000</a> Tilt rod assembly	<a href="#">Buy now</a>

# Bracket 1




68R0010-0200

Ref	Part	
16	<a href="#">60RG3311104D</a> Bracket swivel1	<a href="#">Buy now</a>
17	<a href="#">68T436310000</a> Lever Tilt	<a href="#">Buy now</a>
18	<a href="#">68T436160000</a> Rod Tilt Lock	<a href="#">Buy now</a>
19	<a href="#">68T436460000</a> Shaft, lever	<a href="#">Buy now</a>
20	<a href="#">68T436410000</a> Lever, tilt	<a href="#">Buy now</a>
21	<a href="#">68T436170000</a> Rod, tilt lock	<a href="#">Buy now</a>
22	<a href="#">990800560000</a> Circlip(22k)	<a href="#">Buy now</a>
23	<a href="#">68T433500000</a> Receiver assembly	<a href="#">Buy now</a>
24	<a href="#">9050618M4100</a> Spring, tension	<a href="#">Buy now</a>
25	<a href="#">63V431910000</a> Shaft, stopper	<a href="#">Buy now</a>
27	<a href="#">68T436140000</a> Plate, tilt lock	<a href="#">Buy now</a>
28	<a href="#">9050620M4200</a> Spring, Tension	<a href="#">Buy now</a>
29	<a href="#">68T436150000</a> Plate, tilt lock	<a href="#">Buy now</a>
30	<a href="#">68T436110000</a> Shaft, tilt lock	<a href="#">Buy now</a>
31	<a href="#">990800460000</a> Circlip (eu0)	<a href="#">Buy now</a>



# Bracket 1




68R0010-0200

Ref	Part	
32	<a href="#">68T436590000</a> Shaft, reverse lock	<a href="#">Buy now</a>
34	<a href="#">68T436270000</a> Stopper	<a href="#">Buy now</a>
35	<a href="#">9010906M8400</a> Bolt	<a href="#">Buy now</a>
36	<a href="#">9020610M2400</a> Washer, wave	<a href="#">Buy now</a>




## Bracket 2




Ref	Part	
1	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
2	<a href="#">68T821270000</a> Wire, lead 2	<a href="#">Buy now</a>
3	<a href="#">63V425280000</a> Plate, friction	<a href="#">Buy now</a>
4	<a href="#">689433730100</a> Seal, damper	<a href="#">Buy now</a>
5	<a href="#">9010506M0700</a> Bolt (689)	<a href="#">Buy now</a>
6	<a href="#">60RG2511114D</a> Bracket, steering	<a href="#">Buy now</a>
7	<a href="#">63V425370000</a> Bushing, pivot shaft	<a href="#">Buy now</a>
8	<a href="#">903863004800</a> Bush	<a href="#">Buy now</a>
9	<a href="#">9321029M9400</a> O-ring(6h1)	<a href="#">Buy now</a>
10	<a href="#">9038630M6000</a> Bush(6j8)	<a href="#">Buy now</a>
11	<a href="#">9011608M5400</a> Bolt, stud(63v)	<a href="#">Buy now</a>
12	<a href="#">68T445170000</a> Mount rubber	<a href="#">Buy now</a>
13	<a href="#">68T445260000</a> Plate	<a href="#">Buy now</a>
14	<a href="#">953800860000</a> Nut (661)	<a href="#">Buy now</a>
15	<a href="#">970750602500</a> Bolt	<a href="#">Buy now</a>

## Bracket 2



Ref	Part	
16	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">68T44551004D</a> Housing, lower mount rubber 1	<a href="#">Buy now</a>
18	<a href="#">68T445570000</a> Mount Damper Lower Front	<a href="#">Buy now</a>
19	<a href="#">682445550000</a> Mount damper, lower side	<a href="#">Buy now</a>
20	<a href="#">901190601200</a> Bolt, with washer	<a href="#">Buy now</a>
21	<a href="#">901190601300</a> Bolt, with washer	<a href="#">Buy now</a>
22	<a href="#">9017906M2800</a> Nut(63v)	<a href="#">Buy now</a>


# Carburetor



68R0100-1070

Ref	Part	
1	<a href="#">68R143011000</a> Carburetor assembly 1	<a href="#">Buy now</a>
2	<a href="#">6E5143210000</a> Screw, throttle	<a href="#">Buy now</a>
3	<a href="#">6J8143340000</a> Spring, throttle	<a href="#">Buy now</a>
4	<a href="#">985800401200</a> Screw, pan head (686)	<a href="#">Buy now</a>
5	<a href="#">68T143850000</a> Float	<a href="#">Buy now</a>
6	<a href="#">67D149660000</a> Rubber cap	<a href="#">Buy now</a>
7	<a href="#">67D143860000</a> Pin, float	<a href="#">Buy now</a>
8	<a href="#">68T145460000</a> Valve, needle	<a href="#">Buy now</a>
9	<a href="#">68T1492E3700</a> Jet, main (#74)	<a href="#">Buy now</a>
10	<a href="#">68T1492F1K00</a> Jet, air slow (#39)	<a href="#">Buy now</a>
11	<a href="#">68T1492A0000</a> Nozzle, main	<a href="#">Buy now</a>
12	<a href="#">67D149840000</a> Gasket, float chamber	<a href="#">Buy now</a>
13	<a href="#">68T149810000</a> Body, float chamber	<a href="#">Buy now</a>
14	<a href="#">6J8149590000</a> Gasket, drain screw	<a href="#">Buy now</a>
15	<a href="#">66T149910000</a> Plug, drain	<a href="#">Buy now</a>


# Carburetor



68R0100-1070


Ref	Part	
16	<a href="#">67D143230000</a> Screw, air adjusting	<a href="#">Buy now</a>
17	<a href="#">67D145360000</a> Gasket	<a href="#">Buy now</a>
18	<a href="#">67D145270000</a> Plate	<a href="#">Buy now</a>
19	<a href="#">68T141260000</a> Plug	<a href="#">Buy now</a>
20	<a href="#">67D1432A0000</a> Plug	<a href="#">Buy now</a>

# Control




Ref	Part	
1	<a href="#">68T427260000</a> Grommet	<a href="#">Buy now</a>
2	<a href="#">68T441210100</a> Lever, shift rod	<a href="#">Buy now</a>
3	<a href="#">6G1416620194</a> Bracket	<a href="#">Buy now</a>
4	<a href="#">9010906M8100</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">9046410M6000</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">916903001400</a> Pin, spring (647)	<a href="#">Buy now</a>
7	<a href="#">65W441160000</a> Spring	<a href="#">Buy now</a>
8	<a href="#">66R441170000</a> Bracket	<a href="#">Buy now</a>
9	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
10	<a href="#">68T441430000</a> Rod, shift 1	<a href="#">Buy now</a>
11	<a href="#">904681800100</a> Clip	<a href="#">Buy now</a>
12	<a href="#">901700601500</a> Connector, shift rod	<a href="#">Buy now</a>
13	<a href="#">953800670000</a> Nut	<a href="#">Buy now</a>
14	<a href="#">68T485380000</a> Clamp, cable 1	<a href="#">Buy now</a>
15	<a href="#">970800601200</a> Bolt(gh1)	<a href="#">Buy now</a>

## Control



Ref	Part	
16	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">63D485380000</a> Clamp, cable 1	<a href="#">Buy now</a>
18	<a href="#">68T416380000</a> Pulley	<a href="#">Buy now</a>
19	<a href="#">68R412830000</a> Lever Free Accel.	<a href="#">Buy now</a>
20	<a href="#">9038706M5900</a> Collar (6h3)	<a href="#">Buy now</a>
21	<a href="#">68T412110000</a> Link, accel.	<a href="#">Buy now</a>
22	<a href="#">68T144970000</a> Stay, throttle wire	<a href="#">Buy now</a>
23	<a href="#">9020106M6200</a> Washer, plate (6e5)	<a href="#">Buy now</a>
24	<a href="#">970800604500</a> Bolt, hexagon	<a href="#">Buy now</a>
26	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
28	<a href="#">661412620200</a> Joint, choke lever	<a href="#">Buy now</a>
29	<a href="#">647143956000</a> Cap,over flow pipe	<a href="#">Buy now</a>

## Crankshaft & Piston




68F0010-0030

Ref	Part	
1	<a href="#">9310230M2200</a> Oil seal (6g8)	<a href="#">Buy now</a>
2	<a href="#">9310125M6900</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">68T114110000</a> Crankshaft	<a href="#">Buy now</a>
4	<a href="#">68T114162100</a> Plane bearing, crankshaft 1	<a href="#">Buy now</a>
5	<a href="#">68T116500000</a> Connecting rod kit	<a href="#">Buy now</a>
6	<a href="#">67D116540000</a> Bolt, connecting rod	<a href="#">Buy now</a>
7	<a href="#">60RE16360000</a> Piston (0.50mm o/s)	<a href="#">Buy now</a>
8	<a href="#">68T116050100</a> Piston ring set (0.50mm o/s)	<a href="#">Buy now</a>
9	<a href="#">68T116330000</a> Pin, piston	<a href="#">Buy now</a>
10	<a href="#">934501502300</a> Circlip 131116340000	<a href="#">Buy now</a>




# Cylinder & Crankcase




Ref	Part	
1	<a href="#">68TW009B004D</a> Cylinder Block assembly	<a href="#">Buy now</a>
2	<a href="#">68T151000094</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">995301201600</a> Pin, dowel	<a href="#">Buy now</a>
4	<a href="#">9011908M2900</a> Bolt, with washer	<a href="#">Buy now</a>
5	<a href="#">68T113510000</a> Gasket, cylinder	<a href="#">Buy now</a>
6	<a href="#">66M124110000</a> Thermostat	<a href="#">Buy now</a>
7	<a href="#">68T12413009M</a> Cover, thermostat	<a href="#">Buy now</a>
8	<a href="#">6G812414A000</a> Gasket, cover	<a href="#">Buy now</a>
9	<a href="#">970130602000</a> Bolt(62y)	<a href="#">Buy now</a>
10	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">68T124810000</a> Pipe 1	<a href="#">Buy now</a>
12	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
13	<a href="#">60RG1113001S</a> Outer cover, exhaust	<a href="#">Buy now</a>
14	<a href="#">6E9243780000</a> Pipe, joint 4	<a href="#">Buy now</a>
15	<a href="#">68T41114A000</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
16	<a href="#">970130602500</a> Bolt(62y)	<a href="#">Buy now</a>
17	<a href="#">929030660000</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">68T124820000</a> Pipe 2	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
1	<a href="#">68TW009A004D</a> Cylinder head assembly	<a href="#">Buy now</a>
2	<a href="#">68T111110094</a> Head, Cylinder 1	<a href="#">Buy now</a>
3	<a href="#">6EEE11331000</a> Guide, valve 1	<a href="#">Buy now</a>
4	<a href="#">68T111810000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
5	<a href="#">995101011400</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
6	<a href="#">9010508M3600</a> Bolt (6g8)	<a href="#">Buy now</a>
7	<a href="#">9010508M7800</a> Bolt, washer based	<a href="#">Buy now</a>
8	<a href="#">970130607000</a> Bolt(62j)	<a href="#">Buy now</a>
9	<a href="#">929030660000</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">68T111910094</a> Cover, Cylinder Head 1	<a href="#">Buy now</a>
11	<a href="#">650243780000</a> Pipe, joint 2	<a href="#">Buy now</a>
12	<a href="#">68T113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
13	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
14	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
15	<a href="#">68T111680000</a> Cover, breather	<a href="#">Buy now</a>

## Cylinder & Crankcase 2



Ref	Part	
16	<a href="#">68T11169A000</a> Gasket, breather cover	<a href="#">Buy now</a>
17	<a href="#">985070401000</a> Screw, pan head(6g8)	<a href="#">Buy now</a>
18	<a href="#">929070460000</a> Washer(jf2)	<a href="#">Buy now</a>
19	<a href="#">68T113250000</a> Anode	<a href="#">Buy now</a>
20	<a href="#">9015105M0500</a> Screw, countersunk	<a href="#">Buy now</a>
21	<a href="#">6G8111970100</a> Plug, blind	<a href="#">Buy now</a>
22	<a href="#">9321013M6300</a> O-ring (6g8)	<a href="#">Buy now</a>
23	<a href="#">6G8153630000</a> Plug, oil	<a href="#">Buy now</a>
24	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>
25	<a href="#">947020027400</a> Plug, spark (br6hs-10)	<a href="#">Buy now</a>


# Electrical 1



Ref	Part	
1	<a href="#">68R855400000</a> C.d.i. Unit assembly	<a href="#">Buy now</a>
2	<a href="#">68T825220000</a> Clamp, coupler	<a href="#">Buy now</a>
3	<a href="#">977804051200</a> Screw, pan head tapping	<a href="#">Buy now</a>
4	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
5	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">68T855420000</a> Bracket	<a href="#">Buy now</a>
7	<a href="#">970950801200</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
8	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
9	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">680855700200</a> Ignition coil assembly	<a href="#">Buy now</a>
11	<a href="#">904802516100</a> Grommet(656)	<a href="#">Buy now</a>
12	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
14	<a href="#">6E3823702100</a> Plug cap assembly	<a href="#">Buy now</a>
15	<a href="#">664819706200</a> Rectifier assembly	<a href="#">Buy now</a>
16	<a href="#">978800502500</a> Screw, panhead (a93)	<a href="#">Buy now</a>




# Electrical 1



Ref	Part	
17	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
18	<a href="#">6A0821190000</a> Cover, lead wire	<a href="#">Buy now</a>
19	<a href="#">67F825040000</a> Oil pressure switch assembly	<a href="#">Buy now</a>
20	<a href="#">68T821271000</a> Wire, lead 2	<a href="#">Buy now</a>
21	<a href="#">68T854100000</a> Emergency signal light assembly	<a href="#">Buy now</a>


## Electrical 2



Ref	Part	
1	<a href="#">65W825750100</a> Engine stop switch assembly	<a href="#">Buy now</a>
2	<a href="#">682825560000</a> Lanyard, stop switch	<a href="#">Buy now</a>
3	<a href="#">6898257Y0000</a> Cap	<a href="#">Buy now</a>
4	<a href="#">6G1427250000</a> Grommet	<a href="#">Buy now</a>




# Fuel




Ref	Part	
1	<a href="#">6G1243040200</a> Fuel pipe joint comp. 1	<a href="#">Buy now</a>
2	<a href="#">61N243290000</a> Seal	<a href="#">Buy now</a>
3	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">9044510M1800</a> Hose (I400)	<a href="#">Buy now</a>
6	<a href="#">9046709M0900</a> Clip(6k8)	<a href="#">Buy now</a>
7	<a href="#">68T242510100</a> Strainer 1	<a href="#">Buy now</a>
8	<a href="#">9044510M5000</a> Hose (I400)	<a href="#">Buy now</a>
10	<a href="#">9044614M6600</a> Hose(64x)	<a href="#">Buy now</a>
11	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
12	<a href="#">68T244100000</a> Fuel pump assembly	<a href="#">Buy now</a>
13	<a href="#">66M244130100</a> Body 2	<a href="#">Buy now</a>
14	<a href="#">6A0244210100</a> Valve, check	<a href="#">Buy now</a>
15	<a href="#">6E7143250000</a> Screw, pan head	<a href="#">Buy now</a>
16	<a href="#">66M244110000</a> Diaphragm	<a href="#">Buy now</a>

# Fuel




Ref	Part	
17	<a href="#">66M244230000</a> Spring, diaphragm	<a href="#">Buy now</a>
18	<a href="#">66M131310000</a> Plunger	<a href="#">Buy now</a>
19	<a href="#">66M243740000</a> Pin	<a href="#">Buy now</a>
20	<a href="#">66M244540000</a> Spring	<a href="#">Buy now</a>
21	<a href="#">66M244710100</a> Diaphragm	<a href="#">Buy now</a>
22	<a href="#">66M244440000</a> Screw	<a href="#">Buy now</a>
23	<a href="#">953800560000</a> Nut, hexagon (663)	<a href="#">Buy now</a>
24	<a href="#">970950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
25	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
26	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
27	<a href="#">9321020M6500</a> O-ring	<a href="#">Buy now</a>
28	<a href="#">904451001600</a> Hose (l280)	<a href="#">Buy now</a>
31	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
32	<a href="#">9046410M5300</a> Clamp	<a href="#">Buy now</a>
33	<a href="#">68T281000000</a> Tool kit	<a href="#">Buy now</a>

## Fuel 2



Ref	Part	
1	<a href="#">6Y1243065300</a> Fuel pipe comp. 1	<a href="#">Buy now</a>
2	<a href="#">9044511M0600</a> Hose (I3000)	<a href="#">Buy now</a>
3	<a href="#">6Y1243605200</a> Primer pump assembly	<a href="#">Buy now</a>
4	<a href="#">9044511M7800</a> Hose (I1000)	<a href="#">Buy now</a>
5	<a href="#">650243515100</a> Band 1	<a href="#">Buy now</a>
6	<a href="#">6G1243050300</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>
7	<a href="#">932100828700</a> O-ring (655)	<a href="#">Buy now</a>
8	<a href="#">6Y1243050400</a> Fuel pipe joint comp. 2	<a href="#">Buy now</a>


# Fuel Tank



FWD  
66R0700-9260


Ref	Part	
1	<a href="#">6YL242010100</a> Fuel Tank assembly (12L)	<a href="#">Buy now</a>
2	<a href="#">6YL246100000</a> Cap Assembly	<a href="#">Buy now</a>
3	<a href="#">6YL246410000</a> Gasket, cap 1	<a href="#">Buy now</a>
4	<a href="#">6YL242600100</a> Fuel meter assembly	<a href="#">Buy now</a>
5	<a href="#">9015705M1600</a> Screw, pan head	<a href="#">Buy now</a>
6	<a href="#">6YL243290000</a> Seal	<a href="#">Buy now</a>
7	<a href="#">6YL242680100</a> Gasket, fuel meter	<a href="#">Buy now</a>
8	<a href="#">6YL243065200</a> Fuel pipe comp. 1	<a href="#">Buy now</a>

# Generator




Ref	Part	
1	<a href="#">68T855500100</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">68T855200000</a> Coil, charge	<a href="#">Buy now</a>
3	<a href="#">68T855800100</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">68T855330000</a> Coil, lighting	<a href="#">Buy now</a>
5	<a href="#">6H2855820000</a> Attachment, pulser	<a href="#">Buy now</a>
6	<a href="#">975130652500</a> Bolt, with washer(61b)	<a href="#">Buy now</a>
7	<a href="#">970950501000</a> Bolt (682)	<a href="#">Buy now</a>
8	<a href="#">9011906MA100</a> Bolt, with washer(63m)	<a href="#">Buy now</a>
9	<a href="#">68T813280000</a> Clamp	<a href="#">Buy now</a>
10	<a href="#">970130601200</a> Bolt(gh1)	<a href="#">Buy now</a>
11	<a href="#">929030660000</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
13	<a href="#">9028004M0600</a> Key, woodruff(6a1)	<a href="#">Buy now</a>
14	<a href="#">901701206600</a> Nut, hexagon 6481155500	<a href="#">Buy now</a>
15	<a href="#">902011247200</a> Washer, plate (4n0)	<a href="#">Buy now</a>

# Intake



Ref	Part	
1	<a href="#">68T13641201S</a> Manifold 1	<a href="#">Buy now</a>
2	<a href="#">6EEF43770000</a> Pipe, joint 2	<a href="#">Buy now</a>
3	<a href="#">68T136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
4	<a href="#">970130603500</a> Bolt(3rv)	<a href="#">Buy now</a>
5	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">970130602500</a> Bolt(62y)	<a href="#">Buy now</a>
7	<a href="#">929030660000</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">916905001400</a> Pin, spring (647)	<a href="#">Buy now</a>
9	<a href="#">90445092K100</a> Hose (l420)	<a href="#">Buy now</a>
10	<a href="#">68T13646A000</a> Gasket, manifold 2	<a href="#">Buy now</a>
11	<a href="#">68T142710000</a> Insulator	<a href="#">Buy now</a>
12	<a href="#">68T144400000</a> Silencer assembly, intake	<a href="#">Buy now</a>
13	<a href="#">9321031MJ500</a> O-ring	<a href="#">Buy now</a>
14	<a href="#">9038706M7000</a> Collar (6h5)	<a href="#">Buy now</a>
15	<a href="#">975950658500</a> Bolt, flange	<a href="#">Buy now</a>


# Intake



Ref	Part	
16	<a href="#">68T124830000</a> Pipe 3	<a href="#">Buy now</a>
17	<a href="#">9046508M9900</a> Clamp	<a href="#">Buy now</a>
18	<a href="#">9046508M8300</a> Clamp	<a href="#">Buy now</a>
19	<a href="#">970950601000</a> Bolt	<a href="#">Buy now</a>
20	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
21	<a href="#">6H4412710100</a> Knob, choke	<a href="#">Buy now</a>
22	<a href="#">689412730000</a> Grommet	<a href="#">Buy now</a>
23	<a href="#">68T412560000</a> Rod, choke 1	<a href="#">Buy now</a>
24	<a href="#">6J8412620000</a> Joint, choke lever	<a href="#">Buy now</a>




## Lower Casing & Drive 1




Ref	Part	
1	<a href="#">68T45300004D</a> Lower unit assembly	<a href="#">Buy now</a>
2	<a href="#">60RG5311004D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">6G1453170900</a> Bushing, drive shaft 2	<a href="#">Buy now</a>
4	<a href="#">9038714M4900</a> Collar (6g1)	<a href="#">Buy now</a>
5	<a href="#">93306004U000</a> Bearing (7k2)	<a href="#">Buy now</a>
6	<a href="#">68T452510000</a> Anode	<a href="#">Buy now</a>
7	<a href="#">958950601600</a> Bolt, flange deep recess	<a href="#">Buy now</a>
8	<a href="#">929900630000</a> Washer, tooth	<a href="#">Buy now</a>
9	<a href="#">9034008M0400</a> Plug, straight screw	<a href="#">Buy now</a>
10	<a href="#">904300800300</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">6G145361014D</a> Cap, lower casing	<a href="#">Buy now</a>
12	<a href="#">6G1453620900</a> Bushing, lower casing cap	<a href="#">Buy now</a>
13	<a href="#">933060042300</a> Bearing (7k2)	<a href="#">Buy now</a>
14	<a href="#">931011507400</a> Oil seal (655)	<a href="#">Buy now</a>
15	<a href="#">932104904600</a> O-ring (620)	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
16	<a href="#">9321053M0800</a> O-ring(50m)	<a href="#">Buy now</a>
17	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
18	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
19	<a href="#">63V443010000</a> Water pump housing comp.	<a href="#">Buy now</a>
20	<a href="#">63V443220000</a> Insert, cartridge	<a href="#">Buy now</a>
21	<a href="#">68T443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
22	<a href="#">68T443520000</a> Impeller	<a href="#">Buy now</a>
23	<a href="#">664443380000</a> Key, woodruff	<a href="#">Buy now</a>
24	<a href="#">932104439800</a> O-ring(55x)	<a href="#">Buy now</a>
25	<a href="#">68T443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
26	<a href="#">9360412M0700</a> Pin, dowel (688)	<a href="#">Buy now</a>
27	<a href="#">970800804500</a> Bolt, hexagon	<a href="#">Buy now</a>
28	<a href="#">63V443280000</a> Plate	<a href="#">Buy now</a>
29	<a href="#">68T45331005B</a> Housing, bearing	<a href="#">Buy now</a>
30	<a href="#">6G1453160900</a> Bushing, drive shaft 1	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
31	<a href="#">9310111M2300</a> Oil seal (6g1)	<a href="#">Buy now</a>
32	<a href="#">68T45315A000</a> Packing, lower casing	<a href="#">Buy now</a>
33	<a href="#">9321006ME600</a> O-ring	<a href="#">Buy now</a>
34	<a href="#">970800802500</a> Screw, bind(j36)	<a href="#">Buy now</a>
35	<a href="#">68T441500000</a> Shift cam assembly	<a href="#">Buy now</a>
36	<a href="#">6AU455111000</a> Shaft, drive	<a href="#">Buy now</a>
37	<a href="#">9046709M0500</a> Clip (6g1)	<a href="#">Buy now</a>
38	<a href="#">934300701200</a> Circlip(6I2)	<a href="#">Buy now</a>
39	<a href="#">68T455510000</a> Pinion	<a href="#">Buy now</a>
40	<a href="#">6G1455333000</a> Shim (t:2.2mm)	<a href="#">Buy now</a>
41	<a href="#">68T455600000</a> Gear	<a href="#">Buy now</a>
42	<a href="#">664455870130</a> Shim (t:0.30mm)	<a href="#">Buy now</a>
43	<a href="#">68T455710000</a> Gear	<a href="#">Buy now</a>
44	<a href="#">9020115M8900</a> Washer, plate (6g1)	<a href="#">Buy now</a>
45	<a href="#">647455670000</a> Shim, gear adjust	<a href="#">Buy now</a>

## Lower Casing & Drive 1




Ref	Part	
46	<a href="#">68T456310000</a> Clutch, dog	<a href="#">Buy now</a>
47	<a href="#">6G1456320000</a> Cross, pin	<a href="#">Buy now</a>
48	<a href="#">654456330000</a> Ring, cross pin	<a href="#">Buy now</a>
49	<a href="#">9050112M0500</a> Spring, compression	<a href="#">Buy now</a>
50	<a href="#">6G1456350000</a> Plunger, shift	<a href="#">Buy now</a>
51	<a href="#">68T456110000</a> Shaft, propeller	<a href="#">Buy now</a>

## Lower Casing & Drive 2




Ref	Part	
1	<a href="#">68T443610000</a> Tube, water 1	<a href="#">Buy now</a>
2	<a href="#">63V443651000</a> Damper, water seal 1	<a href="#">Buy now</a>
3	<a href="#">9360412M0700</a> Pin, dowel (688)	<a href="#">Buy now</a>
4	<a href="#">970750803500</a> Bolt(70w)	<a href="#">Buy now</a>
5	<a href="#">929900860000</a> Washer, plain (663)	<a href="#">Buy now</a>
6	<a href="#">6G1452140000</a> Cover, water inlet	<a href="#">Buy now</a>
7	<a href="#">6G1452150000</a> Cover, water inlet	<a href="#">Buy now</a>
8	<a href="#">9015205M0300</a> Screw, countersunk	<a href="#">Buy now</a>
9	<a href="#">901850500200</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
10	<a href="#">63V453750000</a> Damper, seal	<a href="#">Buy now</a>
11	<a href="#">6G1459870200</a> Spacer	<a href="#">Buy now</a>
12	<a href="#">9020110M0100</a> Washer, plate(6m7)	<a href="#">Buy now</a>
13	<a href="#">9017110M0100</a> Nut castle (683)	<a href="#">Buy now</a>
14	<a href="#">914903002000</a> Pin cotter	<a href="#">Buy now</a>
15	<a href="#">6G1459520000</a> Propeller (3x8-1/2 x8 -n)	<a href="#">Buy now</a>

## Lower Casing & Drive 2



Ref	Part	
16	<a href="#">6G1W45920000</a> Propeller (3x9 x5 -n)	<a href="#">Buy now</a>
17	<a href="#">6G1456160100</a> Nut, propeller	<a href="#">Buy now</a>
18	<a href="#">9020110M0200</a> Washer, plate(6g9)	<a href="#">Buy now</a>


# Oil Pan



Ref	Part	
1	<a href="#">68T411370094</a> Guide, exhaust	<a href="#">Buy now</a>
2	<a href="#">65W427170000</a> Rubber, seal 2	<a href="#">Buy now</a>
3	<a href="#">68T451810000</a> Plate	<a href="#">Buy now</a>
4	<a href="#">970950801400</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">904300814300</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
6	<a href="#">9310112M7000</a> Oil seal	<a href="#">Buy now</a>
7	<a href="#">68T134210100</a> Strainer 2	<a href="#">Buy now</a>
8	<a href="#">9046711M0800</a> Clip(72x)	<a href="#">Buy now</a>
9	<a href="#">6G8115750000</a> Relief valve ass'y	<a href="#">Buy now</a>
10	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
11	<a href="#">68T15311005B</a> Oil pan	<a href="#">Buy now</a>
12	<a href="#">6H1113720000</a> Nipple, hose	<a href="#">Buy now</a>
13	<a href="#">9034010M1000</a> Plug, straight screw	<a href="#">Buy now</a>
14	<a href="#">9043010M1100</a> Gasket	<a href="#">Buy now</a>
15	<a href="#">68T153160000</a> Damper, engine mount 1	<a href="#">Buy now</a>




# Oil Pan




Ref	Part	
16	<a href="#">68T153170000</a> Spacer, engine mount	<a href="#">Buy now</a>
17	<a href="#">978850500800</a> Screw, pan head	<a href="#">Buy now</a>
18	<a href="#">68T134750000</a> Gasket	<a href="#">Buy now</a>
19	<a href="#">9360410M0300</a> Pin, dowel (688)	<a href="#">Buy now</a>
20	<a href="#">901190800500</a> Bolt, with washer	<a href="#">Buy now</a>
21	<a href="#">970750803000</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
22	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>
23	<a href="#">68T153620000</a> Plug, oil level	<a href="#">Buy now</a>

# Oil Pump




Ref	Part	
1	<a href="#">9310218M2100</a> Oil seal (6g8)	<a href="#">Buy now</a>
2	<a href="#">68T121710000</a> Camshaft 1	<a href="#">Buy now</a>
3	<a href="#">66M115370094</a> Gear, driven	<a href="#">Buy now</a>
4	<a href="#">970140601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
5	<a href="#">902011320100</a> Washer 6474283300	<a href="#">Buy now</a>
6	<a href="#">9020106M9400</a> Washer (6g8)	<a href="#">Buy now</a>
7	<a href="#">68T462410000</a> Belt	<a href="#">Buy now</a>
8	<a href="#">68T115360000</a> Gear, drive	<a href="#">Buy now</a>
9	<a href="#">68T115570000</a> Washer 1	<a href="#">Buy now</a>
10	<a href="#">6G8115870100</a> Washer, lock	<a href="#">Buy now</a>
11	<a href="#">9017024M0900</a> Nut (6g8)	<a href="#">Buy now</a>
12	<a href="#">9028003M0100</a> Key woodruff 146115450000	<a href="#">Buy now</a>
13	<a href="#">68T462970000</a> Cover, dust	<a href="#">Buy now</a>
14	<a href="#">904801062700</a> Grommet	<a href="#">Buy now</a>
15	<a href="#">68T133000000</a> Oil pump assembly	<a href="#">Buy now</a>

Oil Pump




Ref	Part	
16	<a href="#">68T133290000</a> Gasket, pump cover	<a href="#">Buy now</a>
17	<a href="#">970950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
18	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>

## Remo Con Attachment




Ref	Part	
1	<a href="#">68R485010000</a> Remote cont. attachment assembly.	<a href="#">Buy now</a>
2	<a href="#">68T485310000</a> Bracket, remote control 1	<a href="#">Buy now</a>
3	<a href="#">682485385000</a> Clamp, cable	<a href="#">Buy now</a>
4	<a href="#">916903001200</a> Pin, spring	<a href="#">Buy now</a>
5	<a href="#">970800601200</a> Bolt(gh1)	<a href="#">Buy now</a>
6	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
7	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
8	<a href="#">6AU441111000</a> Handle, gear shift	<a href="#">Buy now</a>
9	<a href="#">932101232700</a> O-ring(3ld)	<a href="#">Buy now</a>
10	<a href="#">970950501600</a> Bolt(6a1)	<a href="#">Buy now</a>
11	<a href="#">929950560000</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">6FM483440000</a> Cable end, remote control	<a href="#">Buy now</a>
13	<a href="#">904681800800</a> Clip 620436610000	<a href="#">Buy now</a>
14	<a href="#">663483440000</a> Cable end, remote control	<a href="#">Buy now</a>
16	<a href="#">68T427251000</a> Grommet	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
1	<a href="#">6AUW00010000</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310218M2100</a> Oil seal (6g8)	<a href="#">Buy now</a>
3	<a href="#">68T111810000</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
4	<a href="#">68T113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
5	<a href="#">68T11169A000</a> Gasket, breather cover	<a href="#">Buy now</a>
6	<a href="#">9321013M6300</a> O-ring (6g8)	<a href="#">Buy now</a>
7	<a href="#">9310230M2200</a> Oil seal (6g8)	<a href="#">Buy now</a>
8	<a href="#">9310125M6900</a> Oil seal	<a href="#">Buy now</a>
9	<a href="#">68T113510000</a> Gasket, cylinder	<a href="#">Buy now</a>
10	<a href="#">6G812414A000</a> Gasket, cover	<a href="#">Buy now</a>
11	<a href="#">68T41114A000</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
12	<a href="#">902800301700</a> Key woodruff 146115450000	<a href="#">Buy now</a>
13	<a href="#">68T136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
14	<a href="#">68T13646A000</a> Gasket, manifold 2	<a href="#">Buy now</a>
15	<a href="#">9321031MJ500</a> O-ring	<a href="#">Buy now</a>

## Repair Kit 1



Ref	Part	
16	<a href="#">68T133290000</a> Gasket, pump cover	<a href="#">Buy now</a>
17	<a href="#">932102480000</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">9321020M6500</a> O-ring	<a href="#">Buy now</a>

## Repair Kit 2




**FWD**  
68R0100-0260

Ref	Part	
1	<a href="#">68TW00930000</a> Carburetor repair kit	<a href="#">Buy now</a>
2	<a href="#">68T143850000</a> Float	<a href="#">Buy now</a>
3	<a href="#">67D143860000</a> Pin, float	<a href="#">Buy now</a>
4	<a href="#">68T145460000</a> Valve, needle	<a href="#">Buy now</a>
5	<a href="#">67D149840000</a> Gasket, float chamber	<a href="#">Buy now</a>
6	<a href="#">6J8149950000</a> Gasket, drain screw	<a href="#">Buy now</a>
7	<a href="#">979800411200</a> Screw, pan head (686)	<a href="#">Buy now</a>
8	<a href="#">67D145360000</a> Gasket	<a href="#">Buy now</a>




## Repair Kit 3



Ref	Part	
1	<a href="#">68TW00012000</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">9310112M7000</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">9043010M1100</a> Gasket	<a href="#">Buy now</a>
4	<a href="#">68T134750000</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
6	<a href="#">931011507400</a> Oil seal (655)	<a href="#">Buy now</a>
7	<a href="#">932104904600</a> O-ring (620)	<a href="#">Buy now</a>
8	<a href="#">9321053M0800</a> O-ring(50m)	<a href="#">Buy now</a>
9	<a href="#">932104439800</a> O-ring(55x)	<a href="#">Buy now</a>
10	<a href="#">9310111M2300</a> Oil seal (6g1)	<a href="#">Buy now</a>
11	<a href="#">68T45315A000</a> Packing, lower casing	<a href="#">Buy now</a>
12	<a href="#">9321006ME600</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">68TW00780000</a> Water pump repair kit	<a href="#">Buy now</a>
14	<a href="#">63V443220000</a> Insert, cartridge	<a href="#">Buy now</a>
15	<a href="#">68T443660000</a> Damper, water seal 2	<a href="#">Buy now</a>




## Repair Kit 3




Ref	Part	
16	<a href="#">68T443520000</a> Impeller	<a href="#">Buy now</a>
17	<a href="#">664443380000</a> Key, woodruff	<a href="#">Buy now</a>
19	<a href="#">68T443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
20	<a href="#">970800804500</a> Bolt, hexagon	<a href="#">Buy now</a>

# Starter




Ref	Part	
1	<a href="#">68T157100100</a> Starter assembly	<a href="#">Buy now</a>
2	<a href="#">68T157110100</a> Case, Starter	<a href="#">Buy now</a>
3	<a href="#">67D157640000</a> Collar 1	<a href="#">Buy now</a>
4	<a href="#">68T157950000</a> Guide, rope	<a href="#">Buy now</a>
5	<a href="#">63V157140000</a> Drum, sheave	<a href="#">Buy now</a>
6	<a href="#">63V157410000</a> Pawl, drive	<a href="#">Buy now</a>
7	<a href="#">63V157130000</a> Spring, starter	<a href="#">Buy now</a>
8	<a href="#">68T157160000</a> Plate, drive	<a href="#">Buy now</a>
9	<a href="#">63V157050100</a> Spring, drive pawl	<a href="#">Buy now</a>
10	<a href="#">63V157670100</a> Spring	<a href="#">Buy now</a>
11	<a href="#">68T157840000</a> Spring, return	<a href="#">Buy now</a>
12	<a href="#">63V157440000</a> Circlip	<a href="#">Buy now</a>
13	<a href="#">68T157930000</a> Screw	<a href="#">Buy now</a>
14	<a href="#">68T157640000</a> Collar 1	<a href="#">Buy now</a>
15	<a href="#">6G1157550000</a> Handle, starter	<a href="#">Buy now</a>

# Starter




Ref	Part	
16	<a href="#">63V157510000</a> Starter rope (5x50000mm)	<a href="#">Buy now</a>
17	<a href="#">6G1157790000</a> Cover	<a href="#">Buy now</a>
18	<a href="#">6A0157890000</a> Damper	<a href="#">Buy now</a>
19	<a href="#">66T157940000</a> Stopper	<a href="#">Buy now</a>
20	<a href="#">66T157340000</a> Spring, return	<a href="#">Buy now</a>
21	<a href="#">68T157700000</a> Cable comp., starter stop	<a href="#">Buy now</a>
22	<a href="#">66T157310000</a> Retainer, spring	<a href="#">Buy now</a>
23	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
24	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
25	<a href="#">68T157620000</a> Seal, rubber 2	<a href="#">Buy now</a>
26	<a href="#">68T157740000</a> Stay 4	<a href="#">Buy now</a>
27	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>

# Steering




Ref	Part	
1	<a href="#">68TW0084104D</a> Handle steering assembly	<a href="#">Buy now</a>
2	<a href="#">66R42101014D</a> Handle, steering	<a href="#">Buy now</a>
3	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
4	<a href="#">9010906M8000</a> Bolt	<a href="#">Buy now</a>
7	<a href="#">68T421380100</a> Lever, throttle	<a href="#">Buy now</a>
8	<a href="#">65W421590000</a> Stay	<a href="#">Buy now</a>
9	<a href="#">6G1421260000</a> Piece, friction	<a href="#">Buy now</a>
10	<a href="#">65W421250000</a> Bolt, friction adjusting	<a href="#">Buy now</a>
11	<a href="#">914901601000</a> Pin, cotter	<a href="#">Buy now</a>
12	<a href="#">67D421770000</a> Rubber, handle	<a href="#">Buy now</a>
13	<a href="#">67D421190000</a> Grip, steering handle	<a href="#">Buy now</a>
14	<a href="#">60NG21370000</a> Indicator Throttle	<a href="#">Buy now</a>
15	<a href="#">9026902M0900</a> Rivet(6l5)	<a href="#">Buy now</a>
16	<a href="#">9014905M1300</a> Screw, countersunk	<a href="#">Buy now</a>
17	<a href="#">9020110M0200</a> Washer, plate(6g9)	<a href="#">Buy now</a>

# Steering



Ref	Part	
18	<a href="#">905012321500</a> Spring (655)	<a href="#">Buy now</a>
19	<a href="#">903860803200</a> Bushing (650)	<a href="#">Buy now</a>
20	<a href="#">68T263011100</a> Throttle cable assembly	<a href="#">Buy now</a>
21	<a href="#">904470700500</a> Hose, with spring	<a href="#">Buy now</a>
22	<a href="#">66R421710000</a> Bushing	<a href="#">Buy now</a>
23	<a href="#">9020143M0000</a> Washer, plate	<a href="#">Buy now</a>
24	<a href="#">9020643M2200</a> Washer, wave	<a href="#">Buy now</a>
25	<a href="#">9020243M5700</a> Washer, plate	<a href="#">Buy now</a>
26	<a href="#">9038640M9900</a> Bush	<a href="#">Buy now</a>
27	<a href="#">66M421310100</a> Cover, handle steering	<a href="#">Buy now</a>
28	<a href="#">957801030000</a> Nut, nylon (6e5)	<a href="#">Buy now</a>
29	<a href="#">953801070000</a> Nut (682)	<a href="#">Buy now</a>
30	<a href="#">66R44111004D</a> Handle, gear shift	<a href="#">Buy now</a>
31	<a href="#">66R441730000</a> Lever, shift control	<a href="#">Buy now</a>
32	<a href="#">9015906M1800</a> Screw, with washer(6b0)	<a href="#">Buy now</a>


# Steering



Ref	Part	
33	<a href="#">66R421290000</a> Bushing, rubber	<a href="#">Buy now</a>
34	<a href="#">970950803000</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
35	<a href="#">929900860000</a> Washer, plain (663)	<a href="#">Buy now</a>
36	<a href="#">9038626MA300</a> Bush	<a href="#">Buy now</a>
37	<a href="#">9020626M2500</a> Washer, wave	<a href="#">Buy now</a>
38	<a href="#">9020226M5900</a> Washer, plate	<a href="#">Buy now</a>
39	<a href="#">68T441130100</a> Cam plate, handle	<a href="#">Buy now</a>
40	<a href="#">66R441160000</a> Spring	<a href="#">Buy now</a>
41	<a href="#">66R441180000</a> Bracket	<a href="#">Buy now</a>
42	<a href="#">66R485380000</a> Clamp, cable 1	<a href="#">Buy now</a>
43	<a href="#">63D485380000</a> Clamp, cable 1	<a href="#">Buy now</a>
44	<a href="#">68T483210000</a> Cable	<a href="#">Buy now</a>
45	<a href="#">990800460000</a> Circlip (eu0)	<a href="#">Buy now</a>
46	<a href="#">66R441140000</a> Stopper	<a href="#">Buy now</a>
47	<a href="#">6E0441911100</a> Indicator, shift	<a href="#">Buy now</a>




# Steering



Ref	Part	
48	<a href="#">66R483440000</a> Cable end, remote control	<a href="#">Buy now</a>
49	<a href="#">9020106M6200</a> Washer, plate (6e5)	<a href="#">Buy now</a>
50	<a href="#">9017005M3800</a> Nut	<a href="#">Buy now</a>
51	<a href="#">914902001200</a> Pin, cotter (648)	<a href="#">Buy now</a>
52	<a href="#">68T42121104D</a> Bracket	<a href="#">Buy now</a>
53	<a href="#">9011610M2800</a> Bolt, stud	<a href="#">Buy now</a>




# Steering Friction



  
68R0100-1170


Ref	Part	
1	<a href="#">68T425080000</a> Steering friction assembly	<a href="#">Buy now</a>
2	<a href="#">68T425250100</a> Plate, friction	<a href="#">Buy now</a>
3	<a href="#">970950502000</a> Bolt, hexagon	<a href="#">Buy now</a>
4	<a href="#">929950560000</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">67C425620000</a> Shaft, steering lock	<a href="#">Buy now</a>
6	<a href="#">9020210M5600</a> Washer, plate	<a href="#">Buy now</a>
7	<a href="#">68T425610000</a> Knob, steering lock	<a href="#">Buy now</a>
8	<a href="#">689436330000</a> Cover, tilt lever	<a href="#">Buy now</a>
9	<a href="#">65W425280000</a> Plate, friction	<a href="#">Buy now</a>
10	<a href="#">903870505300</a> Collar	<a href="#">Buy now</a>
11	<a href="#">9038705M1100</a> Collar	<a href="#">Buy now</a>
14	<a href="#">9020910M2600</a> Washer	<a href="#">Buy now</a>
15	<a href="#">9018510M1400</a> Nut, self-locking	<a href="#">Buy now</a>
16	<a href="#">68T425270000</a> Plate, friction	<a href="#">Buy now</a>
17	<a href="#">9010908M9100</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>

## Top Cowling



Ref	Part	
1	<a href="#">68R42610104D</a> Top Cowling assembly	<a href="#">Buy now</a>
2	<a href="#">68T426130000</a> Molding Air Duct	<a href="#">Buy now</a>
3	<a href="#">977806051600</a> Screw, panhead tapping (j20)	<a href="#">Buy now</a>
4	<a href="#">6G1426510200</a> Hook	<a href="#">Buy now</a>
5	<a href="#">9026604M0400</a> Rivet(6e7)	<a href="#">Buy now</a>
6	<a href="#">68T426150000</a> Seal	<a href="#">Buy now</a>
7	<a href="#">68T426520000</a> Hook	<a href="#">Buy now</a>
8	<a href="#">970950501600</a> Bolt(6a1)	<a href="#">Buy now</a>
9	<a href="#">929950560000</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">68T426490000</a> Holder, clamp band	<a href="#">Buy now</a>
11	<a href="#">68R426781000</a> Graphic, rear	<a href="#">Buy now</a>
12	<a href="#">68TW00701000</a> Graphic Set	<a href="#">Buy now</a>


## Upper Casing



68R0010-0220

Ref	Part	
1	<a href="#">68T45111004D</a> Casing upper	<a href="#">Buy now</a>
2	<a href="#">60RE4711005B</a> Muffler 1	<a href="#">Buy now</a>
3	<a href="#">975750651400</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
4	<a href="#">9048014M5400</a> Grommet	<a href="#">Buy now</a>
5	<a href="#">68T453210000</a> Plate	<a href="#">Buy now</a>
6	<a href="#">970800600800</a> Bolt (fj1)	<a href="#">Buy now</a>
7	<a href="#">978850500800</a> Screw, pan head	<a href="#">Buy now</a>
8	<a href="#">9360412M0700</a> Pin, dowel (688)	<a href="#">Buy now</a>
9	<a href="#">970750803500</a> Bolt(70w)	<a href="#">Buy now</a>
10	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>

# Valve



Ref	Part	
1	<a href="#">67D121110000</a> Valve, intake	<a href="#">Buy now</a>
2	<a href="#">67D121210000</a> Valve, exhaust	<a href="#">Buy now</a>
3	<a href="#">6EEE21160000</a> Seat, valve spring	<a href="#">Buy now</a>
4	<a href="#">68T121130000</a> Spring, valve inne	<a href="#">Buy now</a>
5	<a href="#">7NJ121170000</a> Retainer, valve spring	<a href="#">Buy now</a>
6	<a href="#">7CNE21180000</a> Cotter, valve	<a href="#">Buy now</a>
7	<a href="#">6EEE21190000</a> Seal, valve stem	<a href="#">Buy now</a>
8	<a href="#">68T121460000</a> Shaft, rocker	<a href="#">Buy now</a>
9	<a href="#">9038713M5600</a> Collar (6g8)	<a href="#">Buy now</a>
10	<a href="#">9038714M0300</a> Collar	<a href="#">Buy now</a>
11	<a href="#">9050112M4000</a> Spring, compression (6g8)	<a href="#">Buy now</a>
12	<a href="#">68T121510000</a> Arm, valve rocker	<a href="#">Buy now</a>
13	<a href="#">6G8121590000</a> Screw, valve adjusting	<a href="#">Buy now</a>
14	<a href="#">6G8121580000</a> Nut, lock	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.