



# Yamaha F6CMH 2010

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

|                                   |    |
|-----------------------------------|----|
| <b>BOTTOM COWLING</b>             | 3  |
| <b>BRACKET</b>                    | 4  |
| <b>CARBURETOR</b>                 | 7  |
| <b>CONTROL</b>                    | 9  |
| <b>CRANKSHAFT &amp; PISTON</b>    | 11 |
| <b>CYLINDER &amp; CRANKCASE 1</b> | 12 |
| <b>CYLINDER &amp; CRANKCASE 2</b> | 14 |
| <b>ELECTRICAL</b>                 | 17 |
| <b>FUEL 1</b>                     | 18 |
| <b>FUEL 2</b>                     | 19 |
| <b>GENERATOR</b>                  | 23 |
| <b>INTAKE</b>                     | 24 |
| <b>LOWER CASING &amp; DRIVE 1</b> | 26 |
| <b>LOWER CASING &amp; DRIVE 2</b> | 29 |
| <b>OPTIONAL PARTS</b>             | 31 |
| <b>REPAIR KIT 1</b>               | 32 |
| <b>REPAIR KIT 2</b>               | 34 |
| <b>REPAIR KIT 3</b>               | 35 |
| <b>STARTER</b>                    | 36 |
| <b>STEERING</b>                   | 39 |
| <b>TOP COWLING</b>                | 42 |
| <b>UPPER CASING</b>               | 45 |
| <b>VALVE</b>                      | 46 |


## Bottom Cowling



  
 6BV1100J1301

| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXG2711004D</a><br>Cowling, bottom 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">68F8511900</a><br>Bolt                | <a href="#">Buy now</a> |
| 3   | <a href="#">9048021M82</a><br>Grommet             | <a href="#">Buy now</a> |
| 4   | <a href="#">9038706176</a><br>Collar              | <a href="#">Buy now</a> |
| 5   | <a href="#">9048014M14</a><br>Grommet (6e0)       | <a href="#">Buy now</a> |
| 7   | <a href="#">68T4280100</a><br>Cowling clamp comp. | <a href="#">Buy now</a> |
| 8   | <a href="#">9709506012</a><br>Bolt(gh1)           | <a href="#">Buy now</a> |
| 9   | <a href="#">9299506600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 10  | <a href="#">6BXG273100</a><br>Carrying handle     | <a href="#">Buy now</a> |
| 11  | <a href="#">9709508020</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 12  | <a href="#">9299508600</a><br>Washer, plain (663) | <a href="#">Buy now</a> |
| 13  | <a href="#">9538008600</a><br>Nut (661)           | <a href="#">Buy now</a> |
| 14  | <a href="#">9048022M72</a><br>Grommet             | <a href="#">Buy now</a> |
| 15  | <a href="#">6AH4279450</a><br>Label, warning (ge  | <a href="#">Buy now</a> |


# Bracket



6BV1110-J160

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 1   | <a href="#">6L8G3111014D</a><br>Bracket, clamp 1   | <a href="#">Buy now</a> |
| 2   | <a href="#">6L8G3112004D</a><br>Bracket, clamp 2   | <a href="#">Buy now</a> |
| 3   | <a href="#">6204311400</a><br>Pad, transom clamp   | <a href="#">Buy now</a> |
| 4   | <a href="#">6E04311601</a><br>Screw, transom clamp | <a href="#">Buy now</a> |
| 5   | <a href="#">6L8G311801</a><br>Handle, transom cl   | <a href="#">Buy now</a> |
| 6   | <a href="#">9024304M01</a><br>Pin(6a1)             | <a href="#">Buy now</a> |
| 7   | <a href="#">9010108M07</a><br>Bolt(6e0)            | <a href="#">Buy now</a> |
| 8   | <a href="#">9020208M58</a><br>Washer, plate        | <a href="#">Buy now</a> |
| 9   | <a href="#">68DG311300</a><br>Plate, clamp bracket | <a href="#">Buy now</a> |
| 10  | <a href="#">9018508057</a><br>Nut, nylon (6j8)     | <a href="#">Buy now</a> |
| 11  | <a href="#">9038706M11</a><br>Collar               | <a href="#">Buy now</a> |
| 12  | <a href="#">9010106335</a><br>Bolt, hexagon (624)  | <a href="#">Buy now</a> |
| 13  | <a href="#">9299006600</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |
| 14  | <a href="#">9538006600</a><br>Nut(661)             | <a href="#">Buy now</a> |
| 15  | <a href="#">68DG3311014D</a><br>Bracket, swivel 1  | <a href="#">Buy now</a> |


# Bracket



6BV1110-J160

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">68DG3312014D</a><br>Bracket, swivel 2  | <a href="#">Buy now</a> |
| 17  | <a href="#">9589506035</a><br>Bolt, flange(4nx)    | <a href="#">Buy now</a> |
| 18  | <a href="#">6BX4318100</a><br>Lever, tilt stop 1   | <a href="#">Buy now</a> |
| 19  | <a href="#">6E04363200</a><br>Knob, tilt           | <a href="#">Buy now</a> |
| 20  | <a href="#">6E0433130094</a><br>Bracket, swivel 3  | <a href="#">Buy now</a> |
| 21  | <a href="#">6204318900</a><br>Bushing              | <a href="#">Buy now</a> |
| 22  | <a href="#">9589506020</a><br>Bolt, flange(jk3)    | <a href="#">Buy now</a> |
| 23  | <a href="#">6BX4856100</a><br>Spring 1             | <a href="#">Buy now</a> |
| 24  | <a href="#">6BXG331900</a><br>Plate                | <a href="#">Buy now</a> |
| 25  | <a href="#">68DG316000</a><br>Tilt rod assembly    | <a href="#">Buy now</a> |
| 26  | <a href="#">6N0G316500</a><br>Plate, tilt lock     | <a href="#">Buy now</a> |
| 27  | <a href="#">9169030008</a><br>Pin. spring(656)     | <a href="#">Buy now</a> |
| 28  | <a href="#">9050208M05</a><br>Spring, conical(6e0) | <a href="#">Buy now</a> |
| 29  | <a href="#">6BX4361400</a><br>Plate, tilt lock     | <a href="#">Buy now</a> |
| 30  | <a href="#">6BX4318800</a><br>Spring               | <a href="#">Buy now</a> |


# Bracket



6BV1110-J160


| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 31  | <a href="#">6BX4319800</a><br>Spring 2              | <a href="#">Buy now</a> |
| 32  | <a href="#">9010906M84</a><br>Bolt                  | <a href="#">Buy now</a> |
| 33  | <a href="#">68DG253700</a><br>Bushing, pivot sha    | <a href="#">Buy now</a> |
| 34  | <a href="#">68DG253900</a><br>Bushing, pivot sha    | <a href="#">Buy now</a> |
| 35  | <a href="#">6BXG253800</a><br>Bushing, pivot sha    | <a href="#">Buy now</a> |
| 36  | <a href="#">6BXG254900</a><br>Bushing, pivot sha    | <a href="#">Buy now</a> |
| 37  | <a href="#">6E04252803</a><br>Plate, friction       | <a href="#">Buy now</a> |
| 38  | <a href="#">6L54252901</a><br>Screw, friction piece | <a href="#">Buy now</a> |
| 39  | <a href="#">68DG256101</a><br>Knob, steering loc    | <a href="#">Buy now</a> |
| 40  | <a href="#">9026604M05</a><br>Rivet(6I5)            | <a href="#">Buy now</a> |
| 41  | <a href="#">6BXF459100</a><br>Emblem, fuel cock     | <a href="#">Buy now</a> |

# Carburetor




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">6BV1430101</a><br>Carburetor assembly 1 | <a href="#">Buy now</a> |
| 1   | <a href="#">6BW1430100</a><br>Carburetor assembly 1 | <a href="#">Buy now</a> |
| 1   | <a href="#">6BX1430100</a><br>Carburetor assembly 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX1498500</a><br>Float                 | <a href="#">Buy now</a> |
| 3   | <a href="#">6BX1498000</a><br>Body, float chamber   | <a href="#">Buy now</a> |
| 4   | <a href="#">6BX1498400</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 5   | <a href="#">6BV1494700</a><br>Jet, needle           | <a href="#">Buy now</a> |
| 5   | <a href="#">6BW1494700</a><br>Jet, needle           | <a href="#">Buy now</a> |
| 5   | <a href="#">6BX1494700</a><br>Jet, needle           | <a href="#">Buy now</a> |
| 6   | <a href="#">6BW1492320</a><br>Screw, pilot          | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX1492320</a><br>Screw, pilot          | <a href="#">Buy now</a> |
| 7   | <a href="#">6BX1452300</a><br>Screw, stop           | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX1455500</a><br>Spring                | <a href="#">Buy now</a> |
| 9   | <a href="#">6BX1493500</a><br>Spring                | <a href="#">Buy now</a> |
| 10  | <a href="#">6BX1499100</a><br>Screw                 | <a href="#">Buy now</a> |

# Carburetor




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 11  | <a href="#">6BX1459200</a><br>Screw                 | <a href="#">Buy now</a> |
| 12  | <a href="#">4JH1456200</a><br>O-ring                | <a href="#">Buy now</a> |
| 13  | <a href="#">6BX1454600</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 14  | <a href="#">6BX1454800</a><br>Pin, float arm        | <a href="#">Buy now</a> |
| 15  | <a href="#">6BX1493700</a><br>Clip                  | <a href="#">Buy now</a> |
| 16  | <a href="#">6BV1494311</a><br>Jet, main (#60)       | <a href="#">Buy now</a> |
| 16  | <a href="#">6BW1494315</a><br>Jet, main (#70)       | <a href="#">Buy now</a> |
| 16  | <a href="#">6BX1494317</a><br>Jet, main (#75)       | <a href="#">Buy now</a> |
| 17  | <a href="#">6BV1494801</a><br>Jet (#35)             | <a href="#">Buy now</a> |
| 17  | <a href="#">6BX1494804</a><br>Jet (#42)             | <a href="#">Buy now</a> |
| 18  | <a href="#">6BX1455600</a><br>Spring                | <a href="#">Buy now</a> |
| 19  | <a href="#">9858004006</a><br>Screw, pan head (7h3) | <a href="#">Buy now</a> |

## Control



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXG411100</a><br>Handle, gear shift       | <a href="#">Buy now</a> |
| 2   | <a href="#">6BXG367900</a><br>Cover                    | <a href="#">Buy now</a> |
| 3   | <a href="#">9010508046</a><br>Bolt, flange             | <a href="#">Buy now</a> |
| 4   | <a href="#">6BXG411900CA</a><br>Shaft, change          | <a href="#">Buy now</a> |
| 5   | <a href="#">6BXG412200</a><br>Bushing, shift rod lever | <a href="#">Buy now</a> |
| 6   | <a href="#">9321009350</a><br>O-ring                   | <a href="#">Buy now</a> |
| 7   | <a href="#">9050112802</a><br>Spring,compression       | <a href="#">Buy now</a> |
| 8   | <a href="#">9350516024</a><br>Ball                     | <a href="#">Buy now</a> |
| 9   | <a href="#">6BXG412100</a><br>Lever, shift rod         | <a href="#">Buy now</a> |
| 10  | <a href="#">9038706504</a><br>Collar(650)              | <a href="#">Buy now</a> |
| 11  | <a href="#">9011905M04</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 12  | <a href="#">6BX4414300</a><br>Rod, shift               | <a href="#">Buy now</a> |
| 13  | <a href="#">9299005600</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 14  | <a href="#">9149016010</a><br>Pin, cotter              | <a href="#">Buy now</a> |
| 15  | <a href="#">68DG414500</a><br>Connector, shift rod 1   | <a href="#">Buy now</a> |


## Control



6BV1100-J150

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">68DG414600</a><br>Connector, shift rod 2 | <a href="#">Buy now</a> |
| 17  | <a href="#">9011906256</a><br>Bolt, with washer      | <a href="#">Buy now</a> |


# Crankshaft & Piston



  
6BV1100-J030


| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXE141000</a><br>Crankshaft                     | <a href="#">Buy now</a> |
| 2   | <a href="#">90201266P2</a><br>Washer, plate(ja8)             | <a href="#">Buy now</a> |
| 3   | <a href="#">6BX1165000</a><br>Connecting rod ass             | <a href="#">Buy now</a> |
| 4   | <a href="#">67D1165400</a><br>Bolt, connecting rod           | <a href="#">Buy now</a> |
| 5   | <a href="#">6BXE16310096</a><br>Piston (std)                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6BXE163500</a><br>Pisron (0,25mm o/s)<br>AP      | <a href="#">Buy now</a> |
| 5   | <a href="#">6BXE163600</a><br>Piston (0.50mm o/s)<br>AP      | <a href="#">Buy now</a> |
| 6   | <a href="#">6BXE160300</a><br>Piston ring set (s             | <a href="#">Buy now</a> |
| 6   | <a href="#">6BXE160400</a><br>Piston ring set (0,25mm)<br>AP | <a href="#">Buy now</a> |
| 6   | <a href="#">6BXE160500</a><br>Piston Ring Set (0 50Mm)<br>AP | <a href="#">Buy now</a> |
| 7   | <a href="#">6BX1163300</a><br>Pin, piston                    | <a href="#">Buy now</a> |
| 8   | <a href="#">9345016068</a><br>Circlip (4g0)                  | <a href="#">Buy now</a> |

# Cylinder & Crankcase 1



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXWE090001S</a><br>Crank cylinder ass           | <a href="#">Buy now</a> |
| 2   | <a href="#">6BXE1111001S</a><br>Head, cylinder with ex valve | <a href="#">Buy now</a> |
| 3   | <a href="#">67D1113310</a><br>Guide, valve 1                 | <a href="#">Buy now</a> |
| 4   | <a href="#">9010508M36</a><br>Bolt (6g8)                     | <a href="#">Buy now</a> |
| 5   | <a href="#">9951010114</a><br>Pin, dowel(3vd)                | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX1118100</a><br>Gasket, cylinder head 1        | <a href="#">Buy now</a> |
| 7   | <a href="#">6BXE1191005B</a><br>Cover, cylinder he           | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX1135600</a><br>Seal, cylinder 2               | <a href="#">Buy now</a> |
| 9   | <a href="#">9709506020</a><br>Bolt(7u8)                      | <a href="#">Buy now</a> |
| 10  | <a href="#">9299506600</a><br>Washer, plain (646)            | <a href="#">Buy now</a> |
| 11  | <a href="#">66M1241101</a><br>Thermostat                     | <a href="#">Buy now</a> |
| 12  | <a href="#">6881241200</a><br>Seal, thermostat               | <a href="#">Buy now</a> |
| 13  | <a href="#">68DE2413001S</a><br>Cover, thermostat            | <a href="#">Buy now</a> |
| 14  | <a href="#">6502437800</a><br>Pipe, joint 2                  | <a href="#">Buy now</a> |
| 15  | <a href="#">68DE132500</a><br>Anode                          | <a href="#">Buy now</a> |


# Cylinder & Crankcase 1



6BV1100-J020


| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">9788005025</a><br>Screw, panhead (a93) | <a href="#">Buy now</a> |
| 17  | <a href="#">68DE2414A0</a><br>Gasket, cover        | <a href="#">Buy now</a> |
| 20  | <a href="#">6BXF432300</a><br>Pipe 12              | <a href="#">Buy now</a> |
| 21  | <a href="#">9046409021</a><br>Clamp                | <a href="#">Buy now</a> |
| 22  | <a href="#">9046506M86</a><br>Clamp                | <a href="#">Buy now</a> |
| 24  | <a href="#">9046508371</a><br>Clamp(4km)           | <a href="#">Buy now</a> |
| 25  | <a href="#">6G08251900</a><br>Wire, earth lead     | <a href="#">Buy now</a> |
| 26  | <a href="#">9470200372</a><br>Plug, spark (cr6hsb) | <a href="#">Buy now</a> |

## Cylinder & Crankcase 2




| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXE1311001S</a><br>Cylinder 1        | <a href="#">Buy now</a> |
| 2   | <a href="#">6E92437800</a><br>Pipe, Joint 4       | <a href="#">Buy now</a> |
| 3   | <a href="#">3Y61536100</a><br>Gauge, level        | <a href="#">Buy now</a> |
| 4   | <a href="#">9310225022</a><br>Oil seal            | <a href="#">Buy now</a> |
| 5   | <a href="#">93306205B2</a><br>Bearing             | <a href="#">Buy now</a> |
| 6   | <a href="#">6BXE116800</a><br>Cover, breather     | <a href="#">Buy now</a> |
| 7   | <a href="#">9701305010</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX1135100</a><br>Gasket, cylinder    | <a href="#">Buy now</a> |
| 9   | <a href="#">9951010114</a><br>Pin, dowel(3vd)     | <a href="#">Buy now</a> |
| 10  | <a href="#">6BXE5111001S</a><br>Crankcase 1       | <a href="#">Buy now</a> |
| 11  | <a href="#">6502437800</a><br>Pipe, joint 2       | <a href="#">Buy now</a> |
| 12  | <a href="#">6761137200</a><br>Nipple, hose        | <a href="#">Buy now</a> |
| 13  | <a href="#">9701306050</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 14  | <a href="#">9290306600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 15  | <a href="#">68DE5396005B</a><br>Housing, oil seal | <a href="#">Buy now</a> |

## Cylinder & Crankcase 2





| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">9321035537</a><br>O-ring                    | <a href="#">Buy now</a> |
| 17  | <a href="#">9310220108</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 18  | <a href="#">9310210004</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 19  | <a href="#">9709508020</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 20  | <a href="#">9299508600</a><br>Washer, plain (663)       | <a href="#">Buy now</a> |
| 21  | <a href="#">9709508014</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 22  | <a href="#">9043008800</a><br>Gasket (256-11198-00)     | <a href="#">Buy now</a> |
| 25  | <a href="#">6BXE331000</a><br>Rotor assembly            | <a href="#">Buy now</a> |
| 26  | <a href="#">6BXE331600</a><br>Cover, pump               | <a href="#">Buy now</a> |
| 27  | <a href="#">9851706012</a><br>Screw, pan                | <a href="#">Buy now</a> |
| 28  | <a href="#">51Y1341100</a><br>Strainer, oil             | <a href="#">Buy now</a> |
| 29  | <a href="#">9050118576</a><br>Spring, compression (3y1) | <a href="#">Buy now</a> |
| 30  | <a href="#">6BXE347500</a><br>Gasket                    | <a href="#">Buy now</a> |
| 31  | <a href="#">6BXE3417001S</a><br>Cover, strainer         | <a href="#">Buy now</a> |
| 32  | <a href="#">9010508M76</a><br>Bolt, washer based        | <a href="#">Buy now</a> |

## Cylinder & Crankcase 2




| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 33  | <a href="#">9020108818</a><br>Washer              | <a href="#">Buy now</a> |
| 34  | <a href="#">9709506035</a><br>Bolt(j52)           | <a href="#">Buy now</a> |
| 35  | <a href="#">9299506600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 36  | <a href="#">9321024M79</a><br>O-ring              | <a href="#">Buy now</a> |
| 37  | <a href="#">68DE536200</a><br>Plug, oil level     | <a href="#">Buy now</a> |



6BV1100-J120


| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 1   | <a href="#">6BX8257500</a><br>Engine stop switch   | <a href="#">Buy now</a> |
| 2   | <a href="#">6828255600</a><br>Lanyard, stop switch | <a href="#">Buy now</a> |
| 3   | <a href="#">6898257Y00</a><br>Cap                  | <a href="#">Buy now</a> |
| 4   | <a href="#">9709506012</a><br>Bolt(gh1)            | <a href="#">Buy now</a> |
| 5   | <a href="#">9299506600</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX8253100</a><br>Wire, lead           | <a href="#">Buy now</a> |
| 7   | <a href="#">9046513M97</a><br>Clamp                | <a href="#">Buy now</a> |

# Fuel 1




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXF411100</a><br>Tank, fuel            | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX2461000</a><br>Cap assembly          | <a href="#">Buy now</a> |
| 3   | <a href="#">6BX2464100</a><br>Gasket, cap 1         | <a href="#">Buy now</a> |
| 4   | <a href="#">6A08231700</a><br>Damper, ignition coil | <a href="#">Buy now</a> |
| 5   | <a href="#">9038706119</a><br>Collar                | <a href="#">Buy now</a> |
| 6   | <a href="#">9048001559</a><br>Grommet(4bh)          | <a href="#">Buy now</a> |
| 7   | <a href="#">6BX2416700</a><br>Strainer              | <a href="#">Buy now</a> |
| 8   | <a href="#">6BXF431100</a><br>Pipe, fuel 1          | <a href="#">Buy now</a> |
| 9   | <a href="#">9046709M09</a><br>Clip(6k8)             | <a href="#">Buy now</a> |

## Fuel 2




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6G12430402</a><br>Fuel pipe joint comp. 1 | <a href="#">Buy now</a> |
| 2   | <a href="#">60RF432900</a><br>Seal                    | <a href="#">Buy now</a> |
| 3   | <a href="#">9709506025</a><br>Bolt                    | <a href="#">Buy now</a> |
| 4   | <a href="#">9299506600</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 5   | <a href="#">6BX2476U00</a><br>Protector,1             | <a href="#">Buy now</a> |
| 6   | <a href="#">6BXF431200</a><br>Pipe 2                  | <a href="#">Buy now</a> |
| 7   | <a href="#">9046709M09</a><br>Clip(6k8)               | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX2450000</a><br>Fuel cock assembly 1    | <a href="#">Buy now</a> |
| 9   | <a href="#">9015906M10</a><br>Screw, with washer(6I5) | <a href="#">Buy now</a> |
| 10  | <a href="#">6BXF431300</a><br>Pipe 3                  | <a href="#">Buy now</a> |
| 12  | <a href="#">9046412224</a><br>Clamp(4pe)              | <a href="#">Buy now</a> |
| 13  | <a href="#">68T2425101</a><br>Strainer 1              | <a href="#">Buy now</a> |
| 14  | <a href="#">6BXF247C00</a><br>Hose 3                  | <a href="#">Buy now</a> |
| 16  | <a href="#">9046511M10</a><br>Clamp                   | <a href="#">Buy now</a> |
| 17  | <a href="#">6882437800</a><br>Pipe, joint             | <a href="#">Buy now</a> |

## Fuel 2




| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 18  | <a href="#">6BXF247D00</a><br>Hose 4             | <a href="#">Buy now</a> |
| 21  | <a href="#">6BX2441000</a><br>Fuel pump assembly | <a href="#">Buy now</a> |
| 22  | <a href="#">67D2441200</a><br>Body 1             | <a href="#">Buy now</a> |
| 23  | <a href="#">67D2441302</a><br>Body 2             | <a href="#">Buy now</a> |
| 24  | <a href="#">6A02442101</a><br>Valve, check       | <a href="#">Buy now</a> |
| 25  | <a href="#">6E71432500</a><br>Screw, pan head    | <a href="#">Buy now</a> |
| 26  | <a href="#">6BX2441100</a><br>Diaphragm          | <a href="#">Buy now</a> |
| 27  | <a href="#">67D2442300</a><br>Spring, diaphragm  | <a href="#">Buy now</a> |
| 28  | <a href="#">6BX1313100</a><br>Plunger            | <a href="#">Buy now</a> |
| 29  | <a href="#">66M2437400</a><br>Pin                | <a href="#">Buy now</a> |
| 30  | <a href="#">6BX2445400</a><br>Spring             | <a href="#">Buy now</a> |
| 31  | <a href="#">67D2441401</a><br>Body 3             | <a href="#">Buy now</a> |
| 32  | <a href="#">66M2447101</a><br>Diaphragm          | <a href="#">Buy now</a> |
| 33  | <a href="#">67D2444400</a><br>Screw              | <a href="#">Buy now</a> |
| 34  | <a href="#">9538004600</a><br>Nut, hex           | <a href="#">Buy now</a> |

## Fuel 2




| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 35  | <a href="#">9321027ME3</a><br>O-ring                          | <a href="#">Buy now</a> |
| 36  | <a href="#">9709506030</a><br>Bolt(jf7)                       | <a href="#">Buy now</a> |
| 37  | <a href="#">9299506100</a><br>Washer(6a1)                     | <a href="#">Buy now</a> |
| 39  | <a href="#">6BXF247B00</a><br>Hose 2                          | <a href="#">Buy now</a> |
| 41  | <a href="#">6BX2436000</a><br>Primer pump assembly            | <a href="#">Buy now</a> |
| 42  | <a href="#">6BX2413500</a><br>Clamp 1                         | <a href="#">Buy now</a> |
| 43  | <a href="#">6BX2413600</a><br>Clamp 2                         | <a href="#">Buy now</a> |
| 44  | <a href="#">9010906M80</a><br>Bolt                            | <a href="#">Buy now</a> |
| 45  | <a href="#">6BXF247A00</a><br>Hose 1                          | <a href="#">Buy now</a> |
| 46  | <a href="#">9046409021</a><br>Clamp                           | <a href="#">Buy now</a> |
| 49  | <a href="#">6BXE397100</a><br>Pipe, fuel 1                    | <a href="#">Buy now</a> |
| 51  | <a href="#">6BXF810000</a><br>Tool kit<br>AP                  | <a href="#">Buy now</a> |
| 52  | <a href="#">6BVF819970E0</a><br>Om f4b/f5a/f6c '10<br>UR (E)  | <a href="#">Buy now</a> |
| 52  | <a href="#">6BVF819970F0</a><br>Om f4b/f5a/f6c '10<br>UR (F)  | <a href="#">Buy now</a> |
| 52  | <a href="#">6BVF819970S0</a><br>Om f4b/f5a/f6c '10<br>UR (ES) | <a href="#">Buy now</a> |

## Fuel 2



| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 52  | <a href="#">6BVF819970D0</a><br>Om f4b/f5a/f6c '10<br>UR (NL) | <a href="#">Buy now</a> |
| 52  | <a href="#">6BVF819970G0</a><br>Om f4b/f5a/f6c '10<br>UR (D)  | <a href="#">Buy now</a> |
| 52  | <a href="#">6BVF819970H0</a><br>Om f4b/f5a/f6c '10<br>UR (I)  | <a href="#">Buy now</a> |
| 53  | <a href="#">6BVF819980K0</a><br>Om f4b/f5a/f6c '10<br>UR (DK) | <a href="#">Buy now</a> |
| 53  | <a href="#">6BVF819980L0</a><br>Om f4b/f5a/f6c '10<br>UR (SF) | <a href="#">Buy now</a> |
| 53  | <a href="#">6BVF819980M0</a><br>Om f4b/f5a/f6c '10<br>UR (S)  | <a href="#">Buy now</a> |
| 53  | <a href="#">6BVF819980N0</a><br>Om f4b/f5a/f6c '10<br>UR (N)  | <a href="#">Buy now</a> |
| 53  | <a href="#">6BVF819980P0</a><br>Om f4b/f5a/f6c '10<br>UR (P)  | <a href="#">Buy now</a> |
| 53  | <a href="#">6BVF819980R0</a><br>Om f4b/f5a/f6c '10<br>UR (GR) | <a href="#">Buy now</a> |


# Generator



  
6BV1100-J110

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BX8555000</a><br>Rotor assembly              | <a href="#">Buy now</a> |
| 2   | <a href="#">6BV8557101</a><br>Ignition coil with cdi unit | <a href="#">Buy now</a> |
| 2   | <a href="#">6BW8557101</a><br>Ignition coil with cdi unit | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX8557100</a><br>Ignition coil with cdi unit | <a href="#">Buy now</a> |
| 3   | <a href="#">9028004M06</a><br>Key, woodruff(6a1)          | <a href="#">Buy now</a> |
| 4   | <a href="#">9017012066</a><br>Nut, hexagon 6481155500     | <a href="#">Buy now</a> |
| 5   | <a href="#">9020112472</a><br>Washer, plate (4n0)         | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX1572300</a><br>Pulley, starter             | <a href="#">Buy now</a> |
| 7   | <a href="#">9010506037</a><br>Bolt, flange                | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX8237000</a><br>Plug cap assembly           | <a href="#">Buy now</a> |
| 9   | <a href="#">9048025161</a><br>Grommet(656)                | <a href="#">Buy now</a> |
| 10  | <a href="#">9046508361</a><br>Clamp(7mx)                  | <a href="#">Buy now</a> |
| 11  | <a href="#">9709506012</a><br>Bolt(gh1)                   | <a href="#">Buy now</a> |
| 12  | <a href="#">9299506600</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |


# Intake



6BV1100-J060

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BX1444000</a><br>Silencer assembly, intake     | <a href="#">Buy now</a> |
| 2   | <a href="#">9048018M74</a><br>Grommet                       | <a href="#">Buy now</a> |
| 3   | <a href="#">93210320A7</a><br>O-ring                        | <a href="#">Buy now</a> |
| 4   | <a href="#">6BXF431400</a><br>Pipe 4                        | <a href="#">Buy now</a> |
| 5   | <a href="#">6BXE316F00</a><br>Hose, oil 1                   | <a href="#">Buy now</a> |
| 6   | <a href="#">9046709M09</a><br>Clip(6k8)                     | <a href="#">Buy now</a> |
| 7   | <a href="#">6BXE364700</a><br>Gasket, manifold 3            | <a href="#">Buy now</a> |
| 8   | <a href="#">6BXE364600</a><br>Gasket, manifold 2            | <a href="#">Buy now</a> |
| 9   | <a href="#">9011006350</a><br>Bolt, hexagon socket head     | <a href="#">Buy now</a> |
| 10  | <a href="#">9020106106</a><br>Washer, plate                 | <a href="#">Buy now</a> |
| 11  | <a href="#">6BXE36411094</a><br>Manifold, intake 1          | <a href="#">Buy now</a> |
| 12  | <a href="#">6BXE364500</a><br>Gasket, manifold 1            | <a href="#">Buy now</a> |
| 13  | <a href="#">9757506525</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 14  | <a href="#">6BXF633000</a><br>Starter cable assembly        | <a href="#">Buy now</a> |
| 15  | <a href="#">6BXF633300</a><br>Nut                           | <a href="#">Buy now</a> |


# Intake



6BV1100-J060


| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 16  | <a href="#">6BXE315100</a><br>Stay                | <a href="#">Buy now</a> |
| 17  | <a href="#">9709505010</a><br>Bolt (682)          | <a href="#">Buy now</a> |
| 18  | <a href="#">9299505600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXG5300004D</a><br>Lower unit assembly<br>S(17.1") | <a href="#">Buy now</a> |
| 1   | <a href="#">6BXG5300104D</a><br>Lower unit assembly<br>L(22.1") | <a href="#">Buy now</a> |
| 2   | <a href="#">68DG5311004D</a><br>Casing, lower                   | <a href="#">Buy now</a> |
| 3   | <a href="#">6E04531709</a><br>Bushing                           | <a href="#">Buy now</a> |
| 4   | <a href="#">6E04531609</a><br>Bushing                           | <a href="#">Buy now</a> |
| 5   | <a href="#">9310110M14</a><br>Oil seal                          | <a href="#">Buy now</a> |
| 6   | <a href="#">93306004YH</a><br>Bearing (7k2)                     | <a href="#">Buy now</a> |
| 7   | <a href="#">9043008020</a><br>Gasket                            | <a href="#">Buy now</a> |
| 8   | <a href="#">9034008002</a><br>Plug, straight screw              | <a href="#">Buy now</a> |
| 9   | <a href="#">68DG532100</a><br>Plate                             | <a href="#">Buy now</a> |
| 10  | <a href="#">6L24414700</a><br>Boot, shift rod                   | <a href="#">Buy now</a> |
| 11  | <a href="#">68DG5315A0</a><br>Packing, lower cas                | <a href="#">Buy now</a> |
| 12  | <a href="#">9709506025</a><br>Bolt                              | <a href="#">Buy now</a> |
| 13  | <a href="#">9299506600</a><br>Washer, plain (646)               | <a href="#">Buy now</a> |
| 14  | <a href="#">68DG5361004D</a><br>Cap, lower casing               | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 16  | <a href="#">9310113M12</a><br>Oil seal                 | <a href="#">Buy now</a> |
| 17  | <a href="#">9321048214</a><br>O-ring                   | <a href="#">Buy now</a> |
| 18  | <a href="#">9589506016</a><br>Bolt, flange deep recess | <a href="#">Buy now</a> |
| 19  | <a href="#">6BX4431100</a><br>Housing, water pump      | <a href="#">Buy now</a> |
| 20  | <a href="#">6BXG431501</a><br>Gasket, water pump       | <a href="#">Buy now</a> |
| 21  | <a href="#">6BX4432200</a><br>Insert, cartridge        | <a href="#">Buy now</a> |
| 22  | <a href="#">6BX4432300</a><br>Outer plate, cartridge   | <a href="#">Buy now</a> |
| 23  | <a href="#">67D4436600</a><br>Damper, water seal 2     | <a href="#">Buy now</a> |
| 24  | <a href="#">6E04435200</a><br>Impeller                 | <a href="#">Buy now</a> |
| 25  | <a href="#">9360409066</a><br>Pin, dowel               | <a href="#">Buy now</a> |
| 26  | <a href="#">9709506045</a><br>Bolt, hexagon            | <a href="#">Buy now</a> |
| 27  | <a href="#">9360418080</a><br>Pin, dowel. (647)        | <a href="#">Buy now</a> |
| 28  | <a href="#">68DG432800</a><br>Plate                    | <a href="#">Buy now</a> |
| 29  | <a href="#">68DG551100</a><br>Shaft, drive<br>S(17.1") | <a href="#">Buy now</a> |
| 29  | <a href="#">68DG551110</a><br>Shaft, drive<br>L(22.1") | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 30  | <a href="#">9046708M01</a><br>Clip (6e0)                     | <a href="#">Buy now</a> |
| 31  | <a href="#">6BX4555100</a><br>Pinion                         | <a href="#">Buy now</a> |
| 32  | <a href="#">9900106600</a><br>Circlip(53l)                   | <a href="#">Buy now</a> |
| 33  | <a href="#">9020111M49</a><br>Washer, plate (6e0)            | <a href="#">Buy now</a> |
| 34  | <a href="#">67D4556000</a><br>Gear                           | <a href="#">Buy now</a> |
| 35  | <a href="#">67D4557000</a><br>Gear                           | <a href="#">Buy now</a> |
| 36  | <a href="#">67D4557600</a><br>Washer, thrust 2               | <a href="#">Buy now</a> |
| 37  | <a href="#">67D4563101</a><br>Clutch, dog                    | <a href="#">Buy now</a> |
| 38  | <a href="#">90501120A9</a><br>Spring, compression            | <a href="#">Buy now</a> |
| 39  | <a href="#">67D4563500</a><br>Plunger, shift                 | <a href="#">Buy now</a> |
| 40  | <a href="#">68DG561110</a><br>Shaft, propeller               | <a href="#">Buy now</a> |
| 41  | <a href="#">6BXG415000</a><br>Shift cam assembly<br>S(17.1") | <a href="#">Buy now</a> |
| 41  | <a href="#">6BXG415010</a><br>Shift cam assembly<br>L(22.1") | <a href="#">Buy now</a> |

## Lower Casing & Drive 2




| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXG436000</a><br>Water tube assembly<br>S(17.1")        | <a href="#">Buy now</a> |
| 1   | <a href="#">6BXG436010</a><br>Water tube assembly<br>L(22.1")        | <a href="#">Buy now</a> |
| 2   | <a href="#">68DG525100</a><br>Anode                                  | <a href="#">Buy now</a> |
| 3   | <a href="#">9589506012</a><br>Bolt, flange deep recess               | <a href="#">Buy now</a> |
| 4   | <a href="#">9299006300</a><br>Washer, tooth                          | <a href="#">Buy now</a> |
| 5   | <a href="#">9011906253</a><br>Bolt, with washer<br>S(17.1")          | <a href="#">Buy now</a> |
| 5   | <a href="#">9011906254</a><br>Bolt, with washer<br>L(22.1")          | <a href="#">Buy now</a> |
| 13  | <a href="#">9038706806</a><br>Collar(6e0)<br>L(22.1")                | <a href="#">Buy now</a> |
| 7   | <a href="#">68DG598700</a><br>Spacer 1                               | <a href="#">Buy now</a> |
| 8   | <a href="#">6L54561600</a><br>Nut, propeller                         | <a href="#">Buy now</a> |
| 9   | <a href="#">9149025030</a><br>Pin, cotter(6I5)                       | <a href="#">Buy now</a> |
| 10  | <a href="#">9020108M54</a><br>Washer, plate (6e5)                    | <a href="#">Buy now</a> |
| 11  | <a href="#">6E04594101EL</a><br>Propeller (3x7-1/2 x8 -ba)<br>UR     | <a href="#">Buy now</a> |
| 11  | <a href="#">6E04594301EL</a><br>Propeller (3x7-1/2"x7"-ba)<br>UR     | <a href="#">Buy now</a> |
| 11  | <a href="#">6E04594900EL</a><br>Propeller (3x7-1/4 x6-1/2 -ba)<br>UR | <a href="#">Buy now</a> |

## Lower Casing & Drive 2




| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 11  | <a href="#">6E04595200EL</a><br>Propeller (3x7-1/4 x8-1/4 -ba)<br>UR | <a href="#">Buy now</a> |
| 12  | <a href="#">6BXG5211004D</a><br>Extension<br>L(22.1")                | <a href="#">Buy now</a> |
| 14  | <a href="#">6BX4531801</a><br>Bushing, drive shaft<br>L(22.1")       | <a href="#">Buy now</a> |
| 15  | <a href="#">9342022M03</a><br>Cir clip (6e0)<br>L(22.1")             | <a href="#">Buy now</a> |

## Optional Parts




| Ref | Part                                                                              |                         |
|-----|-----------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BX85550A0</a><br>Rotor assembly<br>AP EXCEPT FOR RUS                 | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX85510A0</a><br>Lighting coil assembly<br>AP EXCEPT FOR RUS         | <a href="#">Buy now</a> |
| 3   | <a href="#">9759506520</a><br>Bolt(7u8)<br>AP EXCEPT FOR RUS                      | <a href="#">Buy now</a> |
| 4   | <a href="#">6BX8196000</a><br>Rectifier & regulator assembly<br>AP EXCEPT FOR RUS | <a href="#">Buy now</a> |
| 5   | <a href="#">9759506516</a><br>Bolt, with washer(6r6)<br>AP EXCEPT FOR RUS         | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX8194900</a><br>Wire, lead<br>AP EXCEPT FOR RUS                     | <a href="#">Buy now</a> |
| 7   | <a href="#">67F8215B00</a><br>Cap (black)                                         | <a href="#">Buy now</a> |
| 8   | <a href="#">67F8215100</a><br>Fuse                                                | <a href="#">Buy now</a> |
| 9   | <a href="#">9046430009</a><br>Clamp<br>AP EXCEPT FOR RUS                          | <a href="#">Buy now</a> |
| 10  | <a href="#">6BX8258100</a><br>Stay, cord clamp<br>AP EXCEPT FOR RUS               | <a href="#">Buy now</a> |
| 11  | <a href="#">6BX8238800</a><br>Plate<br>AP EXCEPT FOR RUS                          | <a href="#">Buy now</a> |
| 12  | <a href="#">9010906M80</a><br>Bolt<br>AP EXCEPT FOR RUS                           | <a href="#">Buy now</a> |
| 13  | <a href="#">9046508371</a><br>Clamp(4km)<br>AP EXCEPT FOR RUS                     | <a href="#">Buy now</a> |

# Repair Kit 1




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXWE00100</a><br>Power head gasket kit   | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX1118100</a><br>Gasket, cylinder head 1 | <a href="#">Buy now</a> |
| 3   | <a href="#">6BX1135600</a><br>Seal, cylinder 2        | <a href="#">Buy now</a> |
| 4   | <a href="#">9310225022</a><br>Oil seal                | <a href="#">Buy now</a> |
| 5   | <a href="#">6BX1135100</a><br>Gasket, cylinder        | <a href="#">Buy now</a> |
| 6   | <a href="#">9321035537</a><br>O-ring                  | <a href="#">Buy now</a> |
| 7   | <a href="#">9310220108</a><br>Oil seal                | <a href="#">Buy now</a> |
| 8   | <a href="#">9310210004</a><br>Oil seal                | <a href="#">Buy now</a> |
| 9   | <a href="#">9043008800</a><br>Gasket (256-11198-00)   | <a href="#">Buy now</a> |
| 10  | <a href="#">68DE2414A0</a><br>Gasket, cover           | <a href="#">Buy now</a> |
| 11  | <a href="#">93210320A7</a><br>O-ring                  | <a href="#">Buy now</a> |
| 12  | <a href="#">6BXE364700</a><br>Gasket, manifold 3      | <a href="#">Buy now</a> |
| 13  | <a href="#">6BXE364600</a><br>Gasket, manifold 2      | <a href="#">Buy now</a> |
| 14  | <a href="#">6BXE364500</a><br>Gasket, manifold 1      | <a href="#">Buy now</a> |
| 15  | <a href="#">6BXE347500</a><br>Gasket                  | <a href="#">Buy now</a> |

## Repair Kit 1




| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">9321024M79</a><br>O-ring               | <a href="#">Buy now</a> |
| 17  | <a href="#">9321027ME3</a><br>O-ring               | <a href="#">Buy now</a> |
| 18  | <a href="#">6BX4511300</a><br>Gasket, upper casing | <a href="#">Buy now</a> |

## Repair Kit 2




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXW009300</a><br>Carburetor repair kit | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX1498500</a><br>Float                 | <a href="#">Buy now</a> |
| 3   | <a href="#">6BX1498400</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 4   | <a href="#">6BX1459200</a><br>Screw                 | <a href="#">Buy now</a> |
| 5   | <a href="#">4JH1456200</a><br>O-ring                | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX1454600</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 7   | <a href="#">6BX1454800</a><br>Pin, float arm        | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX1493700</a><br>Clip                  | <a href="#">Buy now</a> |

## Repair Kit 3




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXWG00120</a><br>Lower unit gasket kit  | <a href="#">Buy now</a> |
| 2   | <a href="#">9310110M14</a><br>Oil seal               | <a href="#">Buy now</a> |
| 3   | <a href="#">9043008020</a><br>Gasket                 | <a href="#">Buy now</a> |
| 4   | <a href="#">68DG5315A0</a><br>Packing, lower cas     | <a href="#">Buy now</a> |
| 5   | <a href="#">6BXG431501</a><br>Gasket, water pump     | <a href="#">Buy now</a> |
| 6   | <a href="#">9310113M12</a><br>Oil seal               | <a href="#">Buy now</a> |
| 7   | <a href="#">9321048214</a><br>O-ring                 | <a href="#">Buy now</a> |
| 8   | <a href="#">6BXWG07800</a><br>Water pump repair kit  | <a href="#">Buy now</a> |
| 9   | <a href="#">6BX4431100</a><br>Housing, water pum     | <a href="#">Buy now</a> |
| 11  | <a href="#">6BX4432200</a><br>Insert, cartridge      | <a href="#">Buy now</a> |
| 12  | <a href="#">6BX4432300</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |
| 13  | <a href="#">67D4436600</a><br>Damper, water seal 2   | <a href="#">Buy now</a> |
| 14  | <a href="#">6E04435200</a><br>Impeller               | <a href="#">Buy now</a> |
| 15  | <a href="#">9709506045</a><br>Bolt, hexagon          | <a href="#">Buy now</a> |
| 16  | <a href="#">9360418080</a><br>Pin. dowel. (647)      | <a href="#">Buy now</a> |

# Starter




| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 1   | <a href="#">6BX1571000</a><br>Starter assembly   | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX1571100</a><br>Case, starter      | <a href="#">Buy now</a> |
| 3   | <a href="#">63V1579501</a><br>Guide, rope        | <a href="#">Buy now</a> |
| 4   | <a href="#">67D1576400</a><br>Collar 1           | <a href="#">Buy now</a> |
| 5   | <a href="#">67D1571400</a><br>Drum, sheave       | <a href="#">Buy now</a> |
| 6   | <a href="#">67D1574100</a><br>Pawl, drive        | <a href="#">Buy now</a> |
| 7   | <a href="#">67D1571300</a><br>Spring, starter    | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX1570500</a><br>Spring, drive pawl | <a href="#">Buy now</a> |
| 9   | <a href="#">67D1576700</a><br>Spring             | <a href="#">Buy now</a> |
| 10  | <a href="#">67D1573500</a><br>Guide, cam         | <a href="#">Buy now</a> |
| 11  | <a href="#">67D1579300</a><br>Screw              | <a href="#">Buy now</a> |
| 12  | <a href="#">63V1576400</a><br>Collar 1           | <a href="#">Buy now</a> |
| 13  | <a href="#">67D1579401</a><br>Stopper            | <a href="#">Buy now</a> |
| 14  | <a href="#">67D1573400</a><br>Spring, return     | <a href="#">Buy now</a> |
| 15  | <a href="#">*</a><br>item_description<br>*1      | <a href="#">Buy now</a> |

# Starter




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">6G11575500</a><br>Handle, starter        | <a href="#">Buy now</a> |
| 17  | <a href="#">6G11577900</a><br>Cover                  | <a href="#">Buy now</a> |
| 18  | <a href="#">67D1573900</a><br>Washer, thrust         | <a href="#">Buy now</a> |
| 19  | <a href="#">67D1574400</a><br>Circlip                | <a href="#">Buy now</a> |
| 20  | <a href="#">6BX1576200</a><br>Seal, rubber 2         | <a href="#">Buy now</a> |
| 21  | <a href="#">9709506035</a><br>Bolt(j52)              | <a href="#">Buy now</a> |
| 22  | <a href="#">9299506600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 23  | <a href="#">9709506020</a><br>Bolt(7u8)              | <a href="#">Buy now</a> |
| 25  | <a href="#">6BXE577000</a><br>Wire comp starter      | <a href="#">Buy now</a> |
| 26  | <a href="#">9046407008</a><br>Clamp                  | <a href="#">Buy now</a> |
| 27  | <a href="#">6BX8237700</a><br>Label (Sparkplug Mark) | <a href="#">Buy now</a> |
| 28  | <a href="#">6AH8199540</a><br>Label, warning         | <a href="#">Buy now</a> |
| 29  | <a href="#">6AH8199550</a><br>Label, warning         | <a href="#">Buy now</a> |
| 30  | <a href="#">6BXE343760</a><br>Mark, caution          | <a href="#">Buy now</a> |
| 31  | <a href="#">6BXE442760</a><br>Label, instruction     | <a href="#">Buy now</a> |

Starter




| Ref | Part                                        |                         |
|-----|---------------------------------------------|-------------------------|
| 32  | <a href="#">6AH8199440</a><br>Label, safety | <a href="#">Buy now</a> |
| 33  | <a href="#">6AH8199450</a><br>Label, safety | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXG2111004D</a><br>Handle, steering        | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX4212900</a><br>Bushing, rubber           | <a href="#">Buy now</a> |
| 3   | <a href="#">6BXG217100</a><br>Bushing                   | <a href="#">Buy now</a> |
| 4   | <a href="#">6BXG217200</a><br>Bushing 2                 | <a href="#">Buy now</a> |
| 5   | <a href="#">6BXG218100</a><br>Washer                    | <a href="#">Buy now</a> |
| 6   | <a href="#">6BXG218800</a><br>Washer, wave              | <a href="#">Buy now</a> |
| 7   | <a href="#">6BXG218200</a><br>Washer 2                  | <a href="#">Buy now</a> |
| 8   | <a href="#">6BX4213100</a><br>Cover, handle steering    | <a href="#">Buy now</a> |
| 9   | <a href="#">9707508025</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |
| 10  | <a href="#">6G14212501</a><br>Bolt, friction adjusting  | <a href="#">Buy now</a> |
| 11  | <a href="#">6G14212600</a><br>Piece, friction           | <a href="#">Buy now</a> |
| 12  | <a href="#">9149016010</a><br>Pin, cotter               | <a href="#">Buy now</a> |
| 13  | <a href="#">68DG211901</a><br>Grip, steering han        | <a href="#">Buy now</a> |
| 14  | <a href="#">60PG213700</a><br>Indicator, throttl        | <a href="#">Buy now</a> |
| 15  | <a href="#">9026902M09</a><br>Rivet(6I5)                | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">68DG217710</a><br>Rubber, handle       | <a href="#">Buy now</a> |
| 17  | <a href="#">9014905M13</a><br>Screw, countersunk   | <a href="#">Buy now</a> |
| 18  | <a href="#">9020110M02</a><br>Washer, plate(6g9)   | <a href="#">Buy now</a> |
| 19  | <a href="#">9050123215</a><br>Spring (655)         | <a href="#">Buy now</a> |
| 20  | <a href="#">9038608032</a><br>Bushing (650)        | <a href="#">Buy now</a> |
| 21  | <a href="#">6BX4213800</a><br>Lever, throttle      | <a href="#">Buy now</a> |
| 22  | <a href="#">68DG215900</a><br>Stay                 | <a href="#">Buy now</a> |
| 23  | <a href="#">9788505012</a><br>Screw,pan head (646) | <a href="#">Buy now</a> |
| 24  | <a href="#">6BXF630100</a><br>Throttle cable ass   | <a href="#">Buy now</a> |
| 25  | <a href="#">6BX4163800</a><br>Pulley               | <a href="#">Buy now</a> |
| 26  | <a href="#">6BX4128300</a><br>Lever, free accel.   | <a href="#">Buy now</a> |
| 27  | <a href="#">9038706252</a><br>Collar               | <a href="#">Buy now</a> |
| 28  | <a href="#">6BX4121100</a><br>Link, accel.         | <a href="#">Buy now</a> |
| 29  | <a href="#">6BXE449700</a><br>Stay, throttle wir   | <a href="#">Buy now</a> |
| 30  | <a href="#">6614126202</a><br>Joint, choke lever   | <a href="#">Buy now</a> |

# Steering




| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 31  | <a href="#">9709506035</a><br>Bolt(j52)           | <a href="#">Buy now</a> |
| 32  | <a href="#">9299506600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 33  | <a href="#">9709506012</a><br>Bolt(gh1)           | <a href="#">Buy now</a> |
| 35  | <a href="#">9020106M62</a><br>Washer, plate (6e5) | <a href="#">Buy now</a> |
| 36  | <a href="#">6471439560</a><br>Cap,over flow pipe  | <a href="#">Buy now</a> |
| 37  | <a href="#">9046406006</a><br>Clamp               | <a href="#">Buy now</a> |
| 38  | <a href="#">9046407M20</a><br>Clamp(6h0)          | <a href="#">Buy now</a> |
| 39  | <a href="#">9046407M05</a><br>Clamp (6g5)         | <a href="#">Buy now</a> |
| 40  | <a href="#">9046508395</a><br>Clamp               | <a href="#">Buy now</a> |
| 41  | <a href="#">6AH4279440</a><br>Label, warning (ge  | <a href="#">Buy now</a> |

# Top Cowling




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BVG261000</a><br>Top cowling assembly (white)   | <a href="#">Buy now</a> |
| 1   | <a href="#">6BVG261010</a><br>-<br>FOR RUS                   | <a href="#">Buy now</a> |
| 1   | <a href="#">6BWG261000</a><br>Top Cowling assembly (White)   | <a href="#">Buy now</a> |
| 1   | <a href="#">6BWG261010</a><br>-<br>FOR RUS                   | <a href="#">Buy now</a> |
| 1   | <a href="#">6BXG261000</a><br>Top cowling assembly (white)   | <a href="#">Buy now</a> |
| 1   | <a href="#">6BXG261010</a><br>-<br>FOR RUS                   | <a href="#">Buy now</a> |
| 2   | <a href="#">6BXG261300</a><br>-                              | <a href="#">Buy now</a> |
| 2   | <a href="#">6BXG261310</a><br>Molding, air duct<br>FOR RUS   | <a href="#">Buy now</a> |
| 3   | <a href="#">9778040012</a><br>Screw, trushead tapping (ge31) | <a href="#">Buy now</a> |
| 4   | <a href="#">6BXG265100</a><br>Hook                           | <a href="#">Buy now</a> |
| 5   | <a href="#">9026604M04</a><br>Rivet(6e7)                     | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX4261500</a><br>Seal                           | <a href="#">Buy now</a> |
| 7   | <a href="#">60R4265200</a><br>Hook                           | <a href="#">Buy now</a> |
| 8   | <a href="#">9709505014</a><br>Bolt, w/ plain                 | <a href="#">Buy now</a> |
| 9   | <a href="#">9299505600</a><br>Washer, plain (646)            | <a href="#">Buy now</a> |

# Top Cowling




| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 10  | <a href="#">68T4264900</a><br>Holder, clamp band          | <a href="#">Buy now</a> |
| 11  | <a href="#">6BXG213400</a><br>Cover                       | <a href="#">Buy now</a> |
| 12  | <a href="#">6BVW007000</a><br>Graphic Set                 | <a href="#">Buy now</a> |
| 12  | <a href="#">6BWW007000</a><br>Graphic Set                 | <a href="#">Buy now</a> |
| 12  | <a href="#">6BXW007000</a><br>Graphic Set                 | <a href="#">Buy now</a> |
| 12  | <a href="#">6BXW007010</a><br>Graphic Set<br>FOR RUS      | <a href="#">Buy now</a> |
| 13  | <a href="#">6BV4267700</a><br>Graphic, front<br>FOR RUS   | <a href="#">Buy now</a> |
| 13  | <a href="#">6BW4267700</a><br>Graphic, front<br>FOR RUS   | <a href="#">Buy now</a> |
| 13  | <a href="#">6BX4267700</a><br>Graphic Front<br>FOR RUS    | <a href="#">Buy now</a> |
| 13  | <a href="#">6BX4268100</a><br>Mark, cowling               | <a href="#">Buy now</a> |
| 14  | <a href="#">6BX4269700</a><br>Tuning fork mark            | <a href="#">Buy now</a> |
| 14  | <a href="#">6BX4269710</a><br>Tuning fork mark<br>FOR RUS | <a href="#">Buy now</a> |
| 15  | <a href="#">9026604M00</a><br>Rivet 2 (662)               | <a href="#">Buy now</a> |
| 16  | <a href="#">60RE343400</a><br>Label, Caution              | <a href="#">Buy now</a> |
| 17  | <a href="#">6S74269840</a><br>Label, warning (fu          | <a href="#">Buy now</a> |

# Top Cowling



| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 18  | <a href="#">6S74269850</a><br>Label, warning (fu | <a href="#">Buy now</a> |


## Upper Casing



  
6BV1100J1701

| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXG5111004D</a><br>Upper casing & grease nipple | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX1531600</a><br>Damper 1                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6BXG532100</a><br>Plate                          | <a href="#">Buy now</a> |
| 4   | <a href="#">9709506014</a><br>Bolt(gj3)                      | <a href="#">Buy now</a> |
| 5   | <a href="#">9299506600</a><br>Washer, plain (646)            | <a href="#">Buy now</a> |
| 6   | <a href="#">6BX4511300</a><br>Gasket, upper casing           | <a href="#">Buy now</a> |
| 7   | <a href="#">9038706806</a><br>Collar(6e0)                    | <a href="#">Buy now</a> |
| 8   | <a href="#">9757506540</a><br>Bolt, hexagon w/w deep recess  | <a href="#">Buy now</a> |
| 9   | <a href="#">9707506050</a><br>Bolt(jf7)                      | <a href="#">Buy now</a> |
| 11  | <a href="#">6474515101</a><br>Cover, upper casing            | <a href="#">Buy now</a> |
| 12  | <a href="#">9048010M13</a><br>Grommet (6e0)                  | <a href="#">Buy now</a> |
| 13  | <a href="#">6BXG272300</a><br>Cover, bottom                  | <a href="#">Buy now</a> |
| 16  | <a href="#">6BX4271600</a><br>Rubber, seal 1                 | <a href="#">Buy now</a> |

# Valve



  
6BV1100-J050

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6BXE217000</a><br>Camshaft assembly 1    | <a href="#">Buy now</a> |
| 2   | <a href="#">6BX1211100</a><br>Valve, intake          | <a href="#">Buy now</a> |
| 3   | <a href="#">67D1212100</a><br>Valve, exhaust         | <a href="#">Buy now</a> |
| 4   | <a href="#">51Y1211900</a><br>Seal, valve stem       | <a href="#">Buy now</a> |
| 5   | <a href="#">60R1211300</a><br>Spring, valve inne     | <a href="#">Buy now</a> |
| 6   | <a href="#">68T1211600</a><br>Seat, valve spring     | <a href="#">Buy now</a> |
| 7   | <a href="#">7NJ1211700</a><br>Retainer, valve spring | <a href="#">Buy now</a> |
| 8   | <a href="#">7NJ1211800</a><br>Cotter, valve          | <a href="#">Buy now</a> |
| 9   | <a href="#">67D1215100</a><br>Arm, valve rocker      | <a href="#">Buy now</a> |
| 10  | <a href="#">7FK1216500</a><br>Pivot, rocker arm      | <a href="#">Buy now</a> |
| 11  | <a href="#">7FK1215800</a><br>Nut, lock              | <a href="#">Buy now</a> |
| 12  | <a href="#">67D1215700</a><br>Bolt                   | <a href="#">Buy now</a> |
| 13  | <a href="#">6BXE215500</a><br>Guide, push rod        | <a href="#">Buy now</a> |
| 14  | <a href="#">6BX1215400</a><br>Rod, valve push        | <a href="#">Buy now</a> |
| 15  | <a href="#">JA91215300</a><br>Lifter, valve          | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.