



# Yamaha FL115AET 2001

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>Bottom Cowling</b>	3
<b>Bracket 1</b>	6
<b>Bracket 2</b>	9
<b>Control</b>	12
<b>Crankshaft &amp; Piston</b>	15
<b>Cylinder &amp; Crankcase</b>	16
<b>Cylinder &amp; Crankcase 2</b>	19
<b>Electrical 1</b>	22
<b>Electrical 2</b>	23
<b>Electrical 3</b>	26
<b>Fuel</b>	28
<b>Fuel 2</b>	31
<b>Fuel Injection Nozzle</b>	32
<b>Fuel Injection Pump</b>	34
<b>Generator</b>	37
<b>Intake</b>	39
<b>Intake 1</b>	41
<b>Lower Casing &amp; Drive 3</b>	44
<b>Lower Casing &amp; Drive 4</b>	49
<b>Meter</b>	51
<b>Oil Pan</b>	52
<b>Power Trim &amp; Tilt Assy 1</b>	54
<b>Power Trim &amp; Tilt Assy 2</b>	57
<b>Remote Control Assy 2</b>	60
<b>Remote Control Box</b>	66
<b>Repair Kit 1</b>	67
<b>Repair Kit 2</b>	69
<b>Starting Motor</b>	71
<b>Steering Guide Attachment 1</b>	74
<b>Steering Guide Attachment 2</b>	75
<b>Switch &amp; Panel</b>	76
<b>Top Cowling</b>	78
<b>Upper Casing</b>	81
<b>Valve</b>	83

## Bottom Cowling




Ref	Part	
1	<a href="#">68V42710008D</a> Bottom cowling assembly	<a href="#">Buy now</a>
2	<a href="#">9011908M2200</a> Bolt, with washer	<a href="#">Buy now</a>
3	<a href="#">9048022M1500</a> Grommet (6e5)	<a href="#">Buy now</a>
4	<a href="#">9038708M3700</a> Collar (6e5)	<a href="#">Buy now</a>
5	<a href="#">67F42815008D</a> Lever, clamp	<a href="#">Buy now</a>
6	<a href="#">67F42816008D</a> Lever, clamp	<a href="#">Buy now</a>
7	<a href="#">67F42828009S</a> Plate, clamp	<a href="#">Buy now</a>
8	<a href="#">9010906M8200</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">68V428180000</a> Lever, clamp	<a href="#">Buy now</a>
10	<a href="#">9038615M7300</a> Bush(6l2)	<a href="#">Buy now</a>
11	<a href="#">9020615M1800</a> Washer, wave(6l2)	<a href="#">Buy now</a>
12	<a href="#">9020106M0200</a> Washer,plate (6k8)	<a href="#">Buy now</a>
13	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
14	<a href="#">64D431440000</a> Hook, spring	<a href="#">Buy now</a>
15	<a href="#">9010906M8000</a> Bolt	<a href="#">Buy now</a>

## Bottom Cowling




Ref	Part	
16	<a href="#">9050616M3400</a> Spring, tension(64d)	<a href="#">Buy now</a>
17	<a href="#">68V42738008D</a> Plate, fitting	<a href="#">Buy now</a>
19	<a href="#">68V427251000</a> Grommet	<a href="#">Buy now</a>
20	<a href="#">67F427560000</a> Stay, clamp	<a href="#">Buy now</a>
21	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
22	<a href="#">6H1427262100</a> Grommet	<a href="#">Buy now</a>
23	<a href="#">6H3443910100</a> Nipple, hose	<a href="#">Buy now</a>
24	<a href="#">6H4427480000</a> Grommet	<a href="#">Buy now</a>
25	<a href="#">67F427170000</a> Rubber, seal 2	<a href="#">Buy now</a>
26	<a href="#">6E5825880000</a> Plate	<a href="#">Buy now</a>
27	<a href="#">9010906M8100</a> Bolt	<a href="#">Buy now</a>
28	<a href="#">9046508M2300</a> Clamp (6h3)	<a href="#">Buy now</a>
30	<a href="#">67F125720000</a> Adapter	<a href="#">Buy now</a>
32	<a href="#">6R3125810000</a> Joint, hose 1	<a href="#">Buy now</a>
33	<a href="#">6R3125820000</a> Joint, hose 2	<a href="#">Buy now</a>

## Bottom Cowling



Ref	Part	
34	<a href="#">6R3125830000</a> Gasket, hose joint	<a href="#">Buy now</a>
35	<a href="#">68V243120000</a> Pipe 2	<a href="#">Buy now</a>
36	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
37	<a href="#">61A427160000</a> Rubber seal 1	<a href="#">Buy now</a>
38	<a href="#">67F42741018D</a> Apron	<a href="#">Buy now</a>
39	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
40	<a href="#">9015906M2800</a> Screw, with washer	<a href="#">Buy now</a>
42	<a href="#">9048013M2400</a> Grommet (6e9)	<a href="#">Buy now</a>
43	<a href="#">9038706M4300</a> Coller (6e9)	<a href="#">Buy now</a>


# Bracket 1



  
68V0010-0210


Ref	Part	
1	<a href="#">68V43111018D</a> Bracket, clamp	<a href="#">Buy now</a>
2	<a href="#">6G5452510100</a> Anode	<a href="#">Buy now</a>
3	<a href="#">6G5445260000</a> Plate	<a href="#">Buy now</a>
4	<a href="#">970950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
5	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
6	<a href="#">6E5821480000</a> Wire, lead 5	<a href="#">Buy now</a>
7	<a href="#">970950601000</a> Bolt	<a href="#">Buy now</a>
8	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">68V43112018D</a> Bracket, clamp	<a href="#">Buy now</a>
11	<a href="#">978850601200</a> Screw, pan head(62j)	<a href="#">Buy now</a>
12	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">9370006M0300</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
14	<a href="#">663451190000</a> Cap, grease nipple	<a href="#">Buy now</a>
15	<a href="#">64E431310100</a> Bolt, clamp bracket	<a href="#">Buy now</a>
16	<a href="#">970950802000</a> Bolt, hexagon	<a href="#">Buy now</a>

# Bracket 1



Ref	Part	
17	<a href="#">929900810000</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
18	<a href="#">9038625M3100</a> Bushing (6e5)	<a href="#">Buy now</a>
19	<a href="#">9020126M5900</a> Washer, plate (6e5)	<a href="#">Buy now</a>
20	<a href="#">9018522M1100</a> Nut, self-locking	<a href="#">Buy now</a>
21	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
22	<a href="#">64E43311208D</a> Bracket, swivel	<a href="#">Buy now</a>
23	<a href="#">9046508M6300</a> Clamp(61u)	<a href="#">Buy now</a>
26	<a href="#">68V821493000</a> Wire, lead 3	<a href="#">Buy now</a>
27	<a href="#">66T431440000</a> Hook, spring	<a href="#">Buy now</a>
29	<a href="#">6G5431810200</a> Lever, tilt stop 1	<a href="#">Buy now</a>
30	<a href="#">6G5431850200</a> Lever, tilt stop 2	<a href="#">Buy now</a>
31	<a href="#">9038610M1600</a> Bushing (688)	<a href="#">Buy now</a>
32	<a href="#">6G5431480000</a> Collar, distance	<a href="#">Buy now</a>
33	<a href="#">9024906M1900</a> Pin(6e5)	<a href="#">Buy now</a>
34	<a href="#">9038710M0500</a> Collar(6e5)	<a href="#">Buy now</a>


# Bracket 1



  
68V0010-0210


Ref	Part	
35	<a href="#">916903002000</a> Pin, spring (6h4)	<a href="#">Buy now</a>
36	<a href="#">9050614M2400</a> Spring, tension(6e5)	<a href="#">Buy now</a>
37	<a href="#">64E431260000</a> Pin, upper shock mount	<a href="#">Buy now</a>
38	<a href="#">9038622M9800</a> Bush(61u)	<a href="#">Buy now</a>
39	<a href="#">9341022M1100</a> Circlip(61u)	<a href="#">Buy now</a>
40	<a href="#">9010112M0500</a> Bolt (l:130mm)	<a href="#">Buy now</a>
41	<a href="#">9020113M0100</a> Washer, plate(6e5)	<a href="#">Buy now</a>
42	<a href="#">9020112M0500</a> Washer, plate(663)	<a href="#">Buy now</a>
43	<a href="#">953801260000</a> Nut (707)	<a href="#">Buy now</a>

## Bracket 2



Ref	Part	
1	<a href="#">64E431390100</a> Cam, trim sender (with screw)	<a href="#">Buy now</a>
2	<a href="#">977806052500</a> Screw, tapping(65j)	<a href="#">Buy now</a>
3	<a href="#">64E836720200</a> Trim sender	<a href="#">Buy now</a>
4	<a href="#">703821190000</a> Cover, lead wire	<a href="#">Buy now</a>
5	<a href="#">901570600900</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
6	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
7	<a href="#">61A433760000</a> Bolt, thrust receiver	<a href="#">Buy now</a>
8	<a href="#">957801030000</a> Nut, nylon (6e5)	<a href="#">Buy now</a>
9	<a href="#">68V42510308D</a> Steering bracket assembly	<a href="#">Buy now</a>
10	<a href="#">9020138M6000</a> Washer, plate (6e5)	<a href="#">Buy now</a>
11	<a href="#">9321037MH700</a> O-ring(61u)	<a href="#">Buy now</a>
12	<a href="#">9038638M3200</a> Bush(6e5)	<a href="#">Buy now</a>
13	<a href="#">9020240M4700</a> Washer, plate(61a)	<a href="#">Buy now</a>
14	<a href="#">68V44551008D</a> Housing, lower mount rubber	<a href="#">Buy now</a>
15	<a href="#">9341037M0400</a> Circlip (6e5)	<a href="#">Buy now</a>


## Bracket 2



68V0010-0220

Ref	Part	
16	<a href="#">61A445750000</a> Damper, lower mount rubber	<a href="#">Buy now</a>
17	<a href="#">61A445550194</a> Mount damper, lower side	<a href="#">Buy now</a>
18	<a href="#">9020232M1900</a> Washer, plate (6e5)	<a href="#">Buy now</a>
19	<a href="#">9020116M5500</a> Washer, plate (6e5)	<a href="#">Buy now</a>
20	<a href="#">9020115M5800</a> Washer, plate (6e5)	<a href="#">Buy now</a>
21	<a href="#">9010914MA700</a> Bolt	<a href="#">Buy now</a>
22	<a href="#">953801460000</a> Nut, hex. (ge6)	<a href="#">Buy now</a>
23	<a href="#">929951460000</a> Washer (6e5)	<a href="#">Buy now</a>
24	<a href="#">68V44553008D</a> Cover, lower mount	<a href="#">Buy now</a>
25	<a href="#">970751004000</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
26	<a href="#">929951010000</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
27	<a href="#">67F445140094</a> Mount damper, upper side	<a href="#">Buy now</a>
28	<a href="#">975750854500</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
29	<a href="#">9010912M3700</a> Bolt	<a href="#">Buy now</a>
30	<a href="#">67F445260000</a> Plate	<a href="#">Buy now</a>


## Bracket 2



68V0010-0220


Ref	Part	
31	<a href="#">9020112M0900</a> Washer, plate	<a href="#">Buy now</a>
32	<a href="#">67F445330000</a> Damper, upper mount rubber	<a href="#">Buy now</a>
33	<a href="#">9018512M1200</a> Nut, self-locking(6e5)	<a href="#">Buy now</a>
34	<a href="#">68V485110100</a> Hook, steering	<a href="#">Buy now</a>
35	<a href="#">901161017500</a> Bolt, stud	<a href="#">Buy now</a>
36	<a href="#">901851005100</a> Nut, self-locking	<a href="#">Buy now</a>

## Control



Ref	Part	
1	<a href="#">67F485380000</a> Clamp, cable 1	<a href="#">Buy now</a>
2	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">663483440000</a> Cable end, remote control	<a href="#">Buy now</a>
4	<a href="#">904681800800</a> Clip 620436610000	<a href="#">Buy now</a>
5	<a href="#">68V441170000</a> Bracket	<a href="#">Buy now</a>
6	<a href="#">68F8259F0000</a> Switch assembly	<a href="#">Buy now</a>
7	<a href="#">61A825880000</a> Plate	<a href="#">Buy now</a>
8	<a href="#">978850401600</a> Screw, panhead (796)	<a href="#">Buy now</a>
9	<a href="#">929900410000</a> Ybs67-4 washer, spring	<a href="#">Buy now</a>
10	<a href="#">970950604000</a> Bolt (682)	<a href="#">Buy now</a>
11	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">68V441220100</a> Bushing, shift rod lever	<a href="#">Buy now</a>
13	<a href="#">9020207M0700</a> Washer, plate (688)	<a href="#">Buy now</a>
15	<a href="#">68V441210000</a> Lever, shift rod	<a href="#">Buy now</a>
16	<a href="#">9038606M1200</a> Bushing (688)	<a href="#">Buy now</a>


## Control



  
68V0010-1200

Ref	Part	
17	<a href="#">68V441203000</a> Handle gear shift assembly	<a href="#">Buy now</a>
18	<a href="#">932100916500</a> O-ring	<a href="#">Buy now</a>
19	<a href="#">9038690M9000</a> Bush(61a)	<a href="#">Buy now</a>
20	<a href="#">9020109M0200</a> Washer, plate(61a)	<a href="#">Buy now</a>
21	<a href="#">914902001500</a> Pin, cotter (648)	<a href="#">Buy now</a>
22	<a href="#">68V441180000</a> Bracket	<a href="#">Buy now</a>
23	<a href="#">970750602500</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">9350104M0200</a> Ball (697)	<a href="#">Buy now</a>
26	<a href="#">905011208200</a> Spring 6484411600	<a href="#">Buy now</a>
27	<a href="#">648427150000</a> Bushing 2	<a href="#">Buy now</a>
30	<a href="#">68V421570000</a> Lever, throttle	<a href="#">Buy now</a>
31	<a href="#">9020110M0200</a> Washer, plate(6g9)	<a href="#">Buy now</a>
32	<a href="#">9020610M0400</a> Washer, wave (676)	<a href="#">Buy now</a>
33	<a href="#">9038706M2100</a> Collar	<a href="#">Buy now</a>
34	<a href="#">9017906M2800</a> Nut(63v)	<a href="#">Buy now</a>


## Control



  
68V0010-1200

Ref	Part	
35	<a href="#">68V421540000</a> Lever, throttle control	<a href="#">Buy now</a>
36	<a href="#">67F441350000</a> Spring	<a href="#">Buy now</a>
38	<a href="#">970800603500</a> Bolt(j52)	<a href="#">Buy now</a>
39	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
43	<a href="#">9020106M3100</a> Washer (6a0)	<a href="#">Buy now</a>


## Crankshaft & Piston



68V0010-0030


Ref	Part	
1	<a href="#">68V114110000</a> Crankshaft	<a href="#">Buy now</a>
2	<a href="#">9310248M6000</a> Oil seal	<a href="#">Buy now</a>
3	<a href="#">9310148M6800</a> Oil seal	<a href="#">Buy now</a>
4	<a href="#">67F114162000</a> Plane bearing, crankshaft 1	<a href="#">Buy now</a>
5	<a href="#">67F114170000</a> Plane bearing, crankshaft 2	<a href="#">Buy now</a>
6	<a href="#">67F114182000</a> Plane bearing, crankshaft 3	<a href="#">Buy now</a>
7	<a href="#">68VW11640000</a> Piston/con-rod assembly std	<a href="#">Buy now</a>
8	<a href="#">K1CA32750000</a> Bolt, connecting rod	<a href="#">Buy now</a>
9	<a href="#">6D8116041000</a> Piston ring set (0.25mm o/s)	<a href="#">Buy now</a>
10	<a href="#">68V116560000</a> Plane bearing, connecting rod	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
1	<a href="#">68VW009B011S</a> Cylinder block assembly	<a href="#">Buy now</a>
2	<a href="#">68V15100001S</a> Crankcase assembly	<a href="#">Buy now</a>
3	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
4	<a href="#">9011910M8800</a> Bolt, with washer	<a href="#">Buy now</a>
5	<a href="#">9011908M6600</a> Bolt, with washer	<a href="#">Buy now</a>
6	<a href="#">9034014M0600</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
7	<a href="#">904301411500</a> Gasket (663)	<a href="#">Buy now</a>
8	<a href="#">62Y111190000</a> Hanger, engine	<a href="#">Buy now</a>
9	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
10	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">904801207200</a> Grommet(53y)	<a href="#">Buy now</a>
12	<a href="#">67F151420000</a> Guide 1	<a href="#">Buy now</a>
13	<a href="#">68V41113001S</a> Outer cover, exhaust	<a href="#">Buy now</a>
14	<a href="#">9034018M0900</a> Plug, straight screw	<a href="#">Buy now</a>
15	<a href="#">904301813000</a> Gasket (1j7)	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
16	<a href="#">67F41114A000</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
17	<a href="#">9011906MA400</a> Bolt, with washer	<a href="#">Buy now</a>
18	<a href="#">6G5124160000</a> Valve, pressure control	<a href="#">Buy now</a>
19	<a href="#">9050116M1100</a> Spring, compression (688)	<a href="#">Buy now</a>
20	<a href="#">9048020M0500</a> Grommet (688)	<a href="#">Buy now</a>
21	<a href="#">67F1246A001S</a> Cover 1	<a href="#">Buy now</a>
22	<a href="#">67F12435A000</a> Gasket	<a href="#">Buy now</a>
23	<a href="#">9011906MA200</a> Bolt, with washer	<a href="#">Buy now</a>
24	<a href="#">67F113250000</a> Anode	<a href="#">Buy now</a>
25	<a href="#">67F113270094</a> Anode cover assembly	<a href="#">Buy now</a>
26	<a href="#">970750602000</a> Bolt(7u8)	<a href="#">Buy now</a>
28	<a href="#">67F113280000</a> Grommet, anode	<a href="#">Buy now</a>
29	<a href="#">970750802500</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
30	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>
31	<a href="#">67F1243A0000</a> Hose 1	<a href="#">Buy now</a>

## Cylinder & Crankcase




Ref	Part	
32	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
33	<a href="#">9046720M1500</a> Clip	<a href="#">Buy now</a>
34	<a href="#">67F113510100</a> Gasket, cylinder	<a href="#">Buy now</a>
35	<a href="#">67F427610094</a> Stopper	<a href="#">Buy now</a>
36	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
37	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
38	<a href="#">68F445330000</a> Damper, upper mount rubber	<a href="#">Buy now</a>
39	<a href="#">5GH134400000</a> Element assembly, oil cleaner	<a href="#">Buy now</a>
40	<a href="#">904012014500</a> Bolt, union	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
1	<a href="#">68VW009A001S</a> Cylinder head complete	<a href="#">Buy now</a>
2	<a href="#">68V111100094</a> Cylinder head assembly	<a href="#">Buy now</a>
3	<a href="#">67F111331000</a> Guide, intake valve	<a href="#">Buy now</a>
4	<a href="#">903445101900</a> Plug, taper screw	<a href="#">Buy now</a>
5	<a href="#">901190723500</a> Bolt, with washer	<a href="#">Buy now</a>
6	<a href="#">918090800600</a> Pin, dowel	<a href="#">Buy now</a>
7	<a href="#">901190723400</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">67F113250000</a> Anode	<a href="#">Buy now</a>
9	<a href="#">67F113270094</a> Anode cover assembly	<a href="#">Buy now</a>
10	<a href="#">970800602000</a> Bolt(7u8)	<a href="#">Buy now</a>
11	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">67F113280000</a> Grommet, anode	<a href="#">Buy now</a>
13	<a href="#">970750802500</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
14	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>
15	<a href="#">970950801400</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
16	<a href="#">904300814300</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
17	<a href="#">67F111810100</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
18	<a href="#">9038710M0800</a> Pin, dowel	<a href="#">Buy now</a>
19	<a href="#">9010510M8900</a> Bolt, washer based	<a href="#">Buy now</a>
20	<a href="#">9011908M9100</a> Bolt, with washer	<a href="#">Buy now</a>
21	<a href="#">68V11191001S</a> Cover, cylinder head 1	<a href="#">Buy now</a>
22	<a href="#">67F111680000</a> Cover, breather	<a href="#">Buy now</a>
23	<a href="#">985070400800</a> Screw, pan head(jg1)	<a href="#">Buy now</a>
24	<a href="#">929070460000</a> Washer(jf2)	<a href="#">Buy now</a>
25	<a href="#">904801207200</a> Grommet(53y)	<a href="#">Buy now</a>
26	<a href="#">67F113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
27	<a href="#">970800603000</a> Bolt(jf7)	<a href="#">Buy now</a>
29	<a href="#">67F111920000</a> Cover, cylinder head 2	<a href="#">Buy now</a>
30	<a href="#">9015906M2900</a> Screw, with washer	<a href="#">Buy now</a>
31	<a href="#">60V124110000</a> Thermostat	<a href="#">Buy now</a>

## Cylinder & Crankcase 2




Ref	Part	
32	<a href="#">68V12413001S</a> Cover, thermostat	<a href="#">Buy now</a>
33	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
34	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
35	<a href="#">6G8153630000</a> Plug, oil	<a href="#">Buy now</a>
36	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>
37	<a href="#">947020040000</a> Plug, spark (lfr6a-11)	<a href="#">Buy now</a>

# Electrical 1




Ref	Part	
1	<a href="#">68V8591A0100</a> Engine control unit assembly	<a href="#">Buy now</a>
2	<a href="#">68V823170000</a> Damper, ignition coil	<a href="#">Buy now</a>
3	<a href="#">624425420000</a> Collar	<a href="#">Buy now</a>
4	<a href="#">9011906M5900</a> Bolt, with washer	<a href="#">Buy now</a>
5	<a href="#">68V823100100</a> Ignition coil assembly	<a href="#">Buy now</a>
6	<a href="#">68V823101000</a> Ignition coil assembly	<a href="#">Buy now</a>
7	<a href="#">970950602500</a> Bolt	<a href="#">Buy now</a>
8	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
9	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">68V823880000</a> Plate	<a href="#">Buy now</a>
11	<a href="#">904640600100</a> Clamp	<a href="#">Buy now</a>
12	<a href="#">67F823610000</a> Clamp, cord	<a href="#">Buy now</a>
13	<a href="#">67F823620000</a> Clamp, cord 2	<a href="#">Buy now</a>
14	<a href="#">68V819600000</a> Rectifier & regulator assembly	<a href="#">Buy now</a>
18	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>

## Electrical 2




Ref	Part	
1	<a href="#">68V821050000</a> Battery cable	<a href="#">Buy now</a>
2	<a href="#">970130602000</a> Bolt(62y)	<a href="#">Buy now</a>
3	<a href="#">929030610000</a> Washer(6a1)	<a href="#">Buy now</a>
4	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
5	<a href="#">68V819500000</a> Relay assembly	<a href="#">Buy now</a>
6	<a href="#">977806062500</a> Screw, tapping(65j)	<a href="#">Buy now</a>
7	<a href="#">68V8194A0000</a> Relay	<a href="#">Buy now</a>
8	<a href="#">68V819530000</a> Stay, relay	<a href="#">Buy now</a>
9	<a href="#">977806062000</a> Screw, tapping(6k8)	<a href="#">Buy now</a>
10	<a href="#">978800601000</a> Screw pan head	<a href="#">Buy now</a>
11	<a href="#">929900610000</a> Washer(6a1)	<a href="#">Buy now</a>
13	<a href="#">6G5821190000</a> Cover, lead wire	<a href="#">Buy now</a>
14	<a href="#">68V8195B0100</a> Relay assembly	<a href="#">Buy now</a>
15	<a href="#">68V819490000</a> Wire, lead	<a href="#">Buy now</a>
16	<a href="#">68V825320000</a> Cap	<a href="#">Buy now</a>

## Electrical 2




Ref	Part	
21	<a href="#">929030660000</a> Washer, plain (646)	<a href="#">Buy now</a>
22	<a href="#">68V819480000</a> Brkt. Cover Set	<a href="#">Buy now</a>
23	<a href="#">6A0823170000</a> Damper, ignition coil	<a href="#">Buy now</a>
24	<a href="#">903870611900</a> Collar	<a href="#">Buy now</a>
25	<a href="#">9011906M5900</a> Bolt, with washer	<a href="#">Buy now</a>
26	<a href="#">68V825940000</a> Clamp	<a href="#">Buy now</a>
27	<a href="#">9046412M5800</a> Clamp	<a href="#">Buy now</a>
28	<a href="#">68V855480000</a> Holder	<a href="#">Buy now</a>
29	<a href="#">977806052000</a> Screw, tapping(6k8)	<a href="#">Buy now</a>
30	<a href="#">68V819420000</a> Cover	<a href="#">Buy now</a>
31	<a href="#">67F2812A0000</a> Puller, fuse	<a href="#">Buy now</a>
32	<a href="#">68V825900000</a> Wire Harness assembly	<a href="#">Buy now</a>
33	<a href="#">67F821510000</a> Fuse	<a href="#">Buy now</a>
34	<a href="#">5JJ821516000</a> Fuse	<a href="#">Buy now</a>
35	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>

## Electrical 2




Ref	Part	
36	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
37	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>

## Electrical 3




Ref	Part	
1	<a href="#">67F8132G0100</a> Plate	<a href="#">Buy now</a>
2	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
3	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">68V8259M0100</a> Wire harness assembly 2	<a href="#">Buy now</a>
5	<a href="#">68V825880000</a> Plate	<a href="#">Buy now</a>
6	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
7	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">9046513M1800</a> Clamp	<a href="#">Buy now</a>
9	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
10	<a href="#">970950602000</a> Bolt(7u8)	<a href="#">Buy now</a>
11	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
13	<a href="#">67F857900000</a> Thermosensor assembly	<a href="#">Buy now</a>
14	<a href="#">67F857570000</a> Retainer	<a href="#">Buy now</a>
15	<a href="#">68V857530000</a> Gasket, sender unit	<a href="#">Buy now</a>
18	<a href="#">9046506M8600</a> Clamp	<a href="#">Buy now</a>

## Electrical 3




Ref	Part	
19	<a href="#">970850601000</a> Bolt	<a href="#">Buy now</a>
20	<a href="#">68V825040000</a> Oil pressure switch assembly	<a href="#">Buy now</a>
21	<a href="#">68V813150000</a> Lead wire assembly	<a href="#">Buy now</a>
22	<a href="#">63D825631000</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
23	<a href="#">6E5825870000</a> Gasket	<a href="#">Buy now</a>
24	<a href="#">67F836140000</a> Bracket	<a href="#">Buy now</a>
25	<a href="#">9010906M8600</a> Bolt	<a href="#">Buy now</a>

# Fuel




Ref	Part	
1	<a href="#">689855470000</a> Damper	<a href="#">Buy now</a>
2	<a href="#">6R3243770000</a> Pipe, joint 3	<a href="#">Buy now</a>
3	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
4	<a href="#">9044513M2700</a> Hose (I950)	<a href="#">Buy now</a>
5	<a href="#">6D8245600800</a> Filter assembly	<a href="#">Buy now</a>
6	<a href="#">68V245210100</a> Cup, filter	<a href="#">Buy now</a>
7	<a href="#">68V245630000</a> Element, filter	<a href="#">Buy now</a>
8	<a href="#">932103273800</a> O-ring(1wg)	<a href="#">Buy now</a>
9	<a href="#">68V244690100</a> Float, water level	<a href="#">Buy now</a>
10	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
11	<a href="#">68V245660000</a> Bracket Filter	<a href="#">Buy now</a>
12	<a href="#">953800860000</a> Nut (661)	<a href="#">Buy now</a>
13	<a href="#">970950601600</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
14	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
15	<a href="#">9044513M1100</a> Pipe, fuel 1	<a href="#">Buy now</a>

# Fuel




Ref	Part	
16	<a href="#">68V244100000</a> Fuel pump assembly	<a href="#">Buy now</a>
17	<a href="#">68V244120000</a> Body 1	<a href="#">Buy now</a>
18	<a href="#">68V244540000</a> Spring	<a href="#">Buy now</a>
19	<a href="#">68V131310000</a> Plunger	<a href="#">Buy now</a>
20	<a href="#">68V244230000</a> Spring, diaphragm	<a href="#">Buy now</a>
21	<a href="#">68V244110000</a> Diaphragm	<a href="#">Buy now</a>
22	<a href="#">68V243740000</a> Pin	<a href="#">Buy now</a>
23	<a href="#">68V244130000</a> Body 2	<a href="#">Buy now</a>
24	<a href="#">68V244710000</a> Diaphragm	<a href="#">Buy now</a>
25	<a href="#">68V244140000</a> Body 3	<a href="#">Buy now</a>
26	<a href="#">68V244440000</a> Screw	<a href="#">Buy now</a>
27	<a href="#">68V241490000</a> Nut	<a href="#">Buy now</a>
29	<a href="#">932103068200</a> O-ring (371)	<a href="#">Buy now</a>
30	<a href="#">9011906M8300</a> Bolt, with washer	<a href="#">Buy now</a>
31	<a href="#">67F245750000</a> Lever, fuel change	<a href="#">Buy now</a>

# Fuel



Ref	Part	
32	<a href="#">68V244950000</a> Shaft	<a href="#">Buy now</a>
33	<a href="#">916092501400</a> Pin, Spring	<a href="#">Buy now</a>
34	<a href="#">9020108M1200</a> Washer plate (682)	<a href="#">Buy now</a>
35	<a href="#">67F244910000</a> Bracket, fuel pump	<a href="#">Buy now</a>
36	<a href="#">901190723500</a> Bolt, with washer	<a href="#">Buy now</a>
37	<a href="#">918090800600</a> Pin, dowel	<a href="#">Buy now</a>
38	<a href="#">67F281000000</a> Tool kit	<a href="#">Buy now</a>


## Fuel 2



Flood Marine Services


Ref	Part	
1	<a href="#">6YK243064200</a> Fuel pipe comp. 1	<a href="#">Buy now</a>

# Fuel Injection Nozzle




Ref	Part	
1	<a href="#">68V131600000</a> Delivery pipe assembly 1	<a href="#">Buy now</a>
2	<a href="#">68V8A3600000</a> Injector unit	<a href="#">Buy now</a>
3	<a href="#">68V137660000</a> Rubber, injector	<a href="#">Buy now</a>
4	<a href="#">68V142250000</a> Cap	<a href="#">Buy now</a>
5	<a href="#">68V134350000</a> Nipple	<a href="#">Buy now</a>
6	<a href="#">68V143970000</a> O-ring	<a href="#">Buy now</a>
7	<a href="#">68V811470000</a> Screw 3	<a href="#">Buy now</a>
8	<a href="#">68V139060100</a> Regulator, pressure (with o-ri	<a href="#">Buy now</a>
9	<a href="#">68V145650000</a> Screw	<a href="#">Buy now</a>
10	<a href="#">68V143560000</a> Washer, spring	<a href="#">Buy now</a>
11	<a href="#">68V142640000</a> Collar	<a href="#">Buy now</a>
12	<a href="#">68V218410000</a> Cooler	<a href="#">Buy now</a>
13	<a href="#">68V139710000</a> Pipe Fuel 1	<a href="#">Buy now</a>
14	<a href="#">68V139720000</a> Pipe, fuel 2	<a href="#">Buy now</a>
15	<a href="#">68V245190000</a> Clip	<a href="#">Buy now</a>

## Fuel Injection Nozzle




Ref	Part	
16	<a href="#">68V2411M0000</a> Clip	<a href="#">Buy now</a>
17	<a href="#">68V147770000</a> Bolt	<a href="#">Buy now</a>
18	<a href="#">68V144280000</a> Bolt	<a href="#">Buy now</a>
19	<a href="#">68V144750000</a> Washer	<a href="#">Buy now</a>
20	<a href="#">68V143570000</a> Washer, plain	<a href="#">Buy now</a>
21	<a href="#">68V144460000</a> Bolt	<a href="#">Buy now</a>
22	<a href="#">68V142650000</a> Collar	<a href="#">Buy now</a>
23	<a href="#">970850601000</a> Bolt	<a href="#">Buy now</a>
24	<a href="#">904300601400</a> Gasket 256113960000	<a href="#">Buy now</a>
25	<a href="#">68V2247A0000</a> Hose 1	<a href="#">Buy now</a>
26	<a href="#">68V2247B0000</a> Hose 2	<a href="#">Buy now</a>
27	<a href="#">68V2481H0000</a> Clamp	<a href="#">Buy now</a>
28	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>

# Fuel Injection Pump




Ref	Part	
1	<a href="#">68V141800000</a> Float chamber assembly	<a href="#">Buy now</a>
2	<a href="#">68V141820000</a> Cover, Float Chamber	<a href="#">Buy now</a>
3	<a href="#">68V141810000</a> Body, float chamber 1	<a href="#">Buy now</a>
4	<a href="#">68V137690000</a> O-ring	<a href="#">Buy now</a>
5	<a href="#">68V149850000</a> Float	<a href="#">Buy now</a>
6	<a href="#">68V143860000</a> Pin, float	<a href="#">Buy now</a>
7	<a href="#">68V137810000</a> Damper, pump	<a href="#">Buy now</a>
8	<a href="#">68V139150000</a> Filter	<a href="#">Buy now</a>
9	<a href="#">68V137840000</a> Cover, pump	<a href="#">Buy now</a>
10	<a href="#">68V149840000</a> Gasket, float chamber	<a href="#">Buy now</a>
11	<a href="#">68V145670000</a> Screw	<a href="#">Buy now</a>
12	<a href="#">68V142550000</a> Plate, valve seat	<a href="#">Buy now</a>
13	<a href="#">68V145920000</a> Screw	<a href="#">Buy now</a>
14	<a href="#">68V141910000</a> Plug, drain	<a href="#">Buy now</a>
15	<a href="#">68V141260000</a> Washer	<a href="#">Buy now</a>

# Fuel Injection Pump




Ref	Part	
16	<a href="#">68V145460000</a> Valve, needle	<a href="#">Buy now</a>
17	<a href="#">68V139070000</a> Fuel pump comp.	<a href="#">Buy now</a>
18	<a href="#">68V148072000</a> CRANKCASE assembly	<a href="#">Buy now</a>
19	<a href="#">68V243870000</a> Clip	<a href="#">Buy now</a>
20	<a href="#">68V135930000</a> Damper	<a href="#">Buy now</a>
21	<a href="#">68V137160000</a> Collar	<a href="#">Buy now</a>
22	<a href="#">68V135420000</a> Hose, vacuum sensing 1	<a href="#">Buy now</a>
23	<a href="#">68V135330000</a> Hose, vacuum sensing 4	<a href="#">Buy now</a>
24	<a href="#">68V135440000</a> Hose Vacuum Sensing 2	<a href="#">Buy now</a>
25	<a href="#">68V135320000</a> Hose, vacuum sensing 3	<a href="#">Buy now</a>
26	<a href="#">68V135450000</a> Hose 1	<a href="#">Buy now</a>
27	<a href="#">68V135460000</a> Hose 2	<a href="#">Buy now</a>
28	<a href="#">68V243770000</a> Pipe, joint 1	<a href="#">Buy now</a>
29	<a href="#">68V243790000</a> Pipe, joint 4	<a href="#">Buy now</a>
30	<a href="#">68V135770000</a> Clip	<a href="#">Buy now</a>

# Fuel Injection Pump




Ref	Part	
31	<a href="#">68V135340000</a> Hose, vacuum sensing 5	<a href="#">Buy now</a>
32	<a href="#">68V135470100</a> Hose 3	<a href="#">Buy now</a>
33	<a href="#">68V142940000</a> Hose	<a href="#">Buy now</a>
34	<a href="#">68V2417H0000</a> Clamp 1	<a href="#">Buy now</a>
35	<a href="#">68V135350000</a> Hose, vacuum sensing 5	<a href="#">Buy now</a>
36	<a href="#">68V134900100</a> Relief Valve assembly	<a href="#">Buy now</a>

# Generator




Ref	Part	
1	<a href="#">68V814500000</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">68V814600000</a> Base assembly	<a href="#">Buy now</a>
3	<a href="#">68V855800000</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">68V814100000</a> Stator assembly	<a href="#">Buy now</a>
5	<a href="#">63D813452000</a> Screw, pan	<a href="#">Buy now</a>
6	<a href="#">985170401200</a> Screw, pan head	<a href="#">Buy now</a>
7	<a href="#">445813282000</a> Clamp, read	<a href="#">Buy now</a>
8	<a href="#">68V816730000</a> Rotor	<a href="#">Buy now</a>
9	<a href="#">995300801200</a> Pin, dowel(6g8)	<a href="#">Buy now</a>
10	<a href="#">970950603000</a> Bolt(jf7)	<a href="#">Buy now</a>
11	<a href="#">929950610000</a> Washer(6a1)	<a href="#">Buy now</a>
12	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">9028004M0800</a> Key, woodruff	<a href="#">Buy now</a>
14	<a href="#">9020125M0200</a> Washer, plate(61a)	<a href="#">Buy now</a>
15	<a href="#">9017024M2200</a> Nut(61a)	<a href="#">Buy now</a>

# Generator




Ref	Part	
16	<a href="#">67F813320000</a> Plate, timing	<a href="#">Buy now</a>
17	<a href="#">979850621000</a> Screw pan head	<a href="#">Buy now</a>
18	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
19	<a href="#">67F813370100</a> Cover, flywheel	<a href="#">Buy now</a>
20	<a href="#">9038706M7100</a> Collar (6g8)	<a href="#">Buy now</a>
21	<a href="#">9048015M3100</a> Grommet (6g1)	<a href="#">Buy now</a>
22	<a href="#">9011906M9200</a> Bolt, with washer	<a href="#">Buy now</a>

# Intake




Ref	Part	
1	<a href="#">975750854000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
2	<a href="#">9011908M6800</a> Bolt, with washer	<a href="#">Buy now</a>
3	<a href="#">9038708M3200</a> Collar	<a href="#">Buy now</a>
4	<a href="#">916905001400</a> Pin, spring (647)	<a href="#">Buy now</a>
5	<a href="#">68V136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
6	<a href="#">67F153730000</a> Pipe, breather	<a href="#">Buy now</a>
7	<a href="#">904651009800</a> Clamp	<a href="#">Buy now</a>
8	<a href="#">9046720M1500</a> Clip	<a href="#">Buy now</a>
9	<a href="#">9046512M0300</a> Clamp, cord (688)	<a href="#">Buy now</a>
10	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
11	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
12	<a href="#">68V142910000</a> Bracket 1	<a href="#">Buy now</a>
13	<a href="#">9011906M4900</a> Bolt, with washer	<a href="#">Buy now</a>
14	<a href="#">68V144400000</a> Silencer assembly Intake	<a href="#">Buy now</a>
15	<a href="#">9321048MJ900</a> O-ring	<a href="#">Buy now</a>

# Intake




Ref	Part	
16	<a href="#">9011906M8200</a> Bolt, with washer	<a href="#">Buy now</a>
17	<a href="#">9011906ME100</a> Bolt, with washer	<a href="#">Buy now</a>
18	<a href="#">65L858860000</a> Thermosensor	<a href="#">Buy now</a>
19	<a href="#">68V142920000</a> Bracket 2	<a href="#">Buy now</a>
20	<a href="#">970950802000</a> Bolt, hexagon	<a href="#">Buy now</a>
21	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>
22	<a href="#">9046513M1800</a> Clamp	<a href="#">Buy now</a>

# Intake 1




Ref	Part	
1	<a href="#">68V142000100</a> Intake assembly	<a href="#">Buy now</a>
2	<a href="#">68V137510100</a> Body, Throttle 1	<a href="#">Buy now</a>
3	<a href="#">68V143230000</a> Screw, air adjusting	<a href="#">Buy now</a>
4	<a href="#">68V143210000</a> Screw, throttle	<a href="#">Buy now</a>
5	<a href="#">68V143310000</a> Spring, throttle valve	<a href="#">Buy now</a>
6	<a href="#">68V137520100</a> Body, throttle 2	<a href="#">Buy now</a>
8	<a href="#">68V131050000</a> Control valve assembly	<a href="#">Buy now</a>
9	<a href="#">68V149600000</a> Body assembly	<a href="#">Buy now</a>
10	<a href="#">68V1312A0000</a> Valve, control	<a href="#">Buy now</a>
11	<a href="#">68V134730000</a> O-ring	<a href="#">Buy now</a>
12	<a href="#">68V811460000</a> Screw 2	<a href="#">Buy now</a>
13	<a href="#">68V811620000</a> Washer Plain	<a href="#">Buy now</a>
14	<a href="#">68V145110000</a> Filter assembly	<a href="#">Buy now</a>
15	<a href="#">68V811450100</a> Screw 1	<a href="#">Buy now</a>
17	<a href="#">68V858850000</a> Throttle sensor assembly	<a href="#">Buy now</a>

# Intake 1




Ref	Part	
18	<a href="#">68V8182L0000</a> O-ring 1	<a href="#">Buy now</a>
19	<a href="#">68V823800000</a> Sensor, pressure	<a href="#">Buy now</a>
20	<a href="#">68V811470000</a> Screw 3	<a href="#">Buy now</a>
21	<a href="#">68V144960000</a> Bolt	<a href="#">Buy now</a>
22	<a href="#">68V135740000</a> Bolt 2	<a href="#">Buy now</a>
23	<a href="#">68V153730000</a> Pipe, breather	<a href="#">Buy now</a>
24	<a href="#">68V147770000</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">68V144750000</a> Washer	<a href="#">Buy now</a>
26	<a href="#">68V144191000</a> Pipe	<a href="#">Buy now</a>
27	<a href="#">68V136410094</a> Manifold 1	<a href="#">Buy now</a>
28	<a href="#">995301011400</a> Pin, dowel(3vd)	<a href="#">Buy now</a>
29	<a href="#">9321048MG800</a> O-ring	<a href="#">Buy now</a>
30	<a href="#">68V412370000</a> Joint, link	<a href="#">Buy now</a>
31	<a href="#">6H4412370000</a> Joint, link	<a href="#">Buy now</a>
32	<a href="#">953800570000</a> Nut (656)	<a href="#">Buy now</a>

# Intake 1




Ref	Part	
33	<a href="#">68V1441L0000</a> Bracket 1	<a href="#">Buy now</a>
34	<a href="#">68V811450000</a> Screw 1	<a href="#">Buy now</a>
35	<a href="#">68V8259N0000</a> Wire Harness assembly 3	<a href="#">Buy now</a>
36	<a href="#">68V144530000</a> Joint, air cleaner 1	<a href="#">Buy now</a>
37	<a href="#">68V1441J0000</a> Pipe, silencer	<a href="#">Buy now</a>

## Lower Casing & Drive 3




Ref	Part	
1	<a href="#">68W45300308D</a> Lower Unit assembly	<a href="#">Buy now</a>
2	<a href="#">6E545301048D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93315628U900</a> Brg,cyl-cal roller (6e5)	<a href="#">Buy now</a>
4	<a href="#">93315345W000</a> Bearing, cylindrical(6l6)	<a href="#">Buy now</a>
5	<a href="#">93341360U800</a> Bearing, thrust (6l6)	<a href="#">Buy now</a>
6	<a href="#">6L6455380000</a> Spacer, 1	<a href="#">Buy now</a>
7	<a href="#">6E5455676000</a> Shim (t:0.50mm)	<a href="#">Buy now</a>
8	<a href="#">9034008M0400</a> Plug, straight screw	<a href="#">Buy now</a>
9	<a href="#">688453411000</a> Plug, drain	<a href="#">Buy now</a>
10	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
11	<a href="#">6E5455360000</a> Sleeve, drive shaft	<a href="#">Buy now</a>
12	<a href="#">6E5453780000</a> Nipple, hose	<a href="#">Buy now</a>
13	<a href="#">9044507MF200</a> Hose (l250)	<a href="#">Buy now</a>
14	<a href="#">6E5835581000</a> End, nipple	<a href="#">Buy now</a>
15	<a href="#">6E5453210000</a> Plate	<a href="#">Buy now</a>

## Lower Casing & Drive 3




Ref	Part	
16	<a href="#">932105867700</a> O-ring(47x)	<a href="#">Buy now</a>
17	<a href="#">931060901400</a> Oil seal	<a href="#">Buy now</a>
18	<a href="#">9011906M1000</a> Bolt, with washer	<a href="#">Buy now</a>
19	<a href="#">6E5441500200</a> Shift cam assembly	<a href="#">Buy now</a>
20	<a href="#">934300800600</a> Circlip(2r6)	<a href="#">Buy now</a>
21	<a href="#">9050111M1000</a> Spring, compression (663)	<a href="#">Buy now</a>
22	<a href="#">61A455380000</a> Spacer, 1	<a href="#">Buy now</a>
23	<a href="#">9020122M0100</a> Washer, plate(61a)	<a href="#">Buy now</a>
24	<a href="#">9020622M1900</a> Washer, wave(61a)	<a href="#">Buy now</a>
25	<a href="#">61A455270000</a> Collar, drive shaft	<a href="#">Buy now</a>
26	<a href="#">61A443110100</a> Housing, water pump	<a href="#">Buy now</a>
27	<a href="#">61A443220200</a> Insert, cartridge	<a href="#">Buy now</a>
28	<a href="#">9321086M3800</a> O-ring (6e5)	<a href="#">Buy now</a>
29	<a href="#">932103716000</a> O-ring (6g8)	<a href="#">Buy now</a>
30	<a href="#">6E5443520100</a> Impeller	<a href="#">Buy now</a>

## Lower Casing & Drive 3




Ref	Part	
31	<a href="#">9028004M0500</a> Key, woodruff (6e5)	<a href="#">Buy now</a>
32	<a href="#">6E5443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
33	<a href="#">6E544315A000</a> Gasket, water pump	<a href="#">Buy now</a>
34	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
35	<a href="#">9011908M1400</a> Bolt, with washer	<a href="#">Buy now</a>
36	<a href="#">6E5453310094</a> Housing, bearing	<a href="#">Buy now</a>
37	<a href="#">9310128M1600</a> Oil seal (6e5)	<a href="#">Buy now</a>
38	<a href="#">93315430V500</a> Bearing, cylindrical(6k0)	<a href="#">Buy now</a>
39	<a href="#">6E5455876000</a> Shim (t:0.50mm)	<a href="#">Buy now</a>
40	<a href="#">93341930V200</a> Bearing, thrust(64d)	<a href="#">Buy now</a>
41	<a href="#">9321055M1400</a> O-ring (70e)	<a href="#">Buy now</a>
42	<a href="#">6E5453440000</a> Cover, oil seal	<a href="#">Buy now</a>
43	<a href="#">970950802500</a> Bolt (62g)	<a href="#">Buy now</a>
44	<a href="#">929950860000</a> Washer, plain (663)	<a href="#">Buy now</a>
45	<a href="#">68V455013000</a> Drive shaft comp.	<a href="#">Buy now</a>

## Lower Casing & Drive 3




Ref	Part	
46	<a href="#">68V455510000</a> Pinion	<a href="#">Buy now</a>
47	<a href="#">9017016M0100</a> Nut, hexagon (688)	<a href="#">Buy now</a>
48	<a href="#">68W455600000</a> Gear	<a href="#">Buy now</a>
49	<a href="#">93315425U700</a> Brg,cyl-cal roller (6e5)	<a href="#">Buy now</a>
50	<a href="#">6K1456110000</a> Shaft, Propeller	<a href="#">Buy now</a>
51	<a href="#">9020126M0000</a> Washer, plate(6k0)	<a href="#">Buy now</a>
52	<a href="#">6L6456112000</a> Shaft, Propeller	<a href="#">Buy now</a>
53	<a href="#">6E5456410200</a> Shifter	<a href="#">Buy now</a>
54	<a href="#">6E5456340100</a> Slide, shift	<a href="#">Buy now</a>
55	<a href="#">9050116M3700</a> Spring (6g5)	<a href="#">Buy now</a>
56	<a href="#">935073200900</a> Ball (12r)	<a href="#">Buy now</a>
57	<a href="#">935113202700</a> Ball (498)	<a href="#">Buy now</a>
58	<a href="#">935031600300</a> Ball	<a href="#">Buy now</a>
59	<a href="#">9025008M0700</a> Pin, straight (6g5)	<a href="#">Buy now</a>
60	<a href="#">68V456310000</a> Clutch, dog	<a href="#">Buy now</a>

## Lower Casing & Drive 3




Ref	Part	
61	<a href="#">6E5456330100</a> Ring, cross pin	<a href="#">Buy now</a>
62	<a href="#">6L6453320094</a> Housing, bearing	<a href="#">Buy now</a>
63	<a href="#">93332000V700</a> Bearing(6l6)	<a href="#">Buy now</a>
64	<a href="#">68W455700000</a> Gear	<a href="#">Buy now</a>
66	<a href="#">6L6455760000</a> Washer, thrust	<a href="#">Buy now</a>
67	<a href="#">93341440U500</a> Bearing, thrust (6k0)	<a href="#">Buy now</a>
68	<a href="#">6K1455786000</a> Shim (t:0.50mm)	<a href="#">Buy now</a>
69	<a href="#">93315440V600</a> Bearing, cylindrical(6k0)	<a href="#">Buy now</a>
70	<a href="#">93317330U500</a> Bearing	<a href="#">Buy now</a>
71	<a href="#">9310130M1700</a> Oil seal (6e5)	<a href="#">Buy now</a>
72	<a href="#">9321086M3900</a> O-ring (6e5)	<a href="#">Buy now</a>
73	<a href="#">6L6455776000</a> Shim (t:0.50mm)	<a href="#">Buy now</a>
74	<a href="#">902820401000</a> Key, strait(663)	<a href="#">Buy now</a>
75	<a href="#">688453830200</a> Washer, claw	<a href="#">Buy now</a>
76	<a href="#">688453840000</a> Nut	<a href="#">Buy now</a>

## Lower Casing & Drive 4




Ref	Part	
1	<a href="#">6E5443660000</a> Damper, water seal 2	<a href="#">Buy now</a>
2	<a href="#">68V443613000</a> Tube, water 1	<a href="#">Buy now</a>
3	<a href="#">6E5443650000</a> Damper, water seal 1	<a href="#">Buy now</a>
4	<a href="#">6E5443120000</a> Cover, water pump housing	<a href="#">Buy now</a>
5	<a href="#">9360812M0500</a> Pin, dowel b (6e5)	<a href="#">Buy now</a>
6	<a href="#">970751004500</a> Bolt(64d)	<a href="#">Buy now</a>
7	<a href="#">929951010000</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
8	<a href="#">9011910M8900</a> Bolt, with washer	<a href="#">Buy now</a>
9	<a href="#">663453760000</a> Guide, seal damper	<a href="#">Buy now</a>
10	<a href="#">688453750000</a> Damper, seal 2	<a href="#">Buy now</a>
11	<a href="#">688452140200</a> Cover, water inlet	<a href="#">Buy now</a>
12	<a href="#">688452150200</a> Cover, water inlet	<a href="#">Buy now</a>
13	<a href="#">9015205M0700</a> Screw, countersunk	<a href="#">Buy now</a>
14	<a href="#">901850590400</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
15	<a href="#">6L6453710000</a> Tab-trim	<a href="#">Buy now</a>

## Lower Casing & Drive 4



Ref	Part	
16	<a href="#">9010510M0000</a> Bolt, hexagon (663)	<a href="#">Buy now</a>
17	<a href="#">90445070G600</a> Hose (l1700)	<a href="#">Buy now</a>
18	<a href="#">6E5835580000</a> End, nipple	<a href="#">Buy now</a>
19	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
22	<a href="#">6E5459870100</a> Spacer 1	<a href="#">Buy now</a>
23	<a href="#">688459970100</a> Spacer 2	<a href="#">Buy now</a>
24	<a href="#">929901820000</a> Washer (6e5)	<a href="#">Buy now</a>
25	<a href="#">9017118M0400</a> Nut, castle (6e5)	<a href="#">Buy now</a>
26	<a href="#">914904003000</a> Pin, cotter (663)	<a href="#">Buy now</a>
27	<a href="#">6L6459300198</a> Propeller (3x13"x17"-kl)	<a href="#">Buy now</a>

# Meter




Flood Marine Services

68V0300-0370


Ref	Part	
1	<a href="#">6Y583500T200</a> Digital tachometer assembly	<a href="#">Buy now</a>
2	<a href="#">9E4500443300</a> Housing, connector (m-4-w)	<a href="#">Buy now</a>
3	<a href="#">9E4500453300</a> Housing, f-4-w(5pcs)	<a href="#">Buy now</a>
4	<a href="#">929900410000</a> Ybs67-4 washer, spring	<a href="#">Buy now</a>
5	<a href="#">953800460000</a> Nut,hex	<a href="#">Buy now</a>
6	<a href="#">6Y583553N000</a> Wire, lead (l=2.5m)	<a href="#">Buy now</a>
7	<a href="#">1E6821510000</a> Fuse (10a)	<a href="#">Buy now</a>
8	<a href="#">6R3825218000</a> Wire, lead (for tacho., 8m)	<a href="#">Buy now</a>
9	<a href="#">6R3825538000</a> Wire, lead	<a href="#">Buy now</a>
10	<a href="#">6R3825533000</a> Wire, lead	<a href="#">Buy now</a>

# Oil Pan




Ref	Part	
1	<a href="#">67F15311005B</a> Oil pan set	<a href="#">Buy now</a>
2	<a href="#">67F153160000</a> Damper 1	<a href="#">Buy now</a>
3	<a href="#">9034014M0600</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
4	<a href="#">9043014M0900</a> Gasket	<a href="#">Buy now</a>
5	<a href="#">9010106M2700</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
7	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
8	<a href="#">67F153120000</a> Gasket, oil pan	<a href="#">Buy now</a>
9	<a href="#">67F134110000</a> Strainer, oil	<a href="#">Buy now</a>
10	<a href="#">970170602500</a> Bolt, hexagon	<a href="#">Buy now</a>
11	<a href="#">929070660000</a> Washer(6ta)	<a href="#">Buy now</a>
12	<a href="#">9038706M6400</a> Collar	<a href="#">Buy now</a>
13	<a href="#">67F134150000</a> Seal, oil strainer	<a href="#">Buy now</a>
14	<a href="#">67F133000000</a> Oil pump assembly	<a href="#">Buy now</a>
15	<a href="#">67F133380000</a> Seal	<a href="#">Buy now</a>

# Oil Pan




Ref	Part	
16	<a href="#">970800604500</a> Bolt, hexagon	<a href="#">Buy now</a>
18	<a href="#">9360412M0700</a> Pin, dowel (688)	<a href="#">Buy now</a>
19	<a href="#">9321019MJ100</a> O-ring	<a href="#">Buy now</a>
20	<a href="#">68V153620000</a> Plug, Oil Level	<a href="#">Buy now</a>

## Power Trim & Tilt Assy 1




Ref	Part	
1	<a href="#">68V43800004D</a> Power trim & tilt assembly	<a href="#">Buy now</a>
2	<a href="#">64E438250100</a> Housing Trim & Tilt	<a href="#">Buy now</a>
3	<a href="#">6AW4388J0000</a> Plug 2	<a href="#">Buy now</a>
4	<a href="#">9321010M7400</a> O-ring	<a href="#">Buy now</a>
5	<a href="#">64E438170000</a> Filter 2	<a href="#">Buy now</a>
6	<a href="#">64E438100000</a> Tilt piston sub assembly	<a href="#">Buy now</a>
7	<a href="#">64E438980000</a> Seal, dust 2	<a href="#">Buy now</a>
8	<a href="#">64E438670000</a> O-ring 7	<a href="#">Buy now</a>
9	<a href="#">64E438660000</a> O-ring 6	<a href="#">Buy now</a>
10	<a href="#">6E5438620000</a> O-ring 2	<a href="#">Buy now</a>
11	<a href="#">64E438830000</a> O-ring 10	<a href="#">Buy now</a>
12	<a href="#">6E5438720000</a> Ring, back-up 2	<a href="#">Buy now</a>
13	<a href="#">6E5438140200</a> Piston, free	<a href="#">Buy now</a>
15	<a href="#">64E438200000</a> Trim piston sub assembly	<a href="#">Buy now</a>
16	<a href="#">64E438210800</a> Screw, trim cylinder end	<a href="#">Buy now</a>

## Power Trim & Tilt Assy 1




Ref	Part	
17	<a href="#">64E438220000</a> Seal, trim dust	<a href="#">Buy now</a>
18	<a href="#">64E4384J0000</a> Seal, trim down	<a href="#">Buy now</a>
19	<a href="#">6G5438640000</a> O-ring 4	<a href="#">Buy now</a>
20	<a href="#">6E5438640000</a> O-ring 4	<a href="#">Buy now</a>
21	<a href="#">6E5438740100</a> Ring, back-up 4	<a href="#">Buy now</a>
22	<a href="#">64E438280100</a> Body, reservoir	<a href="#">Buy now</a>
23	<a href="#">64E438290000</a> Plug, reservoir	<a href="#">Buy now</a>
24	<a href="#">64E438970000</a> O-ring	<a href="#">Buy now</a>
25	<a href="#">64E4388E0100</a> Bolt ,screw (l:14mm)	<a href="#">Buy now</a>
26	<a href="#">64E438690000</a> O-ring 9	<a href="#">Buy now</a>
27	<a href="#">64E4381G0000</a> Pin 1	<a href="#">Buy now</a>
28	<a href="#">6E5438580000</a> Ball 1	<a href="#">Buy now</a>
29	<a href="#">64E4382G0000</a> Valve seat	<a href="#">Buy now</a>
30	<a href="#">9020108M1400</a> Washer, plate	<a href="#">Buy now</a>
31	<a href="#">970800801600</a> Bolt	<a href="#">Buy now</a>

## Power Trim & Tilt Assy 1




Ref	Part	
32	<a href="#">64E438180100</a> Lower shock mount pin set	<a href="#">Buy now</a>
33	<a href="#">9038622M9800</a> Bush(61u)	<a href="#">Buy now</a>

## Power Trim & Tilt Assy 2




Ref	Part	
1	<a href="#">64E4388E1000</a> Bolt ,screw (l:34.7mm)	<a href="#">Buy now</a>
2	<a href="#">64E438310000</a> Connector, shaft	<a href="#">Buy now</a>
3	<a href="#">64E438680000</a> O-ring 8	<a href="#">Buy now</a>
4	<a href="#">68V438300000</a> Gear pump assembly	<a href="#">Buy now</a>
5	<a href="#">72X438580000</a> Ball	<a href="#">Buy now</a>
6	<a href="#">64E438430000</a> Screw, valve lock	<a href="#">Buy now</a>
7	<a href="#">64E438410000</a> Piston, shuttle	<a href="#">Buy now</a>
8	<a href="#">64E438020000</a> Valve sub assembly	<a href="#">Buy now</a>
9	<a href="#">6E5438960000</a> O-ring	<a href="#">Buy now</a>
10	<a href="#">6G5438630000</a> O-ring 3	<a href="#">Buy now</a>
11	<a href="#">66Y438510000</a> Seat, relief valve	<a href="#">Buy now</a>
12	<a href="#">64E438580000</a> Ball	<a href="#">Buy now</a>
13	<a href="#">64E438590000</a> Pin, Valve Support	<a href="#">Buy now</a>
14	<a href="#">68V438550000</a> Spring Up Relief	<a href="#">Buy now</a>
15	<a href="#">6E5438260100</a> Plug, taper screw	<a href="#">Buy now</a>

## Power Trim & Tilt Assy 2




Ref	Part	
16	<a href="#">64E438500000</a> Valve sub assembly	<a href="#">Buy now</a>
17	<a href="#">6E5438830000</a> O-ring 10	<a href="#">Buy now</a>
18	<a href="#">64E438160000</a> Filter 1	<a href="#">Buy now</a>
20	<a href="#">64E438171000</a> Filter 2	<a href="#">Buy now</a>
21	<a href="#">64E438600100</a> Manual valve sub-assembly	<a href="#">Buy now</a>
22	<a href="#">72X85075L000</a> O-ring (nsd161)	<a href="#">Buy now</a>
23	<a href="#">64E438270000</a> Ring set	<a href="#">Buy now</a>
24	<a href="#">64E438750000</a> Ring, snap	<a href="#">Buy now</a>
25	<a href="#">64E438791100</a> Screw, with washer	<a href="#">Buy now</a>
26	<a href="#">64E438790000</a> Screw, with washer	<a href="#">Buy now</a>
27	<a href="#">68V438800000</a> Motor assembly	<a href="#">Buy now</a>
28	<a href="#">6H14386K1000</a> Spring, brush	<a href="#">Buy now</a>
29	<a href="#">64E4380J0000</a> Holder Brush	<a href="#">Buy now</a>
30	<a href="#">64E438910000</a> Brush 1	<a href="#">Buy now</a>
31	<a href="#">985070401000</a> Screw, pan head(6g8)	<a href="#">Buy now</a>

## Power Trim & Tilt Assy 2




Ref	Part	
32	<a href="#">64E4380F0000</a> Holder, brush 2	<a href="#">Buy now</a>
33	<a href="#">64E438920000</a> Breaker comp. (brush 2)	<a href="#">Buy now</a>
34	<a href="#">6G5438650100</a> O-ring	<a href="#">Buy now</a>
35	<a href="#">9310208M4300</a> Oil seal(6b0)	<a href="#">Buy now</a>
36	<a href="#">64E438050000</a> Armature assembly	<a href="#">Buy now</a>
37	<a href="#">64E438431000</a> Screw valve lock	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
1	<a href="#">704482072300</a> Remote Control assembly	<a href="#">Buy now</a>
2	<a href="#">978900501600</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
3	<a href="#">EL8482510000</a> Plate, cam	<a href="#">Buy now</a>
4	<a href="#">704482650000</a> Shaft, friction	<a href="#">Buy now</a>
5	<a href="#">701482460000</a> Spacer	<a href="#">Buy now</a>
6	<a href="#">934300602400</a> Circlip (701)	<a href="#">Buy now</a>
7	<a href="#">EL8482590000</a> Circlip 1	<a href="#">Buy now</a>
8	<a href="#">704482620000</a> Shaft, throttle	<a href="#">Buy now</a>
9	<a href="#">704482640000</a> Friction, throttle	<a href="#">Buy now</a>
10	<a href="#">704482660000</a> Spacer 2	<a href="#">Buy now</a>
11	<a href="#">704825401000</a> Neutral switch assembly	<a href="#">Buy now</a>
12	<a href="#">985800301400</a> Screw, pan head (n151)	<a href="#">Buy now</a>
13	<a href="#">EL8482810000</a> Screw 1	<a href="#">Buy now</a>
14	<a href="#">704482151000</a> Graphic 1	<a href="#">Buy now</a>
15	<a href="#">704482810000</a> Screw1	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
16	<a href="#">985800552500</a> Screw, panhead (a93)	<a href="#">Buy now</a>
17	<a href="#">704482610000</a> Arm, throttle	<a href="#">Buy now</a>
18	<a href="#">EL8481910000</a> Washer 1	<a href="#">Buy now</a>
19	<a href="#">985800554000</a> Screw, panhead (eg9)	<a href="#">Buy now</a>
20	<a href="#">970800601800</a> Bolt (fj0)	<a href="#">Buy now</a>
21	<a href="#">703483450100</a> Cable end, remote control 2	<a href="#">Buy now</a>
22	<a href="#">704482870000</a> Washer 1	<a href="#">Buy now</a>
23	<a href="#">953800560000</a> Nut, hexagon (663)	<a href="#">Buy now</a>
24	<a href="#">EL8482710000</a> Arm, shift	<a href="#">Buy now</a>
25	<a href="#">EL8481270000</a> Screw 1	<a href="#">Buy now</a>
26	<a href="#">703483580000</a> Anchor, cable	<a href="#">Buy now</a>
27	<a href="#">EL8482310000</a> Housing, gear	<a href="#">Buy now</a>
28	<a href="#">EL8482410000</a> Arm, drive	<a href="#">Buy now</a>
29	<a href="#">EL8482540000</a> Stopper Throttle Adjusting	<a href="#">Buy now</a>
30	<a href="#">987800602000</a> Screw flat head	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
31	<a href="#">EL8481580000</a> Spring 1	<a href="#">Buy now</a>
32	<a href="#">985800400600</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
33	<a href="#">987800501800</a> Screw (704)	<a href="#">Buy now</a>
34	<a href="#">EL8482440000</a> Spring, free accel.	<a href="#">Buy now</a>
35	<a href="#">EL8482450000</a> Plate, lock	<a href="#">Buy now</a>
36	<a href="#">704482220000</a> Grip, control lever	<a href="#">Buy now</a>
37	<a href="#">704825940000</a> Clamp	<a href="#">Buy now</a>
38	<a href="#">704482280000</a> Holder, switch	<a href="#">Buy now</a>
39	<a href="#">704825633100</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
40	<a href="#">704482290000</a> Grip, control lever 2	<a href="#">Buy now</a>
41	<a href="#">929900530000</a> Washer, tooth	<a href="#">Buy now</a>
42	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
43	<a href="#">701482480000</a> Roller, free accel	<a href="#">Buy now</a>
44	<a href="#">703482380000</a> Spring, detent	<a href="#">Buy now</a>
45	<a href="#">EL8482320000</a> Gear 1	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
46	<a href="#">EL8481640000</a> Pin 2	<a href="#">Buy now</a>
47	<a href="#">704482420000</a> Shaft, drive	<a href="#">Buy now</a>
48	<a href="#">704482250000</a> Cover	<a href="#">Buy now</a>
49	<a href="#">704481920000</a> Washer 2	<a href="#">Buy now</a>
50	<a href="#">978900601800</a> Screw, pan head(6e5)	<a href="#">Buy now</a>
51	<a href="#">929900630000</a> Washer, tooth	<a href="#">Buy now</a>
53	<a href="#">EL8482790000</a> Circlip 2	<a href="#">Buy now</a>
54	<a href="#">704481930000</a> Washer 3	<a href="#">Buy now</a>
55	<a href="#">EL8482340000</a> Bushing 1	<a href="#">Buy now</a>
56	<a href="#">704482190000</a> Cover, lead	<a href="#">Buy now</a>
57	<a href="#">704481440000</a> Plate, stopper 2	<a href="#">Buy now</a>
58	<a href="#">704481761000</a> Grommet	<a href="#">Buy now</a>
59	<a href="#">703481920000</a> Washer 2	<a href="#">Buy now</a>
60	<a href="#">EL8482330000</a> Gear 2	<a href="#">Buy now</a>
61	<a href="#">703482350000</a> Bushing	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
62	<a href="#">704482820000</a> Screw 2	<a href="#">Buy now</a>
63	<a href="#">EL8481531000</a> Shaft, free accel.	<a href="#">Buy now</a>
64	<a href="#">704481660000</a> Plug	<a href="#">Buy now</a>
65	<a href="#">704482840000</a> Grommet	<a href="#">Buy now</a>
66	<a href="#">704819500000</a> Relay assembly	<a href="#">Buy now</a>
67	<a href="#">704825901000</a> Wireharness assembly	<a href="#">Buy now</a>
68	<a href="#">704482291000</a> Grip, control lever 2	<a href="#">Buy now</a>
69	<a href="#">70482563F000</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
70	<a href="#">704482281000</a> Holder, switch	<a href="#">Buy now</a>
71	<a href="#">985800555500</a> Screw, pan head	<a href="#">Buy now</a>
72	<a href="#">704481560000</a> Nut 1	<a href="#">Buy now</a>
74	<a href="#">704482850000</a> Grommet 2	<a href="#">Buy now</a>
75	<a href="#">704482860000</a> Grommet 3	<a href="#">Buy now</a>
76	<a href="#">704481780000</a> Plate, shift	<a href="#">Buy now</a>
77	<a href="#">704482210000</a> Lever control	<a href="#">Buy now</a>

## Remote Control Assy 2



Ref	Part	
78	<a href="#">704481192000</a> Cover	<a href="#">Buy now</a>


## Remote Control Box



  
67H0100-9310


Ref	Part	
2	<a href="#">704482072300</a> Remote Control assembly	<a href="#">Buy now</a>
3	<a href="#">701483502000</a> Cable, Remote Control L=23F	<a href="#">Buy now</a>

# Repair Kit 1




Ref	Part	
1	<a href="#">68VW00010000</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">904300814300</a> Gasket (256-11198-00)	<a href="#">Buy now</a>
3	<a href="#">9321024M7900</a> O-ring	<a href="#">Buy now</a>
4	<a href="#">67F111810300</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
5	<a href="#">9310238M5900</a> Oil seal	<a href="#">Buy now</a>
6	<a href="#">904301411500</a> Gasket (663)	<a href="#">Buy now</a>
7	<a href="#">67F12435A000</a> Gasket	<a href="#">Buy now</a>
8	<a href="#">68V857530000</a> Gasket, sender unit	<a href="#">Buy now</a>
9	<a href="#">67F41114A200</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
10	<a href="#">9310248M6000</a> Oil seal	<a href="#">Buy now</a>
11	<a href="#">9310148M6800</a> Oil seal	<a href="#">Buy now</a>
12	<a href="#">904301813000</a> Gasket (1j7)	<a href="#">Buy now</a>
13	<a href="#">67F113510100</a> Gasket, cylinder	<a href="#">Buy now</a>
14	<a href="#">68V136450000</a> Gasket, manifold 1	<a href="#">Buy now</a>
15	<a href="#">9321048MG800</a> O-ring	<a href="#">Buy now</a>

## Repair Kit 1




Ref	Part	
16	<a href="#">932103068200</a> O-ring (371)	<a href="#">Buy now</a>
17	<a href="#">67F113560000</a> Seal, cylinder 2	<a href="#">Buy now</a>
18	<a href="#">904300601400</a> Gasket 256113960000	<a href="#">Buy now</a>
19	<a href="#">9321048MJ900</a> O-ring	<a href="#">Buy now</a>

## Repair Kit 2




Ref	Part	
1	<a href="#">68VW00012000</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">904300802000</a> Gasket	<a href="#">Buy now</a>
3	<a href="#">932105814400</a> O-ring(47x)	<a href="#">Buy now</a>
4	<a href="#">931060901400</a> Oil seal	<a href="#">Buy now</a>
5	<a href="#">9321086M3800</a> O-ring (6e5)	<a href="#">Buy now</a>
6	<a href="#">932103716000</a> O-ring (6g8)	<a href="#">Buy now</a>
7	<a href="#">6E544315A000</a> Gasket,water pump	<a href="#">Buy now</a>
8	<a href="#">9310128M1600</a> Oil seal (6e5)	<a href="#">Buy now</a>
9	<a href="#">9321055M1400</a> O-ring (70e)	<a href="#">Buy now</a>
10	<a href="#">9310130M1700</a> Oil seal (6e5)	<a href="#">Buy now</a>
11	<a href="#">9321086M3900</a> O-ring (6e5)	<a href="#">Buy now</a>
12	<a href="#">9321019MJ100</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">67F451130000</a> Gasket, upper casing	<a href="#">Buy now</a>
14	<a href="#">67F153120000</a> Gasket, oil pan	<a href="#">Buy now</a>
15	<a href="#">67F134150000</a> Seal, oil strainer	<a href="#">Buy now</a>

## Repair Kit 2




Ref	Part	
16	<a href="#">67F41133A100</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
17	<a href="#">932100916500</a> O-ring	<a href="#">Buy now</a>
18	<a href="#">68V451230000</a> Gasket, muffler	<a href="#">Buy now</a>
19	<a href="#">67F451270000</a> Seal	<a href="#">Buy now</a>
20	<a href="#">9043014M0900</a> Gasket	<a href="#">Buy now</a>
21	<a href="#">67F41134A000</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
22	<a href="#">67F411380000</a> Seal, ext. 1	<a href="#">Buy now</a>
23	<a href="#">6N6W00780200</a> Water pump repair kit	<a href="#">Buy now</a>
24	<a href="#">61A443220200</a> Insert, cartridge	<a href="#">Buy now</a>
27	<a href="#">6E5443520100</a> Impeller	<a href="#">Buy now</a>
28	<a href="#">6E5443230000</a> Outer plate, cartridge	<a href="#">Buy now</a>
30	<a href="#">936061201900</a> Pin, dowel (614)	<a href="#">Buy now</a>
31	<a href="#">9011908M1400</a> Bolt, with washer	<a href="#">Buy now</a>
32	<a href="#">9028004M0500</a> Key, woodruff (6e5)	<a href="#">Buy now</a>

# Starting Motor




Ref	Part	
1	<a href="#">68V818000100</a> Starting motor assembly	<a href="#">Buy now</a>
2	<a href="#">67F818500000</a> Armature assembly	<a href="#">Buy now</a>
3	<a href="#">67F818100000</a> Stator assembly	<a href="#">Buy now</a>
4	<a href="#">68F818400000</a> Brush holder assembly	<a href="#">Buy now</a>
5	<a href="#">67F818010000</a> Brush set	<a href="#">Buy now</a>
6	<a href="#">67F818130000</a> Spring, brush	<a href="#">Buy now</a>
7	<a href="#">68F818200000</a> Rear bracket assembly	<a href="#">Buy now</a>
8	<a href="#">67F818080000</a> Pinion assembly	<a href="#">Buy now</a>
9	<a href="#">67F818570000</a> Pinion stopper set	<a href="#">Buy now</a>
10	<a href="#">67F818070000</a> Gear assembly, starting motor	<a href="#">Buy now</a>
11	<a href="#">67F818320000</a> Clutch, over run	<a href="#">Buy now</a>
12	<a href="#">67F818360000</a> Shaft, pinion	<a href="#">Buy now</a>
13	<a href="#">67F818210000</a> Bracket, center 1	<a href="#">Buy now</a>
14	<a href="#">67F818410000</a> Bearing	<a href="#">Buy now</a>
15	<a href="#">67F818910000</a> Gear, ring	<a href="#">Buy now</a>

# Starting Motor




Ref	Part	
16	<a href="#">67F8183R0000</a> Gasket	<a href="#">Buy now</a>
17	<a href="#">67F818300000</a> Bracket, center 2	<a href="#">Buy now</a>
18	<a href="#">67F8183T0000</a> Gear, idler	<a href="#">Buy now</a>
19	<a href="#">67F818090000</a> Washer kit	<a href="#">Buy now</a>
20	<a href="#">67F818420000</a> Cover	<a href="#">Buy now</a>
21	<a href="#">67F818390000</a> Lever assembly	<a href="#">Buy now</a>
22	<a href="#">68V819410100</a> Starter relay assembly	<a href="#">Buy now</a>
23	<a href="#">67F818690000</a> Cover, dust	<a href="#">Buy now</a>
24	<a href="#">6K7818261100</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">67F818280000</a> Bolt 2	<a href="#">Buy now</a>
26	<a href="#">67F818460000</a> Screw	<a href="#">Buy now</a>
27	<a href="#">901790800300</a> Nut	<a href="#">Buy now</a>
28	<a href="#">60V819250000</a> Terminal	<a href="#">Buy now</a>
29	<a href="#">68F825820000</a> Cover, wire harness	<a href="#">Buy now</a>
30	<a href="#">970130804500</a> Bolt	<a href="#">Buy now</a>

# Starting Motor



Ref	Part	
31	<a href="#">929901010000</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
32	<a href="#">953330860000</a> Nut(6I2)	<a href="#">Buy now</a>
33	<a href="#">929030810000</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>


## Steering Guide Attachment 1



67H0100-9290

Ref	Part	
1	<a href="#">6E5613500200</a> Steering guide attachment kit	<a href="#">Buy now</a>
2	<a href="#">6E5613510100</a> Rod, steering link	<a href="#">Buy now</a>
3	<a href="#">9038710M6100</a> Collar (6e5)	<a href="#">Buy now</a>
4	<a href="#">9056012M0100</a> Spacer (6e5)	<a href="#">Buy now</a>
5	<a href="#">6E5613550000</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">9018509M0100</a> Nut, nylon (663)	<a href="#">Buy now</a>
7	<a href="#">9020110M2000</a> Washer, plate (663)	<a href="#">Buy now</a>
8	<a href="#">6E5431450100</a> Cap, clamp bracket	<a href="#">Buy now</a>
9	<a href="#">932101627500</a> O-ring	<a href="#">Buy now</a>


## Steering Guide Attachment 2



67H0100-0300

Ref	Part	
1	<a href="#">6E5613010100</a> Tie bar assembly (l:600-800mm)	<a href="#">Buy now</a>
2	<a href="#">6E5613130000</a> Adjuster	<a href="#">Buy now</a>
3	<a href="#">6E5613111100</a> Tie bar	<a href="#">Buy now</a>
4	<a href="#">6E5613150000</a> Tie bar, 2	<a href="#">Buy now</a>
5	<a href="#">6E5613030000</a> Steering axle comp.	<a href="#">Buy now</a>
6	<a href="#">9017014M0600</a> Nut (6e5)	<a href="#">Buy now</a>
7	<a href="#">953801470000</a> Nut (6e5)	<a href="#">Buy now</a>
8	<a href="#">9020110M7600</a> Washer, plate (6e5)	<a href="#">Buy now</a>
9	<a href="#">9010109M7000</a> Bolt (6e5)	<a href="#">Buy now</a>
10	<a href="#">9017009M0500</a> Nut, hexagon (6e5)	<a href="#">Buy now</a>
11	<a href="#">9018509M0100</a> Nut, nylon (663)	<a href="#">Buy now</a>


## Switch & Panel



68V0100-0400

Ref	Part	
1	<a href="#">61B825700100</a> Panel switch assembly	<a href="#">Buy now</a>
2	<a href="#">61B825880100</a> Plate	<a href="#">Buy now</a>
3	<a href="#">61B825510100</a> Stop Switch assembly	<a href="#">Buy now</a>
4	<a href="#">61B825100000</a> Main switch assembly	<a href="#">Buy now</a>
5	<a href="#">6K1825750100</a> Engine stop switch assembly	<a href="#">Buy now</a>
6	<a href="#">682825560000</a> Lanyard, stop switch	<a href="#">Buy now</a>
7	<a href="#">6K1836140100</a> Bracket	<a href="#">Buy now</a>
8	<a href="#">989800501000</a> Screw, bind(6k1)	<a href="#">Buy now</a>
9	<a href="#">929900510000</a> Ybs67-5 washer, spring	<a href="#">Buy now</a>
10	<a href="#">953800560000</a> Nut, hexagon (663)	<a href="#">Buy now</a>
11	<a href="#">6R5833830000</a> Buzzer	<a href="#">Buy now</a>
12	<a href="#">61B858300000</a> Control Unit assembly	<a href="#">Buy now</a>
13	<a href="#">989800602000</a> Screw, bind (j17)	<a href="#">Buy now</a>
14	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
15	<a href="#">929900610000</a> Washer(6a1)	<a href="#">Buy now</a>


## Switch & Panel



  
68V0100-0400


Ref	Part	
16	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">9014905M0500</a> Screw(6k0)	<a href="#">Buy now</a>
20	<a href="#">929900560000</a> Washer, plain (646)	<a href="#">Buy now</a>
21	<a href="#">6K18258A4000</a> Extension, wire harness	<a href="#">Buy now</a>

## Top Cowling




Ref	Part	
1	<a href="#">68V42610018D</a> Top Cowling assembly	<a href="#">Buy now</a>
2	<a href="#">68V426470000</a> Holder Clamp Band	<a href="#">Buy now</a>
3	<a href="#">929900610000</a> Washer(6a1)	<a href="#">Buy now</a>
4	<a href="#">953800660000</a> Nut(661)	<a href="#">Buy now</a>
5	<a href="#">68V426510000</a> Hook	<a href="#">Buy now</a>
6	<a href="#">970950601200</a> Bolt(gh1)	<a href="#">Buy now</a>
7	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">68V426520000</a> Hook	<a href="#">Buy now</a>
9	<a href="#">970800601200</a> Bolt(gh1)	<a href="#">Buy now</a>
11	<a href="#">67F426490000</a> Holder, clamp band	<a href="#">Buy now</a>
14	<a href="#">67F426620000</a> Damper	<a href="#">Buy now</a>
15	<a href="#">68V426130000</a> Molding, air duct	<a href="#">Buy now</a>
17	<a href="#">68V426290000</a> Seal	<a href="#">Buy now</a>
18	<a href="#">68V42612008D</a> Air duct, top cowling	<a href="#">Buy now</a>
19	<a href="#">9017906M2800</a> Nut(63v)	<a href="#">Buy now</a>

## Top Cowling




Ref	Part	
20	<a href="#">68V426280000</a> Seal	<a href="#">Buy now</a>
21	<a href="#">68V427180000</a> Rubber, seal 3	<a href="#">Buy now</a>
22	<a href="#">68V426150000</a> Seal	<a href="#">Buy now</a>
23	<a href="#">68V426320000</a> Window	<a href="#">Buy now</a>
24	<a href="#">68V426340000</a> Seal, Window	<a href="#">Buy now</a>
25	<a href="#">929900520000</a> Ybs66-5 washer, plain	<a href="#">Buy now</a>
26	<a href="#">977805062500</a> Screw, tapping	<a href="#">Buy now</a>
27	<a href="#">68V426773000</a> Graphic, front	<a href="#">Buy now</a>
28	<a href="#">68V426780000</a> Graphic, front	<a href="#">Buy now</a>
29	<a href="#">68VW00700000</a> Graphic Set	<a href="#">Buy now</a>
30	<a href="#">68V426810000</a> Emblem, yamaha	<a href="#">Buy now</a>
31	<a href="#">992410028000</a> Emblem, yamaha	<a href="#">Buy now</a>
32	<a href="#">68V426170000</a> Damper Form	<a href="#">Buy now</a>
33	<a href="#">68V426190000</a> Damper, form	<a href="#">Buy now</a>
34	<a href="#">6H3443910100</a> Nipple, hose	<a href="#">Buy now</a>

## Top Cowling




Ref	Part	
35	<a href="#">9044510M4300</a> Hose (l400)	<a href="#">Buy now</a>
36	<a href="#">9046511M1000</a> Clamp	<a href="#">Buy now</a>
37	<a href="#">9046508M6300</a> Clamp(61u)	<a href="#">Buy now</a>
38	<a href="#">977805062000</a> Screw, tapping	<a href="#">Buy now</a>

## Upper Casing




Ref	Part	
1	<a href="#">67F411370194</a> Guide, exhaust	<a href="#">Buy now</a>
2	<a href="#">975750854000</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
3	<a href="#">9360816M1600</a> Pin, dowel(6t4)	<a href="#">Buy now</a>
4	<a href="#">6G1427270000</a> Grommet	<a href="#">Buy now</a>
5	<a href="#">67F4113101CA</a> Manifold, ext. 1	<a href="#">Buy now</a>
6	<a href="#">67F41133A000</a> Gasket, exhaust manifold 1	<a href="#">Buy now</a>
7	<a href="#">970750607000</a> Bolt(4kg)	<a href="#">Buy now</a>
8	<a href="#">929900660000</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">68V14711305B</a> Muffler 1	<a href="#">Buy now</a>
10	<a href="#">68V451230000</a> Gasket, muffler	<a href="#">Buy now</a>
11	<a href="#">970800603000</a> Bolt(jf7)	<a href="#">Buy now</a>
12	<a href="#">929950660000</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">9360619M2300</a> Pin, dowel	<a href="#">Buy now</a>
14	<a href="#">67F41134A000</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
15	<a href="#">67F4518100CA</a> Plate	<a href="#">Buy now</a>

## Upper Casing




Ref	Part	
16	<a href="#">67F411380000</a> Seal, ext. 1	<a href="#">Buy now</a>
17	<a href="#">67F451270000</a> Seal	<a href="#">Buy now</a>
18	<a href="#">68V45111308D</a> Casing, upper	<a href="#">Buy now</a>
19	<a href="#">9011910M0800</a> Bolt, with washer	<a href="#">Buy now</a>
21	<a href="#">6E5453180000</a> Bushing, drive shaft 3	<a href="#">Buy now</a>
22	<a href="#">9342036M0100</a> Circlip (6a0)	<a href="#">Buy now</a>
23	<a href="#">67F451510000</a> Cover, upper casing	<a href="#">Buy now</a>
24	<a href="#">985800601600</a> Screw pan head	<a href="#">Buy now</a>
26	<a href="#">6H3451550000</a> Cap	<a href="#">Buy now</a>
27	<a href="#">67F451130000</a> Gasket, upper casing	<a href="#">Buy now</a>
28	<a href="#">970850601000</a> Bolt	<a href="#">Buy now</a>
30	<a href="#">9011908M5800</a> Bolt, with washer	<a href="#">Buy now</a>
31	<a href="#">67F427240000</a> Grommet	<a href="#">Buy now</a>

# Valve



Ref	Part	
1	<a href="#">68V121110000</a> Valve, intake	<a href="#">Buy now</a>
2	<a href="#">68V121210000</a> Valve, exhaust	<a href="#">Buy now</a>
3	<a href="#">67F121160000</a> Seat, valve spring	<a href="#">Buy now</a>
4	<a href="#">67F121140000</a> Spring, valve outer	<a href="#">Buy now</a>
5	<a href="#">67F121170000</a> Retainer, valve spring	<a href="#">Buy now</a>
6	<a href="#">67F121180000</a> Cotter, valve	<a href="#">Buy now</a>
7	<a href="#">K0AA37210000</a> Seal, valve stem	<a href="#">Buy now</a>
8	<a href="#">K0AA37220000</a> Seal, valve stem 2	<a href="#">Buy now</a>
9	<a href="#">67F121530000</a> Lifter, valve	<a href="#">Buy now</a>
10	<a href="#">67F121697000</a> Pad, adjusting (2.950)	<a href="#">Buy now</a>
11	<a href="#">67F121710000</a> Camshaft 1	<a href="#">Buy now</a>
12	<a href="#">6D8121810000</a> Camshaft 2	<a href="#">Buy now</a>
13	<a href="#">936051010800</a> Pin, dowel (8g8)	<a href="#">Buy now</a>
14	<a href="#">67F115370000</a> Gear, driven	<a href="#">Buy now</a>
15	<a href="#">9011910M0600</a> Bolt	<a href="#">Buy now</a>

# Valve



Ref	Part	
16	<a href="#">9310238M5900</a> Oil seal	<a href="#">Buy now</a>
17	<a href="#">67F462410000</a> Belt	<a href="#">Buy now</a>
18	<a href="#">67F115900000</a> Tensioner assembly	<a href="#">Buy now</a>
19	<a href="#">9050616M3900</a> Spring, tension	<a href="#">Buy now</a>
20	<a href="#">9044515M0300</a> Hose (I23)	<a href="#">Buy now</a>
21	<a href="#">67F115950000</a> Plate, valve	<a href="#">Buy now</a>
22	<a href="#">9011910M7200</a> Bolt, with washer(6m6)	<a href="#">Buy now</a>
23	<a href="#">67F115360000</a> Gear Drive	<a href="#">Buy now</a>
24	<a href="#">901704000300</a> Nut	<a href="#">Buy now</a>
25	<a href="#">902800400800</a> Key woodruff 604115450000	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.