



Yamaha FT9.9DMH 2002

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	6
BRACKET 2	9
CARBURETOR	11
CONTROL	13
CRANKSHAFT. PISTON	16
CYLINDER. CRANKCASE 1	18
CYLINDER. CRANKCASE 2	20
ELECTRICAL 1	21
ELECTRICAL 2	23
FUEL	25
FUEL TANK	27
GENERATOR	28
INTAKE	29
LOWER CASING. DRIVE 1	31
LOWER CASING. DRIVE 2	35
OIL PAN	37
OIL PUMP	39
REMOTE CONTROL ASSY	41
REMOTE CONTROL ATTACHMENT	46
REMOTE CONTROL BOX	48
REPAIR KIT 1	49
REPAIR KIT 2	51
REPAIR KIT 3	52
STARTER	54
STARTING MOTOR	57
STEERING	58
STEERING FRICTION	62
STEERING GUIDE	63
TOP COWLING	64
UPPER CASING	65
VALVE	66

Bottom Cowling




 FWD
66R1300-2150

C7

Ref	Part	
1	66M-42710-03-4D Bottom Cowling assembly	Buy now
2	97095-06035 Bolt(j52)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	97095-06025 Bolt	Buy now
6	90480-15M31 Grommet (6g1)	Buy now
7	90387-06M52 Collar (6g1)	Buy now
8	66M-42716-00 Rubber, seal 1	Buy now
9	66M-42738-00-4D Plate, fitting	Buy now
10	90109-06M82 Bolt	Buy now
11	66M-42725-00 Grommet	Buy now
11	66M-42725-20 Grommet	Buy now
12	62Y-42727-00 Grommet	Buy now
12	65W-42727-00 Grommet	Buy now
13	66M-42815-00-4D Lever, clamp 1	Buy now
14	90386-12M37 Bushing (6f5)	Buy now

Bottom Cowling




 66R1300-2150

C7

Ref	Part	
15	90386-12MA2 Bush	Buy now
16	90206-12052 Washer, wave (666)	Buy now
17	6L2-42816-00 Lever, clamp	Buy now
18	97095-06012 Bolt(gh1)	Buy now
19	66M-42766-00 Bracket 2	Buy now
20	90109-06M86 Bolt	Buy now
21	6H3-44391-01 Nipple, hose	Buy now
22	65W-26326-10 Grommet	Buy now
22	66M-26326-00 Grommet	Buy now
23	682-42727-00 Grommet	Buy now
24	682-42724-00 Grommet	Buy now
25	65W-42726-00 Grommet	Buy now
25	65W-42726-10 Grommet	Buy now
26	66M-42743-00 Bracket	Buy now
28	90465-25M57 Clamp(63v)	Buy now

Bottom Cowling





66R1300-2150

Ref	Part	
29	90464-09M13 Clamp (6h1)	Buy now
30	66R-44532-00 Stopper Upper Mount	Buy now
31	6H4-42726-00 Grommet	Buy now
32	62Y-82377-00 Label	Buy now
33	6A1-28176-00 Label Caution	Buy now
34	6E3-8257H-00 Plate Mark	Buy now
35	6G8-13444-51 Mark	Buy now

C7

Bracket 1




 66R0700-1200

E2

Ref	Part	
1	63V-43111-05-4D Bracket, clamp 1	Buy now
2	63V-43112-06-4D Bracket, clamp 2	Buy now
3	66M-82148-00 Wire, lead 4	Buy now
4	97885-06008 Screw, pan head(6a3)	Buy now
5	6E0-43118-01 Handle, transom clamp	Buy now
6	90243-04M01 Pin(6a1)	Buy now
7	6E7-43116-00 Screw, transom clamp	Buy now
8	648-43114-01 Pad, transom clamp	Buy now
9	63W-43131-10 Bolt, clamp bracket FOR RIDE GUIDE	Buy now
10	90202-22M54 Washer, plate(63v)	Buy now
11	90386-22M94 Bush(63v)	Buy now
13	66R-43113-00 Plate, clamp bracket	Buy now
14	90185-22043 Nut, self-locking	Buy now
15	90387-06M13 Collar(6h6)	Buy now
16	90101-06M29 Bolt, hexagon (682)	Buy now

Bracket 1




 FWD
 66R0700-1200

E2

Ref	Part	
17	92995-06600 Washer, plain (646)	Buy now
18	95380-06700 Nut	Buy now
19	6L2-43160-00 Tilt rod assembly	Buy now
20	66M-43311-10-4D Bracket, swivel 1 L,X	Buy now
21	66M-43630-01 Tilt lever assembly	Buy now
22	682-43318-01 Cover	Buy now
23	63V-43191-00 Shaft, stopper	Buy now
24	90202-07M60 Washer, plate	Buy now
25	90387-07M07 Collar	Buy now
26	90386-07M95 Bush(63v)	Buy now
27	66M-43350-01 Receiver assembly	Buy now
28	90507-20M00 Spring, tension(63v)	Buy now
29	63V-43641-01 Lever, tilt	Buy now
30	90157-05014 Screw, pan head	Buy now
31	99080-05600 Circlip(22k)	Buy now

Bracket 1




66R0700-1200

E2

Ref	Part	
32	66R-43614-00 Plate, tilt lock	Buy now
33	90508-18M41 Spring, torsion	Buy now
34	66R-43615-00 Plate, tilt lock	Buy now
35	66R-43611-00 Shaft, tilt lock	Buy now
36	93430-04M03 Circlip (eu0)	Buy now
37	63V-43659-00 Shaft, reverse lock	Buy now
39	66R-43617-00 Rod, tilt lock	Buy now
40	90506-26M38 Spring, reverse lock 1	Buy now
41	63V-43181-00 Lever, tilt stop 1	Buy now
42	90109-06M84 Bolt	Buy now
43	90206-10M24 Washer, wave	Buy now
44	90101-08M88 Bolt (6g8)	Buy now
45	92995-08600 Washer, plain (663)	Buy now
46	90185-08057 Nut, nylon (6j8)	Buy now
47	90201-08MA4 Washer, plate (6g8)	Buy now


Bracket 2



E4


Ref	Part	
1	93700-06M03 Nipple, grease(6a1)	Buy now
2	63V-42528-00 Plate, friction	Buy now
3	689-43373-01 Seal, damper	Buy now
4	90105-06M07 Bolt (689)	Buy now
5	66M-82127-00 Wire, Lead 2	Buy now
6	66M-42511-11-4D Bracket, steering L,X	Buy now
7	90209-40008 Washer	Buy now
8	65F-42537-00 Bushing, pivot shaft	Buy now
9	90386-30048 Bush	Buy now
10	93210-29M94 O-ring(6h1)	Buy now
11	90386-30M60 Bush(6j8)	Buy now
12	90116-08M54 Bolt, stud(63v)	Buy now
13	90201-08M06 Washer, plate	Buy now
14	66M-44514-00-4D Mount damper, upper side	Buy now
15	66M-44526-00 Plate	Buy now

Bracket 2



Ref	Part	
16	95380-08600 Nut (661)	Buy now
17	66M-44366-00 Damper, water seal	Buy now
18	97075-06025 Bolt	Buy now
19	92995-06600 Washer, plain (646)	Buy now
20	66M-44551-00-4D Housing, lower mount rubber 1	Buy now
21	66M-44557-00 Mount damper, lower front	Buy now
22	682-44555-30 Mount damper, lower side	Buy now
23	90119-08M45 Bolt, with washer	Buy now
24	90119-08M46 Bolt, with washer	Buy now
25	90179-08M34 Nut	Buy now
26	66R-44533-00 Damper, upper mount rubber	Buy now
27	63V-48511-01 Hook, steering	Buy now
28	97075-08035 Bolt(70w)	Buy now
29	92995-08600 Washer, plain (663)	Buy now
30	90185-08057 Nut, nylon (6j8)	Buy now

Carburetor




66R0010-9070

B4

Ref	Part	
1	66R-14301-00 Carburetor assembly 1	Buy now
2	66N-14381-00 Body, Float Chamber	Buy now
3	62Y-14383-00 Screw, drain	Buy now
4	66M-14398-00 Gasket	Buy now
5	66M-14384-00 Gasket, float chamber	Buy now
6	6L2-14385-00 Float	Buy now
7	6E5-14386-01 Pin, float	Buy now
8	6L2-14392-00 Valve, needle	Buy now
9	97980-04110 Screw, pan head (e56)	Buy now
10	6L2-14157-00 Cover, mixing	Buy now
11	62Y-14399-00 Gasket	Buy now
12	66N-14341-00 Nozzle, main	Buy now
13	66N-14343-34 Jet, main (#68)	Buy now
14	66M-14342-23 Jet, pilot (#45)	Buy now
15	62Y-14355-00 Plug	Buy now

Carburetor




 66R0010-9070

Ref	Part	
16	5H0-14323-00 Pilot screw set	Buy now
17	30X-14334-00 Spring, air adjusting	Buy now
18	62Y-14521-00 Screw, adjust	Buy now
19	97980-04112 Screw, pan head (686)	Buy now
20	62Y-14397-00 O-ring	Buy now
21	98980-04006 Screw, bind(6l2)	Buy now
22	646-14212-01 Spring, pilot adjusting	Buy now
23	6F5-14397-00 O-ring	Buy now
24	66M-14827-00 Filter	Buy now
25	97890-04005 Screw, pan head(6g8)	Buy now
26	66M-14157-00 Cover Mixing	Buy now
27	98580-03005 Screw, pan head(78g)	Buy now

B4

Control




66R0700-118C

D6

Ref	Part	
1	65W-44121-00 Lever, shift rod	Buy now
2	66M-44122-00 Bushing, shift rod lever	Buy now
3	90254-03M05 Pin, spring	Buy now
4	6F5-41662-00 Bracket 2	Buy now
5	90109-06M81 Bolt	Buy now
6	65W-44116-00 Spring	Buy now
7	66R-44117-00 Bracket	Buy now
8	90109-06M86 Bolt	Buy now
9	66M-44143-10 Rod, shift L,X	Buy now
10	90170-06015 Connector, shift rod	Buy now
11	95380-06700 Nut	Buy now
12	90468-18008 Clip 620436610000	Buy now
13	65W-44142-00 Joint	Buy now
15	65W-44125-00 Lever, shift rod	Buy now
16	90387-06M29 Coller (6a0)	Buy now


Control



D6

Ref	Part	
17	90201-06M31 Washer (6a0)	Buy now
18	97095-06025 Bolt	Buy now
19	92995-06600 Washer, plain (646)	Buy now
20	66M-44192-00 Joint, rod 1	Buy now
21	90201-05M06 Washer, plate(61u)	Buy now
22	90468-10005 Pin, hair 6264123500	Buy now
24	65W-41638-00 Pulley	Buy now
25	65W-41283-00 Lever, free accel.	Buy now
26	661-41262-02 Joint, choke lever	Buy now
27	90387-06M08 Collar	Buy now
28	66M-41211-00 Link, accel.	Buy now
29	65W-14497-01 Stay, Throttle Wire	Buy now
31	97095-06055 Bolt, hexagon w/w deep recess	Buy now
33	97095-06010 Bolt	Buy now
34	663-48344-00 Cable end, remote control	Buy now

Control




66R0700-1180

D6

Ref	Part	
36	6H3-48538-00 Clamp, cable	Buy now

Crankshaft. Piston




 FWD
66M0010-8031

A7

Ref	Part	
1	93102-35M51 Oil seal	Buy now
2	93102-25M52 Oil seal	Buy now
3	66M-11411-00 Crankshaft	Buy now
4	66M-11416-00 Plane bearing, crankshaft 1 UR BROWN	Buy now
4	66M-11416-10 Plane bearing, crankshaft 1 UR BLACK	Buy now
4	66M-11416-20 Plane bearing, crankshaft 1 UR BLUE	Buy now
5	66M-11650-00 Connecting rod kit	Buy now
6	66M-11654-00 Bolt, connecting rod	Buy now
7	90201-07M01 Washer, plate	Buy now
8	66M-11631-00-96 Piston (std)	Buy now
8	66M-11635-00 Piston (0.25mm o/s) AP	Buy now
8	66M-11636-00 Piston (0.50Mm O/S) AP	Buy now
9	66M-11603-00 Piston ring set (std)	Buy now
9	66M-11604-00 Piston ring set (0.25mm o/s) AP	Buy now
9	66M-11605-00 Piston ring set (0.50mm o/s) AP	Buy now

Crankshaft. Piston


Ref	Part	
10	634-11633-00 Pin, piston	Buy now
11	93450-15023 Circlip 131116340000	Buy now



 FWD
66M0010-8031

A7


Cylinder. Crankcase 1



A5

Ref	Part	
3	99510-10114 Pin, dowel(3vd)	Buy now
4	90119-08M66 Bolt, with washer	Buy now
5	90119-06M14 Bolt, with washer (677)	Buy now
6	6E5-24377-00 Pipe, joint	Buy now
7	90445-10M46 Hose (I200)	Buy now
8	66M-11325-00 Anode	Buy now
10	66M-11328-00 Grommet, anode	Buy now
11	97095-06020 Bolt(7u8)	Buy now
12	92995-06600 Washer, plain (646)	Buy now
13	97095-05012 Bolt, hexagon	Buy now
14	92995-05600 Washer, plain (646)	Buy now
15	66M-12535-00 Plate	Buy now
18	66M-11357-00 Seal, cylinder 3	Buy now
21	66M-11351-00 Gasket, cylinder	Buy now
22	66M-12411-00 Thermostat	Buy now

Cylinder. Crankcase 1




66R1300-2020

A5

Ref	Part	
24	62Y-12414-00 Gasket, cover	Buy now
26	676-11372-00 Nipple, hose	Buy now
27	66M-41114-00 Gasket, exhaust outer cover	Buy now
28	90119-06MA4 Bolt, with washer	Buy now
29	90445-09061 Hose (L65)	Buy now
30	688-24378-00 Pipe, joint	Buy now
31	90445-09086 Hose (I1500)	Buy now
32	90445-09105 Hose (I420)	Buy now
33	5GH-13440-00 Element assembly, oil cleaner	Buy now
34	90401-20M00 Bolt, union(62y)	Buy now


Cylinder. Crankcase 2



Ref	Part	
3	66M-11133-10 Guide Valve 1	Buy now
4	93450-09M01 Circlip (6g8)	Buy now
5	66M-11181-00 Gasket, cylinder head 1	Buy now
6	99510-10114 Pin, dowel(3vd)	Buy now
7	90105-08M78 Bolt, washer based	Buy now
8	90119-06MA3 Bolt, with washer	Buy now
10	66M-11356-00 Seal, cylinder 2	Buy now
11	97095-06020 Bolt(7u8)	Buy now
12	92995-06600 Washer, plain (646)	Buy now
13	6G8-15363-00 Plug, oil	Buy now
14	93210-24M79 O-ring	Buy now
15	66M-12138-60 Mark Caution	Buy now
16	94701-00375 Plug, spark (dpr6ea-9)(62y)	Buy now

B1

Electrical 1




66R0700-1120

C4

Ref	Part	
1	<u>66M-85540-01</u> C.d.i. Unit assembly	Buy now
2	<u>97095-06020</u> Bolt(7u8)	Buy now
3	<u>92995-06600</u> Washer, plain (646)	Buy now
4	<u>66M-85570-00</u> Ignition coil assembly	Buy now
5	<u>90480-25161</u> Grommet(656)	Buy now
8	<u>6G8-82370-30</u> Plug cap assembly	Buy now
9	<u>62Y-82504-10</u> Oil pressure switch assembly	Buy now
10	<u>66M-82127-10</u> Wire, lead 2	Buy now
11	<u>65W-85410-01</u> Emergency signal light assembly	Buy now
12	<u>6H1-83557-00</u> Tube	Buy now
13	<u>66M-85542-10</u> Bracket	Buy now
14	<u>90387-06M05</u> Collar(6h4)	Buy now
15	<u>90480-13M24</u> Grommet (6e9)	Buy now
16	<u>95895-06020</u> Bolt, flange(jk3)	Buy now
17	<u>90201-06M05</u> Washer, plate(6e3)	Buy now

Electrical 1




66R0700-1120

C4


Ref	Part	
18	97095-06025 Bolt	Buy now
20	90464-09M13 Clamp (6h1)	Buy now
21	6G8-81960-A1 Rectifier & regulator assembly	Buy now
22	97095-06016 Bolt, hexagon deep recess	Buy now
24	6G8-82150-00 Fuse holder assembly	Buy now
25	663-82151-00 Fuse	Buy now
26	6G5-82152-00 Holder, fuse	Buy now

Flood Marine Services



C5


Ref	Part	
1	6G1-81941-10 Starter relay	Buy now
2	6G1-81952-00 Holder, relay	Buy now
3	66M-82117-00 Wire, lead	Buy now
4	65W-8182B-00 Nut, special	Buy now
5	66R-82105-00 Battery cable	Buy now
6	95380-08700 Nut(661)	Buy now
7	92990-08600 Washer, plain (663)	Buy now
8	66M-86111-00 Coil, solenoid	Buy now
9	66M-86116-00 Wire, Pull	Buy now
10	66M-86112-00 Stay Solenoid	Buy now
11	97880-05008 Screw, with washer	Buy now
12	92990-05600 Washer, plain (646)	Buy now
13	97095-06016 Bolt, hexagon deep recess	Buy now
14	92995-06600 Washer, plain (646)	Buy now
15	90480-10M13 Grommet (6e0)	Buy now



Ref	Part	
16	66M-86117-00 Hook, wire pull	Buy now
17	93210-03261 O-ring (663)	Buy now
18	66M-82590-00 Wire Harness assembly	Buy now
19	6G1-42725-00 Grommet	Buy now


C5

Fuel



B6

Ref	Part	
1	6G1-24304-02 Fuel pipe joint comp. 1	Buy now
2	97095-06020 Bolt(7u8)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	90445-10M40 Hose (l400)	Buy now
5	65W-24251-00 Strainer 1	Buy now
6	90445-10M20 Hose (l400)	Buy now
7	90467-09M03 Clip(6k8)	Buy now
8	90465-11M10 Clamp	Buy now
9	66M-24410-10 Fuel pump assembly	Buy now
10	66M-24413-01 Body 2	Buy now
11	6A0-24421-01 Valve, check	Buy now
12	66M-24411-10 Diaphragm	Buy now
13	66M-24423-00 Spring, diaphragm	Buy now
14	66M-13131-10 Plunger	Buy now
15	66M-24454-00 Spring	Buy now




66M0010-9090

Be

Ref	Part	
16	66M-24444-00 Screw	Buy now
17	66M-24471-00 Diaphragm	Buy now
18	6E7-14325-00 Screw, pan head	Buy now
19	95380-05600 Nut, hexagon (663)	Buy now
20	66M-24374-00 Pin	Buy now
21	97880-06030 Screw, pan head(6e0)	Buy now
22	92990-06100 Washer(6a1)	Buy now
23	92990-06600 Washer, plain (646)	Buy now
24	93210-20M65 O-ring	Buy now
25	90445-10M93 Hose (l400)	Buy now
27	90465-06M86 Clamp	Buy now
28	90464-09M31 Clamp(6m7)	Buy now
29	62Y-28100-00 Tool kit	Buy now


Fuel Tank



F5

Ref	Part	
1	6YL-24201-02 Fuel Tank assembly AP	Buy now
2	6YL-24610-00 Cap Assembly	Buy now
3	6YL-24641-00 Gasket, cap 1	Buy now
4	6YL-24260-01 Fuel meter assembly	Buy now
5	90157-05M16 Screw, pan head	Buy now
6	6YL-24329-00 Seal	Buy now
7	6YL-24268-01 Gasket, fuel meter	Buy now
8	6YL-24306-52 Fuel pipe comp. 1 AP	Buy now


Generator



C3

Ref	Part	
1	66M-85550-00 Rotor assembly WITHOUT RING GEAR	Buy now
1	66M-85550-10 Rotor assembly WITH RING GEAR	Buy now
2	66M-85520-00 Coil, charge	Buy now
3	66M-85580-00 Coil, pulser	Buy now
4	66M-85533-10 Coil, Lighting 10A	Buy now
5	97095-06025 Bolt	Buy now
6	92995-06100 Washer(6a1)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	97095-06016 Bolt, hexagon deep recess	Buy now
10	97095-06040 Bolt (682)	Buy now
12	90280-05013 Key, woodruff	Buy now
13	90179-16M05 Nut (689)	Buy now
14	90201-16M44 Washer (689)	Buy now


Intake



B3

Ref	Part	
1	66M-13641-00-94 Manifold 1	Buy now
2	66M-13645-00 Gasket, manifold 1	Buy now
3	97095-06040 Bolt (682)	Buy now
4	92995-06600 Washer, plain (646)	Buy now
5	93606-12019 Pin, dowel (614)	Buy now
6	66M-13646-00 Gasket, manifold 2	Buy now
7	66M-14271-00 Insulator	Buy now
8	66M-14440-00 Silencer assembly, intake	Buy now
9	93210-35M86 O-ring(6l2)	Buy now
10	90119-06M76 Bolt, with washer	Buy now
11	90387-06M79 Collar	Buy now
12	66M-14477-00 Plate	Buy now
13	66M-41271-00 Knob, choke	Buy now
14	689-41273-00 Grommet	Buy now
15	66M-41292-00 Bush 2	Buy now

Intake




69B0010-0060

Ref	Part	
16	66M-41298-00 Washer 2	Buy now
17	97780-50510 Screw, tapping(6u1)	Buy now
18	66M-41252-00 Lever, choke 1	Buy now
19	90240-05M20 Pin, clevis	Buy now
20	90206-05005 Washer, wave(656)	Buy now
21	91690-20016 Pin, spring (677)	Buy now
22	90202-05088 Washer, plate (666)	Buy now
23	6R5-41237-00 Joint, link	Buy now
24	66M-41256-00 Rod, choke 1	Buy now
25	66M-15373-00 Pipe, breather	Buy now
26	90465-08M82 Clamp	Buy now
27	90465-08M83 Clamp	Buy now


B3

Lower Casing. Drive 1




Ref	Part	
1	66R-45300-11-4D 24 – L	Buy now
1	66R-45300-21-4D Lower unit assembly X	Buy now
2	66R-45311-01-4D Casing, lower	Buy now
3	93315-314V8 Bearing, needle (6e7)	Buy now
4	66R-45536-00 Sleeve, drive shaft	Buy now
5	93341-41416 Bearing	Buy now
6	66R-45587-00-13 Shim (t:1.13mm) UR	Buy now
6	66R-45587-00-20 Shim (t:1.2mm) UR	Buy now
7	93332-00005 Brg,cyl-cal roller 0.19g nt	Buy now
8	626-45577-00-01 Shim (t:0.10mm) UR	Buy now
8	626-45577-00-03 Shim (t:0.30mm) UR	Buy now
8	626-45577-00-05 Shim (t:0.50mm) UR	Buy now
9	90340-08002 Plug, straight screw	Buy now
10	90430-08020 Gasket	Buy now
11	63V-44301-00 Water pump housing comp.	Buy now

Lower Casing. Drive 1




Ref	Part	
12	63V-44322-00 Insert, cartridge	Buy now
13	647-44366-00 Damper, water seal 2	Buy now
14	63V-44352-01 Impeller	Buy now
15	664-44338-00 Key, woodruff	Buy now
16	93210-44398 O-ring(55x)	Buy now
17	63V-44323-00 Outer plate, cartridge	Buy now
18	93604-12M07 Pin, dowel (688)	Buy now
19	97080-08045 Bolt, hexagon	Buy now
20	63V-44328-00 Plate	Buy now
21	63V-45331-00-5B Housing, bearing	Buy now
22	90381-14020 Bushing, drive shaft 1	Buy now
23	93101-20048 Oil seal (20x30x6-648)	Buy now
24	63V-45315-A0 Packing, lower casing	Buy now
25	93210-06ME6 O-ring	Buy now
26	97080-08025 Screw, bind(j36)	Buy now

Lower Casing. Drive 1



Ref	Part	
27	66R-44150-10 Shift cam assembly L	Buy now
27	66R-44150-20 Shift Cam assembly X	Buy now
28	66R-45510-10 Drive Shaft assembly L	Buy now
28	66R-45510-20 Drive Shaft assembly X	Buy now
29	66R-45551-00 Pinion	Buy now
30	90179-08M06 Nut (6e7)	Buy now
31	66R-45560-00 Gear	Buy now
32	66R-45571-00 Gear	Buy now
34	90201-17682 Washer, plate (2k7)	Buy now
35	683-45611-00 Shaft propeller	Buy now
36	650-45635-00 Plunger, shift	Buy now
37	682-45631-00 Clutch, dog	Buy now
38	90250-05010 Pin straight 648456320000	Buy now
39	648-45633-00 Ring, cross pin	Buy now
40	90501-14M09 Spring, compression	Buy now


Lower Casing. Drive 1



F1


Ref	Part	
41	66R-45361-00-4D Cap, lower casing	Buy now
42	93306-00501 Bearing(1ff)	Buy now
43	93315-317U2 Brg,cyl-cal roller 14g (683)	Buy now
44	93101-17054 Oil seal (17x30x6-650)	Buy now
45	93210-74M68 O-ring (6g8)	Buy now
46	93210-74316 O-ring (1j7)	Buy now
47	97095-06025 Bolt	Buy now
48	92995-06600 Washer, plain (646)	Buy now

Lower Casing. Drive 2



Ref	Part	
1	66M-44361-10 Tube, water L	Buy now
1	66R-44361-20 Tube Water X	Buy now
2	63V-44365-10 Damper, water seal 1	Buy now
3	63V-44368-00 Rubber, water seal 4	Buy now
4	93604-12M07 Pin, dowel (688)	Buy now
5	97075-08035 Bolt(70w) L	Buy now
6	92995-08600 Washer, plain (663) L	Buy now
7	6G1-45214-00 Cover, water inlet	Buy now
8	63V-45215-00 Cover, water inlet	Buy now
9	90152-05M04 Screw, countersunk	Buy now
10	90185-05002 Nut nylon (sus)(ex4)	Buy now
11	61N-45251-01 Anode	Buy now
12	95895-06030 Bolt, flange deep recess	Buy now
13	92990-06300 Washer, tooth	Buy now
14	63V-45375-00 Damper, seal	Buy now


Lower Casing. Drive 2



Ref	Part	
15	6G8-45987-02 Spacer	Buy now
16	93450-10M04 Circlip(6g8)	Buy now
17	90201-31MA3 Washer, plate (6g8)	Buy now
18	6G8-45986-00 Ring, deflector	Buy now
19	90201-10M02 Washer, plate(6g9)	Buy now
20	90171-10M07 Nut, castle(6g8)	Buy now
21	91490-30025 Pin cotter	Buy now
22	6G8-45941-00 Propeller (pa 3x11-3/4"x11"-r) UR	Buy now
22	6G8-45943-00 Propeller (pa 3x11-3/4"x9-1/4" UR	Buy now
22	6G8-45945-00 Propeller (pa 3x11-3/4"x12-1/4 UR	Buy now
22	6G8-45947-00-EL Propeller (3x11-3/4"x9-1/4"-r) UR ALUMINIUM	Buy now

F4


Oil Pan



E7

Ref	Part	
1	66M-41137-00-5B Guide, exhaust	Buy now
2	93101-12M63 Oil seal	Buy now
3	93606-12019 Pin, dowel (614)	Buy now
4	66M-11355-00 Seal, cylinder 1	Buy now
5	97095-06020 Bolt(7u8)	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	66M-41131-01-94 Manifold, Ext. 1	Buy now
8	66M-41133-00 Gasket, exhaust manifold 1	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
11	66M-41138-00 Seal, ext. 1	Buy now
12	66M-13421-00 Strainer 2	Buy now
13	66M-13417-00 Cover, Strainer	Buy now
14	66M-13416-00 Pipe Oil 1	Buy now
15	66M-24351-00 Band 1	Buy now
16	6G8-11575-00 Relief valve ass'y	Buy now


Oil Pan



E7

Ref	Part	
17	90340-14M06 Plug, straight screw(62y)	Buy now
18	90430-14M09 Gasket	Buy now
19	66M-15316-00 Damper 1	Buy now
20	66M-15362-00 Plug, Oil Level	Buy now


Oil Pump



B5

Ref	Part	
1	93102-18M21 Oil seal (6g8)	Buy now
2	66M-12170-00 Camshaft assembly 1	Buy now
2	66M-12171-10 Camshaft 1	Buy now
3	66M-11537-00-94 Gear, driven	Buy now
4	97013-06016 Bolt, hexagon deep recess	Buy now
5	90201-13201 Washer 6474283300	Buy now
6	90201-06M94 Washer (6g8)	Buy now
7	66M-11536-10 Gear, drive	Buy now
8	66M-11557-00 Washer 1	Buy now
9	90170-28M37 Nut	Buy now
10	90280-03M01 Key woodruff 146115450000	Buy now
11	66M-46241-00 Belt	Buy now
12	66M-46297-00 Cover, dust	Buy now
13	90480-10M16 Grommet(6j8)	Buy now
14	90480-12072 Grommet(53y)	Buy now


Oil Pump



Ref	Part	
15	66M-13300-10 Oil Pump assembly	Buy now
16	66M-13329-10 Gasket, pump cover	Buy now
17	97095-06035 Bolt(j52)	Buy now
18	92995-06600 Washer, plain (646)	Buy now


B5

Remote Control Assy



Ref	Part	
1	703-48203-15 Remote control assembly (7p) AP	Buy now
2	703-48261-01 Arm, throttle	Buy now
3	703-48153-00 Shaft, free accel.	Buy now
4	703-48235-00 Bushing	Buy now
5	703-48268-00 Spacer 3	Buy now
6	703-48264-00 Throttle, friction	Buy now
7	95380-05600 Nut, hexagon (663)	Buy now
8	97380-05025 Bolt	Buy now
9	703-48265-00 Shaft Friction	Buy now
10	93430-06024 Circlip (701)	Buy now
11	703-48245-00 Plate, lock	Buy now
12	703-48252-00 Roller, cam	Buy now
13	701-48248-00 Roller, free accel	Buy now
14	703-48198-00 Washer, wave 3	Buy now
15	703-48243-00 Bushing 3	Buy now


Remote Control Assy



A4

Ref	Part	
16	703-48236-00 Bushing	Buy now
17	703-48189-00 Retainer	Buy now
18	703-48234-00 Roller, detent	Buy now
19	703-48345-01 Cable end, remote control 2	Buy now
20	703-48358-00 Anchor, cable	Buy now
21	703-48244-00 Spring, free accel.	Buy now
22	703-48238-00 Spring, detent	Buy now
23	703-48246-00 Spacer 1	Buy now
24	703-48227-00 Spring, neutral lock	Buy now
25	703-48226-00 Plate, stopper	Buy now
26	703-48222-00 Grip, control lever SINGLE	Buy now
27	703-48223-00 Lock, neutral	Buy now
28	703-48225-00 Cover	Buy now
29	703-48219-00 Cover, lead	Buy now
30	703-48281-00 Screw, flat head	Buy now


Remote Control Assy



A4

Ref	Part	
31	703-48282-00 Screw	Buy now
32	97380-08030 Bolt, hexagon (fj1)	Buy now
33	92990-08600 Washer, plain (663)	Buy now
34	98580-04010 Screw, pan head (e56)	Buy now
35	98580-04006 Screw, pan head (7h3)	Buy now
36	98580-05010 Screw, pan head(62x)	Buy now
37	98580-03015 Screw, pan head (n151)	Buy now
38	703-48291-10 Screw	Buy now
39	95380-06600 Nut(661)	Buy now
40	703-48293-10 Spacer, remote control SINGLE	Buy now
41	701-48287-00 Washer 1	Buy now
42	703-48215-00 Graphic	Buy now
43	703-82510-33 Main switch assembly	Buy now
44	703-82577-00 Cap, key	Buy now
45	703-82531-00 Wire, lead	Buy now

Remote Control Assy




A4

Ref	Part	
46	688-82575-01 Engine stop switch assembly	Buy now
47	682-82556-00 Lanyard, stop switch	Buy now
48	688-82586-21 Extension, wire harness L)5M (7P)	Buy now
49	703-82540-00 Neutral switch assembly	Buy now
50	703-83383-02 Buzzer	Buy now
51	703-48284-00 Grommet	Buy now
52	703-82591-00 Band	Buy now
53	703-82592-00 Band	Buy now
54	703-48224-00 Cover, control lever WITHOUT PT/T SW.	Buy now
55	703-48221-00 Grip	Buy now
56	703-48152-00 Knob, free accel	Buy now
57	703-48212-00 Rear housing	Buy now
58	703-48213-00 Back, panel	Buy now
59	703-48271-00 Arm, shift	Buy now
60	703-48211-01 Housing,1	Buy now


Remote Control Assy

Ref	Part	
61	703-48232-00 Drive gear	Buy now




A4

Remote Control Attachment



Ref	Part	
1	66M-48501-00 Remote cont. attachment assembly. AP	Buy now
2	65W-44142-00 Joint	Buy now
3	90254-03M05 Pin, spring	Buy now
4	65W-44125-00 Lever, shift rod	Buy now
5	90387-06M29 Coller (6a0)	Buy now
6	90201-06M31 Washer (6a0)	Buy now
7	97595-06525 Bolt, hexagon w/w deep recess	Buy now
8	66M-44192-00 Joint, rod 1	Buy now
9	90201-05M06 Washer, plate(61u)	Buy now
10	90468-10005 Pin, hair 6264123500	Buy now
11	90468-18008 Clip 620436610000	Buy now
12	663-48344-00 Cable end, remote control	Buy now
14	6H3-48538-00 Clamp, cable	Buy now
15	66M-42725-20 Grommet	Buy now
16	62Y-42727-00 Grommet	Buy now



Remote Control Attachment



Ref	Part	
17	65W-26326-10 Grommet	Buy now
18	65W-42726-10 Grommet	Buy now
19	63V-48511-01 Hook, steering	Buy now
20	97575-08535 Bolt(70w)	Buy now
21	90185-08057 Nut, nylon (6j8)	Buy now

E1

Remote Control Box




67M0100-8280

F7

Ref	Part	
1	703-48203-15 Remote control assembly (7p) AP	Buy now
2	701-48310-80 Cable, Remote Control L=10F UR	Buy now
2	701-48310-90 Cable, Remote Control L=11F UR	Buy now
2	701-48320-00 Cable, Remote Control L=12F UR	Buy now


Repair Kit 1



A7

Ref	Part	
1	66M-W0001-01 Power head gasket kit	Buy now
2	66M-11357-00 Seal, cylinder 3	Buy now
3	66M-11351-00 Gasket, cylinder	Buy now
4	62Y-12414-00 Gasket, cover	Buy now
5	66M-41114-00 Gasket, exhaust outer cover	Buy now
6	66M-11181-00 Gasket, cylinder head 1	Buy now
7	66M-11356-00 Seal, cylinder 2	Buy now
8	93210-24M79 O-ring	Buy now
9	93102-35M51 Oil seal	Buy now
10	93102-25M52 Oil seal	Buy now
11	66M-13645-00 Gasket, manifold 1	Buy now
12	66M-13646-00 Gasket, manifold 2	Buy now
13	93210-35M86 O-ring(6l2)	Buy now
14	93102-18M21 Oil seal (6g8)	Buy now
15	90280-03M01 Key woodruff 146115450000	Buy now

Repair Kit 1




66M0100-1280

A7

Ref	Part	
16	66M-13329-10 Gasket, pump cover	Buy now
17	93210-20M65 O-ring	Buy now


Repair Kit 2



B1

Ref	Part	
1	66M-W0093-01 Carburetor repair kit	Buy now
2	66M-14398-00 Gasket	Buy now
3	6L2-14398-00 Gasket	Buy now
4	66M-14377-00 Stopper	Buy now
5	66M-14384-00 Gasket, float chamber	Buy now
6	6L2-14385-00 Float	Buy now
7	6E5-14386-01 Pin, float	Buy now
8	6L2-14392-00 Valve, needle	Buy now
9	62Y-14399-00 Gasket	Buy now
10	5H0-14323-00 Pilot screw set	Buy now
11	97980-04112 Screw, pan head (686)	Buy now
12	62Y-14397-00 O-ring	Buy now
13	6F5-14397-00 O-ring	Buy now
14	66M-14827-00 Filter	Buy now

Repair Kit 3




66R0700-9330

B2

Ref	Part	
1	66R-W0001-20 Lower Unit Gasket Kit	Buy now
2	93101-12M63 Oil seal	Buy now
3	66M-41133-00 Gasket, exhaust manifold 1	Buy now
4	66M-41138-00 Seal, ext. 1	Buy now
5	90430-14M09 Gasket	Buy now
6	66M-45113-00 Gasket, upper casing	Buy now
7	66M-45115-00 Gasket, upper casing	Buy now
8	66M-45128-00 Seal 2	Buy now
9	90430-08020 Gasket	Buy now
10	63V-44322-00 Insert, cartridge	Buy now
11	63V-44352-01 Impeller	Buy now
12	93210-44398 O-ring(55x)	Buy now
13	63V-44323-00 Outer plate, cartridge	Buy now
14	93101-20048 Oil seal (20x30x6-648)	Buy now
15	63V-45315-A0 Packing, lower casing	Buy now


Repair Kit 3



Ref	Part	
16	93210-06ME6 O-ring	Buy now
17	93101-17054 Oil seal (17x30x6-650)	Buy now
18	93210-74M68 O-ring (6g8)	Buy now
19	93210-74316 O-ring (1j7)	Buy now
20	63V-44365-10 Damper, water seal 1	Buy now
21	63V-44368-00 Rubber, water seal 4	Buy now
22	63V-W0078-00 Water pump repair kit	Buy now
23	647-44366-00 Damper, water seal 2	Buy now
24	97080-08045 Bolt, hexagon	Buy now
28	664-44338-00 Key, woodruff	Buy now

B2

Starter




66R1300-2100

C1

Ref	Part	
1	66M-15710-01 Starter assembly	Buy now
2	66M-15711-01 Case, starter	Buy now
3	90387-06M05 Collar(6h4)	Buy now
4	63V-15714-00 Drum, sheave	Buy now
5	63V-15741-00 Pawl, drive	Buy now
6	63V-15713-00 Spring, starter	Buy now
7	63V-15716-00 Plate, drive	Buy now
8	63V-15705-01 Spring, drive pawl	Buy now
9	63V-15767-01 Spring	Buy now
10	63V-15784-01 Spring, return	Buy now
11	63V-15744-00 Circlip	Buy now
12	63V-15768-00 Screw	Buy now
13	63V-15764-00 Collar 1	Buy now
14	* item_description	Buy now
15	66T-15794-00 Stopper	Buy now


Starter



C1

Ref	Part	
16	66T-15734-00 Spring, return	Buy now
17	66M-15770-00 Cable comp., starter stop	Buy now
18	90446-06M90 Hose	Buy now
19	66T-15731-00 Retainer, spring	Buy now
20	6G1-15755-00 Handle, starter	Buy now
21	6G1-15779-00 Cover	Buy now
22	97095-06020 Bolt(7u8)	Buy now
23	92995-06600 Washer, plain (646)	Buy now
24	66M-15758-00 Guide, Rope	Buy now
24	66M-15758-10 Guide, Rope	Buy now
25	90119-06M59 Bolt, with washer	Buy now
26	97095-06090 Bolt(62y)	Buy now
27	92995-06100 Washer(6a1)	Buy now
28	90201-06M05 Washer, plate(6e3)	Buy now
29	95380-06700 Nut	Buy now


Starter



C1

Ref	Part	
30	66M-15762-00 Seal Rubber 2	Buy now
31	66M-15774-00 Stay 4	Buy now
32	90109-06M86 Bolt	Buy now
33	66M-84342-00 Seat, Emblem	Buy now
34	66M-15711-10 Case, starter	Buy now
35	6A1-83625-41 Mark 5	Buy now
36	6A1-83625-51 Mark 5	Buy now
37	66M-14427-60 Label Instruction	Buy now
38	6G8-13437-63 Mark, caution	Buy now


Starting Motor



Ref	Part	
1	66M-81800-01 Starting motor assembly	Buy now
2	65W-81826-00 Bolt	Buy now
3	65W-81857-01 Retainer	Buy now
4	66M-81830-00 Front bracket assembly	Buy now
5	65W-81807-00 Gear assembly, starting motor	Buy now
6	65W-81850-01 Armature assembly	Buy now
7	66M-81820-00 Rear bracket assembly	Buy now
8	65W-81801-00 Brush set	Buy now
9	65W-81840-00 Brush holder assembly	Buy now
10	65W-81825-00 Screw	Buy now
11	90119-08M39 Bolt, with washer	Buy now
12	90109-08M78 Bolt	Buy now
13	90109-08M85 Bolt	Buy now

C6


Steering



D2

Ref	Part	
3	90109-06M86 Bolt	Buy now
4	90109-06M80 Bolt	Buy now
7	66R-42138-00 Lever, Throttle	Buy now
8	65W-42159-00 Stay	Buy now
9	6G1-42126-00 Piece, friction	Buy now
10	65W-42125-00 Bolt, friction adjusting	Buy now
11	91490-16010 Pin, cotter	Buy now
12	66M-42177-00 Rubber, handle	Buy now
13	66M-42119-00 Grip, steering handle	Buy now
14	689-42137-20 Indicator, Throttle	Buy now
15	90269-02M09 Rivet(615)	Buy now
16	90149-05M13 Screw, countersunk	Buy now
17	90201-10M02 Washer, plate(6g9)	Buy now
18	90501-23215 Spring (655)	Buy now
19	90386-08032 Bushing (650)	Buy now


Steering



D2

Ref	Part	
20	66M-26311-00 Cable, throttle 1	Buy now
21	90446-10M87 Hose	Buy now
22	66R-42171-00 Bushing	Buy now
23	90201-43M00 Washer, plate	Buy now
24	90206-43M22 Washer, wave	Buy now
25	90202-43M57 Washer, plate	Buy now
26	90386-40M99 Bush	Buy now
27	66M-42131-01 Cover, handle steering	Buy now
28	95780-10300 Nut, nylon (6e5)	Buy now
29	95380-10700 Nut (682)	Buy now
30	66R-44111-00-4D Handle, gear shift	Buy now
31	66R-44173-00 Lever, shift control	Buy now
32	90159-06M18 Screw, with washer(6b0)	Buy now
33	66R-42129-00 Bushing, rubber	Buy now
34	97095-08030 Bolt, hexagon (fj1)	Buy now


Steering



D2

Ref	Part	
35	92995-08600 Washer, plain (663)	Buy now
36	90386-26MA3 Bush	Buy now
37	90206-26M25 Washer, wave	Buy now
38	90202-26M59 Washer, plate	Buy now
39	66R-44113-01 Cam plate, handle	Buy now
40	66R-44116-00 Spring	Buy now
41	66R-44118-00 Bracket	Buy now
42	66R-48538-00 Clamp, cable 1	Buy now
43	63D-48538-00 Clamp, cable 1	Buy now
44	90465-08M79 Clamp	Buy now
45	97095-06012 Bolt(gh1)	Buy now
46	92995-06600 Washer, plain (646)	Buy now
47	66R-48321-00 Cable	Buy now
48	66R-48344-00 Cable end, remote control	Buy now
49	90201-06M31 Washer (6a0)	Buy now


Steering



D2

Ref	Part	
50	90170-05M38 Nut	Buy now
51	90468-18008 Clip 620436610000	Buy now
52	99080-04600 Circlip (eu0)	Buy now
53	66R-44114-00 Stopper	Buy now
54	66R-48531-00 Bracket Remote Control 1	Buy now
56	66R-48532-00 Bracket, remote control 2	Buy now
57	97595-06510 Bolt, hexagon w/w deep recess	Buy now
58	6E0-44191-11 Indicator, shift	Buy now
59	65W-82575-01 Engine stop switch assembly	Buy now
60	682-82556-00 Lanyard, stop switch	Buy now
61	689-8257Y-00 Cap	Buy now
62	6E0-83627-41 Label, caution 7	Buy now
63	6E0-83627-51 Label, Caution 7	Buy now

Steering Friction




66M0010-8170

D5

Ref	Part	
1	66M-42508-01 Steering friction assembly	Buy now
2	93700-06M03 Nipple, grease(6a1)	Buy now
3	66M-42527-00 Plate, friction	Buy now
4	90109-08M91 Bolt, hexagon deep recess	Buy now
5	65W-42562-00 Shaft, steering lock	Buy now
6	66M-42561-00 Knob Steering Lock	Buy now
7	689-43633-00 Cover, tilt lever	Buy now
8	90202-10M56 Washer, plate	Buy now
9	65W-42528-00 Plate, friction	Buy now
10	90209-10M26 Washer	Buy now
11	90185-10M14 Nut, self-locking	Buy now
12	90387-05M11 Collar	Buy now
13	90119-05M03 Bolt With Washer	Buy now

Steering Guide




63V0100-5210

F6

Ref	Part	
1	63V-61350-00 Steering guide attachment kit AP	Buy now
2	90201-10M20 Washer, plate (663)	Buy now
3	90185-09M01 Nut, nylon (663)	Buy now
4	90170-09M03 Nut (689)	Buy now
5	90387-10M42 Coller (688)	Buy now
6	6E5-61355-00 Bolt	Buy now
7	90201-10M63 Washer, plate	Buy now
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now


Top Cowling



Ref	Part	
1	66R-42610-10-4D Top Cowling assembly	Buy now
2	66M-42613-00 Molding Air Duct	Buy now
3	97780-60520 Screw, tapping(6k8)	Buy now
4	6E0-42651-02 Hook	Buy now
5	90266-04M04 Rivet(6e7)	Buy now
6	6E7-42652-00 Hook	Buy now
8	66M-42615-00 Seal	Buy now
9	66R-42678-20 Graphic, rear	Buy now
10	66M-W0070-20 Graphic set	Buy now
11	66N-42677-00 Graphic, Front	Buy now
12	90202-05M38 Washer, plate(6l2)	Buy now
13	67F-13434-02 Label, Caution	Buy now

A4


Upper Casing



E6

Ref	Part	
1	66M-45111-10-4D Casing, upper L,X	Buy now
2	66M-45113-00 Gasket, upper casing	Buy now
3	97575-08545 Bolt, hexagon w/w deep recess	Buy now
4	93606-12019 Pin, dowel (614)	Buy now
5	66M-45126-00 Plate, Seal Damper	Buy now
6	66M-45115-00 Gasket, upper casing	Buy now
7	66M-45136-00 Pipe	Buy now
8	66M-45128-00 Seal 2	Buy now
9	90157-06M06 Screw, pan head(6m7)	Buy now
10	66R-45211-20-4D Extension X	Buy now
11	63V-45127-00 Seal X	Buy now
12	92990-08600 Washer, plain (663) X	Buy now
13	95380-08600 Nut (661) X	Buy now
14	93604-12M07 Pin, dowel (688) X	Buy now
15	90116-08M62 Bolt, stud X	Buy now

Valve




 66M0010-1051

B2

Ref	Part	
1	66M-12111-00 Valve, intake	Buy now
2	66M-12121-00 Valve, exhaust	Buy now
3	66M-12116-00 Seat, valve spring	Buy now
4	66M-12113-00 Spring, valve inner	Buy now
5	30X-12117-00 Retainer, valve spring	Buy now
6	30X-12118-00 Cotter, valve	Buy now
7	51Y-12119-00 Seal, valve stem	Buy now
8	66M-12146-00 Shaft, rocker	Buy now
9	90387-13M56 Collar (6g8)	Buy now
10	90387-13001 Collar	Buy now
11	90387-13002 Collar	Buy now
12	90501-12M40 Spring, compression (6g8)	Buy now
13	90501-12M41 Spring Compression (6G8)	Buy now
14	66M-12151-10 Arm, Valve Rocker	Buy now
15	62Y-12159-00 Screw Valve Adjusting	Buy now

Valve



66M0010-1051

B2

Ref	Part	
16	62Y-12158-00 Nut, lock	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.