



# Yamaha INTHDP/HDL 2014

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents


<b>CONTROL</b> .....	3
<b>GIMBAL HOUSING 1</b> .....	4
<b>GIMBAL HOUSING 2</b> .....	9
<b>OPTIONAL PARTS</b> .....	12
<b>or 12 REMOTE CONTROL ASSY 3 SECTION</b> .....	13
<b>POWER STEERING CYLINDER ASSY</b> .....	14
<b>POWER TILT BODY ASSY 1 (PREVIOUS MODEL)</b> .....	16
<b>POWER TILT BODY ASSY 2</b> .....	20
<b>REMOTE CONTROL</b> .....	24
<b>REMOTE CONTROL ASSY 1</b> .....	27
<b>REMOTE CONTROL ASSY 2</b> .....	30
<b>REMOTE CONTROL ASSY 3</b> .....	35
<b>TIILT CYLINDER</b> .....	41
<b>TRANSOM PLATE</b> .....	45

## Control




Ref	Part	
1	<a href="#">6U04831110</a> Cable	<a href="#">Buy now</a>
2	<a href="#">9044608M37</a> Hose(6u0)	<a href="#">Buy now</a>
3	<a href="#">9321010107</a> O-ring (4g0)	<a href="#">Buy now</a>
4	<a href="#">9020113M05</a> Washer, plate(6u0)	<a href="#">Buy now</a>
5	<a href="#">9017012M28</a> Nut(6u0)	<a href="#">Buy now</a>
6	<a href="#">6G82636300</a> End, wire 1	<a href="#">Buy now</a>

## Gimbal Housing 1



Ref	Part	
2	<a href="#">9011612M37</a> Bolt, stud	<a href="#">Buy now</a>
3	<a href="#">9011612M36</a> Bolt, stud	<a href="#">Buy now</a>
4	<a href="#">6U04583400</a> Gasket, transom	<a href="#">Buy now</a>
5	<a href="#">9370009M00</a> Nipple, grease(6t4)	<a href="#">Buy now</a>
6	<a href="#">6634511900</a> Cap, grease nipple	<a href="#">Buy now</a>
7	<a href="#">9038916M00</a> Bush(6t4)	<a href="#">Buy now</a>
8	<a href="#">9038432001</a> Bush, bimetal formed(6u0) <b>JUN.2001 AND FOLLOWING</b>	<a href="#">Buy now</a>
8	<a href="#">9038432M19</a> Bush, bimetal formed(6u0) <b>MAY 2001 AND BELOW</b>	<a href="#">Buy now</a>
9	<a href="#">9310132001</a> Oil seal(6u0) <b>JUN.2001 AND FOLLOWING</b>	<a href="#">Buy now</a>
9	<a href="#">9310432M08</a> Oil seal(6u0) <b>MAY 2001 AND BELOW</b>	<a href="#">Buy now</a>
10	<a href="#">6U04278200</a> Graphic, rear <b>FOR MMS</b>	<a href="#">Buy now</a>
10	<a href="#">6U04278210</a> Graphic, rear <b>FOR DBN1</b>	<a href="#">Buy now</a>
11	<a href="#">6U01461300</a> Gasket, exhaust pipe	<a href="#">Buy now</a>
12	<a href="#">9046413M39</a> Clamp(6u0)	<a href="#">Buy now</a>
13	<a href="#">9011906M46</a> Bolt, with washer (697)	<a href="#">Buy now</a>


# Gimbal Housing 1



A

Ref	Part	
14	<a href="#">9048020M45</a> Grommet(6t4)	<a href="#">Buy now</a>
15	<a href="#">6T48365200</a> Connector	<a href="#">Buy now</a>
16	<a href="#">9044507M18</a> Hose(62t)	<a href="#">Buy now</a>
17	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
18	<a href="#">6E58355800</a> End, nipple	<a href="#">Buy now</a>
19	<a href="#">6T44583H01</a> Set plate, rubber seal	<a href="#">Buy now</a>
20	<a href="#">9709006012</a> Bolt(gh1)	<a href="#">Buy now</a>
21	<a href="#">6U04436110</a> Tube, water <b>C AUG.2000 AND FOLLOWING</b>	<a href="#">Buy now</a>
22	<a href="#">9045032097</a> Hose clamp assembly <b>C JUL.1998 AND FOLLOWING</b>	<a href="#">Buy now</a>
23	<a href="#">6U04583M10</a> Hose, water 1 <b>C AUG.2000 AND FOLLOWING</b>	<a href="#">Buy now</a>
24	<a href="#">6U04436500</a> Damper, water seal <b>C AUG.2000 AND FOLLOWING</b>	<a href="#">Buy now</a>
25	<a href="#">6U04437310</a> Set plate, water tube <b>C AUG.2000 AND FOLLOWING</b>	<a href="#">Buy now</a>
26	<a href="#">6U04431400</a> Spacer <b>C AUG.2000 AND FOLLOWING</b>	<a href="#">Buy now</a>
27	<a href="#">6U01258110</a> Joint, hose 1 <b>C AUG.2000 AND FOLLOWING</b>	<a href="#">Buy now</a>
28	<a href="#">6U01258210</a> Joint, hose 2 <b>C AUG.2000 AND FOLLOWING</b>	<a href="#">Buy now</a>


# Gimbal Housing 1



A

Ref	Part	
29	<a href="#">9709006025</a> Bolt	<a href="#">Buy now</a>
30	<a href="#">9299006600</a> Washer, plain (646)	<a href="#">Buy now</a>
31	<a href="#">93399999U0</a> Bearing(6t4)	<a href="#">Buy now</a>
32	<a href="#">6T44584200</a> Plate, gimbal bearing	<a href="#">Buy now</a>
33	<a href="#">9310235M30</a> Oil seal(6t4)	<a href="#">Buy now</a>
34	<a href="#">6U04586700</a> Bellows APR.1999 AND BELOW	<a href="#">Buy now</a>
34	<a href="#">6U04586701</a> Bellows MAY.1999 AND FOLLOWING	<a href="#">Buy now</a>
35	<a href="#">9045090M10</a> Hose clamp assembly(6t4)	<a href="#">Buy now</a>
36	<a href="#">6U08272J00</a> Plate, earth 1	<a href="#">Buy now</a>
37	<a href="#">6T44839200</a> Boot, remocon cable	<a href="#">Buy now</a>
38	<a href="#">9045035M11</a> Hose clamp assembly(6t4)	<a href="#">Buy now</a>
40	<a href="#">9046510M12</a> Clamp	<a href="#">Buy now</a>
40	<a href="#">9046513M11</a> Clamp (6e5)	<a href="#">Buy now</a>
41	<a href="#">6T44834100</a> Sleeve, shift	<a href="#">Buy now</a>
42	<a href="#">6T44114500</a> Bellows, exhaust	<a href="#">Buy now</a>


# Gimbal Housing 1



A


Ref	Part	
43	<a href="#">9045070M13</a> Hose clamp assembly(6t4)	<a href="#">Buy now</a>
45	<a href="#">6U04525100</a> Anode	<a href="#">Buy now</a>
46	<a href="#">9011906M96</a> Bolt, with washer(6g8)	<a href="#">Buy now</a>
47	<a href="#">6U04583200</a> Cover, transom plate	<a href="#">Buy now</a>
48	<a href="#">9321020256</a> O-ring (688)	<a href="#">Buy now</a>
50	<a href="#">6T48256300</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
51	<a href="#">6T48361400</a> Bracket	<a href="#">Buy now</a>
52	<a href="#">9321039M89</a> O-ring(6h2)	<a href="#">Buy now</a>
53	<a href="#">9015905M12</a> Screw, with washer(6t4)	<a href="#">Buy now</a>
55	<a href="#">9044507M30</a> Hose (I570)	<a href="#">Buy now</a>
57	<a href="#">9046407M40</a> Clamp(6u0)	<a href="#">Buy now</a>
58	<a href="#">9299012200</a> Ybs66-12 washer,plain	<a href="#">Buy now</a>
59	<a href="#">6U04583300</a> Plate, transom 2	<a href="#">Buy now</a>
60	<a href="#">9578012300</a> Nut, nylon (6f2)	<a href="#">Buy now</a>
61	<a href="#">9707510030</a> Bolt	<a href="#">Buy now</a>

## Gimbal Housing 1



Ref	Part	
62	<a href="#">9299510600</a> Washer, plate	<a href="#">Buy now</a>
63	<a href="#">9046411M18</a> Clamp(6e5)	<a href="#">Buy now</a>
64	<a href="#">9778050112</a> Screw, tapping(61a)	<a href="#">Buy now</a>
65	<a href="#">6U04387100</a> Ring, back up	<a href="#">Buy now</a>
66	<a href="#">6U04583M00</a> Hose, water 1 <b>C JUN.1998 AND BELOW</b>	<a href="#">Buy now</a>
67	<a href="#">6U01258100</a> Joint, hose 1 <b>C JUN.1998 AND BELOW</b>	<a href="#">Buy now</a>
68	<a href="#">6U01258200</a> Joint, hose 2 <b>C JUN.1998 AND BELOW</b>	<a href="#">Buy now</a>
69	<a href="#">6U01257300</a> Flange, hose jt. 1 <b>C JUL.2000 AND BELOW</b>	<a href="#">Buy now</a>
70	<a href="#">9321037ME9</a> O-ring(6u0) <b>C JUL.2000 AND BELOW</b>	<a href="#">Buy now</a>
71	<a href="#">6U04436100</a> Tube, water <b>C JUL.1998 AND FOLLOWING</b>	<a href="#">Buy now</a>
72	<a href="#">6U04583M01</a> Hose, water 1 <b>C JUL.1998 AND FOLLOWING</b>	<a href="#">Buy now</a>
73	<a href="#">6U04437800</a> Gasket, water tube <b>C JUL.1998 AND FOLLOWING</b>	<a href="#">Buy now</a>
74	<a href="#">6U04437300</a> Set plate, water tube <b>C JUL.1998 AND FOLLOWING</b>	<a href="#">Buy now</a>
75	<a href="#">9017024426</a> Nut <b>C JUL.1998 AND FOLLOWING</b>	<a href="#">Buy now</a>

## Gimbal Housing 2




6U00300-0030

**B**

Ref	Part	
2	<a href="#">9038625M90</a> Bush(6u0)	<a href="#">Buy now</a>
3	<a href="#">9038625M91</a> Bush(6u0)	<a href="#">Buy now</a>
4	<a href="#">9020228M50</a> Washer, plate(6u0)	<a href="#">Buy now</a>
5	<a href="#">9011910M44</a> Bolt, with washer	<a href="#">Buy now</a>
6	<a href="#">9299010600</a> Washer, plate	<a href="#">Buy now</a>
7	<a href="#">9578010300</a> Nut, nylon (6e5)	<a href="#">Buy now</a>
8	<a href="#">6U04252100</a> Shaft, steering pivot	<a href="#">Buy now</a>
9	<a href="#">9020132M02</a> Washer, plate(6u0)	<a href="#">Buy now</a>
11	<a href="#">9010910M56</a> Bolt(6u0)	<a href="#">Buy now</a>
12	<a href="#">9018520M08</a> Nut, self-locking(6u0)	<a href="#">Buy now</a>
13	<a href="#">6U04252200</a> Shaft, steering pivot 2	<a href="#">Buy now</a>
14	<a href="#">9020126M01</a> Washer, plate(6t4)	<a href="#">Buy now</a>
15	<a href="#">9169040040</a> Pin, spring (663)	<a href="#">Buy now</a>
16	<a href="#">6U04314300</a> Bolt	<a href="#">Buy now</a>
16	<a href="#">6U04314301</a> Bolt	<a href="#">Buy now</a>

## Gimbal Housing 2




  
6U00300-0030

**B**

Ref	Part	
17	<a href="#">9020117M01</a> Washer, plate(6u0)	<a href="#">Buy now</a>
18	<a href="#">6U08367200</a> Trim sender (std tilt) <b>STANPED 6U0-00</b>	<a href="#">Buy now</a>
19	<a href="#">6T48259G00</a> Switch, trim limit	<a href="#">Buy now</a>
20	<a href="#">9015905M13</a> Screw, with washer(6t4)	<a href="#">Buy now</a>
21	<a href="#">9020905M18</a> Washer(6t4)	<a href="#">Buy now</a>
22	<a href="#">6U08367402</a> Coupler, sender	<a href="#">Buy now</a>
25	<a href="#">9011906M97</a> Bolt, hexagon w/w deep recess	<a href="#">Buy now</a>
26	<a href="#">9046512M45</a> Clamp(6u0)	<a href="#">Buy now</a>
27	<a href="#">9010106M02</a> Bolt	<a href="#">Buy now</a>
29	<a href="#">9011612M47</a> Bolt, stud(6u0)	<a href="#">Buy now</a>
30	<a href="#">6E54537800</a> Nipple, hose	<a href="#">Buy now</a>
31	<a href="#">6U04511300</a> Gasket, upper casing	<a href="#">Buy now</a>
32	<a href="#">6T48212700</a> Wire, lead 5	<a href="#">Buy now</a>
33	<a href="#">9709506010</a> Bolt	<a href="#">Buy now</a>
34	<a href="#">6U04586800</a> Retainer, bellows	<a href="#">Buy now</a>

## Gimbal Housing 2




 6U00300-0030

**B**

Ref	Part	
35	<a href="#">9709006010</a> Bolt	<a href="#">Buy now</a>
36	<a href="#">9299006600</a> Washer, plain (646)	<a href="#">Buy now</a>

## Optional Parts



6U00300-D220

E

Ref	Part	
1	<a href="#">6T4W458400</a> 13- 1	<a href="#">Buy now</a>
2	<a href="#">6T46130100</a> Twin kit	<a href="#">Buy now</a>
2	<a href="#">6T46130101</a> Twin kit	<a href="#">Buy now</a>
3	<a href="#">6T46131300</a> Adjuster	<a href="#">Buy now</a>
3	<a href="#">6T46131301</a> Adjuster	<a href="#">Buy now</a>
4	<a href="#">6T46131100</a> Tie bar	<a href="#">Buy now</a>
5	<a href="#">6T46131500</a> Tie Bar	<a href="#">Buy now</a>
5	<a href="#">6T46131501</a> Tie Bar	<a href="#">Buy now</a>
6	<a href="#">9531318700</a> Nut	<a href="#">Buy now</a>
7	<a href="#">9024009M13</a> Pin, clevis(6t4)	<a href="#">Buy now</a>
8	<a href="#">9149025020</a> Pin, cotter	<a href="#">Buy now</a>
9	<a href="#">7044829300</a> 704 sgl top mount spacer kit UR SINGLE	<a href="#">Buy now</a>
9	<a href="#">7044829310</a> Spacer, Remote Control UR TWIN	<a href="#">Buy now</a>
10	<a href="#">6U04388F00</a> Spacer	<a href="#">Buy now</a>

# Or 12 Remote Control Assy 3 Section

**PARTS NEW**

News No. : PE0-SD-060002

Model	6U00
Subject	6U30
CATALOGUE NO.	6U40

Revised parts catalogue will be issued by PDI  
(YPEC=Yamaha Parts Electrical Catalogue =

1. LIST of Models and CATALOGUE No's.  
The applicable MODELS, MODEL CODES, and C

MODEL	MODEL CODE	CA
INT-HDP/HDL	6U00	
DE-DHD	6U30	
DE-DHT(TRP)	6U40	
INT-HDP/HDL	6U00	

2. LIST CORRECTION  
**FIG. 22 or 12 REMOTE CONTROL ASSY**

REF.NO.	PART NO.	DESCRIPTION
67	6XE-81950-00	.RELAY
78	704-81950-00	.RELAY

\* These changes are applied from initial production.

3. ILLUSTRATION CORRECTION  
**FIG. 22 or 12 REMOTE CONTROL ASSY**


(INCORRECT)

Thank you very much for your cooperation.

Parts Manager Check	Service Manager Check	Parts Manager File	YAM 250 Tech
---------------------	-----------------------	--------------------	--------------


Ref	Part	
67	<a href="#">6XE8195000</a> Relay assembly	<a href="#">Buy now</a>
78	<a href="#">7048195000</a> Relay assembly	<a href="#">Buy now</a>

# Power Steering Cylinder Assy



Ref	Part	
1	<a href="#">6T442401018D</a> Power steering cylinder assembly DBN1	<a href="#">Buy now</a>
2	<a href="#">6T44241000</a> Cylinder sub-assembly	<a href="#">Buy now</a>
4	<a href="#">6T44242000</a> Rod sub-assembly	<a href="#">Buy now</a>
6	<a href="#">6T44241300</a> O-ring	<a href="#">Buy now</a>
7	<a href="#">6T44243000</a> 7- 7	<a href="#">Buy now</a>
7	<a href="#">6T44243001</a> 7- 7	<a href="#">Buy now</a>
10	<a href="#">6T44245100</a> Snap ring, dust wiper	<a href="#">Buy now</a>
11	<a href="#">6T44244400</a> U-packing, spool valve	<a href="#">Buy now</a>
12	<a href="#">6T44244500</a> O-ring	<a href="#">Buy now</a>
13	<a href="#">20</a> - U-PACKING, CYLINDER 1	<a href="#">Buy now</a>
15	<a href="#">6T44244100</a> Dust cover, valve	<a href="#">Buy now</a>
16	<a href="#">11</a> 6Yf-8357X-10	<a href="#">Buy now</a>
20	<a href="#">6T44244700</a> Seat, valve 1	<a href="#">Buy now</a>
21	<a href="#">6T44244800</a> Seat, valve 2	<a href="#">Buy now</a>
22	<a href="#">6T44241100</a> Rod, end	<a href="#">Buy now</a>

# Power Steering Cylinder Assy




6U00300-0060

C


Ref	Part	
23	<a href="#">6T44241200</a> Nut, rod end	<a href="#">Buy now</a>
24	<a href="#">17</a> 97027-10025	<a href="#">Buy now</a>
25	<a href="#">26</a> -	<a href="#">Buy now</a>
30	<a href="#">12</a> 92990-10100 U-PACKING, SPOOL SHAFT 1	<a href="#">Buy now</a>
13	<a href="#">9149025020</a> Pin, cotter <b>UR WITHOUT POWER</b>	<a href="#">Buy now</a>
25	<a href="#">6T44247200</a> 7- 25	<a href="#">Buy now</a>
26	<a href="#">6T44247300</a> Tube, support	<a href="#">Buy now</a>
28	<a href="#">6T44247500</a> Washer, support tube	<a href="#">Buy now</a>
30	<a href="#">6T44247800</a> Bolt, lock plate	<a href="#">Buy now</a>
32	<a href="#">6T44247600</a> 7- 32	<a href="#">Buy now</a>
33	<a href="#">9024009M13</a> Pin, clevis(6t4)	<a href="#">Buy now</a>

# Power Tilt Body Assy 1 (Previous Model)




Ref	Part	
2	<a href="#">6T44382900</a> Plug, reservoir	<a href="#">Buy now</a>
3	<a href="#">9321021276</a> O-ring	<a href="#">Buy now</a>
4	<a href="#">6T44382800</a> Body, reservoir	<a href="#">Buy now</a>
5	<a href="#">9739506020</a> Bolt(7u8)	<a href="#">Buy now</a>
6	<a href="#">9299506100</a> Washer(6a1)	<a href="#">Buy now</a>
7	<a href="#">6T44388001</a> Motor assembly <b>12V</b>	<a href="#">Buy now</a>
8	<a href="#">9858005008</a> Screw, pan head (7g3)	<a href="#">Buy now</a>
9	<a href="#">6T44386J00</a> Washer, special	<a href="#">Buy now</a>
10	<a href="#">6T44389100</a> Brush 1 <b>12V</b>	<a href="#">Buy now</a>
11	<a href="#">6T44386K00</a> Spring, brush	<a href="#">Buy now</a>
12	<a href="#">6T44380700</a> Wire Sub assembly <b>12V</b>	<a href="#">Buy now</a>
13	<a href="#">6T44388500</a> Grommet	<a href="#">Buy now</a>
14	<a href="#">6T44380600</a> Brush holder assembly	<a href="#">Buy now</a>
15	<a href="#">6T44380400</a> Stator assembly	<a href="#">Buy now</a>
16	<a href="#">6T44380501</a> Armature assembly	<a href="#">Buy now</a>

## Power Tilt Body Assy 1 (Previous Model)




Ref	Part	
17	<a href="#">9321081782</a> O-ring(6t4)	<a href="#">Buy now</a>
18	<a href="#">9330060820</a> Bearing(6t4)	<a href="#">Buy now</a>
19	<a href="#">9020614086</a> Washer, wave(6t4)	<a href="#">Buy now</a>
20	<a href="#">6T44388100</a> Frame, end	<a href="#">Buy now</a>
21	<a href="#">6T44388700</a> Bolt, through	<a href="#">Buy now</a>
22	<a href="#">6T44388400</a> Frame, commutator end	<a href="#">Buy now</a>
23	<a href="#">9858005010</a> Screw, pan head(62x)	<a href="#">Buy now</a>
24	<a href="#">6T44385500</a> Spring, up relief	<a href="#">Buy now</a>
25	<a href="#">6T44389500</a> Seat, relief valve	<a href="#">Buy now</a>
26	<a href="#">6T44384400</a> Pin, valve support	<a href="#">Buy now</a>
27	<a href="#">6H14384G11</a> Seal, relief valve	<a href="#">Buy now</a>
28	<a href="#">9160910014</a> Pin, spring(61a)	<a href="#">Buy now</a>
29	<a href="#">6T44389300</a> Washer	<a href="#">Buy now</a>
30	<a href="#">6T44385100</a> Seat, relief valve	<a href="#">Buy now</a>
31	<a href="#">6T44384G00</a> Seal, relief valve	<a href="#">Buy now</a>

# Power Tilt Body Assy 1 (Previous Model)




Ref	Part	
32	<a href="#">9350108001</a> Ball	<a href="#">Buy now</a>
33	<a href="#">9321010M74</a> O-ring	<a href="#">Buy now</a>
34	<a href="#">6H14381600</a> Filter 1	<a href="#">Buy now</a>
35	<a href="#">6T44384100</a> Piston, shuttle	<a href="#">Buy now</a>
36	<a href="#">6T44380203</a> Valve sub assembly	<a href="#">Buy now</a>
37	<a href="#">6H14386700</a> O-ring	<a href="#">Buy now</a>
38	<a href="#">6H14386600</a> O-ring	<a href="#">Buy now</a>
39	<a href="#">6T44388H00</a> Plug	<a href="#">Buy now</a>
40	<a href="#">6T44382K00</a> Cap, relief valve	<a href="#">Buy now</a>
41	<a href="#">6H14385610</a> Spring, down relief	<a href="#">Buy now</a>
42	<a href="#">61A4384F00</a> Seal, main valve	<a href="#">Buy now</a>
43	<a href="#">6T44386000</a> Manual valve sub-assembly	<a href="#">Buy now</a>
45	<a href="#">9321006519</a> O-ring(6h0)	<a href="#">Buy now</a>
46	<a href="#">6T44386900</a> O-ring	<a href="#">Buy now</a>
47	<a href="#">6T44385H00</a> Spring, seal	<a href="#">Buy now</a>

## Power Tilt Body Assy 1 (Previous Model)




Ref	Part	
48	<a href="#">6T44384900</a> Pin, valve support	<a href="#">Buy now</a>
49	<a href="#">9321006632</a> O-ring (26h)	<a href="#">Buy now</a>
50	<a href="#">6H14386800</a> O-ring	<a href="#">Buy now</a>
51	<a href="#">6T44387600</a> Ring, snap	<a href="#">Buy now</a>
52	<a href="#">6T44383000</a> Gear pump assembly	<a href="#">Buy now</a>
53	<a href="#">9739506025</a> Bolt	<a href="#">Buy now</a>
54	<a href="#">9299006600</a> Washer, plain (646)	<a href="#">Buy now</a>
55	<a href="#">9760104230</a> 5- 55	<a href="#">Buy now</a>
56	<a href="#">6H14383100</a> Connector, shaft	<a href="#">Buy now</a>
57	<a href="#">6H14381700</a> Filter 2	<a href="#">Buy now</a>
59	<a href="#">9321009350</a> O-ring	<a href="#">Buy now</a>

## Power Tilt Body Assy 2




Ref	Part	
2	<a href="#">6T44382900</a> Plug, reservoir	<a href="#">Buy now</a>
3	<a href="#">9321021276</a> O-ring	<a href="#">Buy now</a>
4	<a href="#">N354382800</a> Body, Reservoir	<a href="#">Buy now</a>
5	<a href="#">6T44388600</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">9759006420</a> 6- 6	<a href="#">Buy now</a>
7	<a href="#">6T44388001</a> Motor assembly <b>12V</b>	<a href="#">Buy now</a>
8	<a href="#">6T44386J00</a> Washer, special	<a href="#">Buy now</a>
9	<a href="#">9858005008</a> Screw, pan head (7g3)	<a href="#">Buy now</a>
10	<a href="#">6T44380700</a> Wire Sub assembly <b>12V</b>	<a href="#">Buy now</a>
11	<a href="#">6T44388500</a> Grommet	<a href="#">Buy now</a>
12	<a href="#">6T44386K00</a> Spring, brush	<a href="#">Buy now</a>
13	<a href="#">6T44380600</a> Brush holder assembly	<a href="#">Buy now</a>
14	<a href="#">6T44389100</a> Brush 1 <b>12V</b>	<a href="#">Buy now</a>
15	<a href="#">9321081782</a> O-ring(6t4)	<a href="#">Buy now</a>
16	<a href="#">9330060820</a> Bearing(6t4)	<a href="#">Buy now</a>

## Power Tilt Body Assy 2



Ref	Part	
17	<a href="#">9020614086</a> Washer, wave(6t4)	<a href="#">Buy now</a>
18	<a href="#">6T44388700</a> Bolt, through	<a href="#">Buy now</a>
19	<a href="#">9760705210</a> Screw, With Washer	<a href="#">Buy now</a>
20	<a href="#">6T44385500</a> Spring, up relief	<a href="#">Buy now</a>
21	<a href="#">6T44389500</a> Seat, relief valve	<a href="#">Buy now</a>
22	<a href="#">6T44382K00</a> Cap, relief valve	<a href="#">Buy now</a>
23	<a href="#">6T44384400</a> Pin, valve support	<a href="#">Buy now</a>
24	<a href="#">9160910014</a> Pin, spring(61a)	<a href="#">Buy now</a>
25	<a href="#">6T44389300</a> Washer	<a href="#">Buy now</a>
26	<a href="#">6T44384G00</a> Seal, relief valve	<a href="#">Buy now</a>
27	<a href="#">6T44385100</a> Seat, relief valve	<a href="#">Buy now</a>
28	<a href="#">9350108001</a> Ball	<a href="#">Buy now</a>
29	<a href="#">93210064A5</a> O-ring(61a)	<a href="#">Buy now</a>
30	<a href="#">6T44384101</a> Piston, Shuttle	<a href="#">Buy now</a>
31	<a href="#">9321009165</a> O-ring	<a href="#">Buy now</a>


## Power Tilt Body Assy 2



C


Ref	Part	
32	<a href="#">6T44380203</a> Valve sub assembly	<a href="#">Buy now</a>
34	<a href="#">6T44386000</a> Manual valve sub-assembly	<a href="#">Buy now</a>
35	<a href="#">6T44386E00</a> Lever 1	<a href="#">Buy now</a>
36	<a href="#">9169040014</a> Pin, spring (6f2)	<a href="#">Buy now</a>
37	<a href="#">6T44384800</a> Rod, Manual Release	<a href="#">Buy now</a>
38	<a href="#">6T44386H00</a> Washer	<a href="#">Buy now</a>
39	<a href="#">6T44387H00</a> Washer	<a href="#">Buy now</a>
40	<a href="#">6T44384500</a> Screw, Manual Release	<a href="#">Buy now</a>
41	<a href="#">6T44385400</a> Spring, Manual Release	<a href="#">Buy now</a>
42	<a href="#">9290705600</a> Washer(1rw)	<a href="#">Buy now</a>
43	<a href="#">9530704600</a> Nut(6ta)	<a href="#">Buy now</a>
45	<a href="#">9321082491</a> O-ring (5r0)	<a href="#">Buy now</a>
46	<a href="#">6T44387600</a> Ring, snap	<a href="#">Buy now</a>
47	<a href="#">9321007003</a> O-ring (11m)	<a href="#">Buy now</a>
48	<a href="#">6T44384900</a> Pin, valve support	<a href="#">Buy now</a>

## Power Tilt Body Assy 2




Ref	Part	
49	<a href="#">9321006001</a> O-ring (26h)	<a href="#">Buy now</a>
50	<a href="#">6T44385H00</a> Spring, seal	<a href="#">Buy now</a>
51	<a href="#">6T44383000</a> Gear pump assembly	<a href="#">Buy now</a>
53	<a href="#">9131805012</a> Bolt, socket	<a href="#">Buy now</a>
54	<a href="#">9760704230</a> Screw, pan head with washer	<a href="#">Buy now</a>
55	<a href="#">9160940025</a> Pin, spring (6g0)	<a href="#">Buy now</a>
57	<a href="#">6T44386900</a> O-ring	<a href="#">Buy now</a>
58	<a href="#">6H14389F00</a> O-Ring	<a href="#">Buy now</a>
59	<a href="#">6H14381600</a> Filter 1	<a href="#">Buy now</a>
60	<a href="#">6H14385610</a> Spring, down relief	<a href="#">Buy now</a>
62	<a href="#">9321012N52</a> O-ring	<a href="#">Buy now</a>
64	<a href="#">6H14384G11</a> Seal, relief valve	<a href="#">Buy now</a>
65	<a href="#">6H14384F10</a> Seal, main valve	<a href="#">Buy now</a>
66	<a href="#">6H14383100</a> Connector, shaft	<a href="#">Buy now</a>
67	<a href="#">6H14381700</a> Filter 2	<a href="#">Buy now</a>

## Remote Control



Ref	Part	
1	<a href="#">6XE4825011</a> Remote control assembly UR SEE FIG,11	<a href="#">Buy now</a>
2	<a href="#">6XE4828011</a> Remote control assembly UR SEE FIG,12	<a href="#">Buy now</a>
3	<a href="#">6XF4825011</a> Remote control assembly UR SEE FIG,10	<a href="#">Buy now</a>
4	<a href="#">7014831080</a> Cable, Remote Control L=10F UR	<a href="#">Buy now</a>
4	<a href="#">7014831090</a> Cable, Remote Control L=11F UR	<a href="#">Buy now</a>
4	<a href="#">7014832000</a> Cable, Remote Control L=12F UR	<a href="#">Buy now</a>
4	<a href="#">7014832020</a> Cable, Remote Control L=13F UR	<a href="#">Buy now</a>
4	<a href="#">7014832030</a> Cable, Remote Control L=14F UR	<a href="#">Buy now</a>
4	<a href="#">7014832040</a> Cable, Remote Control L=19F UR	<a href="#">Buy now</a>
4	<a href="#">7014832050</a> Cable, Remote Control L=15F UR	<a href="#">Buy now</a>
4	<a href="#">7014832060</a> Cable, Remote Control L=16F UR	<a href="#">Buy now</a>
4	<a href="#">7014832070</a> Cable, Remote Control L=20F UR	<a href="#">Buy now</a>
4	<a href="#">7014832080</a> Cable, Remote Control L=17F UR	<a href="#">Buy now</a>
4	<a href="#">7014832090</a> Cable, Remote Control L=18F UR	<a href="#">Buy now</a>
4	<a href="#">7014835000</a> Cable, Remote Control L=21F UR	<a href="#">Buy now</a>


# Remote Control



D


Ref	Part	
4	<a href="#">7014835010</a> Cable, Remote Control L=22F UR	<a href="#">Buy now</a>
4	<a href="#">7014835020</a> Cable, Remote Control L=23F UR	<a href="#">Buy now</a>
4	<a href="#">7014835030</a> Cable, Remote Control L=24F UR	<a href="#">Buy now</a>
4	<a href="#">7014835040</a> Cable, Remote Control L=25F UR	<a href="#">Buy now</a>
4	<a href="#">7014835050</a> Cable, Remote Control L=26F UR	<a href="#">Buy now</a>
4	<a href="#">7014835060</a> Cable, Remote Control L=27F UR	<a href="#">Buy now</a>

# Remote Control Assy 1




Ref	Part	
1	<a href="#">6XF4825011</a> Remote control assembly	<a href="#">Buy now</a>
3	<a href="#">19</a> - NO.	<a href="#">Buy now</a>
10	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
11	<a href="#">7044826600</a> Spacer 2	<a href="#">Buy now</a>
12	<a href="#">6XF8254000</a> Neutral switch assembly	<a href="#">Buy now</a>
14	<a href="#">47</a> -	<a href="#">Buy now</a>
15	<a href="#">9789005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
16	<a href="#">6X04826100</a> Arm, Throttle	<a href="#">Buy now</a>
17	<a href="#">EL84819100</a> Washer 1	<a href="#">Buy now</a>
20	<a href="#">15</a> - PLUNGER 1	<a href="#">Buy now</a>
23	<a href="#">27</a> -	<a href="#">Buy now</a>
24	<a href="#">16</a> 92907-08600 SCREW, PAN HEAD 3	<a href="#">Buy now</a>
25	<a href="#">30</a> -	<a href="#">Buy now</a>
26	<a href="#">9878006020</a> Screw flat head	<a href="#">Buy now</a>
31	<a href="#">67</a> 61 6X0-48128-00 SCREW(M6X30) 3	<a href="#">Buy now</a>

# Remote Control Assy 1




Ref	Part	
33	<a href="#">3</a> WASHER 3	<a href="#">Buy now</a>
35	<a href="#">36</a> -	<a href="#">Buy now</a>
37	<a href="#">39</a> -	<a href="#">Buy now</a>
43	<a href="#">5</a> 90480-13M24	<a href="#">Buy now</a>
44	<a href="#">40</a> -	<a href="#">Buy now</a>
55	<a href="#">58</a> -	<a href="#">Buy now</a>
63	<a href="#">46</a> -	<a href="#">Buy now</a>
64	<a href="#">50</a> -	<a href="#">Buy now</a>
28	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
29	<a href="#">11</a> 6Yf-8357X-10 NUT 1 3	<a href="#">Buy now</a>
38	<a href="#">EL84827900</a> Circlip 2	<a href="#">Buy now</a>
39	<a href="#">7044819300</a> Washer 3	<a href="#">Buy now</a>
42	<a href="#">EL84823300</a> Gear 2	<a href="#">Buy now</a>
43	<a href="#">7034823500</a> Bushing	<a href="#">Buy now</a>
44	<a href="#">6X04815300</a> Shaft, Free Accel.	<a href="#">Buy now</a>

# Remote Control Assy 1




Ref	Part	
53	<a href="#">6X04822100</a> Lever, control	<a href="#">Buy now</a>
55	<a href="#">7044822500</a> Cover	<a href="#">Buy now</a>
65	<a href="#">6E04419111</a> Indicator, shift	<a href="#">Buy now</a>
66	<a href="#">6XF8254100</a> Wire, lead	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
1	<a href="#">6XE4825011</a> Remote control assembly	<a href="#">Buy now</a>
2	<a href="#">9789005016</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
3	<a href="#">6XE4825100</a> 11- 3	<a href="#">Buy now</a>
4	<a href="#">7044826500</a> Shaft, friction	<a href="#">Buy now</a>
5	<a href="#">7014824600</a> Spacer	<a href="#">Buy now</a>
6	<a href="#">9343006024</a> Circlip (701)	<a href="#">Buy now</a>
7	<a href="#">9299010600</a> Washer, plate	<a href="#">Buy now</a>
8	<a href="#">EL84825900</a> Circlip 1	<a href="#">Buy now</a>
9	<a href="#">7044826200</a> Shaft, throttle	<a href="#">Buy now</a>
10	<a href="#">7044826400</a> Friction, throttle	<a href="#">Buy now</a>
11	<a href="#">7044826600</a> Spacer 2	<a href="#">Buy now</a>
12	<a href="#">6XE8254000</a> Neutral switch assembly	<a href="#">Buy now</a>
13	<a href="#">6A54812910</a> Screw, pan head (n151)	<a href="#">Buy now</a>
14	<a href="#">6XE4828100</a> Screw	<a href="#">Buy now</a>
15	<a href="#">6XE4821500</a> Graphic	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
16	<a href="#">9789005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
17	<a href="#">7044826100</a> Arm, throttle	<a href="#">Buy now</a>
18	<a href="#">EL84819100</a> Washer 1	<a href="#">Buy now</a>
19	<a href="#">7044828300</a> Screw,panhead (eg9)	<a href="#">Buy now</a>
20	<a href="#">9739506018</a> Bolt (fj0)	<a href="#">Buy now</a>
21	<a href="#">7034834501</a> Cable end, remote control 2	<a href="#">Buy now</a>
22	<a href="#">7044828700</a> Washer 1	<a href="#">Buy now</a>
23	<a href="#">9538005600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
24	<a href="#">EL84827100</a> Arm, shift	<a href="#">Buy now</a>
25	<a href="#">EL84812700</a> Screw 1	<a href="#">Buy now</a>
26	<a href="#">7034835800</a> Anchor, cable	<a href="#">Buy now</a>
27	<a href="#">EL84823100</a> Housing, gear	<a href="#">Buy now</a>
28	<a href="#">EL84824100</a> Arm, drive	<a href="#">Buy now</a>
29	<a href="#">EL84825400</a> Stopper Throttle Adjusting	<a href="#">Buy now</a>
30	<a href="#">9878006020</a> Screw flat head	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
31	<a href="#">EL84815800</a> Spring 1	<a href="#">Buy now</a>
32	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
33	<a href="#">9878005018</a> Screw (704)	<a href="#">Buy now</a>
34	<a href="#">EL84824400</a> Spring, free accel.	<a href="#">Buy now</a>
35	<a href="#">EL84824500</a> Plate, lock	<a href="#">Buy now</a>
36	<a href="#">7034826300</a> Bushing	<a href="#">Buy now</a>
37	<a href="#">7044822200</a> Grip, control lever	<a href="#">Buy now</a>
38	<a href="#">7048259400</a> Clamp	<a href="#">Buy now</a>
39	<a href="#">6XE4822800</a> Holder, switch	<a href="#">Buy now</a>
40	<a href="#">6XE8256300</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
41	<a href="#">7044822900</a> Grip, control lever 2	<a href="#">Buy now</a>
42	<a href="#">9299005300</a> Washer, tooth	<a href="#">Buy now</a>
43	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
44	<a href="#">7014824800</a> Roller, free accel	<a href="#">Buy now</a>
45	<a href="#">7034823800</a> Spring, detent	<a href="#">Buy now</a>

## Remote Control Assy 2




Ref	Part	
46	<a href="#">EL84823200</a> Gear 1	<a href="#">Buy now</a>
47	<a href="#">EL84816400</a> Pin 2	<a href="#">Buy now</a>
48	<a href="#">7044824200</a> Shaft, drive	<a href="#">Buy now</a>
49	<a href="#">7044822500</a> Cover	<a href="#">Buy now</a>
50	<a href="#">7044819200</a> Washer 2	<a href="#">Buy now</a>
51	<a href="#">9789006018</a> Screw, pan head(6e5)	<a href="#">Buy now</a>
52	<a href="#">9299006300</a> Washer, tooth	<a href="#">Buy now</a>
53	<a href="#">7024826300</a> Bushing 4	<a href="#">Buy now</a>
54	<a href="#">EL84827900</a> Circlip 2	<a href="#">Buy now</a>
55	<a href="#">7044819300</a> Washer 3	<a href="#">Buy now</a>
56	<a href="#">EL84823400</a> Bushing 1	<a href="#">Buy now</a>
57	<a href="#">7044821900</a> Cover, lead	<a href="#">Buy now</a>
58	<a href="#">7044814400</a> Plate, stopper 2	<a href="#">Buy now</a>
59	<a href="#">7044817600</a> Grommet	<a href="#">Buy now</a>
60	<a href="#">7034819200</a> Washer 2	<a href="#">Buy now</a>

## Remote Control Assy 2



Ref	Part	
61	<a href="#">EL84823300</a> Gear 2	<a href="#">Buy now</a>
62	<a href="#">7034823500</a> Bushing	<a href="#">Buy now</a>
63	<a href="#">7044828200</a> Screw 2	<a href="#">Buy now</a>
64	<a href="#">EL84815310</a> Shaft, free accel.	<a href="#">Buy now</a>
65	<a href="#">7044816600</a> Plug	<a href="#">Buy now</a>
66	<a href="#">7044828400</a> Grommet	<a href="#">Buy now</a>
67	<a href="#">6XE8254100</a> Wire, lead	<a href="#">Buy now</a>
68	<a href="#">7044822100</a> Lever control	<a href="#">Buy now</a>
69	<a href="#">7044811900</a> Cover	<a href="#">Buy now</a>


# Remote Control Assy 3



6U330031611

Ref	Part	
1	<a href="#">6XE4828011</a> Remote control assembly	<a href="#">Buy now</a>
2	<a href="#">9789005016</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
3	<a href="#">6XE4825100</a> 11- 3	<a href="#">Buy now</a>
4	<a href="#">7044826500</a> Shaft, friction	<a href="#">Buy now</a>
5	<a href="#">7014824600</a> Spacer	<a href="#">Buy now</a>
6	<a href="#">9343006024</a> Circlip (701)	<a href="#">Buy now</a>
7	<a href="#">9299010600</a> Washer, plate	<a href="#">Buy now</a>
8	<a href="#">EL84825900</a> Circlip 1	<a href="#">Buy now</a>
9	<a href="#">7044826200</a> Shaft, throttle	<a href="#">Buy now</a>
10	<a href="#">7044826400</a> Friction, throttle	<a href="#">Buy now</a>
11	<a href="#">7044826600</a> Spacer 2	<a href="#">Buy now</a>
12	<a href="#">6XE8254010</a> Neutral switch assembly	<a href="#">Buy now</a>
13	<a href="#">6A54812910</a> Screw, pan head (n151)	<a href="#">Buy now</a>
14	<a href="#">6XE4828100</a> Screw	<a href="#">Buy now</a>
15	<a href="#">6XE4821510</a> Graphic	<a href="#">Buy now</a>


# Remote Control Assy 3



6U330031611

Ref	Part	
16	<a href="#">9789005025</a> Screw, panhead (a93)	<a href="#">Buy now</a>
17	<a href="#">7044826100</a> Arm, throttle	<a href="#">Buy now</a>
18	<a href="#">EL84819100</a> Washer 1	<a href="#">Buy now</a>
19	<a href="#">7044828300</a> Screw,panhead (eg9)	<a href="#">Buy now</a>
20	<a href="#">9738006018</a> Bolt (fj0)	<a href="#">Buy now</a>
21	<a href="#">7034834501</a> Cable end, remote control 2	<a href="#">Buy now</a>
22	<a href="#">7044828700</a> Washer 1	<a href="#">Buy now</a>
23	<a href="#">9538005600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
24	<a href="#">EL84827100</a> Arm, shift	<a href="#">Buy now</a>
25	<a href="#">EL84812700</a> Screw 1	<a href="#">Buy now</a>
26	<a href="#">7034835800</a> Anchor, cable	<a href="#">Buy now</a>
27	<a href="#">EL84823100</a> Housing, gear	<a href="#">Buy now</a>
28	<a href="#">EL84824100</a> Arm, drive	<a href="#">Buy now</a>
29	<a href="#">EL84825400</a> Stopper Throttle Adjusting	<a href="#">Buy now</a>
30	<a href="#">9278006020</a> Screw flat head	<a href="#">Buy now</a>


## Remote Control Assy 3



E

Ref	Part	
31	<a href="#">EL84815800</a> Spring 1	<a href="#">Buy now</a>
32	<a href="#">9858004006</a> Screw, pan head (7h3)	<a href="#">Buy now</a>
33	<a href="#">9878005018</a> Screw (704)	<a href="#">Buy now</a>
34	<a href="#">EL84824400</a> Spring, free accel.	<a href="#">Buy now</a>
35	<a href="#">EL84824500</a> Plate, lock	<a href="#">Buy now</a>
36	<a href="#">7034826300</a> Bushing	<a href="#">Buy now</a>
37	<a href="#">7044822200</a> Grip, control lever	<a href="#">Buy now</a>
38	<a href="#">7048259400</a> Clamp	<a href="#">Buy now</a>
39	<a href="#">6XE4822800</a> Holder, switch	<a href="#">Buy now</a>
40	<a href="#">6XE8256340</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
41	<a href="#">7044822900</a> Grip, control lever 2	<a href="#">Buy now</a>
42	<a href="#">9299005300</a> Washer, tooth	<a href="#">Buy now</a>
43	<a href="#">9538006600</a> Nut(661)	<a href="#">Buy now</a>
44	<a href="#">7014824800</a> Roller, free accel	<a href="#">Buy now</a>
45	<a href="#">7034823800</a> Spring, detent	<a href="#">Buy now</a>


# Remote Control Assy 3



E

Ref	Part	
46	<a href="#">EL84823200</a> Gear 1	<a href="#">Buy now</a>
47	<a href="#">EL84816400</a> Pin 2	<a href="#">Buy now</a>
48	<a href="#">7044824200</a> Shaft, drive	<a href="#">Buy now</a>
49	<a href="#">7044822500</a> Cover	<a href="#">Buy now</a>
50	<a href="#">7044819200</a> Washer 2	<a href="#">Buy now</a>
51	<a href="#">9789006018</a> Screw, pan head(6e5)	<a href="#">Buy now</a>
52	<a href="#">9299006300</a> Washer, tooth	<a href="#">Buy now</a>
53	<a href="#">7024826300</a> Bushing 4	<a href="#">Buy now</a>
54	<a href="#">EL84827900</a> Circlip 2	<a href="#">Buy now</a>
55	<a href="#">7044819300</a> Washer 3	<a href="#">Buy now</a>
56	<a href="#">EL84823400</a> Bushing 1	<a href="#">Buy now</a>
57	<a href="#">7044821900</a> Cover, lead	<a href="#">Buy now</a>
58	<a href="#">7044814400</a> Plate, stopper 2	<a href="#">Buy now</a>
59	<a href="#">7044817600</a> Grommet	<a href="#">Buy now</a>
60	<a href="#">7034819200</a> Washer 2	<a href="#">Buy now</a>


# Remote Control Assy 3



E

Ref	Part	
61	<a href="#">EL84823300</a> Gear 2	<a href="#">Buy now</a>
62	<a href="#">7034823500</a> Bushing	<a href="#">Buy now</a>
63	<a href="#">7044828200</a> Screw 2	<a href="#">Buy now</a>
64	<a href="#">EL84815310</a> Shaft, free accel.	<a href="#">Buy now</a>
65	<a href="#">7044816600</a> Plug	<a href="#">Buy now</a>
66	<a href="#">7044828400</a> Grommet	<a href="#">Buy now</a>
67	<a href="#">6XE8195000</a> Relay assembly Go to P/N ) PEO-SD-060002	<a href="#">Buy now</a>
68	<a href="#">6XE8259000</a> Wire harness assembly	<a href="#">Buy now</a>
69	<a href="#">7044822910</a> Grip, control lever 2	<a href="#">Buy now</a>
70	<a href="#">6XE8256310</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
71	<a href="#">7044822810</a> Holder, switch	<a href="#">Buy now</a>
72	<a href="#">7044812800</a> Screw, pan head	<a href="#">Buy now</a>
73	<a href="#">7044815600</a> Nut 1	<a href="#">Buy now</a>
74	<a href="#">6XE8256320</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
75	<a href="#">7044828500</a> Grommet 2	<a href="#">Buy now</a>


## Remote Control Assy 3



E


Ref	Part	
76	<a href="#">7044828600</a> Grommet 3	<a href="#">Buy now</a>
77	<a href="#">7044817800</a> Plate, shift	<a href="#">Buy now</a>
78	<a href="#">7048195000</a> Relay assembly Go to P/N ) PEO-SD-060002	<a href="#">Buy now</a>
79	<a href="#">7044822100</a> Lever control	<a href="#">Buy now</a>
80	<a href="#">7044811920</a> Cover	<a href="#">Buy now</a>

## Tilt Cylinder




Ref	Part	
3	<u>6U00300D040</u> Model	<a href="#">Buy now</a>
3	<u>8</u> - ) 800117 AND BELOW	<a href="#">Buy now</a>
4	<u>9299506600</u> Washer, plain (646)	<a href="#">Buy now</a>
5	<u>9020906M05</u> Washer (688)	<a href="#">Buy now</a>
6	<u>6T48211700</u> Wire, lead	<a href="#">Buy now</a>
8	<u>9709506010</u> Bolt	<a href="#">Buy now</a>
9	<u>41</u> 6Tc-13556-00	<a href="#">Buy now</a>
9	<u>6T44383K00</u> Hose, oil 1	<a href="#">Buy now</a>
10	<u>36</u> -	<a href="#">Buy now</a>
11	<u>6U04383F00</u> Hose, oil 3	<a href="#">Buy now</a>
12	<u>6U04383G00</u> Hose, oil 4	<a href="#">Buy now</a>
13	<u>39</u> -	<a href="#">Buy now</a>
13	<u>6U04383H00</u> Hose, oil 5	<a href="#">Buy now</a>
19	<u>23</u> -	<a href="#">Buy now</a>
26	<u>31</u> -	<a href="#">Buy now</a>

## Tilt Cylinder




Ref	Part	
26	<a href="#"><u>9709506020</u></a> Bolt(7u8)	<a href="#">Buy now</a>
36	<a href="#"><u>34</u></a> -	<a href="#">Buy now</a>
36	<a href="#"><u>6U08211700</u></a> Wire, lead	<a href="#">Buy now</a>
43	<a href="#"><u>2</u></a> N64-83510-00 <b>MMS</b>	<a href="#">Buy now</a>
44	<a href="#"><u>37</u></a> -	<a href="#">Buy now</a>
46	<a href="#"><u>7</u></a> 6Tc-41661-00	<a href="#">Buy now</a>
1	<a href="#"><u>12</u></a> 92990-10100	<a href="#">Buy now</a>
1	<a href="#"><u>6U04278320</u></a> Graphic, Drive (Hydra Drive) <b>FOR DBN1</b>	<a href="#">Buy now</a>
3	<a href="#"><u>6</u></a> - <b>) 800117 AND BELOW</b>	<a href="#">Buy now</a>
8	<a href="#"><u>15</u></a> -	<a href="#">Buy now</a>
17	<a href="#"><u>6U0438130094</u></a> Cylinder, tilt	<a href="#">Buy now</a>
17	<a href="#"><u>6U0438130194</u></a> Cylinder, tilt	<a href="#">Buy now</a>
21	<a href="#"><u>6T44382E00</u></a> Adaptor 2	<a href="#">Buy now</a>
25	<a href="#"><u>32</u></a> -	<a href="#">Buy now</a>
25	<a href="#"><u>6U04381001</u></a> Tilt piston sub assembly	<a href="#">Buy now</a>

# Tilt Cylinder




# Tilt Cylinder



Ref	Part	
46	<a href="#">9014908M11</a> Screw(6t4)	<a href="#">Buy now</a>

# Transom Plate



6U00010-0010

A

Ref	Part	
?	<a href="#">6T445831008D</a> Plate, Transom DBN1	<a href="#">Buy now</a>
2	<a href="#">6U01101910</a> Mount, rubber 2	<a href="#">Buy now</a>
4	<a href="#">9038712M00</a> Collar(6t4)	<a href="#">Buy now</a>
5	<a href="#">9010113M04</a> Bolt(6t4)	<a href="#">Buy now</a>
7	<a href="#">9021521292</a> Washer, Lock FOR POWER	<a href="#">Buy now</a>
9	<a href="#">9046508M33</a> Clamp(6t4)	<a href="#">Buy now</a>
10	<a href="#">6U08214900</a> Wire, lead 3	<a href="#">Buy now</a>
12	<a href="#">9299506600</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">9578012300</a> Nut, nylon (6f2)	<a href="#">Buy now</a>
14	<a href="#">9020113M02</a> Washer, plate(6t4)	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.