



Yamaha LZ250DETO 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers




Contents

BOTTOM COWLING	3
BRACKET 1	8
BRACKET 2	12
CONTROL	15
CRANKSHAFT. PISTON	20
CYLINDER. CRANKCASE 1	23
CYLINDER. CRANKCASE 2	26
CYLINDER. CRANKCASE 3	28
ELECTRICAL 1	30
ELECTRICAL 2	33
ELECTRICAL 3	35
ELECTRICAL 4	39
FUEL 1	40
FUEL 2	44
FUEL INJECTION NOZZLE	45
FUEL INJECTION PUMP	48
FUEL PUMP DRIVE GEAR	51
GENERATOR	53
INTAKE	55
LOWER CASING. DRIVE 1	57
LOWER CASING. DRIVE 2	64
LOWER CASING. DRIVE 3	67
LOWER CASING. DRIVE 4	74
METER	77
OIL PUMP	79
OIL TANK	83
POWER TRIM & TILT ASSY 1	86
POWER TRIM & TILT ASSY 2	91
REMOTE CONTROL BOX	92
REPAIR KIT 1	93
REPAIR KIT 2	95
STARTING MOTOR	97
STEERING GUIDE ATTACHMENT 1	100
STEERING GUIDE ATTACHMENT 2	101
SWITCH. PANEL	102
TOP COWLING	104
UPPER CASING	107
VAPOR SEPARATOR 1	110
VAPOR SEPARATOR 2	114

Bottom Cowling




Bottom Cowling



A5

Ref	Part	
16	64D-43144-00 Hook, spring	Buy now
17	90109-06M80 Bolt	Buy now
18	90506-16M34 Spring, tension(64d)	Buy now
19	60V-42615-00 Seal	Buy now
20	6E5-44391-00 Nipple, hose	Buy now
21	60V-42725-00 Grommet	Buy now
22	60V-42738-00-8D Plate, fitting	Buy now
23	90109-06M81 Bolt	Buy now
24	64D-42738-10-5B Plate, fitting	Buy now
26	90480-22M81 Grommet	Buy now
27	90387-08M37 Coller (6e5)	Buy now
28	90201-08M54 Washer, plate (6e5)	Buy now
29	97075-08035 Bolt(70w)	Buy now
30	90119-08M22 Bolt, with washer	Buy now
31	688-42726-10 Grommet	Buy now


Bottom Cowling



A5

Ref	Part	
32	6E5-82588-00 Plate	Buy now
33	95895-06020 Bolt, flange(jk3)	Buy now
34	60V-42723-00-5B Cover, bottom	Buy now
35	60V-42721-A0 Gasket 1	Buy now
36	60V-42718-00 Rubber, seal 3	Buy now
38	60V-42741-00-8D Apron	Buy now
39	60V-42756-00 Stay, clamp	Buy now
40	97880-04016 Screw, with washer(61b)	Buy now
41	92990-04600 Washer, plain (646)	Buy now
42	90111-06034 Bolt,hex. socket button	Buy now
43	97595-06520 Bolt(7u8)	Buy now
44	60V-12581-00 Joint, hose 1	Buy now
45	60V-12576-00 Hose 1	Buy now
46	60V-12578-00 Hose 3	Buy now
47	60V-12588-00 Hose 5	Buy now


Bottom Cowling



A5

Ref	Part	
48	6E5-24378-00 Pipe, joint 3	Buy now
61	90465-11M10 Clamp FLUSHING KIT	Buy now
50	60V-42771-00 Apron	Buy now
51	97575-08555 Bolt, hexagon w/w deep recess	Buy now
52	61A-42717-00 Rubber, seal 2	Buy now
53	61A-42716-00 Rubber seal 1	Buy now
54	60V-42774-00 Stay, Apron 1	Buy now
55	95895-06016 Bolt, flange deep recess	Buy now
56	6H4-42726-00 Grommet	Buy now
57	6R3-12572-00 Adapter FLUSHING KIT	Buy now
58	90169-05M00 Screw truss head tapping FLUSHING KIT	Buy now
59	6R3-12580-00 Joint assembly FLUSHING KIT	Buy now
60	90445-11M36 Hose (I700) FLUSHING KIT	Buy now
62	68F-42753-00 Fastner AP	Buy now
63	90464-20258 Clamp AP	Buy now


Bottom Cowling



A5

Ref	Part	
64	68H-42791-01 Mark 1	Buy now
65	60V-2415E-60 Label, Caution	Buy now
66	6A1-28176-00 Label Caution	Buy now
67	6E3-8257H-00 Plate Mark	Buy now


Bracket 1



B4


Ref	Part	
1	69J-43111-01-8D Bracket, clamp 1	Buy now
2	6G5-45251-02 Anode	Buy now
3	6G5-44526-00 Plate	Buy now
4	97095-06025 Bolt	Buy now
5	92995-06600 Washer, plain (646)	Buy now
6	6H1-82148-00 Wire, lead	Buy now
7	97095-06010 Bolt	Buy now
9	6E5-82148-00 Wire, lead 5	Buy now
10	97885-06012 Screw, pan head(62j)	Buy now
12	61A-43132-00 Washer, friction	Buy now
13	97885-06010 Screw pan head	Buy now
14	69J-43112-01-8D Bracket, clamp 2	Buy now
15	61A-43133-00 Washer, friction	Buy now
17	93700-06M03 Nipple, grease(6a1)	Buy now
18	90465-08M83 Clamp	Buy now

Bracket 1



Ref	Part	
19	97985-06212 Screw, with washer(6h3)	Buy now
20	6R3-43131-00 Bolt, clamp bracket	Buy now
21	90386-25M31 Bushing (6e5)	Buy now
22	90201-26M59 Washer, plate (6e5)	Buy now
23	90185-22M11 Nut, self-locking	Buy now
24	90465-11M10 Clamp	Buy now
26	97095-06014 Bolt(gj3)	Buy now
28	97095-10045 Bolt(64d)	Buy now
29	92995-10100 Ybs67-10 washer, spring	Buy now
30	92995-10600 Washer, plate	Buy now
31	61A-43311-21-8D Bracket, swivel 1 <i>X</i>	Buy now
31	61A-43311-31-8D Bracket, swivel <i>U</i>	Buy now
33	61A-82147-20 Wire, lead 5 <i>X</i>	Buy now
33	61A-82147-30 Wire, lead 5 <i>U</i>	Buy now
34	6G5-43144-00 Hook, spring	Buy now

Bracket 1




B4

Ref	Part	
36	61A-43181-01 Lever, tilt stop 1	Buy now
37	6G5-43185-02 Lever, tilt stop 2	Buy now
38	90386-10M16 Bushing (688)	Buy now
39	6G5-43148-00 Collar, distance	Buy now
40	90249-06M19 Pin(6e5)	Buy now
41	90387-10M02 Collar(6e5)	Buy now
42	91690-30020 Pin, spring (6h4)	Buy now
43	90506-16003 Spring, tension	Buy now
44	6E5-43126-02 Pin, upper shock mount	Buy now
45	90386-18M63 Bush(6e5)	Buy now
46	90386-18M14 Bushing (6e5)	Buy now
47	93410-18M02 Circlip (6f2)	Buy now
48	90101-12M05 Bolt (l:130mm)	Buy now
49	90201-13M01 Washer, plate(6e5)	Buy now
50	90201-12M05 Washe, plate(663)	Buy now


Bracket 1

Ref	Part	
51	95380-12600 Nut (707)	Buy now



B4


Bracket 2



B6

Ref	Part	
1	60V-42510-20-8D Steering Bracket assembly X	Buy now
1	60V-42510-30-8D Steering Bracket assembly U	Buy now
2	90201-40M00 Washer, plate(61a)	Buy now
3	90386-39M89 Bush(61a)	Buy now
4	93210-35321 O-ring (3m7)	Buy now
5	90202-40M47 Washer, plate(61a)	Buy now
6	61A-44551-01-8D Housing, lower mount rubber	Buy now
7	93410-37M04 Circlip (6e5)	Buy now
8	61A-44575-00 Damper, lower mount rubber	Buy now
9	60V-44555-00-94 Mount damper, lower side	Buy now
10	90202-32M19 Washer, plate (6e5)	Buy now
11	90201-16M55 Washer, plate (6e5)	Buy now
12	6E5-82149-00 Wire, lead 3	Buy now
13	90109-14M48 Bolt	Buy now
14	90201-15M58 Washer, plate (6e5)	Buy now


Bracket 2



B6

Ref	Part	
15	95380-14800 Nut, crown (6e5)	Buy now
16	92995-14600 Washer (6e5)	Buy now
17	61A-44552-01-94 Housing, lower mount rubber	Buy now
18	97095-10045 Bolt(64d)	Buy now
19	92995-10600 Washer, plate	Buy now
20	61A-44553-00-8D Cover, lower mount	Buy now
21	6A0-15789-00 Damper	Buy now
22	60V-44514-00-94 Mount damper, upper side	Buy now
23	90201-16M01 Washer, plate(61a)	Buy now
24	90202-28M46 Washer, plate(61a)	Buy now
25	90201-28M01 Washer, plate(61a)	Buy now
26	90109-14M10 Bolt	Buy now
27	90185-14M00 Nut, self-locking(61a)	Buy now
29	61A-44511-00-94 Cover, upper mount	Buy now
32	69J-83672-00 Trim sender	Buy now


Bracket 2



B6

Ref	Part	
33	97885-06016 Screw, pan head(6b0)	Buy now
34	61A-43376-00 Bolt, thrust receiver	Buy now
35	95780-10300 Nut, nylon (6e5)	Buy now


Control



B1

Ref	Part	
1	60V-48531-00 Bracket, Remote Control 1	Buy now
2	663-48538-00 Clamp, cable 1	Buy now
3	91690-30010 Pin, spring (663)	Buy now
4	90109-06M80 Bolt	Buy now
5	60V-44117-00-1S Bracket	Buy now
6	60V-44194-00 Cap	Buy now
7	97095-06020 Bolt(7u8)	Buy now
8	60V-44176-00-1S Bracket	Buy now
9	93700-06M01 Nipple, grease(61a)	Buy now
10	90386-12069 Bush(666)	Buy now
11	90387-08M09 Collar(61a)	Buy now
12	97095-08035 Bolt(70w)	Buy now
13	92995-08200 Ybs66-8 washer, plain	Buy now
14	90508-20M31 Spring, torsion(61a)	Buy now
15	61A-8259F-00 Switch assembly	Buy now


Control



B1

Ref	Part	
16	61A-82588-01 Plate	Buy now
17	97885-04016 Screw, panhead (796)	Buy now
18	92995-04100 Ybs67-4 washer, spring	Buy now
19	60V-8259F-00 Switch assembly	Buy now
23	61A-44121-00 Lever, shift rod	Buy now
24	68J-44122-01 Bushing, shift rod lever	Buy now
25	90202-08M20 Washer, plate (6e5)	Buy now
26	90468-18008 Clip 620436610000	Buy now
27	6E5-48344-00 Cable end, remote control	Buy now
28	90202-06007 Washer plate 626441880000	Buy now
29	61A-44118-00-8D Bracket	Buy now
30	93700-06M03 Nipple, grease(6a1)	Buy now
31	61A-44116-00 Spring	Buy now
32	97095-06030 Bolt(jf7)	Buy now
33	92995-06100 Washer(6a1)	Buy now

Control




60V1100-323C

B1

Ref	Part	
34	92995-06600 Washer, plain (646)	Buy now
35	61A-44120-22 Handle gear shift assembly X	Buy now
35	61A-44120-32 Handle gear shift assembly U	Buy now
36	93210-09165 O-ring	Buy now
37	61A-44112-00 Stay, handle gear shift	Buy now
38	97013-06012 Bolt(gh1)	Buy now
39	92903-06100 Washer(6a1)	Buy now
40	92903-06600 Washer, plain (646)	Buy now
41	95313-08600 Nut(6l2)	Buy now
42	90386-90M90 Bush(61a)	Buy now
43	91490-20012 Pin, cotter (648)	Buy now
44	90201-09M02 Washer, plate(61a)	Buy now
45	61A-15315-00 Seal, crankcase	Buy now
46	61A-42724-00 Grommet	Buy now
47	61A-44138-00 Washer	Buy now

Control




60V1100-3230

B1

Ref	Part	
48	97885-06008 Screw, pan head(6a3)	Buy now
49	65L-41632-01 Lever, magneto control	Buy now
52	97013-08045 Bolt	Buy now
53	92990-08200 Ybs66-8 washer, plain	Buy now
54	90206-12M00 Washer, wave (676)	Buy now
55	90387-08M16 Collar	Buy now
56	61A-41237-00 Joint, link	Buy now
57	95380-05600 Nut, hexagon (663)	Buy now
58	6H4-41237-00 Joint, link	Buy now
59	60V-41230-00 Cam accelerator comp	Buy now
60	90201-06M31 Washer (6a0)	Buy now
61	90387-06M29 Coller (6a0)	Buy now
62	90206-10M04 Washer, wave (676)	Buy now
63	90119-06MA4 Bolt, with washer	Buy now
64	69L-42744-00 Stay	Buy now


Control



B1

Ref	Part	
65	<u>97885-06030</u> Screw, pan head(6e0)	<u>Buy now</u>
66	<u>95380-06600</u> Nut(661)	<u>Buy now</u>
67	<u>688-44194-00</u> Cap	<u>Buy now</u>
68	<u>90159-05M25</u> Screw,pan head (646)	<u>Buy now</u>


Crankshaft. Piston



B-1


Ref	Part	
1	61A-11411-00 Crankshaft	Buy now
2	61A-11447-00 Seal, crank	Buy now
3	93311-940V0 Bearing, cylindrical(61a)	Buy now
4	93102-40M38 Oil seal(61a)	Buy now
5	60V-11479-00 O-ring	Buy now
6	93306-209U1 Bearing(61a)	Buy now
7	93310-959U0 Bearing, cylindrical(61a)	Buy now
8	61A-11536-00 Gear, drive	Buy now
9	93306-308U0 Bearing(61a)	Buy now
10	93410-40M03 Circlip(n02)	Buy now
11	61A-11586-01 Pulley, crankshaft balance	Buy now
12	60V-11555-00 Nut, crankshaft 1	Buy now
13	93104-22M07 Oil seal(61a)	Buy now
14	60V-15359-00-94 Housing, oil seal	Buy now
15	93102-40010 Oil seal	Buy now

Crankshaft. Piston



Ref	Part	
16	93420-61M07 Circlip(61a)	Buy now
17	60V-15353-00 Gasket, drain	Buy now
18	97095-06020 Bolt(7u8)	Buy now
19	92995-06100 Washer(6a1)	Buy now
20	60V-11631-00-85 Piston (Std)	Buy now
20	60V-11635-00 Piston (0.25Mm O/S) AP	Buy now
20	60V-11636-00 Piston (0.50 o/s) AP	Buy now
21	60V-11603-00 Piston ring set (std)	Buy now
21	60V-11604-00 Piston ring set (0.25mm o/s) AP	Buy now
21	60V-11605-00 Piston ring set (0.50mm o/s) AP	Buy now
22	60V-11642-00-85 Piston 2 (std)	Buy now
22	60V-11645-00 Piston 2 (0.25mm o/s) AP	Buy now
22	60V-11646-00 Piston 2 (0.50mm o/s) AP	Buy now
24	61A-11633-02 Pin, piston	Buy now
25	61A-11634-00 Clip, piston pin	Buy now


Crankshaft. Piston



B1

Ref	Part	
26	69L-11650-00 Connecting Rod assembly	Buy now
27	90109-09001 Bolt	Buy now
28	93310-32638 Bearing	Buy now
29	90201-26M03 Washer, plate(61a)	Buy now
30	93310-84106 Bearing	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
3	6E5-11372-01 Nipple, hose	Buy now
4	624-14485-00 Pipe, joint	Buy now
5	60V-11370-00 Check valve assembly	Buy now
6	90384-06M07 Bush, bimetal formed(6r3)	Buy now
7	90383-16M01 Bush, formed(61a)	Buy now
8	650-11370-01 Check valve assembly	Buy now
9	60V-11370-10 Check valve assembly	Buy now
10	90116-08012 Bolt, stud	Buy now
11	663-11518-01 Lock, bearing	Buy now
12	90340-14M00 Plug, straight screw(62y)	Buy now
13	90430-14115 Gasket (663)	Buy now
14	93608-12063 Pin, dowel (626)	Buy now
15	90445-07M10 Hose (L770)	Buy now
16	90468-07M02 Clip (6e5)	Buy now
17	90105-10M75 Bolt, washer based(65j)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
18	90105-10067 Bolt, flange	Buy now
19	90119-06M13 Bolt, with washer (682)	Buy now
20	90445-07M03 Hose (I200)	Buy now
21	90445-07016 Hose (I60)	Buy now
22	90445-07M29 Hose (I200)	Buy now
23	90445-07MA6 Hose (I200)	Buy now
24	6E0-24378-00 Pipe, joint	Buy now
25	6G5-12581-00 Joint, hose	Buy now
26	62Y-11325-00 Anode	Buy now
27	66M-11328-00 Grommet, anode	Buy now
28	66M-11327-00-94 Cover, anode	Buy now
29	66M-12535-00 Plate	Buy now
30	97095-05012 Bolt, hexagon	Buy now
31	92995-05600 Washer, plain (646)	Buy now
32	97013-06020 Bolt(62y)	Buy now


Cylinder. Crankcase 1



Ref	Part	
33	92903-06600 Washer, plain (646)	Buy now
34	60V-11371-00-94 Cover	Buy now
35	60V-11381-00 Gasket 1	Buy now
36	90119-06MA2 Bolt, with washer	Buy now
37	60V-12411-00 Thermostat	Buy now
38	60V-12413-00-1S Cover Thermostat	Buy now
39	60V-12414-A0 Gasket, cover	Buy now
40	99480-06012 2-	Buy now
41	90119-06055 Bolt, with washer	Buy now
42	66M-11325-00 Anode	Buy now
49	6E5-42761-00-1S Stopper	Buy now
51	68F-44533-00 Damper, upper mount rubber	Buy now

A6


Cylinder. Crankcase 2



B3

Ref	Part	
1	60V-11111-00-1S Head Cylinder 1	Buy now
2	67F-11325-00 Anode	Buy now
3	67F-11327-00-94 Anode cover assembly	Buy now
4	69J-11327-00-94 Anode cover assembly	Buy now
5	60V-11327-00-94 Anode cover assembly	Buy now
6	97075-06020 Bolt(7u8)	Buy now
7	92995-06600 Washer, plain (646)	Buy now
8	67F-11328-00 Grommet, anode	Buy now
9	60V-12535-00 Plate	Buy now
10	97575-08545 Bolt, hexagon w/w deep recess	Buy now
11	97075-08035 Bolt(70w)	Buy now
12	92995-08600 Washer, plain (663)	Buy now
13	68F-11119-00 Hanger, engine	Buy now
14	90119-06MA2 Bolt, with washer	Buy now
15	60V-11191-00-1S Cover, Cylinder Head 1	Buy now


Cylinder. Crankcase 2



Ref	Part	
16	60V-11193-00 Gasket, head cover 1	Buy now
17	90119-06MA4 Bolt, with washer	Buy now
18	68F-83919-00 Clamp, harness	Buy now
19	99590-10114 Pin, dowel	Buy now
20	90119-08MA5 Bolt, with washer	Buy now
21	90119-08MA8 Bolt, with washer	Buy now
22	60V-11181-00 Gasket, cylinder head 1	Buy now
23	60V-11121-00-1S Head, cylinder 2	Buy now
35	69J-1111E-00 Hanger, engine 2	Buy now
37	60V-11192-00-1S Cover, cylinder head 2	Buy now
45	94702-00405 Plug, spark (bk6eku)	Buy now

B3


Cylinder. Crankcase 3



B5

Ref	Part	
1	60V-41113-00-94 Outer cover, exhaust	Buy now
2	676-11372-00 Nipple, hose	Buy now
3	60V-41112-00 Gasket, exhaust inner cover	Buy now
4	60V-41267-00 Bushing, joint	Buy now
5	90119-06MA3 Bolt, with washer	Buy now
6	60V-11327-00-94 Anode cover assembly	Buy now
7	67F-11325-00 Anode	Buy now
8	97075-06020 Bolt(7u8)	Buy now
9	92995-06600 Washer, plain (646)	Buy now
10	67F-11328-00 Grommet, anode	Buy now
11	97075-08030 Bolt, hexagon (fj1)	Buy now
12	92995-08600 Washer, plain (663)	Buy now
13	90467-08004 Clip, pipe 6162435600	Buy now
14	6G5-12416-00 Valve, pressure control	Buy now
15	90501-16M11 Spring, compression (688)	Buy now


Cylinder. Crankcase 3



Ref	Part	
16	90480-20M05 Grommet (688)	Buy now
17	60V-11382-A0 Gasket 2	Buy now
18	6G5-11372-00-1S Cover, bypass 2	Buy now
19	90119-06MA2 Bolt, with washer	Buy now
20	61A-12576-00 Hose 1	Buy now
21	90465-13M18 Clamp	Buy now

B5


Electrical 1



E6


Ref	Part	
1	60V-85542-00-94 Bracket	Buy now
2	60V-85564-00 Grommet	Buy now
3	68F-86129-00 Collar	Buy now
4	68F-86129-10 Collar	Buy now
5	68F-85119-00 Bolt	Buy now
6	60V-8591A-00 Engine Control Unit assembly	Buy now
7	90119-06MA3 Bolt, with washer	Buy now
8	60V-85548-00 Holder	Buy now
9	97013-06014 Bolt(gj3)	Buy now
10	92903-06600 Washer, plain (646)	Buy now
11	60V-8591B-00 Driver, injector assembly	Buy now
12	90119-06MA2 Bolt, with washer	Buy now
13	6E5-82519-00 Wire, Earth Lead	Buy now
14	97095-06012 Bolt(gh1)	Buy now
15	92995-06600 Washer, plain (646)	Buy now

Electrical 1



E6


Ref	Part	
18	68F-82310-01 Ignition coil assembly	Buy now
19	90480-25161 Grommet(656)	Buy now
20	90446-10M01 Tube (6e5)	Buy now
21	68F-82310-11 Ignition coil assembly	Buy now
22	90464-18003 Clamp	Buy now
23	90480-22M15 Grommet (6e5)	Buy now
24	90465-11M10 Clamp	Buy now
25	97013-05020 Bolt, hexagon	Buy now
26	92903-05600 Washer, plain (646)	Buy now
27	68F-82370-01 Plug cap assembly	Buy now
28	60V-82314-00 Cover Ignition Coil	Buy now
29	60V-24198-00 Seat, Rubber	Buy now
30	60V-24198-10 Seat, Rubber	Buy now
31	60V-8818D-00 Seat 1	Buy now
32	60V-8818D-10 Seat 1	Buy now



Ref	Part	
33	60V-23116-00 Seat 2	Buy now
34	60V-23116-10 Seat 2	Buy now
35	60V-2318U-00 Plate, Seat	Buy now
36	60V-2318U-10 Plate, Seat	Buy now
37	68F-85516-01 Spacer	Buy now
40	6A0-82317-00 Damper, ignition coil	Buy now
41	624-42542-00 Collar	Buy now
42	90119-06M65 Bolt, with washer	Buy now
43	60V-8252U-00 Cover	Buy now
44	60V-23115-00 Seat 1	Buy now
45	90111-06034 Bolt, hex. socket button	Buy now
46	68V-81950-00 Relay assembly	Buy now
47	97095-06016 Bolt, hexagon deep recess	Buy now

E6


Electrical 2



F1


Ref	Part	
1	90446-10M86 Hose	Buy now
2	90465-11M10 Clamp	Buy now
3	61A-81949-00 Wire, lead	Buy now
4	97095-06012 Bolt(gh1)	Buy now
5	92995-06600 Washer, plain (646)	Buy now
6	60V-82105-00 Battery cable	Buy now
7	95333-08600 Nut(6l2)	Buy now
8	92903-08100 Ybs67-8 washer, spring	Buy now
9	6E5-82531-10 Wire, lead	Buy now
10	60V-82590-10 Wire Harness assembly	Buy now
13	90465-13M18 Clamp	Buy now
14	60V-8259M-00 Wire Harness assembly 2	Buy now
15	90465-05M87 Clamp	Buy now
17	90464-11008 Clamp	Buy now
19	69J-82563-00 Trim & tilt switch assembly	Buy now

Electrical 2



F1


Ref	Part	
20	69J-82587-00 Gasket	Buy now
21	69J-42723-00 Cover, Bottom	Buy now
22	60V-83614-00 18 –	Buy now
23	60V-83635-00 18 –	Buy now
24	90464-20213 Clamp(4kj)	Buy now
25	90464-23199 Clamp(4hm)	Buy now
26	90109-06M86 Bolt	Buy now
27	67H-82380-00 Sensor, pressure	Buy now
28	98580-06520 Screw pan head	Buy now
29	6E5-82588-00 Plate	Buy now
30	95895-06020 Bolt, flange(jk3)	Buy now



F3


Ref	Part	
1	60V-81960-00 Rectifier & regulator assembly	Buy now
2	60V-81975-A0 Plate, rectifier fitting	Buy now
3	60V-81972-00-1S Cover, rectifier	Buy now
4	90119-06MA3 Bolt, with washer	Buy now
5	90119-06MA4 Bolt, with washer	Buy now
6	90445-09M25 Hose (I1500)	Buy now
7	90467-08M18 Clip	Buy now
8	6L2-82599-01 Cover, connector	Buy now
9	60V-81948-00 Bracket	Buy now
10	68F-85119-00 Bolt	Buy now
11	90119-06M65 Bolt, with washer	Buy now
12	68F-85516-01 Spacer	Buy now
13	68F-86129-00 Collar	Buy now
14	6A0-82317-00 Damper, ignition coil	Buy now
15	624-42542-00 Collar	Buy now

Electrical 3



F3


Ref	Part	
16	60V-87149-00 Connector	Buy now
17	97095-06012 Bolt(gh1)	Buy now
18	92995-06600 Washer, plain (646)	Buy now
19	60V-81950-00 Relay assembly	Buy now
21	682-82119-01 Cover, lead wire	Buy now
22	97095-06010 Bolt	Buy now
23	92995-06100 Washer(6a1)	Buy now
25	68V-8194A-00 Relay	Buy now
26	68F-82117-00 Wire, lead	Buy now
31	68V-81953-00 Stay, relay	Buy now
32	97780-60620 Screw, tapping(6k8)	Buy now
33	90464-23199 Clamp(4hm)	Buy now
34	60V-82170-00 Fuse box assembly <i>Go to P/N) PE0-OM-070040</i>	Buy now
35	60V-82151-00 Fuse (100A) <i>Go to P/N) PE0-OM-070040</i>	Buy now
36	68F-8195A-00 Relay assembly	Buy now



F3


Ref	Part	
37	67F-82151-00 Fuse	Buy now
38	67F-82151-10 Fuse	Buy now
39	68F-82846-00 Screw, pan head (m5)	Buy now
40	97780-50616 Screw, pan head tapping (ak5)	Buy now
41	60V-85544-00 Case	Buy now
42	67F-2812A-00 Puller, fuse	Buy now
43	60V-82157-00 Damper	Buy now
44	60V-81336-00 Grommet	Buy now
45	60V-81336-10 Grommet	Buy now
46	60V-81128-00 Clamp	Buy now
48	60V-81942-00 Cover	Buy now
49	60V-82176-00 Damper	Buy now
51	90169-05M00 Screw truss head tapping	Buy now
52	65L-85886-00 Thermosensor	Buy now
53	60V-85553-00 Nut Rotor	Buy now

Electrical 3



F3


Ref	Part	
54	90201-12M34 Washer (692)	Buy now
55	60V-81919-00 Graphic, Regulator Go to P/N) PE0-OM-070040	Buy now
56	60V-81919-10 Graphic, regulator	Buy now
57	69J-81949-00 Wire, lead (isolator, 3.8m) AP	Buy now



F6


Ref	Part	
1	60V-82588-00 Plate	Buy now
2	97095-06012 Bolt(gh1)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	61A-85790-00 Thermosensor assembly	Buy now
5	92990-10600 Washer, plate	Buy now
6	61A-85895-00 Crank position sender	Buy now
7	97885-05012 Screw,pan head (646)	Buy now
8	688-82560-10 Thermo switch assembly	Buy now
9	90446-10M87 Hose	Buy now

Fuel 1



Ref	Part	
1	61A-24313-00 Pipe 3	Buy now
2	90464-13M34 Clamp(6r3)	Buy now
3	90445-13M17 Hose(l2700)	Buy now
4	6R3-24377-00 Pipe, joint 3	Buy now
5	6E5-82594-00 Clamp	Buy now
6	90465-11M10 Clamp	Buy now
7	68F-24560-00 Filter assembly	Buy now
8	68F-24562-00 Cup, filter	Buy now
9	68F-24519-00 Clip	Buy now
10	68F-24469-00 Float, Water Level	Buy now
11	65L-24531-01 Nut	Buy now
12	61A-24564-00 O-ring	Buy now
13	68F-24563-00 Element, filter	Buy now
14	65L-24564-00 Gasket	Buy now
15	68F-24567-00 Spring	Buy now


Fuel 1



D7

Ref	Part	
16	65L-24558-00 Holder, filter	Buy now
17	97595-06416 Bolt, with washer(62x)	Buy now
18	90201-06068 Washer,plate (6k8)	Buy now
19	68F-24566-00 Bracket, filter	Buy now
20	97595-06514 Bolt(gj3)	Buy now
21	90387-06M60 Collar (6h3)	Buy now
22	90480-10M23 Grommet(6k7)	Buy now
23	90119-06M88 Bolt, with washer	Buy now
24	68F-24311-00 Pipe, Fuel 1	Buy now
26	6E5-24378-00 Pipe, joint 3	Buy now
27	6G5-24315-00 Pipe 5	Buy now
28	90447-19004 Hose, with spring	Buy now
29	6E5-24315-00 Pipe 5	Buy now
30	6E5-24410-03 Fuel pump assembly	Buy now
31	6E5-24444-00 Screw	Buy now


Fuel 1



D7

Ref	Part	
32	6E5-24413-00 Body 2	Buy now
33	6E5-24471-00 Diaphragm	Buy now
34	6E5-24435-00 Gasket, body 2	Buy now
35	6E5-24411-00 Diaphragm	Buy now
36	648-24424-00 Seat, spring	Buy now
37	6E5-24423-00 Spring, diaphragm	Buy now
38	6E5-24434-02 Gasket, body	Buy now
39	6A0-24421-01 Valve, check	Buy now
40	6A0-14325-00 Screw, pan head	Buy now
41	95380-03600 Nut (6g8)	Buy now
42	6E5-24412-10 Body 1	Buy now
43	650-24431-A0 Gasket, fuel pump	Buy now
44	97095-06050 Bolt(jf7)	Buy now
45	92995-06600 Washer, plain (646)	Buy now
46	6G5-24316-10 Pipe 6	Buy now

Fuel 1




D7

Ref	Part	
47	6E5-24313-00 Pipe 3	Buy now
50	65L-83557-00 Tube	Buy now
51	90446-15M07 Hose(6g4)	Buy now
52	90445-13M12 Hose (L235)	Buy now
53	68F-28100-00 Tool kit	Buy now
54	60V-28199-70-A0 Om z250d/lz250d UR (E,F,S)	Buy now
54	60V-28199-70-B0 Om z250d/lz250d UR (D,NL,I)	Buy now
55	60V-28199-80-A0 Manual,Owner's UR (DK,P,GR)	Buy now
55	60V-28199-80-B0 Om z250d/lz250d '06 UR (N,S,SS)	Buy now

Fuel 2


Ref	Part	
1	6YK-24307-42 Fuel pipe comp. 2 AP	Buy now
2	90450-10M07 Hose, clamp AP	Buy now



68J1100-2140

E3


Fuel Injection Nozzle



C6

Ref	Part	
1	68F-13767-00 Cap, injector	Buy now
2	90119-08M60 Bolt (682)	Buy now
3	60V-13782-00 Stay	Buy now
4	90387-08M31 Collar	Buy now
5	90110-08M04 Bolt, hexagon socket head	Buy now
6	60V-13161-00 Pipe Delivery 1	Buy now
7	60V-13171-00 Pipe Delivery 2	Buy now
8	60V-13898-00 Holder	Buy now
9	68F-24551-00 Bolt, joint	Buy now
10	68F-24576-00 Washer	Buy now
11	60V-13761-00 Injector assembly	Buy now
12	68F-1410B-00 Packing kit	Buy now
13	60V-14264-00 Collar	Buy now
14	65L-14565-00 Screw	Buy now
15	60V-82389-00 Plate 2	Buy now


Fuel Injection Nozzle



Ca

Ref	Part	
16	60V-82398-00 Plate 3	Buy now
17	60V-81545-00 Screw 1	Buy now
18	60V-81546-00 Screw 2	Buy now
19	60V-82380-00 Sensor Pressure	Buy now
20	68F-82388-00 Plate	Buy now
21	68F-82384-00 Packing kit	Buy now
22	60V-13938-00 Pipe	Buy now
23	60V-13973-00 Pipe, fuel 3	Buy now
24	68F-2466A-00 Packing kit	Buy now
25	60V-13974-00 Pipe, fuel 4	Buy now
27	65L-14596-00 Washer	Buy now
28	90480-10M23 Grommet(6k7)	Buy now
29	90387-05M00 Collar(6k7)	Buy now
30	60V-13975-00 Pipe Fuel 5	Buy now
32	60V-13976-00 Pipe, fuel 6	Buy now


Fuel Injection Nozzle




Ref	Part	
34	68F-13764-00 Gasket (t=2.2)	Buy now
35	97013-08070 Bolt	Buy now
36	92903-08600 Washer, plain (663)	Buy now
37	97513-08590 Bolt, with washer	Buy now
38	60V-13716-00 Collar	Buy now
39	97013-08055 Bolt, hexagon	Buy now
43	90447-22004 Hose, with spring	Buy now
44	90447-15001 Hose, with spring	Buy now

Ca

Fuel Injection Pump




Fuel Injection Pump




C4

Ref	Part	
17	60V-13854-00 Plate 4	Buy now
18	60V-13910-00 Fuel Pump assembly	Buy now
19	60V-14005-00 Ring, seal	Buy now
20	60V-14126-00 Gasket	Buy now
21	68F-24300-00 Fuel pipe joint	Buy now
22	60V-24178-00 Bolt 3	Buy now
23	60V-24176-00 Bolt 1	Buy now
24	60V-24378-00 Pipe Joint 4	Buy now
25	60V-24864-00 Tube	Buy now
26	60V-2510T-00 Tube	Buy now
27	68F-13815-00 Joint 1	Buy now
28	68F-2466A-00 Packing kit	Buy now
29	60V-13816-00 Joint 2	Buy now
30	68F-24486-00 O-ring	Buy now
32	60V-13505-00 Joint, Pump	Buy now

Fuel Injection Pump



Fuel Pump Drive Gear




60V1010-3060

B6

Ref	Part	
1	60V-11598-00-94 Bracket, tensioner	Buy now
2	97013-08055 Bolt, hexagon	Buy now
3	92903-08600 Washer, plain (663)	Buy now
4	60V-11590-00 Tensioner assembly	Buy now
5	90119-10M72 Bolt, with washer(6m6)	Buy now
6	60V-12113-00 Spring Valve Inner	Buy now
7	90445-15002 Hose (I30)	Buy now
8	60V-11595-00 Plate, valve	Buy now
9	97013-08012 Bolt(62e)	Buy now
10	60V-46241-00 Belt	Buy now
11	68F-11579-01-94 Coupling, flywheel	Buy now
13	68F-11536-00-94 Gear, drive	Buy now
14	93605-10108 Pin, dowel (8g8)	Buy now
15	60V-11557-00 Washer 1	Buy now
16	97095-08025 Bolt (62g)	Buy now


Fuel Pump Drive Gear



Ref	Part	
17	92995-08600 Washer, plain (663)	Buy now
18	68F-11537-00-94 Gear, driven	Buy now
19	90280-03M01 Key woodruff 146115450000	Buy now
20	95707-08600 Nut, flange(jn5)	Buy now


B6

Generator



Ref	Part	
1	60V-81450-00 Rotor assembly	Buy now
2	60V-81410-00 Stator assembly	Buy now
3	60V-85580-00 Coil, pulser	Buy now
4	61A-83721-00 Cover	Buy now
5	97013-06035 Bolt(3rv)	Buy now
6	92903-06100 Washer(6a1)	Buy now
7	92903-06600 Washer, plain (646)	Buy now
8	97885-05030 Ybs86-530 screw,panhead	Buy now
9	92995-05100 Ybs67-5 washer, spring	Buy now
10	92995-05600 Washer, plain (646)	Buy now
11	90280-05015 Key, woodruff	Buy now
12	90170-24M22 Nut(61a)	Buy now
13	90201-25M02 Washer, plate(61a)	Buy now
14	60V-81332-00 Plate Timing	Buy now
15	97885-06010 Screw pan head	Buy now


Generator



Ref	Part	
16	92995-06600 Washer, plain (646)	Buy now
17	90465-06M86 Clamp	Buy now
18	60V-81337-00 Cover, flywheel	Buy now
19	663-82317-01 Damper, ignition coil	Buy now
20	624-42542-00 Collar	Buy now
21	6A0-82317-00 Damper, ignition coil	Buy now
22	95895-06030 Bolt, flange deep recess	Buy now
23	60V-14488-00 Label, caution	Buy now
24	6A1-83625-51 Mark 5	Buy now
25	6A1-83625-41 Mark 5	Buy now
26	6E5-85711-60 Mark Caution	Buy now
27	6K1-83623-41 Mark 3	Buy now
28	6K1-83623-50 Mark 3	Buy now


E4

Intake



D1


Ref	Part	
1	60V-13610-00 Reed valve assembly	Buy now
2	60V-W0004-00 Reed set	Buy now
3	60V-13621-A0 Gasket, Valve Seat	Buy now
4	97880-05016 Screw, pan head(6b0)	Buy now
5	92990-05600 Washer, plain (646)	Buy now
6	60V-13624-00-1S Plate Reed Valve	Buy now
7	60V-13552-00 Nozzle	Buy now
8	60V-13572-00 Nozzle	Buy now
9	60V-11379-00 Valve, check	Buy now
10	6F6-11370-01 Check valve assembly	Buy now
11	90445-07M03 Hose (l200)	Buy now
12	90445-07016 Hose (l60)	Buy now
13	90445-07015 Hose (l65)	Buy now
14	60V-11369-00 Valve Check	Buy now
15	650-11370-01 Check valve assembly	Buy now



D1

Ref	Part	
16	90105-06028 Bolt, washer based	Buy now
17	60V-13646-00 Gasket, manifold 2	Buy now
18	60V-13645-00 Gasket, manifold 1	Buy now
19	97013-06060 Bolt, hexagon	Buy now
20	92903-06600 Washer, plain (646)	Buy now
21	95670-06660 Bolt, stud	Buy now
22	90179-06M24 Nut(6j8)	Buy now
23	60V-14440-00 Silencer assembly, intake	Buy now
24	60V-14476-00 Seal	Buy now
25	90445-07M44 Hose (I390)	Buy now
26	90159-06M16 Screw, with washer(61a)	Buy now
27	68F-11119-00 Hanger, engine	Buy now
28	90119-06MA2 Bolt, with washer	Buy now


Lower Casing. Drive 1



C7

Ref	Part	
1	60V-45300-20-8D Lower unit assembly X	Buy now
1	60V-45300-30-8D Lower Unit assembly U	Buy now
2	60V-45301-00-8D Casing Lower	Buy now
3	93311-83280 Ball bearing	Buy now
4	93332-000W1 Bearing(61a)	Buy now
5	61A-45567-00-10 Shim (t:0.10mm) UR	Buy now
5	61A-45567-00-12 Shim (t:0.12mm) UR	Buy now
5	61A-45567-00-15 Shim (t:0.15mm) UR	Buy now
5	61A-45567-00-18 Shim (t:0.18mm) UR	Buy now
5	61A-45567-00-30 Shim (t:0.30mm) UR	Buy now
5	61A-45567-00-40 Shim (t:0.40mm) UR	Buy now
5	61A-45567-00-50 Shim (t:0.50mm) UR	Buy now
6	663-44366-00 Damper, water seal 2	Buy now
7	90340-08002 Plug, straight screw	Buy now
8	688-45341-10 Plug, drain	Buy now


Lower Casing. Drive 1



C7


Ref	Part	
9	90430-08020 Gasket	Buy now
10	61A-45376-00-94 Guide, seal damper	Buy now
11	61A-45321-01 Plate	Buy now
12	93210-64488 93210-64488	Buy now
13	93106-09014 Oil seal	Buy now
14	90119-06M10 Bolt, with washer	Buy now
15	60V-44150-00 Shift cam assembly	Buy now
16	99001-08600 Circlip(2r6)	Buy now
17	90501-11M10 Spring, compression (663)	Buy now
18	61A-44311-01 Housing, water pump	Buy now
19	61A-44322-02 Insert, cartridge	Buy now
20	93210-86M38 O-ring (6e5)	Buy now
21	93210-37160 O-ring (6g8)	Buy now
22	6E5-44365-00 Damper, water seal 1	Buy now
23	6E5-44312-00 Cover, water pump housing	Buy now

Lower Casing. Drive 1




Ref	Part	
24	6E5-44352-01 Impeller	Buy now
25	90280-04M05 Key, woodruff (6e5)	Buy now
26	61A-45538-00 Spacer, 1	Buy now
27	61A-45527-00 Collar, drive shaft	Buy now
28	90201-22M01 Washer, plate(61a)	Buy now
29	90206-22M19 Washer, wave(61a)	Buy now
30	6G5-44323-00 Outer plate, cartridge	Buy now
31	6E5-44315-A0 Gasket,water pump	Buy now
32	93606-12019 Pin, dowel (614)	Buy now
33	90119-08M14 Bolt, with washer	Buy now
34	61A-45331-00-94 Housing, bearing	Buy now
35	93101-28M16 Oil seal (6e5)	Buy now
36	93317-330U2 Bearing, cylindrical(6k0)	Buy now
37	61A-45587-00-10 Shim (t:0.10mm) UR	Buy now
37	61A-45587-00-12 Shim (t:0.12mm) UR	Buy now

Lower Casing. Drive 1



Ref	Part	
37	61A-45587-00-15 Shim (t:0.15mm) UR	Buy now
37	61A-45587-00-18 Shim (t:0.18mm) UR	Buy now
37	61A-45587-00-30 Shim (t:0.30mm) UR	Buy now
37	61A-45587-00-40 Shim (t:0.40mm) UR	Buy now
37	61A-45587-00-50 Shim (t:0.50mm) UR	Buy now
38	93341-930U9 Bearing	Buy now
39	93210-55M14 O-ring (70e)	Buy now
40	6E5-45344-00 Cover, oil seal	Buy now
41	97095-08025 Bolt (62g)	Buy now
42	92995-08600 Washer, plain (663)	Buy now
43	60V-45501-20 29 – X	Buy now
43	60V-45501-30 Drive shaft comp. U	Buy now
44	60V-45551-00 Pinion	Buy now
45	90201-16M00 Washer, plate(6t5)	Buy now
46	90170-16M19 Nut(6t5)	Buy now


Lower Casing. Drive 1



C7


Ref	Part	
47	60V-45560-00 Gear	Buy now
48	60V-45611-00 Shaft, propeller	Buy now
49	61A-45641-02 Shifter	Buy now
50	61A-45634-01 Slide, shift	Buy now
51	61A-45632-00 Pin, cross	Buy now
52	60V-45631-00 Clutch, dog	Buy now
53	61A-45633-00 Ring, cross pin	Buy now
54	6H1-45668-00 Shaft, free 1	Buy now
55	61A-45635-00 Plunger, shift	Buy now
56	90201-02M00 Washer, plate(61a)	Buy now
57	90183-02M03 Nut, spring (6h1)	Buy now
58	90501-10M77 Spring, compression(61a)	Buy now
59	93501-04011 Ball	Buy now
60	60V-45332-00-94 Housing, bearing	Buy now
61	99590-10114 Pin, dowel	Buy now

Lower Casing. Drive 1



Ref	Part	
62	93306-210U0 Bearing(61a)	Buy now
63	61A-45571-00 Gear	Buy now
64	90201-31M00 Washer, plate(61a)	Buy now
65	61A-45577-00-10 Shim (t:0.10mm) UR	Buy now
65	61A-45577-00-12 Shim (t:0.12mm) UR	Buy now
65	61A-45577-00-15 Shim (t:0.15mm) UR	Buy now
65	61A-45577-00-18 Shim (t:0.18mm) UR	Buy now
65	61A-45577-00-30 Shim (t:0.30mm) UR	Buy now
65	61A-45577-00-40 Shim (t:0.40mm) UR	Buy now
65	61A-45577-00-50 Shim (t:0.50mm) UR	Buy now
66	93315-43061 Bearing	Buy now
67	93101-30M17 Oil seal (6e5)	Buy now
68	93211-04384 O-ring (705)	Buy now
69	90105-08049 Bolt, flange	Buy now
70	90201-08023 Washer, plate	Buy now


Lower Casing. Drive 1



C7

Ref	Part	
71	93700-09M00 Nipple, grease(6t4)	Buy now
72	69J-45361-00-8D Cap, lower casing	Buy now
73	97095-08020 Bolt, hexagon	Buy now


Lower Casing. Drive 2



D4


Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	61A-44361-20 Tube, water X	Buy now
2	61A-44361-30 Tube, water U	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	97095-10045 Bolt(64d)	Buy now
6	92995-10100 Ybs67-10 washer, spring	Buy now
7	92995-10600 Washer, plate	Buy now
8	90119-10MA2 Bolt, with washer	Buy now
9	61A-45375-00 Damper, seal	Buy now
10	61A-45214-10 Cover, water inlet 1	Buy now
11	61A-45215-10 Cover, water inlet 2	Buy now
12	90152-05003 Screw, countersunk	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now
14	69L-45371-00 Tab-trim	Buy now

Lower Casing. Drive 2



Ref	Part	
15	90105-10M00 Bolt, hexagon (663)	Buy now
16	69J-45987-00 Spacer 1	Buy now
17	688-45997-01 Spacer 2	Buy now
18	92990-18200 Washer (6e5)	Buy now
19	90171-18M04 Nut, castle (6e5)	Buy now
20	91490-40030 Pin, cotter (663)	Buy now
21	61A-45972-00-98 Propeller (3x14-1/2"x21"-t) UR	Buy now
21	61A-45974-00-98 Propeller (3x14-1/2"x19"-t) UR	Buy now
21	6G5-45970-02-98 Propeller (3x15-1/4 x15 -m) UR	Buy now
21	6G5-45972-02-98 Propeller (3x13-3/4 x21 -m) UR	Buy now
21	6G5-45974-03-98 Propeller (3x13-3/4"x19"-m2) UR	Buy now
21	6G5-45978-03-98 Propeller (3x13-3/4"x17"-m2) UR	Buy now
21	61A-45978-00-98 Propeller (3x15"x17"-t) UR	Buy now
21	6R4-45970-A0 Propeller (3X15-1/4"X19"-M) UR	Buy now
21	6R4-45972-A0 Propeller (3X14-7/8"X21"-M) UR	Buy now


Lower Casing. Drive 2



Ref	Part	
21	6R4-45974-A0 Propeller (3X14-1/2"X23"-M) UR	Buy now
21	6R4-45976-A0 Propeller (3X14-1/2"X15"-M) UR	Buy now
21	6R4-45978-A0 Propeller (3X15-1/4"X17"-M) UR	Buy now

D4


Lower Casing. Drive 3



D6

Ref	Part	
3	93311-83280 Ball bearing	Buy now
4	61B-45538-01 Spacer 1	Buy now
5	93315-660W3 Bearing, cylindrical(61b)	Buy now
6	93341-670V0 Bearing, thrust (61b)	Buy now
8	663-44366-00 Damper, water seal 2	Buy now
9	90340-08002 Plug, straight screw	Buy now
10	688-45341-10 Plug, drain	Buy now
11	90430-08020 Gasket	Buy now
13	61A-45321-01 Plate	Buy now
14	93210-64488 93210-64488	Buy now
15	93106-09014 Oil seal	Buy now
16	90119-06M10 Bolt, with washer	Buy now
17	60W-44150-00 Shift cam assembly	Buy now
18	99001-08600 Circlip(2r6)	Buy now
19	90501-11M10 Spring, compression (663)	Buy now


Lower Casing. Drive 3



D6

Ref	Part	
20	61A-44311-01 Housing, water pump	Buy now
21	61A-44322-02 Insert, cartridge	Buy now
22	93210-86M38 O-ring (6e5)	Buy now
23	93210-37160 O-ring (6g8)	Buy now
24	6E5-44365-00 Damper, water seal 1	Buy now
25	6E5-44312-00 Cover, water pump housing	Buy now
26	6E5-44352-01 Impeller	Buy now
27	90280-04M05 Key, woodruff (6e5)	Buy now
28	61A-45538-00 Spacer, 1	Buy now
29	61A-45527-00 Collar, drive shaft	Buy now
30	90201-22M01 Washer, plate(61a)	Buy now
31	90206-22M19 Washer, wave(61a)	Buy now
32	6G5-44323-00 Outer plate, cartridge	Buy now
33	6E5-44315-A0 Gasket,water pump	Buy now
34	93606-12019 Pin, dowel (614)	Buy now


Lower Casing. Drive 3



D6

Ref	Part	
35	90119-08M14 Bolt, with washer	Buy now
36	61A-45331-00-94 Housing, bearing	Buy now
37	93101-28M16 Oil seal (6e5)	Buy now
38	93317-330U2 Bearing, cylindrical(6k0)	Buy now
39	61A-45587-00-10 Shim (t:0.10mm) UR	Buy now
39	61A-45587-00-12 Shim (t:0.12mm) UR	Buy now
39	61A-45587-00-15 Shim (t:0.15mm) UR	Buy now
39	61A-45587-00-18 Shim (t:0.18mm) UR	Buy now
39	61A-45587-00-30 Shim (t:0.30mm) UR	Buy now
39	61A-45587-00-40 Shim (t:0.40mm) UR	Buy now
39	61A-45587-00-50 Shim (t:0.50mm) UR	Buy now
40	93341-930U9 Bearing	Buy now
41	93210-55M14 O-ring (70e)	Buy now
42	6E5-45344-00 Cover, oil seal	Buy now
43	97095-08025 Bolt (62g)	Buy now


Lower Casing. Drive 3



D6

Ref	Part	
44	92995-08600 Washer, plain (663)	Buy now
45	60V-45501-20 29 – X	Buy now
46	60V-45551-00 Pinion	Buy now
47	90201-16M00 Washer, plate(6t5)	Buy now
48	90170-16M19 Nut(6t5)	Buy now
49	60W-45560-00 Gear	Buy now
50	93317-428U7 Bearing	Buy now
51	69K-45611-00 Shaft, propeller	Buy now
52	61B-45641-01 Shifter	Buy now
53	61A-45634-01 Slide, shift	Buy now
54	61A-45632-00 Pin, cross	Buy now
55	60V-45631-00 Clutch, dog	Buy now
56	61A-45633-00 Ring, cross pin	Buy now
57	6H1-45668-00 Shaft, free 1	Buy now
58	61A-45635-00 Plunger, shift	Buy now


Lower Casing. Drive 3



D6

Ref	Part	
59	90201-02M00 Washer, plate(61a)	Buy now
60	90183-02M03 Nut, spring (6h1)	Buy now
61	90501-10M77 Spring, compression(61a)	Buy now
62	93501-04011 Ball	Buy now
63	60W-45332-00-94 Housing, bearing	Buy now
64	99590-10114 Pin, dowel	Buy now
65	93332-00048 Bearing(6k0)	Buy now
66	60W-45571-00 Gear	Buy now
67	93341-440U5 Bearing, thrust (6k0)	Buy now
68	6K1-45578-01-10 Shim (t:0.10mm) UR	Buy now
68	6K1-45578-01-12 Shim (t:0.12mm) UR	Buy now
68	6K1-45578-01-15 Shim (t:0.15mm) UR	Buy now
68	6K1-45578-01-18 Shim (t:0.18mm) UR	Buy now
68	6K1-45578-01-30 Shim (t:0.30mm) UR	Buy now
68	6K1-45578-01-40 Shim (t:0.40mm) UR	Buy now


Lower Casing. Drive 3



D6

Ref	Part	
68	6K1-45578-01-50 Shim (t:0.50mm) UR	Buy now
69	61B-45383-00 Washer, claw	Buy now
70	69K-45384-00 Nut	Buy now
71	69K-45577-00 Shim (t:0.10mm) UR	Buy now
71	69K-45577-10 Shim (t:0.12mm) UR	Buy now
71	69K-45577-20 Shim (t:0.15mm) UR	Buy now
71	69K-45577-30 Shim (t:0.18mm) UR	Buy now
71	69K-45577-40 Shim (t:0.30mm) UR	Buy now
71	69K-45577-50 Shim (t:0.40mm) UR	Buy now
71	69K-45577-60 Shim (t:0.50mm) UR	Buy now
72	93315-43061 Bearing	Buy now
73	93101-30M17 Oil seal (6e5)	Buy now
74	93211-04384 O-ring (705)	Buy now
75	90105-08049 Bolt, flange	Buy now
76	90201-08023 Washer, plate	Buy now


Lower Casing. Drive 3



D6

Ref	Part	
77	93700-09M00 Nipple, grease(6t4)	Buy now
78	69J-45361-00-8D Cap, lower casing	Buy now
79	97095-08020 Bolt, hexagon	Buy now


Lower Casing. Drive 4



E3

Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	61A-44361-20 Tube, water X	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	97095-10045 Bolt(64d)	Buy now
6	92995-10100 Ybs67-10 washer, spring	Buy now
7	92995-10600 Washer, plate	Buy now
8	90119-10MA2 Bolt, with washer	Buy now
9	61A-45375-00 Damper, seal	Buy now
10	61A-45214-10 Cover, water inlet 1	Buy now
11	61A-45215-10 Cover, water inlet 2	Buy now
12	90152-05003 Screw, countersunk	Buy now
13	90185-05002 Nut nylon (sus)(ex4)	Buy now
14	69L-45371-00 Tab-trim	Buy now
15	90105-10M00 Bolt, hexagon (663)	Buy now

Lower Casing. Drive 4




Ref	Part	
16	69J-45987-00 Spacer 1	Buy now
17	688-45997-01 Spacer 2	Buy now
18	92990-18200 Washer (6e5)	Buy now
19	90171-18M04 Nut, castle (6e5)	Buy now
20	91490-40030 Pin, cotter (663)	Buy now
21	61B-45972-00-98 Propeller (ss 3x14-1/2"x21"-tl) UR	Buy now
21	61B-45974-00-98 Propeller (3x14-1/2"x19"-tl) UR	Buy now
21	61B-45978-00-98 Propeller (3x5"x17"-tl) UR	Buy now
21	6K1-45970-01-98 Propeller (3x15-1/4"x15"-ml) UR	Buy now
21	6K1-45972-01-98 Propeller (3x13-3/4"x21"-ml) UR	Buy now
21	6K1-45974-02-98 Propeller (3x13-3/4"x19"-ml1) UR	Buy now
21	6K1-45978-02-98 Propeller (3x13-3/4"x17"-ml1) UR	Buy now
21	6R1-45970-A0 Propeller, Ss (3 X 15-1/4" X 19"-MI) UR	Buy now
21	6R1-45972-A0 Propeller (3X14-7/8"X21"-MI) UR	Buy now
21	6R1-45974-A0 Propeller (3X14-1/2"X23"-MI) UR	Buy now

Lower Casing. Drive 4


Ref	Part	
21	6R1-45976-A0 Propeller (3X15-1/4"X15"-MI) UR	Buy now
21	6R1-45978-A0 Propeller (3X15-1/4"x17"-MI) UR	Buy now

COUNTER ROTATION




E3

Meter



F1


Ref	Part	
1	6Y5-8350T-02 Digital tachometer assembly AP	Buy now
2	9E450-04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450-04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5-83500-S5 Meter assembly AP	Buy now
7	6Y5-83570-S5 Speedometer assembly	Buy now
10	6Y5-83533-T2 Grommet	Buy now
11	6Y5-83557-31 Tube	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
20	90465-11M10 Clamp AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
15	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
16	1E6-82151-00 Fuse (10a) FOR 6Y5-83553-M0	Buy now



F1

Ref	Part	
17	6Y5-82117-00 Wire, lead AP	Buy now
18	68F-82553-80 Extension, wire lead (8m) AP	Buy now
18	68F-82553-90 Extension, wire lead (9m) AP	Buy now
19	6Y5-83557-10 Tube (8m) AP	Buy now
21	6Y5-8350F-00 Fuel meter movement assembly AP	Buy now
23	6Y5-83553-F1 Wire, lead AP	Buy now
24	6Y5-85752-01 Sender unit assembly, fuel meter AP	Buy now
25	90158-06002 33 – AP	Buy now
27	703-82531-00 Wire, lead AP	Buy now


Oil Pump



D3

Ref	Part	
1	60V-13200-00 Oil injection pump assembly	Buy now
2	6R3-13471-00 Screw	Buy now
3	6L2-13475-00 Gasket, breather bolt	Buy now
4	93210-19M82 O-ring(6j8)	Buy now
5	90109-06M40 Bolt(6h0)	Buy now
6	6G5-13416-00 Pipe, oil 1	Buy now
7	90446-17MA8 Hose	Buy now
8	90465-11M10 Clamp	Buy now
9	90446-07M35 Hose(62t)	Buy now
10	90445-07M96 Hose(62t)	Buy now
11	90446-07M48 Hose(62t)	Buy now
12	90445-07M44 Hose (I390)	Buy now
13	90445-07M46 Hose (I390)	Buy now
14	90445-07M10 Hose (L770)	Buy now
15	90445-07M04 Hose(62t)	Buy now


Oil Pump



D3

Ref	Part	
16	6R3-13183-00 Valve, check	Buy now
17	90468-07M02 Clip (6e5)	Buy now
18	90464-07M05 Clamp (6g5)	Buy now
20	90464-07M20 Clamp(6h0)	Buy now
21	61A-11537-00 Gear, driven	Buy now
22	90201-09M01 Washer, plate(61b)	Buy now
23	61A-13117-00 Collar, distance	Buy now
24	93210-18MA9 O-ring(61a)	Buy now
25	6R5-41237-00 Joint, link	Buy now
26	65L-41241-00 Rod, Link	Buy now
27	95380-05600 Nut, hexagon (663)	Buy now
28	6H1-41237-00 Joint, link	Buy now
29	91490-12012 Pin, cotter (6g8)	Buy now
30	90202-05088 Washer, plate (666)	Buy now
31	60V-24319-00 Pipe, oil	Buy now

Oil Pump




D3

Ref	Part	
33	90467-08M18 Clip	Buy now
34	68F-13100-00 Solenoid pump assembly	Buy now
35	68F-13418-00 Hose 4	Buy now
36	68F-13184-00 Spring, oil pipe	Buy now
37	68F-13440-00 Filter assembly	Buy now
38	68F-1316F-00 Hose 1	Buy now
39	68F-13133-00 Clip	Buy now
40	68F-1316G-00 Hose 2	Buy now
41	68F-1316A-00 Check Valve assembly	Buy now
42	68F-13416-00 Hose 3	Buy now
43	68F-14485-00 Pipe, joint	Buy now
44	60V-1319K-00 Plate	Buy now
45	97095-06020 Bolt(7u8)	Buy now
46	92995-06100 Washer(6a1)	Buy now
47	92995-06600 Washer, plain (646)	Buy now


Oil Pump

Ref	Part	
48	90110-06M06 Bolt, hexagon socket head	Buy now



D3


Oil Tank



D5

Ref	Part	
1	61A-21750-00 Oil tank assembly	Buy now
2	6E5-13448-00 Cap, oil tank	Buy now
3	90465-13M11 Clamp (6e5)	Buy now
4	61A-85730-01 Oil level gauge assembly	Buy now
5	61A-13411-00 Strainer, oil	Buy now
6	6E5-13414-00 Gasket, strainer cover	Buy now
7	90445-05M07 Hose (I700)	Buy now
8	6A0-82317-00 Damper, ignition coil	Buy now
9	624-42542-00 Collar	Buy now
10	90119-06M65 Bolt, with washer	Buy now
11	6R3-8259E-00 Switch assembly	Buy now
12	6E5-24379-00 Pipe, joint 4	Buy now
13	90445-12M04 Hose (I3000)	Buy now
14	90465-11M10 Clamp	Buy now
15	6E5-24323-00 Pipe 12	Buy now


Oil Tank



D5

Ref	Part	
18	90464-13M34 Clamp(6r3)	Buy now
19	61A-21708-20 Sub oil tank assembly.	Buy now
20	6E5-21733-20 Sub tank, oil (10.5l)	Buy now
21	6E5-21770-03 Oil tank cap assembly	Buy now
22	6E5-24322-00 Pipe 11	Buy now
24	646-24251-02 Strainer 1	Buy now
25	6E5-24319-01 Pipe, oil	Buy now
27	6E5-81900-01 Oil feed pump assembly	Buy now
28	6E5-81922-00 Grommet	Buy now
29	6E5-24321-01 Pipe 10	Buy now
31	90445-11M26 Hose (l8000)	Buy now
33	6E5-85720-04 Oil level gauge assembly	Buy now
34	6R3-85721-80 Wire, lead	Buy now
35	6E5-21734-01-33 Holder, oil sub tank	Buy now
36	6E5-21798-01-33 Bracket, damper	Buy now


Oil Tank



Ref	Part	
37	6E5-21746-00 Damper	Buy now
38	97080-06100 Bolt, hexagon	Buy now
39	92990-06600 Washer, plain (646)	Buy now
40	95380-06600 Nut(661)	Buy now
42	6E5-13437-62 Mark Caution	Buy now

D5


Power Trim & Tilt Assy 1



C1

Ref	Part	
1	60V-43800-00-4D Power trim & tilt assembly	Buy now
2	61A-43840-01 Power tilt assembly	Buy now
3	61A-43810-00 Tilt piston sub assembly	Buy now
4	61A-43861-00 O-ring	Buy now
5	61A-43871-00 Ring, back up	Buy now
6	93106-19N50 Oil seal	Buy now
7	6H1-43861-00 O-ring	Buy now
8	6H1-43872-00 Ring, back up	Buy now
9	61A-4389H-00 O-ring	Buy now
11	6H1-43814-00 Piston, free	Buy now
12	61A-43813-01 Cylinder, tilt	Buy now
13	69J-43888-00 Bolt, socket	Buy now
14	61A-43835-01 Pipe	Buy now
15	61A-43833-01 Pipe	Buy now
16	61A-43818-00 Pin, lower shock mount	Buy now


Power Trim & Tilt Assy 1



C1

Ref	Part	
17	90386-18M14 Bushing (6e5)	Buy now
18	6H1-43817-00 Filter 2	Buy now
19	97607-04230 Screw, pan head with washer	Buy now
20	69J-43828-00 Body, reservoir	Buy now
21	6H1-43869-00 O-ring	Buy now
22	61A-4384L-00 Spring Trim Down	Buy now
23	6T4-43851-00 Seat, relief valve	Buy now
24	97607-05210 Screw, With Washer	Buy now
25	61A-4384K-00 Plate, trim down	Buy now
26	61A-4384J-00 Seal, trim down	Buy now
27	93210-064A5 O-ring(61a)	Buy now
28	93505-32038 Ball(7fk)	Buy now
29	61A-43875-00 Ring, snap	Buy now
30	61A-43848-00 Rod, manual release	Buy now
31	61A-43854-00 Spring, manual release	Buy now


Power Trim & Tilt Assy 1



C1

Ref	Part	
32	61A-43845-00 Screw, manual release	Buy now
33	6H1-43875-00 Ring, snap	Buy now
34	93210-18397 O-ring (6g5)	Buy now
35	61A-43847-00 Seat, manual valve	Buy now
36	6T4-43876-00 Ring, snap	Buy now
37	93210-07003 O-ring (11m)	Buy now
38	93210-06001 O-ring (26h)	Buy now
39	6T4-43849-00 Pin, valve support	Buy now
40	61A-4385H-00 Spring, seal	Buy now
41	61A-4384F-00 Seal, main valve	Buy now
42	6H1-43831-00 Connector, shaft	Buy now
43	6T4-43830-00 Gear pump assembly	Buy now
44	61A-4382K-00 Cap, relief valve	Buy now
45	6H1-43856-10 Spring, down relief	Buy now
46	6T4-43844-00 Pin, valve support	Buy now


Power Trim & Tilt Assy 1



C1

Ref	Part	
47	6T4-4384G-00 Seal, relief valve	Buy now
48	6T4-43855-00 Spring, up relief	Buy now
49	6T4-43895-00 Seat, relief valve	Buy now
50	93210-10M74 O-ring	Buy now
51	6H1-43816-00 Filter 1	Buy now
52	6T4-43802-03 Valve sub assembly	Buy now
53	6H1-43866-00 O-ring	Buy now
54	6H1-43867-00 O-ring	Buy now
55	6T4-43841-00 Piston, shuttle	Buy now
56	93210-09165 O-ring	Buy now
57	6H1-43829-00 Plug, reservoir	Buy now
58	61A-43878-00 Bolt, socket	Buy now
59	6T4-43875-01 Ring, snap	Buy now
60	61A-43822-00 Seal, trim dust	Buy now
61	61A-43821-00 Screw, trim cylinder end	Buy now


Power Trim & Tilt Assy 1



C1

Ref	Part	
62	91609-10014 Pin, spring(61a)	Buy now
64	61A-43820-10 Trim piston sub assembly	Buy now
65	61A-43874-00 Ring, back up	Buy now
66	61A-43864-00 O-ring	Buy now
67	61A-43875-10 Ring, snap	Buy now
68	61A-4383H-11 Hose, oil 5	Buy now
69	61A-4384H-10 Spring	Buy now
70	61A-43876-00 Ring, snap	Buy now
71	6T4-43893-00 Washer	Buy now
72	93501-08001 Ball	Buy now
73	61A-4382A-00 Adaptor 1	Buy now
74	69J-43880-00 Motor assembly	Buy now


Power Trim & Tilt Assy 2



Ref	Part	
1	69J-43880-00 Motor assembly	Buy now
2	90206-14N50 Washer, wave	Buy now
3	93399-999T6 Bearing	Buy now
4	69J-43805-00 Armature assembly	Buy now
5	69J-43804-00 Stator assembly	Buy now
6	69J-43861-00 O-ring	Buy now
7	69J-43886-00 Bolt	Buy now
8	69J-43882-00 Oil seal	Buy now
9	69J-43891-00 Brush 1	Buy now
10	69J-4386K-00 Spring, brush	Buy now
11	69J-43881-00 Frame, end	Buy now

C4

Remote Control Box




67H0100-9310

E7

Ref	Part	
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	704-48207-23 Remote Control assembly AP WITH PT/T SW.	Buy now
3	701-48320-50 Cable, Remote Control L=15F UR	Buy now
3	701-48320-60 Cable, Remote Control L=16F UR	Buy now
3	701-48320-80 Cable, Remote Control L=17F UR	Buy now
3	701-48350-00 Cable, Remote Control L=21F UR	Buy now
3	701-48350-20 Cable, Remote Control L=23F UR	Buy now


Repair Kit 1



F4

Ref	Part	
1	60V-W0001-00 Power head gasket kit	Buy now
2	60V-11193-00 Gasket, head cover 1	Buy now
3	60V-11181-00 Gasket, cylinder head 1	Buy now
4	90430-14115 Gasket (663)	Buy now
5	60V-11381-00 Gasket 1	Buy now
6	60V-12414-A0 Gasket, cover	Buy now
7	60V-41112-00 Gasket, exhaust inner cover	Buy now
8	60V-11382-A0 Gasket 2	Buy now
9	93104-22M07 Oil seal(61a)	Buy now
10	93102-40010 Oil seal	Buy now
11	60V-15353-00 Gasket, drain	Buy now
12	60V-13646-00 Gasket, manifold 2	Buy now
13	60V-13645-00 Gasket, manifold 1	Buy now
14	60V-14476-00 Seal	Buy now
15	93210-18MA9 O-ring(61a)	Buy now


Repair Kit 1



F4

Ref	Part	
16	60V-13621-A0 Gasket, Valve Seat	Buy now
17	60V-11479-00 O-ring	Buy now
18	60V-45113-00 Gasket, upper casing	Buy now


Repair Kit 2



F5

Ref	Part	
1	60V-W0001-20 Lower unit gasket kit	Buy now
2	61A-41134-A0 Gasket, exhaust manifold	Buy now
3	60V-45114-00 Gasket, upper casing	Buy now
4	90430-08020 Gasket	Buy now
5	61A-45123-01 Gasket, muffler	Buy now
6	6E5-44365-00 Damper, water seal 1	Buy now
7	6E5-44366-00 Damper, water seal 2	Buy now
8	93210-64488 93210-64488	Buy now
9	93106-09014 Oil seal	Buy now
10	93210-86M38 O-ring (6e5)	Buy now
11	93210-37160 O-ring (6g8)	Buy now
12	6E5-44315-A0 Gasket,water pump	Buy now
13	93101-28M16 Oil seal (6e5)	Buy now
14	93210-55M14 O-ring (70e)	Buy now
15	93211-04384 O-ring (705)	Buy now


Repair Kit 2



F5

Ref	Part	
16	93101-30M17 Oil seal (6e5)	Buy now
17	61A-W0078-A3 Water pump repair kit	Buy now
18	61A-44322-02 Insert, cartridge	Buy now
21	6E5-44352-01 Impeller	Buy now
22	6G5-44323-00 Outer plate, cartridge	Buy now
24	93606-12019 Pin, dowel (614)	Buy now
25	90119-08M14 Bolt, with washer	Buy now
26	90280-04M05 Key, woodruff (6e5)	Buy now


Starting Motor



F7

Ref	Part	
1	60V-81800-00 Starting motor assembly	Buy now
2	67F-81850-00 Armature assembly	Buy now
3	67F-81810-00 Stator assembly	Buy now
4	69J-81840-00 Brush holder assembly	Buy now
5	69J-81801-00 Brush set	Buy now
6	67F-81813-00 Spring, brush	Buy now
7	68F-81820-00 Rear bracket assembly	Buy now
8	67F-81808-00 Pinion assembly	Buy now
9	67F-81857-00 Pinion stopper set	Buy now
10	67F-81807-00 Gear assembly, starting motor	Buy now
11	67F-81832-00 Clutch, over run	Buy now
12	67F-81836-00 Shaft, pinion	Buy now
13	67F-81821-00 Bracket, center 1	Buy now
14	67F-81841-00 Bearing	Buy now
15	67F-81891-00 Gear, ring	Buy now


Starting Motor



F7

Ref	Part	
16	67F-8183R-00 Gasket	Buy now
17	67F-81830-00 Bracket, center 2	Buy now
18	60V-8183T-00 Gear, idler	Buy now
19	67F-81809-00 Washer kit	Buy now
20	60V-81842-00 Cover	Buy now
21	69J-81839-00 Lever assembly	Buy now
22	69J-81941-00 Starter relay assembly	Buy now
23	69J-81869-00 Cover Dust	Buy now
24	6K7-81826-10 Bolt	Buy now
25	69J-81828-00 Bolt 2	Buy now
26	67F-81846-00 Screw	Buy now
27	90179-08003 Nut	Buy now
28	60V-81925-00 Terminal	Buy now
29	68F-82582-00 Cover, wire harness	Buy now
30	97013-08045 Bolt	Buy now


Starting Motor



Ref	Part	
31	92903-08600 Washer, plain (663)	Buy now
32	67F-83627-01 Label, caution 7	Buy now

F7

Steering Guide Attachment 1




67H0100-9290

E5

Ref	Part	
1	6E5-61350-02 Steering guide attachment kit AP	Buy now
2	6E5-61351-01 Rod, steering link	Buy now
3	90387-10M61 Collar (6e5)	Buy now
4	90560-12M01 Spacer (6e5)	Buy now
5	6E5-61355-00 Bolt	Buy now
6	90185-09M01 Nut, nylon (663)	Buy now
7	90201-10M20 Washer, plate (663)	Buy now
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now

Steering Guide Attachment 2




67H0100-0300

E6


Ref	Part	
1	6E5-61301-01 Tie bar assembly (l:600-800mm) AP	Buy now
2	6E5-61313-00 Adjuster	Buy now
3	6E5-61311-11 Tie bar	Buy now
4	6E5-61315-00 Tie bar, 2	Buy now
5	6E5-61303-00 Steering axle comp.	Buy now
6	90170-14M06 Nut (6e5)	Buy now
7	95380-14700 Nut (6e5)	Buy now
8	90201-10M76 Washer, plate (6e5)	Buy now
9	90101-09M70 Bolt (6e5)	Buy now
10	90170-09M05 Nut, hexagon (6e5)	Buy now
11	90185-09M01 Nut, nylon (663)	Buy now

Switch. Panel



Ref	Part	
1	6K1-82570-07 Panel switch assembly AP	Buy now
2	6K1-82571-01 Plate, panel switch	Buy now
3	6K1-82510-06 Main switch assembly	Buy now
4	703-82577-00 Cap, key	Buy now
5	6K1-82575-00 Engine stop switch assembly	Buy now
6	682-82556-00 Lanyard, stop switch	Buy now
7	6K1-83614-01 Bracket	Buy now
8	98980-05010 Screw, bind(6k1)	Buy now
23	92990-05100 Ybs67-5 washer, spring AP	Buy now
21	95380-05600 Nut, hexagon (663) AP	Buy now
11	688-83383-11 Buzzer	Buy now
12	6K1-85830-01 Control unit assembly	Buy now
13	98980-06020 Screw, bind (j17)	Buy now
14	95380-06600 Nut(661)	Buy now
15	92990-06100 Washer(6a1)	Buy now


Switch. Panel



F3

Ref	Part	
16	92990-06600 Washer, plain (646)	Buy now
17	6K1-81980-00 Diode assembly	Buy now
18	6K1-8258A-40 Extension, wire harness AP	Buy now
19	61B-8258A-01 Extension, wire harness AP	Buy now
20	90149-05M05 Screw(6k0) AP	Buy now
22	92990-05600 Washer, plain (646) AP	Buy now


Top Cowling



A4

Ref	Part	
1	60V-42610-00-8D Top Cowling assembly	Buy now
2	68F-42647-01-94 Holder, clamp band	Buy now
3	68F-42648-01-94 Holder, clamp band	Buy now
4	92990-06100 Washer(6a1)	Buy now
5	95380-06600 Nut(661)	Buy now
6	68F-42663-00 Damper 2	Buy now
7	60V-42651-00 Hook	Buy now
8	60V-42652-00 Hook	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	60V-42613-00-8D Molding, Air Duct	Buy now
12	60V-42621-00 Mldg Top	Buy now
13	97780-50616 Screw, pan head tapping (ak5)	Buy now
14	60V-42664-00 Damper	Buy now
15	90445-11M33 Hose (1700)	Buy now


Top Cowling



A4

Ref	Part	
16	60V-42687-00 Emblem, rear	Buy now
17	90462-08018 Clamp	Buy now
18	97780-50612 Screw, tapping(61a)	Buy now
19	90179-06M24 Nut(6j8)	Buy now
20	60V-42662-00 Damper	Buy now
21	60V-42677-00 Graphic, front	Buy now
22	60V-W0070-00 1-	Buy now
23	60V-42681-00 Mark, cowling	Buy now
24	60V-42682-00 Mark, cowling	Buy now
25	60V-42678-00 Graphic, front	Buy now
26	67F-13448-00 Cap	Buy now
27	60V-42626-00 Louver 1	Buy now
28	60V-42626-10 Louver 1	Buy now
29	90160-05005 Screw, round tapping	Buy now
30	60V-42637-00 Damper Form	Buy now


Top Cowling



A4

Ref	Part	
31	60V-42637-10 Damper Form	Buy now
32	68F-13434-00 Label, Caution	Buy now


Upper Casing



C5

Ref	Part	
1	60V-45111-20-8D Casing, Upper X	Buy now
1	60V-45111-30-8D Casing, Upper U	Buy now
2	6E5-24377-00 Pipe, joint	Buy now
3	61A-42791-S0 Mark 1	Buy now
4	61A-42792-S0 Mark	Buy now
5	61A-45155-00 Cap	Buy now
6	97095-06010 Bolt	Buy now
38	92995-06600 Washer, plain (646) U	Buy now
8	93608-12M05 Pin, dowel b (6e5)	Buy now
9	90119-08052 Bolt, with washer	Buy now
10	61A-45378-00 Nipple, hose	Buy now
11	90119-06M17 Bolt, with washer	Buy now
12	93606-12019 Pin, dowel (614)	Buy now
13	90445-07M21 Hose (l1160) U	Buy now
13	90445-07MF0 Hose (l1160) X	Buy now


Upper Casing



C5

Ref	Part	
14	6E5-83558-00 End, nipple	Buy now
15	90465-11M10 Clamp	Buy now
16	6E5-45318-00 Bushing, drive shaft 3	Buy now
17	93420-36M01 Circlip (6a0)	Buy now
18	60V-45114-00 Gasket, upper casing	Buy now
19	60V-41137-00-94 Guide, exhaust	Buy now
21	60V-45113-00 Gasket, upper casing	Buy now
22	90119-08053 Bolt, with washer UR *1	Buy now
23	90119-08060 Bolt, with washer	Buy now
24	6H1-11372-00 Nipple, hose	Buy now
25	60V-41131-00-94 Manifold, Ext. 1	Buy now
22	90119-08065 Bolt, with washer UR *2	Buy now
26	90119-08056 Bolt With Washer	Buy now
27	61A-41132-01-5B Manifold, exhaust	Buy now
28	61A-41134-A0 Gasket, exhaust manifold	Buy now


Upper Casing



C5

Ref	Part	
29	90119-08059 Bolt, with washer	Buy now
30	60V-14711-20-5B Muffler 1	Buy now
31	6E5-14737-00 Damper, muffler	Buy now
32	90183-05M02 Nut, spring (6e5)	Buy now
35	61A-45123-01 Gasket, muffler <i>U</i>	Buy now
36	61A-14721-30-5B Muffler 2 <i>U</i>	Buy now
37	97095-06035 Bolt(j52) <i>U</i>	Buy now


Vapor Separator 1



B7

Ref	Part	
1	60V-24216-00 Stay	Buy now
2	68F-24473-00 Screw	Buy now
3	60V-14980-00 Body, float chamber	Buy now
4	60V-14182-00 Cover, float chamber	Buy now
5	65L-14546-00 Valve, needle	Buy now
6	66K-14985-00 Float	Buy now
7	66K-14548-01 Pin, float arm	Buy now
8	66K-14984-00 Gasket, float chamber	Buy now
9	65L-14125-00 Screw	Buy now
10	68F-13906-00 Regulator, pressure	Buy now
11	66K-14325-01 Screw, pan head	Buy now
12	60V-14163-00 Spacer	Buy now
13	65L-13905-00 Filter comp	Buy now
14	68F-13971-00 Pipe, fuel 1	Buy now
15	65L-24387-00 Clip	Buy now


Vapor Separator 1



B7

Ref	Part	
16	65L-14966-00 Cap	Buy now
17	65L-24486-00 O-ring	Buy now
18	68F-24251-00 Strainer 1	Buy now
19	66K-14245-00 Screw, guide	Buy now
20	68F-82509-00 Wire, sub lead	Buy now
21	65L-14227-00 Washer	Buy now
22	60V-13907-00 Fuel pump comp.	Buy now
23	65L-14159-00 Clip	Buy now
24	68F-13781-00 Damper, pump	Buy now
25	68F-13844-00 Plate 2	Buy now
26	68F-13915-00 Filter	Buy now
27	65L-1416A-00 O-ring	Buy now
28	66K-14271-00 Insulator	Buy now
29	65L-8182A-00 Nut	Buy now
30	65L-8182K-00 Nut	Buy now


Vapor Separator 1



B7

Ref	Part	
31	65L-8182E-00 Washer	Buy now
32	65L-8182F-00 Washer	Buy now
33	68F-13843-00 Plate 1	Buy now
34	65L-14147-00 O-ring	Buy now
35	68F-14274-00 Connector	Buy now
36	66K-24376-00 Pipe, joint 1	Buy now
37	66K-24489-00 O-ring	Buy now
38	68F-14271-00 Insulator	Buy now
39	65L-14397-00 O-ring	Buy now
40	65L-14992-00 Screw, drain	Buy now
41	65L-14997-00 Seal	Buy now
42	60V-24375-01 Grommet	Buy now
43	60V-24397-01 Collar	Buy now
44	66K-24579-00 Washer 2	Buy now
45	65L-24592-00 Bolt	Buy now

Vapor Separator 1




60V1010-3070

B7

Ref	Part	
46	65L-24169-00 Washer, lock	Buy now
47	60V-82507-00 Wire, lead	Buy now
48	66K-13542-00 Hose, vacuum sensing 1	Buy now
49	66K-13544-00 Hose, Vacuum Sensing 2	Buy now
50	66K-13532-00 Hose, vacuum sensing 3	Buy now
51	65L-24461-00 Pipe, joint 4	Buy now
52	66K-13533-00 Hose, vacuum sensing 4	Buy now
53	65L-13898-00 Plate 4	Buy now
54	65L-14565-00 Screw	Buy now
55	60V-24339-01 Grommet	Buy now
56	60V-13534-00 Hose, Vacuum Sensing 5	Buy now
57	90465-11M10 Clamp	Buy now

Vapor Separator 2





60V1010-3080

C3

Ref	Part	
1	60V-13751-00 Body, throttle 1	Buy now
2	65L-14527-00 Plate	Buy now
3	65L-14565-00 Screw	Buy now
4	65L-14334-00 Spring, air adjusting	Buy now
5	65L-14523-00 Screw, stop	Buy now
6	6K5-14592-00 Screw	Buy now
7	90201-05552 Washer, plate(65j)	Buy now
8	65L-14578-00 Collar	Buy now
9	68F-13568-00 Stud	Buy now
10	61A-85885-00 Throttle sensor assembly	Buy now
11	6K7-85886-00 Bracket	Buy now
12	97985-05212 Screw, with washer(6g7)	Buy now
13	90387-05M00 Collar(6k7)	Buy now
14	60V-85516-00 Spacer	Buy now
15	60V-14596-00 Washer	Buy now

Vapor Separator 2



 60V1010-3080

C3

Ref	Part	
16	97985-05330 Screw, with washer(61b)	Buy now
17	65L-14573-00 Lever	Buy now
18	65L-14579-00 Spring	Buy now
19	65L-41217-00 Rod, accel. lever	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.