



Yamaha LZ250DETO 2004

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	8
BRACKET 2	12
CONTROL	15
CRANKSHAFT. PISTON	20
CYLINDER. CRANKCASE 1	23
CYLINDER. CRANKCASE 2	27
CYLINDER. CRANKCASE 3	29
ELECTRICAL 1	31
ELECTRICAL 2	34
ELECTRICAL 3	36
ELECTRICAL 4	40
FUEL 1	41
FUEL 2	45
FUEL INJECTION NOZZLE	46
FUEL INJECTION PUMP	49
FUEL PUMP DRIVE GEAR	52
GENERATOR	54
INTAKE	56
LOWER CASING. DRIVE 1	58
LOWER CASING. DRIVE 2	65
LOWER CASING. DRIVE 3	68
LOWER CASING. DRIVE 4	76
METER	79
OIL PUMP	81
OIL TANK	85
POWER TRIM & TILT ASSY 1	88
POWER TRIM & TILT ASSY 2	93
REMOTE CONTROL BOX	94
REPAIR KIT 1	95
REPAIR KIT 2	97
STARTING MOTOR	99
STEERING GUIDE	102
SWITCH. PANEL 1	104
SWITCH. PANEL 2	106
SWITCH. PANEL 3	108
TOP COWLING	110
UPPER CASING	113
VAPOR SEPARATOR 1	116
VAPOR SEPARATOR 2	120


Bottom Cowling



A5

Ref	Part	
1	60V42710008D Bottom cowling assembly	Buy now
2	6E52437700 Pipe, joint	Buy now
3	61A4272700 Grommet	Buy now
4	68F428280094 Plate, clamp	Buy now
5	68F428281094 Plate, clamp	Buy now
6	9010906M82 Bolt	Buy now
7	60V42815008D Lever Clamp	Buy now
8	60V42816008D Lever, clamp	Buy now
9	60V42817008D Lever, clamp	Buy now
10	68F4281800 Lever, clamp	Buy now
11	67F4281800 Lever, clamp	Buy now
12	9038615M73 Bush(6I2)	Buy now
13	9020615M18 Washer, wave(6I2)	Buy now
14	9020106068 Washer,plate (6k8)	Buy now
15	9709506016 Bolt, hexagon deep recess	Buy now


Bottom Cowling



A5

Ref	Part	
16	64D4314400 Hook, spring	Buy now
17	9010906M80 Bolt	Buy now
18	9050616M34 Spring, tension(64d)	Buy now
19	60V4261500 Seal	Buy now
20	6E54439100 Nipple, hose	Buy now
21	60V4272500 Grommet	Buy now
22	60V42738008D Plate, fitting	Buy now
23	9010906M81 Bolt	Buy now
24	64D42738105B Plate, fitting	Buy now
26	9048022M81 Grommet	Buy now
27	9038708M37 Collar (6e5)	Buy now
28	9020108M54 Washer, plate (6e5)	Buy now
29	9707508035 Bolt(70w)	Buy now
30	9011908M22 Bolt, with washer	Buy now
31	6884272610 Grommet	Buy now


Bottom Cowling



A5

Ref	Part	
32	6E58258800 Plate	Buy now
33	9589506020 Bolt, flange(jk3)	Buy now
34	60V42723005B Cover, bottom	Buy now
35	60V42721A0 Gasket 1	Buy now
36	60V4271800 Rubber, seal 3	Buy now
38	60V42741008D Apron	Buy now
39	60V4275600 Stay, clamp	Buy now
40	9788004016 Screw, with washer(61b)	Buy now
41	9299004600 Washer, plain (646)	Buy now
42	9011106034 Bolt,hex. socket button	Buy now
43	9709506020 Bolt(7u8)	Buy now
44	9299506600 Washer, plain (646)	Buy now
45	60V1258100 Joint, hose 1	Buy now
46	60V1257600 Hose 1	Buy now
47	60V1257800 Hose 3	Buy now


Bottom Cowling



A5

Ref	Part	
48	60V1258800 Hose 5	Buy now
49	6E52437800 Pipe, joint 3	Buy now
63	9046511M10 Clamp FLUSHING KIT	Buy now
51	60V4277100 Apron	Buy now
52	9707508055 -	Buy now
53	9299508600 Washer, plain (663)	Buy now
54	61A4271700 Rubber, seal 2	Buy now
55	61A4271600 Rubber seal 1	Buy now
56	60V4277400 Stay, Apron 1	Buy now
57	9589506016 Bolt, flange deep recess	Buy now
58	6H44272600 Grommet	Buy now
59	6R31257200 Adapter FLUSHING KIT	Buy now
60	9016905M00 Screw truss head tapping FLUSHING KIT	Buy now
61	6R31258000 Joint assembly FLUSHING KIT	Buy now
62	9044511M36 Hose (I700) FLUSHING KIT	Buy now


Bottom Cowling



A5


Ref	Part	
64	68F4275300 Fastner AP FOR USA	Buy now
65	9046420258 Clamp AP FOR USA	Buy now
66	68H4279101 Mark 1	Buy now
67	60V2415E40 Label, Caution EXCEPT FOR CAR	Buy now
67	60V2415E60 Label, Caution FOR CAR	Buy now
68	6A12817600 Label Caution FOR CAR	Buy now
69	6E38257H00 Plate Mark FOR CAR	Buy now

Bracket 1



Ref	Part	
1	69J43111018D Bracket, clamp 1	Buy now
2	6G54525102 Anode	Buy now
3	6G54452600 Plate	Buy now
4	9709506025 Bolt	Buy now
5	9299506600 Washer, plain (646)	Buy now
6	6H18214800 Wire, lead	Buy now
7	9709506010 Bolt	Buy now
9	6E58214800 Wire, lead 5	Buy now
10	9788506012 Screw, pan head(62j)	Buy now
12	61A4313200 Washer, friction	Buy now
13	9788506010 Screw pan head	Buy now
14	69J43112018D Bracket, clamp 2	Buy now
15	61A4313300 Washer,friction	Buy now
17	9370006M03 Nipple, grease(6a1)	Buy now
18	9046508M83 Clamp	Buy now


Bracket 1



B4

Ref	Part	
21	6R34313100 Bolt, clamp bracket	Buy now
22	9038625M31 Bushing (6e5)	Buy now
23	9020126M59 Washer, plate (6e5)	Buy now
24	9018522M11 Nut, self-locking	Buy now
25	9046511M10 Clamp	Buy now
27	9709506014 Bolt(gj3)	Buy now
29	9709510045 Bolt(64d)	Buy now
30	9299510100 Ybs67-10 washer, spring	Buy now
31	9299510600 Washer, plate	Buy now
32	61A43311218D Bracket, swivel 1 X	Buy now
32	61A43311318D Bracket, swivel U	Buy now
34	61A8214720 Wire, lead 5 X	Buy now
34	61A8214730 Wire, lead 5 U	Buy now
35	6G54314400 Hook, spring	Buy now
37	61A4318101 Lever, tilt stop 1	Buy now


Bracket 1



B4


Ref	Part	
38	6G54318502 Lever, tilt stop 2	Buy now
39	9038610M16 Bushing (688)	Buy now
40	6G54314800 Collar, distance	Buy now
41	9024906M19 Pin(6e5)	Buy now
42	9038710M02 Collar(6e5)	Buy now
43	9169030020 Pin, spring (6h4)	Buy now
44	9050616003 Spring, tension	Buy now
45	6E54312602 Pin, upper shock mount	Buy now
46	9038618M63 Bush(6e5)	Buy now
47	9038618M14 Bushing (6e5)	Buy now
48	9341018M02 Circlip (6f2)	Buy now
49	9010112M05 Bolt (l:130mm)	Buy now
49	9010112M77 Bolt (l:150mm) FOR USA	Buy now
50	9020113M01 Washer, plate(6e5)	Buy now
51	9020112M05 Washer, plate(663)	Buy now

Bracket 1



Ref	Part	
52	9538012600 Nut (707)	Buy now


Bracket 2



B7

Ref	Part	
1	60V42510208D Steering Bracket assembly X	Buy now
1	60V42510308D Steering Bracket assembly U	Buy now
2	9020140M00 Washer, plate(61a)	Buy now
3	9038639M89 Bush(61a)	Buy now
4	9321035321 O-ring (3m7)	Buy now
5	9020240M47 Washer, plate(61a)	Buy now
6	61A44551018D Housing, lower mount rubber	Buy now
7	9341037M04 Circlip (6e5)	Buy now
8	61A4457500 Damper, lower mount rubber	Buy now
9	60V445550094 Mount damper, lower side	Buy now
10	9020232M19 Washer, plate (6e5)	Buy now
11	9020116M55 Washer, plate (6e5)	Buy now
12	6E58214900 Wire, lead 3	Buy now
13	9010914M48 Bolt	Buy now
14	9020115M58 Washer, plate (6e5)	Buy now


Bracket 2



B7

Ref	Part	
15	9538014800 Nut, crown (6e5)	Buy now
16	9299514600 Washer (6e5)	Buy now
17	61A445520194 Housing, lower mount rubber	Buy now
18	9709510045 Bolt(64d)	Buy now
19	9299510600 Washer, plate	Buy now
20	61A44553008D Cover, lower mount	Buy now
21	6A01578900 Damper	Buy now
22	60V445140094 Mount damper, upper side	Buy now
23	9020116M01 Washer, plate(61a)	Buy now
24	9020228M46 Washer, plate(61a)	Buy now
25	9020128M01 Washer, plate(61a)	Buy now
26	9010914M10 Bolt	Buy now
27	9018514M00 Nut, self-locking(61a)	Buy now
29	61A445110094 Cover, upper mount	Buy now
32	69J8367200 Trim sender EXCEPT FOR USA	Buy now


Bracket 2



B7


Ref	Part	
32	69J8367210 Trim sender FOR USA	Buy now
33	9788506016 Screw, pan head(6b0)	Buy now
34	61A4337600 Bolt, thrust receiver	Buy now
35	9578010300 Nut, nylon (6e5)	Buy now

Control




Ref	Part	
1	60V4853110 -	Buy now
2	6634853800 Clamp, cable 1	Buy now
3	9169030010 Pin, spring (663)	Buy now
4	9010906M80 Bolt	Buy now
5	60V44117001S Bracket	Buy now
6	60V44119400 Cap	Buy now
7	9709506020 Bolt(7u8)	Buy now
8	60V44176001S Bracket	Buy now
9	9370006M01 Nipple, grease(61a)	Buy now
10	9038612069 Bush(666)	Buy now
11	9038708M09 Collar(61a)	Buy now
12	9709508035 Bolt(70w)	Buy now
13	9299508200 Ybs66-8 washer, plain	Buy now
14	9050820M31 Spring, torsion(61a)	Buy now
15	61A8259F00 Switch assembly	Buy now

Control




Ref	Part	
16	61A8258801 Plate	Buy now
17	9788504016 Screw, panhead (796)	Buy now
18	9299504100 Ybs67-4 washer, spring	Buy now
19	60V8259F00 Switch assembly	Buy now
23	61A4412100 Lever, shift rod	Buy now
24	68J4412201 Bushing, shift rod lever	Buy now
25	9020208M20 Washer, plate (6e5)	Buy now
26	9046818008 Clip 620436610000	Buy now
27	6E54834400 Cable end, remote control	Buy now
28	9020206007 Washer plate 626441880000	Buy now
29	61A44118008D Bracket	Buy now
30	9370006M03 Nipple, grease(6a1)	Buy now
31	61A4411600 Spring	Buy now
32	9709506030 Bolt(jf7)	Buy now
33	9299506100 Washer(6a1)	Buy now

Control



Ref	Part	
34	9299506600 Washer, plain (646)	Buy now
35	61A4412022 Handle gear shift assembly X	Buy now
35	61A4412032 Handle gear shift assembly U	Buy now
36	9321009165 O-ring	Buy now
37	61A4411200 Stay, handle gear shift	Buy now
38	9701306012 Bolt(gh1)	Buy now
39	9290306100 Washer(6a1)	Buy now
40	9290306600 Washer, plain (646)	Buy now
41	9531308600 Nut(6l2)	Buy now
42	9038690M90 Bush(61a)	Buy now
43	9149020012 Pin, cotter (648)	Buy now
44	9020109M02 Washer, plate(61a)	Buy now
45	61A1531500 Seal, crankcase	Buy now
46	61A4272400 Grommet	Buy now
47	61A4413800 Washer	Buy now


Control



B1

Ref	Part	
48	9788506008 Screw, pan head(6a3)	Buy now
49	65L4163201 Lever, magneto control	Buy now
52	9701308045 Bolt	Buy now
53	9299008200 Ybs66-8 washer, plain	Buy now
54	9020612M00 Washer, wave (676)	Buy now
55	9038708M16 Collar	Buy now
56	61A4123700 Joint, link	Buy now
57	9538005600 Nut, hexagon (663)	Buy now
58	6H44123700 Joint, link	Buy now
59	60V4123000 Cam accelerator comp	Buy now
60	9020106M31 Washer (6a0)	Buy now
61	9038706M29 Collar (6a0)	Buy now
62	9020610M04 Washer, wave (676)	Buy now
63	9011906MA4 Bolt, with washer	Buy now
64	69L4274400 Stay	Buy now


Control



B1

Ref	Part	
65	9015706006 Screw Pan Head	Buy now
66	9538006600 Nut(661)	Buy now
67	6884419400 Cap	Buy now
68	9015905M25 Screw,pan head (646)	Buy now


Crankshaft. Piston



B1


Ref	Part	
1	6D01141100 Crankshaft	Buy now
2	61A1144700 Seal, crank	Buy now
3	93311940V0 Bearing, cylindrical(61a)	Buy now
4	9310240M38 Oil seal(61a)	Buy now
5	60V1147900 O-ring	Buy now
6	93306209U1 Bearing(61a)	Buy now
7	93310959U0 Bearing, cylindrical(61a)	Buy now
8	61A1153600 Gear, drive	Buy now
9	93306308U0 Bearing(61a)	Buy now
10	9341040M03 Circlip(n02)	Buy now
11	61A1158601 Pulley, crankshaft balance	Buy now
12	60V1155500 Nut, crankshaft 1	Buy now
13	9310422M07 Oil seal(61a)	Buy now
14	60V153590094 Housing, oil seal	Buy now
15	9310240010 Oil seal	Buy now

Crankshaft. Piston



Ref	Part	
16	9342061M07 Circlip(61a)	Buy now
17	60V1535300 Gasket, drain	Buy now
18	9709506020 Bolt(7u8)	Buy now
19	9299506100 Washer(6a1)	Buy now
20	6D0116310085 Piston (std)	Buy now
20	6D01163500 Piston (0.25mm o/s) AP	Buy now
20	6D01163600 Piston (0.50mm o/s) AP	Buy now
21	6D01160300 Piston ring set (std)	Buy now
21	6D01160400 Piston ring set (0.25mm o/s) AP	Buy now
21	6D01160500 Piston ring set (0.50mm o/s) AP	Buy now
22	6D0116420085 Piston 2 (std)	Buy now
22	6D01164500 Piston 2 (0.25mm o/s) AP	Buy now
22	6D01164600 Piston 2 (0.50mm o/s) AP	Buy now
24	61A1163302 Pin, piston	Buy now
25	60X1163400 Clip, piston pin	Buy now


Crankshaft. Piston



B1

Ref	Part	
26	69L1165000 Connecting Rod assembly	Buy now
27	9010909001 Bolt	Buy now
28	9331032657 Bearing	Buy now
29	9020126M03 Washer, plate(61a)	Buy now
30	9331084106 Bearing	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
1	60YW0090111S Crank cylinder assembly	Buy now
2	60V15100011S Crankcase assembly	Buy now
3	6E51137201 Nipple, hose	Buy now
4	6241448500 Pipe, joint	Buy now
5	60V1137000 Check valve assembly	Buy now
6	9038406M07 Bush, bimetal formed(6r3)	Buy now
7	9038316M01 Bush, formed(61a)	Buy now
8	6501137001 Check valve assembly	Buy now
9	60V1137010 Check valve assembly	Buy now
10	9011608012 Bolt, stud	Buy now
11	6631151801 Lock, bearing	Buy now
12	9034014M00 Plug, straight screw(62y)	Buy now
13	9043014115 Gasket (663)	Buy now
14	9360812063 Pin, dowel (626)	Buy now
15	9044507M10 Hose (L770)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
16	9046807M02 Clip (6e5)	Buy now
17	9010510M75 Bolt, washer based(65j)	Buy now
18	9010510067 Bolt, flange	Buy now
19	9011906089 Bolt, with washer	Buy now
20	9044507M03 Hose (I200)	Buy now
21	9044507016 Hose (I60)	Buy now
22	9044507M29 Hose (I200)	Buy now
23	9044507MA6 Hose (I200)	Buy now
24	6E02437800 Pipe, joint	Buy now
25	6G51258100 Joint, hose	Buy now
26	60V1132501 Anode	Buy now
27	66M1132800 Grommet, anode	Buy now
28	66M113270094 Cover, anode	Buy now
29	66M1253500 Plate	Buy now
30	9709505012 Bolt, hexagon	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
31	9299505600 Washer, plain (646)	Buy now
32	9701306020 Bolt(62y)	Buy now
33	9290306600 Washer, plain (646)	Buy now
34	60V113710094 Cover	Buy now
35	60V2413500 Clamp 1	Buy now
36	9701305012 Bolt, hexagon	Buy now
37	9290305600 Washer, plain (646)	Buy now
38	60V1138100 Gasket 1	Buy now
39	9011906MA2 Bolt, with washer	Buy now
40	60V1241100 Thermostat	Buy now
41	60V12413001S Cover Thermostat	Buy now
42	60V12414A0 Gasket, cover	Buy now
43	9948006012 Pin	Buy now
44	9011906055 Bolt, with washer	Buy now
45	66M1132500 Anode	Buy now


Cylinder. Crankcase 1



A6


Ref	Part	
52	6E542761001S Stopper	Buy now
54	68F4453300 Damper, upper mount rubber	Buy now

Cylinder. Crankcase 2



Ref	Part	
1	60V11111001S Head Cylinder 1	Buy now
2	67F1132500 Anode	Buy now
3	67F113270094 Anode cover assembly	Buy now
4	69J113270094 Anode cover assembly	Buy now
5	60V113270094 Anode cover assembly	Buy now
6	9707506020 Bolt(7u8)	Buy now
7	9299506600 Washer, plain (646)	Buy now
8	67F1132800 Grommet, anode	Buy now
9	60V1253500 Plate	Buy now
10	9757508550 Bolt, with washer	Buy now
11	9707508035 Bolt(70w)	Buy now
12	9299508600 Washer, plain (663)	Buy now
13	68F1111900 Hanger, engine	Buy now
14	9011906MA2 Bolt, with washer	Buy now
15	60V11191001S -	Buy now

Cylinder. Crankcase 2




60V1010-3040

B3

Ref	Part	
16	60V1119300 Gasket, head cover 1	Buy now
17	9011906MA4 Bolt, with washer	Buy now
18	68F8391900 Clamp, harness	Buy now
19	9959010114 Pin, dowel	Buy now
20	9011908MA5 Bolt, with washer	Buy now
21	9011908MA8 Bolt, with washer	Buy now
22	60V1118100 Gasket, cylinder head 1	Buy now
23	60V11121001S Head, cylinder 2	Buy now
35	69J1111E00 Hanger, engine 2	Buy now
37	60V11192001S Cover, cylinder head 2	Buy now
45	9470200405 Plug, spark (bkr6eku)	Buy now


Cylinder. Crankcase 3



B5


Ref	Part	
1	60V411130094 Outer cover, exhaust	Buy now
2	6761137200 Nipple, hose	Buy now
3	60V4111200 Gasket, exhaust inner cover	Buy now
4	60V4126700 Bushing, joint	Buy now
5	9011906MA3 Bolt, with washer	Buy now
6	60V113270094 Anode cover assembly	Buy now
7	67F1132500 Anode	Buy now
8	9707506020 Bolt(7u8)	Buy now
9	9299506600 Washer, plain (646)	Buy now
10	67F1132800 Grommet, anode	Buy now
11	9707508030 Bolt, hexagon (fj1)	Buy now
12	9299508600 Washer, plain (663)	Buy now
13	9046708004 Clip, pipe 6162435600	Buy now
14	6G51241600 Valve, pressure control	Buy now
15	9050116M11 Spring, compression (688)	Buy now

Cylinder. Crankcase 3



Ref	Part	
16	9048020M05 Grommet (688)	Buy now
17	60V11382A0 Gasket 2	Buy now
18	6G511372001S Cover, bypass 2	Buy now
19	9011906MA2 Bolt, with washer	Buy now
20	61A1257600 Hose 1	Buy now
21	9046513M18 Clamp	Buy now


Electrical 1



E6

Ref	Part	
1	60V855420194 Bracket	Buy now
2	60V8556400 Grommet	Buy now
3	68F8612900 Collar	Buy now
4	68F8612910 Collar	Buy now
5	68F8511900 Bolt	Buy now
6	60V8591A01 Engine Control Unit assembly EXCEPT FOR BRA	Buy now
6	60V8591A21 - FOR BRA	Buy now
7	9011906MA3 Bolt, with washer	Buy now
8	60V8554800 Holder	Buy now
9	9701306014 Bolt(gj3)	Buy now
10	9290306600 Washer, plain (646)	Buy now
11	60V8591B00 Driver, injector assembly	Buy now
12	9011906MA2 Bolt, with washer	Buy now
13	6E58251900 Wire, Earth Lead	Buy now
14	9709506012 Bolt(gh1)	Buy now


Electrical 1



E6

Ref	Part	
15	9299506600 Washer, plain (646)	Buy now
18	60V8231000 Ignition coil assembly	Buy now
19	9048025161 Grommet(656)	Buy now
20	9044610M01 Tube (6e5)	Buy now
21	60V8231010 Ignition coil assembly	Buy now
22	9046418003 Clamp	Buy now
23	9048022M15 Grommet (6e5)	Buy now
24	9046511M10 Clamp	Buy now
25	9701305020 Bolt, hexagon	Buy now
26	9290305600 Washer, plain (646)	Buy now
27	68F8237001 Plug cap assembly	Buy now
28	60V8231400 Cover Ignition Coil	Buy now
29	60V2419800 Seat, Rubber	Buy now
30	60V2419810 Seat, Rubber	Buy now
31	60V8818D00 Seat 1	Buy now


Electrical 1



E6

Ref	Part	
32	60V8818D10 Seat 1	Buy now
33	60V2311600 Seat 2	Buy now
34	60V2311610 Seat 2	Buy now
35	60V2318U00 Plate, Seat	Buy now
36	60V2318U10 Plate, Seat	Buy now
37	68F8551601 Spacer	Buy now
40	6A08231700 Damper, ignition coil	Buy now
41	6244254200 Collar	Buy now
42	9011906M65 Bolt, with washer	Buy now
43	60V8252U00 Cover	Buy now
44	60V2311500 Seat 1	Buy now
45	9011106034 Bolt, hex. socket button	Buy now
46	68V8195000 Relay assembly	Buy now
47	9709506016 Bolt, hexagon deep recess	Buy now


Electrical 2



F1

Ref	Part	
1	9044707011 Hose, with spring	Buy now
2	9046511M10 Clamp	Buy now
3	61A8194900 Wire, lead	Buy now
4	9709506012 Bolt(gh1)	Buy now
5	9299506600 Washer, plain (646)	Buy now
6	60V8210500 Battery cable	Buy now
7	9533308600 Nut(612)	Buy now
8	9290308100 Ybs67-8 washer, spring	Buy now
9	6E58253110 Wire, lead	Buy now
10	60V8259020 Wire harness assembly FOR USA	Buy now
10	60V8259030 Wire Harness assembly EXCEPT FOR USA	Buy now
13	9046511M52 Clamp(6e7)	Buy now
14	60V8259M00 Wire Harness assembly 2	Buy now
15	9046505M87 Clamp	Buy now
17	9046411008 Clamp	Buy now


Electrical 2



F1


Ref	Part	
19	69J8256300 Trim & tilt switch assembly	Buy now
20	69J8258700 Gasket	Buy now
21	69J4272300 Cover, Bottom	Buy now
22	60V8361400 Bracket	Buy now
23	60V8361410 Bracket	Buy now
24	60V8363510 Bracket	Buy now
25	9046420213 Clamp(4kj)	Buy now
26	9709506014 Bolt(gj3)	Buy now
27	9010906M86 Bolt	Buy now
28	60V8361800 Plate	Buy now
29	68F8363400 Grommet	Buy now
30	67H8238000 Sensor, pressure	Buy now
31	9858006520 Screw pan head	Buy now
32	6E58258800 Plate	Buy now
33	9589506020 Bolt, flange(jk3)	Buy now

Electrical 3



Ref	Part	
1	60V8196001 Rectifier & regulator assembly	Buy now
2	60V81975A0 Plate, rectifier fitting	Buy now
3	60V81972001S Cover, rectifier	Buy now
4	9011906MA3 Bolt, with washer	Buy now
5	9011906MA4 Bolt, with washer	Buy now
6	9044509M25 Hose (I1500)	Buy now
7	9046708M18 Clip	Buy now
8	6L28259901 Cover, connector	Buy now
9	9044710004 Hose, With Spring	Buy now
10	60V8194800 Bracket	Buy now
11	68F8511900 Bolt	Buy now
12	9011906M65 Bolt, with washer	Buy now
13	68F8551601 Spacer	Buy now
14	68F8612900 Collar	Buy now
15	6A08231700 Damper, ignition coil	Buy now


Electrical 3



F3


Ref	Part	
16	6244254200 Collar	Buy now
17	60V8714900 Connector	Buy now
18	9709506012 Bolt(gh1)	Buy now
19	9299506600 Washer, plain (646)	Buy now
20	60V8195000 Relay assembly	Buy now
22	6828211901 Cover, lead wire	Buy now
23	9709506010 Bolt	Buy now
24	9299506100 Washer(6a1)	Buy now
26	68V8194A00 Relay	Buy now
27	68F8211700 Wire, lead	Buy now
32	68V8195300 Stay, relay	Buy now
33	9778060620 Screw, tapping(6k8)	Buy now
34	9046423199 Clamp(4hm)	Buy now
35	60V8217000 Fuse box assembly Go to P/N) PE0-OM-070040	Buy now
36	60V8215100 Fuse (100A) Go to P/N) PE0-OM-070040	Buy now

Electrical 3



Ref	Part	
37	68F8195A00 Relay assembly	Buy now
38	67F8215100 Fuse	Buy now
39	67F8215110 Fuse	Buy now
40	68F8284600 Screw, pan head (m5)	Buy now
41	9778050620 Screw, tapping	Buy now
42	60V8554400 Case	Buy now
43	67F2812A00 Puller, fuse	Buy now
44	60V8215700 Damper	Buy now
45	60V8133600 Grommet	Buy now
46	60V8133610 Grommet	Buy now
47	60V8112800 Clamp	Buy now
49	60V8194210 Cover	Buy now
50	9046408004 Clamp	Buy now
51	60V8217600 Damper	Buy now
53	9016905M00 Screw truss head tapping	Buy now


Electrical 3



F3


Ref	Part	
54	65L8588600 Thermosensor	Buy now
55	60V8555300 Nut Rotor	Buy now
56	9020112M34 Washer (692)	Buy now
57	60V8191900 Graphic, Regulator Go to P/N) PE0-OM-070040	Buy now
58	60V8191910 Graphic, regulator	Buy now
59	69J8194900 Wire, lead (isolator, 3.8m) AP	Buy now

Electrical 4




Ref	Part	
1	60V8258800 Plate	Buy now
2	9709506012 Bolt(gh1)	Buy now
3	9299506600 Washer, plain (646)	Buy now
4	61A8579000 Thermosensor assembly	Buy now
5	9299010600 Washer, plate	Buy now
6	61A8589500 Crank position sender	Buy now
7	9788505012 Screw,pan head (646)	Buy now
8	6888256010 Thermo switch assembly	Buy now
9	9044610M87 Hose	Buy now

Fuel 1




Ref	Part	
1	61A2431300 Pipe 3	Buy now
2	9046413M34 Clamp(6r3)	Buy now
3	9044513M17 Hose(l2700)	Buy now
4	6R32437700 Pipe, joint 3 EXCEPT FOR USA	Buy now
5	6E58259400 Clamp	Buy now
6	9046511M10 Clamp	Buy now
7	68F2456000 Filter assembly	Buy now
8	68F2456200 Cup, filter	Buy now
9	68F2451900 Clip	Buy now
10	68F2446900 Float, Water Level	Buy now
11	65L2453101 Nut	Buy now
12	61A2456400 O-ring	Buy now
13	68F2456300 Element, filter	Buy now
14	65L2456400 Gasket	Buy now
15	68F2456700 Spring	Buy now

Fuel 1




Ref	Part	
16	60H2455800 Holder, filter	Buy now
17	9759506416 Bolt, with washer(62x)	Buy now
18	9020106068 Washer,plate (6k8)	Buy now
19	68F2456600 Bracket, filter	Buy now
20	9759506514 Bolt(gj3)	Buy now
21	9038706M60 Collar (6h3)	Buy now
22	9048010M23 Grommet(6k7)	Buy now
23	9011906M88 Bolt, with washer	Buy now
24	68F2431100 Pipe, Fuel 1	Buy now
26	6E52437800 Pipe, joint 3	Buy now
27	6G52431500 Pipe 5	Buy now
28	9044719004 Hose, with spring	Buy now
29	6E52431500 Pipe 5	Buy now
30	6E52441003 Fuel pump assembly	Buy now
31	6E52444400 Screw	Buy now

Fuel 1




Ref	Part	
32	6E52441300 Body 2	Buy now
33	6E52447100 Diaphragm	Buy now
34	6E52443500 Gasket, body 2	Buy now
35	6E52441100 Diaphragm	Buy now
36	6482442400 Seat, spring	Buy now
37	6E52442300 Spring, diaphragm	Buy now
38	6E52443402 Gasket, body	Buy now
39	6A02442101 Valve, check	Buy now
40	6A01432500 Screw, pan head	Buy now
41	9538003600 Nut (6g8)	Buy now
42	6E52441210 Body 1	Buy now
43	65024431A0 Gasket, fuel pump	Buy now
44	9759506550 Bolt, hexagon w/w deep recess	Buy now
45	6G52431610 Pipe 6	Buy now
46	6E52431300 Pipe 3	Buy now

Fuel 1



Ref	Part	
49	65L8355700 Tube	Buy now
50	9044615M07 Hose(6g4)	Buy now
51	9044513M12 Hose (L235)	Buy now
52	6R32437710 Pipe, joint 3 FOR USA	Buy now
53	61H2819R31 Tag Warning FOR USA	Buy now
54	68F2810000 Tool kit AP	Buy now

Fuel 2





61A0200-0110

E3

Ref	Part	
1	6Y22430750 Fuel pipe comp. 2 AP EXCEPT FOR USA	Buy now
2	9044513M01 Hose (I2050)	Buy now
3	6E52435151 Band 1	Buy now
4	9048006M19 Grommet (6e3)	Buy now
5	6Y22436060 Primer pump assembly	Buy now
6	9045010M07 Hose, clamp AP EXCEPT FOR USA	Buy now


Fuel Injection Nozzle



C6


Ref	Part	
1	68F1376700 Cap, injector	Buy now
2	9011908M60 Bolt (682)	Buy now
3	60V1378200 Stay	Buy now
4	9038708M31 Collar	Buy now
5	9011008M04 Bolt, hexagon socket head	Buy now
6	60V1316100 Pipe Delivery 1	Buy now
7	60V1317100 Pipe Delivery 2	Buy now
8	60V1389800 Holder	Buy now
9	68F2455100 Bolt, joint	Buy now
10	68F2457600 Washer	Buy now
11	60V1376100 Injector assembly	Buy now
12	68F1410B00 Packing kit	Buy now
13	60V1426400 Collar	Buy now
14	65L1456500 Screw	Buy now
15	60V8238900 Plate 2	Buy now

Fuel Injection Nozzle



Ref	Part	
16	60V8239800 Plate 3	Buy now
17	60V8154500 Screw 1	Buy now
18	60V8154600 Screw 2	Buy now
19	60V8238000 Sensor Pressure	Buy now
20	68F8238800 Plate	Buy now
21	68F8238400 Packing kit	Buy now
22	60V1393800 Pipe	Buy now
23	60V1397300 Pipe, fuel 3	Buy now
24	68F2466A00 Packing kit	Buy now
25	60V1397400 Pipe, fuel 4	Buy now
27	65L1459600 Washer	Buy now
28	9048010M23 Grommet(6k7)	Buy now
29	9038705M00 Collar(6k7)	Buy now
30	60V1397500 Pipe Fuel 5	Buy now
32	60V1397600 Pipe, fuel 6	Buy now


Fuel Injection Nozzle



C6


Ref	Part	
34	68F1376400 Gasket (t=2.2)	Buy now
35	9751308570 Bolt, with washer	Buy now
36	9701308090 Bolt, with washer	Buy now
37	9290308600 Washer, plain (663)	Buy now
38	60V1371600 Collar	Buy now
39	9701308055 Bolt, hexagon	Buy now
42	9044722004 Hose, with spring	Buy now
43	9044715001 Hose, with spring	Buy now

Fuel Injection Pump




Ref	Part	
1	60V1217000 Camshaft assembly 1	Buy now
2	60V1242400 Plate, Cartridge Inner	Buy now
3	9330600001 Brg,r-b 6000 26mm 19g ky	Buy now
4	68F1217300 Cap, camshaft 1	Buy now
5	93306001U0 Bearing	Buy now
6	68F1222300 Seal	Buy now
7	68F1243900 O-ring	Buy now
8	60V1217100 Camshaft 1	Buy now
9	68F1222800 Bolt	Buy now
10	68F1345500 Plug	Buy now
11	68F1347300 O-ring	Buy now
13	60V1399300 Cover, control rack	Buy now
14	60W1399300 Cover Control Rack	Buy now
15	65L1456500 Screw	Buy now
16	68F2457900 Washer 2	Buy now

Fuel Injection Pump




Ref	Part	
17	60V1385400 Plate 4	Buy now
18	60V1391000 Fuel Pump assembly	Buy now
19	60V1400500 Ring, seal	Buy now
20	60V1412600 Gasket	Buy now
21	68F2430000 Fuel pipe joint	Buy now
22	60V2417800 Bolt 3	Buy now
23	60V2417600 Bolt 1	Buy now
24	60V2437800 Pipe Joint 4	Buy now
25	60V2486400 Tube	Buy now
26	60V2510T00 Tube	Buy now
27	68F1381500 Joint 1	Buy now
28	68F2466A00 Packing kit	Buy now
29	60V1381600 Joint 2	Buy now
30	68F2448600 O-ring	Buy now
32	60V1350500 Joint Comp.	Buy now

Fuel Injection Pump



Ref	Part	
34	60V1347300 Seal	Buy now
35	60V1414800 Pipe	Buy now
36	65L2438700 Clip	Buy now
37	60V2431200 Pipe 2	Buy now
38	68F2435600 Clip, pipe 1	Buy now
39	60V2431300 Pipe 3	Buy now
41	60V1414900 Pipe	Buy now
43	60V2431400 Pipe 4	Buy now
45	60V2431500 Pipe 5	Buy now
47	60V1397200 Pipe, fuel 2	Buy now


Fuel Pump Drive Gear



B6

Ref	Part	
1	60V115980094 Bracket, tensioner	Buy now
2	9701308055 Bolt, hexagon	Buy now
3	9290308600 Washer, plain (663)	Buy now
4	60V1159000 Tensioner assembly	Buy now
5	9011910M72 Bolt, with washer(6m6)	Buy now
6	60V1211300 Spring Valve Inner	Buy now
7	9044515002 Hose (I30)	Buy now
8	60V1159500 Plate, valve	Buy now
9	9701308012 Bolt(62e)	Buy now
10	60V4624100 Belt	Buy now
11	68F115790194 Coupling, flywheel	Buy now
13	68F115360094 Gear, drive	Buy now
14	9360510108 Pin, dowel (8g8)	Buy now
15	60V1155700 Washer 1	Buy now
16	9020108M00 Washer, plate(6e0)	Buy now

Fuel Pump Drive Gear





60V2100-C060

B6

Ref	Part	
17	9709508025 Bolt (62g)	Buy now
18	68F115370094 Gear, driven	Buy now
19	9028003M01 Key woodruff 146115450000	Buy now
20	9570708600 Nut, flange(jn5)	Buy now


Generator



E4


Ref	Part	
1	60V8145000 Rotor assembly	Buy now
2	60V8141001 Stator assembly	Buy now
3	60V8558000 Coil, pulser	Buy now
4	61A8372100 Cover	Buy now
5	9701306035 Bolt(3rv)	Buy now
6	9290306100 Washer(6a1)	Buy now
7	9290306600 Washer, plain (646)	Buy now
8	9788505030 Ybs86-530 screw,panhead	Buy now
9	9299505100 Ybs67-5 washer, spring	Buy now
10	9299505600 Washer, plain (646)	Buy now
11	9028005015 Key, woodruff	Buy now
12	9017024M22 Nut(61a)	Buy now
13	9020125M02 Washer, plate(61a)	Buy now
14	60V8133200 Plate Timing	Buy now
15	9788506010 Screw pan head	Buy now

Generator



Ref	Part	
16	9299506600 Washer, plain (646)	Buy now
17	9046506M86 Clamp	Buy now
18	60V8133700 Cover, flywheel	Buy now
19	6638231701 Damper, ignition coil	Buy now
20	6244254200 Collar	Buy now
21	6A08231700 Damper, ignition coil	Buy now
22	9589506030 Bolt, flange deep recess	Buy now
23	60V1448800 Label, caution	Buy now
24	6A18362551 Mark 5 FOR CAR	Buy now
25	6A18362541 Mark 5	Buy now
26	6E58571140 Mark, Caution EXCEPT FOR CAR	Buy now
26	6E58571160 Mark Caution FOR CAR	Buy now
27	6K18362341 Mark 3	Buy now
28	6K18362350 Mark 3 FOR CAR	Buy now


Intake



D1

Ref	Part	
1	60V1361000 Reed valve assembly	Buy now
2	60VW000400 Reed set	Buy now
3	60V13621A0 Gasket, Valve Seat	Buy now
4	9788005016 Screw, pan head(6b0)	Buy now
5	9299005600 Washer, plain (646)	Buy now
6	60V13624001S Plate Reed Valve	Buy now
7	60V1355200 Nozzle	Buy now
8	60V1357200 Nozzle	Buy now
9	60V1137900 Valve, check	Buy now
10	6F61137001 Check valve assembly	Buy now
11	9044507M03 Hose (I200)	Buy now
12	9044507016 Hose (I60)	Buy now
13	9044507015 Hose (I65)	Buy now
14	60V1136900 Valve Check	Buy now
15	6501137001 Check valve assembly	Buy now


Intake



D1


Ref	Part	
16	9010506028 Bolt, washer based	Buy now
17	60V1364600 Gasket, manifold 2	Buy now
18	60V1364500 Gasket, manifold 1	Buy now
19	9701306060 Bolt, hexagon	Buy now
20	9290306600 Washer, plain (646)	Buy now
21	9567006660 Bolt, stud	Buy now
22	9017906M24 Nut(6j8)	Buy now
23	60V1444000 Silencer assembly, intake	Buy now
24	60V1447600 Seal	Buy now
25	9044507M44 Hose (I390)	Buy now
26	9015906M16 Screw, with washer(61a)	Buy now
27	68F1111900 Hanger, engine	Buy now
28	9011906MA2 Bolt, with washer	Buy now

Lower Casing. Drive 1




Ref	Part	
1	60V45300208D Lower unit assembly X	Buy now
1	60V45300308D Lower Unit assembly U	Buy now
2	60V45301008D Casing Lower	Buy now
3	9331183280 Ball bearing	Buy now
4	93332000W1 Bearing(61a)	Buy now
5	61A455670010 Shim (t:0.10mm) UR	Buy now
5	61A455670012 Shim (t:0.12mm) UR	Buy now
5	61A455670015 Shim (t:0.15mm) UR	Buy now
5	61A455670018 Shim (t:0.18mm) UR	Buy now
5	61A455670030 Shim (t:0.30mm) UR	Buy now
5	61A455670040 Shim (t:0.40mm) UR	Buy now
5	61A455670050 Shim (t:0.50mm) UR	Buy now
6	6634436600 Damper, water seal 2	Buy now
7	9034008002 Plug, straight screw	Buy now
8	6884534110 Plug, drain	Buy now

Lower Casing. Drive 1




Ref	Part	
9	9043008020 Gasket	Buy now
10	61A453760094 Guide, seal damper	Buy now
11	61A4532101 Plate	Buy now
12	9321064488 93210-64488	Buy now
13	9310609014 Oil seal	Buy now
14	9011906M10 Bolt, with washer	Buy now
15	60V4415000 Shift cam assembly	Buy now
16	9900108600 Circlip(2r6)	Buy now
17	9050111M10 Spring, compression (663)	Buy now
18	61A4431101 Housing, water pump	Buy now
19	61A4432202 Insert, cartridge	Buy now
20	9321086M38 O-ring (6e5)	Buy now
21	9321037160 O-ring (6g8)	Buy now
22	6E54436500 Damper, water seal 1	Buy now
23	6E54431200 Cover, water pump housing	Buy now

Lower Casing. Drive 1




Ref	Part	
24	6E54435201 Impeller	Buy now
25	9028004M05 Key, woodruff (6e5)	Buy now
26	61A4553800 Spacer, 1	Buy now
27	61A4552700 Collar, drive shaft	Buy now
28	9020122M01 Washer, plate(61a)	Buy now
29	9020622M19 Washer, wave(61a)	Buy now
30	6G54432300 Outer plate, cartridge	Buy now
31	6E544315A0 Gasket,water pump	Buy now
32	9360612019 Pin, dowel (614)	Buy now
33	9011908M14 Bolt, with washer	Buy now
34	61A453310094 Housing, bearing	Buy now
35	9310128M16 Oil seal (6e5)	Buy now
36	93317330U2 Bearing, cylindrical(6k0)	Buy now
37	61A455870010 Shim (t:0.10mm) UR	Buy now
37	61A455870012 Shim (t:0.12mm) UR	Buy now

Lower Casing. Drive 1




Ref	Part	
37	61A455870015 Shim (t:0.15mm) UR	Buy now
37	61A455870018 Shim (t:0.18mm) UR	Buy now
37	61A455870030 Shim (t:0.30mm) UR	Buy now
37	61A455870040 Shim (t:0.40mm) UR	Buy now
37	61A455870050 Shim (t:0.50mm) UR	Buy now
38	93341930U9 Bearing	Buy now
39	9321055M14 O-ring (70e)	Buy now
40	6E54534400 Cover, oil seal	Buy now
41	9709508025 Bolt (62g)	Buy now
42	9299508600 Washer, plain (663)	Buy now
43	60V4550120 - X	Buy now
43	60V4550130 Drive shaft comp. U	Buy now
44	60V4555100 Pinion	Buy now
45	9020116M00 Washer, plate(6t5)	Buy now
46	9017016M19 Nut(6t5)	Buy now

Lower Casing. Drive 1




Ref	Part	
47	60V4556000 Gear	Buy now
48	60V4561100 Shaft, propeller	Buy now
49	61A4564102 Shifter	Buy now
50	61A4563401 Slide, shift	Buy now
51	61A4563200 Pin, cross	Buy now
52	60V4563100 Clutch, dog	Buy now
53	61A4563300 Ring, cross pin	Buy now
54	6H14566800 Shaft, free 1	Buy now
55	61A4563500 Plunger, shift	Buy now
56	9020102M00 Washer, plate(61a)	Buy now
57	9018302M03 Nut, spring (6h1)	Buy now
58	9050110M77 Spring, compression(61a)	Buy now
59	9350104011 Ball	Buy now
60	60V453320094 Housing, bearing	Buy now
61	9959010114 Pin, dowel	Buy now

Lower Casing. Drive 1



Ref	Part	
62	93306210U0 Bearing(61a)	Buy now
63	61A4557100 Gear	Buy now
64	9020131M00 Washer, plate(61a)	Buy now
65	61A455770010 Shim (t:0.10mm) UR	Buy now
65	61A455770012 Shim (t:0.12mm) UR	Buy now
65	61A455770015 Shim (t:0.15mm) UR	Buy now
65	61A455770018 Shim (t:0.18mm) UR	Buy now
65	61A455770030 Shim (t:0.30mm) UR	Buy now
65	61A455770040 Shim (t:0.40mm) UR	Buy now
65	61A455770050 Shim (t:0.50mm) UR	Buy now
66	9331543061 Bearing	Buy now
67	9310130M17 Oil seal (6e5)	Buy now
68	9321104384 O-ring (705)	Buy now
69	9010508049 Bolt, flange	Buy now
70	9020108023 Washer, plate	Buy now


Lower Casing. Drive 1



Ref	Part	
71	9370009M00 Nipple, grease(6t4)	Buy now
72	69J45361008D Cap, lower casing	Buy now
73	9709508020 Bolt, hexagon	Buy now

Lower Casing. Drive 2

STD




60V1100-3300

D5


Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	61A4436120 Tube, water X	Buy now
2	61A4436130 Tube, water U	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	9360812M05 Pin, dowel b (6e5)	Buy now
5	9709510045 Bolt(64d)	Buy now
6	9299510100 Ybs67-10 washer, spring	Buy now
7	9299510600 Washer, plate	Buy now
8	9011910MA2 Bolt, with washer	Buy now
9	61A4537500 Damper, seal	Buy now
10	61A4521410 Cover, water inlet 1	Buy now
11	61A4521510 Cover, water inlet 2	Buy now
12	9015205003 Screw, countersunk	Buy now
13	9018505002 Nut nylon (sus)(ex4)	Buy now
14	69L4537100 Tab-trim	Buy now

Lower Casing. Drive 2




Ref	Part	
15	9010510M00 Bolt, hexagon (663)	Buy now
16	69J4598700 Spacer 1	Buy now
17	6884599701 Spacer 2	Buy now
18	9299018200 Washer (6e5)	Buy now
19	9017118M04 Nut, castle (6e5)	Buy now
20	9149040030 Pin, cotter (663)	Buy now
21	61A459720098 Propeller (3x14-1/2"x21"-t) UR	Buy now
21	61A459740098 Propeller (3x14-1/2"x19"-t) UR	Buy now
21	6G5459700298 Propeller (3x15-1/4 x15 -m) UR	Buy now
21	6G5459720298 Propeller (3x13-3/4 x21 -m) UR	Buy now
21	6G5459740398 Propeller (3x13-3/4"x19"-m2) UR	Buy now
21	6G5459780398 Propeller (3x13-3/4"x17"-m2) UR	Buy now
21	61A459780098 Propeller (3x15"x17"-t) UR	Buy now
21	6R445970A0 Propeller (3X15-1/4"X19"-M) UR	Buy now
21	6R445972A0 Propeller (3X14-7/8"X21"-M) UR	Buy now

Lower Casing. Drive 2




Ref	Part	
21	6R445974A0 Propeller (3X14-1/2"X23"-M) UR	Buy now
21	6R445976A0 Propeller (3X14-1/2"X15"-M) UR	Buy now
21	6R445978A0 Propeller (3X15-1/4"X17"-M) UR	Buy now

Lower Casing. Drive 3




Ref	Part	
1	60W45300208D Lower Unit assembly X	Buy now
1	60W45300308D Lower Unit assembly U	Buy now
2	60V45301008D Casing Lower	Buy now
3	9331183280 Ball bearing	Buy now
4	61B4553801 Spacer 1	Buy now
5	93315660W3 Bearing, cylindrical(61b)	Buy now
6	93341670V0 Bearing, thrust (61b)	Buy now
7	61A455670010 Shim (t:0.10mm) UR	Buy now
7	61A455670012 Shim (t:0.12mm) UR	Buy now
7	61A455670015 Shim (t:0.15mm) UR	Buy now
7	61A455670018 Shim (t:0.18mm) UR	Buy now
7	61A455670030 Shim (t:0.30mm) UR	Buy now
7	61A455670040 Shim (t:0.40mm) UR	Buy now
7	61A455670050 Shim (t:0.50mm) UR	Buy now
8	6634436600 Damper, water seal 2	Buy now

Lower Casing. Drive 3




Ref	Part	
9	9034008002 Plug, straight screw	Buy now
10	6884534110 Plug, drain	Buy now
11	9043008020 Gasket	Buy now
12	61A453760094 Guide, seal damper	Buy now
13	61A4532101 Plate	Buy now
14	9321064488 93210-64488	Buy now
15	9310609014 Oil seal	Buy now
16	9011906M10 Bolt, with washer	Buy now
17	60W4415000 Shift cam assembly	Buy now
18	9900108600 Circlip(2r6)	Buy now
19	9050111M10 Spring, compression (663)	Buy now
20	61A4431101 Housing, water pump	Buy now
21	61A4432202 Insert, cartridge	Buy now
22	9321086M38 O-ring (6e5)	Buy now
23	9321037160 O-ring (6g8)	Buy now

Lower Casing. Drive 3




Ref	Part	
24	6E54436500 Damper, water seal 1	Buy now
25	6E54431200 Cover, water pump housing	Buy now
26	6E54435201 Impeller	Buy now
27	9028004M05 Key, woodruff (6e5)	Buy now
28	61A4553800 Spacer, 1	Buy now
29	61A4552700 Collar, drive shaft	Buy now
30	9020122M01 Washer, plate(61a)	Buy now
31	9020622M19 Washer, wave(61a)	Buy now
32	6G54432300 Outer plate, cartridge	Buy now
33	6E544315A0 Gasket,water pump	Buy now
34	9360612019 Pin, dowel (614)	Buy now
35	9011908M14 Bolt, with washer	Buy now
36	61A453310094 Housing, bearing	Buy now
37	9310128M16 Oil seal (6e5)	Buy now
38	93317330U2 Bearing, cylindrical(6k0)	Buy now

Lower Casing. Drive 3




Ref	Part	
39	61A455870010 Shim (t:0.10mm) UR	Buy now
39	61A455870012 Shim (t:0.12mm) UR	Buy now
39	61A455870015 Shim (t:0.15mm) UR	Buy now
39	61A455870018 Shim (t:0.18mm) UR	Buy now
39	61A455870030 Shim (t:0.30mm) UR	Buy now
39	61A455870040 Shim (t:0.40mm) UR	Buy now
39	61A455870050 Shim (t:0.50mm) UR	Buy now
40	93341930U9 Bearing	Buy now
41	9321055M14 O-ring (70e)	Buy now
42	6E54534400 Cover, oil seal	Buy now
43	9709508025 Bolt (62g)	Buy now
44	9299508600 Washer, plain (663)	Buy now
45	60V4550120 -	Buy now
45	60V4550130 Drive shaft comp. U	Buy now
46	60V4555100 Pinion	Buy now

Lower Casing. Drive 3




Ref	Part	
47	9020116M00 Washer, plate(6t5)	Buy now
48	9017016M19 Nut(6t5)	Buy now
49	60W4556001 Gear	Buy now
50	9331762891 Bearing	Buy now
51	9345037097 Circlip	Buy now
52	69K4561100 Shaft, propeller	Buy now
53	61B4564101 Shifter	Buy now
54	61A4563401 Slide, shift	Buy now
55	61A4563200 Pin, cross	Buy now
56	60V4563100 Clutch, dog	Buy now
57	61A4563300 Ring, cross pin	Buy now
58	6H14566800 Shaft, free 1	Buy now
59	61A4563500 Plunger, shift	Buy now
60	9020102M00 Washer, plate(61a)	Buy now
61	9018302M03 Nut, spring (6h1)	Buy now

Lower Casing. Drive 3




Ref	Part	
62	9050110M77 Spring, compression(61a)	Buy now
63	9350104011 Ball	Buy now
64	60W453320094 Housing, bearing	Buy now
65	9959010114 Pin, dowel	Buy now
66	9333200048 Bearing(6k0)	Buy now
67	60W4557100 Gear	Buy now
68	93341440U5 Bearing, thrust (6k0)	Buy now
69	6K1455780110 Shim (t:0.10mm) UR	Buy now
69	6K1455780112 Shim (t:0.12mm) UR	Buy now
69	6K1455780115 Shim (t:0.15mm) UR	Buy now
69	6K1455780118 Shim (t:0.18mm) UR	Buy now
69	6K1455780130 Shim (t:0.30mm) UR	Buy now
69	6K1455780140 Shim (t:0.40mm) UR	Buy now
69	6K1455780150 Shim (t:0.50mm) UR	Buy now
70	61B4538300 Washer, claw	Buy now

Lower Casing. Drive 3



Ref	Part	
71	69K4538400 Nut	Buy now
72	69K4557700 Shim (t:0.10mm) UR	Buy now
72	69K4557710 Shim (t:0.12mm) UR	Buy now
72	69K4557720 Shim (t:0.15mm) UR	Buy now
72	69K4557730 Shim (t:0.18mm) UR	Buy now
72	69K4557740 Shim (t:0.30mm) UR	Buy now
72	69K4557750 Shim (t:0.40mm) UR	Buy now
72	69K4557760 Shim (t:0.50mm) UR	Buy now
73	9331543061 Bearing	Buy now
74	9310130M17 Oil seal (6e5)	Buy now
75	9321104384 O-ring (705)	Buy now
76	9010508049 Bolt, flange	Buy now
77	9020108023 Washer, plate	Buy now
78	9370009M00 Nipple, grease(6t4)	Buy now
79	69J45361008D Cap, lower casing	Buy now


Lower Casing. Drive 3



D7

Ref	Part	
80	9709508020 Bolt, hexagon	Buy now

Lower Casing. Drive 4




60W1100-3320

E4


Ref	Part	
1	6E54436600 Damper, water seal 2	Buy now
2	61A4436120 Tube, water X	Buy now
2	61A4436130 Tube, water U	Buy now
3	6E54436500 Damper, water seal 1	Buy now
4	9360812M05 Pin, dowel b (6e5)	Buy now
5	9709510045 Bolt(64d)	Buy now
6	9299510100 Ybs67-10 washer, spring	Buy now
7	9299510600 Washer, plate	Buy now
8	9011910MA2 Bolt, with washer	Buy now
9	61A4537500 Damper, seal	Buy now
10	61A4521410 Cover, water inlet 1	Buy now
11	61A4521510 Cover, water inlet 2	Buy now
12	9015205003 Screw, countersunk	Buy now
13	9018505002 Nut nylon (sus)(ex4)	Buy now
14	69L4537100 Tab-trim	Buy now

Lower Casing. Drive 4



Ref	Part	
15	9010510M00 Bolt, hexagon (663)	Buy now
16	69J4598700 Spacer 1	Buy now
17	6884599701 Spacer 2	Buy now
18	9299018200 Washer (6e5)	Buy now
19	9017118M04 Nut, castle (6e5)	Buy now
20	9149040030 Pin, cotter (663)	Buy now
21	61B459720098 Propeller (ss 3x14-1/2"x21"-tl) UR	Buy now
21	61B459740098 Propeller (3x14-1/2"x19"-tl) UR	Buy now
21	6K1459700198 Propeller (3x15-1/4"x15"-ml) UR	Buy now
21	6K1459720198 Propeller (3x13-3/4"x21"-ml) UR	Buy now
21	6K1459740298 Propeller (3x13-3/4"x19"-ml1) UR	Buy now
21	6K1459780298 Propeller (3x13-3/4"x17"-ml1) UR	Buy now
21	61B459780098 Propeller (3x5"x17"-tl) UR	Buy now
21	6R145970A0 Propeller, Ss (3 X 15-1/4" X 19"-MI) UR	Buy now
21	6R145972A0 Propeller (3X14-7/8"X21"-MI) UR	Buy now


Lower Casing. Drive 4



E4


Ref	Part	
21	6R145974A0 Propeller (3X14-1/2"X23"-MI) UR	Buy now
21	6R145976A0 Propeller (3X15-1/4"X15"-MI) UR	Buy now
21	6R145978A0 Propeller (3X15-1/4"x17"-MI) UR	Buy now

Meter



Ref	Part	
1	6Y58350T03 Digital tachometer assembly AP	Buy now
2	9E45004433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E45004533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	9299004100 Ybs67-4 washer, spring	Buy now
5	9538004600 Nut,hex	Buy now
6	6Y583500S5 Meter assembly AP	Buy now
7	6Y583570S5 Speedometer assembly	Buy now
10	6Y583533T2 Grommet	Buy now
11	6Y58355731 Tube	Buy now
12	6Y58372800 Connector assembly	Buy now
20	9046511M10 Clamp AP	Buy now
14	6Y587122S0 Cord assembly 1 AP	Buy now
15	6Y58355300 Wire, lead (l=2.5m) AP	Buy now
15	6Y583553M0 Wire, lead (l=2.5m) AP	Buy now
16	1E68215100 Fuse (10a) FOR 6Y5-83553-M0	Buy now


Meter



F1

Ref	Part	
17	6Y58211700 Wire, lead AP	Buy now
18	68F8255380 Extension, wire lead (8m) AP	Buy now
18	68F8255390 Extension, wire lead (9m) AP	Buy now
19	6Y58355700 Tube (8m) AP FOR CAR, VEN	Buy now
19	6Y58355710 Tube (8m) AP FOR BRA	Buy now
21	6Y58350F00 Fuel meter movement assembly AP FOR BRA	Buy now
23	6Y583553F1 Wire, lead AP FOR BRA	Buy now
24	6Y58575201 Sender unit assembly, fuel meter AP FOR BRA	Buy now
25	9015806002 Screw, Wood AP FOR BRA	Buy now
27	7038253100 Wire, lead AP FOR BRA	Buy now

Oil Pump




60V1010-3120

D3

Ref	Part	
1	60V1320000 Oil injection pump assembly	Buy now
2	6R31347100 Screw	Buy now
3	6L21347500 Gasket, breather bolt	Buy now
4	9321019M82 O-ring(6j8)	Buy now
5	9010906M40 Bolt(6h0)	Buy now
6	6G51341600 Pipe, oil 1	Buy now
7	9044617MA8 Hose (L200)	Buy now
8	9046511M10 Clamp	Buy now
9	9044607M35 Hose(62t)	Buy now
10	9044507M96 Hose(62t)	Buy now
11	9044607M48 Hose(62t)	Buy now
12	9044507M44 Hose (l390)	Buy now
13	9044507M46 Hose (l390)	Buy now
14	9044507M10 Hose (L770)	Buy now
15	9044507M04 Hose(62t)	Buy now

Oil Pump




60V1010-3120

D3

Ref	Part	
16	6R31318300 Valve, check	Buy now
17	9046807M02 Clip (6e5)	Buy now
18	9046407M05 Clamp (6g5)	Buy now
20	9046407M20 Clamp(6h0)	Buy now
21	61A1153700 Gear, driven	Buy now
22	9020109M01 Washer, plate(61b)	Buy now
23	61A1311700 Collar, distance	Buy now
24	9321018MA9 O-ring(61a)	Buy now
25	6R54123700 Joint, link	Buy now
26	65L4124110 -	Buy now
27	9538005600 Nut, hexagon (663)	Buy now
28	6H14123700 Joint, link	Buy now
29	9149012012 Pin, cotter (6g8)	Buy now
30	9020205088 Washer, plate (666)	Buy now
31	60V2431900 Pipe, oil	Buy now

Oil Pump




60V1010-3120

D3

Ref	Part	
33	9046708M18 Clip	Buy now
34	68F1310000 Solenoid pump assembly	Buy now
35	68F1341800 Hose 4	Buy now
36	68F1318400 Spring, oil pipe	Buy now
37	68F1344000 Filter assembly	Buy now
38	68F1316F00 Hose 1	Buy now
39	68F1313300 Clip	Buy now
40	68F1316G00 Hose 2	Buy now
41	68F1316A00 Check Valve assembly	Buy now
42	68F1341600 Hose 3	Buy now
43	68F1448500 Pipe, joint	Buy now
44	60V1319K00 Plate	Buy now
45	9709506020 Bolt(7u8)	Buy now
46	9299506100 Washer(6a1)	Buy now
47	9299506600 Washer, plain (646)	Buy now


Oil Pump



D3


Ref	Part	
48	9011006M06 Bolt, hexagon socket head	Buy now

Oil Tank



Ref	Part	
1	61A2175000 Oil tank assembly	Buy now
2	6E51344800 Cap, oil tank	Buy now
41	9046513M11 Clamp (6e5) EXCEPT FOR USA	Buy now
4	61A8573001 Oil level gauge assembly	Buy now
5	61A1341100 Strainer, oil	Buy now
6	6E51341400 Gasket, strainer cover	Buy now
7	9044505M07 Hose (I700)	Buy now
8	6A08231700 Damper, ignition coil	Buy now
9	6244254200 Collar	Buy now
10	9011906M65 Bolt, with washer	Buy now
11	6R38259E00 Switch assembly	Buy now
12	6E52437900 Pipe, joint 4	Buy now
13	9044512M04 Hose (I3000)	Buy now
14	9046511M10 Clamp	Buy now
15	6E52432300 Pipe 12	Buy now


Oil Tank



D5

Ref	Part	
18	9046413M34 Clamp(6r3)	Buy now
19	61A2170820 Sub oil tank assembly. EXCEPT FOR USA	Buy now
20	6E52173320 Sub tank, oil (10.5l)	Buy now
21	6E52177003 Oil tank cap assembly	Buy now
22	6E52432200 Pipe 11	Buy now
24	6462425102 Strainer 1	Buy now
25	6E52431901 Pipe, oil	Buy now
27	6E58190001 Oil feed pump assembly	Buy now
28	6E58192200 Grommet	Buy now
29	6E52432101 Pipe 10	Buy now
31	9044511M26 Hose (l8000)	Buy now
33	6E58572004 Oil level gauge assembly	Buy now
34	6R38572180 Wire, lead	Buy now
35	6E5217340133 Holder, oil sub tank EXCEPT FOR USA	Buy now
36	6E5217980133 Bracket, damper EXCEPT FOR USA	Buy now

Oil Tank




60V1010-3130

D5

Ref	Part	
37	6E52174600 Damper EXCEPT FOR USA	Buy now
38	9708006100 Bolt, hexagon EXCEPT FOR USA	Buy now
39	9299006600 Washer, plain (646) EXCEPT FOR USA	Buy now
40	9538006600 Nut(661) EXCEPT FOR USA	Buy now
42	6E51343743 Mark, Caution FOR BRA, VEN	Buy now
42	6E51343762 Mark Caution FOR CAR	Buy now


Power Trim & Tilt Assy 1



C2

Ref	Part	
1	60V43800004D Power trim & tilt assembly	Buy now
2	61A4384001 Power tilt assembly	Buy now
3	61A4381000 Tilt piston sub assembly	Buy now
4	61A4386100 O-ring	Buy now
5	61A4387100 Ring, back up	Buy now
6	9310619N50 Oil seal	Buy now
7	6H14386100 O-ring	Buy now
8	6H14387200 Ring, back up	Buy now
9	61A4389H00 O-ring	Buy now
11	6H14381400 Piston, free	Buy now
12	61A4381301 Cylinder, tilt	Buy now
13	69J4388800 Bolt, socket	Buy now
14	61A4383501 Pipe	Buy now
15	61A4383301 Pipe	Buy now
16	61A4381800 Pin, lower shock mount	Buy now


Power Trim & Tilt Assy 1



C2

Ref	Part	
17	9038618M14 Bushing (6e5)	Buy now
18	6H14381700 Filter 2	Buy now
19	9760704230 Screw, pan head with washer	Buy now
20	69J4382800 Body, reservoir	Buy now
21	6H14386900 O-ring	Buy now
22	61A4384L00 Spring Trim Down	Buy now
23	6T44385100 Seat, relief valve	Buy now
24	9760705210 Screw, With Washer	Buy now
25	61A4384K00 Plate, trim down	Buy now
26	61A4384J00 Seal, trim down	Buy now
27	93210064A5 O-ring(61a)	Buy now
28	9350532038 Ball(7fk)	Buy now
29	61A4387500 Ring, snap	Buy now
30	61A4384800 Rod, manual release	Buy now
31	61A4385400 Spring, manual release	Buy now


Power Trim & Tilt Assy 1



C2

Ref	Part	
32	61A4384500 Screw, manual release	Buy now
33	6H14387500 Ring, snap	Buy now
34	9321018397 O-ring (6g5)	Buy now
35	61A4384700 Seat, manual valve	Buy now
36	6T44387600 Ring, snap	Buy now
37	9321007003 O-ring (11m)	Buy now
38	9321006001 O-ring (26h)	Buy now
39	6T44384900 Pin, valve support	Buy now
40	61A4385H00 Spring, seal	Buy now
41	61A4384F00 Seal, main valve	Buy now
42	6H14383100 Connector, shaft	Buy now
43	6T44383000 Gear pump assembly	Buy now
44	61A4382K00 Cap, relief valve	Buy now
45	6H14385610 Spring, down relief	Buy now
46	6T44384400 Pin, valve support	Buy now


Power Trim & Tilt Assy 1



C2

Ref	Part	
47	6T44384G00 Seal, relief valve	Buy now
48	6T44385500 Spring, up relief	Buy now
49	6T44389500 Seat, relief valve	Buy now
50	9321010M74 O-ring	Buy now
51	6H14381600 Filter 1	Buy now
52	6T44380203 Valve sub assembly	Buy now
53	6H14386600 O-ring	Buy now
54	6H14386700 O-ring	Buy now
55	6T44384100 Piston, shuttle	Buy now
56	9321009165 O-ring	Buy now
57	6H14382900 Plug, reservoir	Buy now
58	61A4387800 Bolt, socket	Buy now
59	6T44387501 Ring, snap	Buy now
60	61A4382200 Seal, trim dust	Buy now
61	61A4382100 Screw, trim cylinder end	Buy now


Power Trim & Tilt Assy 1



C2

Ref	Part	
62	9160910014 Pin, spring(61a)	Buy now
64	61A4382010 Trim piston sub assembly	Buy now
65	61A4387400 Ring, back up	Buy now
66	61A4386400 O-ring	Buy now
67	61A4387510 Ring, snap	Buy now
68	61A4383H11 Hose, oil 5	Buy now
69	61A4384H10 Spring	Buy now
70	61A4387600 Ring, snap	Buy now
71	6T44389300 Washer	Buy now
72	9350108001 Ball	Buy now
73	61A4382A00 Adaptor 1	Buy now
74	69J4388000 Motor assembly REFER TO FIG.27	Buy now

Power Trim & Tilt Assy 2





60V1010-3260

C5


Ref	Part	
1	69J4388000 Motor assembly	Buy now
2	9020614N50 Washer, wave	Buy now
3	93399999T6 Bearing	Buy now
4	69J4380500 Armature assembly	Buy now
5	69J4380400 Stator assembly	Buy now
6	69J4386100 O-ring	Buy now
7	69J4388600 Bolt	Buy now
8	69J4388200 Oil seal	Buy now
9	69J4389100 Brush 1	Buy now
10	69J4386K00 Spring, brush	Buy now
11	69J4388100 Frame, end	Buy now

Remote Control Box



Ref	Part	
1	7034820517 Remote control assembly (10p, ptt) AP FOR BRA	Buy now
1	70348205A4 Remote control assembly (10p, ptt) AP FOR VEN	Buy now
2	7044820514 704 single top mount (mec rc) AP FOR CAR	Buy now
3	7044820723 Remote Control assembly AP WITH PT/T SW.	Buy now
4	7014832050 Cable, Remote Control L=15F UR	Buy now
4	7014832060 Cable, Remote Control L=16F UR	Buy now
4	7014832080 Cable, Remote Control L=17F UR	Buy now
4	7014835000 Cable, Remote Control L=21F UR	Buy now
4	7014835010 Cable, Remote Control L=22F UR	Buy now
4	7014835020 Cable, Remote Control L=23F UR	Buy now


Repair Kit 1



F6

Ref	Part	
1	60VW000100 Power head gasket kit	Buy now
2	60V1119300 Gasket, head cover 1	Buy now
3	60V1118100 Gasket, cylinder head 1	Buy now
4	9043014115 Gasket (663)	Buy now
5	60V1138100 Gasket 1	Buy now
6	60V12414A0 Gasket, cover	Buy now
7	60V4111200 Gasket, exhaust inner cover	Buy now
8	60V11382A0 Gasket 2	Buy now
9	9310422M07 Oil seal(61a)	Buy now
10	9310240010 Oil seal	Buy now
11	60V1535300 Gasket, drain	Buy now
12	60V1364600 Gasket, manifold 2	Buy now
13	60V1364500 Gasket, manifold 1	Buy now
14	60V1447600 Seal	Buy now
15	9321018MA9 O-ring(61a)	Buy now


Repair Kit 1



F6


Ref	Part	
16	60V13621A0 Gasket, Valve Seat	Buy now
17	60V1147900 O-ring	Buy now
18	60V4511300 Gasket, upper casing	Buy now

Repair Kit 2




Ref	Part	
1	60VW000120 Lower unit gasket kit	Buy now
2	61A41134A0 Gasket, exhaust manifold	Buy now
3	60V4511400 Gasket, upper casing	Buy now
4	9043008020 Gasket	Buy now
5	61A4512301 Gasket, muffler	Buy now
6	6E54436500 Damper, water seal 1	Buy now
7	6E54436600 Damper, water seal 2	Buy now
8	9321064488 93210-64488	Buy now
9	9310609014 Oil seal	Buy now
10	9321086M38 O-ring (6e5)	Buy now
11	9321037160 O-ring (6g8)	Buy now
12	6E544315A0 Gasket, water pump	Buy now
13	9310128M16 Oil seal (6e5)	Buy now
14	9321055M14 O-ring (70e)	Buy now
15	9321104384 O-ring (705)	Buy now

Repair Kit 2



Ref	Part	
16	9310130M17 Oil seal (6e5)	Buy now
17	61AW0078A3 Water pump repair kit	Buy now
18	61A4432202 Insert, cartridge	Buy now
21	6E54435201 Impeller	Buy now
22	6G54432300 Outer plate, cartridge	Buy now
24	9360612019 Pin, dowel (614)	Buy now
25	9011908M14 Bolt, with washer	Buy now
26	9028004M05 Key, woodruff (6e5)	Buy now


Starting Motor



F7

Ref	Part	
1	60X8180000 Starting motor assembly	Buy now
2	67F8185000 Armature assembly	Buy now
3	67F8181000 Stator assembly	Buy now
4	69J8184000 Brush holder assembly	Buy now
5	69J8180100 Brush set	Buy now
6	67F8181300 Spring, brush	Buy now
7	68F8182000 Rear bracket assembly	Buy now
8	67F8180800 Pinion assembly	Buy now
9	67F8185700 Pinion stopper set	Buy now
10	67F8180700 Gear assembly, starting motor	Buy now
11	67F8183200 Clutch, over run	Buy now
12	67F8183600 Shaft, pinion	Buy now
13	67F8182100 Bracket, center 1	Buy now
14	67F8184100 Bearing	Buy now
15	67F8189100 Gear, ring	Buy now


Starting Motor



F7

Ref	Part	
16	67F8183R00 Gasket	Buy now
17	67F8183000 Bracket, center 2	Buy now
18	60V8183T00 Gear, idler	Buy now
19	67F8180900 Washer kit	Buy now
20	60X8184200 Cover	Buy now
21	69J8183900 Lever assembly	Buy now
22	69J8194100 Starter relay assembly	Buy now
23	69J8186900 Cover Dust	Buy now
24	6K78182610 Bolt	Buy now
25	69J8182800 Bolt 2	Buy now
26	67F8184600 Screw	Buy now
27	9017908003 Nut	Buy now
28	60V8192500 Terminal	Buy now
29	68F8258200 Cover, wire harness	Buy now
30	9701308045 Bolt	Buy now


Starting Motor



F7

Ref	Part	
31	9290308600 Washer, plain (663)	Buy now
32	67F8362701 Label, caution 7	Buy now


Steering Guide



E6

Ref	Part	
1	6E56135002 Steering guide attachment kit AP	Buy now
2	6E56135101 Rod, steering link	Buy now
3	9038710M61 Collar (6e5)	Buy now
4	9056012M01 Spacer (6e5)	Buy now
5	6E56135500 Bolt	Buy now
6	9018509M01 Nut, nylon (663)	Buy now
7	9020110M20 Washer, plate (663)	Buy now
8	6E54314501 Cap, clamp bracket	Buy now
9	9321016275 O-ring	Buy now
10	6E56130101 Tie bar assembly (l:600-800mm) AP	Buy now
11	6E56131300 Adjuster	Buy now
12	6E56131111 Tie bar	Buy now
13	6E56131500 Tie bar, 2	Buy now
14	6E56130300 Steering axle comp.	Buy now
15	9017014M06 Nut (6e5)	Buy now


Steering Guide



E6


Ref	Part	
16	9538014700 Nut (6e5)	Buy now
17	9020110M76 Washer, plate (6e5)	Buy now
18	9010109M70 Bolt (6e5)	Buy now
19	9017009M05 Nut, hexagon (6e5)	Buy now

Switch. Panel 1



Ref	Part	
1	6R58257004 Panel switch assembly AP FOR CAR	Buy now
2	6R58258801 Plate	Buy now
3	6R58257101 Panel, switch	Buy now
4	6R58251002 Main switch assembly	Buy now
5	6768257700 Cap, key	Buy now
6	6888257501 Engine stop switch assembly	Buy now
7	6828255600 Lanyard, stop switch	Buy now
8	64D8258100 Stay, cord clamp	Buy now
9	9730305012 Bolt, hexagon	Buy now
15	9290305100 Ybs67-5 washer, spring AP FOR CAR	Buy now
11	9530305700 Nut (656)	Buy now
12	6R58338300 Buzzer	Buy now
13	9014905M05 Screw(6k0) AP FOR CAR	Buy now
14	9530305600 Nut, hexagon (663) AP FOR CAR	Buy now
16	9290305600 Washer, plain (646) AP FOR CAR	Buy now

Switch. Panel 1





69J2100-3400

F3


Ref	Part	
17	6K18258A40 Extension, wire harness AP FOR CAR	Buy now

Switch. Panel 2



Ref	Part	
1	6K18257007 Panel switch assembly AP FOR BRA	Buy now
2	6K18257101 Plate, panel switch	Buy now
3	6K18251006 Main switch assembly	Buy now
4	7038257700 Cap, key	Buy now
5	6K18257500 Engine stop switch assembly	Buy now
6	6828255600 Lanyard, stop switch	Buy now
7	6K18361401 Bracket	Buy now
8	9898005010 Screw, bind(6k1)	Buy now
23	9299005100 Ybs67-5 washer, spring AP FOR BRA	Buy now
21	9538005600 Nut, hexagon (663) AP FOR BRA	Buy now
11	6888338311 Buzzer	Buy now
12	6K18583001 Control unit assembly	Buy now
13	9898006020 Screw, bind (j17)	Buy now
14	9538006600 Nut(661)	Buy now
15	9299006100 Washer(6a1)	Buy now


Switch. Panel 2



F4

Ref	Part	
16	9299006600 Washer, plain (646)	Buy now
17	6K18198000 Diode assembly	Buy now
18	6K18258A40 Extension, wire harness AP FOR BRA	Buy now
19	61B8258A01 Extension, wire harness AP FOR BRA	Buy now
20	9014905M05 Screw(6k0) AP FOR BRA	Buy now
22	9299005600 Washer, plain (646) AP FOR BRA	Buy now

Switch. Panel 3





67H1100-2360

F5

Ref	Part	
1	61B8257002 Panel switch assembly AP FOR CAR, VEN	Buy now
2	61B8258801 Plate	Buy now
3	61B8255101 Stop Switch assembly	Buy now
4	61B8251001 Main switch assembly	Buy now
5	6768257700 Cap, key	Buy now
6	6K18257500 Engine stop switch assembly	Buy now
7	6828255600 Lanyard, stop switch	Buy now
8	6K18361401 Bracket	Buy now
9	9898005010 Screw, bind(6k1)	Buy now
23	9299005100 Ybs67-5 washer, spring AP FOR CAR, VEN	Buy now
21	9538005600 Nut, hexagon (663) AP FOR CAR, VEN	Buy now
12	6R58338300 Buzzer	Buy now
13	61B8583000 Control Unit assembly	Buy now
14	9898006020 Screw, bind (j17)	Buy now
15	9538006600 Nut(661)	Buy now

Switch. Panel 3





67H1100-2360

F5

Ref	Part	
16	9299006100 Washer(6a1)	Buy now
17	9299006600 Washer, plain (646)	Buy now
18	6K18258A40 Extension, wire harness AP FOR CAR,VEN	Buy now
19	61B8258A01 Extension, wire harness AP FOR CAR,VEN	Buy now
20	9014905M05 Screw(6k0) AP FOR CAR,VEN	Buy now
22	9299005600 Washer, plain (646) AP FOR CAR,VEN	Buy now


Top Cowling



A4

Ref	Part	
1	60V42610008D Top Cowling assembly	Buy now
2	68F426470194 Holder, clamp band	Buy now
3	68F426480194 Holder, clamp band	Buy now
4	9299006100 Washer(6a1)	Buy now
5	9538006600 Nut(661)	Buy now
6	68F4266300 Damper 2	Buy now
7	60V4265101 Hook	Buy now
8	60V4265200 Hook	Buy now
9	9709506016 Bolt, hexagon deep recess	Buy now
10	9299506600 Washer, plain (646)	Buy now
11	60V42613008D Molding, Air Duct	Buy now
12	60V4262100 Mldg Top	Buy now
13	9778050616 Screw, pan head tapping (ak5)	Buy now
14	60V4266400 Damper	Buy now
15	9044511M33 Hose (I700)	Buy now


Top Cowling



A4

Ref	Part	
16	60V4268700 Emblem, rear	Buy now
17	9046208018 Clamp	Buy now
18	9778050612 Screw, tapping(61a)	Buy now
19	9017906M24 Nut(6j8)	Buy now
20	60V4266200 Damper	Buy now
21	60V4267700 Graphic, front	Buy now
22	60VW007000 -	Buy now
23	60V4268100 Mark, cowling	Buy now
24	60V4268200 Mark, cowling	Buy now
25	60V4267800 Graphic, front	Buy now
26	67F1344800 Cap	Buy now
27	60V4262600 Louver 1	Buy now
28	60V4262610 Louver 1	Buy now
29	9016005005 Screw, round tapping	Buy now
30	60V4263700 Damper Form	Buy now


Top Cowling



A4

Ref	Part	
31	60V4263710 Damper Form	Buy now
32	68F1343400 Label, Caution	Buy now


Upper Casing



C6

Ref	Part	
1	60V45111208D Casing, Upper X	Buy now
1	60V45111308D Casing, Upper U	Buy now
2	6E52437700 Pipe, joint	Buy now
3	61A42791S0 Mark 1	Buy now
4	61A42792S0 Mark	Buy now
5	61A4515500 Cap	Buy now
6	9709506010 Bolt	Buy now
39	9299506600 Washer, plain (646) U	Buy now
8	9360812M05 Pin, dowel b (6e5)	Buy now
9	9011908052 Bolt, with washer	Buy now
10	61A4537800 Nipple, hose	Buy now
11	9011906M17 Bolt, with washer	Buy now
12	9360612019 Pin, dowel (614)	Buy now
13	9044507M21 Hose (I1160) U	Buy now
13	9044507MF0 Hose (I1160) X	Buy now


Upper Casing



C6

Ref	Part	
14	6E58355800 End, nipple	Buy now
15	9046511M10 Clamp	Buy now
16	6E54531800 Bushing, drive shaft 3	Buy now
17	9342036M01 Circlip (6a0)	Buy now
18	60V4511400 Gasket, upper casing	Buy now
19	60V411371094 Guide, exhaust	Buy now
21	60V4511300 Gasket, upper casing	Buy now
22	9011908079 Bolt, with washer Go to P/N) PE0-OM-050009	Buy now
23	9011908072 Bolt, With Washer Go to P/N) PE0-OM-050009	Buy now
24	9011908060 Bolt, with washer	Buy now
25	6H11137200 Nipple, hose	Buy now
26	60V411310194 Manifold, ext. 1	Buy now
26	60V411311094 - FOR VEN	Buy now
27	9011908056 Bolt With Washer	Buy now
28	61A41132015B Manifold, exhaust	Buy now


Upper Casing



C6


Ref	Part	
28	61A41132105B - FOR VEN	Buy now
29	61A41134A0 Gasket, exhaust manifold	Buy now
30	9011908059 Bolt, with washer	Buy now
31	60V14711205B Muffler 1	Buy now
31	60V14711305B Muffler 1 FOR VEN	Buy now
32	6E51473700 Damper, muffler	Buy now
33	9018305M02 Nut, spring (6e5)	Buy now
36	61A4512301 Gasket, muffler U	Buy now
37	61A14721305B Muffler 2 U	Buy now
38	9709506035 Bolt(j52) U	Buy now

Vapor Separator 1




Ref	Part	
1	60V2421600 Stay	Buy now
2	68F2447300 Screw	Buy now
3	60V1498000 Body, float chamber	Buy now
4	60V1418200 Cover, float chamber	Buy now
5	65L1454600 Valve, needle	Buy now
6	66K1498500 Float	Buy now
7	66K1454801 Pin, float arm	Buy now
8	66K1498400 Gasket, float chamber	Buy now
9	65L1412500 Screw	Buy now
10	68F1390600 Regulator, pressure	Buy now
11	66K1432501 Screw, pan head	Buy now
12	60V1416300 Spacer	Buy now
13	65L1390500 Filter comp	Buy now
14	68F1397100 Pipe, fuel 1	Buy now
15	65L2438700 Clip	Buy now

Vapor Separator 1




Ref	Part	
16	65L1496600 Cap	Buy now
17	65L2448600 O-ring	Buy now
18	68F2425100 Strainer 1	Buy now
19	66K1424500 Screw, guide	Buy now
20	68F8250900 Wire, sub lead	Buy now
21	65L1422700 Washer	Buy now
22	60V1390700 Fuel pump comp.	Buy now
23	65L1415900 Clip	Buy now
24	68F1378100 Damper, pump	Buy now
25	68F1384400 Plate 2	Buy now
26	68F1391500 Filter	Buy now
27	65L1416A00 O-ring	Buy now
28	66K1427100 Insulator	Buy now
29	65L8182A00 Nut	Buy now
30	65L8182K00 Nut	Buy now

Vapor Separator 1




Ref	Part	
31	65L8182E00 Washer	Buy now
32	65L8182F00 Washer	Buy now
33	68F1384300 Plate 1	Buy now
34	65L1414700 O-ring	Buy now
35	68F1427400 Connector	Buy now
36	66K2437600 Pipe, joint 1	Buy now
37	66K2448900 O-ring	Buy now
38	68F1427100 Insulator	Buy now
39	65L1439700 O-ring	Buy now
40	65L1499200 Screw, drain	Buy now
41	65L1499700 Seal	Buy now
42	60V2437501 Grommet	Buy now
43	60V2439701 Collar	Buy now
44	66K2457900 Washer 2	Buy now
45	65L2459200 Bolt	Buy now

Vapor Separator 1



Ref	Part	
46	65L2416900 Washer, lock	Buy now
47	60V8250700 Wire, lead	Buy now
48	66K1354200 Hose, vacuum sensing 1	Buy now
49	66K1354400 Hose, Vacuum Sensing 2	Buy now
50	66K1353200 Hose, vacuum sensing 3	Buy now
51	65L2446100 Pipe joint 4	Buy now
52	66K1353300 Hose, vacuum sensing 4	Buy now
53	65L1389800 Plate 4	Buy now
54	65L1456500 Screw	Buy now
55	60V2433901 Grommet	Buy now
56	60V1353400 Hose, Vacuum Sensing 5	Buy now
57	9046511M10 Clamp	Buy now

Vapor Separator 2





60V1010-3080

C3

Ref	Part	
1	60V1375100 Body, throttle 1	Buy now
2	65L1452700 Plate	Buy now
3	65L1456500 Screw	Buy now
4	65L1433400 Spring, air adjusting	Buy now
5	65L1452300 Screw, stop	Buy now
6	6K51459200 Screw	Buy now
7	9020105552 Washer, plate(65j)	Buy now
8	65L1457800 Collar	Buy now
9	68F1356800 Stud	Buy now
10	61A8588500 Throttle sensor assembly	Buy now
11	6K78588600 Bracket	Buy now
12	9798505212 Screw, with washer(6g7)	Buy now
13	9038705M00 Collar(6k7)	Buy now
14	60V8551600 Spacer	Buy now
15	60V1459600 Washer	Buy now

Vapor Separator 2




60V1010-3080

C3

Ref	Part	
16	9798505330 Screw, with washer(61b)	Buy now
17	65L1457300 Lever	Buy now
18	65L1457900 Spring	Buy now
19	65L4121700 Rod, accel. lever	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.