



Yamaha LZ250DETO 2006

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers




Contents

| | |
|-------------------------------------|-----|
| BOTTOM COWLING | 3 |
| BRACKET 1 | 8 |
| BRACKET 2 | 11 |
| CONTROL | 14 |
| CRANKSHAFT & PISTON | 19 |
| CYLINDER & CRANKCASE 1 | 22 |
| CYLINDER & CRANKCASE 2 | 26 |
| CYLINDER & CRANKCASE 3 | 28 |
| ELECTRICAL 1 | 30 |
| ELECTRICAL 2 | 34 |
| ELECTRICAL 3 | 36 |
| ELECTRICAL 4 | 40 |
| FUEL | 41 |
| FUEL INJECTION NOZZLE | 46 |
| FUEL INJECTION PUMP | 49 |
| FUEL PUMP DRIVE GEAR | 52 |
| GENERATOR | 54 |
| INTAKE | 56 |
| LOWER CASING & DRIVE 1 | 58 |
| LOWER CASING & DRIVE 2 | 65 |
| LOWER CASING & DRIVE 3 | 68 |
| LOWER CASING & DRIVE 4 | 75 |
| METER | 78 |
| OIL PUMP | 79 |
| OIL TANK | 83 |
| POWER TRIM & TILT ASSY 1 | 86 |
| POWER TRIM & TILT ASSY 2 | 91 |
| REMOTE CONTROL BOX | 92 |
| REPAIR KIT 1 | 93 |
| REPAIR KIT 2 | 95 |
| STARTING MOTOR | 97 |
| STEERING GUIDE | 100 |
| SWITCH & PANEL | 102 |
| TOP COWLING | 104 |
| UPPER CASING | 107 |
| VAPOR SEPARATOR 1 | 110 |
| VAPOR SEPARATOR 2 | 114 |

Bottom Cowling




Bottom Cowling



A5

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 17 | 64D4314400 Hook, spring | Buy now |
| 18 | 9010906M80 Bolt | Buy now |
| 19 | 9050618M40 Spring, tension | Buy now |
| 20 | 6D04261500 Seal | Buy now |
| 21 | 60V4439100 Nipple, Hose | Buy now |
| 22 | 60V4272500 Grommet | Buy now |
| 23 | 6D04272100 Gasket 1 | Buy now |
| 24 | 60V42738028D Plate, fitting | Buy now |
| 25 | 60V4271602 Rubber, Seal 1 | Buy now |
| 26 | 60V4271701 Rubber, seal 2 | Buy now |
| 27 | 9010906M81 Bolt | Buy now |
| 28 | 64D42738108D Plate, Fitting | Buy now |
| 30 | 9048022M81 Grommet | Buy now |
| 31 | 9038708M37 Coller (6e5) | Buy now |


Bottom Cowling



A5

| Ref | Part | |
|-----|--|-------------------------|
| 32 | 9020108M54 Washer, plate (6e5) | Buy now |
| 33 | 9707508035 Bolt(70w) | Buy now |
| 34 | 9011908M22 Bolt, with washer | Buy now |
| 35 | 6C54272400 Grommet | Buy now |
| 68 | 9046511M10 Clamp FLUSHING KIT | Buy now |
| 37 | 6E58258800 Plate | Buy now |
| 38 | 9589506020 Bolt, flange(jk3) | Buy now |
| 39 | 60V42723005B Cover, bottom | Buy now |
| 40 | 60V42721A0 Gasket 1 | Buy now |
| 41 | 60V4271800 Rubber, seal 3 | Buy now |
| 42 | 9011006038 Bolt, hexagon socket head | Buy now |
| 43 | 60V42741008D Apron | Buy now |
| 44 | 60V4275600 Stay, clamp | Buy now |
| 45 | 9788004016 Screw, with washer(61b) | Buy now |
| 46 | 9299004600 Washer, plain (646) | Buy now |


Bottom Cowling




A5

| Ref | Part | |
|-----|--|-------------------------|
| 47 | 9011106034 Bolt,hex. socket button | Buy now |
| 48 | 9709506020 Bolt(7u8) | Buy now |
| 49 | 9299506600 Washer, plain (646) | Buy now |
| 50 | 60V1258100 Joint, hose 1 | Buy now |
| 51 | 60V1257600 Hose 1 | Buy now |
| 52 | 60V1257800 Hose 3 | Buy now |
| 53 | 60V1258800 Hose 5 | Buy now |
| 54 | 6E52437800 Pipe, joint 3 | Buy now |
| 56 | 60V4277100 Apron | Buy now |
| 57 | 9707508055 - | Buy now |
| 58 | 9299508600 Washer, plain (663) | Buy now |
| 59 | 6D04271700 Rubber, seal 2 | Buy now |
| 60 | 61A4271600 Rubber seal 1 | Buy now |
| 61 | 60V4277400 Stay, Apron 1 | Buy now |
| 62 | 9589506016 Bolt, flange deep recess | Buy now |

Bottom Cowling




Bracket 1



B4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 69J43111018D Bracket, clamp 1 | Buy now |
| 2 | 6G54525102 Anode | Buy now |
| 3 | 6G54452600 Plate | Buy now |
| 4 | 9709506025 Bolt | Buy now |
| 5 | 9299506600 Washer, plain (646) | Buy now |
| 6 | 6H18214800 Wire, lead | Buy now |
| 7 | 9709506010 Bolt | Buy now |
| 9 | 6E58214800 Wire, lead 5 | Buy now |
| 10 | 9788506012 Screw, pan head(62j) | Buy now |
| 12 | 61A4313200 Washer, friction | Buy now |
| 13 | 9788506010 Screw pan head | Buy now |
| 14 | 69J43112018D Bracket, clamp 2 | Buy now |
| 15 | 61A4313300 Washer, friction | Buy now |
| 17 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 18 | 9046508M83 Clamp | Buy now |


Bracket 1



B4

| Ref | Part | |
|-----|--|-------------------------|
| 21 | 6R34313100 Bolt, clamp bracket | Buy now |
| 22 | 9038625M31 Bushing (6e5) | Buy now |
| 23 | 9020126M59 Washer, plate (6e5) | Buy now |
| 24 | 9018522M11 Nut, self-locking | Buy now |
| 25 | 9046511M10 Clamp | Buy now |
| 27 | 9709506014 Bolt(gj3) | Buy now |
| 29 | 9011910024 Bolt, with washer | Buy now |
| 30 | 61A43311218D Bracket, swivel 1 X (25.1") | Buy now |
| 32 | 61A8214720 Wire, lead 5 X (25.1") | Buy now |
| 33 | 6G54314400 Hook, spring | Buy now |
| 35 | 61A4318101 Lever, tilt stop 1 | Buy now |
| 36 | 6G54318502 Lever, tilt stop 2 | Buy now |
| 37 | 9038610M16 Bushing (688) | Buy now |
| 38 | 6G54314800 Collar, distance | Buy now |
| 39 | 9024906M19 Pin(6e5) | Buy now |


Bracket 1



| Ref | Part | |
|-----|--|-------------------------|
| 40 | 9038710M02 Collar(6e5) | Buy now |
| 41 | 9169030020 Pin, spring (6h4) | Buy now |
| 42 | 9050616003 Spring, tension | Buy now |
| 43 | 6E54312602 Pin, upper shock mount | Buy now |
| 44 | 9038618M63 Bush(6e5) | Buy now |
| 45 | 9038618M14 Bushing (6e5) | Buy now |
| 46 | 9341018M02 Circlip (6f2) | Buy now |
| 47 | 9010112M05 Bolt (l:130mm) | Buy now |
| 48 | 9020113M01 Washer, plate(6e5) | Buy now |
| 49 | 9020112M05 Washe, plate(663) | Buy now |
| 50 | 9538012600 Nut (707) | Buy now |

B4


Bracket 2



B6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V42510208D Steering Bracket assembly X (25.1") | Buy now |
| 2 | 9020140M00 Washer, plate(61a) | Buy now |
| 3 | 9038639M89 Bush(61a) | Buy now |
| 4 | 9321035321 O-ring (3m7) | Buy now |
| 5 | 9020240M47 Washer, plate(61a) | Buy now |
| 6 | 61A44551018D Housing, lower mount rubber | Buy now |
| 7 | 9341037M04 Circlip (6e5) | Buy now |
| 8 | 61A4457500 Damper, lower mount rubber | Buy now |
| 9 | 60V44550094 Mount damper, lower side | Buy now |
| 10 | 9020232M19 Washer, plate (6e5) | Buy now |
| 11 | 9020116016 Washer, plate | Buy now |
| 12 | 6E58214900 Wire, lead 3 | Buy now |
| 13 | 9010114002 Bolt | Buy now |
| 14 | 9020115M58 Washer, plate (6e5) | Buy now |
| 15 | 9538014800 Nut, crown (6e5) | Buy now |


Bracket 2



B6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9299514600 Washer (6e5) | Buy now |
| 17 | 61A445520194 Housing, lower mount rubber | Buy now |
| 18 | 9011910024 Bolt, with washer | Buy now |
| 19 | 61A44553028D Cover, lower mount | Buy now |
| 20 | 6S31578901 Damper | Buy now |
| 21 | 6A01578900 Damper | Buy now |
| 22 | 60V445140094 Mount damper, upper side | Buy now |
| 23 | 9020116015 Washer, plate | Buy now |
| 24 | 9020228M46 Washer, plate(61a) | Buy now |
| 25 | 9020128M01 Washer, plate(61a) | Buy now |
| 26 | 9010114003 Bolt | Buy now |
| 27 | 9018514M00 Nut, self-locking(61a) | Buy now |
| 29 | 61A445110094 Cover, upper mount | Buy now |
| 31 | 69J8367200 Trim sender | Buy now |
| 32 | 9788506016 Screw, pan head(6b0) | Buy now |


Bracket 2



B6

| Ref | Part | |
|-----|---|-------------------------|
| 33 | 61A4337600 Bolt, thrust receiver | Buy now |
| 34 | 9578010300 Nut, nylon (6e5) | Buy now |

Control




60X4100-E230

B1

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V4853120 Bracket, remote control 1 | Buy now |
| 2 | 6634853800 Clamp, cable 1 | Buy now |
| 3 | 9169030010 Pin, spring (663) | Buy now |
| 4 | 9709508016 Bolt, hexagon deep recess | Buy now |
| 5 | 9299508600 Washer, plain (663) | Buy now |
| 6 | 6D044117001S Bracket | Buy now |
| 7 | 60V4419400 Cap | Buy now |
| 8 | 9709506020 Bolt(7u8) | Buy now |
| 9 | 60V44176001S Bracket | Buy now |
| 10 | 9370006M01 Nipple, grease(61a) | Buy now |
| 11 | 9038612069 Bush(666) | Buy now |
| 12 | 9038708M09 Collar(61a) | Buy now |
| 13 | 9709508035 Bolt(70w) | Buy now |
| 14 | 9299508200 Ybs66-8 washer, plain | Buy now |
| 15 | 9050820M31 Spring, torsion(61a) | Buy now |


Control



B1

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 61A8259F00 Switch assembly | Buy now |
| 17 | 61A8258801 Plate | Buy now |
| 18 | 9798504116 Screw, with washer(61b) | Buy now |
| 19 | 60V8259F00 Switch assembly | Buy now |
| 22 | 61A4412100 Lever, shift rod | Buy now |
| 23 | 68J4412201 Bushing, shift rod lever | Buy now |
| 24 | 9020208M20 Washer, plate (6e5) | Buy now |
| 25 | 9046818008 Clip 620436610000 | Buy now |
| 26 | 6E54834400 Cable end, remote control | Buy now |
| 27 | 9020206007 Washer plate 626441880000 | Buy now |
| 28 | 61A44118008D Bracket | Buy now |
| 29 | 9370006M03 Nipple, grease(6a1) | Buy now |
| 30 | 61A4411600 Spring | Buy now |
| 31 | 9709506030 Bolt(jf7) | Buy now |
| 32 | 9299506100 Washer(6a1) | Buy now |

Control




60X4100-E23C

B1

| Ref | Part | |
|-----|---|-------------------------|
| 33 | 9299506600 Washer, plain (646) | Buy now |
| 34 | 61A4412023 Handle gear shift assembly X (25.1") | Buy now |
| 35 | 9321009165 O-ring | Buy now |
| 36 | 61A4411200 Stay, handle gear shift | Buy now |
| 37 | 9701306012 Bolt(gh1) | Buy now |
| 38 | 9290306100 Washer(6a1) | Buy now |
| 39 | 9290306600 Washer, plain (646) | Buy now |
| 40 | 9531308600 Nut(6l2) | Buy now |
| 41 | 9038690M90 Bush(61a) | Buy now |
| 42 | 9149020012 Pin, cotter (648) | Buy now |
| 43 | 9020109M02 Washer, plate(61a) | Buy now |
| 44 | 61A1531500 Seal, crankcase | Buy now |
| 45 | 61A4272400 Grommet | Buy now |
| 46 | 61A4413800 Washer | Buy now |
| 47 | 9788506008 Screw, pan head(6a3) | Buy now |

Control




60X4100-E230

B1

| Ref | Part | |
|-----|--|-------------------------|
| 48 | 65L4163201 Lever, magneto control | Buy now |
| 51 | 9701308045 Bolt | Buy now |
| 52 | 9299008200 Ybs66-8 washer, plain | Buy now |
| 53 | 9020612M00 Washer, wave (676) | Buy now |
| 54 | 9038708M16 Collar | Buy now |
| 55 | 61A4123700 Joint, link | Buy now |
| 56 | 9538005600 Nut, hexagon (663) | Buy now |
| 57 | 6H44123700 Joint, link | Buy now |
| 58 | 60V4123000 Cam accelerator comp | Buy now |
| 59 | 9020106M31 Washer (6a0) | Buy now |
| 60 | 9038706M29 Coller (6a0) | Buy now |
| 61 | 9020610M04 Washer, wave (676) | Buy now |
| 62 | 9011906MA4 Bolt, with washer | Buy now |
| 63 | 69L4274400 Stay | Buy now |
| 64 | 9015706006 Screw Pan Head | Buy now |


Control



B1

| Ref | Part | |
|-----|--|-------------------------|
| 65 | 9538006600 Nut(661) | Buy now |
| 66 | 6884419400 Cap | Buy now |
| 67 | 9015905M25 Screw,pan head (646) | Buy now |


Crankshaft & Piston



B2


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6D01141100 Crankshaft | Buy now |
| 2 | 61A1144700 Seal, crank | Buy now |
| 3 | 93311940V0 Bearing, cylindrical(61a) | Buy now |
| 4 | 9310240M38 Oil seal(61a) | Buy now |
| 5 | 60V1147900 O-ring | Buy now |
| 6 | 93306209U1 Bearing(61a) | Buy now |
| 7 | 93310959U0 Bearing, cylindrical(61a) | Buy now |
| 8 | 61A1153600 Gear, drive | Buy now |
| 9 | 93306308U0 Bearing(61a) | Buy now |
| 10 | 9341040M03 Circlip(n02) | Buy now |
| 11 | 61A1158601 Pulley, crankshaft balance | Buy now |
| 12 | 60V1155500 Nut, crankshaft 1 | Buy now |
| 13 | 9310422M07 Oil seal(61a) | Buy now |
| 14 | 6D0153590094 Housing, oil seal | Buy now |
| 15 | 9310340011 Oil seal | Buy now |

Crankshaft & Piston



| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9342061M07 Circlip(61a) | Buy now |
| 17 | 9321085M32 O-ring (173) | Buy now |
| 18 | 9709506020 Bolt(7u8) | Buy now |
| 19 | 9299506100 Washer(6a1) | Buy now |
| 20 | 6D0116310285 Piston (std) | Buy now |
| 20 | 6D01163502 Piston (0.25mm o/s) AP | Buy now |
| 20 | 6D01163602 Piston (0.50mm o/s) AP | Buy now |
| 21 | 6D01160301 Piston ring set (std) | Buy now |
| 21 | 6D01160401 Piston ring set (0.25mm o/s) AP | Buy now |
| 21 | 6D01160501 Piston ring set (0.50mm o/s) AP | Buy now |
| 22 | 6D0116420285 Piston 2 (std) | Buy now |
| 22 | 6D01164502 Piston 2 (0.25mm o/s) AP | Buy now |
| 22 | 6D01164602 Piston 2 (0.50mm o/s) | Buy now |
| 24 | 61A1163302 Pin, piston | Buy now |
| 25 | 60X1163400 Clip, piston pin | Buy now |


Crankshaft & Piston



B2

| Ref | Part | |
|-----|---|-------------------------|
| 26 | 69L1165000 Connecting Rod assembly | Buy now |
| 27 | 9010909001 Bolt | Buy now |
| 28 | 9331032657 Bearing | Buy now |
| 29 | 9020126M03 Washer, plate(61a) | Buy now |
| 30 | 9331084106 Bearing | Buy now |


Cylinder & Crankcase 1



A6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60YW0090151S Crank cylinder assembly Go to P/N) PE0-OM-100023 | Buy now |
| 2 | 60V15100031S Crankcase assembly | Buy now |
| 3 | 6E51137201 Nipple, hose | Buy now |
| 4 | 6241448500 Pipe, joint | Buy now |
| 5 | 60V1137000 Check valve assembly | Buy now |
| 6 | 9038406M07 Bush, bimetal formed(6r3) | Buy now |
| 7 | 9038316M01 Bush, formed(61a) | Buy now |
| 8 | 6501137001 Check valve assembly | Buy now |
| 9 | 60V1137010 Check valve assembly | Buy now |
| 10 | 9011608012 Bolt, stud | Buy now |
| 11 | 6631151801 Lock, bearing | Buy now |
| 12 | 9034014M00 Plug, straight screw(62y) | Buy now |
| 13 | 9043014115 Gasket (663) | Buy now |
| 14 | 9360812063 Pin, dowel (626) | Buy now |
| 15 | 9044507M10 Hose (L770) | Buy now |


Cylinder & Crankcase 1



A6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9046807M02 Clip (6e5) | Buy now |
| 17 | 9011910022 Bolt, with washer | Buy now |
| 18 | 9011910021 Bolt With Washer | Buy now |
| 19 | 9011906089 Bolt, with washer | Buy now |
| 20 | 9044507M03 Hose (l200) | Buy now |
| 21 | 9044507016 Hose (l60) | Buy now |
| 22 | 9044507M29 Hose (l200) | Buy now |
| 23 | 9044507MA6 Hose (l200) | Buy now |
| 24 | 6E02437800 Pipe, joint | Buy now |
| 25 | 6G51258100 Joint, hose | Buy now |
| 26 | 60V1132501 Anode | Buy now |
| 27 | 66M1132800 Grommet, anode | Buy now |
| 28 | 66M113270094 Cover, anode | Buy now |
| 29 | 66M1253500 Plate | Buy now |
| 30 | 9709505012 Bolt, hexagon | Buy now |


Cylinder & Crankcase 1



A6

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 9299505600 Washer, plain (646) | Buy now |
| 32 | 9701306020 Bolt(62y) | Buy now |
| 33 | 9290306600 Washer, plain (646) | Buy now |
| 34 | 60V113710094 Cover | Buy now |
| 35 | 60V2413500 Clamp 1 | Buy now |
| 36 | 9701305012 Bolt, hexagon | Buy now |
| 37 | 9290305600 Washer, plain (646) | Buy now |
| 38 | 60V1138100 Gasket 1 | Buy now |
| 39 | 9011906MA2 Bolt, with washer | Buy now |
| 40 | 60V1241100 Thermostat | Buy now |
| 41 | 67F1241200 Seal, thermostat | Buy now |
| 42 | 60V12413001S Cover Thermostat | Buy now |
| 43 | 60V12414A0 Gasket, cover | Buy now |
| 44 | 9948006012 Pin | Buy now |
| 45 | 9011906055 Bolt, with washer | Buy now |


Cylinder & Crankcase 1



A6


| Ref | Part | |
|-----|--|-------------------------|
| 46 | 66M1132500 Anode | Buy now |
| 53 | 6E542761001S Stopper | Buy now |
| 55 | 68F4453300 Damper, upper mount rubber | Buy now |

Cylinder & Crankcase 2



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V1111001S Head Cylinder 1 | Buy now |
| 2 | 67F1132500 Anode <i>Go to P/N) PE0-OM-100023</i> | Buy now |
| 3 | 67F113270094 Anode cover assembly <i>Go to P/N) PE0-OM-100023</i> | Buy now |
| 4 | 69J113270094 Anode cover assembly <i>Go to P/N) PE0-OM-100023</i> | Buy now |
| 5 | 60V113270094 Anode cover assembly <i>Go to P/N) PE0-OM-100023</i> | Buy now |
| 6 | 9707506020 Bolt(7u8) <i>Go to P/N) PE0-OM-100023</i> | Buy now |
| 7 | 9299506600 Washer, plain (646) <i>Go to P/N) PE0-OM-100023</i> | Buy now |
| 8 | 67F1132800 Grommet, anode <i>Go to P/N) PE0-OM-100023</i> | Buy now |
| 9 | 60V1253500 Plate | Buy now |
| 10 | 9757508550 Bolt, with washer | Buy now |
| 11 | 9707508035 Bolt(70w) | Buy now |
| 12 | 9299508600 Washer, plain (663) | Buy now |
| 13 | 68F1111900 Hanger, engine | Buy now |
| 14 | 9011906MA2 Bolt, with washer | Buy now |
| 15 | 60V11191001S - | Buy now |


Cylinder & Crankcase 2



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60V1119300 Gasket, head cover 1 | Buy now |
| 17 | 9011906MA4 Bolt, with washer | Buy now |
| 18 | 68F8391900 Clamp, harness | Buy now |
| 19 | 9959010114 Pin, dowel | Buy now |
| 20 | 9011908MA5 Bolt, with washer | Buy now |
| 21 | 9011908MA8 Bolt, with washer | Buy now |
| 22 | 60V1118100 Gasket, cylinder head 1 | Buy now |
| 23 | 60V11121001S Head, cylinder 2 | Buy now |
| 35 | 69J1111E00 Hanger, engine 2 | Buy now |
| 37 | 60V11192001S Cover, cylinder head 2 | Buy now |
| 45 | 9470200405 Plug, spark (bkr6eku) | Buy now |


B4

Cylinder & Crankcase 3



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V411130094 Outer cover, exhaust | Buy now |
| 2 | 6761137200 Nipple, hose | Buy now |
| 3 | 60V4111200 Gasket, exhaust inner cover | Buy now |
| 4 | 60V4126700 Bushing, joint | Buy now |
| 5 | 9011906MA3 Bolt, with washer | Buy now |
| 6 | 60V113270094 Anode cover assembly <i>Go to P/N) PEO-OM-100023</i> | Buy now |
| 7 | 67F1132500 Anode <i>Go to P/N) PEO-OM-100023</i> | Buy now |
| 8 | 9707506020 Bolt(7u8) <i>Go to P/N) PEO-OM-100023</i> | Buy now |
| 9 | 9299506600 Washer, plain (646) <i>Go to P/N) PEO-OM-100023</i> | Buy now |
| 10 | 67F1132800 Grommet, anode <i>Go to P/N) PEO-OM-100023</i> | Buy now |
| 11 | 9707508030 Bolt, hexagon (fj1) | Buy now |
| 12 | 9299508600 Washer, plain (663) | Buy now |
| 13 | 9046708M18 Clip | Buy now |
| 14 | 60H1241600 Valve, pressure control | Buy now |
| 15 | 9050116M11 Spring, compression (688) | Buy now |


Cylinder & Crankcase 3



B6

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9048020M05 Grommet (688) | Buy now |
| 17 | 60V11382A0 Gasket 2 | Buy now |
| 18 | 6G511372001S Cover, bypass 2 | Buy now |
| 19 | 9011906MA2 Bolt, with washer | Buy now |
| 20 | 61A1257600 Hose 1 | Buy now |
| 21 | 9046513M18 Clamp | Buy now |


Electrical 1




E6

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V855420194 Bracket | Buy now |
| 2 | 60V8556400 Grommet | Buy now |
| 3 | 68F8612900 Collar | Buy now |
| 4 | 68F8612910 Collar | Buy now |
| 5 | 68F8511900 Bolt | Buy now |
| 6 | 60V8591A50 Engine Control Unit assembly | Buy now |
| 7 | 9011906MA3 Bolt, with washer | Buy now |
| 8 | 60V8554800 Holder | Buy now |
| 9 | 9701306014 Bolt(gj3) | Buy now |
| 10 | 9290306600 Washer, plain (646) | Buy now |
| 11 | 60V8591B00 Driver, injector assembly | Buy now |
| 12 | 9011906MA2 Bolt, with washer | Buy now |
| 13 | 60V8251900 Wire, Earth Lead | Buy now |
| 14 | 60V8251910 Wire, earth lead | Buy now |
| 15 | 9709506012 Bolt(gh1) | Buy now |

Electrical 1




Electrical 1



E6

| Ref | Part | |
|-----|--|-------------------------|
| 34 | 60V8818D00 Seat 1 | Buy now |
| 35 | 60V8818D10 Seat 1 | Buy now |
| 36 | 60V2311600 Seat 2 | Buy now |
| 37 | 60V2311610 Seat 2 | Buy now |
| 38 | 60V2318U00 Plate, Seat | Buy now |
| 39 | 60V2318U10 Plate, Seat | Buy now |
| 40 | 68F8551601 Spacer | Buy now |
| 43 | 6D08252R00 Damper | Buy now |
| 44 | 6A08231700 Damper, ignition coil | Buy now |
| 45 | 9038706119 Collar | Buy now |
| 46 | 9011906M65 Bolt, with washer | Buy now |
| 47 | 60V8252U01 Cover | Buy now |
| 48 | 60V2311500 Seat 1 | Buy now |
| 49 | 9011106034 Bolt, hex. socket button | Buy now |
| 50 | 68V8195000 Relay assembly | Buy now |


Electrical 1



| Ref | Part | |
|-----|---|-------------------------|
| 51 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 53 | 9046208028 Clamp | Buy now |

E6


Electrical 2



F1


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 9044707011 Hose, with spring | Buy now |
| 2 | 9046511M10 Clamp | Buy now |
| 3 | 61A8194900 Wire, lead | Buy now |
| 4 | 9709506012 Bolt(gh1) | Buy now |
| 5 | 9299506600 Washer, plain (646) | Buy now |
| 7 | 60V8210500 Battery cable | Buy now |
| 8 | 9533308600 Nut(6l2) | Buy now |
| 9 | 9290308100 Ybs67-8 washer, spring | Buy now |
| 10 | 6D08253100 Wire, lead | Buy now |
| 11 | 60V8259060 Wire Harness assembly | Buy now |
| 12 | 68F8355700 Tube | Buy now |
| 15 | 9046511M52 Clamp(6e7) | Buy now |
| 16 | 6D08259M10 Wire Harness assembly 2 | Buy now |
| 18 | 9046208029 Clamp | Buy now |
| 20 | 9046411008 Clamp | Buy now |

Electrical 2




F1

| Ref | Part | |
|-----|---|-------------------------|
| 22 | 69J8256300 Trim & tilt switch assembly | Buy now |
| 23 | 69J8258700 Gasket | Buy now |
| 24 | 69J4272300 Cover, Bottom | Buy now |
| 25 | 60V8361420 Bracket | Buy now |
| 26 | 60V8361410 Bracket | Buy now |
| 27 | 60V8363510 Bracket | Buy now |
| 28 | 9046420213 Clamp(4kj) | Buy now |
| 29 | 9709506014 Bolt(gj3) | Buy now |
| 30 | 9010906M86 Bolt | Buy now |
| 31 | 60V8361800 Plate | Buy now |
| 32 | 68F8363400 Grommet | Buy now |
| 33 | 67H8238000 Sensor, pressure | Buy now |
| 34 | 9858006520 Screw pan head | Buy now |
| 35 | 6E58258800 Plate | Buy now |
| 36 | 9589506020 Bolt, flange(jk3) | Buy now |



F3


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V8196001 Rectifier & regulator assembly | Buy now |
| 2 | 60V81975A0 Plate, rectifier fitting | Buy now |
| 3 | 60V81972001S Cover, rectifier | Buy now |
| 4 | 9011906MA3 Bolt, with washer | Buy now |
| 5 | 9011906MA4 Bolt, with washer | Buy now |
| 6 | 6D08366G00 Bracket 3 | Buy now |
| 7 | 60V8818D10 Seat 1 | Buy now |
| 8 | 9044509M25 Hose (I1500) | Buy now |
| 9 | 9046708M18 Clip | Buy now |
| 10 | 9044710004 Hose, With Spring | Buy now |
| 11 | 60V8194800 Bracket | Buy now |
| 12 | 68F8511900 Bolt | Buy now |
| 13 | 9011906M65 Bolt, with washer | Buy now |
| 14 | 68F8551601 Spacer | Buy now |
| 15 | 68F8612900 Collar | Buy now |



F3

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6A08231700 Damper, ignition coil | Buy now |
| 17 | 9038706119 Collar | Buy now |
| 18 | 60V8714900 Connector | Buy now |
| 19 | 9011006139 Bolt, hexagon socket head | Buy now |
| 20 | 60V8195000 Relay assembly | Buy now |
| 21 | 9011006191 Bolt, hexagon socket head | Buy now |
| 22 | 6828211901 Cover, lead wire | Buy now |
| 23 | 9709506010 Bolt | Buy now |
| 24 | 9299506100 Washer(6a1) | Buy now |
| 25 | 9299506600 Washer, plain (646) | Buy now |
| 26 | 68V8194A00 Relay | Buy now |
| 27 | 68F8211700 Wire, lead | Buy now |
| 32 | 68F8195300 Stay, relay | Buy now |
| 33 | 9778060620 Screw, tapping(6k8) | Buy now |
| 34 | 9046423199 Clamp(4hm) | Buy now |


Electrical 3



F3


| Ref | Part | |
|-----|--|-------------------------|
| 35 | 60V8217000 Fuse box assembly Go to P/N) PEO-OM-070040 | Buy now |
| 36 | 60V8215100 Fuse (100A) Go to P/N) PEO-OM-070040 | Buy now |
| 37 | 68F8195A00 Relay assembly | Buy now |
| 38 | 67F8215100 Fuse | Buy now |
| 39 | 67F8215110 Fuse | Buy now |
| 40 | 68F8284600 Screw, pan head (m5) | Buy now |
| 41 | 9778050620 Screw, tapping | Buy now |
| 42 | 60V8554400 Case | Buy now |
| 43 | 67F2812A00 Puller, fuse | Buy now |
| 44 | 60V8215700 Damper | Buy now |
| 45 | 60V8133600 Grommet | Buy now |
| 46 | 60V8133610 Grommet | Buy now |
| 47 | 60V8112800 Clamp | Buy now |
| 49 | 60V8194210 Cover | Buy now |
| 50 | 9046408004 Clamp | Buy now |

Electrical 3



F3


| Ref | Part | |
|-----|--|-------------------------|
| 51 | 60V8217600 Damper | Buy now |
| 53 | 9016905M00 Screw truss head tapping | Buy now |
| 54 | 65L8588600 Thermosensor | Buy now |
| 55 | 60V8555300 Nut Rotor | Buy now |
| 56 | 9020112M34 Washer (692) | Buy now |
| 57 | 60V8191900 Graphic, Regulator <i>Go to P/N) PE0-OM-070040</i> | Buy now |
| 58 | 60V8191910 Graphic, regulator | Buy now |
| 59 | 69J8194900 Wire, lead (isolator, 3.8m) AP | Buy now |



60V1010-3190

F6


| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V8258800 Plate | Buy now |
| 2 | 9709506012 Bolt(gh1) | Buy now |
| 3 | 9299506600 Washer, plain (646) | Buy now |
| 4 | 61A8579000 Thermosensor assembly | Buy now |
| 5 | 9299010600 Washer, plate | Buy now |
| 6 | 61A8589500 Crank position sender | Buy now |
| 7 | 9788505012 Screw,pan head (646) | Buy now |
| 8 | 6888256010 Thermo switch assembly | Buy now |
| 9 | 9044610M87 Hose | Buy now |



E1


| Ref | Part | |
|-----|---|-------------------------|
| 1 | 61A2431300 Pipe 3 | Buy now |
| 2 | 9044713008 Hose, with spring | Buy now |
| 3 | 9046413M34 Clamp(6r3) | Buy now |
| 4 | 9044513M17 Hose(l2700) | Buy now |
| 5 | 6R32437700 Pipe, joint 3 | Buy now |
| 6 | 6E58259400 Clamp | Buy now |
| 7 | 9046511M10 Clamp | Buy now |
| 8 | 68F2456010 Filter assembly | Buy now |
| 9 | 68F2456210 Cup, filter | Buy now |
| 10 | 68F2451910 Clip | Buy now |
| 11 | 68F2446910 Float Water Level | Buy now |
| 12 | 65L2453101 Nut | Buy now |
| 13 | 61A2456400 O-ring | Buy now |
| 14 | 68F2456310 Element, filter | Buy now |
| 15 | 65L2456400 Gasket | Buy now |

Fuel



E1


| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60H2455800 Holder, filter | Buy now |
| 17 | 9759506416 Bolt, with washer(62x) | Buy now |
| 18 | 9020106068 Washer,plate (6k8) | Buy now |
| 19 | 68F2456600 Bracket, filter | Buy now |
| 20 | 9759506514 Bolt(gj3) | Buy now |
| 21 | 9038706M60 Collar (6h3) | Buy now |
| 22 | 9048010M23 Grommet(6k7) | Buy now |
| 23 | 9011906M88 Bolt, with washer | Buy now |
| 24 | 68F2431100 Pipe, Fuel 1 | Buy now |
| 26 | 6E52437800 Pipe, joint 3 | Buy now |
| 27 | 6G52431500 Pipe 5 | Buy now |
| 28 | 9044719004 Hose, with spring | Buy now |
| 29 | 6E52431500 Pipe 5 | Buy now |
| 30 | 6E52441004 Fuel pump assembly | Buy now |
| 31 | 6E52444401 Screw | Buy now |



E1


| Ref | Part | |
|-----|---|-------------------------|
| 32 | 6E52441301 Body 2 | Buy now |
| 33 | 6E52447101 Diaphragm | Buy now |
| 34 | 6E52443501 Gasket, body 2 | Buy now |
| 35 | 6E52441101 Diaphragm | Buy now |
| 36 | 6482442400 Seat,spring | Buy now |
| 37 | 6E52442300 Spring, diaphragm | Buy now |
| 38 | 6E52441211 Body 1 | Buy now |
| 39 | 6A02442101 Valve, check | Buy now |
| 40 | 6A01432500 Screw, pan head | Buy now |
| 41 | 9538003600 Nut (6g8) | Buy now |
| 42 | 6E52449200 Bush, fuel pump | Buy now |
| 43 | 6E52448600 O-ring | Buy now |
| 44 | 65024431A0 Gasket,fuel pump | Buy now |
| 45 | 9011006128 Bolt, hexagon socket head | Buy now |
| 46 | 6G52431610 Pipe 6 | Buy now |

Fuel



| Ref | Part | |
|-----|---|-------------------------|
| 47 | 6E52431300 Pipe 3 | Buy now |
| 50 | 9044715002 Hose With Spring | Buy now |
| 51 | 9044615M07 Hose(6g4) | Buy now |
| 52 | 9044513M12 Hose (L235) | Buy now |
| 54 | 61H2819R31 Tag Warning | Buy now |
| 55 | 68F2810000 Tool kit | Buy now |
| 56 | 6D02819973D0 Om z-lz250d/lz-z300a '06 UR (NL) | Buy now |
| 56 | 6D02819973E0 Om z-lz250d/lz-z300a '06 UR (E) | Buy now |
| 56 | 6D02819973F0 Om z-lz250d/lz-z300a '06 UR (F) | Buy now |
| 56 | 6D02819973G0 Om z-lz250d/lz-z300a '06 UR (D) | Buy now |
| 56 | 6D02819973H0 Om z-lz250d/lz-z300a '06 UR (I) | Buy now |
| 56 | 6D02819973S0 Om z-lz250d/lz-z300a '06 UR (ES) | Buy now |
| 57 | 6D02819983K0 Om z-lz250d/lz-z300a '06 UR (DK) | Buy now |
| 57 | 6D02819983L0 Om z-lz250d/lz-z300a '06 UR (SF) | Buy now |
| 57 | 6D02819983M0 Om z-lz250d/lz-z300a '06 UR (S) | Buy now |


Fuel



E1

| Ref | Part | |
|-----|---|-------------------------|
| 57 | 6D02819983N0 Om z-lz250d/lz-z300a '06 UR (N) | Buy now |
| 57 | 6D02819983P0 Om z-lz250d/lz-z300a '06 UR (P) | Buy now |
| 57 | 6D02819983R0 Om z-lz250d/lz-z300a '06 UR (GR) | Buy now |


Fuel Injection Nozzle



C7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 68F1376700 Cap, injector | Buy now |
| 2 | 9011908M60 Bolt (682) | Buy now |
| 3 | 60V1378200 Stay | Buy now |
| 4 | 9038708M31 Collar | Buy now |
| 5 | 9011008M04 Bolt, hexagon socket head | Buy now |
| 6 | 60V1316100 Pipe Delivery 1 | Buy now |
| 7 | 60V1317100 Pipe Delivery 2 | Buy now |
| 8 | 60V1389800 Holder | Buy now |
| 9 | 68F2455100 Bolt, joint | Buy now |
| 10 | 68F2457600 Washer | Buy now |
| 11 | 60V1376100 Injector assembly | Buy now |
| 12 | 68F1410B00 Packing kit | Buy now |
| 13 | 60V1426400 Collar | Buy now |
| 14 | 65L1456500 Screw | Buy now |
| 15 | 60V8238900 Plate 2 | Buy now |


Fuel Injection Nozzle



C7

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 60V8239800 Plate 3 | Buy now |
| 17 | 60V8154500 Screw 1 | Buy now |
| 18 | 60V8154600 Screw 2 | Buy now |
| 19 | 60V8238000 Sensor Pressure | Buy now |
| 20 | 68F8238800 Plate | Buy now |
| 21 | 68F8238400 Packing kit | Buy now |
| 22 | 60V1393800 Pipe | Buy now |
| 23 | 60V1397310 Pipe, fuel 3 | Buy now |
| 24 | 68F2466A00 Packing kit | Buy now |
| 25 | 60V1397410 Pipe, fuel 4 | Buy now |
| 27 | 65L1459600 Washer | Buy now |
| 28 | 9048010M23 Grommet(6k7) | Buy now |
| 29 | 9038705M00 Collar(6k7) | Buy now |
| 30 | 60V1397510 Pipe, Fuel 5 | Buy now |
| 32 | 60V1397610 Pipe, fuel 6 | Buy now |


Fuel Injection Nozzle



C7

| Ref | Part | |
|-----|---|-------------------------|
| 34 | 68F1376400 Gasket (t=2.2) | Buy now |
| 35 | 9751308570 Bolt, with washer | Buy now |
| 36 | 9701308090 Bolt, with washer | Buy now |
| 37 | 9290308600 Washer, plain (663) | Buy now |
| 38 | 60V1371600 Collar | Buy now |
| 39 | 9701308055 Bolt, hexagon | Buy now |
| 42 | 9044722004 Hose, with spring | Buy now |
| 43 | 9044715001 Hose, with spring | Buy now |
| 44 | 6D08366P00 Bracket 4 | Buy now |
| 45 | 9759506512 Bolt, hexagon w/w deep recess | Buy now |
| 46 | 9046408004 Clamp | Buy now |


Fuel Injection Pump



C5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V1217000 Camshaft assembly 1 | Buy now |
| 2 | 60V1242400 Plate, Cartridge Inner | Buy now |
| 3 | 9330600001 Brg,r-b 6000 26mm 19g ky | Buy now |
| 4 | 68F1217300 Cap, camshaft 1 | Buy now |
| 5 | 93306001U0 Bearing | Buy now |
| 6 | 68F1222300 Seal | Buy now |
| 7 | 68F1243900 O-ring | Buy now |
| 8 | 60V1217100 Camshaft 1 | Buy now |
| 9 | 68F1222800 Bolt | Buy now |
| 10 | 68F1345500 Plug | Buy now |
| 11 | 68F1347300 O-ring | Buy now |
| 13 | 60V1399300 Cover, control rack | Buy now |
| 14 | 60W1399300 Cover Control Rack | Buy now |
| 15 | 65L1456500 Screw | Buy now |
| 16 | 68F2457900 Washer 2 | Buy now |


Fuel Injection Pump



C5

| Ref | Part | |
|-----|--|-------------------------|
| 17 | 60V1385400 Plate 4 | Buy now |
| 18 | 60V1391000 Fuel Pump assembly | Buy now |
| 19 | 60V1400500 Ring, seal | Buy now |
| 20 | 60V1412600 Gasket | Buy now |
| 21 | 68F2430000 Fuel pipe joint | Buy now |
| 22 | 60V2417800 Bolt 3 | Buy now |
| 23 | 60V2417600 Bolt 1 | Buy now |
| 24 | 60V2437800 Pipe Joint 4 | Buy now |
| 25 | 60V2486400 Tube | Buy now |
| 26 | 60V2510T00 Tube | Buy now |
| 27 | 68F1381510 Joint 1 | Buy now |
| 28 | 68F2466A00 Packing kit | Buy now |
| 29 | 68F1381610 Joint 2 | Buy now |
| 30 | 68F2448600 O-ring | Buy now |
| 32 | 60V1350500 Joint Comp. | Buy now |


Fuel Injection Pump



C5

| Ref | Part | |
|-----|--|-------------------------|
| 34 | 60V1347300 Seal | Buy now |
| 35 | 60V1414800 Pipe | Buy now |
| 36 | 65L2438700 Clip | Buy now |
| 37 | 60V2431200 Pipe 2 | Buy now |
| 38 | 68F2435600 Clip, pipe 1 | Buy now |
| 39 | 60V2431300 Pipe 3 | Buy now |
| 41 | 60V1414900 Pipe | Buy now |
| 43 | 60V2431400 Pipe 4 | Buy now |
| 45 | 60V2431500 Pipe 5 | Buy now |
| 47 | 60V1397200 Pipe, fuel 2 | Buy now |


Fuel Pump Drive Gear



B7

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V115980094 Bracket, tensioner | Buy now |
| 2 | 9701308055 Bolt, hexagon | Buy now |
| 3 | 9290308600 Washer, plain (663) | Buy now |
| 4 | 60V1159000 Tensioner assembly | Buy now |
| 5 | 9011910M72 Bolt, with washer(6m6) | Buy now |
| 6 | 60V1211300 Spring Valve Inner | Buy now |
| 7 | 9044515002 Hose (l30) | Buy now |
| 8 | 60V1159500 Plate, valve | Buy now |
| 9 | 9701308012 Bolt(62e) | Buy now |
| 10 | 60V4624100 Belt | Buy now |
| 11 | 68F115790194 Coupling, flywheel | Buy now |
| 13 | 68F115360094 Gear, drive | Buy now |
| 14 | 9360510108 Pin, dowel (8g8) | Buy now |
| 15 | 60V1155700 Washer 1 | Buy now |
| 16 | 9020108M00 Washer, plate(6e0) | Buy now |

Fuel Pump Drive Gear




60V2100-C060

B7

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 9709508025 Bolt (62g) | Buy now |
| 18 | 68F115370094 Gear, driven | Buy now |
| 19 | 9028003M01 Key woodruff 146115450000 | Buy now |
| 20 | 9570708600 Nut, flange(jn5) | Buy now |


Generator



E4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V8145000 Rotor assembly | Buy now |
| 2 | 60V8141002 Stator assembly | Buy now |
| 3 | 60V8558010 Coil, pulser | Buy now |
| 4 | 61A8372100 Cover | Buy now |
| 5 | 9011006127 Bolt, hexagon socket head | Buy now |
| 6 | 9788505030 Ybs86-530 screw,panhead | Buy now |
| 7 | 9299505100 Ybs67-5 washer, spring | Buy now |
| 8 | 9299505600 Washer, plain (646) | Buy now |
| 9 | 9028005015 Key, woodruff | Buy now |
| 10 | 9017024M22 Nut(61a) | Buy now |
| 11 | 9020125M02 Washer, plate(61a) | Buy now |
| 12 | 60V8133200 Plate Timing | Buy now |
| 13 | 9788506010 Screw pan head | Buy now |
| 14 | 9299506600 Washer, plain (646) | Buy now |
| 15 | 9046506M86 Clamp | Buy now |


Generator



E4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60V8133701 Cover, flywheel | Buy now |
| 17 | 6D08351310 Damper | Buy now |
| 18 | 6D08351300 Damper | Buy now |
| 19 | 6C58231700 Damper, ignition coil | Buy now |
| 20 | 9038706119 Collar | Buy now |
| 21 | 6A08231700 Damper, ignition coil | Buy now |
| 22 | 9589506030 Bolt, flange deep recess | Buy now |
| 23 | 60V1448800 Label, caution | Buy now |
| 24 | 6A18362551 Mark 5 | Buy now |
| 25 | 6A18362541 Mark 5 | Buy now |
| 26 | 6E58571160 Mark Caution | Buy now |
| 27 | 6K18362341 Mark 3 | Buy now |
| 28 | 6K18362350 Mark 3 | Buy now |


Intake



D2

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V1361000 Reed valve assembly | Buy now |
| 2 | 60VW000400 Reed set | Buy now |
| 3 | 60V13621A0 Gasket, Valve Seat | Buy now |
| 4 | 9788005016 Screw, pan head(6b0) | Buy now |
| 5 | 9299005600 Washer, plain (646) | Buy now |
| 6 | 60V13624001S Plate Reed Valve | Buy now |
| 7 | 60V1355200 Nozzle | Buy now |
| 8 | 60V1357200 Nozzle | Buy now |
| 9 | 60V1137900 Valve, check | Buy now |
| 10 | 6F61137001 Check valve assembly | Buy now |
| 11 | 9044507M03 Hose (I200) | Buy now |
| 12 | 9044507016 Hose (I60) | Buy now |
| 13 | 9044507015 Hose (I65) | Buy now |
| 14 | 60V1136900 Valve Check | Buy now |
| 15 | 6501137001 Check valve assembly | Buy now |


Intake



D2

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9010506028 Bolt, washer based | Buy now |
| 17 | 60V1364600 Gasket, manifold 2 | Buy now |
| 18 | 60V1364500 Gasket, manifold 1 | Buy now |
| 19 | 9701306060 Bolt, hexagon | Buy now |
| 20 | 9290306600 Washer, plain (646) | Buy now |
| 21 | 9567006660 Bolt, stud | Buy now |
| 22 | 9017906M24 Nut(6j8) | Buy now |
| 23 | 60V1444000 Silencer assembly, intake | Buy now |
| 24 | 60V1447600 Seal | Buy now |
| 25 | 9044507M44 Hose (i390) | Buy now |
| 26 | 9015906M16 Screw, with washer(61a) | Buy now |
| 27 | 68F1111900 Hanger, engine | Buy now |
| 28 | 9011906MA2 Bolt, with washer | Buy now |


Lower Casing & Drive 1



C7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V45300208D Lower unit assembly X (25.1"),RH | Buy now |
| 2 | 60V45301008D Casing Lower | Buy now |
| 3 | 9331183280 Ball bearing | Buy now |
| 4 | 93332000W1 Bearing(61a) | Buy now |
| 5 | 61A4556700 Shim (t:0.10mm) UR | Buy now |
| 5 | 61A4556710 Shim (t:0.12mm) UR | Buy now |
| 5 | 61A4556720 Shim (t:0.15mm) UR | Buy now |
| 5 | 61A4556730 Shim (t:0.18mm) UR | Buy now |
| 5 | 61A4556740 Shim (t:0.30mm) UR | Buy now |
| 5 | 61A4556750 Shim (t:0.40mm) UR | Buy now |
| 5 | 61A4556760 Shim (t:0.50mm) UR | Buy now |
| 6 | 6634436600 Damper, water seal 2 | Buy now |
| 7 | 9034008002 Plug, straight screw | Buy now |
| 8 | 6884534110 Plug, drain | Buy now |
| 9 | 9043008020 Gasket | Buy now |


Lower Casing & Drive 1



C7

| Ref | Part | |
|-----|---|-------------------------|
| 10 | 61A453760094 Guide, seal damper | Buy now |
| 11 | 61A4532101 Plate | Buy now |
| 12 | 9321064488 93210-64488 | Buy now |
| 13 | 9310609014 Oil seal | Buy now |
| 14 | 9011906M10 Bolt, with washer | Buy now |
| 15 | 60V4415000 Shift cam assembly | Buy now |
| 16 | 9900108600 Circlip(2r6) | Buy now |
| 17 | 9050111M10 Spring, compression (663) | Buy now |
| 18 | 61A4431101 Housing, water pump | Buy now |
| 19 | 61A4432202 Insert, cartridge | Buy now |
| 20 | 9321086M38 O-ring (6e5) | Buy now |
| 21 | 9321037160 O-ring (6g8) | Buy now |
| 22 | 6E54436500 Damper, water seal 1 | Buy now |
| 23 | 6E54431200 Cover, water pump housing | Buy now |
| 24 | 6E54435201 Impeller | Buy now |


Lower Casing & Drive 1



C7

| Ref | Part | |
|-----|---|-------------------------|
| 25 | 9028004M05 Key, woodruff (6e5) | Buy now |
| 26 | 61A4553800 Spacer, 1 | Buy now |
| 27 | 61A4552700 Collar, drive shaft | Buy now |
| 28 | 9020122M01 Washer, plate(61a) | Buy now |
| 29 | 9020622M19 Washer, wave(61a) | Buy now |
| 30 | 6G54432300 Outer plate, cartridge | Buy now |
| 31 | 6E544315A0 Gasket,water pump | Buy now |
| 32 | 9360612019 Pin, dowel (614) | Buy now |
| 33 | 9011908M14 Bolt, with washer | Buy now |
| 34 | 61A453310094 Housing, bearing | Buy now |
| 35 | 9310128M16 Oil seal (6e5) | Buy now |
| 36 | 93317330U2 Bearing, cylindrical(6k0) | Buy now |
| 37 | 61A4558700 Shim (t:0.10mm) UR | Buy now |
| 37 | 61A4558710 Shim (t:0.12mm) UR | Buy now |
| 37 | 61A4558720 Shim (t:0.15mm) UR | Buy now |


Lower Casing & Drive 1



C7

| Ref | Part | |
|-----|---|-------------------------|
| 37 | 61A4558730 Shim (t:0.18mm) UR | Buy now |
| 37 | 61A4558740 Shim (t:0.30mm) UR | Buy now |
| 37 | 61A4558750 Shim (t:0.40mm) UR | Buy now |
| 37 | 61A4558760 Shim (t:0.50mm) UR | Buy now |
| 38 | 93341930U9 Bearing | Buy now |
| 39 | 9321055M14 O-ring (70e) | Buy now |
| 40 | 6E54534400 Cover, oil seal | Buy now |
| 41 | 9709508025 Bolt (62g) | Buy now |
| 42 | 9299508600 Washer, plain (663) | Buy now |
| 43 | 60V4550120 - X (25.1") | Buy now |
| 44 | 60V4555100 Pinion | Buy now |
| 45 | 9020116M00 Washer, plate(6t5) | Buy now |
| 46 | 9017016M19 Nut(6t5) | Buy now |
| 47 | 60V4556000 Gear | Buy now |
| 48 | 60V4561100 Shaft, propeller | Buy now |


Lower Casing & Drive 1



C7

| Ref | Part | |
|-----|--|-------------------------|
| 49 | 61A4564102 Shifter | Buy now |
| 50 | 61A4563401 Slide, shift | Buy now |
| 51 | 61A4563200 Pin, cross | Buy now |
| 52 | 60V4563100 Clutch, dog | Buy now |
| 53 | 61A4563300 Ring, cross pin | Buy now |
| 54 | 6H14566800 Shaft, free 1 | Buy now |
| 55 | 61A4563500 Plunger, shift | Buy now |
| 56 | 9020102M00 Washer, plate(61a) | Buy now |
| 57 | 9018302M03 Nut, spring (6h1) | Buy now |
| 58 | 9050110M77 Spring, compression(61a) | Buy now |
| 59 | 9350104011 Ball | Buy now |
| 60 | 60V453320094 Housing, bearing | Buy now |
| 61 | 9959010114 Pin, dowel | Buy now |
| 62 | 93306210U0 Bearing(61a) | Buy now |
| 63 | 61A4557100 Gear | Buy now |


Lower Casing & Drive 1



| Ref | Part | |
|-----|---|-------------------------|
| 64 | 9020131M00 Washer, plate(61a) | Buy now |
| 65 | 61A4557700 Shim (t:0.10mm) UR | Buy now |
| 65 | 61A4557710 Shim (t:0.12mm) UR | Buy now |
| 65 | 61A4557720 Shim (t:0.15mm) UR | Buy now |
| 65 | 61A4557730 Shim (t:0.18mm) UR | Buy now |
| 65 | 61A4557740 Shim (t:0.30mm) UR | Buy now |
| 65 | 61A4557750 Shim (t:0.40mm) UR | Buy now |
| 65 | 61A4557760 Shim (t:0.50mm) UR | Buy now |
| 66 | 9331543061 Bearing | Buy now |
| 67 | 9310130M17 Oil seal (6e5) | Buy now |
| 68 | 9321104384 O-ring (705) | Buy now |
| 69 | 9010508049 Bolt, flange | Buy now |
| 70 | 9020108023 Washer, plate | Buy now |
| 71 | 9370009M00 Nipple, grease(6t4) | Buy now |
| 72 | 69J45361008D Cap, lower casing | Buy now |


Lower Casing & Drive 1

| Ref | Part | |
|-----|---|-------------------------|
| 73 | 9709508020 Bolt, hexagon | Buy now |




C7

Lower Casing & Drive 2



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6E54436600 Damper, water seal 2 | Buy now |
| 2 | 61A4436120 Tube, water X (25.1") | Buy now |
| 3 | 6E54436500 Damper, water seal 1 | Buy now |
| 4 | 9360812M05 Pin, dowel b (6e5) | Buy now |
| 5 | 9709510045 Bolt(64d) | Buy now |
| 6 | 9299510100 Ybs67-10 washer, spring | Buy now |
| 7 | 9299510600 Washer, plate | Buy now |
| 8 | 9011910MA2 Bolt, with washer | Buy now |
| 9 | 61A4537500 Damper, seal | Buy now |
| 10 | 61A4521410 Cover, water inlet 1 | Buy now |
| 11 | 61A4521510 Cover, water inlet 2 | Buy now |
| 12 | 9015205003 Screw, countersunk | Buy now |
| 13 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 14 | 69L4537100 Tab-trim | Buy now |
| 15 | 9010510M00 Bolt, hexagon (663) | Buy now |


Lower Casing & Drive 2



| Ref | Part | |
|-----|--|-------------------------|
| 16 | 69J4598700 Spacer 1 | Buy now |
| 17 | 6884599701 Spacer 2 | Buy now |
| 18 | 9299018200 Washer (6e5) | Buy now |
| 19 | 9017118M04 Nut, castle (6e5) | Buy now |
| 20 | 9149040030 Pin, cotter (663) | Buy now |
| 21 | 61A459720098 Propeller (3x14-1/2"x21"-t) UR | Buy now |
| 21 | 61A459740098 Propeller (3x14-1/2"x19"-t) UR | Buy now |
| 21 | 61A459780098 Propeller (3x15"x17"-t) UR | Buy now |
| 21 | 6G5459700298 Propeller (3x15-1/4 x15 -m) UR | Buy now |
| 21 | 6G5459720298 Propeller (3x13-3/4 x21 -m) UR | Buy now |
| 21 | 6G5459740398 Propeller (3x13-3/4"x19"-m2) UR | Buy now |
| 21 | 6G5459780398 Propeller (3x13-3/4"x17"-m2) UR | Buy now |
| 21 | 6R445970A1 Propeller (3X15-1/4"X19"-M) UR | Buy now |
| 21 | 6R445972A0 Propeller (3X14-7/8"X21"-M) UR | Buy now |
| 21 | 6R445974A0 Propeller (3X14-1/2"X23"-M) UR | Buy now |


Lower Casing & Drive 2

| Ref | Part | |
|-----|---|-------------------------|
| 21 | 6R445976A0 Propeller (3X14-1/2"X15"-M) UR | Buy now |
| 21 | 6R445978A0 Propeller (3X15-1/4"X17"-M) UR | Buy now |




D4

Lower Casing & Drive 3



| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60W45300208D Lower Unit assembly X (25.1"),LH | Buy now |
| 2 | 60V45301008D Casing Lower | Buy now |
| 3 | 9331183280 Ball bearing | Buy now |
| 4 | 61B4553801 Spacer 1 | Buy now |
| 5 | 93315660W3 Bearing, cylindrical(61b) | Buy now |
| 6 | 93341670V0 Bearing, thrust (61b) | Buy now |
| 7 | 61A4556700 Shim (t:0.10mm) UR | Buy now |
| 7 | 61A4556710 Shim (t:0.12mm) UR | Buy now |
| 7 | 61A4556720 Shim (t:0.15mm) UR | Buy now |
| 7 | 61A4556730 Shim (t:0.18mm) UR | Buy now |
| 7 | 61A4556740 Shim (t:0.30mm) UR | Buy now |
| 7 | 61A4556750 Shim (t:0.40mm) UR | Buy now |
| 7 | 61A4556760 Shim (t:0.50mm) UR | Buy now |
| 8 | 6634436600 Damper, water seal 2 | Buy now |
| 9 | 9034008002 Plug, straight screw | Buy now |


Lower Casing & Drive 3



D6

| Ref | Part | |
|-----|---|-------------------------|
| 10 | 6884534110 Plug, drain | Buy now |
| 11 | 9043008020 Gasket | Buy now |
| 12 | 61A453760094 Guide, seal damper | Buy now |
| 13 | 61A4532101 Plate | Buy now |
| 14 | 9321064488 93210-64488 | Buy now |
| 15 | 9310609014 Oil seal | Buy now |
| 16 | 9011906M10 Bolt, with washer | Buy now |
| 17 | 60W4415000 Shift cam assembly | Buy now |
| 18 | 9900108600 Circlip(2r6) | Buy now |
| 19 | 9050111M10 Spring, compression (663) | Buy now |
| 20 | 61A4431101 Housing, water pump | Buy now |
| 21 | 61A4432202 Insert, cartridge | Buy now |
| 22 | 9321086M38 O-ring (6e5) | Buy now |
| 23 | 9321037160 O-ring (6g8) | Buy now |
| 24 | 6E54436500 Damper, water seal 1 | Buy now |


Lower Casing & Drive 3



D6


| Ref | Part | |
|-----|---|-------------------------|
| 25 | 6E54431200 Cover, water pump housing | Buy now |
| 26 | 6E54435201 Impeller | Buy now |
| 27 | 9028004M05 Key, woodruff (6e5) | Buy now |
| 28 | 61A4553800 Spacer, 1 | Buy now |
| 29 | 61A4552700 Collar, drive shaft | Buy now |
| 30 | 9020122M01 Washer, plate(61a) | Buy now |
| 31 | 9020622M19 Washer, wave(61a) | Buy now |
| 32 | 6G54432300 Outer plate, cartridge | Buy now |
| 33 | 6E544315A0 Gasket,water pump | Buy now |
| 34 | 9360612019 Pin, dowel (614) | Buy now |
| 35 | 9011908M14 Bolt, with washer | Buy now |
| 36 | 61A453310094 Housing, bearing | Buy now |
| 37 | 9310128M16 Oil seal (6e5) | Buy now |
| 38 | 93317330U2 Bearing, cylindrical(6k0) | Buy now |
| 39 | 61A4558700 Shim (t:0.10mm) UR | Buy now |

Lower Casing & Drive 3



| Ref | Part | |
|-----|---|-------------------------|
| 39 | 61A4558710 Shim (t:0.12mm) UR | Buy now |
| 39 | 61A4558720 Shim (t:0.15mm) UR | Buy now |
| 39 | 61A4558730 Shim (t:0.18mm) UR | Buy now |
| 39 | 61A4558740 Shim (t:0.30mm) UR | Buy now |
| 39 | 61A4558750 Shim (t:0.40mm) UR | Buy now |
| 39 | 61A4558760 Shim (t:0.50mm) UR | Buy now |
| 40 | 93341930U9 Bearing | Buy now |
| 41 | 9321055M14 O-ring (70e) | Buy now |
| 42 | 6E54534400 Cover, oil seal | Buy now |
| 43 | 9709508025 Bolt (62g) | Buy now |
| 44 | 9299508600 Washer, plain (663) | Buy now |
| 45 | 60V4550120 - X (25.1") | Buy now |
| 46 | 60V4555100 Pinion | Buy now |
| 47 | 9020116M00 Washer, plate(6t5) | Buy now |
| 48 | 9017016M19 Nut(6t5) | Buy now |


Lower Casing & Drive 3



D6


| Ref | Part | |
|-----|--|-------------------------|
| 49 | 60W4556001 Gear | Buy now |
| 50 | 9331762891 Bearing | Buy now |
| 51 | 9345037097 Circlip | Buy now |
| 52 | 69K4561100 Shaft, propeller | Buy now |
| 53 | 61B4564101 Shifter | Buy now |
| 54 | 61A4563401 Slide, shift | Buy now |
| 55 | 61A4563200 Pin, cross | Buy now |
| 56 | 60V4563100 Clutch, dog | Buy now |
| 57 | 61A4563300 Ring, cross pin | Buy now |
| 58 | 6H14566800 Shaft, free 1 | Buy now |
| 59 | 61A4563500 Plunger, shift | Buy now |
| 60 | 9020102M00 Washer, plate(61a) | Buy now |
| 61 | 9018302M03 Nut, spring (6h1) | Buy now |
| 62 | 9050110M77 Spring, compression(61a) | Buy now |
| 63 | 9350104011 Ball | Buy now |

Lower Casing & Drive 3



| Ref | Part | |
|-----|---|-------------------------|
| 64 | 60W453320094 Housing, bearing | Buy now |
| 65 | 9959010114 Pin, dowel | Buy now |
| 66 | 9333200048 Bearing(6k0) | Buy now |
| 67 | 60W4557100 Gear | Buy now |
| 68 | 93341440U5 Bearing, thrust (6k0) | Buy now |
| 69 | 6K14557801 Shim (t:0.10mm) UR | Buy now |
| 69 | 6K14557810 Shim (t:0.12mm) UR | Buy now |
| 69 | 6K14557820 Shim (t:0.15mm) UR | Buy now |
| 69 | 6K14557830 Shim (t:0.18mm) UR | Buy now |
| 69 | 6K14557840 Shim (t:0.30mm) UR | Buy now |
| 69 | 6K14557850 Shim (t:0.40mm) UR | Buy now |
| 69 | 6K14557860 Shim (t:0.50mm) UR | Buy now |
| 70 | 61B4538300 Washer, claw | Buy now |
| 71 | 69K4538400 Nut | Buy now |
| 72 | 69K4557700 Shim (t:0.10mm) UR | Buy now |


Lower Casing & Drive 3



D6

| Ref | Part | |
|-----|---|-------------------------|
| 72 | 69K4557710 Shim (t:0.12mm) UR | Buy now |
| 72 | 69K4557720 Shim (t:0.15mm) UR | Buy now |
| 72 | 69K4557730 Shim (t:0.18mm) UR | Buy now |
| 72 | 69K4557740 Shim (t:0.30mm) UR | Buy now |
| 72 | 69K4557750 Shim (t:0.40mm) UR | Buy now |
| 72 | 69K4557760 Shim (t:0.50mm) UR | Buy now |
| 73 | 9331543061 Bearing | Buy now |
| 74 | 9310130M17 Oil seal (6e5) | Buy now |
| 75 | 9321104384 O-ring (705) | Buy now |
| 76 | 9010508049 Bolt, flange | Buy now |
| 77 | 9020108023 Washer, plate | Buy now |
| 78 | 9370009M00 Nipple, grease(6t4) | Buy now |
| 79 | 69J45361008D Cap, lower casing | Buy now |
| 80 | 9709508020 Bolt, hexagon | Buy now |

Lower Casing & Drive 4




 60W1100-3320

E3

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6E54436600 Damper, water seal 2 | Buy now |
| 2 | 61A4436120 Tube, water X (25.1") | Buy now |
| 3 | 6E54436500 Damper, water seal 1 | Buy now |
| 4 | 9360812M05 Pin, dowel b (6e5) | Buy now |
| 5 | 9709510045 Bolt(64d) | Buy now |
| 6 | 9299510100 Ybs67-10 washer, spring | Buy now |
| 7 | 9299510600 Washer, plate | Buy now |
| 8 | 9011910MA2 Bolt, with washer | Buy now |
| 9 | 61A4537500 Damper, seal | Buy now |
| 10 | 61A4521410 Cover, water inlet 1 | Buy now |
| 11 | 61A4521510 Cover, water inlet 2 | Buy now |
| 12 | 9015205003 Screw, countersunk | Buy now |
| 13 | 9018505002 Nut nylon (sus)(ex4) | Buy now |
| 14 | 69L4537100 Tab-trim | Buy now |
| 15 | 9010510M00 Bolt, hexagon (663) | Buy now |

Lower Casing & Drive 4




| Ref | Part | |
|-----|---|-------------------------|
| 16 | 69J4598700 Spacer 1 | Buy now |
| 17 | 6884599701 Spacer 2 | Buy now |
| 18 | 9299018200 Washer (6e5) | Buy now |
| 19 | 9017118M04 Nut, castle (6e5) | Buy now |
| 20 | 9149040030 Pin, cotter (663) | Buy now |
| 21 | 61B459720098 Propeller (ss 3x14-1/2"x21"-tl) UR | Buy now |
| 21 | 61B459740098 Propeller (3x14-1/2"x19"-tl) UR | Buy now |
| 21 | 61B459780098 Propeller (3x5"x17"-tl) UR | Buy now |
| 21 | 6K1459700198 Propeller (3x15-1/4"x15"-ml) UR | Buy now |
| 21 | 6K1459720198 Propeller (3x13-3/4"x21"-ml) UR | Buy now |
| 21 | 6K1459740298 Propeller (3x13-3/4"x19"-ml1) UR | Buy now |
| 21 | 6K1459780298 Propeller (3x13-3/4"x17"-ml1) UR | Buy now |
| 21 | 6R145970A1 Propeller (3X15-1/4"X19"-MI) UR | Buy now |
| 21 | 6R145972A0 Propeller (3X14-7/8"X21"-MI) UR | Buy now |
| 21 | 6R145974A0 Propeller (3X14-1/2"X23"-MI) UR | Buy now |

Lower Casing & Drive 4

| Ref | Part | |
|-----|--|-------------------------|
| 21 | 6R145976A0 Propeller (3X15-1/4"X15"-MI) UR | Buy now |
| 21 | 6R145978A0 Propeller (3X15-1/4"x17"-MI) UR | Buy now |


COUNTER ROTATION



60W1100-3320

E3

Meter




6P22300-E360

E7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 6Y78366000 Water pressure meter assembly AP | Buy now |
| 2 | 6Y58351800 Bulb (12v-1.7w) t6.5 | Buy now |
| 3 | 6Y58353600 Socket, meter | Buy now |
| 4 | 6888366400 Damper | Buy now |
| 5 | 6888366500 Plate, fitting | Buy now |
| 6 | 6888366700 Sender AP | Buy now |


Oil Pump



D4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V1320012 Oil injection pump assembly | Buy now |
| 2 | 6R31347100 Screw | Buy now |
| 3 | 6L21347500 Gasket, breather bolt | Buy now |
| 4 | 9321019M82 O-ring(6j8) | Buy now |
| 5 | 9010906M40 Bolt(6h0) | Buy now |
| 6 | 6G51341600 Pipe, oil 1 | Buy now |
| 7 | 9044617MA8 Hose (L200) | Buy now |
| 8 | 9046511M10 Clamp | Buy now |
| 9 | 9044607M35 Hose(62t) | Buy now |
| 10 | 9044507M96 Hose(62t) | Buy now |
| 11 | 9044607M48 Hose(62t) | Buy now |
| 12 | 9044507M44 Hose (I390) | Buy now |
| 13 | 9044507M46 Hose (I390) | Buy now |
| 14 | 9044507M10 Hose (L770) | Buy now |
| 15 | 9044507M04 Hose(62t) | Buy now |


Oil Pump



D4

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 6R31318310 Valve, check | Buy now |
| 17 | 9046807M02 Clip (6e5) | Buy now |
| 18 | 9046407M05 Clamp (6g5) | Buy now |
| 20 | 9046407M20 Clamp(6h0) | Buy now |
| 21 | 61A1153700 Gear, driven | Buy now |
| 22 | 9020109M01 Washer, plate(61b) | Buy now |
| 23 | 61A1311700 Collar, distance | Buy now |
| 24 | 9321018MA9 O-ring(61a) | Buy now |
| 25 | 6R54123700 Joint, link | Buy now |
| 26 | 65L4124110 - | Buy now |
| 27 | 9538005600 Nut, hexagon (663) | Buy now |
| 28 | 6H14123700 Joint, link | Buy now |
| 29 | 9149012012 Pin, cotter (6g8) | Buy now |
| 30 | 9020205088 Washer, plate (666) | Buy now |
| 31 | 60V2431900 Pipe, oil | Buy now |


Oil Pump



D4

| Ref | Part | |
|-----|--|-------------------------|
| 33 | 9046708M18 Clip | Buy now |
| 34 | 68F1310000 Solenoid pump assembly | Buy now |
| 35 | 68F1341800 Hose 4 | Buy now |
| 36 | 68F1318400 Spring, oil pipe | Buy now |
| 37 | 68F1344000 Filter assembly | Buy now |
| 38 | 68F1316F00 Hose 1 | Buy now |
| 39 | 68F1313300 Clip | Buy now |
| 40 | 68F1316G10 Hose, oil 2 | Buy now |
| 41 | 68F1316A00 Check Valve assembly | Buy now |
| 42 | 68F1341610 Pipe, oil 1 | Buy now |
| 43 | 9044808001 Hose, with union | Buy now |
| 44 | 68F1448500 Pipe, joint | Buy now |
| 45 | 60V1319K00 Plate | Buy now |
| 46 | 9709506020 Bolt(7u8) | Buy now |
| 47 | 9299506100 Washer(6a1) | Buy now |


Oil Pump



| Ref | Part | |
|-----|---|-------------------------|
| 48 | 9299506600 Washer, plain (646) | Buy now |
| 49 | 9011006M06 Bolt, hexagon socket head | Buy now |


D4

Oil Tank



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 61A2175000 Oil tank assembly | Buy now |
| 2 | 6E51344800 Cap, oil tank | Buy now |
| 41 | 9046513M11 Clamp (6e5) AP | Buy now |
| 4 | 61A8573001 Oil level gauge assembly | Buy now |
| 5 | 61A1341100 Strainer, oil | Buy now |
| 6 | 6E51341400 Gasket, strainer cover | Buy now |
| 7 | 9044505M07 Hose (l700) | Buy now |
| 8 | 6A08231700 Damper, ignition coil | Buy now |
| 9 | 9038706119 Collar | Buy now |
| 10 | 9011906M65 Bolt, with washer | Buy now |
| 11 | 6R38259E00 Switch assembly | Buy now |
| 12 | 6E52437900 Pipe, joint 4 | Buy now |
| 13 | 9044512M04 Hose (l3000) | Buy now |
| 14 | 9046511M10 Clamp | Buy now |
| 15 | 6E52432300 Pipe 12 | Buy now |


Oil Tank



D6

| Ref | Part | |
|-----|--|-------------------------|
| 18 | 9046413M34 Clamp(6r3) | Buy now |
| 19 | 61A2170820 Sub oil tank assembly. AP | Buy now |
| 20 | 6E52173320 Sub tank, oil (10.5l) | Buy now |
| 21 | 6E52177003 Oil tank cap assembly | Buy now |
| 22 | 6E52432200 Pipe 11 | Buy now |
| 24 | 6462425102 Strainer 1 | Buy now |
| 25 | 6E52431901 Pipe, oil | Buy now |
| 27 | 6E58190001 Oil feed pump assembly | Buy now |
| 28 | 6E58192200 Grommet | Buy now |
| 29 | 6E52432101 Pipe 10 | Buy now |
| 31 | 9044511M26 Hose (l8000) | Buy now |
| 33 | 6E58572005 Oil level gauge assembly | Buy now |
| 34 | 6R38572180 Wire, lead | Buy now |
| 35 | 6E5217340133 Holder, oil sub tank AP | Buy now |
| 36 | 6E5217980133 Bracket, damper AP | Buy now |


Oil Tank



D6

| Ref | Part | |
|-----|---|-------------------------|
| 37 | 6E52174600 Damper AP | Buy now |
| 38 | 9708006100 Bolt, hexagon AP | Buy now |
| 39 | 9299006600 Washer, plain (646) AP | Buy now |
| 40 | 9538006600 Nut(661) AP | Buy now |


Power Trim & Tilt Assy 1



C1

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V43800004D Power trim & tilt assembly | Buy now |
| 2 | 61A4384001 Power tilt assembly | Buy now |
| 3 | 61A4381000 Tilt piston sub assembly | Buy now |
| 4 | 61A4386100 O-ring | Buy now |
| 5 | 61A4387100 Ring, back up | Buy now |
| 6 | 9310619N50 Oil seal | Buy now |
| 7 | 6H14386100 O-ring | Buy now |
| 8 | 6H14387200 Ring, back up | Buy now |
| 9 | 61A4389H00 O-ring | Buy now |
| 11 | 6H14381400 Piston, free | Buy now |
| 12 | 61A4381301 Cylinder, tilt | Buy now |
| 13 | 69J4388800 Bolt, socket | Buy now |
| 14 | 61A4383501 Pipe | Buy now |
| 15 | 61A4383301 Pipe | Buy now |
| 16 | 61A4381800 Pin, lower shock mount | Buy now |


Power Trim & Tilt Assy 1



C1

| Ref | Part | |
|-----|---|-------------------------|
| 17 | 9038618M14 Bushing (6e5) | Buy now |
| 18 | 6H14381700 Filter 2 | Buy now |
| 19 | 9760704230 Screw, pan head with washer | Buy now |
| 20 | 69J4382800 Body, reservoir | Buy now |
| 21 | 6H14386900 O-ring | Buy now |
| 22 | 61A4384L00 Spring Trim Down | Buy now |
| 23 | 6T44385100 Seat, relief valve | Buy now |
| 24 | 9760705210 Screw, With Washer | Buy now |
| 25 | 61A4384K00 Plate, trim down | Buy now |
| 26 | 61A4384J00 Seal, trim down | Buy now |
| 27 | 93210064A5 O-ring(61a) | Buy now |
| 28 | 9350532038 Ball(7fk) | Buy now |
| 29 | 61A4387500 Ring, snap | Buy now |
| 30 | 61A4384800 Rod, manual release | Buy now |
| 31 | 61A4385400 Spring, manual release | Buy now |


Power Trim & Tilt Assy 1



C1

| Ref | Part | |
|-----|---|-------------------------|
| 32 | 61A4384500 Screw, manual release | Buy now |
| 33 | 6H14387500 Ring, snap | Buy now |
| 34 | 9321018397 O-ring (6g5) | Buy now |
| 35 | 61A4384700 Seat, manual valve | Buy now |
| 36 | 6T44387600 Ring, snap | Buy now |
| 37 | 9321007003 O-ring (11m) | Buy now |
| 38 | 9321006001 O-ring (26h) | Buy now |
| 39 | 6T44384900 Pin, valve support | Buy now |
| 40 | 61A4385H00 Spring, seal | Buy now |
| 41 | 61A4384F00 Seal, main valve | Buy now |
| 42 | 6H14383100 Connector, shaft | Buy now |
| 43 | 6T44383000 Gear pump assembly | Buy now |
| 44 | 61A4382K00 Cap, relief valve | Buy now |
| 45 | 6H14385610 Spring, down relief | Buy now |
| 46 | 6T44384400 Pin, valve support | Buy now |


Power Trim & Tilt Assy 1



C1

| Ref | Part | |
|-----|--|-------------------------|
| 47 | 6T44384G00 Seal, relief valve | Buy now |
| 48 | 6T44385500 Spring, up relief | Buy now |
| 49 | 6T44389500 Seat, relief valve | Buy now |
| 50 | 9321010M74 O-ring | Buy now |
| 51 | 6H14381600 Filter 1 | Buy now |
| 52 | 6T44380203 Valve sub assembly | Buy now |
| 53 | 6H14386600 O-ring | Buy now |
| 54 | 6H14386700 O-ring | Buy now |
| 55 | 6T44384100 Piston, shuttle | Buy now |
| 56 | 9321009165 O-ring | Buy now |
| 57 | 6H14382900 Plug, reservoir | Buy now |
| 58 | 61A4387800 Bolt, socket | Buy now |
| 59 | 6T44387501 Ring, snap | Buy now |
| 60 | 61A4382200 Seal, trim dust | Buy now |
| 61 | 61A4382100 Screw, trim cylinder end | Buy now |


Power Trim & Tilt Assy 1



C1

| Ref | Part | |
|-----|--|-------------------------|
| 62 | 9160910014 Pin, spring(61a) | Buy now |
| 64 | 61A4382010 Trim piston sub assembly | Buy now |
| 65 | 61A4387400 Ring, back up | Buy now |
| 66 | 61A4386400 O-ring | Buy now |
| 67 | 61A4387510 Ring, snap | Buy now |
| 68 | 61A4383H11 Hose, oil 5 | Buy now |
| 69 | 61A4384H10 Spring | Buy now |
| 70 | 61A4387600 Ring, snap | Buy now |
| 71 | 6T44389300 Washer | Buy now |
| 72 | 9350108001 Ball | Buy now |
| 73 | 61A4382A00 Adaptor 1 | Buy now |
| 74 | 69J4388000 Motor assembly REFER TO FIG.26 | Buy now |


Power Trim & Tilt Assy 2



C4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 69J4388000 Motor assembly | Buy now |
| 2 | 9020614N50 Washer, wave | Buy now |
| 3 | 93399999T6 Bearing | Buy now |
| 4 | 69J4380500 Armature assembly | Buy now |
| 5 | 69J4380400 Stator assembly | Buy now |
| 6 | 69J4386100 O-ring | Buy now |
| 7 | 69J4388600 Bolt | Buy now |
| 8 | 69J4388200 Oil seal | Buy now |
| 9 | 69J4389100 Brush 1 | Buy now |
| 10 | 69J4386K00 Spring, brush | Buy now |
| 11 | 69J4388100 Frame, end | Buy now |


Remote Control Box



E6

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 7034820517 Remote control assembly (10p, ptt) AP WITH PT/T SW. | Buy now |
| 2 | 70448207P0 704 twin top mount (mec rc) AP WITH PT/T SW. | Buy now |
| 3 | 7014832050 Cable, Remote Control L=15F UR | Buy now |
| 3 | 7014832060 Cable, Remote Control L=16F UR | Buy now |
| 3 | 7014832080 Cable, Remote Control L=17F UR | Buy now |
| 3 | 7014835000 Cable, Remote Control L=21F UR | Buy now |
| 3 | 7014835020 Cable, Remote Control L=23F UR | Buy now |


Repair Kit 1



F2

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60VW000101 Power head gasket kit | Buy now |
| 2 | 60V1119300 Gasket, head cover 1 | Buy now |
| 3 | 60V1118100 Gasket, cylinder head 1 | Buy now |
| 4 | 9043014115 Gasket (663) | Buy now |
| 5 | 60V1138100 Gasket 1 | Buy now |
| 6 | 60V12414A0 Gasket, cover | Buy now |
| 7 | 60V4111200 Gasket, exhaust inner cover | Buy now |
| 8 | 60V11382A0 Gasket 2 | Buy now |
| 9 | 9310422M07 Oil seal(61a) | Buy now |
| 10 | 9310340011 Oil seal | Buy now |
| 11 | 9321085M32 O-ring (173) | Buy now |
| 12 | 60V1364600 Gasket, manifold 2 | Buy now |
| 13 | 60V1364500 Gasket, manifold 1 | Buy now |
| 14 | 60V1447600 Seal | Buy now |
| 15 | 9321018MA9 O-ring(61a) | Buy now |


Repair Kit 1



F2

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60V13621A0 Gasket, Valve Seat | Buy now |
| 17 | 60V1147900 O-ring | Buy now |
| 18 | 60V4511301 Gasket, upper casing | Buy now |


Repair Kit 2



F3

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60VW000120 Lower unit gasket kit | Buy now |
| 2 | 6D04113400 Gasket, exhaust manifold | Buy now |
| 3 | 60V4511400 Gasket, upper casing | Buy now |
| 4 | 9043008020 Gasket | Buy now |
| 5 | 61A4512301 Gasket, muffler | Buy now |
| 6 | 6E54436500 Damper, water seal 1 | Buy now |
| 7 | 6E54436600 Damper, water seal 2 | Buy now |
| 8 | 9321064488 93210-64488 | Buy now |
| 9 | 9310609014 Oil seal | Buy now |
| 10 | 9321086M38 O-ring (6e5) | Buy now |
| 11 | 9321037160 O-ring (6g8) | Buy now |
| 12 | 6E544315A0 Gasket,water pump | Buy now |
| 13 | 9310128M16 Oil seal (6e5) | Buy now |
| 14 | 9321055M14 O-ring (70e) | Buy now |
| 15 | 9321104384 O-ring (705) | Buy now |


Repair Kit 2



F3

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 9310130M17 Oil seal (6e5) | Buy now |
| 17 | 61AW0078A3 Water pump repair kit | Buy now |
| 18 | 61A4432202 Insert, cartridge | Buy now |
| 21 | 6E54435201 Impeller | Buy now |
| 22 | 6G54432300 Outer plate, cartridge | Buy now |
| 24 | 9360612019 Pin, dowel (614) | Buy now |
| 25 | 9011908M14 Bolt, with washer | Buy now |
| 26 | 9028004M05 Key, woodruff (6e5) | Buy now |


Starting Motor



F7

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60X8180000 Starting motor assembly | Buy now |
| 2 | 67F8185000 Armature assembly | Buy now |
| 3 | 67F8181000 Stator assembly | Buy now |
| 4 | 69J8184000 Brush holder assembly | Buy now |
| 5 | 69J8180100 Brush set | Buy now |
| 6 | 67F8181300 Spring, brush | Buy now |
| 7 | 68F8182000 Rear bracket assembly | Buy now |
| 8 | 67F8180800 Pinion assembly | Buy now |
| 9 | 67F8185700 Pinion stopper set | Buy now |
| 10 | 67F8180700 Gear assembly, starting motor | Buy now |
| 11 | 67F8183200 Clutch, over run | Buy now |
| 12 | 67F8183600 Shaft, pinion | Buy now |
| 13 | 67F8182100 Bracket, center 1 | Buy now |
| 14 | 67F8184100 Bearing | Buy now |
| 15 | 67F8189100 Gear, ring | Buy now |


Starting Motor



F7

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 67F8183R00 Gasket | Buy now |
| 17 | 67F818300 Bracket, center 2 | Buy now |
| 18 | 60V8183T00 Gear, idler | Buy now |
| 19 | 67F8180900 Washer kit | Buy now |
| 20 | 60X8184200 Cover | Buy now |
| 21 | 69J8183900 Lever assembly | Buy now |
| 22 | 69J8194100 Starter relay assembly | Buy now |
| 23 | 69J8186900 Cover Dust | Buy now |
| 24 | 6K78182610 Bolt | Buy now |
| 25 | 69J8182800 Bolt 2 | Buy now |
| 26 | 67F8184600 Screw | Buy now |
| 27 | 9017908003 Nut | Buy now |
| 28 | 60V8192500 Terminal | Buy now |
| 29 | 68F8258200 Cover, wire harness | Buy now |
| 30 | 9701308045 Bolt | Buy now |


Starting Motor



F7

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 9290308600 Washer, plain (663) | Buy now |
| 32 | 67F8362701 Label, caution 7 | Buy now |


Steering Guide



E5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6E56135002 Steering guide attachment kit AP | Buy now |
| 2 | 6E56135101 Rod, steering link | Buy now |
| 3 | 9038710M61 Collar (6e5) | Buy now |
| 4 | 9056012M01 Spacer (6e5) | Buy now |
| 5 | 6E56135500 Bolt | Buy now |
| 6 | 9018509M01 Nut, nylon (663) | Buy now |
| 7 | 9020110M20 Washer, plate (663) | Buy now |
| 8 | 6E54314501 Cap, clamp bracket | Buy now |
| 9 | 9321016275 O-ring | Buy now |
| 10 | 6E56130101 Tie bar assembly (l:600-800mm) AP | Buy now |
| 11 | 6E56131300 Adjuster | Buy now |
| 12 | 6E56131111 Tie bar | Buy now |
| 13 | 6E56131500 Tie bar, 2 | Buy now |
| 14 | 6E56130300 Steering axle comp. | Buy now |
| 15 | 9017014M06 Nut (6e5) | Buy now |


Steering Guide



E5


| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9538014700 Nut (6e5) | Buy now |
| 17 | 9020110M76 Washer, plate (6e5) | Buy now |
| 18 | 9010109M70 Bolt (6e5) | Buy now |
| 19 | 9017009M05 Nut, hexagon (6e5) | Buy now |

Switch & Panel



| Ref | Part | |
|-----|--|-------------------------|
| 1 | 6K18257008 Panel switch assembly AP | Buy now |
| 2 | 6K18257102 Plate, panel switch | Buy now |
| 3 | 6K18251006 Main switch assembly | Buy now |
| 4 | 7038257700 Cap, key | Buy now |
| 5 | 6K18253200 Cap | Buy now |
| 6 | 6K18257500 Engine stop switch assembly | Buy now |
| 7 | 6828255600 Lanyard, stop switch | Buy now |
| 8 | 6K18361401 Bracket | Buy now |
| 9 | 9898005010 Screw, bind(6k1) | Buy now |
| 21 | 9299005100 Ybs67-5 washer, spring AP | Buy now |
| 20 | 9538005600 Nut, hexagon (663) AP | Buy now |
| 12 | 6888338311 Buzzer | Buy now |
| 13 | 6K18583001 Control unit assembly | Buy now |
| 14 | 9898006020 Screw, bind (j17) | Buy now |
| 15 | 9538006600 Nut(661) | Buy now |


Switch & Panel



F1

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9299006100 Washer(6a1) | Buy now |
| 17 | 9299006600 Washer, plain (646) | Buy now |
| 18 | 6K18198000 Diode assembly | Buy now |
| 19 | 9014905M05 Screw(6k0) AP | Buy now |
| 22 | 9299005600 Washer, plain (646) AP | Buy now |
| 23 | 6K18258A40 Extension, wire harness AP (10P) | Buy now |
| 24 | 61B8258A01 Extension, wire harness AP (10P) | Buy now |


Top Cowling



A4

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V42610018D Top cowling assembly | Buy now |
| 2 | 68F426470194 Holder, clamp band | Buy now |
| 3 | 68F426480194 Holder, clamp band | Buy now |
| 4 | 9299006100 Washer(6a1) | Buy now |
| 5 | 9538006600 Nut(661) | Buy now |
| 6 | 68F4266300 Damper 2 | Buy now |
| 7 | 60V4265101 Hook | Buy now |
| 8 | 60V4265200 Hook | Buy now |
| 9 | 9709506016 Bolt, hexagon deep recess | Buy now |
| 10 | 9299506600 Washer, plain (646) | Buy now |
| 11 | 60V42613008D Molding, Air Duct | Buy now |
| 12 | 60V4262100 Mldg Top | Buy now |
| 13 | 9778050616 Screw, pan head tapping (ak5) | Buy now |
| 14 | 60V4266400 Damper | Buy now |
| 15 | 9044511M33 Hose (l700) | Buy now |


Top Cowling



A4

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 60V4268700 Emblem, rear | Buy now |
| 17 | 9046208018 Clamp | Buy now |
| 18 | 9778050612 Screw, tapping(61a) | Buy now |
| 19 | 6D04262700 Damper Form | Buy now |
| 20 | 9017906M24 Nut(6j8) | Buy now |
| 21 | 60V4266200 Damper | Buy now |
| 22 | 60V4267700 Graphic, front | Buy now |
| 23 | 60VW007000 - | Buy now |
| 24 | 60V4268100 Mark, cowling | Buy now |
| 25 | 60V4268200 Mark, cowling | Buy now |
| 26 | 60V4267800 Graphic, front | Buy now |
| 27 | 67F1344800 Cap | Buy now |
| 28 | 6D04262601 Louver 1 | Buy now |
| 29 | 60V4262610 Louver 1 | Buy now |
| 30 | 9016005005 Screw, round tapping | Buy now |


Top Cowling



A4

| Ref | Part | |
|-----|--|-------------------------|
| 31 | 6D04263700 Damper Form | Buy now |
| 32 | 6D04263710 Damper Form | Buy now |
| 33 | 6D04261510 Seal | Buy now |
| 34 | 68F1343400 Label, Caution | Buy now |


Upper Casing



C5

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V45111208D Casing, Upper X (25.1") | Buy now |
| 2 | 6E52437700 Pipe, joint | Buy now |
| 3 | 61A42791S0 Mark 1 | Buy now |
| 4 | 61A42792S0 Mark | Buy now |
| 5 | 61A4515500 Cap | Buy now |
| 6 | 9709506010 Bolt | Buy now |
| 7 | 9299506600 Washer, plain (646) | Buy now |
| 8 | 9360812M05 Pin, dowel b (6e5) | Buy now |
| 9 | 9011908052 Bolt, with washer | Buy now |
| 10 | 61A4537800 Nipple, hose | Buy now |
| 11 | 9011906M17 Bolt, with washer | Buy now |
| 12 | 9360612019 Pin, dowel (614) | Buy now |
| 13 | 9044507MF0 Hose (I1160) X (25.1") | Buy now |
| 14 | 6E58355800 End, nipple | Buy now |
| 15 | 9046511M10 Clamp | Buy now |


Upper Casing



C5

| Ref | Part | |
|-----|--|-------------------------|
| 16 | 6E54531800 Bushing, drive shaft 3 | Buy now |
| 17 | 9342036M01 Circlip (6a0) | Buy now |
| 18 | 60V4511400 Gasket, upper casing | Buy now |
| 19 | 60V411372094 Guide, exhaust | Buy now |
| 21 | 60V4511301 Gasket, upper casing | Buy now |
| 22 | 9011908079 Bolt, with washer | Buy now |
| 23 | 9011908072 Bolt, With Washer | Buy now |
| 24 | 9011908060 Bolt, with washer | Buy now |
| 25 | 6H11137200 Nipple, hose | Buy now |
| 26 | 60V41131035B Manifold, Ext. 1 | Buy now |
| 27 | 9011908056 Bolt With Washer | Buy now |
| 28 | 6D041132005B Manifold, exhaust | Buy now |
| 29 | 6D04113400 Gasket, exhaust manifold | Buy now |
| 30 | 9011908059 Bolt, with washer | Buy now |
| 31 | 60V14711205B Muffler 1 | Buy now |


Upper Casing



| Ref | Part | |
|-----|---|-------------------------|
| 32 | 6E51473700 Damper, muffler | Buy now |
| 33 | 9018305M02 Nut, spring (6e5) | Buy now |
| 34 | 61A4512301 Gasket, muffler | Buy now |

C5


Vapor Separator 1



C1

| Ref | Part | |
|-----|---|-------------------------|
| 1 | 60V2421600 Stay | Buy now |
| 2 | 6D02447300 Screw | Buy now |
| 3 | 60V1498000 Body, float chamber | Buy now |
| 4 | 60V1418201 Cover, float chamber | Buy now |
| 5 | 65L1454600 Valve, needle | Buy now |
| 6 | 66K1498500 Float | Buy now |
| 7 | 66K1454801 Pin, float arm | Buy now |
| 8 | 66K1498400 Gasket, float chamber | Buy now |
| 9 | 65L1412500 Screw | Buy now |
| 10 | 68F1390610 Regulator, pressure | Buy now |
| 11 | 66K1432501 Screw, pan head | Buy now |
| 12 | 60V1416300 Spacer | Buy now |
| 13 | 65L1390500 Filter comp | Buy now |
| 14 | 68F1397100 Pipe, fuel 1 | Buy now |
| 15 | 65L2438700 Clip | Buy now |


Vapor Separator 1



C1

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 65L1496600 Cap | Buy now |
| 17 | 65L2448600 O-ring | Buy now |
| 18 | 60V2425101 Strainer 1 | Buy now |
| 19 | 66K1424500 Screw, guide | Buy now |
| 20 | 68F8250900 Wire, sub lead | Buy now |
| 21 | 65L1422700 Washer | Buy now |
| 22 | 60V1390700 Fuel pump comp. | Buy now |
| 23 | 65L1415900 Clip | Buy now |
| 24 | 68F1378100 Damper, pump | Buy now |
| 25 | 68F1384400 Plate 2 | Buy now |
| 26 | 68F1391500 Filter | Buy now |
| 27 | 65L1416A00 O-ring | Buy now |
| 28 | 66K1427100 Insulator | Buy now |
| 29 | 65L8182A00 Nut | Buy now |
| 30 | 65L8182K00 Nut | Buy now |


Vapor Separator 1



C1

| Ref | Part | |
|-----|---|-------------------------|
| 31 | 65L8182E00 Washer | Buy now |
| 32 | 65L8182F00 Washer | Buy now |
| 33 | 68F1384300 Plate 1 | Buy now |
| 34 | 65L1414700 O-ring | Buy now |
| 35 | 68F1427400 Connector | Buy now |
| 36 | 66K2437600 Pipe, joint 1 | Buy now |
| 37 | 66K2448900 O-ring | Buy now |
| 38 | 68F1427100 Insulator | Buy now |
| 39 | 65L1439700 O-ring | Buy now |
| 40 | 65L1499200 Screw, drain | Buy now |
| 41 | 65L1499700 Seal | Buy now |
| 42 | 60V2437501 Grommet | Buy now |
| 43 | 60V2439701 Collar | Buy now |
| 44 | 66K2457900 Washer 2 | Buy now |
| 45 | 65L2459200 Bolt | Buy now |


Vapor Separator 1



C1

| Ref | Part | |
|-----|--|-------------------------|
| 46 | 65L2416900 Washer, lock | Buy now |
| 47 | 60V8250700 Wire, lead | Buy now |
| 48 | 66K1354200 Hose, vacuum sensing 1 | Buy now |
| 49 | 66K1354400 Hose, Vacuum Sensing 2 | Buy now |
| 50 | 66K1353200 Hose, vacuum sensing 3 | Buy now |
| 51 | 65L2446100 Pipe, joint 4 | Buy now |
| 52 | 66K1353300 Hose, vacuum sensing 4 | Buy now |
| 53 | 65L1389800 Plate 4 | Buy now |
| 54 | 65L1456500 Screw | Buy now |
| 55 | 60V2433901 Grommet | Buy now |
| 56 | 60V1353400 Hose, Vacuum Sensing 5 | Buy now |
| 57 | 6D02486A00 Pipe 1 | Buy now |
| 58 | 6D02486D00 Pipe 2 | Buy now |
| 59 | 9046407M20 Clamp(6h0) | Buy now |
| 60 | 9046511M10 Clamp | Buy now |

Vapor Separator 2




 60X4100-E080

C4

| Ref | Part | |
|-----|--|-------------------------|
| 1 | 60V1375102 Body, throttle 1 | Buy now |
| 2 | 65L1452700 Plate | Buy now |
| 3 | 65L1456500 Screw | Buy now |
| 4 | 65L1433400 Spring, air adjusting | Buy now |
| 5 | 65L1452300 Screw, stop | Buy now |
| 6 | 6K51459200 Screw | Buy now |
| 7 | 9020105552 Washer, plate(65j) | Buy now |
| 8 | 65L1457800 Collar | Buy now |
| 9 | 68F1356800 Stud | Buy now |
| 10 | 61A8588500 Throttle sensor assembly | Buy now |
| 11 | 6K78588601 Bracket | Buy now |
| 12 | 9798505212 Screw, with washer(6g7) | Buy now |
| 13 | 9038705M00 Collar(6k7) | Buy now |
| 14 | 60V8551600 Spacer | Buy now |
| 15 | 60V1459600 Washer | Buy now |

Vapor Separator 2



 60X4100-E080

C4

| Ref | Part | |
|-----|---|-------------------------|
| 16 | 9798505330 Screw, with washer(61b) | Buy now |
| 17 | 65L1457300 Lever | Buy now |
| 18 | 65L1457900 Spring | Buy now |
| 19 | 65L4121700 Rod, accel. lever | Buy now |
| 20 | 6D01459200 Screw | Buy now |

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.