



# Yamaha LZ300AETO 2004

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

|                                     |     |
|-------------------------------------|-----|
| <b>BOTTOM COWLING</b>               | 3   |
| <b>BRACKET 1</b>                    | 8   |
| <b>BRACKET 2</b>                    | 12  |
| <b>CONTROL</b>                      | 15  |
| <b>CRANKSHAFT &amp; PISTON</b>      | 20  |
| <b>CYLINDER &amp; CRANKCASE 1</b>   | 23  |
| <b>CYLINDER &amp; CRANKCASE 2</b>   | 27  |
| <b>CYLINDER &amp; CRANKCASE 3</b>   | 29  |
| <b>ELECTRICAL 1</b>                 | 32  |
| <b>ELECTRICAL 2</b>                 | 35  |
| <b>ELECTRICAL 3</b>                 | 37  |
| <b>ELECTRICAL 4</b>                 | 41  |
| <b>FUEL 1</b>                       | 42  |
| <b>FUEL 2</b>                       | 47  |
| <b>FUEL INJECTION NOZZLE</b>        | 48  |
| <b>FUEL INJECTION PUMP</b>          | 51  |
| <b>FUEL PUMP DRIVE GEAR</b>         | 54  |
| <b>GENERATOR</b>                    | 56  |
| <b>INTAKE</b>                       | 58  |
| <b>LOWER CASING &amp; DRIVE 1</b>   | 60  |
| <b>LOWER CASING &amp; DRIVE 2</b>   | 67  |
| <b>LOWER CASING &amp; DRIVE 3</b>   | 70  |
| <b>LOWER CASING &amp; DRIVE 4</b>   | 77  |
| <b>METER</b>                        | 80  |
| <b>OIL PUMP</b>                     | 82  |
| <b>OIL TANK</b>                     | 86  |
| <b>POWER TRIM &amp; TILT ASSY 1</b> | 89  |
| <b>POWER TRIM &amp; TILT ASSY 2</b> | 94  |
| <b>REMOTE CONTROL BOX</b>           | 95  |
| <b>REPAIR KIT 1</b>                 | 96  |
| <b>REPAIR KIT 2</b>                 | 98  |
| <b>STARTING MOTOR</b>               | 100 |
| <b>STEERING GUIDE</b>               | 103 |
| <b>SWITCH &amp; PANEL</b>           | 105 |
| <b>TOP COWLING</b>                  | 107 |
| <b>UPPER CASING</b>                 | 110 |
| <b>VAPOR SEPARATOR 1</b>            | 113 |
| <b>VAPOR SEPARATOR 2</b>            | 117 |


## Bottom Cowling



A7


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V42710008D</a><br>Bottom cowling assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6E52437700</a><br>Pipe, joint               | <a href="#">Buy now</a> |
| 3   | <a href="#">6D04272700</a><br>Grommet                   | <a href="#">Buy now</a> |
| 4   | <a href="#">68F428280094</a><br>Plate, clamp            | <a href="#">Buy now</a> |
| 5   | <a href="#">68F428281094</a><br>Plate, clamp            | <a href="#">Buy now</a> |
| 6   | <a href="#">9010906M82</a><br>Bolt                      | <a href="#">Buy now</a> |
| 7   | <a href="#">60V42815008D</a><br>Lever Clamp             | <a href="#">Buy now</a> |
| 8   | <a href="#">60V42816008D</a><br>Lever, clamp            | <a href="#">Buy now</a> |
| 9   | <a href="#">60V42817008D</a><br>Lever, clamp            | <a href="#">Buy now</a> |
| 10  | <a href="#">68F4281800</a><br>Lever, clamp              | <a href="#">Buy now</a> |
| 11  | <a href="#">67F4281800</a><br>Lever, clamp              | <a href="#">Buy now</a> |
| 12  | <a href="#">9038615M73</a><br>Bush(6I2)                 | <a href="#">Buy now</a> |
| 13  | <a href="#">9020615M18</a><br>Washer, wave(6I2)         | <a href="#">Buy now</a> |
| 14  | <a href="#">9020106068</a><br>Washer,plate (6k8)        | <a href="#">Buy now</a> |
| 15  | <a href="#">9709506016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |

## Bottom Cowling



| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">64D4314400</a><br>Hook, spring         | <a href="#">Buy now</a> |
| 17  | <a href="#">9010906M80</a><br>Bolt                 | <a href="#">Buy now</a> |
| 18  | <a href="#">9050616M34</a><br>Spring, tension(64d) | <a href="#">Buy now</a> |
| 19  | <a href="#">60V4261500</a><br>Seal                 | <a href="#">Buy now</a> |
| 20  | <a href="#">6E54439100</a><br>Nipple, hose         | <a href="#">Buy now</a> |
| 21  | <a href="#">60V4272500</a><br>Grommet              | <a href="#">Buy now</a> |
| 22  | <a href="#">60V42738008D</a><br>Plate, fitting     | <a href="#">Buy now</a> |
| 23  | <a href="#">9010906M81</a><br>Bolt                 | <a href="#">Buy now</a> |
| 24  | <a href="#">64D42738105B</a><br>Plate, fitting     | <a href="#">Buy now</a> |
| 26  | <a href="#">9048022M81</a><br>Grommet              | <a href="#">Buy now</a> |
| 27  | <a href="#">9038708M37</a><br>Collar (6e5)         | <a href="#">Buy now</a> |
| 28  | <a href="#">9020108M54</a><br>Washer, plate (6e5)  | <a href="#">Buy now</a> |
| 29  | <a href="#">9707508035</a><br>Bolt(70w)            | <a href="#">Buy now</a> |
| 30  | <a href="#">9011908M22</a><br>Bolt, with washer    | <a href="#">Buy now</a> |
| 31  | <a href="#">6884272610</a><br>Grommet              | <a href="#">Buy now</a> |


## Bottom Cowling



**A7**


| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 32  | <a href="#">6E58258800</a><br>Plate                   | <a href="#">Buy now</a> |
| 33  | <a href="#">9589506020</a><br>Bolt, flange(jk3)       | <a href="#">Buy now</a> |
| 34  | <a href="#">6D042723005B</a><br>Cover, bottom         | <a href="#">Buy now</a> |
| 35  | <a href="#">60V4271800</a><br>Rubber, seal 3          | <a href="#">Buy now</a> |
| 37  | <a href="#">60V42741008D</a><br>Apron                 | <a href="#">Buy now</a> |
| 38  | <a href="#">60V4275600</a><br>Stay, clamp             | <a href="#">Buy now</a> |
| 39  | <a href="#">9788004016</a><br>Screw, with washer(61b) | <a href="#">Buy now</a> |
| 40  | <a href="#">9299004600</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 41  | <a href="#">9011106034</a><br>Bolt,hex. socket button | <a href="#">Buy now</a> |
| 42  | <a href="#">9709506020</a><br>Bolt(7u8)               | <a href="#">Buy now</a> |
| 43  | <a href="#">9299506600</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 44  | <a href="#">60V1258100</a><br>Joint, hose 1           | <a href="#">Buy now</a> |
| 45  | <a href="#">60V1257600</a><br>Hose 1                  | <a href="#">Buy now</a> |
| 46  | <a href="#">60V1257800</a><br>Hose 3                  | <a href="#">Buy now</a> |
| 47  | <a href="#">60V1258800</a><br>Hose 5                  | <a href="#">Buy now</a> |

## Bottom Cowling




| Ref | Part                                                                   |                         |
|-----|------------------------------------------------------------------------|-------------------------|
| 48  | <a href="#">6E52437800</a><br>Pipe, joint 3                            | <a href="#">Buy now</a> |
| 62  | <a href="#">9046511M10</a><br>Clamp<br>FLUSHING KIT                    | <a href="#">Buy now</a> |
| 50  | <a href="#">60V4277100</a><br>Apron                                    | <a href="#">Buy now</a> |
| 51  | <a href="#">9707508055</a><br>-                                        | <a href="#">Buy now</a> |
| 52  | <a href="#">9299508600</a><br>Washer, plain (663)                      | <a href="#">Buy now</a> |
| 53  | <a href="#">61A4271700</a><br>Rubber, seal 2                           | <a href="#">Buy now</a> |
| 54  | <a href="#">61A4271600</a><br>Rubber seal 1                            | <a href="#">Buy now</a> |
| 55  | <a href="#">60V4277400</a><br>Stay, Apron 1                            | <a href="#">Buy now</a> |
| 56  | <a href="#">9589506016</a><br>Bolt, flange deep recess                 | <a href="#">Buy now</a> |
| 57  | <a href="#">6H44272600</a><br>Grommet                                  | <a href="#">Buy now</a> |
| 58  | <a href="#">6R31257200</a><br>Adapter<br>FLUSHING KIT                  | <a href="#">Buy now</a> |
| 59  | <a href="#">9016905M00</a><br>Screw truss head tapping<br>FLUSHING KIT | <a href="#">Buy now</a> |
| 60  | <a href="#">6R31258000</a><br>Joint assembly<br>FLUSHING KIT           | <a href="#">Buy now</a> |
| 61  | <a href="#">9044511M36</a><br>Hose (I700)<br>FLUSHING KIT              | <a href="#">Buy now</a> |
| 63  | <a href="#">68F4275300</a><br>Fastner<br>AP                            | <a href="#">Buy now</a> |

## Bottom Cowling



| Ref | Part                                         |                         |
|-----|----------------------------------------------|-------------------------|
| 64  | <a href="#">9046420258</a><br>Clamp<br>AP    | <a href="#">Buy now</a> |
| 65  | <a href="#">68H4279101</a><br>Mark 1         | <a href="#">Buy now</a> |
| 66  | <a href="#">60V2415E60</a><br>Label, Caution | <a href="#">Buy now</a> |
| 67  | <a href="#">6A12817600</a><br>Label Caution  | <a href="#">Buy now</a> |
| 68  | <a href="#">6E38257H00</a><br>Plate Mark     | <a href="#">Buy now</a> |


# Bracket 1



**B6**

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 1   | <a href="#">69J43111018D</a><br>Bracket, clamp 1   | <a href="#">Buy now</a> |
| 2   | <a href="#">6G54525102</a><br>Anode                | <a href="#">Buy now</a> |
| 3   | <a href="#">6G54452600</a><br>Plate                | <a href="#">Buy now</a> |
| 4   | <a href="#">9709506025</a><br>Bolt                 | <a href="#">Buy now</a> |
| 5   | <a href="#">9299506600</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |
| 6   | <a href="#">6H18214800</a><br>Wire, lead           | <a href="#">Buy now</a> |
| 7   | <a href="#">9709506010</a><br>Bolt                 | <a href="#">Buy now</a> |
| 9   | <a href="#">6E58214800</a><br>Wire, lead 5         | <a href="#">Buy now</a> |
| 10  | <a href="#">9788506012</a><br>Screw, pan head(62j) | <a href="#">Buy now</a> |
| 12  | <a href="#">61A4313200</a><br>Washer, friction     | <a href="#">Buy now</a> |
| 13  | <a href="#">9788506010</a><br>Screw pan head       | <a href="#">Buy now</a> |
| 14  | <a href="#">69J43112018D</a><br>Bracket, clamp 2   | <a href="#">Buy now</a> |
| 15  | <a href="#">61A4313300</a><br>Washer,friction      | <a href="#">Buy now</a> |
| 17  | <a href="#">9370006M03</a><br>Nipple, grease(6a1)  | <a href="#">Buy now</a> |
| 18  | <a href="#">9046508M83</a><br>Clamp                | <a href="#">Buy now</a> |


# Bracket 1



**B6**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 21  | <a href="#">6R34313100</a><br>Bolt, clamp bracket      | <a href="#">Buy now</a> |
| 22  | <a href="#">9038625M31</a><br>Bushing (6e5)            | <a href="#">Buy now</a> |
| 23  | <a href="#">9020126M59</a><br>Washer, plate (6e5)      | <a href="#">Buy now</a> |
| 24  | <a href="#">9018522M11</a><br>Nut, self-locking        | <a href="#">Buy now</a> |
| 25  | <a href="#">9046511M10</a><br>Clamp                    | <a href="#">Buy now</a> |
| 27  | <a href="#">9709506014</a><br>Bolt(gj3)                | <a href="#">Buy now</a> |
| 29  | <a href="#">9709510045</a><br>Bolt(64d)                | <a href="#">Buy now</a> |
| 30  | <a href="#">9299510100</a><br>Ybs67-10 washer, spring  | <a href="#">Buy now</a> |
| 31  | <a href="#">9299510600</a><br>Washer, plate            | <a href="#">Buy now</a> |
| 32  | <a href="#">61A43311218D</a><br>Bracket, swivel 1<br>X | <a href="#">Buy now</a> |
| 32  | <a href="#">61A43311318D</a><br>Bracket, swivel<br>U   | <a href="#">Buy now</a> |
| 34  | <a href="#">61A8214720</a><br>Wire, lead 5<br>X        | <a href="#">Buy now</a> |
| 34  | <a href="#">61A8214730</a><br>Wire, lead 5<br>U        | <a href="#">Buy now</a> |
| 35  | <a href="#">6G54314400</a><br>Hook, spring             | <a href="#">Buy now</a> |
| 37  | <a href="#">61A4318101</a><br>Lever, tilt stop 1       | <a href="#">Buy now</a> |


# Bracket 1



**B6**


| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 38  | <a href="#">6G54318502</a><br>Lever, tilt stop 2     | <a href="#">Buy now</a> |
| 39  | <a href="#">9038610M16</a><br>Bushing (688)          | <a href="#">Buy now</a> |
| 40  | <a href="#">6G54314800</a><br>Collar, distance       | <a href="#">Buy now</a> |
| 41  | <a href="#">9038710M02</a><br>Collar(6e5)            | <a href="#">Buy now</a> |
| 42  | <a href="#">9169030020</a><br>Pin, spring (6h4)      | <a href="#">Buy now</a> |
| 43  | <a href="#">9050614M24</a><br>Spring, tension(6e5)   | <a href="#">Buy now</a> |
| 44  | <a href="#">6E54312602</a><br>Pin, upper shock mount | <a href="#">Buy now</a> |
| 45  | <a href="#">9038618M63</a><br>Bush(6e5)              | <a href="#">Buy now</a> |
| 46  | <a href="#">9038618M14</a><br>Bushing (6e5)          | <a href="#">Buy now</a> |
| 47  | <a href="#">9341018M02</a><br>Circlip (6f2)          | <a href="#">Buy now</a> |
| 48  | <a href="#">9010112M05</a><br>Bolt (l:130mm)<br>UR   | <a href="#">Buy now</a> |
| 48  | <a href="#">9010112M77</a><br>Bolt (l:150mm)<br>UR   | <a href="#">Buy now</a> |
| 49  | <a href="#">9020113M01</a><br>Washer, plate(6e5)     | <a href="#">Buy now</a> |
| 50  | <a href="#">9020112M05</a><br>Washer, plate(663)     | <a href="#">Buy now</a> |
| 51  | <a href="#">9538012600</a><br>Nut (707)              | <a href="#">Buy now</a> |

# Bracket 1



| Ref | Part                                   |                         |
|-----|----------------------------------------|-------------------------|
| 52  | <a href="#">9024906M19</a><br>Pin(6e5) | <a href="#">Buy now</a> |


## Bracket 2



**C1**

| Ref | Part                                                                  |                         |
|-----|-----------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V42510208D</a><br>Steering Bracket assembly<br><b>X</b> | <a href="#">Buy now</a> |
| 1   | <a href="#">60V42510308D</a><br>Steering Bracket assembly<br><b>U</b> | <a href="#">Buy now</a> |
| 2   | <a href="#">9020140M00</a><br>Washer, plate(61a)                      | <a href="#">Buy now</a> |
| 3   | <a href="#">9038639M89</a><br>Bush(61a)                               | <a href="#">Buy now</a> |
| 4   | <a href="#">9321035321</a><br>O-ring (3m7)                            | <a href="#">Buy now</a> |
| 5   | <a href="#">9020240M47</a><br>Washer, plate(61a)                      | <a href="#">Buy now</a> |
| 6   | <a href="#">61A44551018D</a><br>Housing, lower mount rubber           | <a href="#">Buy now</a> |
| 7   | <a href="#">9341037M04</a><br>Circlip (6e5)                           | <a href="#">Buy now</a> |
| 8   | <a href="#">61A4457500</a><br>Damper, lower mount rubber              | <a href="#">Buy now</a> |
| 9   | <a href="#">60V445550094</a><br>Mount damper, lower side              | <a href="#">Buy now</a> |
| 10  | <a href="#">9020232M19</a><br>Washer, plate (6e5)                     | <a href="#">Buy now</a> |
| 11  | <a href="#">9020116M55</a><br>Washer, plate (6e5)                     | <a href="#">Buy now</a> |
| 12  | <a href="#">6E58214900</a><br>Wire, lead 3                            | <a href="#">Buy now</a> |
| 13  | <a href="#">9010914M48</a><br>Bolt                                    | <a href="#">Buy now</a> |
| 14  | <a href="#">9020115M58</a><br>Washer, plate (6e5)                     | <a href="#">Buy now</a> |

## Bracket 2




60V1010-3240

**C1**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 15  | <a href="#">9538014800</a><br>Nut, crown (6e5)              | <a href="#">Buy now</a> |
| 16  | <a href="#">9299514600</a><br>Washer (6e5)                  | <a href="#">Buy now</a> |
| 17  | <a href="#">61A445520194</a><br>Housing, lower mount rubber | <a href="#">Buy now</a> |
| 18  | <a href="#">9709510045</a><br>Bolt(64d)                     | <a href="#">Buy now</a> |
| 19  | <a href="#">9299510600</a><br>Washer, plate                 | <a href="#">Buy now</a> |
| 20  | <a href="#">61A44553008D</a><br>Cover, lower mount          | <a href="#">Buy now</a> |
| 21  | <a href="#">6A01578900</a><br>Damper                        | <a href="#">Buy now</a> |
| 22  | <a href="#">60V445140094</a><br>Mount damper, upper side    | <a href="#">Buy now</a> |
| 23  | <a href="#">9020116M01</a><br>Washer, plate(61a)            | <a href="#">Buy now</a> |
| 24  | <a href="#">9020228M46</a><br>Washer, plate(61a)            | <a href="#">Buy now</a> |
| 25  | <a href="#">9020128M01</a><br>Washer, plate(61a)            | <a href="#">Buy now</a> |
| 26  | <a href="#">9010914M10</a><br>Bolt                          | <a href="#">Buy now</a> |
| 27  | <a href="#">9018514M00</a><br>Nut, self-locking(61a)        | <a href="#">Buy now</a> |
| 29  | <a href="#">61A445110094</a><br>Cover, upper mount          | <a href="#">Buy now</a> |
| 32  | <a href="#">69J8367200</a><br>Trim sender                   | <a href="#">Buy now</a> |


## Bracket 2



**C1**

| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 33  | <a href="#">9788506016</a><br>Screw, pan head(6b0)  | <a href="#">Buy now</a> |
| 34  | <a href="#">61A4337600</a><br>Bolt, thrust receiver | <a href="#">Buy now</a> |
| 35  | <a href="#">9578010300</a><br>Nut, nylon (6e5)      | <a href="#">Buy now</a> |


# Control



**B3**

| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">60V4853110</a><br>-                     | <a href="#">Buy now</a> |
| 2   | <a href="#">6634853800</a><br>Clamp, cable 1        | <a href="#">Buy now</a> |
| 3   | <a href="#">9169030010</a><br>Pin, spring (663)     | <a href="#">Buy now</a> |
| 4   | <a href="#">9010906M80</a><br>Bolt                  | <a href="#">Buy now</a> |
| 5   | <a href="#">60V44117001S</a><br>Bracket             | <a href="#">Buy now</a> |
| 6   | <a href="#">60V4419400</a><br>Cap                   | <a href="#">Buy now</a> |
| 7   | <a href="#">9709506020</a><br>Bolt(7u8)             | <a href="#">Buy now</a> |
| 8   | <a href="#">60V44176001S</a><br>Bracket             | <a href="#">Buy now</a> |
| 9   | <a href="#">9370006M01</a><br>Nipple, grease(61a)   | <a href="#">Buy now</a> |
| 10  | <a href="#">9038612069</a><br>Bush(666)             | <a href="#">Buy now</a> |
| 11  | <a href="#">9038708M09</a><br>Collar(61a)           | <a href="#">Buy now</a> |
| 12  | <a href="#">9709508035</a><br>Bolt(70w)             | <a href="#">Buy now</a> |
| 13  | <a href="#">9299508200</a><br>Ybs66-8 washer, plain | <a href="#">Buy now</a> |
| 14  | <a href="#">9050820M31</a><br>Spring, torsion(61a)  | <a href="#">Buy now</a> |
| 15  | <a href="#">61A8259F00</a><br>Switch assembly       | <a href="#">Buy now</a> |


# Control



**B3**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">61A8258801</a><br>Plate                     | <a href="#">Buy now</a> |
| 17  | <a href="#">9788504016</a><br>Screw, panhead (796)      | <a href="#">Buy now</a> |
| 18  | <a href="#">9299504100</a><br>Ybs67-4 washer, spring    | <a href="#">Buy now</a> |
| 19  | <a href="#">60V8259F00</a><br>Switch assembly           | <a href="#">Buy now</a> |
| 23  | <a href="#">61A4412100</a><br>Lever, shift rod          | <a href="#">Buy now</a> |
| 24  | <a href="#">68J4412201</a><br>Bushing, shift rod lever  | <a href="#">Buy now</a> |
| 25  | <a href="#">9020208M20</a><br>Washer, plate (6e5)       | <a href="#">Buy now</a> |
| 26  | <a href="#">9046818008</a><br>Clip 620436610000         | <a href="#">Buy now</a> |
| 27  | <a href="#">6E54834400</a><br>Cable end, remote control | <a href="#">Buy now</a> |
| 28  | <a href="#">9020206007</a><br>Washer plate 626441880000 | <a href="#">Buy now</a> |
| 29  | <a href="#">61A44118008D</a><br>Bracket                 | <a href="#">Buy now</a> |
| 30  | <a href="#">9370006M03</a><br>Nipple, grease(6a1)       | <a href="#">Buy now</a> |
| 31  | <a href="#">61A4411600</a><br>Spring                    | <a href="#">Buy now</a> |
| 32  | <a href="#">9709506030</a><br>Bolt(jf7)                 | <a href="#">Buy now</a> |
| 33  | <a href="#">9299506100</a><br>Washer(6a1)               | <a href="#">Buy now</a> |


# Control



**B3**

| Ref | Part                                                          |                         |
|-----|---------------------------------------------------------------|-------------------------|
| 34  | <a href="#">9299506600</a><br>Washer, plain (646)             | <a href="#">Buy now</a> |
| 35  | <a href="#">61A4412022</a><br>Handle gear shift assembly<br>X | <a href="#">Buy now</a> |
| 35  | <a href="#">61A4412032</a><br>Handle gear shift assembly<br>U | <a href="#">Buy now</a> |
| 36  | <a href="#">9321009165</a><br>O-ring                          | <a href="#">Buy now</a> |
| 37  | <a href="#">61A4411200</a><br>Stay, handle gear shift         | <a href="#">Buy now</a> |
| 38  | <a href="#">9701306012</a><br>Bolt(gh1)                       | <a href="#">Buy now</a> |
| 39  | <a href="#">9290306100</a><br>Washer(6a1)                     | <a href="#">Buy now</a> |
| 40  | <a href="#">9290306600</a><br>Washer, plain (646)             | <a href="#">Buy now</a> |
| 41  | <a href="#">9531308600</a><br>Nut(6l2)                        | <a href="#">Buy now</a> |
| 42  | <a href="#">9038690M90</a><br>Bush(61a)                       | <a href="#">Buy now</a> |
| 43  | <a href="#">9149020012</a><br>Pin, cotter (648)               | <a href="#">Buy now</a> |
| 44  | <a href="#">9020109M02</a><br>Washer, plate(61a)              | <a href="#">Buy now</a> |
| 45  | <a href="#">61A1531500</a><br>Seal, crankcase                 | <a href="#">Buy now</a> |
| 46  | <a href="#">61A4272400</a><br>Grommet                         | <a href="#">Buy now</a> |
| 47  | <a href="#">61A4413800</a><br>Washer                          | <a href="#">Buy now</a> |


# Control



**B3**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 48  | <a href="#">9788506008</a><br>Screw, pan head(6a3)   | <a href="#">Buy now</a> |
| 49  | <a href="#">65L4163201</a><br>Lever, magneto control | <a href="#">Buy now</a> |
| 52  | <a href="#">9701308045</a><br>Bolt                   | <a href="#">Buy now</a> |
| 53  | <a href="#">9299008200</a><br>Ybs66-8 washer, plain  | <a href="#">Buy now</a> |
| 54  | <a href="#">9020612M00</a><br>Washer, wave (676)     | <a href="#">Buy now</a> |
| 55  | <a href="#">9038708M16</a><br>Collar                 | <a href="#">Buy now</a> |
| 56  | <a href="#">61A4123700</a><br>Joint, link            | <a href="#">Buy now</a> |
| 57  | <a href="#">9538005600</a><br>Nut, hexagon (663)     | <a href="#">Buy now</a> |
| 58  | <a href="#">6H44123700</a><br>Joint, link            | <a href="#">Buy now</a> |
| 59  | <a href="#">6D04123000</a><br>Cam accelerator comp   | <a href="#">Buy now</a> |
| 60  | <a href="#">9020106M31</a><br>Washer (6a0)           | <a href="#">Buy now</a> |
| 61  | <a href="#">9038706M29</a><br>Collar (6a0)           | <a href="#">Buy now</a> |
| 62  | <a href="#">9020610M04</a><br>Washer, wave (676)     | <a href="#">Buy now</a> |
| 63  | <a href="#">9011906MA4</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 64  | <a href="#">69L4274400</a><br>Stay                   | <a href="#">Buy now</a> |


# Control



**B3**

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 65  | <a href="#">9015706006</a><br>Screw Pan Head       | <a href="#">Buy now</a> |
| 66  | <a href="#">9538006600</a><br>Nut(661)             | <a href="#">Buy now</a> |
| 67  | <a href="#">6884419400</a><br>Cap                  | <a href="#">Buy now</a> |
| 68  | <a href="#">9015905M25</a><br>Screw,pan head (646) | <a href="#">Buy now</a> |


# Crankshaft & Piston



**B2**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D01141100</a><br>Crankshaft                 | <a href="#">Buy now</a> |
| 2   | <a href="#">61A1144700</a><br>Seal, crank                | <a href="#">Buy now</a> |
| 3   | <a href="#">93311940V0</a><br>Bearing, cylindrical(61a)  | <a href="#">Buy now</a> |
| 4   | <a href="#">9310240M38</a><br>Oil seal(61a)              | <a href="#">Buy now</a> |
| 5   | <a href="#">60V1147900</a><br>O-ring                     | <a href="#">Buy now</a> |
| 6   | <a href="#">93306209U1</a><br>Bearing(61a)               | <a href="#">Buy now</a> |
| 7   | <a href="#">93310959U0</a><br>Bearing, cylindrical(61a)  | <a href="#">Buy now</a> |
| 8   | <a href="#">61A1153600</a><br>Gear, drive                | <a href="#">Buy now</a> |
| 9   | <a href="#">93306308U0</a><br>Bearing(61a)               | <a href="#">Buy now</a> |
| 10  | <a href="#">9341040M03</a><br>Circlip(n02)               | <a href="#">Buy now</a> |
| 11  | <a href="#">61A1158601</a><br>Pulley, crankshaft balance | <a href="#">Buy now</a> |
| 12  | <a href="#">60V1155500</a><br>Nut, crankshaft 1          | <a href="#">Buy now</a> |
| 13  | <a href="#">9310422M07</a><br>Oil seal(61a)              | <a href="#">Buy now</a> |
| 14  | <a href="#">6D0153590094</a><br>Housing, oil seal        | <a href="#">Buy now</a> |
| 15  | <a href="#">9310340011</a><br>Oil seal                   | <a href="#">Buy now</a> |


## Crankshaft & Piston



B2

| Ref | Part                                                             |                         |
|-----|------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">9342061M07</a><br>Circlip(61a)                       | <a href="#">Buy now</a> |
| 17  | <a href="#">9321085M32</a><br>O-ring (173)                       | <a href="#">Buy now</a> |
| 18  | <a href="#">9709506020</a><br>Bolt(7u8)                          | <a href="#">Buy now</a> |
| 19  | <a href="#">9299506100</a><br>Washer(6a1)                        | <a href="#">Buy now</a> |
| 20  | <a href="#">6D0116310085</a><br>Piston (std)                     | <a href="#">Buy now</a> |
| 20  | <a href="#">6D01163500</a><br>Piston (0.25mm o/s)<br>AP          | <a href="#">Buy now</a> |
| 20  | <a href="#">6D01163600</a><br>Piston (0.50mm o/s)<br>AP          | <a href="#">Buy now</a> |
| 21  | <a href="#">6D01160300</a><br>Piston ring set (std)              | <a href="#">Buy now</a> |
| 21  | <a href="#">6D01160400</a><br>Piston ring set (0.25mm o/s)<br>AP | <a href="#">Buy now</a> |
| 21  | <a href="#">6D01160500</a><br>Piston ring set (0.50mm o/s)<br>AP | <a href="#">Buy now</a> |
| 22  | <a href="#">6D0116420085</a><br>Piston 2 (std)                   | <a href="#">Buy now</a> |
| 22  | <a href="#">6D01164500</a><br>Piston 2 (0.25mm o/s)<br>AP        | <a href="#">Buy now</a> |
| 22  | <a href="#">6D01164600</a><br>Piston 2 (0.50mm o/s)<br>AP        | <a href="#">Buy now</a> |
| 24  | <a href="#">6D01163300</a><br>Pin, piston                        | <a href="#">Buy now</a> |
| 25  | <a href="#">60X1163400</a><br>Clip, piston pin                   | <a href="#">Buy now</a> |


# Crankshaft & Piston



**B2**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 26  | <a href="#">6D01165000</a><br>Connecting rod assembly | <a href="#">Buy now</a> |
| 27  | <a href="#">9010909001</a><br>Bolt                    | <a href="#">Buy now</a> |
| 28  | <a href="#">9331032657</a><br>Bearing                 | <a href="#">Buy now</a> |
| 29  | <a href="#">9020126M03</a><br>Washer, plate(61a)      | <a href="#">Buy now</a> |
| 30  | <a href="#">9331084106</a><br>Bearing                 | <a href="#">Buy now</a> |


# Cylinder & Crankcase 1



**A6**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D0W0090101S</a><br>Crank cylinder assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6D015100001S</a><br>Crankcase assembly      | <a href="#">Buy now</a> |
| 3   | <a href="#">6E51137201</a><br>Nipple, hose              | <a href="#">Buy now</a> |
| 4   | <a href="#">6241448500</a><br>Pipe, joint               | <a href="#">Buy now</a> |
| 5   | <a href="#">9038406M07</a><br>Bush, bimetal formed(6r3) | <a href="#">Buy now</a> |
| 6   | <a href="#">9038316M01</a><br>Bush, formed(61a)         | <a href="#">Buy now</a> |
| 7   | <a href="#">60V1137000</a><br>Check valve assembly      | <a href="#">Buy now</a> |
| 8   | <a href="#">6501137001</a><br>Check valve assembly      | <a href="#">Buy now</a> |
| 9   | <a href="#">60V1137010</a><br>Check valve assembly      | <a href="#">Buy now</a> |
| 10  | <a href="#">9011608012</a><br>Bolt, stud                | <a href="#">Buy now</a> |
| 11  | <a href="#">6D01137200</a><br>Nipple Hose               | <a href="#">Buy now</a> |
| 12  | <a href="#">6631151801</a><br>Lock, bearing             | <a href="#">Buy now</a> |
| 13  | <a href="#">9034014M00</a><br>Plug, straight screw(62y) | <a href="#">Buy now</a> |
| 14  | <a href="#">9043014115</a><br>Gasket (663)              | <a href="#">Buy now</a> |
| 15  | <a href="#">9360812063</a><br>Pin, dowel (626)          | <a href="#">Buy now</a> |


# Cylinder & Crankcase 1



**A6**

| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 16  | <a href="#">9044507M10</a><br>Hose (L770)       | <a href="#">Buy now</a> |
| 17  | <a href="#">9046807M02</a><br>Clip (6e5)        | <a href="#">Buy now</a> |
| 18  | <a href="#">9751310590</a><br>Bolt, with washer | <a href="#">Buy now</a> |
| 19  | <a href="#">9011910M11</a><br>Bolt With Washer  | <a href="#">Buy now</a> |
| 20  | <a href="#">9011906089</a><br>Bolt, with washer | <a href="#">Buy now</a> |
| 21  | <a href="#">9044507M03</a><br>Hose (I200)       | <a href="#">Buy now</a> |
| 22  | <a href="#">9044507016</a><br>Hose (I60)        | <a href="#">Buy now</a> |
| 23  | <a href="#">9044507M29</a><br>Hose (I200)       | <a href="#">Buy now</a> |
| 24  | <a href="#">9044507MA6</a><br>Hose (I200)       | <a href="#">Buy now</a> |
| 25  | <a href="#">6E02437800</a><br>Pipe, joint       | <a href="#">Buy now</a> |
| 26  | <a href="#">6G51258100</a><br>Joint, hose       | <a href="#">Buy now</a> |
| 27  | <a href="#">60V1132501</a><br>Anode             | <a href="#">Buy now</a> |
| 28  | <a href="#">66M1132800</a><br>Grommet, anode    | <a href="#">Buy now</a> |
| 29  | <a href="#">66M113270094</a><br>Cover, anode    | <a href="#">Buy now</a> |
| 30  | <a href="#">66M1253500</a><br>Plate             | <a href="#">Buy now</a> |


# Cylinder & Crankcase 1



**A6**

| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 31  | <a href="#">9709505012</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 32  | <a href="#">9299505600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 33  | <a href="#">9701306020</a><br>Bolt(62y)           | <a href="#">Buy now</a> |
| 34  | <a href="#">9290306600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 35  | <a href="#">60V113710094</a><br>Cover             | <a href="#">Buy now</a> |
| 36  | <a href="#">60V2413500</a><br>Clamp 1             | <a href="#">Buy now</a> |
| 37  | <a href="#">9701305012</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 38  | <a href="#">9290305600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 39  | <a href="#">60V1138100</a><br>Gasket 1            | <a href="#">Buy now</a> |
| 40  | <a href="#">9011906MA2</a><br>Bolt, with washer   | <a href="#">Buy now</a> |
| 41  | <a href="#">60V1241100</a><br>Thermostat          | <a href="#">Buy now</a> |
| 42  | <a href="#">60V12413001S</a><br>Cover Thermostat  | <a href="#">Buy now</a> |
| 43  | <a href="#">60V12414A0</a><br>Gasket, cover       | <a href="#">Buy now</a> |
| 44  | <a href="#">9948006012</a><br>Pin                 | <a href="#">Buy now</a> |
| 45  | <a href="#">9011906055</a><br>Bolt, with washer   | <a href="#">Buy now</a> |


# Cylinder & Crankcase 1



**A6**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 46  | <a href="#">66M1132500</a><br>Anode                      | <a href="#">Buy now</a> |
| 53  | <a href="#">6E542761001S</a><br>Stopper                  | <a href="#">Buy now</a> |
| 55  | <a href="#">68F4453300</a><br>Damper, upper mount rubber | <a href="#">Buy now</a> |


## Cylinder & Crankcase 2



**B4**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D011111001S</a><br>Head Cylinder 1      | <a href="#">Buy now</a> |
| 2   | <a href="#">67F1132500</a><br>Anode                  | <a href="#">Buy now</a> |
| 3   | <a href="#">67F113270094</a><br>Anode cover assembly | <a href="#">Buy now</a> |
| 4   | <a href="#">69J113270094</a><br>Anode cover assembly | <a href="#">Buy now</a> |
| 5   | <a href="#">60V113270094</a><br>Anode cover assembly | <a href="#">Buy now</a> |
| 6   | <a href="#">9707506020</a><br>Bolt(7u8)              | <a href="#">Buy now</a> |
| 7   | <a href="#">9299506600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 8   | <a href="#">67F1132800</a><br>Grommet, anode         | <a href="#">Buy now</a> |
| 9   | <a href="#">60V1253500</a><br>Plate                  | <a href="#">Buy now</a> |
| 10  | <a href="#">9757508550</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 11  | <a href="#">9707508035</a><br>Bolt(70w)              | <a href="#">Buy now</a> |
| 12  | <a href="#">9299508600</a><br>Washer, plain (663)    | <a href="#">Buy now</a> |
| 13  | <a href="#">68F1111900</a><br>Hanger, engine         | <a href="#">Buy now</a> |
| 14  | <a href="#">9011906MA2</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 15  | <a href="#">60V11191001S</a><br>-                    | <a href="#">Buy now</a> |


## Cylinder & Crankcase 2



**B4**


| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 16  | <a href="#">60V1119300</a><br>Gasket, head cover 1     | <a href="#">Buy now</a> |
| 17  | <a href="#">9011906MA4</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 18  | <a href="#">68F8391900</a><br>Clamp, harness           | <a href="#">Buy now</a> |
| 19  | <a href="#">9959010114</a><br>Pin, dowel               | <a href="#">Buy now</a> |
| 20  | <a href="#">9011908MA5</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 21  | <a href="#">9011908MA8</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 22  | <a href="#">6D01118100</a><br>Gasket, cylinder head 1  | <a href="#">Buy now</a> |
| 23  | <a href="#">6D011121001S</a><br>Head Cylinder 2        | <a href="#">Buy now</a> |
| 35  | <a href="#">69J1111E00</a><br>Hanger, engine 2         | <a href="#">Buy now</a> |
| 37  | <a href="#">60V11192001S</a><br>Cover, cylinder head 2 | <a href="#">Buy now</a> |
| 45  | <a href="#">9470200405</a><br>Plug, spark (bkr6eku)    | <a href="#">Buy now</a> |

## Cylinder & Crankcase 3



| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D015411001S</a><br>Cover Crankcase 1           | <a href="#">Buy now</a> |
| 2   | <a href="#">6D015421001S</a><br>Cover, Crankcase 2          | <a href="#">Buy now</a> |
| 3   | <a href="#">6D015431001S</a><br>Cover, crankcase 3          | <a href="#">Buy now</a> |
| 4   | <a href="#">6D01545100</a><br>Gasket, Crankcase Cover 1     | <a href="#">Buy now</a> |
| 5   | <a href="#">6D01546100</a><br>Gasket, crankcase cover 2     | <a href="#">Buy now</a> |
| 6   | <a href="#">6D01546200</a><br>Gasket, crankcase cover 3     | <a href="#">Buy now</a> |
| 7   | <a href="#">9011906MA3</a><br>Bolt, with washer             | <a href="#">Buy now</a> |
| 8   | <a href="#">9046506M88</a><br>Clamp                         | <a href="#">Buy now</a> |
| 9   | <a href="#">9759506510</a><br>Bolt, hexagon w/w deep recess | <a href="#">Buy now</a> |
| 10  | <a href="#">9046508M23</a><br>Clamp (6h3)                   | <a href="#">Buy now</a> |
| 12  | <a href="#">9046708M10</a><br>Clip, pipe 6162435600         | <a href="#">Buy now</a> |
| 13  | <a href="#">9044509M30</a><br>Hose (l865)                   | <a href="#">Buy now</a> |
| 14  | <a href="#">9046407008</a><br>Clamp                         | <a href="#">Buy now</a> |
| 15  | <a href="#">9044509068</a><br>Hose (l420)                   | <a href="#">Buy now</a> |
| 16  | <a href="#">9046511M10</a><br>Clamp                         | <a href="#">Buy now</a> |


## Cylinder & Crankcase 3



**B6**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 17  | <a href="#">6882437800</a><br>Pipe, joint                 | <a href="#">Buy now</a> |
| 18  | <a href="#">9044509221</a><br>Hose (I1500)                | <a href="#">Buy now</a> |
| 19  | <a href="#">9044509022</a><br>Hose (I530)                 | <a href="#">Buy now</a> |
| 20  | <a href="#">8H82437600</a><br>Pipe, joint                 | <a href="#">Buy now</a> |
| 21  | <a href="#">60V411130094</a><br>Outer cover, exhaust      | <a href="#">Buy now</a> |
| 22  | <a href="#">6761137200</a><br>Nipple, hose                | <a href="#">Buy now</a> |
| 23  | <a href="#">60V4111200</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 24  | <a href="#">60V4126700</a><br>Bushing, joint              | <a href="#">Buy now</a> |
| 26  | <a href="#">60V113270094</a><br>Anode cover assembly      | <a href="#">Buy now</a> |
| 27  | <a href="#">67F1132500</a><br>Anode                       | <a href="#">Buy now</a> |
| 28  | <a href="#">9707506020</a><br>Bolt(7u8)                   | <a href="#">Buy now</a> |
| 29  | <a href="#">9299506600</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 30  | <a href="#">67F1132800</a><br>Grommet, anode              | <a href="#">Buy now</a> |
| 31  | <a href="#">9707508030</a><br>Bolt, hexagon (fj1)         | <a href="#">Buy now</a> |
| 32  | <a href="#">9299508600</a><br>Washer, plain (663)         | <a href="#">Buy now</a> |


## Cylinder & Crankcase 3



**B6**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 33  | <a href="#">9046708004</a><br>Clip, pipe 6162435600     | <a href="#">Buy now</a> |
| 34  | <a href="#">6G51241600</a><br>Valve, pressure control   | <a href="#">Buy now</a> |
| 35  | <a href="#">9050116M11</a><br>Spring, compression (688) | <a href="#">Buy now</a> |
| 36  | <a href="#">9048020M05</a><br>Grommet (688)             | <a href="#">Buy now</a> |
| 37  | <a href="#">60V11382A0</a><br>Gasket 2                  | <a href="#">Buy now</a> |
| 38  | <a href="#">6G511372001S</a><br>Cover, bypass 2         | <a href="#">Buy now</a> |
| 39  | <a href="#">9011906MA2</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 40  | <a href="#">61A1257600</a><br>Hose 1                    | <a href="#">Buy now</a> |
| 41  | <a href="#">9046513M18</a><br>Clamp                     | <a href="#">Buy now</a> |


# Electrical 1



**F1**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V855420194</a><br>Bracket                    | <a href="#">Buy now</a> |
| 2   | <a href="#">60V8556400</a><br>Grommet                      | <a href="#">Buy now</a> |
| 3   | <a href="#">68F8612900</a><br>Collar                       | <a href="#">Buy now</a> |
| 4   | <a href="#">68F8612910</a><br>Collar                       | <a href="#">Buy now</a> |
| 5   | <a href="#">68F8511900</a><br>Bolt                         | <a href="#">Buy now</a> |
| 6   | <a href="#">6D08591A00</a><br>Engine control unit assembly | <a href="#">Buy now</a> |
| 7   | <a href="#">9011906MA3</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 8   | <a href="#">60V8554800</a><br>Holder                       | <a href="#">Buy now</a> |
| 9   | <a href="#">9701306014</a><br>Bolt(gj3)                    | <a href="#">Buy now</a> |
| 10  | <a href="#">9290306600</a><br>Washer, plain (646)          | <a href="#">Buy now</a> |
| 11  | <a href="#">60V8591B00</a><br>Driver, injector assembly    | <a href="#">Buy now</a> |
| 12  | <a href="#">9011906MA2</a><br>Bolt, with washer            | <a href="#">Buy now</a> |
| 13  | <a href="#">6E58251900</a><br>Wire, Earth Lead             | <a href="#">Buy now</a> |
| 14  | <a href="#">9709506012</a><br>Bolt(gh1)                    | <a href="#">Buy now</a> |
| 15  | <a href="#">9299506600</a><br>Washer, plain (646)          | <a href="#">Buy now</a> |


# Electrical 1



**F1**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 18  | <a href="#">60V8231000</a><br>Ignition coil assembly | <a href="#">Buy now</a> |
| 19  | <a href="#">9048025161</a><br>Grommet(656)           | <a href="#">Buy now</a> |
| 20  | <a href="#">9044610M01</a><br>Tube (6e5)             | <a href="#">Buy now</a> |
| 21  | <a href="#">60V8231010</a><br>Ignition coil assembly | <a href="#">Buy now</a> |
| 22  | <a href="#">9046418003</a><br>Clamp                  | <a href="#">Buy now</a> |
| 23  | <a href="#">9048022M15</a><br>Grommet (6e5)          | <a href="#">Buy now</a> |
| 24  | <a href="#">9046511M10</a><br>Clamp                  | <a href="#">Buy now</a> |
| 25  | <a href="#">9701305020</a><br>Bolt, hexagon          | <a href="#">Buy now</a> |
| 26  | <a href="#">9290305600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 27  | <a href="#">68F8237001</a><br>Plug cap assembly      | <a href="#">Buy now</a> |
| 28  | <a href="#">60V8231401</a><br>Cover Ignition Coil    | <a href="#">Buy now</a> |
| 29  | <a href="#">60V2419800</a><br>Seat, Rubber           | <a href="#">Buy now</a> |
| 30  | <a href="#">60V2419810</a><br>Seat, Rubber           | <a href="#">Buy now</a> |
| 31  | <a href="#">60V8818D00</a><br>Seat 1                 | <a href="#">Buy now</a> |
| 32  | <a href="#">60V8818D10</a><br>Seat 1                 | <a href="#">Buy now</a> |


# Electrical 1



**F1**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 33  | <a href="#">60V2311600</a><br>Seat 2                    | <a href="#">Buy now</a> |
| 34  | <a href="#">60V2311610</a><br>Seat 2                    | <a href="#">Buy now</a> |
| 35  | <a href="#">60V2318U00</a><br>Plate, Seat               | <a href="#">Buy now</a> |
| 36  | <a href="#">60V2318U10</a><br>Plate, Seat               | <a href="#">Buy now</a> |
| 37  | <a href="#">68F8551601</a><br>Spacer                    | <a href="#">Buy now</a> |
| 40  | <a href="#">6A08231700</a><br>Damper, ignition coil     | <a href="#">Buy now</a> |
| 41  | <a href="#">6244254200</a><br>Collar                    | <a href="#">Buy now</a> |
| 42  | <a href="#">9011906M65</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 43  | <a href="#">60V8252U00</a><br>Cover                     | <a href="#">Buy now</a> |
| 44  | <a href="#">60V2311500</a><br>Seat 1                    | <a href="#">Buy now</a> |
| 45  | <a href="#">9011106034</a><br>Bolt, hex. socket button  | <a href="#">Buy now</a> |
| 46  | <a href="#">68V8195000</a><br>Relay assembly            | <a href="#">Buy now</a> |
| 47  | <a href="#">9709506016</a><br>Bolt, hexagon deep recess | <a href="#">Buy now</a> |


## Electrical 2



**F3**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">9044707011</a><br>Hose, with spring           | <a href="#">Buy now</a> |
| 2   | <a href="#">9046511M10</a><br>Clamp                       | <a href="#">Buy now</a> |
| 3   | <a href="#">61A8194900</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 4   | <a href="#">9709506012</a><br>Bolt(gh1)                   | <a href="#">Buy now</a> |
| 5   | <a href="#">9299506600</a><br>Washer, plain (646)         | <a href="#">Buy now</a> |
| 6   | <a href="#">60V8210500</a><br>Battery cable               | <a href="#">Buy now</a> |
| 7   | <a href="#">9533308600</a><br>Nut(6I2)                    | <a href="#">Buy now</a> |
| 8   | <a href="#">9290308100</a><br>Ybs67-8 washer, spring      | <a href="#">Buy now</a> |
| 9   | <a href="#">6D08253100</a><br>Wire, lead                  | <a href="#">Buy now</a> |
| 10  | <a href="#">60V8259030</a><br>Wire Harness assembly       | <a href="#">Buy now</a> |
| 13  | <a href="#">9046511M52</a><br>Clamp(6e7)                  | <a href="#">Buy now</a> |
| 14  | <a href="#">60V8259M00</a><br>Wire Harness assembly 2     | <a href="#">Buy now</a> |
| 15  | <a href="#">9046505M87</a><br>Clamp                       | <a href="#">Buy now</a> |
| 17  | <a href="#">9046411008</a><br>Clamp                       | <a href="#">Buy now</a> |
| 19  | <a href="#">69J8256300</a><br>Trim & tilt switch assembly | <a href="#">Buy now</a> |


## Electrical 2



**F3**


| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 20  | <a href="#">69J8258700</a><br>Gasket            | <a href="#">Buy now</a> |
| 21  | <a href="#">69J4272300</a><br>Cover, Bottom     | <a href="#">Buy now</a> |
| 22  | <a href="#">60V8361400</a><br>Bracket           | <a href="#">Buy now</a> |
| 23  | <a href="#">60V8361410</a><br>Bracket           | <a href="#">Buy now</a> |
| 24  | <a href="#">60V8363510</a><br>Bracket           | <a href="#">Buy now</a> |
| 25  | <a href="#">9046420213</a><br>Clamp(4kj)        | <a href="#">Buy now</a> |
| 26  | <a href="#">9709506014</a><br>Bolt(gj3)         | <a href="#">Buy now</a> |
| 27  | <a href="#">9010906M86</a><br>Bolt              | <a href="#">Buy now</a> |
| 28  | <a href="#">60V8361800</a><br>Plate             | <a href="#">Buy now</a> |
| 29  | <a href="#">68F8363400</a><br>Grommet           | <a href="#">Buy now</a> |
| 30  | <a href="#">67H8238000</a><br>Sensor, pressure  | <a href="#">Buy now</a> |
| 31  | <a href="#">9858006520</a><br>Screw pan head    | <a href="#">Buy now</a> |
| 32  | <a href="#">6E58258800</a><br>Plate             | <a href="#">Buy now</a> |
| 33  | <a href="#">9589506020</a><br>Bolt, flange(jk3) | <a href="#">Buy now</a> |

## Electrical 3



| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V8196001</a><br>Rectifier & regulator assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">60V81975A0</a><br>Plate, rectifier fitting       | <a href="#">Buy now</a> |
| 3   | <a href="#">60V81972001S</a><br>Cover, rectifier             | <a href="#">Buy now</a> |
| 4   | <a href="#">9011906MA3</a><br>Bolt, with washer              | <a href="#">Buy now</a> |
| 5   | <a href="#">9011906MA4</a><br>Bolt, with washer              | <a href="#">Buy now</a> |
| 6   | <a href="#">9044509M25</a><br>Hose (I1500)                   | <a href="#">Buy now</a> |
| 7   | <a href="#">9046708M18</a><br>Clip                           | <a href="#">Buy now</a> |
| 8   | <a href="#">6L28259901</a><br>Cover, connector               | <a href="#">Buy now</a> |
| 9   | <a href="#">9044710004</a><br>Hose, With Spring              | <a href="#">Buy now</a> |
| 10  | <a href="#">60V8194800</a><br>Bracket                        | <a href="#">Buy now</a> |
| 11  | <a href="#">68F8511900</a><br>Bolt                           | <a href="#">Buy now</a> |
| 12  | <a href="#">9011906M65</a><br>Bolt, with washer              | <a href="#">Buy now</a> |
| 13  | <a href="#">68F8551601</a><br>Spacer                         | <a href="#">Buy now</a> |
| 14  | <a href="#">68F8612900</a><br>Collar                         | <a href="#">Buy now</a> |
| 15  | <a href="#">6A08231700</a><br>Damper, ignition coil          | <a href="#">Buy now</a> |


## Electrical 3



**F5**


| Ref | Part                                                                         |                         |
|-----|------------------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">6244254200</a><br>Collar                                         | <a href="#">Buy now</a> |
| 17  | <a href="#">60V8714900</a><br>Connector                                      | <a href="#">Buy now</a> |
| 18  | <a href="#">9709506012</a><br>Bolt(gh1)                                      | <a href="#">Buy now</a> |
| 19  | <a href="#">9299506600</a><br>Washer, plain (646)                            | <a href="#">Buy now</a> |
| 20  | <a href="#">60V8195000</a><br>Relay assembly                                 | <a href="#">Buy now</a> |
| 22  | <a href="#">6828211901</a><br>Cover, lead wire                               | <a href="#">Buy now</a> |
| 23  | <a href="#">9709506010</a><br>Bolt                                           | <a href="#">Buy now</a> |
| 24  | <a href="#">9299506100</a><br>Washer(6a1)                                    | <a href="#">Buy now</a> |
| 26  | <a href="#">68V8194A00</a><br>Relay                                          | <a href="#">Buy now</a> |
| 27  | <a href="#">68F8211700</a><br>Wire, lead                                     | <a href="#">Buy now</a> |
| 32  | <a href="#">68V8195300</a><br>Stay, relay                                    | <a href="#">Buy now</a> |
| 33  | <a href="#">9778060620</a><br>Screw, tapping(6k8)                            | <a href="#">Buy now</a> |
| 34  | <a href="#">9046423199</a><br>Clamp(4hm)                                     | <a href="#">Buy now</a> |
| 35  | <a href="#">60V8217000</a><br>Fuse box assembly<br>Go to P/N ) PE0-OM-070043 | <a href="#">Buy now</a> |
| 36  | <a href="#">60V8215100</a><br>Fuse (100A)<br>Go to P/N ) PE0-OM-070043       | <a href="#">Buy now</a> |

## Electrical 3



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 37  | <a href="#">68F8195A00</a><br>Relay assembly           | <a href="#">Buy now</a> |
| 38  | <a href="#">67F8215100</a><br>Fuse                     | <a href="#">Buy now</a> |
| 39  | <a href="#">67F8215110</a><br>Fuse                     | <a href="#">Buy now</a> |
| 40  | <a href="#">68F8284600</a><br>Screw, pan head (m5)     | <a href="#">Buy now</a> |
| 41  | <a href="#">9778050620</a><br>Screw, tapping           | <a href="#">Buy now</a> |
| 42  | <a href="#">60V8554400</a><br>Case                     | <a href="#">Buy now</a> |
| 43  | <a href="#">67F2812A00</a><br>Puller, fuse             | <a href="#">Buy now</a> |
| 44  | <a href="#">60V8215700</a><br>Damper                   | <a href="#">Buy now</a> |
| 45  | <a href="#">60V8133600</a><br>Grommet                  | <a href="#">Buy now</a> |
| 46  | <a href="#">60V8133610</a><br>Grommet                  | <a href="#">Buy now</a> |
| 47  | <a href="#">60V8112800</a><br>Clamp                    | <a href="#">Buy now</a> |
| 49  | <a href="#">60V8194210</a><br>Cover                    | <a href="#">Buy now</a> |
| 50  | <a href="#">9046408004</a><br>Clamp                    | <a href="#">Buy now</a> |
| 51  | <a href="#">60V8217600</a><br>Damper                   | <a href="#">Buy now</a> |
| 53  | <a href="#">9016905M00</a><br>Screw truss head tapping | <a href="#">Buy now</a> |


## Electrical 3



**F5**

| Ref | Part                                                                          |                         |
|-----|-------------------------------------------------------------------------------|-------------------------|
| 54  | <a href="#">65L8588600</a><br>Thermosensor                                    | <a href="#">Buy now</a> |
| 55  | <a href="#">60V8555300</a><br>Nut Rotor                                       | <a href="#">Buy now</a> |
| 56  | <a href="#">9020112M34</a><br>Washer (692)                                    | <a href="#">Buy now</a> |
| 57  | <a href="#">60V8191900</a><br>Graphic, Regulator<br>Go to P/N ) PE0-OM-070043 | <a href="#">Buy now</a> |
| 58  | <a href="#">60V8191910</a><br>Graphic, regulator                              | <a href="#">Buy now</a> |
| 59  | <a href="#">69J8194900</a><br>Wire, lead (isolator, 3.8m )<br>AP              | <a href="#">Buy now</a> |

## Electrical 4




60V1010-3190

**A4**


| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V8258800</a><br>Plate                  | <a href="#">Buy now</a> |
| 2   | <a href="#">9709506012</a><br>Bolt(gh1)              | <a href="#">Buy now</a> |
| 3   | <a href="#">9299506600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |
| 4   | <a href="#">61A8579000</a><br>Thermosensor assembly  | <a href="#">Buy now</a> |
| 5   | <a href="#">9299010600</a><br>Washer, plate          | <a href="#">Buy now</a> |
| 6   | <a href="#">61A8589500</a><br>Crank position sender  | <a href="#">Buy now</a> |
| 7   | <a href="#">9788505012</a><br>Screw,pan head (646)   | <a href="#">Buy now</a> |
| 8   | <a href="#">6888256010</a><br>Thermo switch assembly | <a href="#">Buy now</a> |
| 9   | <a href="#">9044610M87</a><br>Hose                   | <a href="#">Buy now</a> |

# Fuel 1




| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 1   | <a href="#">61A2431300</a><br>Pipe 3            | <a href="#">Buy now</a> |
| 2   | <a href="#">9046413M34</a><br>Clamp(6r3)        | <a href="#">Buy now</a> |
| 3   | <a href="#">9044513M17</a><br>Hose(l2700)       | <a href="#">Buy now</a> |
| 4   | <a href="#">6R32437700</a><br>Pipe, joint 3     | <a href="#">Buy now</a> |
| 5   | <a href="#">6R32437710</a><br>Pipe, joint 3     | <a href="#">Buy now</a> |
| 6   | <a href="#">6E58259400</a><br>Clamp             | <a href="#">Buy now</a> |
| 7   | <a href="#">9046511M10</a><br>Clamp             | <a href="#">Buy now</a> |
| 8   | <a href="#">68F2456010</a><br>Filter assembly   | <a href="#">Buy now</a> |
| 9   | <a href="#">68F2456210</a><br>Cup, filter       | <a href="#">Buy now</a> |
| 10  | <a href="#">68F2451910</a><br>Clip              | <a href="#">Buy now</a> |
| 11  | <a href="#">68F2446910</a><br>Float Water Level | <a href="#">Buy now</a> |
| 12  | <a href="#">65L2453101</a><br>Nut               | <a href="#">Buy now</a> |
| 13  | <a href="#">61A2456400</a><br>O-ring            | <a href="#">Buy now</a> |
| 14  | <a href="#">68F2456310</a><br>Element, filter   | <a href="#">Buy now</a> |
| 15  | <a href="#">65L2456400</a><br>Gasket            | <a href="#">Buy now</a> |

# Fuel 1




| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">60H2455800</a><br>Holder, filter         | <a href="#">Buy now</a> |
| 17  | <a href="#">9759506416</a><br>Bolt, with washer(62x) | <a href="#">Buy now</a> |
| 18  | <a href="#">9020106068</a><br>Washer,plate (6k8)     | <a href="#">Buy now</a> |
| 19  | <a href="#">68F2456600</a><br>Bracket, filter        | <a href="#">Buy now</a> |
| 20  | <a href="#">9759506514</a><br>Bolt(gj3)              | <a href="#">Buy now</a> |
| 21  | <a href="#">9038706M60</a><br>Collar (6h3)           | <a href="#">Buy now</a> |
| 22  | <a href="#">9048010M23</a><br>Grommet(6k7)           | <a href="#">Buy now</a> |
| 23  | <a href="#">9011906M88</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 24  | <a href="#">68F2431100</a><br>Pipe, Fuel 1           | <a href="#">Buy now</a> |
| 26  | <a href="#">6E52437800</a><br>Pipe, joint 3          | <a href="#">Buy now</a> |
| 27  | <a href="#">6G52431500</a><br>Pipe 5                 | <a href="#">Buy now</a> |
| 28  | <a href="#">9044719004</a><br>Hose, with spring      | <a href="#">Buy now</a> |
| 29  | <a href="#">6E52431500</a><br>Pipe 5                 | <a href="#">Buy now</a> |
| 30  | <a href="#">6E52441003</a><br>Fuel pump assembly     | <a href="#">Buy now</a> |
| 31  | <a href="#">6E52444400</a><br>Screw                  | <a href="#">Buy now</a> |

# Fuel 1



| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 32  | <a href="#">6E52441300</a><br>Body 2            | <a href="#">Buy now</a> |
| 33  | <a href="#">6E52447100</a><br>Diaphragm         | <a href="#">Buy now</a> |
| 34  | <a href="#">6E52443500</a><br>Gasket, body 2    | <a href="#">Buy now</a> |
| 35  | <a href="#">6E52441100</a><br>Diaphragm         | <a href="#">Buy now</a> |
| 36  | <a href="#">6482442400</a><br>Seat, spring      | <a href="#">Buy now</a> |
| 37  | <a href="#">6E52442300</a><br>Spring, diaphragm | <a href="#">Buy now</a> |
| 38  | <a href="#">6E52443402</a><br>Gasket, body      | <a href="#">Buy now</a> |
| 39  | <a href="#">6A02442101</a><br>Valve, check      | <a href="#">Buy now</a> |
| 40  | <a href="#">6A01432500</a><br>Screw, pan head   | <a href="#">Buy now</a> |
| 41  | <a href="#">9538003600</a><br>Nut (6g8)         | <a href="#">Buy now</a> |
| 42  | <a href="#">6E52441210</a><br>Body 1            | <a href="#">Buy now</a> |
| 43  | <a href="#">65024431A0</a><br>Gasket, fuel pump | <a href="#">Buy now</a> |
| 44  | <a href="#">9010106M00</a><br>Bolt(682)         | <a href="#">Buy now</a> |
| 45  | <a href="#">6G52431610</a><br>Pipe 6            | <a href="#">Buy now</a> |
| 46  | <a href="#">6E52431300</a><br>Pipe 3            | <a href="#">Buy now</a> |


# Fuel 1



E2

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 49  | <a href="#">65L8355700</a><br>Tube                          | <a href="#">Buy now</a> |
| 50  | <a href="#">9044615M07</a><br>Hose(6g4)                     | <a href="#">Buy now</a> |
| 51  | <a href="#">9044513M12</a><br>Hose (L235)                   | <a href="#">Buy now</a> |
| 52  | <a href="#">61H2819R31</a><br>Tag Warning                   | <a href="#">Buy now</a> |
| 53  | <a href="#">68F2810000</a><br>Tool kit                      | <a href="#">Buy now</a> |
| 54  | <a href="#">6D02819970E0</a><br>Om z300aet0, '04<br>UR (E)  | <a href="#">Buy now</a> |
| 54  | <a href="#">6D02819970D0</a><br>Om z300aet0, '04<br>UR (NL) | <a href="#">Buy now</a> |
| 54  | <a href="#">6D02819970F0</a><br>Om z300aet0, '04<br>UR (F)  | <a href="#">Buy now</a> |
| 54  | <a href="#">6D02819970G0</a><br>Om z300aet0, '04<br>UR (D)  | <a href="#">Buy now</a> |
| 54  | <a href="#">6D02819970H0</a><br>Om z300aet0, '04<br>UR (I)  | <a href="#">Buy now</a> |
| 54  | <a href="#">6D02819970S0</a><br>Om z300aet0, '04<br>UR (ES) | <a href="#">Buy now</a> |
| 55  | <a href="#">6D02819980K0</a><br>-<br>UR (DK)                | <a href="#">Buy now</a> |
| 55  | <a href="#">6D02819980L0</a><br>-<br>UR (SF)                | <a href="#">Buy now</a> |
| 55  | <a href="#">6D02819980M0</a><br>-<br>UR (S)                 | <a href="#">Buy now</a> |
| 55  | <a href="#">6D02819980N0</a><br>-<br>UR (NL)                | <a href="#">Buy now</a> |


# Fuel 1



**E2**

| Ref | Part                                         |                         |
|-----|----------------------------------------------|-------------------------|
| 55  | <a href="#">6D02819980P0</a><br>-<br>UR (P)  | <a href="#">Buy now</a> |
| 55  | <a href="#">6D02819980R0</a><br>-<br>UR (GR) | <a href="#">Buy now</a> |

## Fuel 2




  
60X1300-3150

**E5**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6YK2430742</a><br>Fuel pipe comp. 2<br>AP | <a href="#">Buy now</a> |
| 2   | <a href="#">9045010M07</a><br>Hose, clamp<br>AP       | <a href="#">Buy now</a> |


# Fuel Injection Nozzle



**D1**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 1   | <a href="#">68F1376700</a><br>Cap, injector             | <a href="#">Buy now</a> |
| 2   | <a href="#">9011908M60</a><br>Bolt (682)                | <a href="#">Buy now</a> |
| 3   | <a href="#">60V1378200</a><br>Stay                      | <a href="#">Buy now</a> |
| 4   | <a href="#">9038708M31</a><br>Collar                    | <a href="#">Buy now</a> |
| 5   | <a href="#">9011008M04</a><br>Bolt, hexagon socket head | <a href="#">Buy now</a> |
| 6   | <a href="#">60V1316100</a><br>Pipe Delivery 1           | <a href="#">Buy now</a> |
| 7   | <a href="#">60V1317100</a><br>Pipe Delivery 2           | <a href="#">Buy now</a> |
| 8   | <a href="#">60V1389800</a><br>Holder                    | <a href="#">Buy now</a> |
| 9   | <a href="#">68F2455100</a><br>Bolt, joint               | <a href="#">Buy now</a> |
| 10  | <a href="#">68F2457600</a><br>Washer                    | <a href="#">Buy now</a> |
| 11  | <a href="#">60V1376100</a><br>Injector assembly         | <a href="#">Buy now</a> |
| 12  | <a href="#">68F1410B00</a><br>Packing kit               | <a href="#">Buy now</a> |
| 13  | <a href="#">60V1426400</a><br>Collar                    | <a href="#">Buy now</a> |
| 14  | <a href="#">65L1456500</a><br>Screw                     | <a href="#">Buy now</a> |
| 15  | <a href="#">60V8238900</a><br>Plate 2                   | <a href="#">Buy now</a> |

# Fuel Injection Nozzle



| Ref | Part                                          |                         |
|-----|-----------------------------------------------|-------------------------|
| 16  | <a href="#">60V8239800</a><br>Plate 3         | <a href="#">Buy now</a> |
| 17  | <a href="#">60V8154500</a><br>Screw 1         | <a href="#">Buy now</a> |
| 18  | <a href="#">60V8154600</a><br>Screw 2         | <a href="#">Buy now</a> |
| 19  | <a href="#">60V8238000</a><br>Sensor Pressure | <a href="#">Buy now</a> |
| 20  | <a href="#">68F8238800</a><br>Plate           | <a href="#">Buy now</a> |
| 21  | <a href="#">68F8238400</a><br>Packing kit     | <a href="#">Buy now</a> |
| 22  | <a href="#">60V1393800</a><br>Pipe            | <a href="#">Buy now</a> |
| 23  | <a href="#">60V1397300</a><br>Pipe, fuel 3    | <a href="#">Buy now</a> |
| 24  | <a href="#">68F2466A00</a><br>Packing kit     | <a href="#">Buy now</a> |
| 25  | <a href="#">60V1397400</a><br>Pipe, fuel 4    | <a href="#">Buy now</a> |
| 27  | <a href="#">65L1459600</a><br>Washer          | <a href="#">Buy now</a> |
| 28  | <a href="#">9048010M23</a><br>Grommet(6k7)    | <a href="#">Buy now</a> |
| 29  | <a href="#">9038705M00</a><br>Collar(6k7)     | <a href="#">Buy now</a> |
| 30  | <a href="#">60V1397500</a><br>Pipe Fuel 5     | <a href="#">Buy now</a> |
| 32  | <a href="#">60V1397600</a><br>Pipe, fuel 6    | <a href="#">Buy now</a> |


# Fuel Injection Nozzle



**D1**


| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 34  | <a href="#">68F1376400</a><br>Gasket (t=2.2)      | <a href="#">Buy now</a> |
| 35  | <a href="#">9751308570</a><br>Bolt, with washer   | <a href="#">Buy now</a> |
| 36  | <a href="#">9701308090</a><br>Bolt, with washer   | <a href="#">Buy now</a> |
| 37  | <a href="#">9290308600</a><br>Washer, plain (663) | <a href="#">Buy now</a> |
| 38  | <a href="#">60V1371600</a><br>Collar              | <a href="#">Buy now</a> |
| 39  | <a href="#">9701308055</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 42  | <a href="#">9044722004</a><br>Hose, with spring   | <a href="#">Buy now</a> |
| 43  | <a href="#">9044715001</a><br>Hose, with spring   | <a href="#">Buy now</a> |

# Fuel Injection Pump




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V1217000</a><br>Camshaft assembly 1      | <a href="#">Buy now</a> |
| 2   | <a href="#">60V1242400</a><br>Plate, Cartridge Inner   | <a href="#">Buy now</a> |
| 3   | <a href="#">9330600001</a><br>Brg,r-b 6000 26mm 19g ky | <a href="#">Buy now</a> |
| 4   | <a href="#">68F1217300</a><br>Cap, camshaft 1          | <a href="#">Buy now</a> |
| 5   | <a href="#">93306001U0</a><br>Bearing                  | <a href="#">Buy now</a> |
| 6   | <a href="#">68F1222300</a><br>Seal                     | <a href="#">Buy now</a> |
| 7   | <a href="#">68F1243900</a><br>O-ring                   | <a href="#">Buy now</a> |
| 8   | <a href="#">60V1217100</a><br>Camshaft 1               | <a href="#">Buy now</a> |
| 9   | <a href="#">68F1222800</a><br>Bolt                     | <a href="#">Buy now</a> |
| 10  | <a href="#">68F1345500</a><br>Plug                     | <a href="#">Buy now</a> |
| 11  | <a href="#">68F1347300</a><br>O-ring                   | <a href="#">Buy now</a> |
| 13  | <a href="#">60V1399300</a><br>Cover, control rack      | <a href="#">Buy now</a> |
| 14  | <a href="#">60W1399300</a><br>Cover Control Rack       | <a href="#">Buy now</a> |
| 15  | <a href="#">65L1456500</a><br>Screw                    | <a href="#">Buy now</a> |
| 16  | <a href="#">68F2457900</a><br>Washer 2                 | <a href="#">Buy now</a> |

# Fuel Injection Pump




| Ref | Part                                             |                         |
|-----|--------------------------------------------------|-------------------------|
| 17  | <a href="#">60V1385400</a><br>Plate 4            | <a href="#">Buy now</a> |
| 18  | <a href="#">60V1391000</a><br>Fuel Pump assembly | <a href="#">Buy now</a> |
| 19  | <a href="#">60V1400500</a><br>Ring, seal         | <a href="#">Buy now</a> |
| 20  | <a href="#">60V1412600</a><br>Gasket             | <a href="#">Buy now</a> |
| 21  | <a href="#">68F2430000</a><br>Fuel pipe joint    | <a href="#">Buy now</a> |
| 22  | <a href="#">60V2417800</a><br>Bolt 3             | <a href="#">Buy now</a> |
| 23  | <a href="#">60V2417600</a><br>Bolt 1             | <a href="#">Buy now</a> |
| 24  | <a href="#">60V2437800</a><br>Pipe Joint 4       | <a href="#">Buy now</a> |
| 25  | <a href="#">60V2486400</a><br>Tube               | <a href="#">Buy now</a> |
| 26  | <a href="#">60V2510T00</a><br>Tube               | <a href="#">Buy now</a> |
| 27  | <a href="#">68F1381500</a><br>Joint 1            | <a href="#">Buy now</a> |
| 28  | <a href="#">68F2466A00</a><br>Packing kit        | <a href="#">Buy now</a> |
| 29  | <a href="#">60V1381600</a><br>Joint 2            | <a href="#">Buy now</a> |
| 30  | <a href="#">68F2448600</a><br>O-ring             | <a href="#">Buy now</a> |
| 32  | <a href="#">60V1350500</a><br>Joint Comp.        | <a href="#">Buy now</a> |

# Fuel Injection Pump



| Ref | Part                                       |                         |
|-----|--------------------------------------------|-------------------------|
| 34  | <a href="#">60V1347300</a><br>Seal         | <a href="#">Buy now</a> |
| 35  | <a href="#">60V1414800</a><br>Pipe         | <a href="#">Buy now</a> |
| 36  | <a href="#">65L2438700</a><br>Clip         | <a href="#">Buy now</a> |
| 37  | <a href="#">60V2431200</a><br>Pipe 2       | <a href="#">Buy now</a> |
| 38  | <a href="#">68F2435600</a><br>Clip, pipe 1 | <a href="#">Buy now</a> |
| 39  | <a href="#">60V2431300</a><br>Pipe 3       | <a href="#">Buy now</a> |
| 41  | <a href="#">60V1414900</a><br>Pipe         | <a href="#">Buy now</a> |
| 43  | <a href="#">60V2431400</a><br>Pipe 4       | <a href="#">Buy now</a> |
| 45  | <a href="#">60V2431500</a><br>Pipe 5       | <a href="#">Buy now</a> |
| 47  | <a href="#">60V1397200</a><br>Pipe, fuel 2 | <a href="#">Buy now</a> |


# Fuel Pump Drive Gear



**C1**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V115980094</a><br>Bracket, tensioner   | <a href="#">Buy now</a> |
| 2   | <a href="#">9701308055</a><br>Bolt, hexagon          | <a href="#">Buy now</a> |
| 3   | <a href="#">9290308600</a><br>Washer, plain (663)    | <a href="#">Buy now</a> |
| 4   | <a href="#">60V1159000</a><br>Tensioner assembly     | <a href="#">Buy now</a> |
| 5   | <a href="#">9011910M72</a><br>Bolt, with washer(6m6) | <a href="#">Buy now</a> |
| 6   | <a href="#">6D01211300</a><br>Spring, valve inner    | <a href="#">Buy now</a> |
| 7   | <a href="#">9044515002</a><br>Hose (I30)             | <a href="#">Buy now</a> |
| 8   | <a href="#">60V1159500</a><br>Plate, valve           | <a href="#">Buy now</a> |
| 9   | <a href="#">9701308012</a><br>Bolt(62e)              | <a href="#">Buy now</a> |
| 10  | <a href="#">60V4624100</a><br>Belt                   | <a href="#">Buy now</a> |
| 11  | <a href="#">68F115790194</a><br>Coupling, flywheel   | <a href="#">Buy now</a> |
| 13  | <a href="#">68F115360094</a><br>Gear, drive          | <a href="#">Buy now</a> |
| 14  | <a href="#">9360510108</a><br>Pin, dowel (8g8)       | <a href="#">Buy now</a> |
| 15  | <a href="#">60V1155700</a><br>Washer 1               | <a href="#">Buy now</a> |
| 16  | <a href="#">9020108M00</a><br>Washer, plate(6e0)     | <a href="#">Buy now</a> |

## Fuel Pump Drive Gear




60V2100-C060

**C1**

| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 17  | <a href="#">9709508025</a><br>Bolt (62g)                | <a href="#">Buy now</a> |
| 18  | <a href="#">68F115370094</a><br>Gear, driven            | <a href="#">Buy now</a> |
| 19  | <a href="#">9028003M01</a><br>Key woodruff 146115450000 | <a href="#">Buy now</a> |
| 20  | <a href="#">9570708600</a><br>Nut, flange(jn5)          | <a href="#">Buy now</a> |


# Generator



**E6**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V8145000</a><br>Rotor assembly          | <a href="#">Buy now</a> |
| 2   | <a href="#">60V8141001</a><br>Stator assembly         | <a href="#">Buy now</a> |
| 3   | <a href="#">60V8558000</a><br>Coil, pulser            | <a href="#">Buy now</a> |
| 4   | <a href="#">61A8372100</a><br>Cover                   | <a href="#">Buy now</a> |
| 5   | <a href="#">9701306035</a><br>Bolt(3rv)               | <a href="#">Buy now</a> |
| 6   | <a href="#">9290306100</a><br>Washer(6a1)             | <a href="#">Buy now</a> |
| 7   | <a href="#">9290306600</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 8   | <a href="#">9788505030</a><br>Ybs86-530 screw,panhead | <a href="#">Buy now</a> |
| 9   | <a href="#">9299505100</a><br>Ybs67-5 washer, spring  | <a href="#">Buy now</a> |
| 10  | <a href="#">9299505600</a><br>Washer, plain (646)     | <a href="#">Buy now</a> |
| 11  | <a href="#">9028005015</a><br>Key, woodruff           | <a href="#">Buy now</a> |
| 12  | <a href="#">9017024M22</a><br>Nut(61a)                | <a href="#">Buy now</a> |
| 13  | <a href="#">9020125M02</a><br>Washer, plate(61a)      | <a href="#">Buy now</a> |
| 14  | <a href="#">60V8133200</a><br>Plate Timing            | <a href="#">Buy now</a> |
| 15  | <a href="#">9788506010</a><br>Screw pan head          | <a href="#">Buy now</a> |


# Generator



**E6**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 16  | <a href="#">9299506600</a><br>Washer, plain (646)      | <a href="#">Buy now</a> |
| 17  | <a href="#">9046506M86</a><br>Clamp                    | <a href="#">Buy now</a> |
| 18  | <a href="#">60V8133700</a><br>Cover, flywheel          | <a href="#">Buy now</a> |
| 19  | <a href="#">6638231701</a><br>Damper, ignition coil    | <a href="#">Buy now</a> |
| 20  | <a href="#">6244254200</a><br>Collar                   | <a href="#">Buy now</a> |
| 21  | <a href="#">6A08231700</a><br>Damper, ignition coil    | <a href="#">Buy now</a> |
| 22  | <a href="#">9589506030</a><br>Bolt, flange deep recess | <a href="#">Buy now</a> |
| 23  | <a href="#">60V1448800</a><br>Label, caution           | <a href="#">Buy now</a> |
| 24  | <a href="#">6A18362551</a><br>Mark 5                   | <a href="#">Buy now</a> |
| 25  | <a href="#">6A18362541</a><br>Mark 5                   | <a href="#">Buy now</a> |
| 26  | <a href="#">6E58571160</a><br>Mark Caution             | <a href="#">Buy now</a> |
| 27  | <a href="#">6K18362341</a><br>Mark 3                   | <a href="#">Buy now</a> |
| 28  | <a href="#">6K18362350</a><br>Mark 3                   | <a href="#">Buy now</a> |


# Intake



**D3**


| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 1   | <a href="#">6D01361000</a><br>Reed valve assembly  | <a href="#">Buy now</a> |
| 2   | <a href="#">60VW000400</a><br>Reed set             | <a href="#">Buy now</a> |
| 3   | <a href="#">60V13621A0</a><br>Gasket, Valve Seat   | <a href="#">Buy now</a> |
| 4   | <a href="#">9788005016</a><br>Screw, pan head(6b0) | <a href="#">Buy now</a> |
| 5   | <a href="#">9299005600</a><br>Washer, plain (646)  | <a href="#">Buy now</a> |
| 6   | <a href="#">60V13624001S</a><br>Plate Reed Valve   | <a href="#">Buy now</a> |
| 7   | <a href="#">60V1355200</a><br>Nozzle               | <a href="#">Buy now</a> |
| 8   | <a href="#">60V1357200</a><br>Nozzle               | <a href="#">Buy now</a> |
| 9   | <a href="#">60V1137900</a><br>Valve, check         | <a href="#">Buy now</a> |
| 10  | <a href="#">6F61137001</a><br>Check valve assembly | <a href="#">Buy now</a> |
| 11  | <a href="#">9044507M03</a><br>Hose (I200)          | <a href="#">Buy now</a> |
| 12  | <a href="#">9044507016</a><br>Hose (I60)           | <a href="#">Buy now</a> |
| 13  | <a href="#">9044507015</a><br>Hose (I65)           | <a href="#">Buy now</a> |
| 14  | <a href="#">60V1136900</a><br>Valve Check          | <a href="#">Buy now</a> |
| 15  | <a href="#">6501137001</a><br>Check valve assembly | <a href="#">Buy now</a> |

# Intake




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">9010506028</a><br>Bolt, washer based        | <a href="#">Buy now</a> |
| 17  | <a href="#">60V1364600</a><br>Gasket, manifold 2        | <a href="#">Buy now</a> |
| 18  | <a href="#">60V1364500</a><br>Gasket, manifold 1        | <a href="#">Buy now</a> |
| 19  | <a href="#">9701306060</a><br>Bolt, hexagon             | <a href="#">Buy now</a> |
| 20  | <a href="#">9290306600</a><br>Washer, plain (646)       | <a href="#">Buy now</a> |
| 21  | <a href="#">9567006660</a><br>Bolt, stud                | <a href="#">Buy now</a> |
| 22  | <a href="#">9017906M24</a><br>Nut(6j8)                  | <a href="#">Buy now</a> |
| 23  | <a href="#">60V1444000</a><br>Silencer assembly, intake | <a href="#">Buy now</a> |
| 24  | <a href="#">60V1447600</a><br>Seal                      | <a href="#">Buy now</a> |
| 25  | <a href="#">9044507M44</a><br>Hose (I390)               | <a href="#">Buy now</a> |
| 26  | <a href="#">9015906M16</a><br>Screw, with washer(61a)   | <a href="#">Buy now</a> |
| 27  | <a href="#">68F1111900</a><br>Hanger, engine            | <a href="#">Buy now</a> |
| 28  | <a href="#">9011906MA2</a><br>Bolt, with washer         | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D045300208D</a><br>Lower Unit assembly<br>X | <a href="#">Buy now</a> |
| 1   | <a href="#">6D045300308D</a><br>Lower unit assembly<br>U | <a href="#">Buy now</a> |
| 2   | <a href="#">6D045301008D</a><br>-                        | <a href="#">Buy now</a> |
| 3   | <a href="#">9331183280</a><br>Ball bearing               | <a href="#">Buy now</a> |
| 4   | <a href="#">93332000W1</a><br>Bearing(61a)               | <a href="#">Buy now</a> |
| 5   | <a href="#">61A455670010</a><br>Shim (t:0.10mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">61A455670012</a><br>Shim (t:0.12mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">61A455670015</a><br>Shim (t:0.15mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">61A455670018</a><br>Shim (t:0.18mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">61A455670030</a><br>Shim (t:0.30mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">61A455670040</a><br>Shim (t:0.40mm)<br>UR    | <a href="#">Buy now</a> |
| 5   | <a href="#">61A455670050</a><br>Shim (t:0.50mm)<br>UR    | <a href="#">Buy now</a> |
| 6   | <a href="#">6634436600</a><br>Damper, water seal 2       | <a href="#">Buy now</a> |
| 7   | <a href="#">9034008002</a><br>Plug, straight screw       | <a href="#">Buy now</a> |
| 8   | <a href="#">6884534110</a><br>Plug, drain                | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 9   | <a href="#">9043008020</a><br>Gasket                    | <a href="#">Buy now</a> |
| 10  | <a href="#">61A453760094</a><br>Guide, seal damper      | <a href="#">Buy now</a> |
| 11  | <a href="#">61A4532101</a><br>Plate                     | <a href="#">Buy now</a> |
| 12  | <a href="#">9321064488</a><br>93210-64488               | <a href="#">Buy now</a> |
| 13  | <a href="#">9310609014</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 14  | <a href="#">9011906M10</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 15  | <a href="#">60V4415000</a><br>Shift cam assembly        | <a href="#">Buy now</a> |
| 16  | <a href="#">9900108600</a><br>Circlip(2r6)              | <a href="#">Buy now</a> |
| 17  | <a href="#">9050111M10</a><br>Spring, compression (663) | <a href="#">Buy now</a> |
| 18  | <a href="#">61A4431101</a><br>Housing, water pump       | <a href="#">Buy now</a> |
| 19  | <a href="#">61A4432202</a><br>Insert, cartridge         | <a href="#">Buy now</a> |
| 20  | <a href="#">9321086M38</a><br>O-ring (6e5)              | <a href="#">Buy now</a> |
| 21  | <a href="#">9321037160</a><br>O-ring (6g8)              | <a href="#">Buy now</a> |
| 22  | <a href="#">6E54436500</a><br>Damper, water seal 1      | <a href="#">Buy now</a> |
| 23  | <a href="#">6E54431200</a><br>Cover, water pump housing | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 24  | <a href="#">6E54435201</a><br>Impeller                  | <a href="#">Buy now</a> |
| 25  | <a href="#">9028004M05</a><br>Key, woodruff (6e5)       | <a href="#">Buy now</a> |
| 26  | <a href="#">61A4553800</a><br>Spacer, 1                 | <a href="#">Buy now</a> |
| 27  | <a href="#">61A4552700</a><br>Collar, drive shaft       | <a href="#">Buy now</a> |
| 28  | <a href="#">9020122M01</a><br>Washer, plate(61a)        | <a href="#">Buy now</a> |
| 29  | <a href="#">9020622M19</a><br>Washer, wave(61a)         | <a href="#">Buy now</a> |
| 30  | <a href="#">6G54432300</a><br>Outer plate, cartridge    | <a href="#">Buy now</a> |
| 31  | <a href="#">6E544315A0</a><br>Gasket,water pump         | <a href="#">Buy now</a> |
| 32  | <a href="#">9360612019</a><br>Pin, dowel (614)          | <a href="#">Buy now</a> |
| 33  | <a href="#">9011908M14</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 34  | <a href="#">61A453310094</a><br>Housing, bearing        | <a href="#">Buy now</a> |
| 35  | <a href="#">9310128M16</a><br>Oil seal (6e5)            | <a href="#">Buy now</a> |
| 36  | <a href="#">93317330U2</a><br>Bearing, cylindrical(6k0) | <a href="#">Buy now</a> |
| 37  | <a href="#">61A455870010</a><br>Shim (t:0.10mm)<br>UR   | <a href="#">Buy now</a> |
| 37  | <a href="#">61A455870012</a><br>Shim (t:0.12mm)<br>UR   | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 37  | <a href="#">61A455870015</a><br>Shim (t:0.15mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">61A455870018</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">61A455870030</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">61A455870040</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 37  | <a href="#">61A455870050</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 38  | <a href="#">93341930U9</a><br>Bearing                 | <a href="#">Buy now</a> |
| 39  | <a href="#">9321055M14</a><br>O-ring (70e)            | <a href="#">Buy now</a> |
| 40  | <a href="#">6E54534400</a><br>Cover, oil seal         | <a href="#">Buy now</a> |
| 41  | <a href="#">9709508025</a><br>Bolt (62g)              | <a href="#">Buy now</a> |
| 42  | <a href="#">9299508600</a><br>Washer, plain (663)     | <a href="#">Buy now</a> |
| 43  | <a href="#">60V4550120</a><br>-<br>X                  | <a href="#">Buy now</a> |
| 43  | <a href="#">60V4550130</a><br>Drive shaft comp.<br>U  | <a href="#">Buy now</a> |
| 44  | <a href="#">60X4555100</a><br>Pinion                  | <a href="#">Buy now</a> |
| 45  | <a href="#">9020116M00</a><br>Washer, plate(6t5)      | <a href="#">Buy now</a> |
| 46  | <a href="#">9017016M19</a><br>Nut(6t5)                | <a href="#">Buy now</a> |

## Lower Casing & Drive 1




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 47  | <a href="#">60X4556000</a><br>Gear                     | <a href="#">Buy now</a> |
| 48  | <a href="#">60V4561100</a><br>Shaft, propeller         | <a href="#">Buy now</a> |
| 49  | <a href="#">61A4564102</a><br>Shifter                  | <a href="#">Buy now</a> |
| 50  | <a href="#">61A4563401</a><br>Slide, shift             | <a href="#">Buy now</a> |
| 51  | <a href="#">61A4563200</a><br>Pin, cross               | <a href="#">Buy now</a> |
| 52  | <a href="#">60V4563100</a><br>Clutch, dog              | <a href="#">Buy now</a> |
| 53  | <a href="#">61A4563300</a><br>Ring, cross pin          | <a href="#">Buy now</a> |
| 54  | <a href="#">6H14566800</a><br>Shaft, free 1            | <a href="#">Buy now</a> |
| 55  | <a href="#">61A4563500</a><br>Plunger, shift           | <a href="#">Buy now</a> |
| 56  | <a href="#">9020102M00</a><br>Washer, plate(61a)       | <a href="#">Buy now</a> |
| 57  | <a href="#">9018302M03</a><br>Nut, spring (6h1)        | <a href="#">Buy now</a> |
| 58  | <a href="#">9050110M77</a><br>Spring, compression(61a) | <a href="#">Buy now</a> |
| 59  | <a href="#">9350104011</a><br>Ball                     | <a href="#">Buy now</a> |
| 60  | <a href="#">6D0453320094</a><br>Housing, bearing       | <a href="#">Buy now</a> |
| 61  | <a href="#">9959010114</a><br>Pin, dowel               | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 62  | <a href="#">93306210U0</a><br>Bearing(61a)            | <a href="#">Buy now</a> |
| 63  | <a href="#">69L4557100</a><br>Gear                    | <a href="#">Buy now</a> |
| 64  | <a href="#">9020131M00</a><br>Washer, plate(61a)      | <a href="#">Buy now</a> |
| 65  | <a href="#">61A455770010</a><br>Shim (t:0.10mm)<br>UR | <a href="#">Buy now</a> |
| 65  | <a href="#">61A455770012</a><br>Shim (t:0.12mm)<br>UR | <a href="#">Buy now</a> |
| 65  | <a href="#">61A455770015</a><br>Shim (t:0.15mm)<br>UR | <a href="#">Buy now</a> |
| 65  | <a href="#">61A455770018</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 65  | <a href="#">61A455770030</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 65  | <a href="#">61A455770040</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 65  | <a href="#">61A455770050</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 66  | <a href="#">9331543064</a><br>Bearing                 | <a href="#">Buy now</a> |
| 67  | <a href="#">9310130002</a><br>Oil seal                | <a href="#">Buy now</a> |
| 68  | <a href="#">9321104384</a><br>O-ring (705)            | <a href="#">Buy now</a> |
| 69  | <a href="#">9010508049</a><br>Bolt, flange            | <a href="#">Buy now</a> |
| 70  | <a href="#">9020108023</a><br>Washer, plate           | <a href="#">Buy now</a> |

# Lower Casing & Drive 1




| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 71  | <a href="#">9370009M00</a><br>Nipple, grease(6t4) | <a href="#">Buy now</a> |
| 72  | <a href="#">6D045361008D</a><br>Cap, lower casing | <a href="#">Buy now</a> |
| 73  | <a href="#">9709508020</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |

## Lower Casing & Drive 2



| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E54436600</a><br>Damper, water seal 2    | <a href="#">Buy now</a> |
| 2   | <a href="#">61A4436120</a><br>Tube, water<br>X        | <a href="#">Buy now</a> |
| 2   | <a href="#">61A4436130</a><br>Tube, water<br>U        | <a href="#">Buy now</a> |
| 3   | <a href="#">6E54436500</a><br>Damper, water seal 1    | <a href="#">Buy now</a> |
| 4   | <a href="#">9044509024</a><br>Hose (l485)<br>U        | <a href="#">Buy now</a> |
| 4   | <a href="#">9044509111</a><br>Hose (l1500)<br>X       | <a href="#">Buy now</a> |
| 5   | <a href="#">9046708M10</a><br>Clip, pipe 6162435600   | <a href="#">Buy now</a> |
| 6   | <a href="#">9046415006</a><br>Clamp                   | <a href="#">Buy now</a> |
| 7   | <a href="#">9046415005</a><br>Clamp                   | <a href="#">Buy now</a> |
| 8   | <a href="#">9360812M05</a><br>Pin, dowel b (6e5)      | <a href="#">Buy now</a> |
| 9   | <a href="#">9709510045</a><br>Bolt(64d)               | <a href="#">Buy now</a> |
| 10  | <a href="#">9299510100</a><br>Ybs67-10 washer, spring | <a href="#">Buy now</a> |
| 11  | <a href="#">9299510600</a><br>Washer, plate           | <a href="#">Buy now</a> |
| 12  | <a href="#">9011910MA2</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 13  | <a href="#">6D04537500</a><br>Damper, seal            | <a href="#">Buy now</a> |


## Lower Casing & Drive 2



**D6**


| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 14  | <a href="#">61A4521410</a><br>Cover, water inlet 1 | <a href="#">Buy now</a> |
| 15  | <a href="#">61A4521510</a><br>Cover, water inlet 2 | <a href="#">Buy now</a> |
| 16  | <a href="#">9015205003</a><br>Screw, countersunk   | <a href="#">Buy now</a> |
| 17  | <a href="#">9018505002</a><br>Nut nylon (sus)(ex4) | <a href="#">Buy now</a> |
| 18  | <a href="#">69L4537100</a><br>Tab-trim             | <a href="#">Buy now</a> |
| 19  | <a href="#">9010510M00</a><br>Bolt, hexagon (663)  | <a href="#">Buy now</a> |
| 20  | <a href="#">6D04436700</a><br>Damper, water seal 3 | <a href="#">Buy now</a> |
| 21  | <a href="#">6D04436200</a><br>Tube, water 2        | <a href="#">Buy now</a> |
| 22  | <a href="#">6D04436500</a><br>Damper, water seal 1 | <a href="#">Buy now</a> |
| 23  | <a href="#">6D04436600</a><br>Damper, water seal 2 | <a href="#">Buy now</a> |
| 24  | <a href="#">69J4598700</a><br>Spacer 1             | <a href="#">Buy now</a> |
| 25  | <a href="#">6884599701</a><br>Spacer 2             | <a href="#">Buy now</a> |
| 26  | <a href="#">9299018200</a><br>Washer (6e5)         | <a href="#">Buy now</a> |
| 27  | <a href="#">9017118M04</a><br>Nut, castle (6e5)    | <a href="#">Buy now</a> |
| 28  | <a href="#">9149040030</a><br>Pin, cotter (663)    | <a href="#">Buy now</a> |

## Lower Casing & Drive 2




| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 29  | <a href="#">61A459720098</a><br>Propeller (3x14-1/2"x21"-t)<br>UR  | <a href="#">Buy now</a> |
| 29  | <a href="#">61A459740098</a><br>Propeller (3x14-1/2"x19"-t)<br>UR  | <a href="#">Buy now</a> |
| 29  | <a href="#">61A459780098</a><br>Propeller (3x15"x17"-t)<br>UR      | <a href="#">Buy now</a> |
| 29  | <a href="#">6G5459700298</a><br>Propeller (3x15-1/4 x15 -m)<br>UR  | <a href="#">Buy now</a> |
| 29  | <a href="#">6G5459720298</a><br>Propeller (3x13-3/4 x21 -m)<br>UR  | <a href="#">Buy now</a> |
| 29  | <a href="#">6G5459740398</a><br>Propeller (3x13-3/4"x19"-m2)<br>UR | <a href="#">Buy now</a> |
| 29  | <a href="#">6G5459780398</a><br>Propeller (3x13-3/4"x17"-m2)<br>UR | <a href="#">Buy now</a> |
| 29  | <a href="#">6R445970A0</a><br>Propeller (3X15-1/4"X19"-M)<br>UR    | <a href="#">Buy now</a> |
| 29  | <a href="#">6R445972A0</a><br>Propeller (3X14-7/8"X21"-M)<br>UR    | <a href="#">Buy now</a> |
| 29  | <a href="#">6R445974A0</a><br>Propeller (3X14-1/2"X23"-M)<br>UR    | <a href="#">Buy now</a> |
| 29  | <a href="#">6R445976A0</a><br>Propeller (3X14-1/2"X15"-M)<br>UR    | <a href="#">Buy now</a> |
| 29  | <a href="#">6R445978A0</a><br>Propeller (3X15-1/4"X17"-M)<br>UR    | <a href="#">Buy now</a> |

## Lower Casing & Drive 3



| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D145300208D</a><br>Lower unit assembly<br>X | <a href="#">Buy now</a> |
| 2   | <a href="#">6D045301008D</a><br>-                        | <a href="#">Buy now</a> |
| 3   | <a href="#">9331183280</a><br>Ball bearing               | <a href="#">Buy now</a> |
| 4   | <a href="#">61B4553801</a><br>Spacer 1                   | <a href="#">Buy now</a> |
| 5   | <a href="#">93315660W3</a><br>Bearing, cylindrical(61b)  | <a href="#">Buy now</a> |
| 6   | <a href="#">93341670V0</a><br>Bearing, thrust (61b)      | <a href="#">Buy now</a> |
| 7   | <a href="#">61A455670010</a><br>Shim (t:0.10mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">61A455670012</a><br>Shim (t:0.12mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">61A455670015</a><br>Shim (t:0.15mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">61A455670018</a><br>Shim (t:0.18mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">61A455670030</a><br>Shim (t:0.30mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">61A455670040</a><br>Shim (t:0.40mm)<br>UR    | <a href="#">Buy now</a> |
| 7   | <a href="#">61A455670050</a><br>Shim (t:0.50mm)<br>UR    | <a href="#">Buy now</a> |
| 8   | <a href="#">6634436600</a><br>Damper, water seal 2       | <a href="#">Buy now</a> |
| 9   | <a href="#">9034008002</a><br>Plug, straight screw       | <a href="#">Buy now</a> |


## Lower Casing & Drive 3



**E1**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 10  | <a href="#">6884534110</a><br>Plug, drain               | <a href="#">Buy now</a> |
| 11  | <a href="#">9043008020</a><br>Gasket                    | <a href="#">Buy now</a> |
| 12  | <a href="#">61A453760094</a><br>Guide, seal damper      | <a href="#">Buy now</a> |
| 13  | <a href="#">61A4532101</a><br>Plate                     | <a href="#">Buy now</a> |
| 14  | <a href="#">9321064488</a><br>93210-64488               | <a href="#">Buy now</a> |
| 15  | <a href="#">9310609014</a><br>Oil seal                  | <a href="#">Buy now</a> |
| 16  | <a href="#">9011906M10</a><br>Bolt, with washer         | <a href="#">Buy now</a> |
| 17  | <a href="#">60W4415000</a><br>Shift cam assembly        | <a href="#">Buy now</a> |
| 18  | <a href="#">9900108600</a><br>Circlip(2r6)              | <a href="#">Buy now</a> |
| 19  | <a href="#">9050111M10</a><br>Spring, compression (663) | <a href="#">Buy now</a> |
| 20  | <a href="#">61A4431101</a><br>Housing, water pump       | <a href="#">Buy now</a> |
| 21  | <a href="#">61A4432202</a><br>Insert, cartridge         | <a href="#">Buy now</a> |
| 22  | <a href="#">9321086M38</a><br>O-ring (6e5)              | <a href="#">Buy now</a> |
| 23  | <a href="#">9321037160</a><br>O-ring (6g8)              | <a href="#">Buy now</a> |
| 24  | <a href="#">6E54436500</a><br>Damper, water seal 1      | <a href="#">Buy now</a> |

## Lower Casing & Drive 3




| Ref | Part                                                         |                         |
|-----|--------------------------------------------------------------|-------------------------|
| 25  | <a href="#">6E54431200</a><br>Cover, water pump housing      | <a href="#">Buy now</a> |
| 26  | <a href="#">6E54435201</a><br>Impeller                       | <a href="#">Buy now</a> |
| 27  | <a href="#">9028004M05</a><br>Key, woodruff (6e5)            | <a href="#">Buy now</a> |
| 28  | <a href="#">61A4553800</a><br>Spacer, 1                      | <a href="#">Buy now</a> |
| 29  | <a href="#">61A4552700</a><br>Collar, drive shaft            | <a href="#">Buy now</a> |
| 30  | <a href="#">9020122M01</a><br>Washer, plate(61a)             | <a href="#">Buy now</a> |
| 31  | <a href="#">9020622M19</a><br>Washer, wave(61a)              | <a href="#">Buy now</a> |
| 32  | <a href="#">6G54432300</a><br>Outer plate, cartridge         | <a href="#">Buy now</a> |
| 33  | <a href="#">6E544315A0</a><br>Gasket,water pump              | <a href="#">Buy now</a> |
| 34  | <a href="#">9360612019</a><br>Pin, dowel (614)               | <a href="#">Buy now</a> |
| 35  | <a href="#">9011908M14</a><br>Bolt, with washer              | <a href="#">Buy now</a> |
| 36  | <a href="#">61A453310094</a><br>Housing, bearing             | <a href="#">Buy now</a> |
| 37  | <a href="#">9310128M16</a><br>Oil seal (6e5)                 | <a href="#">Buy now</a> |
| 38  | <a href="#">93317330U2</a><br>Bearing, cylindrical(6k0)      | <a href="#">Buy now</a> |
| 39  | <a href="#">61A455870010</a><br>Shim (t:0.10mm)<br><b>UR</b> | <a href="#">Buy now</a> |

## Lower Casing & Drive 3



| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 39  | <a href="#">61A455870012</a><br>Shim (t:0.12mm)<br>UR | <a href="#">Buy now</a> |
| 39  | <a href="#">61A455870015</a><br>Shim (t:0.15mm)<br>UR | <a href="#">Buy now</a> |
| 39  | <a href="#">61A455870018</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 39  | <a href="#">61A455870030</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 39  | <a href="#">61A455870040</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 39  | <a href="#">61A455870050</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 40  | <a href="#">93341930U9</a><br>Bearing                 | <a href="#">Buy now</a> |
| 41  | <a href="#">9321055M14</a><br>O-ring (70e)            | <a href="#">Buy now</a> |
| 42  | <a href="#">6E54534400</a><br>Cover, oil seal         | <a href="#">Buy now</a> |
| 43  | <a href="#">9709508025</a><br>Bolt (62g)              | <a href="#">Buy now</a> |
| 44  | <a href="#">9299508600</a><br>Washer, plain (663)     | <a href="#">Buy now</a> |
| 45  | <a href="#">60V4550120</a><br>-<br>X                  | <a href="#">Buy now</a> |
| 46  | <a href="#">60X4555100</a><br>Pinion                  | <a href="#">Buy now</a> |
| 47  | <a href="#">9020116M00</a><br>Washer, plate(6t5)      | <a href="#">Buy now</a> |
| 48  | <a href="#">9017016M19</a><br>Nut(6t5)                | <a href="#">Buy now</a> |


## Lower Casing & Drive 3



**E1**


| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 49  | <a href="#">6D14556000</a><br>-                        | <a href="#">Buy now</a> |
| 50  | <a href="#">9331762891</a><br>Bearing                  | <a href="#">Buy now</a> |
| 51  | <a href="#">9345037097</a><br>Circlip                  | <a href="#">Buy now</a> |
| 52  | <a href="#">69K4561100</a><br>Shaft, propeller         | <a href="#">Buy now</a> |
| 53  | <a href="#">61B4564101</a><br>Shifter                  | <a href="#">Buy now</a> |
| 54  | <a href="#">61A4563401</a><br>Slide, shift             | <a href="#">Buy now</a> |
| 55  | <a href="#">61A4563200</a><br>Pin, cross               | <a href="#">Buy now</a> |
| 56  | <a href="#">60V4563100</a><br>Clutch, dog              | <a href="#">Buy now</a> |
| 57  | <a href="#">61A4563300</a><br>Ring, cross pin          | <a href="#">Buy now</a> |
| 58  | <a href="#">6H14566800</a><br>Shaft, free 1            | <a href="#">Buy now</a> |
| 59  | <a href="#">61A4563500</a><br>Plunger, shift           | <a href="#">Buy now</a> |
| 60  | <a href="#">9020102M00</a><br>Washer, plate(61a)       | <a href="#">Buy now</a> |
| 61  | <a href="#">9018302M03</a><br>Nut, spring (6h1)        | <a href="#">Buy now</a> |
| 62  | <a href="#">9050110M77</a><br>Spring, compression(61a) | <a href="#">Buy now</a> |
| 63  | <a href="#">9350104011</a><br>Ball                     | <a href="#">Buy now</a> |

## Lower Casing & Drive 3



| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 64  | <a href="#">6D1453320094</a><br>Housing, bearing      | <a href="#">Buy now</a> |
| 65  | <a href="#">9959010114</a><br>Pin, dowel              | <a href="#">Buy now</a> |
| 66  | <a href="#">9333200048</a><br>Bearing(6k0)            | <a href="#">Buy now</a> |
| 67  | <a href="#">6D14557100</a><br>Gear                    | <a href="#">Buy now</a> |
| 68  | <a href="#">93341440U5</a><br>Bearing, thrust (6k0)   | <a href="#">Buy now</a> |
| 69  | <a href="#">6K1455780110</a><br>Shim (t:0.10mm)<br>UR | <a href="#">Buy now</a> |
| 69  | <a href="#">6K1455780112</a><br>Shim (t:0.12mm)<br>UR | <a href="#">Buy now</a> |
| 69  | <a href="#">6K1455780115</a><br>Shim (t:0.15mm)<br>UR | <a href="#">Buy now</a> |
| 69  | <a href="#">6K1455780118</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 69  | <a href="#">6K1455780130</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 69  | <a href="#">6K1455780140</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 69  | <a href="#">6K1455780150</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 70  | <a href="#">61B4538300</a><br>Washer, claw            | <a href="#">Buy now</a> |
| 71  | <a href="#">69K4538400</a><br>Nut                     | <a href="#">Buy now</a> |
| 72  | <a href="#">69K4557700</a><br>Shim (t:0.10mm)<br>UR   | <a href="#">Buy now</a> |


## Lower Casing & Drive 3



**E1**

| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 72  | <a href="#">69K4557710</a><br>Shim (t:0.12mm)<br>UR | <a href="#">Buy now</a> |
| 72  | <a href="#">69K4557720</a><br>Shim (t:0.15mm)<br>UR | <a href="#">Buy now</a> |
| 72  | <a href="#">69K4557730</a><br>Shim (t:0.18mm)<br>UR | <a href="#">Buy now</a> |
| 72  | <a href="#">69K4557740</a><br>Shim (t:0.30mm)<br>UR | <a href="#">Buy now</a> |
| 72  | <a href="#">69K4557750</a><br>Shim (t:0.40mm)<br>UR | <a href="#">Buy now</a> |
| 72  | <a href="#">69K4557760</a><br>Shim (t:0.50mm)<br>UR | <a href="#">Buy now</a> |
| 73  | <a href="#">9331543064</a><br>Bearing               | <a href="#">Buy now</a> |
| 74  | <a href="#">9310130002</a><br>Oil seal              | <a href="#">Buy now</a> |
| 75  | <a href="#">9321104384</a><br>O-ring (705)          | <a href="#">Buy now</a> |
| 76  | <a href="#">9010508049</a><br>Bolt, flange          | <a href="#">Buy now</a> |
| 77  | <a href="#">9020108023</a><br>Washer, plate         | <a href="#">Buy now</a> |
| 78  | <a href="#">9370009M00</a><br>Nipple, grease(6t4)   | <a href="#">Buy now</a> |
| 79  | <a href="#">6D045361008D</a><br>Cap, lower casing   | <a href="#">Buy now</a> |
| 80  | <a href="#">9709508020</a><br>Bolt, hexagon         | <a href="#">Buy now</a> |


## Lower Casing & Drive 4



**E5**


| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E54436600</a><br>Damper, water seal 2    | <a href="#">Buy now</a> |
| 2   | <a href="#">61A4436120</a><br>Tube, water<br>X        | <a href="#">Buy now</a> |
| 3   | <a href="#">6E54436500</a><br>Damper, water seal 1    | <a href="#">Buy now</a> |
| 4   | <a href="#">9044509111</a><br>Hose (I1500)<br>X       | <a href="#">Buy now</a> |
| 5   | <a href="#">9046708M10</a><br>Clip, pipe 6162435600   | <a href="#">Buy now</a> |
| 6   | <a href="#">9046415006</a><br>Clamp                   | <a href="#">Buy now</a> |
| 7   | <a href="#">9046415005</a><br>Clamp                   | <a href="#">Buy now</a> |
| 8   | <a href="#">9360812M05</a><br>Pin, dowel b (6e5)      | <a href="#">Buy now</a> |
| 9   | <a href="#">9709510045</a><br>Bolt(64d)               | <a href="#">Buy now</a> |
| 10  | <a href="#">9299510100</a><br>Ybs67-10 washer, spring | <a href="#">Buy now</a> |
| 11  | <a href="#">9299510600</a><br>Washer, plate           | <a href="#">Buy now</a> |
| 12  | <a href="#">9011910MA2</a><br>Bolt, with washer       | <a href="#">Buy now</a> |
| 13  | <a href="#">6D04537500</a><br>Damper, seal            | <a href="#">Buy now</a> |
| 14  | <a href="#">61A4521410</a><br>Cover, water inlet 1    | <a href="#">Buy now</a> |
| 15  | <a href="#">61A4521510</a><br>Cover, water inlet 2    | <a href="#">Buy now</a> |

## Lower Casing & Drive 4



| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 16  | <a href="#">9015205003</a><br>Screw, countersunk                     | <a href="#">Buy now</a> |
| 17  | <a href="#">9018505002</a><br>Nut nylon (sus)(ex4)                   | <a href="#">Buy now</a> |
| 18  | <a href="#">69L4537100</a><br>Tab-trim                               | <a href="#">Buy now</a> |
| 19  | <a href="#">9010510M00</a><br>Bolt, hexagon (663)                    | <a href="#">Buy now</a> |
| 20  | <a href="#">6D04436700</a><br>Damper, water seal 3                   | <a href="#">Buy now</a> |
| 21  | <a href="#">6D04436200</a><br>Tube, water 2                          | <a href="#">Buy now</a> |
| 22  | <a href="#">6D04436500</a><br>Damper, water seal 1                   | <a href="#">Buy now</a> |
| 23  | <a href="#">6D04436600</a><br>Damper, water seal 2                   | <a href="#">Buy now</a> |
| 24  | <a href="#">69J4598700</a><br>Spacer 1                               | <a href="#">Buy now</a> |
| 25  | <a href="#">6884599701</a><br>Spacer 2                               | <a href="#">Buy now</a> |
| 26  | <a href="#">9299018200</a><br>Washer (6e5)                           | <a href="#">Buy now</a> |
| 27  | <a href="#">9017118M04</a><br>Nut, castle (6e5)                      | <a href="#">Buy now</a> |
| 28  | <a href="#">9149040030</a><br>Pin, cotter (663)                      | <a href="#">Buy now</a> |
| 29  | <a href="#">61B459720098</a><br>Propeller (ss 3x14-1/2"x21"-tl<br>UR | <a href="#">Buy now</a> |
| 29  | <a href="#">61B459740098</a><br>Propeller (3x14-1/2"x19"-tl)<br>UR   | <a href="#">Buy now</a> |


## Lower Casing & Drive 4



**E5**


| Ref | Part                                                                     |                         |
|-----|--------------------------------------------------------------------------|-------------------------|
| 29  | <a href="#">61B459780098</a><br>Propeller (3x5"x17"-tl)<br>UR            | <a href="#">Buy now</a> |
| 29  | <a href="#">6K1459700198</a><br>Propeller (3x15-1/4"x15"-ml)<br>UR       | <a href="#">Buy now</a> |
| 29  | <a href="#">6K1459720198</a><br>Propeller (3x13-3/4"x21"-ml)<br>UR       | <a href="#">Buy now</a> |
| 29  | <a href="#">6K1459740298</a><br>Propeller (3x13-3/4"x19"-ml1)<br>UR      | <a href="#">Buy now</a> |
| 29  | <a href="#">6K1459780298</a><br>Propeller (3x13-3/4"x17"-ml1)<br>UR      | <a href="#">Buy now</a> |
| 29  | <a href="#">6R145970A0</a><br>Propeller, Ss (3 X 15-1/4" X 19"-MI)<br>UR | <a href="#">Buy now</a> |
| 29  | <a href="#">6R145972A0</a><br>Propeller (3X14-7/8"X21"-MI)<br>UR         | <a href="#">Buy now</a> |
| 29  | <a href="#">6R145974A0</a><br>Propeller (3X14-1/2"X23"-MI)<br>UR         | <a href="#">Buy now</a> |
| 29  | <a href="#">6R145976A0</a><br>Propeller (3X15-1/4"X15"-MI)<br>UR         | <a href="#">Buy now</a> |
| 29  | <a href="#">6R145978A0</a><br>Propeller (3X15-1/4"x17"-MI)<br>UR         | <a href="#">Buy now</a> |

# Meter




| Ref | Part                                                              |                         |
|-----|-------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6Y58350T03</a><br>Digital tachometer assembly<br>AP   | <a href="#">Buy now</a> |
| 2   | <a href="#">9E45004433</a><br>Housing, connector (m-4-w)<br>M-4-W | <a href="#">Buy now</a> |
| 3   | <a href="#">9E45004533</a><br>Housing, f-4-w(5pcs)<br>F-4-W       | <a href="#">Buy now</a> |
| 4   | <a href="#">9299004100</a><br>Ybs67-4 washer, spring              | <a href="#">Buy now</a> |
| 5   | <a href="#">9538004600</a><br>Nut,hex                             | <a href="#">Buy now</a> |
| 6   | <a href="#">6Y583500S5</a><br>Meter assembly<br>AP                | <a href="#">Buy now</a> |
| 7   | <a href="#">6Y583570S5</a><br>Speedometer assembly                | <a href="#">Buy now</a> |
| 10  | <a href="#">6Y583533T2</a><br>Grommet                             | <a href="#">Buy now</a> |
| 11  | <a href="#">6Y58355731</a><br>Tube                                | <a href="#">Buy now</a> |
| 12  | <a href="#">6Y58372800</a><br>Connector assembly                  | <a href="#">Buy now</a> |
| 20  | <a href="#">9046511M10</a><br>Clamp<br>AP                         | <a href="#">Buy now</a> |
| 14  | <a href="#">6Y587122S0</a><br>Cord assembly 1<br>AP               | <a href="#">Buy now</a> |
| 15  | <a href="#">6Y58355300</a><br>Wire, lead (l=2.5m)<br>AP           | <a href="#">Buy now</a> |
| 15  | <a href="#">6Y583553M0</a><br>Wire, lead (l=2.5m)<br>AP           | <a href="#">Buy now</a> |
| 16  | <a href="#">1E68215100</a><br>Fuse (10a)<br>FOR 6Y5-83553-M0      | <a href="#">Buy now</a> |

Meter




| Ref | Part                                                                 |                         |
|-----|----------------------------------------------------------------------|-------------------------|
| 17  | <a href="#">6Y58211700</a><br>Wire, lead<br>AP                       | <a href="#">Buy now</a> |
| 18  | <a href="#">68F8255380</a><br>Extension, wire lead (8m)<br>AP        | <a href="#">Buy now</a> |
| 18  | <a href="#">68F8255390</a><br>Extension, wire lead (9m)<br>AP        | <a href="#">Buy now</a> |
| 19  | <a href="#">6Y58355710</a><br>Tube (8m)<br>AP                        | <a href="#">Buy now</a> |
| 21  | <a href="#">6Y58350F00</a><br>Fuel meter movement assembly<br>AP     | <a href="#">Buy now</a> |
| 23  | <a href="#">6Y583553F1</a><br>Wire, lead<br>AP                       | <a href="#">Buy now</a> |
| 24  | <a href="#">6Y58575201</a><br>Sender unit assembly, fuel meter<br>AP | <a href="#">Buy now</a> |
| 25  | <a href="#">9015806002</a><br>Screw, Wood<br>AP                      | <a href="#">Buy now</a> |
| 27  | <a href="#">7038253100</a><br>Wire, lead<br>AP                       | <a href="#">Buy now</a> |

# Oil Pump



| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D01320000</a><br>Oil injection pump assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">6R31347100</a><br>Screw                       | <a href="#">Buy now</a> |
| 3   | <a href="#">6L21347500</a><br>Gasket, breather bolt       | <a href="#">Buy now</a> |
| 4   | <a href="#">9321019M82</a><br>O-ring(6j8)                 | <a href="#">Buy now</a> |
| 5   | <a href="#">9010906M40</a><br>Bolt(6h0)                   | <a href="#">Buy now</a> |
| 6   | <a href="#">6G51341600</a><br>Pipe, oil 1                 | <a href="#">Buy now</a> |
| 7   | <a href="#">9044617MA8</a><br>Hose (L200)                 | <a href="#">Buy now</a> |
| 8   | <a href="#">9046511M10</a><br>Clamp                       | <a href="#">Buy now</a> |
| 9   | <a href="#">9044607M35</a><br>Hose(62t)                   | <a href="#">Buy now</a> |
| 10  | <a href="#">9044507M96</a><br>Hose(62t)                   | <a href="#">Buy now</a> |
| 11  | <a href="#">9044607M48</a><br>Hose(62t)                   | <a href="#">Buy now</a> |
| 12  | <a href="#">9044507M44</a><br>Hose (l390)                 | <a href="#">Buy now</a> |
| 13  | <a href="#">9044507M46</a><br>Hose (l390)                 | <a href="#">Buy now</a> |
| 14  | <a href="#">9044507M10</a><br>Hose (L770)                 | <a href="#">Buy now</a> |
| 15  | <a href="#">9044507M04</a><br>Hose(62t)                   | <a href="#">Buy now</a> |


# Oil Pump



**D5**

| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 16  | <a href="#">6R31318300</a><br>Valve, check        | <a href="#">Buy now</a> |
| 17  | <a href="#">9046807M02</a><br>Clip (6e5)          | <a href="#">Buy now</a> |
| 18  | <a href="#">9046407M05</a><br>Clamp (6g5)         | <a href="#">Buy now</a> |
| 20  | <a href="#">9046407M20</a><br>Clamp(6h0)          | <a href="#">Buy now</a> |
| 21  | <a href="#">61A1153700</a><br>Gear, driven        | <a href="#">Buy now</a> |
| 22  | <a href="#">9020109M01</a><br>Washer, plate(61b)  | <a href="#">Buy now</a> |
| 23  | <a href="#">61A1311700</a><br>Collar, distance    | <a href="#">Buy now</a> |
| 24  | <a href="#">9321018MA9</a><br>O-ring(61a)         | <a href="#">Buy now</a> |
| 25  | <a href="#">6R54123700</a><br>Joint, link         | <a href="#">Buy now</a> |
| 26  | <a href="#">65L4124110</a><br>-                   | <a href="#">Buy now</a> |
| 27  | <a href="#">9538005600</a><br>Nut, hexagon (663)  | <a href="#">Buy now</a> |
| 28  | <a href="#">6H14123700</a><br>Joint, link         | <a href="#">Buy now</a> |
| 29  | <a href="#">9149012012</a><br>Pin, cotter (6g8)   | <a href="#">Buy now</a> |
| 30  | <a href="#">9020205088</a><br>Washer, plate (666) | <a href="#">Buy now</a> |
| 31  | <a href="#">60V2431900</a><br>Pipe, oil           | <a href="#">Buy now</a> |


# Oil Pump



**D5**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 33  | <a href="#">9046708M18</a><br>Clip                   | <a href="#">Buy now</a> |
| 34  | <a href="#">68F1310000</a><br>Solenoid pump assembly | <a href="#">Buy now</a> |
| 35  | <a href="#">68F1341800</a><br>Hose 4                 | <a href="#">Buy now</a> |
| 36  | <a href="#">68F1318400</a><br>Spring, oil pipe       | <a href="#">Buy now</a> |
| 37  | <a href="#">68F1344000</a><br>Filter assembly        | <a href="#">Buy now</a> |
| 38  | <a href="#">68F1316F00</a><br>Hose 1                 | <a href="#">Buy now</a> |
| 39  | <a href="#">68F1313300</a><br>Clip                   | <a href="#">Buy now</a> |
| 40  | <a href="#">68F1316G00</a><br>Hose 2                 | <a href="#">Buy now</a> |
| 41  | <a href="#">68F1316A00</a><br>Check Valve assembly   | <a href="#">Buy now</a> |
| 42  | <a href="#">68F1341600</a><br>Hose 3                 | <a href="#">Buy now</a> |
| 43  | <a href="#">68F1448500</a><br>Pipe, joint            | <a href="#">Buy now</a> |
| 44  | <a href="#">60V1319K00</a><br>Plate                  | <a href="#">Buy now</a> |
| 45  | <a href="#">9709506020</a><br>Bolt(7u8)              | <a href="#">Buy now</a> |
| 46  | <a href="#">9299506100</a><br>Washer(6a1)            | <a href="#">Buy now</a> |
| 47  | <a href="#">9299506600</a><br>Washer, plain (646)    | <a href="#">Buy now</a> |


# Oil Pump



**D5**


| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 48  | <a href="#">9011006M06</a><br>Bolt, hexagon socket head | <a href="#">Buy now</a> |

# Oil Tank




| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">61A2175000</a><br>Oil tank assembly        | <a href="#">Buy now</a> |
| 2   | <a href="#">6E51344800</a><br>Cap, oil tank            | <a href="#">Buy now</a> |
| 3   | <a href="#">9046513M11</a><br>Clamp (6e5)              | <a href="#">Buy now</a> |
| 4   | <a href="#">61A8573001</a><br>Oil level gauge assembly | <a href="#">Buy now</a> |
| 5   | <a href="#">61A1341100</a><br>Strainer, oil            | <a href="#">Buy now</a> |
| 6   | <a href="#">6E51341400</a><br>Gasket, strainer cover   | <a href="#">Buy now</a> |
| 7   | <a href="#">9044505M07</a><br>Hose (I700)              | <a href="#">Buy now</a> |
| 8   | <a href="#">6A08231700</a><br>Damper, ignition coil    | <a href="#">Buy now</a> |
| 9   | <a href="#">6244254200</a><br>Collar                   | <a href="#">Buy now</a> |
| 10  | <a href="#">9011906M65</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 11  | <a href="#">6R38259E00</a><br>Switch assembly          | <a href="#">Buy now</a> |
| 12  | <a href="#">6E52437900</a><br>Pipe, joint 4            | <a href="#">Buy now</a> |
| 13  | <a href="#">9044512M04</a><br>Hose (I3000)             | <a href="#">Buy now</a> |
| 14  | <a href="#">9046511M10</a><br>Clamp                    | <a href="#">Buy now</a> |
| 15  | <a href="#">6E52432300</a><br>Pipe 12                  | <a href="#">Buy now</a> |

# Oil Tank



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 18  | <a href="#">9046413M34</a><br>Clamp(6r3)               | <a href="#">Buy now</a> |
| 19  | <a href="#">61A2170820</a><br>Sub oil tank assembly.   | <a href="#">Buy now</a> |
| 20  | <a href="#">6E52173320</a><br>Sub tank, oil (10.5l)    | <a href="#">Buy now</a> |
| 21  | <a href="#">6E52177003</a><br>Oil tank cap assembly    | <a href="#">Buy now</a> |
| 22  | <a href="#">6E52432200</a><br>Pipe 11                  | <a href="#">Buy now</a> |
| 24  | <a href="#">6462425102</a><br>Strainer 1               | <a href="#">Buy now</a> |
| 25  | <a href="#">6E52431901</a><br>Pipe, oil                | <a href="#">Buy now</a> |
| 27  | <a href="#">6E58190001</a><br>Oil feed pump assembly   | <a href="#">Buy now</a> |
| 28  | <a href="#">6E58192200</a><br>Grommet                  | <a href="#">Buy now</a> |
| 29  | <a href="#">6E52432101</a><br>Pipe 10                  | <a href="#">Buy now</a> |
| 31  | <a href="#">9044511M26</a><br>Hose (l8000)             | <a href="#">Buy now</a> |
| 33  | <a href="#">6E58572005</a><br>Oil level gauge assembly | <a href="#">Buy now</a> |
| 34  | <a href="#">6R38572180</a><br>Wire, lead               | <a href="#">Buy now</a> |
| 35  | <a href="#">6E5217340133</a><br>Holder, oil sub tank   | <a href="#">Buy now</a> |
| 36  | <a href="#">6E5217980133</a><br>Bracket, damper        | <a href="#">Buy now</a> |

# Oil Tank




60V1300-3130

**D7**

| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 37  | <a href="#">6E52174600</a><br>Damper              | <a href="#">Buy now</a> |
| 38  | <a href="#">9708006100</a><br>Bolt, hexagon       | <a href="#">Buy now</a> |
| 39  | <a href="#">9299006600</a><br>Washer, plain (646) | <a href="#">Buy now</a> |
| 40  | <a href="#">9538006600</a><br>Nut(661)            | <a href="#">Buy now</a> |
| 42  | <a href="#">6E51343762</a><br>Mark Caution        | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy 1



**C3**

| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">60V43800004D</a><br>Power trim & tilt assembly | <a href="#">Buy now</a> |
| 2   | <a href="#">61A4384001</a><br>Power tilt assembly          | <a href="#">Buy now</a> |
| 3   | <a href="#">61A4381000</a><br>Tilt piston sub assembly     | <a href="#">Buy now</a> |
| 4   | <a href="#">61A4386100</a><br>O-ring                       | <a href="#">Buy now</a> |
| 5   | <a href="#">61A4387100</a><br>Ring, back up                | <a href="#">Buy now</a> |
| 6   | <a href="#">9310619N50</a><br>Oil seal                     | <a href="#">Buy now</a> |
| 7   | <a href="#">6H14386100</a><br>O-ring                       | <a href="#">Buy now</a> |
| 8   | <a href="#">6H14387200</a><br>Ring, back up                | <a href="#">Buy now</a> |
| 9   | <a href="#">61A4389H00</a><br>O-ring                       | <a href="#">Buy now</a> |
| 11  | <a href="#">6H14381400</a><br>Piston, free                 | <a href="#">Buy now</a> |
| 12  | <a href="#">61A4381301</a><br>Cylinder, tilt               | <a href="#">Buy now</a> |
| 13  | <a href="#">69J4388800</a><br>Bolt, socket                 | <a href="#">Buy now</a> |
| 14  | <a href="#">61A4383501</a><br>Pipe                         | <a href="#">Buy now</a> |
| 15  | <a href="#">61A4383301</a><br>Pipe                         | <a href="#">Buy now</a> |
| 16  | <a href="#">61A4381800</a><br>Pin, lower shock mount       | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy 1



**C3**

| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 17  | <a href="#">9038618M14</a><br>Bushing (6e5)               | <a href="#">Buy now</a> |
| 18  | <a href="#">6H14381700</a><br>Filter 2                    | <a href="#">Buy now</a> |
| 19  | <a href="#">9760704230</a><br>Screw, pan head with washer | <a href="#">Buy now</a> |
| 20  | <a href="#">69J4382800</a><br>Body, reservoir             | <a href="#">Buy now</a> |
| 21  | <a href="#">6H14386900</a><br>O-ring                      | <a href="#">Buy now</a> |
| 22  | <a href="#">61A4384L00</a><br>Spring Trim Down            | <a href="#">Buy now</a> |
| 23  | <a href="#">6T44385100</a><br>Seat, relief valve          | <a href="#">Buy now</a> |
| 24  | <a href="#">9760705210</a><br>Screw, With Washer          | <a href="#">Buy now</a> |
| 25  | <a href="#">61A4384K00</a><br>Plate, trim down            | <a href="#">Buy now</a> |
| 26  | <a href="#">61A4384J00</a><br>Seal, trim down             | <a href="#">Buy now</a> |
| 27  | <a href="#">93210064A5</a><br>O-ring(61a)                 | <a href="#">Buy now</a> |
| 28  | <a href="#">9350532038</a><br>Ball(7fk)                   | <a href="#">Buy now</a> |
| 29  | <a href="#">61A4387500</a><br>Ring, snap                  | <a href="#">Buy now</a> |
| 30  | <a href="#">61A4384800</a><br>Rod, manual release         | <a href="#">Buy now</a> |
| 31  | <a href="#">61A4385400</a><br>Spring, manual release      | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy 1



C3

| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 32  | <a href="#">61A4384500</a><br>Screw, manual release | <a href="#">Buy now</a> |
| 33  | <a href="#">6H14387500</a><br>Ring, snap            | <a href="#">Buy now</a> |
| 34  | <a href="#">9321018397</a><br>O-ring (6g5)          | <a href="#">Buy now</a> |
| 35  | <a href="#">61A4384700</a><br>Seat, manual valve    | <a href="#">Buy now</a> |
| 36  | <a href="#">6T44387600</a><br>Ring, snap            | <a href="#">Buy now</a> |
| 37  | <a href="#">9321007003</a><br>O-ring (11m)          | <a href="#">Buy now</a> |
| 38  | <a href="#">9321006001</a><br>O-ring (26h)          | <a href="#">Buy now</a> |
| 39  | <a href="#">6T44384900</a><br>Pin, valve support    | <a href="#">Buy now</a> |
| 40  | <a href="#">61A4385H00</a><br>Spring, seal          | <a href="#">Buy now</a> |
| 41  | <a href="#">61A4384F00</a><br>Seal, main valve      | <a href="#">Buy now</a> |
| 42  | <a href="#">6H14383100</a><br>Connector, shaft      | <a href="#">Buy now</a> |
| 43  | <a href="#">6T44383000</a><br>Gear pump assembly    | <a href="#">Buy now</a> |
| 44  | <a href="#">61A4382K00</a><br>Cap, relief valve     | <a href="#">Buy now</a> |
| 45  | <a href="#">6H14385610</a><br>Spring, down relief   | <a href="#">Buy now</a> |
| 46  | <a href="#">6T44384400</a><br>Pin, valve support    | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy 1



**C3**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 47  | <a href="#">6T44384G00</a><br>Seal, relief valve       | <a href="#">Buy now</a> |
| 48  | <a href="#">6T44385500</a><br>Spring, up relief        | <a href="#">Buy now</a> |
| 49  | <a href="#">6T44389500</a><br>Seat, relief valve       | <a href="#">Buy now</a> |
| 50  | <a href="#">9321010M74</a><br>O-ring                   | <a href="#">Buy now</a> |
| 51  | <a href="#">6H14381600</a><br>Filter 1                 | <a href="#">Buy now</a> |
| 52  | <a href="#">6T44380203</a><br>Valve sub assembly       | <a href="#">Buy now</a> |
| 53  | <a href="#">6H14386600</a><br>O-ring                   | <a href="#">Buy now</a> |
| 54  | <a href="#">6H14386700</a><br>O-ring                   | <a href="#">Buy now</a> |
| 55  | <a href="#">6T44384100</a><br>Piston, shuttle          | <a href="#">Buy now</a> |
| 56  | <a href="#">9321009165</a><br>O-ring                   | <a href="#">Buy now</a> |
| 57  | <a href="#">6H14382900</a><br>Plug, reservoir          | <a href="#">Buy now</a> |
| 58  | <a href="#">61A4387800</a><br>Bolt, socket             | <a href="#">Buy now</a> |
| 59  | <a href="#">6T44387501</a><br>Ring, snap               | <a href="#">Buy now</a> |
| 60  | <a href="#">61A4382200</a><br>Seal, trim dust          | <a href="#">Buy now</a> |
| 61  | <a href="#">61A4382100</a><br>Screw, trim cylinder end | <a href="#">Buy now</a> |


# Power Trim & Tilt Assy 1



**C3**

| Ref | Part                                                            |                         |
|-----|-----------------------------------------------------------------|-------------------------|
| 62  | <a href="#">9160910014</a><br>Pin, spring(61a)                  | <a href="#">Buy now</a> |
| 64  | <a href="#">61A4382010</a><br>Trim piston sub assembly          | <a href="#">Buy now</a> |
| 65  | <a href="#">61A4387400</a><br>Ring, back up                     | <a href="#">Buy now</a> |
| 66  | <a href="#">61A4386400</a><br>O-ring                            | <a href="#">Buy now</a> |
| 67  | <a href="#">61A4387510</a><br>Ring, snap                        | <a href="#">Buy now</a> |
| 68  | <a href="#">61A4383H11</a><br>Hose, oil 5                       | <a href="#">Buy now</a> |
| 69  | <a href="#">61A4384H10</a><br>Spring                            | <a href="#">Buy now</a> |
| 70  | <a href="#">61A4387600</a><br>Ring, snap                        | <a href="#">Buy now</a> |
| 71  | <a href="#">6T44389300</a><br>Washer                            | <a href="#">Buy now</a> |
| 72  | <a href="#">9350108001</a><br>Ball                              | <a href="#">Buy now</a> |
| 73  | <a href="#">61A4382A00</a><br>Adaptor 1                         | <a href="#">Buy now</a> |
| 74  | <a href="#">69J4388000</a><br>Motor assembly<br>REFER TO FIG.27 | <a href="#">Buy now</a> |

## Power Trim & Tilt Assy 2




60V1010-3260

C6

| Ref | Part                                            |                         |
|-----|-------------------------------------------------|-------------------------|
| 1   | <a href="#">69J4388000</a><br>Motor assembly    | <a href="#">Buy now</a> |
| 2   | <a href="#">9020614N50</a><br>Washer, wave      | <a href="#">Buy now</a> |
| 3   | <a href="#">93399999T6</a><br>Bearing           | <a href="#">Buy now</a> |
| 4   | <a href="#">69J4380500</a><br>Armature assembly | <a href="#">Buy now</a> |
| 5   | <a href="#">69J4380400</a><br>Stator assembly   | <a href="#">Buy now</a> |
| 6   | <a href="#">69J4386100</a><br>O-ring            | <a href="#">Buy now</a> |
| 7   | <a href="#">69J4388600</a><br>Bolt              | <a href="#">Buy now</a> |
| 8   | <a href="#">69J4388200</a><br>Oil seal          | <a href="#">Buy now</a> |
| 9   | <a href="#">69J4389100</a><br>Brush 1           | <a href="#">Buy now</a> |
| 10  | <a href="#">69J4386K00</a><br>Spring, brush     | <a href="#">Buy now</a> |
| 11  | <a href="#">69J4388100</a><br>Frame, end        | <a href="#">Buy now</a> |

# Remote Control Box




  
67H0100-9310

**F1**

| Ref | Part                                                                                 |                         |
|-----|--------------------------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">7034820517</a><br>Remote control assembly (10p, ptt)<br>AP WITH PT/T SW. | <a href="#">Buy now</a> |
| 2   | <a href="#">7044820723</a><br>Remote Control assembly<br>AP WITH PT/T SW.            | <a href="#">Buy now</a> |
| 3   | <a href="#">7014832050</a><br>Cable, Remote Control L=15F<br>UR                      | <a href="#">Buy now</a> |
| 3   | <a href="#">7014832060</a><br>Cable, Remote Control L=16F<br>UR                      | <a href="#">Buy now</a> |
| 3   | <a href="#">7014832080</a><br>Cable, Remote Control L=17F<br>UR                      | <a href="#">Buy now</a> |
| 3   | <a href="#">7014835000</a><br>Cable, Remote Control L=21F<br>UR                      | <a href="#">Buy now</a> |
| 3   | <a href="#">7014835020</a><br>Cable, Remote Control L=23F<br>UR                      | <a href="#">Buy now</a> |


# Repair Kit 1



**F5**


| Ref | Part                                                      |                         |
|-----|-----------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D0W000100</a><br>Power Head Gasket Kit       | <a href="#">Buy now</a> |
| 2   | <a href="#">60V1119300</a><br>Gasket, head cover 1        | <a href="#">Buy now</a> |
| 3   | <a href="#">6D01118100</a><br>Gasket, cylinder head 1     | <a href="#">Buy now</a> |
| 4   | <a href="#">9043014115</a><br>Gasket (663)                | <a href="#">Buy now</a> |
| 5   | <a href="#">60V1138100</a><br>Gasket 1                    | <a href="#">Buy now</a> |
| 6   | <a href="#">60V12414A0</a><br>Gasket, cover               | <a href="#">Buy now</a> |
| 7   | <a href="#">60V4111200</a><br>Gasket, exhaust inner cover | <a href="#">Buy now</a> |
| 8   | <a href="#">60V11382A0</a><br>Gasket 2                    | <a href="#">Buy now</a> |
| 9   | <a href="#">9310422M07</a><br>Oil seal(61a)               | <a href="#">Buy now</a> |
| 10  | <a href="#">9310340011</a><br>Oil seal                    | <a href="#">Buy now</a> |
| 11  | <a href="#">9321085M32</a><br>O-ring (173)                | <a href="#">Buy now</a> |
| 12  | <a href="#">60V1364600</a><br>Gasket, manifold 2          | <a href="#">Buy now</a> |
| 13  | <a href="#">60V1364500</a><br>Gasket, manifold 1          | <a href="#">Buy now</a> |
| 14  | <a href="#">60V1447600</a><br>Seal                        | <a href="#">Buy now</a> |
| 15  | <a href="#">9321018MA9</a><br>O-ring(61a)                 | <a href="#">Buy now</a> |

## Repair Kit 1




| Ref | Part                                                    |                         |
|-----|---------------------------------------------------------|-------------------------|
| 16  | <a href="#">60V13621A0</a><br>Gasket, Valve Seat        | <a href="#">Buy now</a> |
| 17  | <a href="#">60V1147900</a><br>O-ring                    | <a href="#">Buy now</a> |
| 18  | <a href="#">60V4511301</a><br>Gasket, upper casing      | <a href="#">Buy now</a> |
| 19  | <a href="#">6D01545100</a><br>Gasket, Crankcase Cover 1 | <a href="#">Buy now</a> |
| 20  | <a href="#">6D01546100</a><br>Gasket, crankcase cover 2 | <a href="#">Buy now</a> |
| 21  | <a href="#">6D01546200</a><br>Gasket, crankcase cover 3 | <a href="#">Buy now</a> |

## Repair Kit 2



| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D0W000120</a><br>Lower unit gasket kit    | <a href="#">Buy now</a> |
| 2   | <a href="#">61A41134A0</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 3   | <a href="#">60V4511400</a><br>Gasket, upper casing     | <a href="#">Buy now</a> |
| 4   | <a href="#">9043008020</a><br>Gasket                   | <a href="#">Buy now</a> |
| 5   | <a href="#">6D04512300</a><br>Gasket, muffler          | <a href="#">Buy now</a> |
| 6   | <a href="#">6E54436500</a><br>Damper, water seal 1     | <a href="#">Buy now</a> |
| 7   | <a href="#">6E54436600</a><br>Damper, water seal 2     | <a href="#">Buy now</a> |
| 8   | <a href="#">9321064488</a><br>93210-64488              | <a href="#">Buy now</a> |
| 9   | <a href="#">9310609014</a><br>Oil seal                 | <a href="#">Buy now</a> |
| 10  | <a href="#">9321086M38</a><br>O-ring (6e5)             | <a href="#">Buy now</a> |
| 11  | <a href="#">9321037160</a><br>O-ring (6g8)             | <a href="#">Buy now</a> |
| 12  | <a href="#">6E544315A0</a><br>Gasket, water pump       | <a href="#">Buy now</a> |
| 13  | <a href="#">9310128M16</a><br>Oil seal (6e5)           | <a href="#">Buy now</a> |
| 14  | <a href="#">9321055M14</a><br>O-ring (70e)             | <a href="#">Buy now</a> |
| 15  | <a href="#">9321104384</a><br>O-ring (705)             | <a href="#">Buy now</a> |


## Repair Kit 2



**F6**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">9310130002</a><br>Oil seal               | <a href="#">Buy now</a> |
| 17  | <a href="#">61AW0078A3</a><br>Water pump repair kit  | <a href="#">Buy now</a> |
| 18  | <a href="#">61A4432202</a><br>Insert, cartridge      | <a href="#">Buy now</a> |
| 21  | <a href="#">6E54435201</a><br>Impeller               | <a href="#">Buy now</a> |
| 22  | <a href="#">6G54432300</a><br>Outer plate, cartridge | <a href="#">Buy now</a> |
| 24  | <a href="#">9360612019</a><br>Pin, dowel (614)       | <a href="#">Buy now</a> |
| 25  | <a href="#">9011908M14</a><br>Bolt, with washer      | <a href="#">Buy now</a> |
| 26  | <a href="#">9028004M05</a><br>Key, woodruff (6e5)    | <a href="#">Buy now</a> |


# Starting Motor



**A5**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D08180000</a><br>Starting motor assembly       | <a href="#">Buy now</a> |
| 2   | <a href="#">67F8185000</a><br>Armature assembly             | <a href="#">Buy now</a> |
| 3   | <a href="#">67F8181000</a><br>Stator assembly               | <a href="#">Buy now</a> |
| 4   | <a href="#">69J8184000</a><br>Brush holder assembly         | <a href="#">Buy now</a> |
| 5   | <a href="#">69J8180100</a><br>Brush set                     | <a href="#">Buy now</a> |
| 6   | <a href="#">67F8181300</a><br>Spring, brush                 | <a href="#">Buy now</a> |
| 7   | <a href="#">68F8182000</a><br>Rear bracket assembly         | <a href="#">Buy now</a> |
| 8   | <a href="#">67F8180800</a><br>Pinion assembly               | <a href="#">Buy now</a> |
| 9   | <a href="#">67F8185700</a><br>Pinion stopper set            | <a href="#">Buy now</a> |
| 10  | <a href="#">67F8180700</a><br>Gear assembly, starting motor | <a href="#">Buy now</a> |
| 11  | <a href="#">67F8183200</a><br>Clutch, over run              | <a href="#">Buy now</a> |
| 12  | <a href="#">67F8183600</a><br>Shaft, pinion                 | <a href="#">Buy now</a> |
| 13  | <a href="#">67F8182100</a><br>Bracket, center 1             | <a href="#">Buy now</a> |
| 14  | <a href="#">67F8184100</a><br>Bearing                       | <a href="#">Buy now</a> |
| 15  | <a href="#">67F8189100</a><br>Gear, ring                    | <a href="#">Buy now</a> |


# Starting Motor



**A5**

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 16  | <a href="#">67F8183R00</a><br>Gasket                 | <a href="#">Buy now</a> |
| 17  | <a href="#">67F8183000</a><br>Bracket, center 2      | <a href="#">Buy now</a> |
| 18  | <a href="#">60V8183T00</a><br>Gear, idler            | <a href="#">Buy now</a> |
| 19  | <a href="#">67F8180900</a><br>Washer kit             | <a href="#">Buy now</a> |
| 20  | <a href="#">60X8184200</a><br>Cover                  | <a href="#">Buy now</a> |
| 21  | <a href="#">69J8183900</a><br>Lever assembly         | <a href="#">Buy now</a> |
| 22  | <a href="#">6D08194100</a><br>Starter relay assembly | <a href="#">Buy now</a> |
| 23  | <a href="#">69J8186900</a><br>Cover Dust             | <a href="#">Buy now</a> |
| 24  | <a href="#">6K78182610</a><br>Bolt                   | <a href="#">Buy now</a> |
| 25  | <a href="#">69J8182800</a><br>Bolt 2                 | <a href="#">Buy now</a> |
| 26  | <a href="#">67F8184600</a><br>Screw                  | <a href="#">Buy now</a> |
| 27  | <a href="#">9017908003</a><br>Nut                    | <a href="#">Buy now</a> |
| 28  | <a href="#">60V8192500</a><br>Terminal               | <a href="#">Buy now</a> |
| 29  | <a href="#">68F8258200</a><br>Cover, wire harness    | <a href="#">Buy now</a> |
| 30  | <a href="#">9701308045</a><br>Bolt                   | <a href="#">Buy now</a> |


# Starting Motor



**A5**

| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 31  | <a href="#">9290308600</a><br>Washer, plain (663) | <a href="#">Buy now</a> |
| 32  | <a href="#">67F8362701</a><br>Label, caution 7    | <a href="#">Buy now</a> |


# Steering Guide



**E7**

| Ref | Part                                                               |                         |
|-----|--------------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6E56135002</a><br>Steering guide attachment kit<br>AP  | <a href="#">Buy now</a> |
| 2   | <a href="#">6E56135101</a><br>Rod, steering link                   | <a href="#">Buy now</a> |
| 3   | <a href="#">9038710M61</a><br>Collar (6e5)                         | <a href="#">Buy now</a> |
| 4   | <a href="#">9056012M01</a><br>Spacer (6e5)                         | <a href="#">Buy now</a> |
| 5   | <a href="#">6E56135500</a><br>Bolt                                 | <a href="#">Buy now</a> |
| 6   | <a href="#">9018509M01</a><br>Nut, nylon (663)                     | <a href="#">Buy now</a> |
| 7   | <a href="#">9020110M20</a><br>Washer, plate (663)                  | <a href="#">Buy now</a> |
| 8   | <a href="#">6E54314501</a><br>Cap, clamp bracket                   | <a href="#">Buy now</a> |
| 9   | <a href="#">9321016275</a><br>O-ring                               | <a href="#">Buy now</a> |
| 10  | <a href="#">6E56130101</a><br>Tie bar assembly (l:600-800mm)<br>AP | <a href="#">Buy now</a> |
| 11  | <a href="#">6E56131300</a><br>Adjuster                             | <a href="#">Buy now</a> |
| 12  | <a href="#">6E56131111</a><br>Tie bar                              | <a href="#">Buy now</a> |
| 13  | <a href="#">6E56131500</a><br>Tie bar, 2                           | <a href="#">Buy now</a> |
| 14  | <a href="#">6E56130300</a><br>Steering axle comp.                  | <a href="#">Buy now</a> |
| 15  | <a href="#">9017014M06</a><br>Nut (6e5)                            | <a href="#">Buy now</a> |


# Steering Guide



**E7**


| Ref | Part                                              |                         |
|-----|---------------------------------------------------|-------------------------|
| 16  | <a href="#">9538014700</a><br>Nut (6e5)           | <a href="#">Buy now</a> |
| 17  | <a href="#">9020110M76</a><br>Washer, plate (6e5) | <a href="#">Buy now</a> |
| 18  | <a href="#">9010109M70</a><br>Bolt (6e5)          | <a href="#">Buy now</a> |
| 19  | <a href="#">9017009M05</a><br>Nut, hexagon (6e5)  | <a href="#">Buy now</a> |

## Switch & Panel



| Ref | Part                                                       |                         |
|-----|------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6K18257007</a><br>Panel switch assembly<br>AP  | <a href="#">Buy now</a> |
| 2   | <a href="#">6K18257101</a><br>Plate, panel switch          | <a href="#">Buy now</a> |
| 3   | <a href="#">6K18251006</a><br>Main switch assembly         | <a href="#">Buy now</a> |
| 4   | <a href="#">7038257700</a><br>Cap, key                     | <a href="#">Buy now</a> |
| 5   | <a href="#">6K18253200</a><br>Cap                          | <a href="#">Buy now</a> |
| 6   | <a href="#">6K18257500</a><br>Engine stop switch assembly  | <a href="#">Buy now</a> |
| 7   | <a href="#">6828255600</a><br>Lanyard, stop switch         | <a href="#">Buy now</a> |
| 8   | <a href="#">6K18361401</a><br>Bracket                      | <a href="#">Buy now</a> |
| 9   | <a href="#">9898005010</a><br>Screw, bind(6k1)             | <a href="#">Buy now</a> |
| 21  | <a href="#">9299005100</a><br>Ybs67-5 washer, spring<br>AP | <a href="#">Buy now</a> |
| 20  | <a href="#">9538005600</a><br>Nut, hexagon (663)<br>AP     | <a href="#">Buy now</a> |
| 12  | <a href="#">6888338311</a><br>Buzzer                       | <a href="#">Buy now</a> |
| 13  | <a href="#">6K18583001</a><br>Control unit assembly        | <a href="#">Buy now</a> |
| 14  | <a href="#">9898006020</a><br>Screw, bind (j17)            | <a href="#">Buy now</a> |
| 15  | <a href="#">9538006600</a><br>Nut(661)                     | <a href="#">Buy now</a> |

## Switch & Panel




68V3300-C380

**F4**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 16  | <a href="#">9299006100</a><br>Washer(6a1)                   | <a href="#">Buy now</a> |
| 17  | <a href="#">9299006600</a><br>Washer, plain (646)           | <a href="#">Buy now</a> |
| 18  | <a href="#">6K18198000</a><br>Diode assembly                | <a href="#">Buy now</a> |
| 19  | <a href="#">9014905M05</a><br>Screw(6k0)<br>AP              | <a href="#">Buy now</a> |
| 22  | <a href="#">9299005600</a><br>Washer, plain (646)<br>AP     | <a href="#">Buy now</a> |
| 23  | <a href="#">6K18258A40</a><br>Extension, wire harness<br>AP | <a href="#">Buy now</a> |
| 24  | <a href="#">61B8258A01</a><br>Extension, wire harness<br>AP | <a href="#">Buy now</a> |


# Top Cowling



**A4**

| Ref | Part                                                        |                         |
|-----|-------------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D042610008D</a><br>Top cowling assembly        | <a href="#">Buy now</a> |
| 2   | <a href="#">68F426470194</a><br>Holder, clamp band          | <a href="#">Buy now</a> |
| 3   | <a href="#">68F426480194</a><br>Holder, clamp band          | <a href="#">Buy now</a> |
| 4   | <a href="#">9299006100</a><br>Washer(6a1)                   | <a href="#">Buy now</a> |
| 5   | <a href="#">9538006600</a><br>Nut(661)                      | <a href="#">Buy now</a> |
| 6   | <a href="#">68F4266300</a><br>Damper 2                      | <a href="#">Buy now</a> |
| 7   | <a href="#">60V4265101</a><br>Hook                          | <a href="#">Buy now</a> |
| 8   | <a href="#">60V4265200</a><br>Hook                          | <a href="#">Buy now</a> |
| 9   | <a href="#">9709506016</a><br>Bolt, hexagon deep recess     | <a href="#">Buy now</a> |
| 10  | <a href="#">9299506600</a><br>Washer, plain (646)           | <a href="#">Buy now</a> |
| 11  | <a href="#">60V42613008D</a><br>Molding, Air Duct           | <a href="#">Buy now</a> |
| 12  | <a href="#">60V4262100</a><br>Mldg Top                      | <a href="#">Buy now</a> |
| 13  | <a href="#">9778050616</a><br>Screw, pan head tapping (ak5) | <a href="#">Buy now</a> |
| 14  | <a href="#">60V4266400</a><br>Damper                        | <a href="#">Buy now</a> |
| 15  | <a href="#">9044511M33</a><br>Hose (I700)                   | <a href="#">Buy now</a> |


# Top Cowling



**A4**

| Ref | Part                                               |                         |
|-----|----------------------------------------------------|-------------------------|
| 16  | <a href="#">60V4268700</a><br>Emblem, rear         | <a href="#">Buy now</a> |
| 17  | <a href="#">9046208018</a><br>Clamp                | <a href="#">Buy now</a> |
| 18  | <a href="#">9778050612</a><br>Screw, tapping(61a)  | <a href="#">Buy now</a> |
| 19  | <a href="#">9017906M24</a><br>Nut(6j8)             | <a href="#">Buy now</a> |
| 20  | <a href="#">60V4266200</a><br>Damper               | <a href="#">Buy now</a> |
| 21  | <a href="#">6D04267700</a><br>Graphic, front       | <a href="#">Buy now</a> |
| 22  | <a href="#">60VW007000</a><br>-                    | <a href="#">Buy now</a> |
| 23  | <a href="#">60V4268100</a><br>Mark, cowling        | <a href="#">Buy now</a> |
| 24  | <a href="#">60V4268200</a><br>Mark, cowling        | <a href="#">Buy now</a> |
| 25  | <a href="#">6D04267800</a><br>Graphic, Rear        | <a href="#">Buy now</a> |
| 26  | <a href="#">67F1344800</a><br>Cap                  | <a href="#">Buy now</a> |
| 27  | <a href="#">60V4262600</a><br>Louver 1             | <a href="#">Buy now</a> |
| 28  | <a href="#">60V4262610</a><br>Louver 1             | <a href="#">Buy now</a> |
| 29  | <a href="#">9016005005</a><br>Screw, round tapping | <a href="#">Buy now</a> |
| 30  | <a href="#">60V4263700</a><br>Damper Form          | <a href="#">Buy now</a> |


# Top Cowling



**A4**

| Ref | Part                                         |                         |
|-----|----------------------------------------------|-------------------------|
| 31  | <a href="#">60V4263710</a><br>Damper Form    | <a href="#">Buy now</a> |
| 32  | <a href="#">68F1343400</a><br>Label, Caution | <a href="#">Buy now</a> |

# Upper Casing




6D01100C2901  
APPLICABLE SERIAL NO.  
\*1: 6D0:1000001-1000338, 6D1: 1000001-1000190  
\*2: 6D0:1000339-, 6D1: 1000191-

C7

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D045111208D</a><br>Casing, Upper<br>X     | <a href="#">Buy now</a> |
| 1   | <a href="#">6D045111308D</a><br>Casing, Upper<br>U     | <a href="#">Buy now</a> |
| 2   | <a href="#">6E52437700</a><br>Pipe, joint              | <a href="#">Buy now</a> |
| 3   | <a href="#">61A42791S0</a><br>Mark 1                   | <a href="#">Buy now</a> |
| 4   | <a href="#">61A42792S0</a><br>Mark                     | <a href="#">Buy now</a> |
| 5   | <a href="#">61A4515500</a><br>Cap                      | <a href="#">Buy now</a> |
| 6   | <a href="#">9709506010</a><br>Bolt                     | <a href="#">Buy now</a> |
| 39  | <a href="#">9299506600</a><br>Washer, plain (646)<br>U | <a href="#">Buy now</a> |
| 8   | <a href="#">9360812M05</a><br>Pin, dowel b (6e5)       | <a href="#">Buy now</a> |
| 9   | <a href="#">9011908052</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 10  | <a href="#">61A4537800</a><br>Nipple, hose             | <a href="#">Buy now</a> |
| 11  | <a href="#">9011906M17</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 12  | <a href="#">9360612019</a><br>Pin, dowel (614)         | <a href="#">Buy now</a> |
| 13  | <a href="#">9044507M21</a><br>Hose (I1160)<br>U        | <a href="#">Buy now</a> |
| 13  | <a href="#">9044507MF0</a><br>Hose (I1160)<br>X        | <a href="#">Buy now</a> |

# Upper Casing



6D01100C2901

APPLICABLE SERIAL NO.


\*1: 6D0:1000001-1000338, 6D1: 1000001-1000190

\*2: 6D0:1000339-, 6D1: 1000191-

**C7**

| Ref | Part                                                     |                         |
|-----|----------------------------------------------------------|-------------------------|
| 14  | <a href="#">6E58355800</a><br>End, nipple                | <a href="#">Buy now</a> |
| 15  | <a href="#">9046511M10</a><br>Clamp                      | <a href="#">Buy now</a> |
| 16  | <a href="#">6E54531800</a><br>Bushing, drive shaft 3     | <a href="#">Buy now</a> |
| 17  | <a href="#">9342036M01</a><br>Circlip (6a0)              | <a href="#">Buy now</a> |
| 18  | <a href="#">60V4511400</a><br>Gasket, upper casing       | <a href="#">Buy now</a> |
| 19  | <a href="#">6D0411370094</a><br>Guide, exhaust           | <a href="#">Buy now</a> |
| 20  | <a href="#">6761137200</a><br>Nipple, hose               | <a href="#">Buy now</a> |
| 21  | <a href="#">9046708M10</a><br>Clip, pipe 6162435600      | <a href="#">Buy now</a> |
| 23  | <a href="#">60V4511301</a><br>Gasket, upper casing       | <a href="#">Buy now</a> |
| 24  | <a href="#">9011908068</a><br>Bolt, with washer<br>UR *1 | <a href="#">Buy now</a> |
| 25  | <a href="#">9011908072</a><br>Bolt, With Washer          | <a href="#">Buy now</a> |
| 24  | <a href="#">9011908079</a><br>Bolt, with washer<br>UR *2 | <a href="#">Buy now</a> |
| 26  | <a href="#">9011908060</a><br>Bolt, with washer          | <a href="#">Buy now</a> |
| 27  | <a href="#">6H11137200</a><br>Nipple, hose               | <a href="#">Buy now</a> |
| 28  | <a href="#">6D041131005B</a><br>Manifold, ext. 1         | <a href="#">Buy now</a> |

# Upper Casing



6D01100C2901

APPLICABLE SERIAL NO.


\*1: 6D0: 1000001-1000338, 6D1: 1000001-1000190

\*2: 6D0: 1000339-, 6D1: 1000191-

**C7**


| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 29  | <a href="#">9011908056</a><br>Bolt With Washer         | <a href="#">Buy now</a> |
| 30  | <a href="#">6D041132005B</a><br>Manifold, exhaust      | <a href="#">Buy now</a> |
| 31  | <a href="#">61A41134A0</a><br>Gasket, exhaust manifold | <a href="#">Buy now</a> |
| 32  | <a href="#">9011908059</a><br>Bolt, with washer        | <a href="#">Buy now</a> |
| 33  | <a href="#">60V14711205B</a><br>Muffler 1<br>U         | <a href="#">Buy now</a> |
| 33  | <a href="#">6D014711205B</a><br>Muffler 1<br>X         | <a href="#">Buy now</a> |
| 34  | <a href="#">6D04512300</a><br>Gasket, muffler          | <a href="#">Buy now</a> |
| 36  | <a href="#">61A4512301</a><br>Gasket, muffler<br>U     | <a href="#">Buy now</a> |
| 37  | <a href="#">6D014721305B</a><br>Muffler 2<br>U         | <a href="#">Buy now</a> |
| 38  | <a href="#">9709506035</a><br>Bolt(j52)<br>U           | <a href="#">Buy now</a> |

# Vapor Separator 1




| Ref | Part                                                |                         |
|-----|-----------------------------------------------------|-------------------------|
| 1   | <a href="#">60V2421600</a><br>Stay                  | <a href="#">Buy now</a> |
| 2   | <a href="#">6D02447300</a><br>Screw                 | <a href="#">Buy now</a> |
| 3   | <a href="#">60V1498000</a><br>Body, float chamber   | <a href="#">Buy now</a> |
| 4   | <a href="#">60V1418201</a><br>Cover, float chamber  | <a href="#">Buy now</a> |
| 5   | <a href="#">65L1454600</a><br>Valve, needle         | <a href="#">Buy now</a> |
| 6   | <a href="#">66K1498500</a><br>Float                 | <a href="#">Buy now</a> |
| 7   | <a href="#">66K1454801</a><br>Pin, float arm        | <a href="#">Buy now</a> |
| 8   | <a href="#">66K1498400</a><br>Gasket, float chamber | <a href="#">Buy now</a> |
| 9   | <a href="#">65L1412500</a><br>Screw                 | <a href="#">Buy now</a> |
| 10  | <a href="#">68F1390600</a><br>Regulator, pressure   | <a href="#">Buy now</a> |
| 11  | <a href="#">66K1432501</a><br>Screw, pan head       | <a href="#">Buy now</a> |
| 12  | <a href="#">60V1416300</a><br>Spacer                | <a href="#">Buy now</a> |
| 13  | <a href="#">65L1390500</a><br>Filter comp           | <a href="#">Buy now</a> |
| 14  | <a href="#">68F1397100</a><br>Pipe, fuel 1          | <a href="#">Buy now</a> |
| 15  | <a href="#">65L2438700</a><br>Clip                  | <a href="#">Buy now</a> |

# Vapor Separator 1




| Ref | Part                                          |                         |
|-----|-----------------------------------------------|-------------------------|
| 16  | <a href="#">65L1496600</a><br>Cap             | <a href="#">Buy now</a> |
| 17  | <a href="#">65L2448600</a><br>O-ring          | <a href="#">Buy now</a> |
| 18  | <a href="#">60V2425100</a><br>Strainer 1      | <a href="#">Buy now</a> |
| 19  | <a href="#">66K1424500</a><br>Screw, guide    | <a href="#">Buy now</a> |
| 20  | <a href="#">68F8250900</a><br>Wire, sub lead  | <a href="#">Buy now</a> |
| 21  | <a href="#">65L1422700</a><br>Washer          | <a href="#">Buy now</a> |
| 22  | <a href="#">60V1390700</a><br>Fuel pump comp. | <a href="#">Buy now</a> |
| 23  | <a href="#">65L1415900</a><br>Clip            | <a href="#">Buy now</a> |
| 24  | <a href="#">68F1378100</a><br>Damper, pump    | <a href="#">Buy now</a> |
| 25  | <a href="#">68F1384400</a><br>Plate 2         | <a href="#">Buy now</a> |
| 26  | <a href="#">68F1391500</a><br>Filter          | <a href="#">Buy now</a> |
| 27  | <a href="#">65L1416A00</a><br>O-ring          | <a href="#">Buy now</a> |
| 28  | <a href="#">66K1427100</a><br>Insulator       | <a href="#">Buy now</a> |
| 29  | <a href="#">65L8182A00</a><br>Nut             | <a href="#">Buy now</a> |
| 30  | <a href="#">65L8182K00</a><br>Nut             | <a href="#">Buy now</a> |

# Vapor Separator 1



| Ref | Part                                        |                         |
|-----|---------------------------------------------|-------------------------|
| 31  | <a href="#">65L8182E00</a><br>Washer        | <a href="#">Buy now</a> |
| 32  | <a href="#">65L8182F00</a><br>Washer        | <a href="#">Buy now</a> |
| 33  | <a href="#">68F1384300</a><br>Plate 1       | <a href="#">Buy now</a> |
| 34  | <a href="#">65L1414700</a><br>O-ring        | <a href="#">Buy now</a> |
| 35  | <a href="#">68F1427400</a><br>Connector     | <a href="#">Buy now</a> |
| 36  | <a href="#">66K2437600</a><br>Pipe, joint 1 | <a href="#">Buy now</a> |
| 37  | <a href="#">66K2448900</a><br>O-ring        | <a href="#">Buy now</a> |
| 38  | <a href="#">68F1427100</a><br>Insulator     | <a href="#">Buy now</a> |
| 39  | <a href="#">65L1439700</a><br>O-ring        | <a href="#">Buy now</a> |
| 40  | <a href="#">65L1499200</a><br>Screw, drain  | <a href="#">Buy now</a> |
| 41  | <a href="#">65L1499700</a><br>Seal          | <a href="#">Buy now</a> |
| 42  | <a href="#">60V2437501</a><br>Grommet       | <a href="#">Buy now</a> |
| 43  | <a href="#">60V2439701</a><br>Collar        | <a href="#">Buy now</a> |
| 44  | <a href="#">66K2457900</a><br>Washer 2      | <a href="#">Buy now</a> |
| 45  | <a href="#">65L2459200</a><br>Bolt          | <a href="#">Buy now</a> |


Vapor Separator 1



C2

| Ref | Part                                                 |                         |
|-----|------------------------------------------------------|-------------------------|
| 46  | <a href="#">65L2416900</a><br>Washer, lock           | <a href="#">Buy now</a> |
| 47  | <a href="#">60V8250700</a><br>Wire, lead             | <a href="#">Buy now</a> |
| 48  | <a href="#">66K1354200</a><br>Hose, vacuum sensing 1 | <a href="#">Buy now</a> |
| 49  | <a href="#">66K1354400</a><br>Hose, Vacuum Sensing 2 | <a href="#">Buy now</a> |
| 50  | <a href="#">66K1353200</a><br>Hose, vacuum sensing 3 | <a href="#">Buy now</a> |
| 51  | <a href="#">65L2446100</a><br>Pipe.joint 4           | <a href="#">Buy now</a> |
| 52  | <a href="#">66K1353300</a><br>Hose, vacuum sensing 4 | <a href="#">Buy now</a> |
| 53  | <a href="#">65L1389800</a><br>Plate 4                | <a href="#">Buy now</a> |
| 54  | <a href="#">65L1456500</a><br>Screw                  | <a href="#">Buy now</a> |
| 55  | <a href="#">60V2433901</a><br>Grommet                | <a href="#">Buy now</a> |
| 56  | <a href="#">60V1353400</a><br>Hose, Vacuum Sensing 5 | <a href="#">Buy now</a> |
| 57  | <a href="#">9046511M10</a><br>Clamp                  | <a href="#">Buy now</a> |

## Vapor Separator 2




  
60V1010-3080

**C5**

| Ref | Part                                                   |                         |
|-----|--------------------------------------------------------|-------------------------|
| 1   | <a href="#">6D01375100</a><br>Body, throttle 1         | <a href="#">Buy now</a> |
| 2   | <a href="#">65L1452700</a><br>Plate                    | <a href="#">Buy now</a> |
| 3   | <a href="#">65L1456500</a><br>Screw                    | <a href="#">Buy now</a> |
| 4   | <a href="#">65L1433400</a><br>Spring, air adjusting    | <a href="#">Buy now</a> |
| 5   | <a href="#">65L1452300</a><br>Screw, stop              | <a href="#">Buy now</a> |
| 6   | <a href="#">6K51459200</a><br>Screw                    | <a href="#">Buy now</a> |
| 7   | <a href="#">9020105552</a><br>Washer, plate(65j)       | <a href="#">Buy now</a> |
| 8   | <a href="#">65L1457800</a><br>Collar                   | <a href="#">Buy now</a> |
| 9   | <a href="#">68F1356800</a><br>Stud                     | <a href="#">Buy now</a> |
| 10  | <a href="#">61A8588500</a><br>Throttle sensor assembly | <a href="#">Buy now</a> |
| 11  | <a href="#">6K78588601</a><br>Bracket                  | <a href="#">Buy now</a> |
| 12  | <a href="#">9798505212</a><br>Screw, with washer(6g7)  | <a href="#">Buy now</a> |
| 13  | <a href="#">9038705M00</a><br>Collar(6k7)              | <a href="#">Buy now</a> |
| 14  | <a href="#">60V8551600</a><br>Spacer                   | <a href="#">Buy now</a> |
| 15  | <a href="#">60V1459600</a><br>Washer                   | <a href="#">Buy now</a> |

## Vapor Separator 2



60V1010-3080

**C5**

| Ref | Part                                                  |                         |
|-----|-------------------------------------------------------|-------------------------|
| 16  | <a href="#">9798505330</a><br>Screw, with washer(61b) | <a href="#">Buy now</a> |
| 17  | <a href="#">65L1457300</a><br>Lever                   | <a href="#">Buy now</a> |
| 18  | <a href="#">65L1457900</a><br>Spring                  | <a href="#">Buy now</a> |
| 19  | <a href="#">65L4121700</a><br>Rod, accel. lever       | <a href="#">Buy now</a> |

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.