



Yamaha Z150PETO 2003

Parts Manual

www.floodmarine.co.uk

+44 2882 246 539


Authorised Yamaha Dealers



Contents

BOTTOM COWLING	3
BRACKET 1	8
BRACKET 2	11
CONTROL	14
CRANKSHAFT. PISTON	17
CYLINDER. CRANKCASE 1	20
CYLINDER. CRANKCASE 2	23
ELECTRICAL 1	26
ELECTRICAL 2	29
ELECTRICAL 3	32
ELECTRICAL 4	37
FUEL 1	38
FUEL 2	42
FUEL INJECTION NOZZLE	43
FUEL INJECTION PUMP	45
FUEL PUMP DRIVE GEAR	49
GENERATOR	51
INTAKE	53
LOWER CASING. DRIVE 1	55
LOWER CASING. DRIVE 2	62
LOWER CASING. DRIVE 3	65
LOWER CASING. DRIVE 4	72
METER	74
OIL PUMP	76
OIL TANK	80
POWER TRIM & TILT ASSY 1	83
POWER TRIM & TILT ASSY 2	86
REMOTE CONTROL BOX	89
REPAIR KIT 1	90
REPAIR KIT 2	92
STARTING MOTOR	94
STEERING GUIDE ATTACHMENT 1	97
STEERING GUIDE ATTACHMENT 2	98
SWITCH. PANEL	99
TOP COWLING	101
UPPER CASING	103
VAPOR SEPARATOR 1	106
VAPOR SEPARATOR 2	110


Bottom Cowling



F5

Ref	Part	
1	68F-42710-00-8D Bottom Cowling assembly	Buy now
2	61A-42727-00 Grommet	Buy now
3	68F-42828-00-94 Plate, clamp	Buy now
4	68F-42828-10-94 Plate, clamp	Buy now
5	90109-06M82 Bolt	Buy now
6	68F-42815-00-8D Lever, clamp	Buy now
7	68F-42816-00-8D Lever, clamp	Buy now
8	68F-42817-00-8D Lever, clamp	Buy now
9	68F-42818-00 Lever, clamp	Buy now
10	67F-42818-00 Lever, clamp	Buy now
11	90386-15M73 Bush(6l2)	Buy now
12	90206-15M18 Washer, wave(6l2)	Buy now
13	90201-06068 Washer,plate (6k8)	Buy now
14	97095-06016 Bolt, hexagon deep recess	Buy now
15	64D-43144-00 Hook, spring	Buy now


Bottom Cowling



F5


Ref	Part	
16	90109-06M80 Bolt	Buy now
17	90506-16M34 Spring, tension(64d)	Buy now
18	68F-42615-00 Seal	Buy now
19	6E5-44391-00 Nipple, hose	Buy now
20	68F-42725-01 Grommet	Buy now
21	68F-42738-00-5B Plate, fitting	Buy now
22	90109-06M86 Bolt	Buy now
23	64D-42738-10-5B Plate, fitting	Buy now
25	90480-22M81 Grommet	Buy now
26	90387-08M37 Collar (6e5)	Buy now
27	90201-08M54 Washer, plate (6e5)	Buy now
28	97075-08035 Bolt(70w)	Buy now
29	90119-08M22 Bolt, with washer	Buy now
30	688-42726-10 Grommet	Buy now
31	6E5-82588-00 Plate	Buy now

Bottom Cowling




Ref	Part	
32	95895-06020 Bolt, flange(jk3)	Buy now
33	68F-42723-00-94 Cover, bottom	Buy now
34	68F-42721-00 Gasket 1	Buy now
36	68F-42769-00 Seal Rubber	Buy now
37	68F-42741-00-4D Apron L	Buy now
37	68F-42741-10-4D Apron X	Buy now
39	90387-06M43 Collar (6e9)	Buy now
40	90480-13M24 Grommet (6e9)	Buy now
41	95380-06600 Nut(661)	Buy now
42	90159-06M03 Screw (6g5)	Buy now
43	95895-06016 Bolt, flange deep recess	Buy now
44	68F-42771-00 Apron	Buy now
45	61A-42717-00 Rubber, seal 2	Buy now
47	68F-42722-00 Gasket 2	Buy now
48	68F-12577-00 Hose 2 L	Buy now

Bottom Cowling




Ref	Part	
48	68F-12577-10 Hose 2 X	Buy now
49	68F-12582-01 Joint, hose 2 L	Buy now
49	68F-12582-10 Joint, hose 2 X	Buy now
50	68F-42718-00 Rubber, seal 3	Buy now
51	68F-42753-00 Fastner	Buy now
52	90464-20258 Clamp	Buy now
53	6E5-42716-10 Rubber seal 1	Buy now
54	90169-05M00 Screw truss head tapping	Buy now
55	6R3Y125J70 Flushing kit	Buy now
56	6R31257200 Adapter	Buy now
57	6R31258000 Joint assembly	Buy now
58	9044511M35 Hose (I700)	Buy now
59	9046511M10 Clamp	Buy now
61	68F-2415E-60 Label Caution	Buy now
62	68F-42791-01 Mark 1	Buy now

Bottom Cowling




Ref	Part	
62	68H-42791-01 Mark 1	Buy now
63	6A1-28176-00 Label Caution	Buy now
64	6E3-8257H-00 Plate Mark	Buy now

Bracket 1



Ref	Part	
1	64E-43111-02-8D Bracket, clamp	Buy now
2	6G5-45251-02 Anode	Buy now
3	6G5-44526-00 Plate	Buy now
4	97095-06030 Bolt(jf7)	Buy now
5	92995-06100 Washer(6a1)	Buy now
6	6E5-82148-00 Wire, lead 5	Buy now
7	97095-06010 Bolt	Buy now
8	92995-06600 Washer, plain (646)	Buy now
9	64E-43112-02-8D Bracket, clamp	Buy now
11	97880-06012 Screw, pan head(62j)	Buy now
12	92990-06600 Washer, plain (646)	Buy now
13	93700-06M03 Nipple, grease(6a1)	Buy now
14	663-45119-00 Cap, grease nipple AP	Buy now
15	64E-43131-01 Bolt, clamp bracket	Buy now
16	97095-08020 Bolt, hexagon	Buy now

Bracket 1




Ref	Part	
17	92995-08100 Ybs67-8 washer, spring	Buy now
18	90386-25M31 Bushing (6e5)	Buy now
19	90201-26M59 Washer, plate (6e5)	Buy now
20	90185-22M11 Nut, self-locking	Buy now
21	90465-11M10 Clamp	Buy now
22	64E-43311-10-8D Bracket, swivel L	Buy now
22	64E-43311-20-8D Bracket, swivel X	Buy now
23	90465-08M63 Clamp(61u)	Buy now
26	6E5-82147-00 Wire, lead 5 L	Buy now
26	6E5-82147-20 Wire, lead 5 X	Buy now
27	6G5-43144-00 Hook, spring	Buy now
29	6G5-43181-02 Lever, tilt stop 1	Buy now
30	6G5-43185-02 Lever, tilt stop 2	Buy now
31	90386-10M16 Bushing (688)	Buy now
32	6G5-43148-00 Collar, distance	Buy now

Bracket 1




Ref	Part	
33	90249-06M19 Pin(6e5)	Buy now
34	90387-10M05 Collar(6e5)	Buy now
35	91690-30020 Pin, spring (6h4)	Buy now
36	90506-14M24 Spring, tension(6e5)	Buy now
37	64E-43126-00 Pin, upper shock mount	Buy now
38	90386-22M98 Bush(61u)	Buy now
39	93410-22M11 Circlip(61u)	Buy now
40	90101-12M03 Bolt (l:115mm)	Buy now
40	90101-12M05 Bolt (l:130mm)	Buy now
41	90201-13M01 Washer, plate(6e5)	Buy now
42	90201-12M05 Washe, plate(663)	Buy now
43	95380-12600 Nut (707)	Buy now

Bracket 2




Ref	Part	
1	64E-43139-02 Cam, trim sender (with screw)	Buy now
2	97780-60525 Screw, tapping(65j)	Buy now
3	64E-83672-02 Trim sender	Buy now
4	97885-06016 Screw, pan head(6b0)	Buy now
5	90465-11M10 Clamp	Buy now
6	93210-37MH7 O-ring(61u)	Buy now
7	90202-40M47 Washer, plate(61a)	Buy now
8	61A-43376-00 Bolt, thrust receiver	Buy now
9	95780-10300 Nut, nylon (6e5)	Buy now
10	68F-42510-A0-8D Steering bracket assembly L	Buy now
10	68F-42510-B0-8D Steering bracket assembly X	Buy now
11	90201-38M60 Washer, plate (6e5)	Buy now
12	90386-38M32 Bush(6e5)	Buy now
13	68F-44551-00-8D Housing, lower mount rubber	Buy now
14	93410-37M04 Circlip (6e5)	Buy now

Bracket 2



Ref	Part	
15	6E5-44575-00 Damper, lower mount rubber	Buy now
16	6G5-44555-00-94 Mount damper, lower side	Buy now
17	90202-32M19 Washer, plate (6e5)	Buy now
18	90201-16M55 Washer, plate (6e5)	Buy now
19	6E5-82149-00 Wire, lead 3	Buy now
20	90109-14MA5 Bolt	Buy now
21	90201-15M58 Washer, plate (6e5)	Buy now
22	90185-14M00 Nut, self-locking(61a)	Buy now
23	92995-14600 Washer (6e5)	Buy now
24	68F-44552-00-8D Housing, lower mount rubber	Buy now
25	97095-10045 Bolt(64d)	Buy now
26	92995-10100 Ybs67-10 washer, spring	Buy now
27	68F-44553-00-4D Cover, lower mount	Buy now
28	93210-41042 O-ring (132)	Buy now
29	68F-44556-00-4D Cover, lower mount 2	Buy now


Bracket 2



B1

Ref	Part	
31	90119-06MA8 Bolt, with washer	Buy now
32	6G5-44514-00-94 Mount damper, upper side	Buy now
33	90201-26M57 Washer, plate (6e5)	Buy now
34	90202-26M18 Washer, plate (6e5)	Buy now
35	90201-14M56 Washer, plate (6e5)	Buy now
36	90109-12M37 Bolt	Buy now
37	90185-12M12 Nut, self-locking(6e5)	Buy now
38	663-44575-00 Damper, lower mount rubber	Buy now
39	6E5-44511-00-5B Cover, upper mount	Buy now

Control




68F2100-3220

A4

Ref	Part	
1	68F-48531-00 Bracket, Remote Control 1	Buy now
2	663-48538-00 Clamp, cable 1	Buy now
3	91690-30010 Pin, spring (663)	Buy now
4	90109-06M80 Bolt	Buy now
5	68F-44117-01-1S Bracket	Buy now
6	97095-06020 Bolt(7u8)	Buy now
7	97013-06012 Bolt(gh1)	Buy now
8	92903-06600 Washer, plain (646)	Buy now
9	68F-44121-00 Lever, shift rod	Buy now
10	68F-44122-01 Bushing, Shift Rod Lever	Buy now
11	90202-08M20 Washer, plate (6e5)	Buy now
12	90468-18008 Clip 620436610000	Buy now
13	6E5-48344-00 Cable end, remote control	Buy now
14	90386-06M12 Bushing (688)	Buy now
15	6E5-44118-01-1S Bracket 2	Buy now

Control




68F2100-3220

A4


Ref	Part	
16	97013-08030 Bolt	Buy now
17	92903-08600 Washer, plain (663)	Buy now
18	93501-04M02 Ball (697)	Buy now
19	90501-12082 Spring 6484411600	Buy now
20	648-42715-00 Bushing 2	Buy now
21	93700-06M03 Nipple, grease(6a1)	Buy now
22	6E5-44120-03 Handle gear shift assembly L	Buy now
22	6E5-44120-23 Handle gear shift assembly X	Buy now
23	93210-09165 O-ring	Buy now
24	90386-16M66 Bush(6e5)	Buy now
25	90202-16061 Washer, plate(663)	Buy now
26	93410-16006 Circlip	Buy now
27	67H-41632-00 Lever, magneto control	Buy now
30	90119-06MA4 Bolt, with washer	Buy now
31	90201-06M31 Washer (6a0)	Buy now

Control



Ref	Part	
32	90206-10M04 Washer, wave (676)	Buy now
33	90387-06M29 Coller (6a0)	Buy now
34	61A-41237-00 Joint, link	Buy now
35	95380-05600 Nut, hexagon (663)	Buy now
36	682-41237-00 Joint, link 2	Buy now
37	68F-41213-00 Cam, accel.	Buy now
42	68F-42744-00 Stay	Buy now
43	90157-06M11 Screw, pan head(697)	Buy now
44	95380-06600 Nut(661)	Buy now
45	688-44194-00 Cap	Buy now
46	68F-8259F-00 Switch assembly	Buy now
47	61A-82588-01 Plate	Buy now
48	97885-04016 Screw, panhead (796)	Buy now
49	92995-04100 Ybs67-4 washer, spring	Buy now


Crankshaft. Piston



B1

Ref	Part	
1	68F-11411-01 Crankshaft	Buy now
2	6E5-11447-00 Seal, ring	Buy now
3	68F-15163-00-94 Housing, bearing 1	Buy now
4	93311-940U3 Brg,cyl-cal roller 36g (6e5)	Buy now
5	93102-40M14 Oil seal(61a)	Buy now
6	93211-04001 O-ring	Buy now
7	90119-06MA3 Bolt, with washer	Buy now
8	93310-954U1 Bearing, cylindrical(64c)	Buy now
9	6R3-11536-00 Gear, drive	Buy now
10	93306-208U0 Brg,r-b 6208 80mm 345g (6e5)	Buy now
11	93410-40M03 Circlip(n02)	Buy now
12	6G5-15359-00-94 Housing, oil seal	Buy now
13	93102-35M61 Oil seal	Buy now
14	93101-22M15 Oil seal (6e5)	Buy now
15	93210-74M35 O-ring (6e5)	Buy now


Crankshaft. Piston



B1

Ref	Part	
16	90119-06MA2 Bolt, with washer	Buy now
17	68F-11631-01-85 Piston (std)	Buy now
17	68F-11635-01 Piston (0.25mm o/s) AP	Buy now
17	68F-11636-01 Piston (0.50mm o/s) AP	Buy now
18	68F-11603-01 Piston ring set (std)	Buy now
18	68F-11604-01 Piston ring set (0.25mm o/s) AP	Buy now
18	68F-11605-01 Piston ring set (0.50mm o/s) AP	Buy now
19	68F-11642-01-85 Piston 2 (std)	Buy now
19	68F-11645-01 Piston 2 (0.25mm o/s) AP	Buy now
19	68F-11646-01 Piston 2 (0.50mm o/s) AP	Buy now
21	6R5-11633-10 Pin, piston	Buy now
22	6R5-11634-10 Clip, piston pin	Buy now
23	68L-11650-00 Connecting rod assembly	Buy now
23	6R5-11650-10 Connecting kit	Buy now
24	90109-08022 Bolt	Buy now


Crankshaft. Piston



B1

Ref	Part	
25	93310-323V6 Bearing	Buy now
26	90201-23M01 Washer, plate(6g6)	Buy now
27	93310-836U0 Bearing, cylindrical(61u)	Buy now


Cylinder. Crankcase 1



A6

Ref	Part	
3	6E5-11372-01 Nipple, hose	Buy now
4	624-14485-00 Pipe, joint	Buy now
5	68F-11372-01 Nipple, hose	Buy now
6	650-11370-01 Check valve assembly	Buy now
7	68F-13552-00 Nozzle	Buy now
8	90384-06M07 Bush, bimetal formed(6r3)	Buy now
9	90384-14M09 Bush, bimetal formed(6r3)	Buy now
10	663-11518-01 Lock, bearing	Buy now
11	646-11370-01 Check valve assembly	Buy now
12	90340-14M00 Plug, straight screw(62y)	Buy now
13	90430-14115 Gasket (663)	Buy now
14	93608-12063 Pin, dowel (626)	Buy now
15	90105-10M20 Bolt (6e5)	Buy now
16	90119-08M94 Bolt, with washer	Buy now
17	90116-08M45 Bolt, stud (6e5)	Buy now

Cylinder. Crankcase 1




A6

Ref	Part	
18	6E5-11325-00 Anode	Buy now
19	98780-04015 Screw, flat head(ga5)	Buy now
21	68F-11381-00 Gasket 1	Buy now
22	90119-06MA2 Bolt, with washer	Buy now
24	6E5-42762-00-1S Stopper	Buy now
25	68F-44533-00 Damper, upper mount rubber	Buy now
27	90445-07M03 Hose (I200)	Buy now
28	90445-07M10 Hose (L770)	Buy now
29	90445-07MA6 Hose (I200)	Buy now
30	90445-07MA4 Hose (I390)	Buy now
31	90445-07M45 Hose (I390)	Buy now
32	90445-07M27 Hose (I390)	Buy now
33	90464-07M20 Clamp(6h0)	Buy now
34	68F-13782-00 Stay	Buy now
35	90387-08M31 Collar	Buy now

Cylinder. Crankcase 1


1
CRANK CYLINDER
ASSY
(Fig. 2, Ref. No. 2 to 26
Fig. 3, Ref. No. 1 to 27
Fig. 4, Ref. No. 1 to 30, 33 to 38
Fig. 9, Ref. No. 18
Fig. 10, Ref. No. 11, 12
Fig. 11, Ref. No. 4
Fig. 13, Ref. No. 43
Fig. 18, Ref. No. 63
Fig. 27, Ref. No. 13)



Ref	Part	
36	90110-08M04 Bolt, hexagon socket head	Buy now

A6


Cylinder. Crankcase 2



B3

Ref	Part	
1	68F-11111-00-94 Head, cylinder 1	Buy now
2	6E5-11325-00 Anode	Buy now
3	98780-04015 Screw, flat head(ga5)	Buy now
4	68F-11121-00-94 Head, cylinder 2	Buy now
7	68F-11181-00 Gasket, cylinder head 1	Buy now
8	90119-08MA8 Bolt, with washer	Buy now
9	68F-11119-00 Hanger, engine	Buy now
10	90119-06MA2 Bolt, with washer	Buy now
11	68F-11191-00-1S Cover, cylinder head 1	Buy now
12	68F-11192-00-1S Cover, cylinder head 2	Buy now
13	68F-11193-01 Gasket, head cover 1	Buy now
14	90119-06MA4 Bolt, with washer	Buy now
15	99590-10114 Pin, dowel	Buy now
16	6E5-12411-30 Thermostat	Buy now
17	688-12413-00-1S Cover, thermostat	Buy now


Cylinder. Crankcase 2



B3

Ref	Part	
18	688-12414-A1 Gasket, cover	Buy now
19	90119-06MA6 Bolt, with washer	Buy now
20	62Y-11325-00 Anode	Buy now
21	66M-11328-00 Grommet, anode	Buy now
22	66M-11327-00-94 Cover, anode	Buy now
23	66M-12535-00 Plate	Buy now
24	97095-05012 Bolt, hexagon	Buy now
25	92995-05600 Washer, plain (646)	Buy now
27	68F-41114-00 Gasket, exhaust outer cover	Buy now
28	68F-41113-00-1S 4-	Buy now
29	650-24378-00 Pipe, joint 2	Buy now
31	90445-09M25 Hose (I1500)	Buy now
32	90467-08M18 Clip	Buy now
33	6G5-12416-00 Valve, pressure control	Buy now
34	90501-16M11 Spring, compression (688)	Buy now


Cylinder. Crankcase 2



B3


Ref	Part	
35	90480-20M05 Grommet (688)	Buy now
36	6G5-11382-A1 Gasket 2	Buy now
37	6G5-11372-00-1S Cover, bypass 2	Buy now
39	68F-12576-00 Hose 1	Buy now
40	90467-23M16 Clip	Buy now
41	94702-00404 Plug, spark (bkr7eku)	Buy now
41	94702-00405 Plug, spark (bkr6eku)	Buy now

Electrical 1




Ref	Part	
1	68F-85542-00-94 Bracket	Buy now
2	68F-85516-01 Spacer	Buy now
3	68F-86129-00 Collar	Buy now
4	68F-86129-10 Collar	Buy now
5	68F-85119-00 Bolt	Buy now
6	68F-8591A-20 Engine Control Unit assembly X	Buy now
6	68F-8591A-30 Engine Control Unit assembly L	Buy now
6	68H-8591A-10 Engine control unit assembly X	Buy now
6	68J-8591A-10 Engine Control Unit assembly L	Buy now
6	68L-8591A-10 16 – X	Buy now
7	90119-06MA3 Bolt, with washer	Buy now
8	68F-85548-01 Holder	Buy now
9	97013-06014 Bolt(gj3)	Buy now
10	92903-06600 Washer, plain (646)	Buy now
11	68F-85142-00-94 Bracket, Reflector 2	Buy now

Electrical 1




Ref	Part	
16	68F-85599-00 Cover	Buy now
17	97013-06012 Bolt(gh1)	Buy now
19	68F-85644-00 Plate	Buy now
22	68F-8591B-00 Driver, injector assembly	Buy now
23	90119-06MA2 Bolt, with washer	Buy now
24	6G0-82519-00 Wire, earth lead	Buy now
25	97095-06012 Bolt(gh1)	Buy now
26	92995-06600 Washer, plain (646)	Buy now
29	68F-82310-01 Ignition coil assembly	Buy now
30	90480-22M15 Grommet (6e5)	Buy now
31	90465-11M10 Clamp	Buy now
32	68F-82310-11 Ignition coil assembly	Buy now
33	97013-05020 Bolt, hexagon	Buy now
34	92903-05600 Washer, plain (646)	Buy now
35	68F-82370-01 Plug cap assembly	Buy now

Electrical 1



Ref	Part	
36	68F-8252U-00 Cover	Buy now
37	68F-8252U-10 Cover	Buy now


Electrical 2



E4

Ref	Part	
1	6H2-81949-11 Wire, lead	Buy now
2	97095-06012 Bolt(gh1)	Buy now
3	92995-06600 Washer, plain (646)	Buy now
4	68F-82105-00 Battery cable	Buy now
5	97095-08016 Bolt, hexagon deep recess	Buy now
6	92995-08600 Washer, plain (663)	Buy now
7	95333-08600 Nut(6I2)	Buy now
8	92903-08100 Ybs67-8 washer, spring	Buy now
9	6E5-82588-00 Plate	Buy now
10	95895-06020 Bolt, flange(jk3)	Buy now
11	6E5-82531-10 Wire, lead	Buy now
12	688-82594-00 Clamp	Buy now
13	68F-82590-10 Wire Harness assembly	Buy now
14	90465-11M52 Clamp(6e7)	Buy now
15	90446-24MF6 Hose	Buy now


Electrical 2



E4


Ref	Part	
16	90446-24MF7 Hose	Buy now
17	90446-34MF8 Hose	Buy now
18	90465-08M89 Clamp	Buy now
19	68F-8259M-00 Wire Harness assembly 2	Buy now
20	68F-8259N-00 Wire Harness assembly 3	Buy now
21	90465-11M10 Clamp	Buy now
23	61A-85790-00 Thermosensor assembly	Buy now
24	92990-10600 Washer, plate	Buy now
25	90465-12M93 Clamp	Buy now
27	92995-06100 Washer(6a1)	Buy now
28	6R3-82563-00 Trim & tilt switch assembly	Buy now
29	6E5-82587-00 Gasket	Buy now
30	6R3-83614-00 Bracket	Buy now
31	90109-06M80 Bolt	Buy now
32	67H-82380-00 Sensor, pressure	Buy now

Electrical 2



Ref	Part	
33	98580-06520 Screw pan head	Buy now
34	97095-06014 Bolt(gj3)	Buy now
36	6K7-82588-00 Plate	Buy now


Electrical 3



E6


Ref	Part	
1	68F-81948-00 Bracket	Buy now
2	68F-82535-00 Grommet	Buy now
3	90465-12M56 Clamp(62t)	Buy now
4	624-42542-00 Collar	Buy now
5	90387-06M91 Collar	Buy now
6	6A0-82317-00 Damper, ignition coil	Buy now
7	90119-06M65 Bolt, with washer	Buy now
8	97095-06012 Bolt(gh1)	Buy now
9	92995-06600 Washer, plain (646)	Buy now
10	68F-81949-20 Wire, lead	Buy now
13	61A-87149-00 Connector	Buy now
14	68F-81950-01 Relay assembly	Buy now
15	682-82119-01 Cover, lead wire	Buy now
16	97095-06010 Bolt	Buy now
17	92995-06100 Washer(6a1)	Buy now

Electrical 3



Ref	Part	
19	90119-06MA4 Bolt, with washer	Buy now
20	90464-18M46 Clamp(65j)	Buy now
21	90464-23199 Clamp(4hm)	Buy now
23	61A-8194A-00 Relay	Buy now
24	95780-06300 Nut, nylon (6g1)	Buy now
25	68F-82117-00 Wire, lead	Buy now
26	61A-81952-00 Holder, relay	Buy now
27	97780-50612 Screw, tapping(61a)	Buy now
28	90464-05141 Clamp(7ly)	Buy now
29	90465-11M52 Clamp(6e7)	Buy now
30	68F-82170-00 Fuse box assembly Go to P/N) PE0-OM-070038	Buy now
31	68F-82151-00 Fuse (80A) Go to P/N) PE0-OM-070038	Buy now
32	68F-8195A-00 Relay assembly	Buy now
33	67F-82151-00 Fuse	Buy now
34	67F-82151-10 Fuse	Buy now

Electrical 3




68F2100-3180

E6

Ref	Part	
35	68F-82846-00 Screw, pan head (m5)	Buy now
36	97780-50620 Screw, tapping	Buy now
37	68F-85544-00 Case	Buy now
38	67F-2812A-00 Puller, fuse	Buy now
39	68F-82176-00 Damper	Buy now
40	68F-8572S-00 Spring	Buy now
41	68F-81336-00 Grommet	Buy now
42	68F-81128-00 Clamp	Buy now
43	97780-50616 Screw, pan head tapping (ak5)	Buy now
44	68F-81960-01 Rectifier & regulator assembly	Buy now
45	69J-81975-A0 Plate, rectifier fitting	Buy now
46	69J-81972-01-1S Cover, rectifier	Buy now
47	90465-13M18 Clamp	Buy now
48	90110-06M07 Bolt, hexagon socket head	Buy now
50	90445-09097 Hose (I1500)	Buy now


Electrical 3



E6


Ref	Part	
51	90467-08M18 Clip	Buy now
52	68F-81942-00 Cover	Buy now
53	90169-05M00 Screw truss head tapping	Buy now
54	68F-8592A-00 Sensor	Buy now
55	65L-11395-00 Holder	Buy now
56	90119-06M74 Bolt, with washer(63m)	Buy now
58	65L-85832-00 Case, under	Buy now
59	65L-11354-00 Gasket	Buy now
60	65L-1131N-00 Gasket, holder	Buy now
61	65L-11396-00 Gasket, holder	Buy now
62	68F-11353-00 Joint	Buy now
63	68F-W1135-00 Seal, cylinder	Buy now
64	97095-06030 Bolt(jf7)	Buy now
67	68F-81919-10 Graphic, Regulator	Buy now
68	68F-81919-00 Graphic, Regulator Go to P/N) PE0-OM-070038	Buy now

Electrical 3



Ref	Part	
69	65L-83625-50 Mark 5	Buy now
70	68F-81949-00 Wire, lead AP	Buy now

Electrical 4




68F0010-0180

F2


Ref	Part	
1	61A-85895-00 Crank position sender	Buy now
2	90465-13M18 Clamp	Buy now
3	97885-05012 Screw, pan head (646)	Buy now
5	688-82560-10 Thermo switch assembly	Buy now
6	65L-85886-00 Thermosensor	Buy now
7	68F-8431R-00 Stay, Setting	Buy now
8	90480-17M80 Grommet	Buy now
9	90179-12M37 Nut	Buy now
10	90201-12M08 Washer, Plate	Buy now
11	97095-06016 Bolt, hexagon deep recess	Buy now
12	92995-06600 Washer, plain (646)	Buy now

Fuel 1




Ref	Part	
1	61A-24313-00 Pipe 3	Buy now
2	90464-13M34 Clamp(6r3)	Buy now
3	90445-13M17 Hose(I2700)	Buy now
4	6R3-24377-00 Pipe, joint 3	Buy now
5	90465-11M10 Clamp	Buy now
6	68F-24560-00 Filter assembly	Buy now
7	68F-24562-00 Cup, filter	Buy now
8	68F-24519-00 Clip	Buy now
9	68F-24469-00 Float, Water Level	Buy now
10	65L-24531-01 Nut	Buy now
11	61A-24564-00 O-ring	Buy now
12	68F-24563-00 Element, filter	Buy now
13	65L-24564-00 Gasket	Buy now
14	68F-24567-00 Spring	Buy now
15	65L-24558-00 Holder, filter	Buy now

Fuel 1



Ref	Part	
16	97595-06416 Bolt, with washer(62x)	Buy now
17	90201-06068 Washer,plate (6k8)	Buy now
18	68F-24566-00 Bracket, filter	Buy now
19	97595-06514 Bolt(gj3)	Buy now
20	90387-06M60 Collar (6h3)	Buy now
21	90480-10M23 Grommet(6k7)	Buy now
22	90119-06M88 Bolt, with washer	Buy now
23	61A-24311-00 Pipe, fuel 1	Buy now
24	61U-24316-00 Pipe 6	Buy now
25	6R5-24408-00 Fuel feed assembly	Buy now
27	6E5-24378-00 Pipe, joint 3	Buy now
28	90445-13M31 Hose (L85)	Buy now
29	67H-24311-00 Pipe, fuel 1	Buy now
30	6E5-24410-03 Fuel pump assembly	Buy now
31	6E5-24444-00 Screw	Buy now

Fuel 1




68F2010-3130

D5

Ref	Part	
32	6E5-24413-00 Body 2	Buy now
33	6E5-24471-00 Diaphragm	Buy now
34	6E5-24435-00 Gasket, body 2	Buy now
35	6E5-24411-00 Diaphragm	Buy now
36	648-24424-00 Seat, spring	Buy now
37	6E5-24423-00 Spring, diaphragm	Buy now
38	6E5-24434-02 Gasket, body	Buy now
39	6A0-24421-01 Valve, check	Buy now
40	6A0-14325-00 Screw, pan head	Buy now
41	95380-03600 Nut (6g8)	Buy now
42	6E5-24412-10 Body 1	Buy now
43	650-24431-A0 Gasket, fuel pump	Buy now
44	97095-06050 Bolt(jf7)	Buy now
45	92995-06600 Washer, plain (646)	Buy now
47	6E5-24313-00 Pipe 3	Buy now


Fuel 1



D5

Ref	Part	
50	6H1-83557-00 Tube	Buy now
51	90446-15M07 Hose(6g4)	Buy now
52	90445-13M12 Hose (L235)	Buy now
53	97095-06012 Bolt(gh1)	Buy now

Fuel 2





68J1100-2140

D7


Ref	Part	
1	6YK-24307-42 Fuel pipe comp. 2 AP	Buy now
2	90450-10M07 Hose, clamp AP	Buy now

Fuel Injection Nozzle




Ref	Part	
1	68F-13767-00 Cap, injector	Buy now
2	90119-08M60 Bolt (682)	Buy now
3	68F-13161-00 Pipe, Delivery 1	Buy now
4	68F-13171-00 Pipe, Delivery 2	Buy now
5	68F-13938-00 Pipe	Buy now
6	68F-13898-00 Holder	Buy now
7	68F-13761-00 Injector assembly	Buy now
8	68F-1410B-00 Packing kit	Buy now
9	68F-13853-00 Plate 3	Buy now
10	68F-24453-00 Screw	Buy now
11	68F-24300-00 Fuel pipe joint	Buy now
12	68F-13595-00 Joint	Buy now
13	68F-24479-00 O-Ring	Buy now
14	68F-24489-00 O-Ring	Buy now
15	68F-13972-00 Pipe, Fuel 2	Buy now

Fuel Injection Nozzle



Ref	Part	
16	65L-24387-00 Clip	Buy now
17	68F-24174-00 Spacer 1	Buy now
18	68F-13764-00 Gasket (t=2.2)	Buy now
19	68F-13716-00 Collar	Buy now
20	97013-08055 Bolt, hexagon	Buy now
21	92903-08600 Washer, plain (663)	Buy now
22	68F-2411J-00 Damper, Side Cover	Buy now
23	68F-82544-00 Clamp	Buy now
24	97013-06012 Bolt(gh1)	Buy now
25	92903-06600 Washer, plain (646)	Buy now

Fuel Injection Pump




68F0010-1081

C3

Ref	Part	
1	68F-12170-01 Camshaft assembly 1	Buy now
2	93306-00001 Brg,r-b 6000 26mm 19g ky	Buy now
3	68F-12173-00 Cap, camshaft 1	Buy now
4	93306-001U0 Bearing	Buy now
5	68F-12223-00 Seal	Buy now
6	68F-12439-00 O-ring	Buy now
7	68F-12171-00 Camshaft 1	Buy now
8	68F-12228-00 Bolt	Buy now
9	68F-13455-00 Plug	Buy now
10	68F-13473-00 O-ring	Buy now
11	68F-24372-00 Joint	Buy now
12	68F-24478-00 Joint	Buy now
13	68F-13993-00 Cover	Buy now
14	68F-24592-00 Bolt	Buy now
15	68F-13573-00 Bolt 1	Buy now

Fuel Injection Pump




68F0010-1081

C3

Ref	Part	
16	68F-13574-00 Bolt 2	Buy now
17	68F-24176-00 Bolt 1	Buy now
18	68F-12157-00 Bolt	Buy now
19	68F-24178-00 Bolt 3	Buy now
20	68F-24551-00 Bolt, joint	Buy now
21	68F-24576-00 Washer	Buy now
22	68F-24579-00 Washer 2	Buy now
23	688-24378-00 Pipe, joint	Buy now
24	68F-13910-00 Fuel Pump assembly	Buy now
25	68F-14005-00 Ring, seal	Buy now
26	68F-14126-00 Gasket	Buy now
27	68F-13942-00 Valve, Outlet	Buy now
28	68F-24470-00 Fuel Regulator assembly	Buy now
29	68F-12443-00 Stay	Buy now
30	68F-82380-01 Sensor, pressure	Buy now


Fuel Injection Pump



C3


Ref	Part	
31	68F-82384-00 Packing kit	Buy now
32	68F-82388-00 Plate	Buy now
33	68F-24638-00 8-	Buy now
34	68F-24312-00 Pipe 2	Buy now
35	68F-24356-00 Clip, pipe 1	Buy now
36	68F-24313-00 Pipe 3	Buy now
38	68F-24314-00 Pipe 4	Buy now
40	68F-13758-00 Pipe, Joint	Buy now
41	68F-24486-00 O-ring	Buy now
42	68F-13815-00 Joint 1	Buy now
43	68F-2466A-00 Packing kit	Buy now
44	68F-13973-00 Pipe Fuel 3	Buy now
46	68F-13974-00 Pipe Fuel 4	Buy now
48	68F-24474-00 Cover	Buy now
50	68F-13816-00 Joint 2	Buy now

Fuel Injection Pump



Ref	Part	
53	97013-08070 Bolt	Buy now
54	92903-08600 Washer, plain (663)	Buy now
55	90446-24MF4 Hose (L350)	Buy now
56	90446-20MF5 Hose	Buy now

Fuel Pump Drive Gear




68F0010-0051

B5

Ref	Part	
1	68F-11598-00-94 Bracket, tensioner	Buy now
2	97013-08045 Bolt	Buy now
3	92903-08600 Washer, plain (663)	Buy now
4	68F-11590-00 Tensioner assembly	Buy now
5	90119-10M72 Bolt, with washer(6m6)	Buy now
6	90506-16M39 Spring, tension	Buy now
7	90445-15M03 Hose (I23)	Buy now
8	68F-11595-00 Plate, Valve	Buy now
9	97013-08012 Bolt(62e)	Buy now
10	68F-46241-00 Belt	Buy now
11	68F-11579-01-94 Coupling, flywheel	Buy now
13	68F-11536-00-94 Gear, drive	Buy now
14	93605-10108 Pin, dowel (8g8)	Buy now
15	60V-11557-00 Washer 1	Buy now
16	97095-08025 Bolt (62g)	Buy now

Fuel Pump Drive Gear




68F0010-0051

B5

Ref	Part	
17	92995-08600 Washer, plain (663)	Buy now
18	68F-11537-00-94 Gear, driven	Buy now
19	90280-03M01 Key woodruff 146115450000	Buy now
20	95707-08600 Nut, flange(jn5)	Buy now


Generator



E1

Ref	Part	
1	68F-81450-00 Rotor assembly	Buy now
2	68F-81410-00 Stator assembly	Buy now
3	68F-85580-00 Coil, pulser	Buy now
4	61A-83721-00 Cover	Buy now
5	97013-06035 Bolt(3rv)	Buy now
6	92903-06100 Washer(6a1)	Buy now
7	92903-06600 Washer, plain (646)	Buy now
8	97885-05030 Ybs86-530 screw,panhead	Buy now
9	92995-05100 Ybs67-5 washer, spring	Buy now
10	92995-05600 Washer, plain (646)	Buy now
11	90280-05015 Key, woodruff	Buy now
12	90170-24M22 Nut(61a)	Buy now
13	90201-25M02 Washer, plate(61a)	Buy now
14	6E5-81332-00 Plate, timing	Buy now
15	97885-06010 Screw pan head	Buy now


Generator



E1


Ref	Part	
16	92995-06600 Washer, plain (646)	Buy now
17	90465-08M23 Clamp (6h3)	Buy now
18	68F-81337-00 Cover Flywheel	Buy now
19	663-82317-01 Damper, ignition coil	Buy now
20	68F-85547-01 Damper	Buy now
21	68F-14488-00 Label, caution	Buy now
22	6A1-83625-51 Mark 5	Buy now
23	6A1-83625-41 Mark 5	Buy now
24	6E5-85711-60 Mark Caution	Buy now
25	6K1-83623-41 Mark 3	Buy now
26	6K1-83623-50 Mark 3	Buy now

Intake



Ref	Part	
1	65L-13610-01 Reed valve assembly	Buy now
1	68H-13610-00 Reed valve assembly	Buy now
2	65J-W0004-01 Reed set	Buy now
3	61A-13621-A0 Gasket, valve seat	Buy now
4	97880-05016 Screw, pan head(6b0)	Buy now
5	92990-05600 Washer, plain (646)	Buy now
6	68F-13624-00-1S Plate,reed valve	Buy now
7	6F6-11372-00 Nipple, hose	Buy now
8	90445-07M03 Hose (I200)	Buy now
9	650-11370-01 Check valve assembly	Buy now
10	90105-06028 Bolt, washer based	Buy now
11	65L-13646-00 Gasket, manifold 2	Buy now
12	65L-13645-00 Gasket, manifold 1	Buy now
13	97013-06060 Bolt, hexagon	Buy now
14	92903-06600 Washer, plain (646)	Buy now


Intake



C7


Ref	Part	
15	95670-06660 Bolt, stud	Buy now
16	90179-06M24 Nut(6j8)	Buy now
17	67H-14440-00 Silencer assembly Intake	Buy now
18	65L-14483-00 Gasket	Buy now
19	90445-07M44 Hose (I390)	Buy now
20	90159-06M16 Screw, with washer(61a)	Buy now

Lower Casing. Drive 1




Ref	Part	
1	64E-45300-02-8D Lower unit assembly L	Buy now
1	64E-45300-22-8D Lower unit assembly X	Buy now
2	6J9-45301-05-8D Casing, lower	Buy now
3	93311-928U5 Bearing, needle (6g5)	Buy now
4	93332-000V3 Bearing, taper roller (6g5)	Buy now
5	6G5-45567-01-10 Shim (t:0.10mm) UR	Buy now
5	6G5-45567-01-12 Shim (t:0.12mm) UR	Buy now
5	6G5-45567-01-15 Shim (t:0.15mm) UR	Buy now
5	6G5-45567-01-18 Shim (t:0.18mm) UR	Buy now
5	6G5-45567-01-30 Shim (t:0.30mm) UR	Buy now
5	6G5-45567-01-40 Shim (t:0.40mm) UR	Buy now
5	6G5-45567-01-50 Shim (t:0.50mm) UR	Buy now
6	90340-08002 Plug, straight screw	Buy now
7	688-45341-10 Plug, drain	Buy now
8	90430-08020 Gasket	Buy now

Lower Casing. Drive 1




Ref	Part	
9	90206-22M19 Washer, wave(61a)	Buy now
10	90201-22M01 Washer, plate(61a)	Buy now
11	61A-45527-00 Collar, drive shaft	Buy now
12	61A-45538-00 Spacer, 1	Buy now
13	6G5-45536-01 Sleeve, drive shaft	Buy now
14	64D-45376-00-94 Guide, seal damper X	Buy now
14	663-45376-00-94 Guide, seal damper L	Buy now
15	688-45375-00 Damper, seal 2	Buy now
16	6E5-45378-00 Nipple, hose	Buy now
17	90445-07ME8 Hose (l250) L	Buy now
17	90445-07ME9 Hose (l250) X	Buy now
18	6E5-83558-10 End, nipple	Buy now
19	6E5-45321-00 Plate	Buy now
20	93210-58144 O-ring(47x)	Buy now
21	93106-09014 Oil seal	Buy now

Lower Casing. Drive 1




Ref	Part	
22	90119-06M10 Bolt, with washer	Buy now
23	6G5-44150-02 Shift cam assembly	Buy now
24	99001-08600 Circlip(2r6)	Buy now
25	90501-11M10 Spring, compression (663)	Buy now
26	61A-44311-01 Housing, water pump	Buy now
27	61A-44322-02 Insert, cartridge	Buy now
28	93210-86M38 O-ring (6e5)	Buy now
29	93210-37160 O-ring (6g8)	Buy now
30	6E5-44365-00 Damper, water seal 1	Buy now
31	6E5-44312-00 Cover, water pump housing	Buy now
32	6E5-44352-01 Impeller	Buy now
33	90280-04M05 Key, woodruff (6e5)	Buy now
34	6G5-44323-00 Outer plate, cartridge	Buy now
35	6E5-44315-A0 Gasket,water pump	Buy now
36	93606-12019 Pin, dowel (614)	Buy now

Lower Casing. Drive 1



Ref	Part	
37	90119-08M14 Bolt, with washer	Buy now
38	6E5-45331-00-94 Housing, bearing	Buy now
39	93101-28M16 Oil seal (6e5)	Buy now
40	93317-330U2 Bearing, cylindrical(6k0)	Buy now
41	6E5-45587-01-10 Shim (t:0.10mm) UR	Buy now
41	6E5-45587-01-12 Shim (t:0.12mm) UR	Buy now
41	6E5-45587-01-15 Shim (t:0.15mm) UR	Buy now
41	6E5-45587-01-18 Shim (t:0.18mm) UR	Buy now
41	6E5-45587-01-30 Shim (t:0.30mm) UR	Buy now
41	6E5-45587-01-40 Shim (t:0.40mm) UR	Buy now
41	6E5-45587-01-50 Shim (t:0.50mm) UR	Buy now
42	93341-930V2 Bearing, thrust(64d)	Buy now
43	93210-55M14 O-ring (70e)	Buy now
44	6E5-45344-00 Cover, oil seal	Buy now
45	97095-08025 Bolt (62g)	Buy now


Lower Casing. Drive 1



C2


Ref	Part	
46	92995-08600 Washer, plain (663)	Buy now
47	6G5-45501-01 Drive shaft comp. L	Buy now
47	6G5-45501-21 Drive shaft comp. X	Buy now
48	6G5-45551-10 Pinion	Buy now
49	90170-16M01 Nut, hexagon (688)	Buy now
50	6G5-45560-10 Gear	Buy now
51	93315-425V3 Bearing, needle (6g5)	Buy now
52	6J9-45611-01 Shaft, propeller	Buy now
53	6E5-45641-02 Shifter	Buy now
54	6E5-45634-01 Slide, shift	Buy now
55	90501-16M37 Spring (6g5)	Buy now
56	93507-32009 Ball (12r)	Buy now
57	93511-32017 Ball (498)	Buy now
58	93503-16003 Ball	Buy now
59	90250-08M07 Pin, straight (6g5)	Buy now

Lower Casing. Drive 1



Ref	Part	
60	6G5-45631-10 Clutch, dog	Buy now
61	6E5-45633-01 Ring, cross pin	Buy now
62	6J9-45332-00-94 Housing, bearing	Buy now
63	93306-209U0 Bearing (6g5)	Buy now
64	6G5-45571-02 Gear	Buy now
65	6G5-45576-10 Washer, thrust 2	Buy now
66	93315-430U8 Bearing	Buy now
67	93101-30M17 Oil seal (6e5)	Buy now
68	93210-97M55 O-ring (6g5)	Buy now
69	6G5-45577-02-10 Shim (t:0.10mm) UR	Buy now
69	6G5-45577-02-12 Shim (t:0.12mm) UR	Buy now
69	6G5-45577-02-15 Shim (t:0.15mm) UR	Buy now
69	6G5-45577-02-18 Shim (t:0.18mm) UR	Buy now
69	6G5-45577-02-30 Shim (t:0.30mm) UR	Buy now
69	6G5-45577-02-40 Shim (t:0.40mm) UR	Buy now


Lower Casing. Drive 1



Ref	Part	
69	6G5-45577-02-50 Shim (t:0.50mm) UR	Buy now
70	90201-30M92 Washer (6g5)	Buy now
71	90282-04M00 Key, straight(6g5)	Buy now
72	6G5-45383-01 Washer, claw	Buy now
73	6G5-45384-00 Nut	Buy now

Lower Casing. Drive 2


STD



Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	6E5-44361-00 Tube, water L	Buy now
2	6E5-44361-20 Tube, water X	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	97075-10045 Bolt(64d)	Buy now
6	92995-10100 Ybs67-10 washer, spring	Buy now
7	90119-10M89 Bolt, with washer	Buy now
8	6j9-45214-00 Cover, water inlet	Buy now
9	6j9-45215-00 Cover, water inlet	Buy now
10	90152-05M08 Screw, countersunk	Buy now
11	90185-05002 Nut nylon (sus)(ex4)	Buy now
12	6j9-45371-01 Tab-trim	Buy now
13	90105-10M00 Bolt, hexagon (663)	Buy now
14	90445-07M33 Hose (L1080)	Buy now

Lower Casing. Drive 2

STD




67H0100-1260

C6

Ref	Part	
15	6E5-83558-00 End, nipple	Buy now
16	90465-11M10 Clamp	Buy now
17	6E5-45987-01 Spacer 1	Buy now
18	688-45997-01 Spacer 2	Buy now
19	92990-18200 Washer (6e5)	Buy now
20	90171-18M04 Nut, castle (6e5)	Buy now
21	91490-40030 Pin, cotter (663)	Buy now
22	6G5-45941-00-98 Propeller (3x15-1/4x15"-m) UR	Buy now
22	6G5-45943-01-98 Propeller (3x13-3/4"x21"-m) UR	Buy now
22	6G5-45945-01-98 Propeller (3x14"x19"-m) UR	Buy now
22	6G5-45947-01-98 Propeller (3x14-1/2"x17"-m) UR	Buy now
22	6G5-45949-00-98 Propeller (3x13-1/2"x23"-m) UR	Buy now
22	6G5-45930-00-98 Propeller (ss 3x13-3/8"x25"-m) UR	Buy now
22	6G5-45932-00-98 Propeller (3x15-3/4"x13"-m) UR	Buy now
22	6G5-45952-00-98 Propeller (3x14-5/8"x16"-m) UR	Buy now

Lower Casing. Drive 2

STD




67H0100-1260

C6


Ref	Part	
22	6G5-45970-02-98 Propeller (3x15-1/4 x15 -m) UR	Buy now
22	6G5-45972-02-98 Propeller (3x13-3/4 x21 -m) UR	Buy now
22	6G5-45974-03-98 Propeller (3x13-3/4"x19"-m2) UR	Buy now
22	6G5-45976-01-98 Propeller (3x13-3/8"x23"-m) UR	Buy now
22	6G5-45978-03-98 Propeller (3x13-3/4"x17"-m2) UR	Buy now
22	6R4-45970-A0 Propeller (3X15-1/4"X19"-M) UR	Buy now
22	6R4-45972-A0 Propeller (3X14-7/8"X21"-M) UR	Buy now
22	6R4-45974-A0 Propeller (3X14-1/2"X23"-M) UR	Buy now
22	6R4-45976-A0 Propeller (3X14-1/2"X15"-M) UR	Buy now
22	6R4-45978-A0 Propeller (3X15-1/4"X17"-M) UR	Buy now

Lower Casing. Drive 3




Ref	Part	
1	64H-45300-22-8D Lower unit assembly X	Buy now
2	6J9-45301-05-8D Casing, lower	Buy now
3	93311-928U5 Bearing, needle (6g5)	Buy now
4	93390-000U2 Bearing(6k0)	Buy now
5	93341-465U4 Bearing, thrust (6k0)	Buy now
6	6G5-45567-01-10 Shim (t:0.10mm) UR	Buy now
6	6G5-45567-01-12 Shim (t:0.12mm) UR	Buy now
6	6G5-45567-01-15 Shim (t:0.15mm) UR	Buy now
6	6G5-45567-01-18 Shim (t:0.18mm) UR	Buy now
6	6G5-45567-01-30 Shim (t:0.30mm) UR	Buy now
6	6G5-45567-01-40 Shim (t:0.40mm) UR	Buy now
6	6G5-45567-01-50 Shim (t:0.50mm) UR	Buy now
7	90340-08002 Plug, straight screw	Buy now
8	688-45341-10 Plug, drain	Buy now
9	90430-08020 Gasket	Buy now

Lower Casing. Drive 3




Ref	Part	
10	90206-22M19 Washer, wave(61a)	Buy now
11	90201-22M01 Washer, plate(61a)	Buy now
12	61A-45527-00 Collar, drive shaft	Buy now
13	61A-45538-00 Spacer, 1	Buy now
14	6G5-45536-01 Sleeve, drive shaft	Buy now
15	64D-45376-00-94 Guide, seal damper X	Buy now
16	688-45375-00 Damper, seal 2	Buy now
17	6J8-45378-00 Nipple, hose (plug)	Buy now
18	6E5-45321-00 Plate	Buy now
19	93210-58144 O-ring(47x)	Buy now
20	93106-09014 Oil seal	Buy now
21	90119-06M10 Bolt, with washer	Buy now
22	6K1-44150-01 Shift cam assembly	Buy now
23	99001-08600 Circlip(2r6)	Buy now
24	90501-11M10 Spring, compression (663)	Buy now

Lower Casing. Drive 3




Ref	Part	
25	61A-44311-01 Housing, water pump	Buy now
26	61A-44322-02 Insert, cartridge	Buy now
27	93210-86M38 O-ring (6e5)	Buy now
28	93210-37160 O-ring (6g8)	Buy now
29	6E5-44365-00 Damper, water seal 1	Buy now
30	6E5-44312-00 Cover, water pump housing	Buy now
31	6E5-44352-01 Impeller	Buy now
32	90280-04M05 Key, woodruff (6e5)	Buy now
33	6G5-44323-00 Outer plate, cartridge	Buy now
34	6E5-44315-A0 Gasket, water pump	Buy now
35	93606-12019 Pin, dowel (614)	Buy now
36	90119-08M14 Bolt, with washer	Buy now
37	6E5-45331-00-94 Housing, bearing	Buy now
38	93101-28M16 Oil seal (6e5)	Buy now
39	93317-330U2 Bearing, cylindrical(6k0)	Buy now

Lower Casing. Drive 3




Ref	Part	
40	6E5-45587-01-10 Shim (t:0.10mm) UR	Buy now
40	6E5-45587-01-12 Shim (t:0.12mm) UR	Buy now
40	6E5-45587-01-15 Shim (t:0.15mm) UR	Buy now
40	6E5-45587-01-18 Shim (t:0.18mm) UR	Buy now
40	6E5-45587-01-30 Shim (t:0.30mm) UR	Buy now
40	6E5-45587-01-40 Shim (t:0.40mm) UR	Buy now
40	6E5-45587-01-50 Shim (t:0.50mm) UR	Buy now
41	93341-930V2 Bearing, thrust(64d)	Buy now
42	93210-55M14 O-ring (70e)	Buy now
43	6E5-45344-00 Cover, oil seal	Buy now
44	97095-08025 Bolt (62g)	Buy now
45	92995-08600 Washer, plain (663)	Buy now
46	6G5-45501-21 Drive shaft comp. X	Buy now
47	6G5-45551-10 Pinion	Buy now
48	90170-16M01 Nut, hexagon (688)	Buy now

Lower Casing. Drive 3




Ref	Part	
49	6K1-45560-01 Gear	Buy now
50	93315-425V3 Bearing, needle (6g5)	Buy now
51	6K1-45611-10 Shaft, propeller	Buy now
52	6K1-45641-01 Shifter	Buy now
53	6E5-45634-01 Slide, shift	Buy now
54	90501-16M37 Spring (6g5)	Buy now
55	93507-32009 Ball (12r)	Buy now
56	93511-32017 Ball (498)	Buy now
57	93503-16003 Ball	Buy now
58	90250-08M07 Pin, straight (6g5)	Buy now
59	6G5-45631-10 Clutch, dog	Buy now
60	6E5-45633-01 Ring, cross pin	Buy now
61	6K1-45332-01-94 Housing, bearing	Buy now
62	93332-00048 Bearing(6k0)	Buy now
63	6K1-45570-20 Gear	Buy now

Lower Casing. Drive 3



Ref	Part	
64	6K1-45576-00 Washer, thrust	Buy now
65	93341-440U5 Bearing, thrust (6k0)	Buy now
66	6K1-45578-01-10 Shim (t:0.10mm) UR	Buy now
66	6K1-45578-01-12 Shim (t:0.12mm) UR	Buy now
66	6K1-45578-01-15 Shim (t:0.15mm) UR	Buy now
66	6K1-45578-01-18 Shim (t:0.18mm) UR	Buy now
66	6K1-45578-01-30 Shim (t:0.30mm) UR	Buy now
66	6K1-45578-01-40 Shim (t:0.40mm) UR	Buy now
66	6K1-45578-01-50 Shim (t:0.50mm) UR	Buy now
67	93315-430U8 Bearing	Buy now
68	93101-30M17 Oil seal (6e5)	Buy now
69	93210-97M55 O-ring (6g5)	Buy now
70	6G5-45577-02-10 Shim (t:0.10mm) UR	Buy now
70	6G5-45577-02-12 Shim (t:0.12mm) UR	Buy now
70	6G5-45577-02-15 Shim (t:0.15mm) UR	Buy now


Lower Casing. Drive 3



D1


Ref	Part	
70	6G5-45577-02-18 Shim (t:0.18mm) UR	Buy now
70	6G5-45577-02-30 Shim (t:0.30mm) UR	Buy now
70	6G5-45577-02-40 Shim (t:0.40mm) UR	Buy now
70	6G5-45577-02-50 Shim (t:0.50mm) UR	Buy now
71	90282-04M00 Key, straight(6g5)	Buy now
72	6G5-45383-01 Washer, claw	Buy now
73	6G5-45384-00 Nut	Buy now

Lower Casing. Drive 4




Ref	Part	
1	6E5-44366-00 Damper, water seal 2	Buy now
2	6E5-44361-20 Tube, water X	Buy now
3	6E5-44365-00 Damper, water seal 1	Buy now
4	93608-12M05 Pin, dowel b (6e5)	Buy now
5	97075-10045 Bolt(64d)	Buy now
6	92995-10100 Ybs67-10 washer, spring	Buy now
7	90119-10M89 Bolt, with washer	Buy now
8	6J9-45214-00 Cover, water inlet	Buy now
9	6J9-45215-00 Cover, water inlet	Buy now
10	90152-05M08 Screw, countersunk	Buy now
11	90185-05002 Nut nylon (sus)(ex4)	Buy now
12	6K1-45371-02 Tab-trim	Buy now
13	90105-10M00 Bolt, hexagon (663)	Buy now
14	6E5-45987-01 Spacer 1	Buy now
15	688-45997-01 Spacer 2	Buy now

Lower Casing. Drive 4




Ref	Part	
16	92990-18200 Washer (6e5)	Buy now
17	90171-18M04 Nut, castle (6e5)	Buy now
18	91490-40030 Pin, cotter (663)	Buy now
19	6K1-45970-01-98 Propeller (3x15-1/4"x15"-ml) UR	Buy now
19	6K1-45972-01-98 Propeller (3x13-3/4"x21"-ml) UR	Buy now
19	6K1-45974-02-98 Propeller (3x13-3/4"x19"-ml1) UR	Buy now
19	6K1-45978-02-98 Propeller (3x13-3/4"x17"-ml1) UR	Buy now
19	6R1-45970-A0 Propeller, Ss (3 X 15-1/4" X 19"-MI) UR	Buy now
19	6R1-45972-A0 Propeller (3X14-7/8"X21"-MI) UR	Buy now
19	6R1-45974-A0 Propeller (3X14-1/2"X23"-MI) UR	Buy now
19	6R1-45976-A0 Propeller (3X15-1/4"X15"-MI) UR	Buy now
19	6R1-45978-A0 Propeller (3X15-1/4"x17"-MI) UR	Buy now

Meter



Ref	Part	
1	6Y5-8350T-02 Digital tachometer assembly AP	Buy now
2	9E450-04433 Housing, connector (m-4-w) M-4-W	Buy now
3	9E450-04533 Housing, f-4-w(5pcs) F-4-W	Buy now
4	92990-04100 Ybs67-4 washer, spring	Buy now
5	95380-04600 Nut,hex	Buy now
6	6Y5-83500-S5 Meter assembly AP	Buy now
7	6Y5-83570-S5 Speedometer assembly	Buy now
10	6Y5-83533-T2 Grommet	Buy now
11	6Y5-83557-31 Tube	Buy now
12	6Y5-83728-00 Connector assembly	Buy now
20	90465-11M10 Clamp AP	Buy now
14	6Y5-87122-S0 Cord assembly 1 AP	Buy now
15	6Y5-83553-00 Wire, lead (l=2.5m) AP	Buy now
15	6Y5-83553-M0 Wire, lead (l=2.5m) AP	Buy now
16	1E6-82151-00 Fuse (10a) FOR 6Y5-83553-M0	Buy now


Meter



E2

Ref	Part	
17	6Y5-82117-00 Wire, lead AP	Buy now
18	68F-82553-80 Extension, wire lead (8m) AP	Buy now
18	68F-82553-90 Extension, wire lead (9m) AP	Buy now
19	6Y5-83557-10 Tube (8m) AP	Buy now
21	6Y5-8350F-00 Fuel meter movement assembly AP	Buy now
23	6Y5-83553-F1 Wire, lead AP	Buy now
24	6Y5-85752-01 Sender unit assembly, fuel meter AP	Buy now
25	90158-06002 33 – AP	Buy now
27	703-82531-00 Wire, lead AP	Buy now


Oil Pump



D1

Ref	Part	
1	68F-13200-00 Oil injection pump assembly	Buy now
1	68H-13200-00 Oil injection pump assembly	Buy now
1	68L-13200-00 Oil injection pump assembly	Buy now
2	6R3-13471-00 Screw	Buy now
3	6L2-13475-00 Gasket, breather bolt	Buy now
4	93210-19M82 O-ring(6j8)	Buy now
5	90109-06M40 Bolt(6h0)	Buy now
6	6G5-13416-00 Pipe, oil 1	Buy now
7	90465-11M10 Clamp	Buy now
8	90445-07M00 Hose (l200)	Buy now
9	90445-07M09 Hose (l390)	Buy now
10	90445-07MA5 Hose (l200)	Buy now
11	90445-07M10 Hose (L770)	Buy now
12	90445-07MA4 Hose (l390)	Buy now
13	90445-07M80 Hose (l770)	Buy now


Oil Pump



D1


Ref	Part	
14	90468-07M02 Clip (6e5)	Buy now
15	6R3-13183-00 Valve, check	Buy now
16	90445-07M04 Hose(62t)	Buy now
17	90464-07M20 Clamp(6h0)	Buy now
18	90464-07M05 Clamp (6g5)	Buy now
19	6R3-11537-00 Gear, driven	Buy now
20	6R3-13117-00 Collar, distance	Buy now
21	93210-13M04 93210-13m04	Buy now
22	90202-08M44 Washer, plate(6r3)	Buy now
23	67H-41241-00 Rod, link	Buy now
24	6H1-41237-00 Joint, link	Buy now
25	95380-05600 Nut, hexagon (663)	Buy now
26	6R5-41237-00 Joint, link	Buy now
27	90468-05M03 Clip(6j8)	Buy now
28	90202-05088 Washer, plate (666)	Buy now

Oil Pump



Ref	Part	
29	90445-12M14 Hose (I50)	Buy now
31	90467-08M18 Clip	Buy now
32	68F-13100-00 Solenoid pump assembly	Buy now
33	68F-13418-00 Hose 4	Buy now
34	68F-13184-00 Spring, oil pipe	Buy now
35	68F-13440-00 Filter assembly	Buy now
36	68F-1316F-00 Hose 1	Buy now
37	68F-13133-00 Clip	Buy now
38	68F-1316G-00 Hose 2	Buy now
39	68F-1316A-00 Check Valve assembly	Buy now
40	68F-13416-00 Hose 3	Buy now
41	68F-14485-00 Pipe, joint	Buy now
42	68F-1319K-00 Plate	Buy now
43	97095-06020 Bolt(7u8)	Buy now
44	92995-06100 Washer(6a1)	Buy now


Oil Pump



D1


Ref	Part	
45	92995-06600 Washer, plain (646)	Buy now
46	90110-06M06 Bolt, hexagon socket head	Buy now

Oil Tank




Ref	Part	
1	68F-21750-00 Oil tank assembly	Buy now
2	6E5-13448-00 Cap, oil tank	Buy now
3	90465-13M11 Clamp (6e5)	Buy now
4	67H-85730-01 Oil level gauge assembly	Buy now
5	6E5-13411-00 Strainer, oil	Buy now
6	6E5-13414-00 Gasket, strainer cover	Buy now
7	6R3-8259E-00 Switch assembly	Buy now
8	90445-07M43 Hose (I600)	Buy now
9	6A0-82317-00 Damper, ignition coil	Buy now
10	624-42542-00 Collar	Buy now
11	90119-06M65 Bolt, with washer	Buy now
12	90465-12M92 Clamp	Buy now
13	6E5-24323-00 Pipe 12	Buy now
14	90465-11M10 Clamp	Buy now
15	6E5-24379-00 Pipe, joint 4	Buy now

Oil Tank



Ref	Part	
16	90445-12207 Hose (I3000)	Buy now
19	90464-13M34 Clamp(6r3)	Buy now
20	61A-21708-20 Sub oil tank assembly.	Buy now
21	6E5-21733-20 Sub tank, oil (10.5l)	Buy now
22	6E5-21770-03 Oil tank cap assembly	Buy now
23	6E5-24322-00 Pipe 11	Buy now
25	646-24251-02 Strainer 1	Buy now
26	6E5-24319-01 Pipe, oil	Buy now
28	6E5-81900-01 Oil feed pump assembly	Buy now
29	6E5-81922-00 Grommet	Buy now
30	6E5-24321-01 Pipe 10	Buy now
32	90445-11M26 Hose (I8000)	Buy now
34	6E5-85720-04 Oil level gauge assembly	Buy now
35	6R3-85721-80 Wire, lead	Buy now
37	6E5-21734-01-33 Holder, oil sub tank	Buy now


Oil Tank



Ref	Part	
38	6E5-21798-01-33 Bracket, damper	Buy now
39	6E5-21746-00 Damper	Buy now
40	97080-06100 Bolt, hexagon	Buy now
41	92990-06600 Washer, plain (646)	Buy now
42	95380-06600 Nut(661)	Buy now
43	6E5-13437-62 Mark Caution	Buy now
44	68F-28100-00 Tool kit	Buy now
45	68F-28199-74-A0 12 – UR (E,F,S)	Buy now
45	68F-28199-74-B0 12 – UR (D,NL,I)	Buy now
46	68F-28199-84-A0 O/m lz150peto/lz200neto/z1 '03 UR (DK,P,GR)	Buy now
46	68F-28199-84-B0 O/m lz150peto/lz200neto/z1 '03 UR (N,S,SS)	Buy now


D3

Power Trim & Tilt Assy 1




Ref	Part	
1	68F-43800-01-4D Power trim & tilt assembly	Buy now
2	64E-43825-01 Housing Trim & Tilt	Buy now
3	64E-4388J-00 Plug 2	Buy now
4	93210-10M74 O-ring	Buy now
5	64E-43817-00 Filter 2	Buy now
6	64E-43810-00 Tilt piston sub assembly	Buy now
7	64E-43898-00 Seal, dust 2	Buy now
8	64E-43867-00 O-ring 7	Buy now
9	64E-43866-00 O-ring 6	Buy now
10	6E5-43862-00 O-ring 2	Buy now
11	64E-43883-00 O-ring 10	Buy now
12	6E5-43872-00 Ring, back-up 2	Buy now
13	6E5-43814-02 Piston, free	Buy now
15	64E-43820-00 Trim piston sub assembly	Buy now
16	64E-43821-00 Screw, trim cylinder end	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
17	64E-43822-00 Seal, trim dust	Buy now
18	64E-4384J-00 Seal, trim down	Buy now
19	6G5-43864-00 O-ring 4	Buy now
20	6E5-43864-00 O-ring 4	Buy now
21	6E5-43874-01 Ring, back-up 4	Buy now
22	64E-43828-00 Body, reservoir	Buy now
23	64E-43829-00 Plug, reservoir	Buy now
24	64E-43897-00 O-ring	Buy now
25	64E-4388E-00 Bolt ,screw (l:14mm)	Buy now
26	64E-43869-00 O-ring 9	Buy now
27	64E-4381G-00 Pin 1	Buy now
28	6E5-43858-00 Ball 1	Buy now
29	64E-4382G-00 Valve seat	Buy now
30	90201-08M14 Washer, plate	Buy now
31	97080-08016 Bolt	Buy now

Power Trim & Tilt Assy 1




Ref	Part	
32	64E-43818-01 Lower shock mount pin set	Buy now
33	90386-22M98 Bush(61u)	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
1	64E-4388E-10 Bolt ,screw (l:34.7mm)	Buy now
2	64E-43831-00 Connector, shaft	Buy now
3	64E-43868-00 O-ring 8	Buy now
4	64E-43830-00 Gear pump assembly	Buy now
5	72X-43858-00 Ball	Buy now
6	64E-43843-00 Screw, valve lock	Buy now
7	64E-43841-00 Piston, shuttle	Buy now
8	64E-43802-00 Valve sub assembly	Buy now
9	6E5-43896-00 O-ring	Buy now
10	6G5-43863-00 O-ring 3	Buy now
11	64E-43851-00 Seat, Relief Valve	Buy now
12	64E-43858-00 Ball	Buy now
13	64E-43859-00 Pin, Valve Support	Buy now
14	64E-43855-00 Spring, up relief	Buy now
15	64E-43850-00 Valve sub assembly	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
16	64E-43865-00 O-ring 10	Buy now
17	64E-43816-00 Filter 1	Buy now
19	64E-43817-10 Filter 2	Buy now
20	64E-43860-00 Manual valve sub-assembly	Buy now
21	72X-85075-L0 O-ring (nsd161)	Buy now
22	64E-43827-00 Ring set	Buy now
23	64E-4387A-00 O-ring	Buy now
24	64E-43873-00 Ring, back up	Buy now
25	64E-43875-00 Ring, snap	Buy now
26	64E-43879-10 Screw, with washer	Buy now
27	64E-43879-00 Screw, with washer	Buy now
28	67H-43880-01 Motor assembly	Buy now
29	6H1-4386K-10 Spring, brush	Buy now
30	64E-4380J-00 Holder Brush	Buy now
31	64E-43891-00 Brush 1	Buy now

Power Trim & Tilt Assy 2




Ref	Part	
32	97607-04310 Screw, pan head(6g8)	Buy now
33	64E-4380F-00 Holder, brush 2	Buy now
34	64E-43892-00 Breaker comp. (brush 2)	Buy now
35	6G5-43865-00 O-ring	Buy now
36	93102-08M43 Oil seal(6b0)	Buy now
37	64E-43805-00 Armature assembly	Buy now
38	64E-43843-10 Screw valve lock	Buy now

Remote Control Box




Ref	Part	
1	703-48205-17 Remote control assembly (10p, ptt) AP WITH PT/T SW.	Buy now
2	704-48207-23 Remote Control assembly AP WITH PT/T SW.	Buy now
3	701-48320-50 Cable, Remote Control L=15F UR	Buy now
3	701-48320-60 Cable, Remote Control L=16F UR	Buy now
3	701-48320-80 Cable, Remote Control L=17F UR	Buy now
3	701-48350-00 Cable, Remote Control L=21F UR	Buy now
3	701-48350-20 Cable, Remote Control L=23F UR	Buy now

Repair Kit 1




Ref	Part	
1	68F-W0001-00 Power head gasket kit	Buy now
2	65L-13645-00 Gasket, manifold 1	Buy now
3	65L-13646-00 Gasket, manifold 2	Buy now
4	61A-13621-A0 Gasket, valve seat	Buy now
5	65L-14483-00 Gasket	Buy now
6	90430-14115 Gasket (663)	Buy now
7	68F-11381-00 Gasket 1	Buy now
8	68F-41114-00 Gasket, exhaust outer cover	Buy now
9	6G5-11382-A1 Gasket 2	Buy now
10	68F-11181-00 Gasket, cylinder head 1	Buy now
11	68F-11193-01 Gasket, head cover 1	Buy now
12	688-12414-A1 Gasket, cover	Buy now
13	93102-40M14 Oil seal(61a)	Buy now
14	93211-04001 O-ring	Buy now
15	93102-35M61 Oil seal	Buy now

Repair Kit 1



Ref	Part	
16	93101-22M15 Oil seal (6e5)	Buy now
17	93210-74M35 O-ring (6e5)	Buy now
18	68F-45113-00 Gasket, upper casing	Buy now


Repair Kit 2



E6

Ref	Part	
1	6G5-W0001-C1 Lower unit gasket kit	Buy now
2	6G5-41134-A1 Gasket, exhaust manifold	Buy now
3	6G5-45114-A1 Gasket, upper casing	Buy now
4	6E5-41135-A0 Gasket, exhaust manifold	Buy now
5	90430-08020 Gasket	Buy now
6	6E5-45123-00 Gasket, muffler	Buy now
7	6E5-44365-00 Damper, water seal 1	Buy now
8	6E5-44366-00 Damper, water seal 2	Buy now
9	93210-58144 O-ring(47x)	Buy now
10	93106-09014 Oil seal	Buy now
11	93210-86M38 O-ring (6e5)	Buy now
12	93210-37160 O-ring (6g8)	Buy now
13	6E5-44315-A0 Gasket,water pump	Buy now
14	93101-28M16 Oil seal (6e5)	Buy now
15	93210-55M14 O-ring (70e)	Buy now


Repair Kit 2



E6

Ref	Part	
16	93210-97M55 O-ring (6g5)	Buy now
17	93101-30M17 Oil seal (6e5)	Buy now
18	61A-W0078-A3 Water pump repair kit	Buy now
19	61A-44322-02 Insert, cartridge	Buy now
22	6E5-44352-01 Impeller	Buy now
23	6G5-44323-00 Outer plate, cartridge	Buy now
25	93606-12019 Pin, dowel (614)	Buy now
26	90119-08M14 Bolt, with washer	Buy now
27	90280-04M05 Key, woodruff (6e5)	Buy now
28	61A-W0078-2A Chrome pump kit	Buy now
29	6R3-44322-42 Insert, cartridge	Buy now
30	6G5-44323-40 Outer plate, cartridge	Buy now


Starting Motor



F3

Ref	Part	
1	68F-81800-01 Starting motor assembly	Buy now
2	67F-81850-00 Armature assembly	Buy now
3	67F-81810-00 Stator assembly	Buy now
4	68F-81840-00 Brush holder assembly	Buy now
5	67F-81801-00 Brush set	Buy now
6	67F-81813-00 Spring, brush	Buy now
7	68F-81820-00 Rear bracket assembly	Buy now
8	67F-81808-00 Pinion assembly	Buy now
9	67F-81857-00 Pinion stopper set	Buy now
10	67F-81807-00 Gear assembly, starting motor	Buy now
11	67F-81832-00 Clutch, over run	Buy now
12	67F-81836-00 Shaft, pinion	Buy now
13	67F-81821-00 Bracket, center 1	Buy now
14	67F-81841-00 Bearing	Buy now
15	67F-81891-00 Gear, ring	Buy now


Starting Motor



F3


Ref	Part	
16	67F-8183R-00 Gasket	Buy now
17	67F-81830-00 Bracket, center 2	Buy now
18	67F-8183T-00 Gear, Idler	Buy now
19	67F-81809-00 Washer kit	Buy now
20	67F-81842-00 Cover	Buy now
21	67F-81839-00 Lever assembly	Buy now
22	68F-81941-01 Starter Relay assembly	Buy now
23	67F-81869-00 Cover, dust	Buy now
24	6K7-81826-10 Bolt	Buy now
25	67F-81828-00 Bolt 2	Buy now
26	67F-81846-00 Screw	Buy now
27	90179-08003 Nut	Buy now
28	68F-81925-00 Terminal	Buy now
29	68F-82582-00 Cover, wire harness	Buy now
30	97013-08045 Bolt	Buy now

Starting Motor



Ref	Part	
31	92903-08600 Washer, plain (663)	Buy now

Steering Guide Attachment 1




67H0100-9290

D6

Ref	Part	
1	6E5-61350-02 Steering guide attachment kit AP	Buy now
2	6E5-61351-01 Rod, steering link	Buy now
3	90387-10M61 Collar (6e5)	Buy now
4	90560-12M01 Spacer (6e5)	Buy now
5	6E5-61355-00 Bolt	Buy now
6	90185-09M01 Nut, nylon (663)	Buy now
7	90201-10M20 Washer, plate (663)	Buy now
8	6E5-43145-01 Cap, clamp bracket	Buy now
9	93210-16275 O-ring	Buy now

Steering Guide Attachment 2




67H0100-0300

D7


Ref	Part	
1	6E5-61301-01 Tie bar assembly (l:600-800mm) AP	Buy now
2	6E5-61313-00 Adjuster	Buy now
3	6E5-61311-11 Tie bar	Buy now
4	6E5-61315-00 Tie bar, 2	Buy now
5	6E5-61303-00 Steering axle comp.	Buy now
6	90170-14M06 Nut (6e5)	Buy now
7	95380-14700 Nut (6e5)	Buy now
8	90201-10M76 Washer, plate (6e5)	Buy now
9	90101-09M70 Bolt (6e5)	Buy now
10	90170-09M05 Nut, hexagon (6e5)	Buy now
11	90185-09M01 Nut, nylon (663)	Buy now

Switch. Panel



Ref	Part	
1	6K1-82570-07 Panel switch assembly AP	Buy now
2	6K1-82571-01 Plate, panel switch	Buy now
3	6K1-82510-06 Main switch assembly	Buy now
4	703-82577-00 Cap, key	Buy now
5	6K1-82575-00 Engine stop switch assembly	Buy now
6	682-82556-00 Lanyard, stop switch	Buy now
7	6K1-83614-01 Bracket	Buy now
8	98980-05010 Screw, bind(6k1)	Buy now
23	92990-05100 Ybs67-5 washer, spring AP	Buy now
21	95380-05600 Nut, hexagon (663) AP	Buy now
11	688-83383-11 Buzzer	Buy now
12	6K1-85830-01 Control unit assembly	Buy now
13	98980-06020 Screw, bind (j17)	Buy now
14	95380-06600 Nut(661)	Buy now
15	92990-06100 Washer(6a1)	Buy now


Switch. Panel



E4

Ref	Part	
16	92990-06600 Washer, plain (646)	Buy now
17	6K1-81980-00 Diode assembly	Buy now
18	6K1-8258A-40 Extension, wire harness AP	Buy now
19	61B-8258A-01 Extension, wire harness AP	Buy now
20	90149-05M05 Screw(6k0) AP	Buy now
22	92990-05600 Washer, plain (646) AP	Buy now


Top Cowling



A4

Ref	Part	
1	68F-42610-50-4D Top cowling assembly	Buy now
1	68H-42610-50-4D Top Cowling assembly	Buy now
1	68L-42610-50-4D Top cowling assembly	Buy now
2	68F-42647-01-94 Holder, clamp band	Buy now
3	68F-42648-01-94 Holder, clamp band	Buy now
4	92990-06100 Washer(6a1)	Buy now
5	95380-06600 Nut(661)	Buy now
6	68F-42663-00 Damper 2	Buy now
7	68F-42651-00 Hook	Buy now
8	67F-42652-00 Hook	Buy now
9	97095-06016 Bolt, hexagon deep recess	Buy now
10	92995-06600 Washer, plain (646)	Buy now
11	68F-42619-00 Damper, form	Buy now
12	68F-42613-00-4D Molding, air duct	Buy now
13	90179-06M24 Nut(6j8)	Buy now


Top Cowling



A4


Ref	Part	
14	68F-42662-00 Damper	Buy now
15	68F-42677-50 Graphic, front	Buy now
15	68H-42677-50 Graphic, front	Buy now
15	68L-42677-50 Graphic, front	Buy now
16	68F-42687-10 Emblem, rear	Buy now
17	68F-W0070-50 Graphic set	Buy now
18	68F-42681-50 Mark, cowling	Buy now
19	68F-42682-50 Mark, cowling	Buy now
20	68F-42678-50 Graphic, rear	Buy now
20	68H-42678-50 Graphic, front	Buy now
20	68L-42678-50 Graphic, Rear	Buy now
21	68F-42677-60 Graphic, front	Buy now
22	67F-13448-00 Cap	Buy now
23	68F-13434-00 Label, Caution	Buy now

Upper Casing



Ref	Part	
1	6E5-45111-02-8D Casing, upper L	Buy now
1	6E5-45111-23-8D Casing, upper X	Buy now
2	6R3-42791-41 Mark 1	Buy now
3	6R3-42792-41 Mark	Buy now
4	6E5-45155-00 Cap	Buy now
5	97095-06010 Bolt	Buy now
6	92995-06600 Washer, plain (646)	Buy now
7	93608-12M05 Pin, dowel b (6e5)	Buy now
8	90119-08027 Bolt, with washer	Buy now
9	6G5-41137-11-94 Guide, exhaust FLUSHING KIT	Buy now
10	6E5-42724-00 Grommet	Buy now
11	6G5-12581-00 Joint, hose	Buy now
13	68F-45113-00 Gasket, upper casing	Buy now
14	90119-08M79 Bolt, hexagon (fj1)	Buy now
15	97095-08045 Bolt, hexagon	Buy now


Upper Casing



B7

Ref	Part	
16	92995-08100 Ybs67-8 washer, spring	Buy now
17	95380-08700 Nut(661)	Buy now
19	6H1-11372-00 Nipple, hose FLUSHING KIT	Buy now
20	6G5-41131-01-5B Manifold, ext. 1	Buy now
21	6G5-45114-A1 Gasket, upper casing	Buy now
22	97095-08030 Bolt, hexagon (fj1)	Buy now
23	92995-08600 Washer, plain (663)	Buy now
24	64D-41132-00-5B Manifold, exhaust	Buy now
25	6G5-41134-A1 Gasket, exhaust manifold	Buy now
28	6E5-14711-01-5B Muffler 1	Buy now
29	6E5-14737-00 Damper, muffler	Buy now
30	90183-05M02 Nut, spring (6e5)	Buy now
31	6E5-45123-00 Gasket, muffler	Buy now
32	6E5-41135-A0 Gasket, exhaust manifold	Buy now
35	6E5-45318-00 Bushing, drive shaft 3 X	Buy now

Upper Casing




68F2010-3260

B7


Ref	Part	
36	93420-36M01 Circlip (6a0) X	Buy now
37	64D-14721-20-5B Muffler 2 X	Buy now
38	64D-45123-00 Gasket, muffler X	Buy now
39	64D-45375-00 Damper, seal X	Buy now

Vapor Separator 1




Ref	Part	
1	68F-13784-00 Cover, pump	Buy now
2	68F-24216-00 Stay	Buy now
3	68F-24473-00 Screw	Buy now
4	66K-14980-00 Body, float chamber	Buy now
5	68F-14182-01 Cover, float chamber	Buy now
6	65L-14546-00 Valve, needle	Buy now
7	66K-14985-00 Float	Buy now
8	66K-14548-01 Pin, float arm	Buy now
9	66K-14984-00 Gasket, float chamber	Buy now
10	65L-14125-00 Screw	Buy now
11	68F-13906-00 Regulator, pressure	Buy now
12	66K-14239-00 Seal	Buy now
13	66K-14325-01 Screw, pan head	Buy now
14	66K-14163-00 Spacer	Buy now
15	65L-13905-00 Filter comp	Buy now

Vapor Separator 1




Ref	Part	
16	68F-13971-00 Pipe, fuel 1	Buy now
17	65L-24387-00 Clip	Buy now
18	65L-14966-00 Cap	Buy now
19	65L-24486-00 O-ring	Buy now
20	68F-24251-00 Strainer 1	Buy now
21	66K-14245-00 Screw, guide	Buy now
22	68F-82509-00 Wire, sub lead	Buy now
23	65L-14227-00 Washer	Buy now
24	68F-13907-00 Fuel pump comp.	Buy now
25	65L-14159-00 Clip	Buy now
26	68F-13781-00 Damper, pump	Buy now
27	68F-13844-00 Plate 2	Buy now
28	68F-13915-00 Filter	Buy now
29	65L-1416A-00 O-ring	Buy now
30	66K-14271-00 Insulator	Buy now

Vapor Separator 1



Ref	Part	
31	65L-8182A-00 Nut	Buy now
32	65L-8182K-00 Nut	Buy now
33	65L-8182E-00 Washer	Buy now
34	65L-8182F-00 Washer	Buy now
35	68F-13843-00 Plate 1	Buy now
36	65L-14147-00 O-ring	Buy now
37	68F-14274-00 Connector	Buy now
38	66K-24376-00 Pipe, joint 1	Buy now
39	66K-24489-00 O-ring	Buy now
40	68F-14271-00 Insulator	Buy now
41	65L-14397-00 O-ring	Buy now
42	65L-14992-00 Screw, drain	Buy now
43	65L-14997-00 Seal	Buy now
44	65L-24375-00 Grommet	Buy now
45	65L-24397-00 Collar	Buy now

Vapor Separator 1




68F0010-0062

B6

Ref	Part	
46	65L-24576-00 Washer	Buy now
47	66K-24579-00 Washer 2	Buy now
48	65L-24592-00 Bolt	Buy now
49	65L-24169-00 Washer, lock	Buy now
50	68F-82507-00 Wire, lead	Buy now
51	66K-13542-00 Hose, vacuum sensing 1	Buy now
52	66K-13544-00 Hose, Vacuum Sensing 2	Buy now
53	66K-13532-00 Hose, vacuum sensing 3	Buy now
54	65L-24461-00 Pipe, joint 4	Buy now
55	66K-13533-00 Hose, vacuum sensing 4	Buy now
56	65L-13898-00 Plate 4	Buy now
57	65L-14565-00 Screw	Buy now
58	90465-11M10 Clamp	Buy now

Vapor Separator 2





68F2010-3070

C2

Ref	Part	
1	68F-13751-00 Body, throttle 1	Buy now
2	65L-14527-00 Plate	Buy now
3	65L-14565-00 Screw	Buy now
4	65L-14334-00 Spring, air adjusting	Buy now
5	65L-14523-00 Screw, stop	Buy now
6	6K5-14592-00 Screw	Buy now
7	90201-05552 Washer, plate(65j)	Buy now
8	65L-14578-00 Collar	Buy now
9	68F-13568-00 Stud	Buy now
10	61A-85885-00 Throttle sensor assembly	Buy now
11	6K7-85886-00 Bracket	Buy now
12	97985-05212 Screw, with washer(6g7)	Buy now
13	90387-05M00 Collar(6k7)	Buy now
14	90480-10M23 Grommet(6k7)	Buy now
15	65L-14596-00 Washer	Buy now

Vapor Separator 2



68F2010-3070

C2

Ref	Part	
16	97985-05330 Screw, with washer(61b)	Buy now
17	65L-14573-00 Lever	Buy now
18	65L-14579-00 Spring	Buy now
19	65L-41217-00 Rod, accel. lever	Buy now

Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.