



# Yamaha Z175GETO 2003

## Parts Manual

[www.floodmarine.co.uk](http://www.floodmarine.co.uk)

+44 2882 246 539


Authorised Yamaha Dealers



# Contents

<b>BOTTOM COWLING</b>	3
<b>BRACKET 1</b>	8
<b>BRACKET 2</b>	11
<b>CONTROL</b>	14
<b>CRANKSHAFT. PISTON</b>	17
<b>CYLINDER. CRANKCASE 1</b>	20
<b>CYLINDER. CRANKCASE 2</b>	23
<b>ELECTRICAL 1</b>	26
<b>ELECTRICAL 2</b>	29
<b>ELECTRICAL 3</b>	32
<b>ELECTRICAL 4</b>	37
<b>FUEL 1</b>	38
<b>FUEL 2</b>	42
<b>FUEL INJECTION NOZZLE</b>	43
<b>FUEL INJECTION PUMP</b>	45
<b>FUEL PUMP DRIVE GEAR</b>	49
<b>GENERATOR</b>	51
<b>INTAKE</b>	53
<b>LOWER CASING. DRIVE 1</b>	55
<b>LOWER CASING. DRIVE 2</b>	62
<b>LOWER CASING. DRIVE 3</b>	65
<b>LOWER CASING. DRIVE 4</b>	72
<b>METER</b>	74
<b>OIL PUMP</b>	76
<b>OIL TANK</b>	80
<b>POWER TRIM &amp; TILT ASSY 1</b>	83
<b>POWER TRIM &amp; TILT ASSY 2</b>	86
<b>REMOTE CONTROL BOX</b>	89
<b>REPAIR KIT 1</b>	90
<b>REPAIR KIT 2</b>	92
<b>STARTING MOTOR</b>	94
<b>STEERING GUIDE ATTACHMENT 1</b>	97
<b>STEERING GUIDE ATTACHMENT 2</b>	98
<b>SWITCH. PANEL</b>	99
<b>TOP COWLING</b>	101
<b>UPPER CASING</b>	103
<b>VAPOR SEPARATOR 1</b>	106
<b>VAPOR SEPARATOR 2</b>	110


## Bottom Cowling



F5

Ref	Part	
1	<a href="#">68F-42710-00-8D</a> Bottom Cowling assembly	<a href="#">Buy now</a>
2	<a href="#">61A-42727-00</a> Grommet	<a href="#">Buy now</a>
3	<a href="#">68F-42828-00-94</a> Plate, clamp	<a href="#">Buy now</a>
4	<a href="#">68F-42828-10-94</a> Plate, clamp	<a href="#">Buy now</a>
5	<a href="#">90109-06M82</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">68F-42815-00-8D</a> Lever, clamp	<a href="#">Buy now</a>
7	<a href="#">68F-42816-00-8D</a> Lever, clamp	<a href="#">Buy now</a>
8	<a href="#">68F-42817-00-8D</a> Lever, clamp	<a href="#">Buy now</a>
9	<a href="#">68F-42818-00</a> Lever, clamp	<a href="#">Buy now</a>
10	<a href="#">67F-42818-00</a> Lever, clamp	<a href="#">Buy now</a>
11	<a href="#">90386-15M73</a> Bush(6l2)	<a href="#">Buy now</a>
12	<a href="#">90206-15M18</a> Washer, wave(6l2)	<a href="#">Buy now</a>
13	<a href="#">90201-06068</a> Washer,plate (6k8)	<a href="#">Buy now</a>
14	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
15	<a href="#">64D-43144-00</a> Hook, spring	<a href="#">Buy now</a>


# Bottom Cowling



**F5**

Ref	Part	
16	<a href="#">90109-06M80</a> Bolt	<a href="#">Buy now</a>
17	<a href="#">90506-16M34</a> Spring, tension(64d)	<a href="#">Buy now</a>
18	<a href="#">68F-42615-00</a> Seal	<a href="#">Buy now</a>
19	<a href="#">6E5-44391-00</a> Nipple, hose	<a href="#">Buy now</a>
20	<a href="#">68F-42725-01</a> Grommet	<a href="#">Buy now</a>
21	<a href="#">68F-42738-00-5B</a> Plate, fitting	<a href="#">Buy now</a>
22	<a href="#">90109-06M86</a> Bolt	<a href="#">Buy now</a>
23	<a href="#">64D-42738-10-5B</a> Plate, fitting	<a href="#">Buy now</a>
25	<a href="#">90480-22M81</a> Grommet	<a href="#">Buy now</a>
26	<a href="#">90387-08M37</a> Coller (6e5)	<a href="#">Buy now</a>
27	<a href="#">90201-08M54</a> Washer, plate (6e5)	<a href="#">Buy now</a>
28	<a href="#">97075-08035</a> Bolt(70w)	<a href="#">Buy now</a>
29	<a href="#">90119-08M22</a> Bolt, with washer	<a href="#">Buy now</a>
30	<a href="#">688-42726-10</a> Grommet	<a href="#">Buy now</a>
31	<a href="#">6E5-82588-00</a> Plate	<a href="#">Buy now</a>


## Bottom Cowling



F5

Ref	Part	
32	<a href="#">95895-06020</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
33	<a href="#">68F-42723-00-94</a> Cover, bottom	<a href="#">Buy now</a>
34	<a href="#">68F-42721-00</a> Gasket 1	<a href="#">Buy now</a>
36	<a href="#">68F-42769-00</a> Seal Rubber	<a href="#">Buy now</a>
37	<a href="#">68F-42741-00-4D</a> Apron L	<a href="#">Buy now</a>
37	<a href="#">68F-42741-10-4D</a> Apron X	<a href="#">Buy now</a>
39	<a href="#">90387-06M43</a> Coller (6e9)	<a href="#">Buy now</a>
40	<a href="#">90480-13M24</a> Grommet (6e9)	<a href="#">Buy now</a>
41	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
42	<a href="#">90159-06M03</a> Screw (6g5)	<a href="#">Buy now</a>
43	<a href="#">95895-06016</a> Bolt, flange deep recess	<a href="#">Buy now</a>
44	<a href="#">68F-42771-00</a> Apron	<a href="#">Buy now</a>
45	<a href="#">61A-42717-00</a> Rubber, seal 2	<a href="#">Buy now</a>
47	<a href="#">68F-42722-00</a> Gasket 2	<a href="#">Buy now</a>
48	<a href="#">68F-12577-00</a> Hose 2 L	<a href="#">Buy now</a>


# Bottom Cowling



**F5**

Ref	Part	
48	<a href="#">68F-12577-10</a> Hose 2 X	<a href="#">Buy now</a>
49	<a href="#">68F-12582-01</a> Joint, hose 2 L	<a href="#">Buy now</a>
49	<a href="#">68F-12582-10</a> Joint, hose 2 X	<a href="#">Buy now</a>
50	<a href="#">68F-42718-00</a> Rubber, seal 3	<a href="#">Buy now</a>
51	<a href="#">68F-42753-00</a> Fastner	<a href="#">Buy now</a>
52	<a href="#">90464-20258</a> Clamp	<a href="#">Buy now</a>
53	<a href="#">6E5-42716-10</a> Rubber seal 1	<a href="#">Buy now</a>
54	<a href="#">90169-05M00</a> Screw truss head tapping	<a href="#">Buy now</a>
55	<a href="#">6R3Y125J70</a> Flushing kit	<a href="#">Buy now</a>
56	<a href="#">6R31257200</a> Adapter	<a href="#">Buy now</a>
57	<a href="#">6R31258000</a> Joint assembly	<a href="#">Buy now</a>
58	<a href="#">9044511M35</a> Hose (I700)	<a href="#">Buy now</a>
59	<a href="#">9046511M10</a> Clamp	<a href="#">Buy now</a>
61	<a href="#">68F-2415E-60</a> Label Caution	<a href="#">Buy now</a>
62	<a href="#">68F-42791-01</a> Mark 1	<a href="#">Buy now</a>


## Bottom Cowling



**F5**


Ref	Part	
62	<a href="#">68H-42791-01</a> Mark 1	<a href="#">Buy now</a>
63	<a href="#">6A1-28176-00</a> Label Caution	<a href="#">Buy now</a>
64	<a href="#">6E3-8257H-00</a> Plate Mark	<a href="#">Buy now</a>

# Bracket 1




Ref	Part	
1	<a href="#">64E-43111-02-8D</a> Bracket, clamp	<a href="#">Buy now</a>
2	<a href="#">6G5-45251-02</a> Anode	<a href="#">Buy now</a>
3	<a href="#">6G5-44526-00</a> Plate	<a href="#">Buy now</a>
4	<a href="#">97095-06030</a> Bolt(jf7)	<a href="#">Buy now</a>
5	<a href="#">92995-06100</a> Washer(6a1)	<a href="#">Buy now</a>
6	<a href="#">6E5-82148-00</a> Wire, lead 5	<a href="#">Buy now</a>
7	<a href="#">97095-06010</a> Bolt	<a href="#">Buy now</a>
8	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">64E-43112-02-8D</a> Bracket, clamp	<a href="#">Buy now</a>
11	<a href="#">97880-06012</a> Screw, pan head(62j)	<a href="#">Buy now</a>
12	<a href="#">92990-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
13	<a href="#">93700-06M03</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
14	<a href="#">663-45119-00</a> Cap, grease nipple AP	<a href="#">Buy now</a>
15	<a href="#">64E-43131-01</a> Bolt, clamp bracket	<a href="#">Buy now</a>
16	<a href="#">97095-08020</a> Bolt, hexagon	<a href="#">Buy now</a>

# Bracket 1




# Bracket 1



Ref	Part	
33	<a href="#">90249-06M19</a> Pin(6e5)	<a href="#">Buy now</a>
34	<a href="#">90387-10M05</a> Collar(6e5)	<a href="#">Buy now</a>
35	<a href="#">91690-30020</a> Pin, spring (6h4)	<a href="#">Buy now</a>
36	<a href="#">90506-14M24</a> Spring, tension(6e5)	<a href="#">Buy now</a>
37	<a href="#">64E-43126-00</a> Pin, upper shock mount	<a href="#">Buy now</a>
38	<a href="#">90386-22M98</a> Bush(61u)	<a href="#">Buy now</a>
39	<a href="#">93410-22M11</a> Circlip(61u)	<a href="#">Buy now</a>
40	<a href="#">90101-12M03</a> Bolt (l:115mm)	<a href="#">Buy now</a>
40	<a href="#">90101-12M05</a> Bolt (l:130mm)	<a href="#">Buy now</a>
41	<a href="#">90201-13M01</a> Washer, plate(6e5)	<a href="#">Buy now</a>
42	<a href="#">90201-12M05</a> Washe, plate(663)	<a href="#">Buy now</a>
43	<a href="#">95380-12600</a> Nut (707)	<a href="#">Buy now</a>

A6


## Bracket 2



**B1**

Ref	Part	
1	<a href="#">64E-43139-02</a> Cam, trim sender (with screw)	<a href="#">Buy now</a>
2	<a href="#">97780-60525</a> Screw, tapping(65j)	<a href="#">Buy now</a>
3	<a href="#">64E-83672-02</a> Trim sender	<a href="#">Buy now</a>
4	<a href="#">97885-06016</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
5	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">93210-37MH7</a> O-ring(61u)	<a href="#">Buy now</a>
7	<a href="#">90202-40M47</a> Washer, plate(61a)	<a href="#">Buy now</a>
8	<a href="#">61A-43376-00</a> Bolt, thrust receiver	<a href="#">Buy now</a>
9	<a href="#">95780-10300</a> Nut, nylon (6e5)	<a href="#">Buy now</a>
10	<a href="#">68F-42510-A0-8D</a> Steering bracket assembly L	<a href="#">Buy now</a>
10	<a href="#">68F-42510-B0-8D</a> Steering bracket assembly X	<a href="#">Buy now</a>
11	<a href="#">90201-38M60</a> Washer, plate (6e5)	<a href="#">Buy now</a>
12	<a href="#">90386-38M32</a> Bush(6e5)	<a href="#">Buy now</a>
13	<a href="#">68F-44551-00-8D</a> Housing, lower mount rubber	<a href="#">Buy now</a>
14	<a href="#">93410-37M04</a> Circlip (6e5)	<a href="#">Buy now</a>


## Bracket 2



**B1**

Ref	Part	
15	<a href="#">6E5-44575-00</a> Damper, lower mount rubber	<a href="#">Buy now</a>
16	<a href="#">6G5-44555-00-94</a> Mount damper, lower side	<a href="#">Buy now</a>
17	<a href="#">90202-32M19</a> Washer, plate (6e5)	<a href="#">Buy now</a>
18	<a href="#">90201-16M55</a> Washer, plate (6e5)	<a href="#">Buy now</a>
19	<a href="#">6E5-82149-00</a> Wire, lead 3	<a href="#">Buy now</a>
20	<a href="#">90109-14MA5</a> Bolt	<a href="#">Buy now</a>
21	<a href="#">90201-15M58</a> Washer, plate (6e5)	<a href="#">Buy now</a>
22	<a href="#">90185-14M00</a> Nut, self-locking(61a)	<a href="#">Buy now</a>
23	<a href="#">92995-14600</a> Washer (6e5)	<a href="#">Buy now</a>
24	<a href="#">68F-44552-00-8D</a> Housing, lower mount rubber	<a href="#">Buy now</a>
25	<a href="#">97095-10045</a> Bolt(64d)	<a href="#">Buy now</a>
26	<a href="#">92995-10100</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
27	<a href="#">68F-44553-00-4D</a> Cover, lower mount	<a href="#">Buy now</a>
28	<a href="#">93210-41042</a> O-ring (132)	<a href="#">Buy now</a>
29	<a href="#">68F-44556-00-4D</a> Cover, lower mount 2	<a href="#">Buy now</a>


## Bracket 2



**B1**

Ref	Part	
31	<a href="#">90119-06MA8</a> Bolt, with washer	<a href="#">Buy now</a>
32	<a href="#">6G5-44514-00-94</a> Mount damper, upper side	<a href="#">Buy now</a>
33	<a href="#">90201-26M57</a> Washer, plate (6e5)	<a href="#">Buy now</a>
34	<a href="#">90202-26M18</a> Washer, plate (6e5)	<a href="#">Buy now</a>
35	<a href="#">90201-14M56</a> Washer, plate (6e5)	<a href="#">Buy now</a>
36	<a href="#">90109-12M37</a> Bolt	<a href="#">Buy now</a>
37	<a href="#">90185-12M12</a> Nut, self-locking(6e5)	<a href="#">Buy now</a>
38	<a href="#">663-44575-00</a> Damper, lower mount rubber	<a href="#">Buy now</a>
39	<a href="#">6E5-44511-00-5B</a> Cover, upper mount	<a href="#">Buy now</a>


## Control



68F2100-3220


A4

Ref	Part	
1	<a href="#">68F-48531-00</a> Bracket, Remote Control 1	<a href="#">Buy now</a>
2	<a href="#">663-48538-00</a> Clamp, cable 1	<a href="#">Buy now</a>
3	<a href="#">91690-30010</a> Pin, spring (663)	<a href="#">Buy now</a>
4	<a href="#">90109-06M80</a> Bolt	<a href="#">Buy now</a>
5	<a href="#">68F-44117-01-1S</a> Bracket	<a href="#">Buy now</a>
6	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
7	<a href="#">97013-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
8	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
9	<a href="#">68F-44121-00</a> Lever, shift rod	<a href="#">Buy now</a>
10	<a href="#">68F-44122-01</a> Bushing, Shift Rod Lever	<a href="#">Buy now</a>
11	<a href="#">90202-08M20</a> Washer, plate (6e5)	<a href="#">Buy now</a>
12	<a href="#">90468-18008</a> Clip 620436610000	<a href="#">Buy now</a>
13	<a href="#">6E5-48344-00</a> Cable end, remote control	<a href="#">Buy now</a>
14	<a href="#">90386-06M12</a> Bushing (688)	<a href="#">Buy now</a>
15	<a href="#">6E5-44118-01-1S</a> Bracket 2	<a href="#">Buy now</a>



A4


Ref	Part	
16	<a href="#">97013-08030</a> Bolt	<a href="#">Buy now</a>
17	<a href="#">92903-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
18	<a href="#">93501-04M02</a> Ball (697)	<a href="#">Buy now</a>
19	<a href="#">90501-12082</a> Spring 6484411600	<a href="#">Buy now</a>
20	<a href="#">648-42715-00</a> Bushing 2	<a href="#">Buy now</a>
21	<a href="#">93700-06M03</a> Nipple, grease(6a1)	<a href="#">Buy now</a>
22	<a href="#">6E5-44120-03</a> Handle gear shift assembly L	<a href="#">Buy now</a>
22	<a href="#">6E5-44120-23</a> Handle gear shift assembly X	<a href="#">Buy now</a>
23	<a href="#">93210-09165</a> O-ring	<a href="#">Buy now</a>
24	<a href="#">90386-16M66</a> Bush(6e5)	<a href="#">Buy now</a>
25	<a href="#">90202-16061</a> Washer, plate(663)	<a href="#">Buy now</a>
26	<a href="#">93410-16006</a> Circlip	<a href="#">Buy now</a>
27	<a href="#">67H-41632-00</a> Lever, magneto control	<a href="#">Buy now</a>
30	<a href="#">90119-06MA4</a> Bolt, with washer	<a href="#">Buy now</a>
31	<a href="#">90201-06M31</a> Washer (6a0)	<a href="#">Buy now</a>



A4


Ref	Part	
32	<a href="#">90206-10M04</a> Washer, wave (676)	<a href="#">Buy now</a>
33	<a href="#">90387-06M29</a> Coller (6a0)	<a href="#">Buy now</a>
34	<a href="#">61A-41237-00</a> Joint, link	<a href="#">Buy now</a>
35	<a href="#">95380-05600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
36	<a href="#">682-41237-00</a> Joint, link 2	<a href="#">Buy now</a>
37	<a href="#">68F-41213-00</a> Cam, accel.	<a href="#">Buy now</a>
42	<a href="#">68F-42744-00</a> Stay	<a href="#">Buy now</a>
43	<a href="#">90157-06M11</a> Screw, pan head(697)	<a href="#">Buy now</a>
44	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
45	<a href="#">688-44194-00</a> Cap	<a href="#">Buy now</a>
46	<a href="#">68F-8259F-00</a> Switch assembly	<a href="#">Buy now</a>
47	<a href="#">61A-82588-01</a> Plate	<a href="#">Buy now</a>
48	<a href="#">97885-04016</a> Screw, panhead (796)	<a href="#">Buy now</a>
49	<a href="#">92995-04100</a> Ybs67-4 washer, spring	<a href="#">Buy now</a>

# Crankshaft. Piston




Ref	Part	
1	<a href="#">68F-11411-01</a> Crankshaft	<a href="#">Buy now</a>
2	<a href="#">6E5-11447-00</a> Seal, ring	<a href="#">Buy now</a>
3	<a href="#">68F-15163-00-94</a> Housing, bearing 1	<a href="#">Buy now</a>
4	<a href="#">93311-940U3</a> Brg,cyl-cal roller 36g (6e5)	<a href="#">Buy now</a>
5	<a href="#">93102-40M14</a> Oil seal(61a)	<a href="#">Buy now</a>
6	<a href="#">93211-04001</a> O-ring	<a href="#">Buy now</a>
7	<a href="#">90119-06MA3</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">93310-954U1</a> Bearing, cylindrical(64c)	<a href="#">Buy now</a>
9	<a href="#">6R3-11536-00</a> Gear, drive	<a href="#">Buy now</a>
10	<a href="#">93306-208U0</a> Brg,r-b 6208 80mm 345g (6e5)	<a href="#">Buy now</a>
11	<a href="#">93410-40M03</a> Circlip(n02)	<a href="#">Buy now</a>
12	<a href="#">6G5-15359-00-94</a> Housing, oil seal	<a href="#">Buy now</a>
13	<a href="#">93102-35M61</a> Oil seal	<a href="#">Buy now</a>
14	<a href="#">93101-22M15</a> Oil seal (6e5)	<a href="#">Buy now</a>
15	<a href="#">93210-74M35</a> O-ring (6e5)	<a href="#">Buy now</a>

# Crankshaft. Piston



Ref	Part	
16	<a href="#">90119-06MA2</a> Bolt, with washer	<a href="#">Buy now</a>
17	<a href="#">68F-11631-01-85</a> Piston (std)	<a href="#">Buy now</a>
17	<a href="#">68F-11635-01</a> Piston (0.25mm o/s) AP	<a href="#">Buy now</a>
17	<a href="#">68F-11636-01</a> Piston (0.50mm o/s) AP	<a href="#">Buy now</a>
18	<a href="#">68F-11603-01</a> Piston ring set (std)	<a href="#">Buy now</a>
18	<a href="#">68F-11604-01</a> Piston ring set (0.25mm o/s) AP	<a href="#">Buy now</a>
18	<a href="#">68F-11605-01</a> Piston ring set (0.50mm o/s) AP	<a href="#">Buy now</a>
19	<a href="#">68F-11642-01-85</a> Piston 2 (std)	<a href="#">Buy now</a>
19	<a href="#">68F-11645-01</a> Piston 2 (0.25mm o/s) AP	<a href="#">Buy now</a>
19	<a href="#">68F-11646-01</a> Piston 2 (0.50mm o/s) AP	<a href="#">Buy now</a>
21	<a href="#">6R5-11633-10</a> Pin, piston	<a href="#">Buy now</a>
22	<a href="#">6R5-11634-10</a> Clip, piston pin	<a href="#">Buy now</a>
23	<a href="#">68L-11650-00</a> Connecting rod assembly	<a href="#">Buy now</a>
23	<a href="#">6R5-11650-10</a> Connecting kit	<a href="#">Buy now</a>
24	<a href="#">90109-08022</a> Bolt	<a href="#">Buy now</a>


## Crankshaft. Piston



Ref	Part	
25	<a href="#">93310-323V6</a> Bearing	<a href="#">Buy now</a>
26	<a href="#">90201-23M01</a> Washer, plate(6g6)	<a href="#">Buy now</a>
27	<a href="#">93310-836U0</a> Bearing, cylindrical(61u)	<a href="#">Buy now</a>

**B1**

# Cylinder. Crankcase 1




68F2100-3020

A6

Ref	Part	
3	<a href="#">6E5-11372-01</a> Nipple, hose	<a href="#">Buy now</a>
4	<a href="#">624-14485-00</a> Pipe, joint	<a href="#">Buy now</a>
5	<a href="#">68F-11372-01</a> Nipple, hose	<a href="#">Buy now</a>
6	<a href="#">650-11370-01</a> Check valve assembly	<a href="#">Buy now</a>
7	<a href="#">68F-13552-00</a> Nozzle	<a href="#">Buy now</a>
8	<a href="#">90384-06M07</a> Bush, bimetal formed(6r3)	<a href="#">Buy now</a>
9	<a href="#">90384-14M09</a> Bush, bimetal formed(6r3)	<a href="#">Buy now</a>
10	<a href="#">663-11518-01</a> Lock, bearing	<a href="#">Buy now</a>
11	<a href="#">646-11370-01</a> Check valve assembly	<a href="#">Buy now</a>
12	<a href="#">90340-14M00</a> Plug, straight screw(62y)	<a href="#">Buy now</a>
13	<a href="#">90430-14115</a> Gasket (663)	<a href="#">Buy now</a>
14	<a href="#">93608-12063</a> Pin, dowel (626)	<a href="#">Buy now</a>
15	<a href="#">90105-10M20</a> Bolt (6e5)	<a href="#">Buy now</a>
16	<a href="#">90119-08M94</a> Bolt, with washer	<a href="#">Buy now</a>
17	<a href="#">90116-08M45</a> Bolt, stud (6e5)	<a href="#">Buy now</a>

# Cylinder. Crankcase 1




A6

Ref	Part	
18	<a href="#">6E5-11325-00</a> Anode	<a href="#">Buy now</a>
19	<a href="#">98780-04015</a> Screw, flat head(ga5)	<a href="#">Buy now</a>
21	<a href="#">68F-11381-00</a> Gasket 1	<a href="#">Buy now</a>
22	<a href="#">90119-06MA2</a> Bolt, with washer	<a href="#">Buy now</a>
24	<a href="#">6E5-42762-00-1S</a> Stopper	<a href="#">Buy now</a>
25	<a href="#">68F-44533-00</a> Damper, upper mount rubber	<a href="#">Buy now</a>
27	<a href="#">90445-07M03</a> Hose (I200)	<a href="#">Buy now</a>
28	<a href="#">90445-07M10</a> Hose (L770)	<a href="#">Buy now</a>
29	<a href="#">90445-07MA6</a> Hose (I200)	<a href="#">Buy now</a>
30	<a href="#">90445-07MA4</a> Hose (I390)	<a href="#">Buy now</a>
31	<a href="#">90445-07M45</a> Hose (I390)	<a href="#">Buy now</a>
32	<a href="#">90445-07M27</a> Hose (I390)	<a href="#">Buy now</a>
33	<a href="#">90464-07M20</a> Clamp(6h0)	<a href="#">Buy now</a>
34	<a href="#">68F-13782-00</a> Stay	<a href="#">Buy now</a>
35	<a href="#">90387-08M31</a> Collar	<a href="#">Buy now</a>

# Cylinder. Crankcase 1


Ref	Part	
36	<a href="#">90110-08M04</a> Bolt, hexagon socket head	<a href="#">Buy now</a>



68F2100-3020

A6


## Cylinder. Crankcase 2



**B3**

Ref	Part	
1	<a href="#">68F-11111-00-94</a> Head, cylinder 1	<a href="#">Buy now</a>
2	<a href="#">6E5-11325-00</a> Anode	<a href="#">Buy now</a>
3	<a href="#">98780-04015</a> Screw, flat head(ga5)	<a href="#">Buy now</a>
4	<a href="#">68F-11121-00-94</a> Head, cylinder 2	<a href="#">Buy now</a>
7	<a href="#">68F-11181-00</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
8	<a href="#">90119-08MA8</a> Bolt, with washer	<a href="#">Buy now</a>
9	<a href="#">68F-11119-00</a> Hanger, engine	<a href="#">Buy now</a>
10	<a href="#">90119-06MA2</a> Bolt, with washer	<a href="#">Buy now</a>
11	<a href="#">68F-11191-00-1S</a> Cover, cylinder head 1	<a href="#">Buy now</a>
12	<a href="#">68F-11192-00-1S</a> Cover, cylinder head 2	<a href="#">Buy now</a>
13	<a href="#">68F-11193-01</a> Gasket, head cover 1	<a href="#">Buy now</a>
14	<a href="#">90119-06MA4</a> Bolt, with washer	<a href="#">Buy now</a>
15	<a href="#">99590-10114</a> Pin, dowel	<a href="#">Buy now</a>
16	<a href="#">6E5-12411-30</a> Thermostat	<a href="#">Buy now</a>
17	<a href="#">688-12413-00-1S</a> Cover, thermostat	<a href="#">Buy now</a>


## Cylinder. Crankcase 2



**B3**

Ref	Part	
18	<a href="#">688-12414-A1</a> Gasket, cover	<a href="#">Buy now</a>
19	<a href="#">90119-06MA6</a> Bolt, with washer	<a href="#">Buy now</a>
20	<a href="#">62Y-11325-00</a> Anode	<a href="#">Buy now</a>
21	<a href="#">66M-11328-00</a> Grommet, anode	<a href="#">Buy now</a>
22	<a href="#">66M-11327-00-94</a> Cover, anode	<a href="#">Buy now</a>
23	<a href="#">66M-12535-00</a> Plate	<a href="#">Buy now</a>
24	<a href="#">97095-05012</a> Bolt, hexagon	<a href="#">Buy now</a>
25	<a href="#">92995-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
27	<a href="#">68F-41114-00</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
28	<a href="#">68F-41113-00-1S</a> 4-	<a href="#">Buy now</a>
29	<a href="#">650-24378-00</a> Pipe, joint 2	<a href="#">Buy now</a>
31	<a href="#">90445-09M25</a> Hose (I1500)	<a href="#">Buy now</a>
32	<a href="#">90467-08M18</a> Clip	<a href="#">Buy now</a>
33	<a href="#">6G5-12416-00</a> Valve, pressure control	<a href="#">Buy now</a>
34	<a href="#">90501-16M11</a> Spring, compression (688)	<a href="#">Buy now</a>


## Cylinder. Crankcase 2



**B3**


Ref	Part	
35	<a href="#">90480-20M05</a> Grommet (688)	<a href="#">Buy now</a>
36	<a href="#">6G5-11382-A1</a> Gasket 2	<a href="#">Buy now</a>
37	<a href="#">6G5-11372-00-1S</a> Cover, bypass 2	<a href="#">Buy now</a>
39	<a href="#">68F-12576-00</a> Hose 1	<a href="#">Buy now</a>
40	<a href="#">90467-23M16</a> Clip	<a href="#">Buy now</a>
41	<a href="#">94702-00404</a> Plug, spark (bkr7eku)	<a href="#">Buy now</a>
41	<a href="#">94702-00405</a> Plug, spark (bkr6eku)	<a href="#">Buy now</a>

# Electrical 1



Ref	Part	
1	<a href="#">68F-85542-00-94</a> Bracket	<a href="#">Buy now</a>
2	<a href="#">68F-85516-01</a> Spacer	<a href="#">Buy now</a>
3	<a href="#">68F-86129-00</a> Collar	<a href="#">Buy now</a>
4	<a href="#">68F-86129-10</a> Collar	<a href="#">Buy now</a>
5	<a href="#">68F-85119-00</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">68F-8591A-20</a> Engine Control Unit assembly X	<a href="#">Buy now</a>
6	<a href="#">68F-8591A-30</a> Engine Control Unit assembly L	<a href="#">Buy now</a>
6	<a href="#">68H-8591A-10</a> Engine control unit assembly X	<a href="#">Buy now</a>
6	<a href="#">68J-8591A-10</a> Engine Control Unit assembly L	<a href="#">Buy now</a>
6	<a href="#">68L-8591A-10</a> 16 – X	<a href="#">Buy now</a>
7	<a href="#">90119-06MA3</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">68F-85548-01</a> Holder	<a href="#">Buy now</a>
9	<a href="#">97013-06014</a> Bolt(gj3)	<a href="#">Buy now</a>
10	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">68F-85142-00-94</a> Bracket, Reflector 2	<a href="#">Buy now</a>


# Electrical 1



E2

Ref	Part	
16	<a href="#">68F-85599-00</a> Cover	<a href="#">Buy now</a>
17	<a href="#">97013-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
19	<a href="#">68F-85644-00</a> Plate	<a href="#">Buy now</a>
22	<a href="#">68F-8591B-00</a> Driver, injector assembly	<a href="#">Buy now</a>
23	<a href="#">90119-06MA2</a> Bolt, with washer	<a href="#">Buy now</a>
24	<a href="#">6G0-82519-00</a> Wire, earth lead	<a href="#">Buy now</a>
25	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
26	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
29	<a href="#">68F-82310-01</a> Ignition coil assembly	<a href="#">Buy now</a>
30	<a href="#">90480-22M15</a> Grommet (6e5)	<a href="#">Buy now</a>
31	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
32	<a href="#">68F-82310-11</a> Ignition coil assembly	<a href="#">Buy now</a>
33	<a href="#">97013-05020</a> Bolt, hexagon	<a href="#">Buy now</a>
34	<a href="#">92903-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
35	<a href="#">68F-82370-01</a> Plug cap assembly	<a href="#">Buy now</a>


## Electrical 1



Ref	Part	
36	<a href="#">68F-8252U-00</a> Cover	<a href="#">Buy now</a>
37	<a href="#">68F-8252U-10</a> Cover	<a href="#">Buy now</a>

E2


## Electrical 2



E4

Ref	Part	
1	<a href="#">6H2-81949-11</a> Wire, lead	<a href="#">Buy now</a>
2	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
3	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
4	<a href="#">68F-82105-00</a> Battery cable	<a href="#">Buy now</a>
5	<a href="#">97095-08016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
6	<a href="#">92995-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
7	<a href="#">95333-08600</a> Nut(6l2)	<a href="#">Buy now</a>
8	<a href="#">92903-08100</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
9	<a href="#">6E5-82588-00</a> Plate	<a href="#">Buy now</a>
10	<a href="#">95895-06020</a> Bolt, flange(jk3)	<a href="#">Buy now</a>
11	<a href="#">6E5-82531-10</a> Wire, lead	<a href="#">Buy now</a>
12	<a href="#">688-82594-00</a> Clamp	<a href="#">Buy now</a>
13	<a href="#">68F-82590-10</a> Wire Harness assembly	<a href="#">Buy now</a>
14	<a href="#">90465-11M52</a> Clamp(6e7)	<a href="#">Buy now</a>
15	<a href="#">90446-24MF6</a> Hose	<a href="#">Buy now</a>


## Electrical 2



E4

Ref	Part	
16	<a href="#">90446-24MF7</a> Hose	<a href="#">Buy now</a>
17	<a href="#">90446-34MF8</a> Hose	<a href="#">Buy now</a>
18	<a href="#">90465-08M89</a> Clamp	<a href="#">Buy now</a>
19	<a href="#">68F-8259M-00</a> Wire Harness assembly 2	<a href="#">Buy now</a>
20	<a href="#">68F-8259N-00</a> Wire Harness assembly 3	<a href="#">Buy now</a>
21	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
23	<a href="#">61A-85790-00</a> Thermosensor assembly	<a href="#">Buy now</a>
24	<a href="#">92990-10600</a> Washer, plate	<a href="#">Buy now</a>
25	<a href="#">90465-12M93</a> Clamp	<a href="#">Buy now</a>
27	<a href="#">92995-06100</a> Washer(6a1)	<a href="#">Buy now</a>
28	<a href="#">6R3-82563-00</a> Trim & tilt switch assembly	<a href="#">Buy now</a>
29	<a href="#">6E5-82587-00</a> Gasket	<a href="#">Buy now</a>
30	<a href="#">6R3-83614-00</a> Bracket	<a href="#">Buy now</a>
31	<a href="#">90109-06M80</a> Bolt	<a href="#">Buy now</a>
32	<a href="#">67H-82380-00</a> Sensor, pressure	<a href="#">Buy now</a>


## Electrical 2



Ref	Part	
33	<a href="#">98580-06520</a> Screw pan head	<a href="#">Buy now</a>
34	<a href="#">97095-06014</a> Bolt(gj3)	<a href="#">Buy now</a>
36	<a href="#">6K7-82588-00</a> Plate	<a href="#">Buy now</a>

E4


## Electrical 3



**E6**


Ref	Part	
1	<a href="#">68F-81948-00</a> Bracket	<a href="#">Buy now</a>
2	<a href="#">68F-82535-00</a> Grommet	<a href="#">Buy now</a>
3	<a href="#">90465-12M56</a> Clamp(62t)	<a href="#">Buy now</a>
4	<a href="#">624-42542-00</a> Collar	<a href="#">Buy now</a>
5	<a href="#">90387-06M91</a> Collar	<a href="#">Buy now</a>
6	<a href="#">6A0-82317-00</a> Damper, ignition coil	<a href="#">Buy now</a>
7	<a href="#">90119-06M65</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
9	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
10	<a href="#">68F-81949-20</a> Wire, lead	<a href="#">Buy now</a>
13	<a href="#">61A-87149-00</a> Connector	<a href="#">Buy now</a>
14	<a href="#">68F-81950-01</a> Relay assembly	<a href="#">Buy now</a>
15	<a href="#">682-82119-01</a> Cover, lead wire	<a href="#">Buy now</a>
16	<a href="#">97095-06010</a> Bolt	<a href="#">Buy now</a>
17	<a href="#">92995-06100</a> Washer(6a1)	<a href="#">Buy now</a>

## Electrical 3



**E6**


Ref	Part	
19	<a href="#">90119-06MA4</a> Bolt, with washer	<a href="#">Buy now</a>
20	<a href="#">90464-18M46</a> Clamp(65j)	<a href="#">Buy now</a>
21	<a href="#">90464-23199</a> Clamp(4hm)	<a href="#">Buy now</a>
23	<a href="#">61A-8194A-00</a> Relay	<a href="#">Buy now</a>
24	<a href="#">95780-06300</a> Nut, nylon (6g1)	<a href="#">Buy now</a>
25	<a href="#">68F-82117-00</a> Wire, lead	<a href="#">Buy now</a>
26	<a href="#">61A-81952-00</a> Holder, relay	<a href="#">Buy now</a>
27	<a href="#">97780-50612</a> Screw, tapping(61a)	<a href="#">Buy now</a>
28	<a href="#">90464-05141</a> Clamp(7ly)	<a href="#">Buy now</a>
29	<a href="#">90465-11M52</a> Clamp(6e7)	<a href="#">Buy now</a>
30	<a href="#">68F-82170-00</a> Fuse box assembly <i>Go to P/N ) PEO-OM-070038</i>	<a href="#">Buy now</a>
31	<a href="#">68F-82151-00</a> Fuse (80A) <i>Go to P/N ) PEO-OM-070038</i>	<a href="#">Buy now</a>
32	<a href="#">68F-8195A-00</a> Relay assembly	<a href="#">Buy now</a>
33	<a href="#">67F-82151-00</a> Fuse	<a href="#">Buy now</a>
34	<a href="#">67F-82151-10</a> Fuse	<a href="#">Buy now</a>



**E6**

Ref	Part	
35	<a href="#">68F-82846-00</a> Screw, pan head (m5)	<a href="#">Buy now</a>
36	<a href="#">97780-50620</a> Screw, tapping	<a href="#">Buy now</a>
37	<a href="#">68F-85544-00</a> Case	<a href="#">Buy now</a>
38	<a href="#">67F-2812A-00</a> Puller, fuse	<a href="#">Buy now</a>
39	<a href="#">68F-82176-00</a> Damper	<a href="#">Buy now</a>
40	<a href="#">68F-8572S-00</a> Spring	<a href="#">Buy now</a>
41	<a href="#">68F-81336-00</a> Grommet	<a href="#">Buy now</a>
42	<a href="#">68F-81128-00</a> Clamp	<a href="#">Buy now</a>
43	<a href="#">97780-50616</a> Screw, pan head tapping (ak5)	<a href="#">Buy now</a>
44	<a href="#">68F-81960-01</a> Rectifier & regulator assembly	<a href="#">Buy now</a>
45	<a href="#">69J-81975-A0</a> Plate, rectifier fitting	<a href="#">Buy now</a>
46	<a href="#">69J-81972-01-1S</a> Cover, rectifier	<a href="#">Buy now</a>
47	<a href="#">90465-13M18</a> Clamp	<a href="#">Buy now</a>
48	<a href="#">90110-06M07</a> Bolt, hexagon socket head	<a href="#">Buy now</a>
50	<a href="#">90445-09097</a> Hose (l1500)	<a href="#">Buy now</a>


## Electrical 3



E6


Ref	Part	
51	<a href="#">90467-08M18</a> Clip	<a href="#">Buy now</a>
52	<a href="#">68F-81942-00</a> Cover	<a href="#">Buy now</a>
53	<a href="#">90169-05M00</a> Screw truss head tapping	<a href="#">Buy now</a>
54	<a href="#">68F-8592A-00</a> Sensor	<a href="#">Buy now</a>
55	<a href="#">65L-11395-00</a> Holder	<a href="#">Buy now</a>
56	<a href="#">90119-06M74</a> Bolt, with washer(63m)	<a href="#">Buy now</a>
58	<a href="#">65L-85832-00</a> Case, under	<a href="#">Buy now</a>
59	<a href="#">65L-11354-00</a> Gasket	<a href="#">Buy now</a>
60	<a href="#">65L-1131N-00</a> Gasket, holder	<a href="#">Buy now</a>
61	<a href="#">65L-11396-00</a> Gasket, holder	<a href="#">Buy now</a>
62	<a href="#">68F-11353-00</a> Joint	<a href="#">Buy now</a>
63	<a href="#">68F-W1135-00</a> Seal, cylinder	<a href="#">Buy now</a>
64	<a href="#">97095-06030</a> Bolt(jf7)	<a href="#">Buy now</a>
67	<a href="#">68F-81919-10</a> Graphic, Regulator	<a href="#">Buy now</a>
68	<a href="#">68F-81919-00</a> Graphic, Regulator Go to P/N ) PEO-OM-070038	<a href="#">Buy now</a>

## Electrical 3



Ref	Part	
69	<a href="#">65L-83625-50</a> Mark 5	<a href="#">Buy now</a>
70	<a href="#">68F-81949-00</a> Wire, lead AP	<a href="#">Buy now</a>

E6




68F0010-0180

F2

Ref	Part	
1	<a href="#">61A-85895-00</a> Crank position sender	<a href="#">Buy now</a>
2	<a href="#">90465-13M18</a> Clamp	<a href="#">Buy now</a>
3	<a href="#">97885-05012</a> Screw,pan head (646)	<a href="#">Buy now</a>
5	<a href="#">688-82560-10</a> Thermo switch assembly	<a href="#">Buy now</a>
6	<a href="#">65L-85886-00</a> Thermosensor	<a href="#">Buy now</a>
7	<a href="#">68F-8431R-00</a> Stay, Setting	<a href="#">Buy now</a>
8	<a href="#">90480-17M80</a> Grommet	<a href="#">Buy now</a>
9	<a href="#">90179-12M37</a> Nut	<a href="#">Buy now</a>
10	<a href="#">90201-12M08</a> Washer, Plate	<a href="#">Buy now</a>
11	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
12	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>


# Fuel 1



D5

Ref	Part	
1	<a href="#">61A-24313-00</a> Pipe 3	<a href="#">Buy now</a>
2	<a href="#">90464-13M34</a> Clamp(6r3)	<a href="#">Buy now</a>
3	<a href="#">90445-13M17</a> Hose(l2700)	<a href="#">Buy now</a>
4	<a href="#">6R3-24377-00</a> Pipe, joint 3	<a href="#">Buy now</a>
5	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
6	<a href="#">68F-24560-00</a> Filter assembly	<a href="#">Buy now</a>
7	<a href="#">68F-24562-00</a> Cup, filter	<a href="#">Buy now</a>
8	<a href="#">68F-24519-00</a> Clip	<a href="#">Buy now</a>
9	<a href="#">68F-24469-00</a> Float, Water Level	<a href="#">Buy now</a>
10	<a href="#">65L-24531-01</a> Nut	<a href="#">Buy now</a>
11	<a href="#">61A-24564-00</a> O-ring	<a href="#">Buy now</a>
12	<a href="#">68F-24563-00</a> Element, filter	<a href="#">Buy now</a>
13	<a href="#">65L-24564-00</a> Gasket	<a href="#">Buy now</a>
14	<a href="#">68F-24567-00</a> Spring	<a href="#">Buy now</a>
15	<a href="#">65L-24558-00</a> Holder, filter	<a href="#">Buy now</a>


# Fuel 1



D5

Ref	Part	
16	<a href="#">97595-06416</a> Bolt, with washer(62x)	<a href="#">Buy now</a>
17	<a href="#">90201-06068</a> Washer,plate (6k8)	<a href="#">Buy now</a>
18	<a href="#">68F-24566-00</a> Bracket, filter	<a href="#">Buy now</a>
19	<a href="#">97595-06514</a> Bolt(gj3)	<a href="#">Buy now</a>
20	<a href="#">90387-06M60</a> Collar (6h3)	<a href="#">Buy now</a>
21	<a href="#">90480-10M23</a> Grommet(6k7)	<a href="#">Buy now</a>
22	<a href="#">90119-06M88</a> Bolt, with washer	<a href="#">Buy now</a>
23	<a href="#">61A-24311-00</a> Pipe, fuel 1	<a href="#">Buy now</a>
24	<a href="#">61U-24316-00</a> Pipe 6	<a href="#">Buy now</a>
25	<a href="#">6R5-24408-00</a> Fuel feed assembly	<a href="#">Buy now</a>
27	<a href="#">6E5-24378-00</a> Pipe, joint 3	<a href="#">Buy now</a>
28	<a href="#">90445-13M31</a> Hose (L85)	<a href="#">Buy now</a>
29	<a href="#">67H-24311-00</a> Pipe, fuel 1	<a href="#">Buy now</a>
30	<a href="#">6E5-24410-03</a> Fuel pump assembly	<a href="#">Buy now</a>
31	<a href="#">6E5-24444-00</a> Screw	<a href="#">Buy now</a>


# Fuel 1



D5

Ref	Part	
32	<a href="#">6E5-24413-00</a> Body 2	<a href="#">Buy now</a>
33	<a href="#">6E5-24471-00</a> Diaphragm	<a href="#">Buy now</a>
34	<a href="#">6E5-24435-00</a> Gasket, body 2	<a href="#">Buy now</a>
35	<a href="#">6E5-24411-00</a> Diaphragm	<a href="#">Buy now</a>
36	<a href="#">648-24424-00</a> Seat,spring	<a href="#">Buy now</a>
37	<a href="#">6E5-24423-00</a> Spring, diaphragm	<a href="#">Buy now</a>
38	<a href="#">6E5-24434-02</a> Gasket, body	<a href="#">Buy now</a>
39	<a href="#">6A0-24421-01</a> Valve, check	<a href="#">Buy now</a>
40	<a href="#">6A0-14325-00</a> Screw, pan head	<a href="#">Buy now</a>
41	<a href="#">95380-03600</a> Nut (6g8)	<a href="#">Buy now</a>
42	<a href="#">6E5-24412-10</a> Body 1	<a href="#">Buy now</a>
43	<a href="#">650-24431-A0</a> Gasket,fuel pump	<a href="#">Buy now</a>
44	<a href="#">97095-06050</a> Bolt(jf7)	<a href="#">Buy now</a>
45	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
47	<a href="#">6E5-24313-00</a> Pipe 3	<a href="#">Buy now</a>

# Fuel 1




D5

Ref	Part	
50	<a href="#">6H1-83557-00</a> Tube	<a href="#">Buy now</a>
51	<a href="#">90446-15M07</a> Hose(6g4)	<a href="#">Buy now</a>
52	<a href="#">90445-13M12</a> Hose (L235)	<a href="#">Buy now</a>
53	<a href="#">97095-06012</a> Bolt(gh1)	<a href="#">Buy now</a>

## Fuel 2


Ref	Part	
1	<a href="#">6YK-24307-42</a> Fuel pipe comp. 2 AP	<a href="#">Buy now</a>
2	<a href="#">90450-10M07</a> Hose, clamp AP	<a href="#">Buy now</a>



68J1100-2140

D7


# Fuel Injection Nozzle



**C6**

Ref	Part	
1	<a href="#">68F-13767-00</a> Cap, injector	<a href="#">Buy now</a>
2	<a href="#">90119-08M60</a> Bolt (682)	<a href="#">Buy now</a>
3	<a href="#">68F-13161-00</a> Pipe, Delivery 1	<a href="#">Buy now</a>
4	<a href="#">68F-13171-00</a> Pipe, Delivery 2	<a href="#">Buy now</a>
5	<a href="#">68F-13938-00</a> Pipe	<a href="#">Buy now</a>
6	<a href="#">68F-13898-00</a> Holder	<a href="#">Buy now</a>
7	<a href="#">68F-13761-00</a> Injector assembly	<a href="#">Buy now</a>
8	<a href="#">68F-1410B-00</a> Packing kit	<a href="#">Buy now</a>
9	<a href="#">68F-13853-00</a> Plate 3	<a href="#">Buy now</a>
10	<a href="#">68F-24453-00</a> Screw	<a href="#">Buy now</a>
11	<a href="#">68F-24300-00</a> Fuel pipe joint	<a href="#">Buy now</a>
12	<a href="#">68F-13595-00</a> Joint	<a href="#">Buy now</a>
13	<a href="#">68F-24479-00</a> O-Ring	<a href="#">Buy now</a>
14	<a href="#">68F-24489-00</a> O-Ring	<a href="#">Buy now</a>
15	<a href="#">68F-13972-00</a> Pipe, Fuel 2	<a href="#">Buy now</a>


# Fuel Injection Nozzle



Ref	Part	
16	<a href="#">65L-24387-00</a> Clip	<a href="#">Buy now</a>
17	<a href="#">68F-24174-00</a> Spacer 1	<a href="#">Buy now</a>
18	<a href="#">68F-13764-00</a> Gasket (t=2.2)	<a href="#">Buy now</a>
19	<a href="#">68F-13716-00</a> Collar	<a href="#">Buy now</a>
20	<a href="#">97013-08055</a> Bolt, hexagon	<a href="#">Buy now</a>
21	<a href="#">92903-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
22	<a href="#">68F-2411J-00</a> Damper, Side Cover	<a href="#">Buy now</a>
23	<a href="#">68F-82544-00</a> Clamp	<a href="#">Buy now</a>
24	<a href="#">97013-06012</a> Bolt(gh1)	<a href="#">Buy now</a>
25	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>

C6


## Fuel Injection Pump



C3

Ref	Part	
1	<a href="#">68F-12170-01</a> Camshaft assembly 1	<a href="#">Buy now</a>
2	<a href="#">93306-00001</a> Brg,r-b 6000 26mm 19g ky	<a href="#">Buy now</a>
3	<a href="#">68F-12173-00</a> Cap, camshaft 1	<a href="#">Buy now</a>
4	<a href="#">93306-001U0</a> Bearing	<a href="#">Buy now</a>
5	<a href="#">68F-12223-00</a> Seal	<a href="#">Buy now</a>
6	<a href="#">68F-12439-00</a> O-ring	<a href="#">Buy now</a>
7	<a href="#">68F-12171-00</a> Camshaft 1	<a href="#">Buy now</a>
8	<a href="#">68F-12228-00</a> Bolt	<a href="#">Buy now</a>
9	<a href="#">68F-13455-00</a> Plug	<a href="#">Buy now</a>
10	<a href="#">68F-13473-00</a> O-ring	<a href="#">Buy now</a>
11	<a href="#">68F-24372-00</a> Joint	<a href="#">Buy now</a>
12	<a href="#">68F-24478-00</a> Joint	<a href="#">Buy now</a>
13	<a href="#">68F-13993-00</a> Cover	<a href="#">Buy now</a>
14	<a href="#">68F-24592-00</a> Bolt	<a href="#">Buy now</a>
15	<a href="#">68F-13573-00</a> Bolt 1	<a href="#">Buy now</a>

## Fuel Injection Pump




68F0010-1081

C3

Ref	Part	
16	<a href="#">68F-13574-00</a> Bolt 2	<a href="#">Buy now</a>
17	<a href="#">68F-24176-00</a> Bolt 1	<a href="#">Buy now</a>
18	<a href="#">68F-12157-00</a> Bolt	<a href="#">Buy now</a>
19	<a href="#">68F-24178-00</a> Bolt 3	<a href="#">Buy now</a>
20	<a href="#">68F-24551-00</a> Bolt, joint	<a href="#">Buy now</a>
21	<a href="#">68F-24576-00</a> Washer	<a href="#">Buy now</a>
22	<a href="#">68F-24579-00</a> Washer 2	<a href="#">Buy now</a>
23	<a href="#">688-24378-00</a> Pipe, joint	<a href="#">Buy now</a>
24	<a href="#">68F-13910-00</a> Fuel Pump assembly	<a href="#">Buy now</a>
25	<a href="#">68F-14005-00</a> Ring, seal	<a href="#">Buy now</a>
26	<a href="#">68F-14126-00</a> Gasket	<a href="#">Buy now</a>
27	<a href="#">68F-13942-00</a> Valve, Outlet	<a href="#">Buy now</a>
28	<a href="#">68F-24470-00</a> Fuel Regulator assembly	<a href="#">Buy now</a>
29	<a href="#">68F-12443-00</a> Stay	<a href="#">Buy now</a>
30	<a href="#">68F-82380-01</a> Sensor, pressure	<a href="#">Buy now</a>


## Fuel Injection Pump



C3

Ref	Part	
31	<a href="#">68F-82384-00</a> Packing kit	<a href="#">Buy now</a>
32	<a href="#">68F-82388-00</a> Plate	<a href="#">Buy now</a>
33	<a href="#">68F-24638-00</a> 8-	<a href="#">Buy now</a>
34	<a href="#">68F-24312-00</a> Pipe 2	<a href="#">Buy now</a>
35	<a href="#">68F-24356-00</a> Clip, pipe 1	<a href="#">Buy now</a>
36	<a href="#">68F-24313-00</a> Pipe 3	<a href="#">Buy now</a>
38	<a href="#">68F-24314-00</a> Pipe 4	<a href="#">Buy now</a>
40	<a href="#">68F-13758-00</a> Pipe, Joint	<a href="#">Buy now</a>
41	<a href="#">68F-24486-00</a> O-ring	<a href="#">Buy now</a>
42	<a href="#">68F-13815-00</a> Joint 1	<a href="#">Buy now</a>
43	<a href="#">68F-2466A-00</a> Packing kit	<a href="#">Buy now</a>
44	<a href="#">68F-13973-00</a> Pipe Fuel 3	<a href="#">Buy now</a>
46	<a href="#">68F-13974-00</a> Pipe Fuel 4	<a href="#">Buy now</a>
48	<a href="#">68F-24474-00</a> Cover	<a href="#">Buy now</a>
50	<a href="#">68F-13816-00</a> Joint 2	<a href="#">Buy now</a>


# Fuel Injection Pump



Ref	Part	
53	<a href="#">97013-08070</a> Bolt	<a href="#">Buy now</a>
54	<a href="#">92903-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
55	<a href="#">90446-24MF4</a> Hose (L350)	<a href="#">Buy now</a>
56	<a href="#">90446-20MF5</a> Hose	<a href="#">Buy now</a>

**C3**

# Fuel Pump Drive Gear




68F0010-0051

B5

Ref	Part	
1	<a href="#">68F-11598-00-94</a> Bracket, tensioner	<a href="#">Buy now</a>
2	<a href="#">97013-08045</a> Bolt	<a href="#">Buy now</a>
3	<a href="#">92903-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
4	<a href="#">68F-11590-00</a> Tensioner assembly	<a href="#">Buy now</a>
5	<a href="#">90119-10M72</a> Bolt, with washer(6m6)	<a href="#">Buy now</a>
6	<a href="#">90506-16M39</a> Spring, tension	<a href="#">Buy now</a>
7	<a href="#">90445-15M03</a> Hose (I23)	<a href="#">Buy now</a>
8	<a href="#">68F-11595-00</a> Plate, Valve	<a href="#">Buy now</a>
9	<a href="#">97013-08012</a> Bolt(62e)	<a href="#">Buy now</a>
10	<a href="#">68F-46241-00</a> Belt	<a href="#">Buy now</a>
11	<a href="#">68F-11579-01-94</a> Coupling, flywheel	<a href="#">Buy now</a>
13	<a href="#">68F-11536-00-94</a> Gear, drive	<a href="#">Buy now</a>
14	<a href="#">93605-10108</a> Pin, dowel (8g8)	<a href="#">Buy now</a>
15	<a href="#">60V-11557-00</a> Washer 1	<a href="#">Buy now</a>
16	<a href="#">97095-08025</a> Bolt (62g)	<a href="#">Buy now</a>

# Fuel Pump Drive Gear




68F0010-0051

**B5**

Ref	Part	
17	<a href="#">92995-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
18	<a href="#">68F-11537-00-94</a> Gear, driven	<a href="#">Buy now</a>
19	<a href="#">90280-03M01</a> Key woodruff 146115450000	<a href="#">Buy now</a>
20	<a href="#">95707-08600</a> Nut, flange(jn5)	<a href="#">Buy now</a>


# Generator



**E1**

Ref	Part	
1	<a href="#">68F-81450-00</a> Rotor assembly	<a href="#">Buy now</a>
2	<a href="#">68F-81410-00</a> Stator assembly	<a href="#">Buy now</a>
3	<a href="#">68F-85580-00</a> Coil, pulser	<a href="#">Buy now</a>
4	<a href="#">61A-83721-00</a> Cover	<a href="#">Buy now</a>
5	<a href="#">97013-06035</a> Bolt(3rv)	<a href="#">Buy now</a>
6	<a href="#">92903-06100</a> Washer(6a1)	<a href="#">Buy now</a>
7	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
8	<a href="#">97885-05030</a> Ybs86-530 screw,panhead	<a href="#">Buy now</a>
9	<a href="#">92995-05100</a> Ybs67-5 washer, spring	<a href="#">Buy now</a>
10	<a href="#">92995-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">90280-05015</a> Key, woodruff	<a href="#">Buy now</a>
12	<a href="#">90170-24M22</a> Nut(61a)	<a href="#">Buy now</a>
13	<a href="#">90201-25M02</a> Washer, plate(61a)	<a href="#">Buy now</a>
14	<a href="#">6E5-81332-00</a> Plate, timing	<a href="#">Buy now</a>
15	<a href="#">97885-06010</a> Screw pan head	<a href="#">Buy now</a>


# Generator



E1

Ref	Part	
16	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">90465-08M23</a> Clamp (6h3)	<a href="#">Buy now</a>
18	<a href="#">68F-81337-00</a> Cover Flywheel	<a href="#">Buy now</a>
19	<a href="#">663-82317-01</a> Damper, ignition coil	<a href="#">Buy now</a>
20	<a href="#">68F-85547-01</a> Damper	<a href="#">Buy now</a>
21	<a href="#">68F-14488-00</a> Label, caution	<a href="#">Buy now</a>
22	<a href="#">6A1-83625-51</a> Mark 5	<a href="#">Buy now</a>
23	<a href="#">6A1-83625-41</a> Mark 5	<a href="#">Buy now</a>
24	<a href="#">6E5-85711-60</a> Mark Caution	<a href="#">Buy now</a>
25	<a href="#">6K1-83623-41</a> Mark 3	<a href="#">Buy now</a>
26	<a href="#">6K1-83623-50</a> Mark 3	<a href="#">Buy now</a>


# Intake



**C7**

Ref	Part	
1	<a href="#">65L-13610-01</a> Reed valve assembly	<a href="#">Buy now</a>
1	<a href="#">68H-13610-00</a> Reed valve assembly	<a href="#">Buy now</a>
2	<a href="#">65J-W0004-01</a> Reed set	<a href="#">Buy now</a>
3	<a href="#">61A-13621-A0</a> Gasket, valve seat	<a href="#">Buy now</a>
4	<a href="#">97880-05016</a> Screw, pan head(6b0)	<a href="#">Buy now</a>
5	<a href="#">92990-05600</a> Washer, plain (646)	<a href="#">Buy now</a>
6	<a href="#">68F-13624-00-1S</a> Plate,reed valve	<a href="#">Buy now</a>
7	<a href="#">6F6-11372-00</a> Nipple, hose	<a href="#">Buy now</a>
8	<a href="#">90445-07M03</a> Hose (l200)	<a href="#">Buy now</a>
9	<a href="#">650-11370-01</a> Check valve assembly	<a href="#">Buy now</a>
10	<a href="#">90105-06028</a> Bolt, washer based	<a href="#">Buy now</a>
11	<a href="#">65L-13646-00</a> Gasket, manifold 2	<a href="#">Buy now</a>
12	<a href="#">65L-13645-00</a> Gasket, manifold 1	<a href="#">Buy now</a>
13	<a href="#">97013-06060</a> Bolt, hexagon	<a href="#">Buy now</a>
14	<a href="#">92903-06600</a> Washer, plain (646)	<a href="#">Buy now</a>


## Intake



Ref	Part	
15	<a href="#">95670-06660</a> Bolt, stud	<a href="#">Buy now</a>
16	<a href="#">90179-06M24</a> Nut(6j8)	<a href="#">Buy now</a>
17	<a href="#">67H-14440-00</a> Silencer assembly Intake	<a href="#">Buy now</a>
18	<a href="#">65L-14483-00</a> Gasket	<a href="#">Buy now</a>
19	<a href="#">90445-07M44</a> Hose (I390)	<a href="#">Buy now</a>
20	<a href="#">90159-06M16</a> Screw, with washer(61a)	<a href="#">Buy now</a>

**C7**


# Lower Casing. Drive 1



**C2**


Ref	Part	
1	<a href="#">64E-45300-02-8D</a> Lower unit assembly <b>L</b>	<a href="#">Buy now</a>
1	<a href="#">64E-45300-22-8D</a> Lower unit assembly <b>X</b>	<a href="#">Buy now</a>
2	<a href="#">6J9-45301-05-8D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93311-928U5</a> Bearing, needle (6g5)	<a href="#">Buy now</a>
4	<a href="#">93332-000V3</a> Bearing, taper roller (6g5)	<a href="#">Buy now</a>
5	<a href="#">6G5-45567-01-10</a> Shim (t:0.10mm) <b>UR</b>	<a href="#">Buy now</a>
5	<a href="#">6G5-45567-01-12</a> Shim (t:0.12mm) <b>UR</b>	<a href="#">Buy now</a>
5	<a href="#">6G5-45567-01-15</a> Shim (t:0.15mm) <b>UR</b>	<a href="#">Buy now</a>
5	<a href="#">6G5-45567-01-18</a> Shim (t:0.18mm) <b>UR</b>	<a href="#">Buy now</a>
5	<a href="#">6G5-45567-01-30</a> Shim (t:0.30mm) <b>UR</b>	<a href="#">Buy now</a>
5	<a href="#">6G5-45567-01-40</a> Shim (t:0.40mm) <b>UR</b>	<a href="#">Buy now</a>
5	<a href="#">6G5-45567-01-50</a> Shim (t:0.50mm) <b>UR</b>	<a href="#">Buy now</a>
6	<a href="#">90340-08002</a> Plug, straight screw	<a href="#">Buy now</a>
7	<a href="#">688-45341-10</a> Plug, drain	<a href="#">Buy now</a>
8	<a href="#">90430-08020</a> Gasket	<a href="#">Buy now</a>

# Lower Casing. Drive 1



Ref	Part	
9	<a href="#">90206-22M19</a> Washer, wave(61a)	<a href="#">Buy now</a>
10	<a href="#">90201-22M01</a> Washer, plate(61a)	<a href="#">Buy now</a>
11	<a href="#">61A-45527-00</a> Collar, drive shaft	<a href="#">Buy now</a>
12	<a href="#">61A-45538-00</a> Spacer, 1	<a href="#">Buy now</a>
13	<a href="#">6G5-45536-01</a> Sleeve, drive shaft	<a href="#">Buy now</a>
14	<a href="#">64D-45376-00-94</a> Guide, seal damper <b>X</b>	<a href="#">Buy now</a>
14	<a href="#">663-45376-00-94</a> Guide, seal damper <b>L</b>	<a href="#">Buy now</a>
15	<a href="#">688-45375-00</a> Damper, seal 2	<a href="#">Buy now</a>
16	<a href="#">6E5-45378-00</a> Nipple, hose	<a href="#">Buy now</a>
17	<a href="#">90445-07ME8</a> Hose (I250) <b>L</b>	<a href="#">Buy now</a>
17	<a href="#">90445-07ME9</a> Hose (I250) <b>X</b>	<a href="#">Buy now</a>
18	<a href="#">6E5-83558-10</a> End, nipple	<a href="#">Buy now</a>
19	<a href="#">6E5-45321-00</a> Plate	<a href="#">Buy now</a>
20	<a href="#">93210-58144</a> O-ring(47x)	<a href="#">Buy now</a>
21	<a href="#">93106-09014</a> Oil seal	<a href="#">Buy now</a>


# Lower Casing. Drive 1



**C2**


Ref	Part	
22	<a href="#">90119-06M10</a> Bolt, with washer	<a href="#">Buy now</a>
23	<a href="#">6G5-44150-02</a> Shift cam assembly	<a href="#">Buy now</a>
24	<a href="#">99001-08600</a> Circlip(2r6)	<a href="#">Buy now</a>
25	<a href="#">90501-11M10</a> Spring, compression (663)	<a href="#">Buy now</a>
26	<a href="#">61A-44311-01</a> Housing, water pump	<a href="#">Buy now</a>
27	<a href="#">61A-44322-02</a> Insert, cartridge	<a href="#">Buy now</a>
28	<a href="#">93210-86M38</a> O-ring (6e5)	<a href="#">Buy now</a>
29	<a href="#">93210-37160</a> O-ring (6g8)	<a href="#">Buy now</a>
30	<a href="#">6E5-44365-00</a> Damper, water seal 1	<a href="#">Buy now</a>
31	<a href="#">6E5-44312-00</a> Cover, water pump housing	<a href="#">Buy now</a>
32	<a href="#">6E5-44352-01</a> Impeller	<a href="#">Buy now</a>
33	<a href="#">90280-04M05</a> Key, woodruff (6e5)	<a href="#">Buy now</a>
34	<a href="#">6G5-44323-00</a> Outer plate, cartridge	<a href="#">Buy now</a>
35	<a href="#">6E5-44315-A0</a> Gasket,water pump	<a href="#">Buy now</a>
36	<a href="#">93606-12019</a> Pin, dowel (614)	<a href="#">Buy now</a>

# Lower Casing. Drive 1




Ref	Part	
37	<a href="#">90119-08M14</a> Bolt, with washer	<a href="#">Buy now</a>
38	<a href="#">6E5-45331-00-94</a> Housing, bearing	<a href="#">Buy now</a>
39	<a href="#">93101-28M16</a> Oil seal (6e5)	<a href="#">Buy now</a>
40	<a href="#">93317-330U2</a> Bearing, cylindrical(6k0)	<a href="#">Buy now</a>
41	<a href="#">6E5-45587-01-10</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
41	<a href="#">6E5-45587-01-12</a> Shim (t:0.12mm) UR	<a href="#">Buy now</a>
41	<a href="#">6E5-45587-01-15</a> Shim (t:0.15mm) UR	<a href="#">Buy now</a>
41	<a href="#">6E5-45587-01-18</a> Shim (t:0.18mm) UR	<a href="#">Buy now</a>
41	<a href="#">6E5-45587-01-30</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>
41	<a href="#">6E5-45587-01-40</a> Shim (t:0.40mm) UR	<a href="#">Buy now</a>
41	<a href="#">6E5-45587-01-50</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>
42	<a href="#">93341-930V2</a> Bearing, thrust(64d)	<a href="#">Buy now</a>
43	<a href="#">93210-55M14</a> O-ring (70e)	<a href="#">Buy now</a>
44	<a href="#">6E5-45344-00</a> Cover, oil seal	<a href="#">Buy now</a>
45	<a href="#">97095-08025</a> Bolt (62g)	<a href="#">Buy now</a>

# Lower Casing. Drive 1




Ref	Part	
46	<a href="#">92995-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
47	<a href="#">6G5-45501-01</a> Drive shaft comp. <i>L</i>	<a href="#">Buy now</a>
47	<a href="#">6G5-45501-21</a> Drive shaft comp. <i>X</i>	<a href="#">Buy now</a>
48	<a href="#">6G5-45551-10</a> Pinion	<a href="#">Buy now</a>
49	<a href="#">90170-16M01</a> Nut, hexagon (688)	<a href="#">Buy now</a>
50	<a href="#">6G5-45560-10</a> Gear	<a href="#">Buy now</a>
51	<a href="#">93315-425V3</a> Bearing, needle (6g5)	<a href="#">Buy now</a>
52	<a href="#">6J9-45611-01</a> Shaft, propeller	<a href="#">Buy now</a>
53	<a href="#">6E5-45641-02</a> Shifter	<a href="#">Buy now</a>
54	<a href="#">6E5-45634-01</a> Slide, shift	<a href="#">Buy now</a>
55	<a href="#">90501-16M37</a> Spring (6g5)	<a href="#">Buy now</a>
56	<a href="#">93507-32009</a> Ball (12r)	<a href="#">Buy now</a>
57	<a href="#">93511-32017</a> Ball (498)	<a href="#">Buy now</a>
58	<a href="#">93503-16003</a> Ball	<a href="#">Buy now</a>
59	<a href="#">90250-08M07</a> Pin, straight (6g5)	<a href="#">Buy now</a>

# Lower Casing. Drive 1



Ref	Part	
60	<a href="#">6G5-45631-10</a> Clutch, dog	<a href="#">Buy now</a>
61	<a href="#">6E5-45633-01</a> Ring, cross pin	<a href="#">Buy now</a>
62	<a href="#">6J9-45332-00-94</a> Housing, bearing	<a href="#">Buy now</a>
63	<a href="#">93306-209U0</a> Bearing (6g5)	<a href="#">Buy now</a>
64	<a href="#">6G5-45571-02</a> Gear	<a href="#">Buy now</a>
65	<a href="#">6G5-45576-10</a> Washer, thrust 2	<a href="#">Buy now</a>
66	<a href="#">93315-430U8</a> Bearing	<a href="#">Buy now</a>
67	<a href="#">93101-30M17</a> Oil seal (6e5)	<a href="#">Buy now</a>
68	<a href="#">93210-97M55</a> O-ring (6g5)	<a href="#">Buy now</a>
69	<a href="#">6G5-45577-02-10</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
69	<a href="#">6G5-45577-02-12</a> Shim (t:0.12mm) UR	<a href="#">Buy now</a>
69	<a href="#">6G5-45577-02-15</a> Shim (t:0.15mm) UR	<a href="#">Buy now</a>
69	<a href="#">6G5-45577-02-18</a> Shim (t:0.18mm) UR	<a href="#">Buy now</a>
69	<a href="#">6G5-45577-02-30</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>
69	<a href="#">6G5-45577-02-40</a> Shim (t:0.40mm)	<a href="#">Buy now</a>


## Lower Casing. Drive 1



Ref	Part	
69	<a href="#">6G5-45577-02-50</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>
70	<a href="#">90201-30M92</a> Washer (6g5)	<a href="#">Buy now</a>
71	<a href="#">90282-04M00</a> Key, straight(6g5)	<a href="#">Buy now</a>
72	<a href="#">6G5-45383-01</a> Washer, claw	<a href="#">Buy now</a>
73	<a href="#">6G5-45384-00</a> Nut	<a href="#">Buy now</a>

C2

## Lower Casing. Drive 2




67H0100-1260

C6


Ref	Part	
1	<a href="#">6E5-44366-00</a> Damper, water seal 2	<a href="#">Buy now</a>
2	<a href="#">6E5-44361-00</a> Tube, water L	<a href="#">Buy now</a>
2	<a href="#">6E5-44361-20</a> Tube, water X	<a href="#">Buy now</a>
3	<a href="#">6E5-44365-00</a> Damper, water seal 1	<a href="#">Buy now</a>
4	<a href="#">93608-12M05</a> Pin, dowel b (6e5)	<a href="#">Buy now</a>
5	<a href="#">97075-10045</a> Bolt(64d)	<a href="#">Buy now</a>
6	<a href="#">92995-10100</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
7	<a href="#">90119-10M89</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">6J9-45214-00</a> Cover, water inlet	<a href="#">Buy now</a>
9	<a href="#">6J9-45215-00</a> Cover, water inlet	<a href="#">Buy now</a>
10	<a href="#">90152-05M08</a> Screw, countersunk	<a href="#">Buy now</a>
11	<a href="#">90185-05002</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
12	<a href="#">6J9-45371-01</a> Tab-trim	<a href="#">Buy now</a>
13	<a href="#">90105-10M00</a> Bolt, hexagon (663)	<a href="#">Buy now</a>
14	<a href="#">90445-07M33</a> Hose (L1080)	<a href="#">Buy now</a>

## Lower Casing. Drive 2



Ref	Part	
15	<a href="#">6E5-83558-00</a> End, nipple	<a href="#">Buy now</a>
16	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
17	<a href="#">6E5-45987-01</a> Spacer 1	<a href="#">Buy now</a>
18	<a href="#">688-45997-01</a> Spacer 2	<a href="#">Buy now</a>
19	<a href="#">92990-18200</a> Washer (6e5)	<a href="#">Buy now</a>
20	<a href="#">90171-18M04</a> Nut, castle (6e5)	<a href="#">Buy now</a>
21	<a href="#">91490-40030</a> Pin, cotter (663)	<a href="#">Buy now</a>
22	<a href="#">6G5-45941-00-98</a> Propeller (3x15-1/4x15-m) UR	<a href="#">Buy now</a>
22	<a href="#">6G5-45943-01-98</a> Propeller (3x13-3/4"x21"-m) UR	<a href="#">Buy now</a>
22	<a href="#">6G5-45945-01-98</a> Propeller (3x14"x19"-m) UR	<a href="#">Buy now</a>
22	<a href="#">6G5-45947-01-98</a> Propeller (3x14-1/2"x17"-m) UR	<a href="#">Buy now</a>
22	<a href="#">6G5-45949-00-98</a> Propeller (3x13-1/2"x23"-m) UR	<a href="#">Buy now</a>
22	<a href="#">6G5-45930-00-98</a> Propeller (ss 3x13-3/8"x25"-m) UR	<a href="#">Buy now</a>
22	<a href="#">6G5-45932-00-98</a> Propeller (3x15-3/4"x13"-m)	<a href="#">Buy now</a>
22	<a href="#">6G5-45952-00-98</a> Propeller (3x14-5/8"x16"-m)	<a href="#">Buy now</a>


## Lower Casing. Drive 2



Ref	Part	
22	<a href="#">6G5-45970-02-98</a> Propeller (3x15-1/4 x15 -m) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6G5-45972-02-98</a> Propeller (3x13-3/4 x21 -m) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6G5-45974-03-98</a> Propeller (3x13-3/4"x19"-m2) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6G5-45976-01-98</a> Propeller (3x13-3/8"x23"-m) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6G5-45978-03-98</a> Propeller (3x13-3/4"x17"-m2) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6R4-45970-A0</a> Propeller (3X15-1/4"X19"-M) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6R4-45972-A0</a> Propeller (3X14-7/8"X21"-M) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6R4-45974-A0</a> Propeller (3X14-1/2"X23"-M) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6R4-45976-A0</a> Propeller (3X14-1/2"X15"-M) <b>UR</b>	<a href="#">Buy now</a>
22	<a href="#">6R4-45978-A0</a> Propeller (3X15-1/4"X17"-M) <b>UR</b>	<a href="#">Buy now</a>


C6

## Lower Casing. Drive 3



Ref	Part	
1	<a href="#">64H-45300-22-8D</a> Lower unit assembly X	<a href="#">Buy now</a>
2	<a href="#">6J9-45301-05-8D</a> Casing, lower	<a href="#">Buy now</a>
3	<a href="#">93311-928U5</a> Bearing, needle (6g5)	<a href="#">Buy now</a>
4	<a href="#">93390-000U2</a> Bearing(6k0)	<a href="#">Buy now</a>
5	<a href="#">93341-465U4</a> Bearing, thrust (6k0)	<a href="#">Buy now</a>
6	<a href="#">6G5-45567-01-10</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
6	<a href="#">6G5-45567-01-12</a> Shim (t:0.12mm) UR	<a href="#">Buy now</a>
6	<a href="#">6G5-45567-01-15</a> Shim (t:0.15mm) UR	<a href="#">Buy now</a>
6	<a href="#">6G5-45567-01-18</a> Shim (t:0.18mm) UR	<a href="#">Buy now</a>
6	<a href="#">6G5-45567-01-30</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>
6	<a href="#">6G5-45567-01-40</a> Shim (t:0.40mm) UR	<a href="#">Buy now</a>
6	<a href="#">6G5-45567-01-50</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>
7	<a href="#">90340-08002</a> Plug, straight screw	<a href="#">Buy now</a>
8	<a href="#">688-45341-10</a> Plug, drain	<a href="#">Buy now</a>
9	<a href="#">90430-08020</a> Gasket	<a href="#">Buy now</a>


## Lower Casing. Drive 3



**D1**

Ref	Part	
10	<a href="#">90206-22M19</a> Washer, wave(61a)	<a href="#">Buy now</a>
11	<a href="#">90201-22M01</a> Washer, plate(61a)	<a href="#">Buy now</a>
12	<a href="#">61A-45527-00</a> Collar, drive shaft	<a href="#">Buy now</a>
13	<a href="#">61A-45538-00</a> Spacer, 1	<a href="#">Buy now</a>
14	<a href="#">6G5-45536-01</a> Sleeve, drive shaft	<a href="#">Buy now</a>
15	<a href="#">64D-45376-00-94</a> Guide, seal damper X	<a href="#">Buy now</a>
16	<a href="#">688-45375-00</a> Damper, seal 2	<a href="#">Buy now</a>
17	<a href="#">6J8-45378-00</a> Nipple, hose (plug)	<a href="#">Buy now</a>
18	<a href="#">6E5-45321-00</a> Plate	<a href="#">Buy now</a>
19	<a href="#">93210-58144</a> O-ring(47x)	<a href="#">Buy now</a>
20	<a href="#">93106-09014</a> Oil seal	<a href="#">Buy now</a>
21	<a href="#">90119-06M10</a> Bolt, with washer	<a href="#">Buy now</a>
22	<a href="#">6K1-44150-01</a> Shift cam assembly	<a href="#">Buy now</a>
23	<a href="#">99001-08600</a> Circlip(2r6)	<a href="#">Buy now</a>
24	<a href="#">90501-11M10</a> Spring, compression (663)	<a href="#">Buy now</a>


## Lower Casing. Drive 3



D1

Ref	Part	
25	<a href="#">61A-44311-01</a> Housing, water pump	<a href="#">Buy now</a>
26	<a href="#">61A-44322-02</a> Insert, cartridge	<a href="#">Buy now</a>
27	<a href="#">93210-86M38</a> O-ring (6e5)	<a href="#">Buy now</a>
28	<a href="#">93210-37160</a> O-ring (6g8)	<a href="#">Buy now</a>
29	<a href="#">6E5-44365-00</a> Damper, water seal 1	<a href="#">Buy now</a>
30	<a href="#">6E5-44312-00</a> Cover, water pump housing	<a href="#">Buy now</a>
31	<a href="#">6E5-44352-01</a> Impeller	<a href="#">Buy now</a>
32	<a href="#">90280-04M05</a> Key, woodruff (6e5)	<a href="#">Buy now</a>
33	<a href="#">6G5-44323-00</a> Outer plate, cartridge	<a href="#">Buy now</a>
34	<a href="#">6E5-44315-A0</a> Gasket,water pump	<a href="#">Buy now</a>
35	<a href="#">93606-12019</a> Pin, dowel (614)	<a href="#">Buy now</a>
36	<a href="#">90119-08M14</a> Bolt, with washer	<a href="#">Buy now</a>
37	<a href="#">6E5-45331-00-94</a> Housing, bearing	<a href="#">Buy now</a>
38	<a href="#">93101-28M16</a> Oil seal (6e5)	<a href="#">Buy now</a>
39	<a href="#">93317-330U2</a> Bearing, cylindrical(6k0)	<a href="#">Buy now</a>


# Lower Casing. Drive 3



D1

Ref	Part	
40	<a href="#">6E5-45587-01-10</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
40	<a href="#">6E5-45587-01-12</a> Shim (t:0.12mm) UR	<a href="#">Buy now</a>
40	<a href="#">6E5-45587-01-15</a> Shim (t:0.15mm) UR	<a href="#">Buy now</a>
40	<a href="#">6E5-45587-01-18</a> Shim (t:0.18mm) UR	<a href="#">Buy now</a>
40	<a href="#">6E5-45587-01-30</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>
40	<a href="#">6E5-45587-01-40</a> Shim (t:0.40mm) UR	<a href="#">Buy now</a>
40	<a href="#">6E5-45587-01-50</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>
41	<a href="#">93341-930V2</a> Bearing, thrust(64d)	<a href="#">Buy now</a>
42	<a href="#">93210-55M14</a> O-ring (70e)	<a href="#">Buy now</a>
43	<a href="#">6E5-45344-00</a> Cover, oil seal	<a href="#">Buy now</a>
44	<a href="#">97095-08025</a> Bolt (62g)	<a href="#">Buy now</a>
45	<a href="#">92995-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
46	<a href="#">6G5-45501-21</a> Drive shaft comp. X	<a href="#">Buy now</a>
47	<a href="#">6G5-45551-10</a> Pinion	<a href="#">Buy now</a>
48	<a href="#">90170-16M01</a> Nut, hexagon (688)	<a href="#">Buy now</a>


# Lower Casing. Drive 3



D1


Ref	Part	
49	<a href="#">6K1-45560-01</a> Gear	<a href="#">Buy now</a>
50	<a href="#">93315-425V3</a> Bearing, needle (6g5)	<a href="#">Buy now</a>
51	<a href="#">6K1-45611-10</a> Shaft, propeller	<a href="#">Buy now</a>
52	<a href="#">6K1-45641-01</a> Shifter	<a href="#">Buy now</a>
53	<a href="#">6E5-45634-01</a> Slide, shift	<a href="#">Buy now</a>
54	<a href="#">90501-16M37</a> Spring (6g5)	<a href="#">Buy now</a>
55	<a href="#">93507-32009</a> Ball (12r)	<a href="#">Buy now</a>
56	<a href="#">93511-32017</a> Ball (498)	<a href="#">Buy now</a>
57	<a href="#">93503-16003</a> Ball	<a href="#">Buy now</a>
58	<a href="#">90250-08M07</a> Pin, straight (6g5)	<a href="#">Buy now</a>
59	<a href="#">6G5-45631-10</a> Clutch, dog	<a href="#">Buy now</a>
60	<a href="#">6E5-45633-01</a> Ring, cross pin	<a href="#">Buy now</a>
61	<a href="#">6K1-45332-01-94</a> Housing, bearing	<a href="#">Buy now</a>
62	<a href="#">93332-00048</a> Bearing(6k0)	<a href="#">Buy now</a>
63	<a href="#">6K1-45570-20</a> Gear	<a href="#">Buy now</a>

# Lower Casing. Drive 3



Ref	Part	
64	<a href="#">6K1-45576-00</a> Washer, thrust	<a href="#">Buy now</a>
65	<a href="#">93341-440U5</a> Bearing, thrust (6k0)	<a href="#">Buy now</a>
66	<a href="#">6K1-45578-01-10</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
66	<a href="#">6K1-45578-01-12</a> Shim (t:0.12mm) UR	<a href="#">Buy now</a>
66	<a href="#">6K1-45578-01-15</a> Shim (t:0.15mm) UR	<a href="#">Buy now</a>
66	<a href="#">6K1-45578-01-18</a> Shim (t:0.18mm) UR	<a href="#">Buy now</a>
66	<a href="#">6K1-45578-01-30</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>
66	<a href="#">6K1-45578-01-40</a> Shim (t:0.40mm) UR	<a href="#">Buy now</a>
66	<a href="#">6K1-45578-01-50</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>
67	<a href="#">93315-430U8</a> Bearing	<a href="#">Buy now</a>
68	<a href="#">93101-30M17</a> Oil seal (6e5)	<a href="#">Buy now</a>
69	<a href="#">93210-97M55</a> O-ring (6g5)	<a href="#">Buy now</a>
70	<a href="#">6G5-45577-02-10</a> Shim (t:0.10mm) UR	<a href="#">Buy now</a>
70	<a href="#">6G5-45577-02-12</a> Shim (t:0.12mm) UR	<a href="#">Buy now</a>
70	<a href="#">6G5-45577-02-15</a> Shim (t:0.15mm) UR	<a href="#">Buy now</a>


## Lower Casing. Drive 3



D1

Ref	Part	
70	<a href="#">6G5-45577-02-18</a> Shim (t:0.18mm) UR	<a href="#">Buy now</a>
70	<a href="#">6G5-45577-02-30</a> Shim (t:0.30mm) UR	<a href="#">Buy now</a>
70	<a href="#">6G5-45577-02-40</a> Shim (t:0.40mm) UR	<a href="#">Buy now</a>
70	<a href="#">6G5-45577-02-50</a> Shim (t:0.50mm) UR	<a href="#">Buy now</a>
71	<a href="#">90282-04M00</a> Key, straight(6g5)	<a href="#">Buy now</a>
72	<a href="#">6G5-45383-01</a> Washer, claw	<a href="#">Buy now</a>
73	<a href="#">6G5-45384-00</a> Nut	<a href="#">Buy now</a>


## Lower Casing. Drive 4



D5

Ref	Part	
1	<a href="#">6E5-44366-00</a> Damper, water seal 2	<a href="#">Buy now</a>
2	<a href="#">6E5-44361-20</a> Tube, water X	<a href="#">Buy now</a>
3	<a href="#">6E5-44365-00</a> Damper, water seal 1	<a href="#">Buy now</a>
4	<a href="#">93608-12M05</a> Pin, dowel b (6e5)	<a href="#">Buy now</a>
5	<a href="#">97075-10045</a> Bolt(64d)	<a href="#">Buy now</a>
6	<a href="#">92995-10100</a> Ybs67-10 washer, spring	<a href="#">Buy now</a>
7	<a href="#">90119-10M89</a> Bolt, with washer	<a href="#">Buy now</a>
8	<a href="#">6J9-45214-00</a> Cover, water inlet	<a href="#">Buy now</a>
9	<a href="#">6J9-45215-00</a> Cover, water inlet	<a href="#">Buy now</a>
10	<a href="#">90152-05M08</a> Screw, countersunk	<a href="#">Buy now</a>
11	<a href="#">90185-05002</a> Nut nylon (sus)(ex4)	<a href="#">Buy now</a>
12	<a href="#">6K1-45371-02</a> Tab-trim	<a href="#">Buy now</a>
13	<a href="#">90105-10M00</a> Bolt, hexagon (663)	<a href="#">Buy now</a>
14	<a href="#">6E5-45987-01</a> Spacer 1	<a href="#">Buy now</a>
15	<a href="#">688-45997-01</a> Spacer 2	<a href="#">Buy now</a>


## Lower Casing. Drive 4



D5

Ref	Part	
16	<a href="#">92990-18200</a> Washer (6e5)	<a href="#">Buy now</a>
17	<a href="#">90171-18M04</a> Nut, castle (6e5)	<a href="#">Buy now</a>
18	<a href="#">91490-40030</a> Pin, cotter (663)	<a href="#">Buy now</a>
19	<a href="#">6K1-45970-01-98</a> Propeller (3x15-1/4"x15"-ml) UR	<a href="#">Buy now</a>
19	<a href="#">6K1-45972-01-98</a> Propeller (3x13-3/4"x21"-ml) UR	<a href="#">Buy now</a>
19	<a href="#">6K1-45974-02-98</a> Propeller (3x13-3/4"x19"-ml1) UR	<a href="#">Buy now</a>
19	<a href="#">6K1-45978-02-98</a> Propeller (3x13-3/4"x17"-ml1) UR	<a href="#">Buy now</a>
19	<a href="#">6R1-45970-A0</a> Propeller, Ss (3 X 15-1/4" X 19"-Mi) UR	<a href="#">Buy now</a>
19	<a href="#">6R1-45972-A0</a> Propeller (3X14-7/8"X21"-Mi) UR	<a href="#">Buy now</a>
19	<a href="#">6R1-45974-A0</a> Propeller (3X14-1/2"X23"-Mi) UR	<a href="#">Buy now</a>
19	<a href="#">6R1-45976-A0</a> Propeller (3X15-1/4"X15"-Mi) UR	<a href="#">Buy now</a>
19	<a href="#">6R1-45978-A0</a> Propeller (3X15-1/4"x17"-Mi) UR	<a href="#">Buy now</a>


# Meter



E2

Ref	Part	
1	<a href="#">6Y5-8350T-02</a> Digital tachometer assembly AP	<a href="#">Buy now</a>
2	<a href="#">9E450-04433</a> Housing, connector (m-4-w) M-4-W	<a href="#">Buy now</a>
3	<a href="#">9E450-04533</a> Housing, f-4-w(5pcs) F-4-W	<a href="#">Buy now</a>
4	<a href="#">92990-04100</a> Ybs67-4 washer, spring	<a href="#">Buy now</a>
5	<a href="#">95380-04600</a> Nut,hex	<a href="#">Buy now</a>
6	<a href="#">6Y5-83500-S5</a> Meter assembly AP	<a href="#">Buy now</a>
7	<a href="#">6Y5-83570-S5</a> Speedometer assembly	<a href="#">Buy now</a>
10	<a href="#">6Y5-83533-T2</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">6Y5-83557-31</a> Tube	<a href="#">Buy now</a>
12	<a href="#">6Y5-83728-00</a> Connector assembly	<a href="#">Buy now</a>
20	<a href="#">90465-11M10</a> Clamp AP	<a href="#">Buy now</a>
14	<a href="#">6Y5-87122-S0</a> Cord assembly 1 AP	<a href="#">Buy now</a>
15	<a href="#">6Y5-83553-00</a> Wire, lead (l=2.5m) AP	<a href="#">Buy now</a>
15	<a href="#">6Y5-83553-M0</a> Wire, lead (l=2.5m) AP	<a href="#">Buy now</a>
16	<a href="#">1E6-82151-00</a> Fuse (10a) FOR 6Y5-83553-M0	<a href="#">Buy now</a>


# Meter



E2

Ref	Part	
17	<a href="#">6Y5-82117-00</a> Wire, lead AP	<a href="#">Buy now</a>
18	<a href="#">68F-82553-80</a> Extension, wire lead (8m) AP	<a href="#">Buy now</a>
18	<a href="#">68F-82553-90</a> Extension, wire lead (9m) AP	<a href="#">Buy now</a>
19	<a href="#">6Y5-83557-10</a> Tube (8m) AP	<a href="#">Buy now</a>
21	<a href="#">6Y5-8350F-00</a> Fuel meter movement assembly AP	<a href="#">Buy now</a>
23	<a href="#">6Y5-83553-F1</a> Wire, lead AP	<a href="#">Buy now</a>
24	<a href="#">6Y5-85752-01</a> Sender unit assembly, fuel meter AP	<a href="#">Buy now</a>
25	<a href="#">90158-06002</a> 33 – AP	<a href="#">Buy now</a>
27	<a href="#">703-82531-00</a> Wire, lead AP	<a href="#">Buy now</a>


# Oil Pump



D1

Ref	Part	
1	<a href="#">68F-13200-00</a> Oil injection pump assembly	<a href="#">Buy now</a>
1	<a href="#">68H-13200-00</a> Oil injection pump assembly	<a href="#">Buy now</a>
1	<a href="#">68L-13200-00</a> Oil injection pump assembly	<a href="#">Buy now</a>
2	<a href="#">6R3-13471-00</a> Screw	<a href="#">Buy now</a>
3	<a href="#">6L2-13475-00</a> Gasket, breather bolt	<a href="#">Buy now</a>
4	<a href="#">93210-19M82</a> O-ring(6j8)	<a href="#">Buy now</a>
5	<a href="#">90109-06M40</a> Bolt(6h0)	<a href="#">Buy now</a>
6	<a href="#">6G5-13416-00</a> Pipe, oil 1	<a href="#">Buy now</a>
7	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
8	<a href="#">90445-07M00</a> Hose (I200)	<a href="#">Buy now</a>
9	<a href="#">90445-07M09</a> Hose (I390)	<a href="#">Buy now</a>
10	<a href="#">90445-07MA5</a> Hose (I200)	<a href="#">Buy now</a>
11	<a href="#">90445-07M10</a> Hose (L770)	<a href="#">Buy now</a>
12	<a href="#">90445-07MA4</a> Hose (I390)	<a href="#">Buy now</a>
13	<a href="#">90445-07M80</a> Hose (I770)	<a href="#">Buy now</a>


# Oil Pump



D1

Ref	Part	
14	<a href="#">90468-07M02</a> Clip (6e5)	<a href="#">Buy now</a>
15	<a href="#">6R3-13183-00</a> Valve, check	<a href="#">Buy now</a>
16	<a href="#">90445-07M04</a> Hose(62t)	<a href="#">Buy now</a>
17	<a href="#">90464-07M20</a> Clamp(6h0)	<a href="#">Buy now</a>
18	<a href="#">90464-07M05</a> Clamp (6g5)	<a href="#">Buy now</a>
19	<a href="#">6R3-11537-00</a> Gear, driven	<a href="#">Buy now</a>
20	<a href="#">6R3-13117-00</a> Collar, distance	<a href="#">Buy now</a>
21	<a href="#">93210-13M04</a> 93210-13m04	<a href="#">Buy now</a>
22	<a href="#">90202-08M44</a> Washer, plate(6r3)	<a href="#">Buy now</a>
23	<a href="#">67H-41241-00</a> Rod, link	<a href="#">Buy now</a>
24	<a href="#">6H1-41237-00</a> Joint, link	<a href="#">Buy now</a>
25	<a href="#">95380-05600</a> Nut, hexagon (663)	<a href="#">Buy now</a>
26	<a href="#">6R5-41237-00</a> Joint, link	<a href="#">Buy now</a>
27	<a href="#">90468-05M03</a> Clip(6j8)	<a href="#">Buy now</a>
28	<a href="#">90202-05088</a> Washer, plate (666)	<a href="#">Buy now</a>


# Oil Pump



**D1**

Ref	Part	
29	<a href="#">90445-12M14</a> Hose (I50)	<a href="#">Buy now</a>
31	<a href="#">90467-08M18</a> Clip	<a href="#">Buy now</a>
32	<a href="#">68F-13100-00</a> Solenoid pump assembly	<a href="#">Buy now</a>
33	<a href="#">68F-13418-00</a> Hose 4	<a href="#">Buy now</a>
34	<a href="#">68F-13184-00</a> Spring, oil pipe	<a href="#">Buy now</a>
35	<a href="#">68F-13440-00</a> Filter assembly	<a href="#">Buy now</a>
36	<a href="#">68F-1316F-00</a> Hose 1	<a href="#">Buy now</a>
37	<a href="#">68F-13133-00</a> Clip	<a href="#">Buy now</a>
38	<a href="#">68F-1316G-00</a> Hose 2	<a href="#">Buy now</a>
39	<a href="#">68F-1316A-00</a> Check Valve assembly	<a href="#">Buy now</a>
40	<a href="#">68F-13416-00</a> Hose 3	<a href="#">Buy now</a>
41	<a href="#">68F-14485-00</a> Pipe, joint	<a href="#">Buy now</a>
42	<a href="#">68F-1319K-00</a> Plate	<a href="#">Buy now</a>
43	<a href="#">97095-06020</a> Bolt(7u8)	<a href="#">Buy now</a>
44	<a href="#">92995-06100</a> Washer(6a1)	<a href="#">Buy now</a>

## Oil Pump




68F0010-0111

D1

Ref	Part	
45	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
46	<a href="#">90110-06M06</a> Bolt, hexagon socket head	<a href="#">Buy now</a>


# Oil Tank



D3

Ref	Part	
1	<a href="#">68F-21750-00</a> Oil tank assembly	<a href="#">Buy now</a>
2	<a href="#">6E5-13448-00</a> Cap, oil tank	<a href="#">Buy now</a>
3	<a href="#">90465-13M11</a> Clamp (6e5)	<a href="#">Buy now</a>
4	<a href="#">67H-85730-01</a> Oil level gauge assembly	<a href="#">Buy now</a>
5	<a href="#">6E5-13411-00</a> Strainer, oil	<a href="#">Buy now</a>
6	<a href="#">6E5-13414-00</a> Gasket, strainer cover	<a href="#">Buy now</a>
7	<a href="#">6R3-8259E-00</a> Switch assembly	<a href="#">Buy now</a>
8	<a href="#">90445-07M43</a> Hose (I600)	<a href="#">Buy now</a>
9	<a href="#">6A0-82317-00</a> Damper, ignition coil	<a href="#">Buy now</a>
10	<a href="#">624-42542-00</a> Collar	<a href="#">Buy now</a>
11	<a href="#">90119-06M65</a> Bolt, with washer	<a href="#">Buy now</a>
12	<a href="#">90465-12M92</a> Clamp	<a href="#">Buy now</a>
13	<a href="#">6E5-24323-00</a> Pipe 12	<a href="#">Buy now</a>
14	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>
15	<a href="#">6E5-24379-00</a> Pipe, joint 4	<a href="#">Buy now</a>


# Oil Tank



D3

Ref	Part	
16	<a href="#">90445-12207</a> Hose (I3000)	<a href="#">Buy now</a>
19	<a href="#">90464-13M34</a> Clamp(6r3)	<a href="#">Buy now</a>
20	<a href="#">61A-21708-20</a> Sub oil tank assembly.	<a href="#">Buy now</a>
21	<a href="#">6E5-21733-20</a> Sub tank, oil (10.5l)	<a href="#">Buy now</a>
22	<a href="#">6E5-21770-03</a> Oil tank cap assembly	<a href="#">Buy now</a>
23	<a href="#">6E5-24322-00</a> Pipe 11	<a href="#">Buy now</a>
25	<a href="#">646-24251-02</a> Strainer 1	<a href="#">Buy now</a>
26	<a href="#">6E5-24319-01</a> Pipe, oil	<a href="#">Buy now</a>
28	<a href="#">6E5-81900-01</a> Oil feed pump assembly	<a href="#">Buy now</a>
29	<a href="#">6E5-81922-00</a> Grommet	<a href="#">Buy now</a>
30	<a href="#">6E5-24321-01</a> Pipe 10	<a href="#">Buy now</a>
32	<a href="#">90445-11M26</a> Hose (I8000)	<a href="#">Buy now</a>
34	<a href="#">6E5-85720-04</a> Oil level gauge assembly	<a href="#">Buy now</a>
35	<a href="#">6R3-85721-80</a> Wire, lead	<a href="#">Buy now</a>
37	<a href="#">6E5-21734-01-33</a> Holder, oil sub tank	<a href="#">Buy now</a>


# Oil Tank



Ref	Part	
38	<a href="#">6E5-21798-01-33</a> Bracket, damper	<a href="#">Buy now</a>
39	<a href="#">6E5-21746-00</a> Damper	<a href="#">Buy now</a>
40	<a href="#">97080-06100</a> Bolt, hexagon	<a href="#">Buy now</a>
41	<a href="#">92990-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
42	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
43	<a href="#">6E5-13437-62</a> Mark Caution	<a href="#">Buy now</a>
44	<a href="#">68F-28100-00</a> Tool kit	<a href="#">Buy now</a>
45	<a href="#">68F-28199-74-A0</a> 12 – UR (E,F,S)	<a href="#">Buy now</a>
45	<a href="#">68F-28199-74-B0</a> 12 – UR (D,NL,I)	<a href="#">Buy now</a>
46	<a href="#">68F-28199-84-A0</a> O/m lz150peto/lz200neto/z1 '03 UR (DK,P,GR)	<a href="#">Buy now</a>
46	<a href="#">68F-28199-84-B0</a> O/m lz150peto/lz200neto/z1 '03 UR (N,S,SS)	<a href="#">Buy now</a>

D3


# Power Trim & Tilt Assy 1



B3

Ref	Part	
1	<a href="#">68F-43800-01-4D</a> Power trim & tilt assembly	<a href="#">Buy now</a>
2	<a href="#">64E-43825-01</a> Housing Trim & Tilt	<a href="#">Buy now</a>
3	<a href="#">64E-4388J-00</a> Plug 2	<a href="#">Buy now</a>
4	<a href="#">93210-10M74</a> O-ring	<a href="#">Buy now</a>
5	<a href="#">64E-43817-00</a> Filter 2	<a href="#">Buy now</a>
6	<a href="#">64E-43810-00</a> Tilt piston sub assembly	<a href="#">Buy now</a>
7	<a href="#">64E-43898-00</a> Seal, dust 2	<a href="#">Buy now</a>
8	<a href="#">64E-43867-00</a> O-ring 7	<a href="#">Buy now</a>
9	<a href="#">64E-43866-00</a> O-ring 6	<a href="#">Buy now</a>
10	<a href="#">6E5-43862-00</a> O-ring 2	<a href="#">Buy now</a>
11	<a href="#">64E-43883-00</a> O-ring 10	<a href="#">Buy now</a>
12	<a href="#">6E5-43872-00</a> Ring, back-up 2	<a href="#">Buy now</a>
13	<a href="#">6E5-43814-02</a> Piston, free	<a href="#">Buy now</a>
15	<a href="#">64E-43820-00</a> Trim piston sub assembly	<a href="#">Buy now</a>
16	<a href="#">64E-43821-00</a> Screw, trim cylinder end	<a href="#">Buy now</a>

# Power Trim & Tilt Assy 1




68F1100-2250

B3

Ref	Part	
17	<a href="#">64E-43822-00</a> Seal, trim dust	<a href="#">Buy now</a>
18	<a href="#">64E-4384J-00</a> Seal, trim down	<a href="#">Buy now</a>
19	<a href="#">6G5-43864-00</a> O-ring 4	<a href="#">Buy now</a>
20	<a href="#">6E5-43864-00</a> O-ring 4	<a href="#">Buy now</a>
21	<a href="#">6E5-43874-01</a> Ring, back-up 4	<a href="#">Buy now</a>
22	<a href="#">64E-43828-00</a> Body, reservoir	<a href="#">Buy now</a>
23	<a href="#">64E-43829-00</a> Plug, reservoir	<a href="#">Buy now</a>
24	<a href="#">64E-43897-00</a> O-ring	<a href="#">Buy now</a>
25	<a href="#">64E-4388E-00</a> Bolt ,screw (l:14mm)	<a href="#">Buy now</a>
26	<a href="#">64E-43869-00</a> O-ring 9	<a href="#">Buy now</a>
27	<a href="#">64E-4381G-00</a> Pin 1	<a href="#">Buy now</a>
28	<a href="#">6E5-43858-00</a> Ball 1	<a href="#">Buy now</a>
29	<a href="#">64E-4382G-00</a> Valve seat	<a href="#">Buy now</a>
30	<a href="#">90201-08M14</a> Washer, plate	<a href="#">Buy now</a>
31	<a href="#">97080-08016</a> Bolt	<a href="#">Buy now</a>


# Power Trim & Tilt Assy 1



Ref	Part	
32	<a href="#">64E-43818-01</a> Lower shock mount pin set	<a href="#">Buy now</a>
33	<a href="#">90386-22M98</a> Bush(61u)	<a href="#">Buy now</a>

**B3**


## Power Trim & Tilt Assy 2



**B5**

Ref	Part	
1	<a href="#">64E-4388E-10</a> Bolt ,screw (l:34.7mm)	<a href="#">Buy now</a>
2	<a href="#">64E-43831-00</a> Connector, shaft	<a href="#">Buy now</a>
3	<a href="#">64E-43868-00</a> O-ring 8	<a href="#">Buy now</a>
4	<a href="#">64E-43830-00</a> Gear pump assembly	<a href="#">Buy now</a>
5	<a href="#">72X-43858-00</a> Ball	<a href="#">Buy now</a>
6	<a href="#">64E-43843-00</a> Screw, valve lock	<a href="#">Buy now</a>
7	<a href="#">64E-43841-00</a> Piston, shuttle	<a href="#">Buy now</a>
8	<a href="#">64E-43802-00</a> Valve sub assembly	<a href="#">Buy now</a>
9	<a href="#">6E5-43896-00</a> O-ring	<a href="#">Buy now</a>
10	<a href="#">6G5-43863-00</a> O-ring 3	<a href="#">Buy now</a>
11	<a href="#">64E-43851-00</a> Seat, Relief Valve	<a href="#">Buy now</a>
12	<a href="#">64E-43858-00</a> Ball	<a href="#">Buy now</a>
13	<a href="#">64E-43859-00</a> Pin, Valve Support	<a href="#">Buy now</a>
14	<a href="#">64E-43855-00</a> Spring, up relief	<a href="#">Buy now</a>
15	<a href="#">64E-43850-00</a> Valve sub assembly	<a href="#">Buy now</a>


## Power Trim & Tilt Assy 2



**B5**

Ref	Part	
16	<a href="#">64E-43865-00</a> O-ring 10	<a href="#">Buy now</a>
17	<a href="#">64E-43816-00</a> Filter 1	<a href="#">Buy now</a>
19	<a href="#">64E-43817-10</a> Filter 2	<a href="#">Buy now</a>
20	<a href="#">64E-43860-00</a> Manual valve sub-assembly	<a href="#">Buy now</a>
21	<a href="#">72X-85075-L0</a> O-ring (nsd161)	<a href="#">Buy now</a>
22	<a href="#">64E-43827-00</a> Ring set	<a href="#">Buy now</a>
23	<a href="#">64E-4387A-00</a> O-ring	<a href="#">Buy now</a>
24	<a href="#">64E-43873-00</a> Ring, back up	<a href="#">Buy now</a>
25	<a href="#">64E-43875-00</a> Ring, snap	<a href="#">Buy now</a>
26	<a href="#">64E-43879-10</a> Screw, with washer	<a href="#">Buy now</a>
27	<a href="#">64E-43879-00</a> Screw, with washer	<a href="#">Buy now</a>
28	<a href="#">67H-43880-01</a> Motor assembly	<a href="#">Buy now</a>
29	<a href="#">6H1-4386K-10</a> Spring, brush	<a href="#">Buy now</a>
30	<a href="#">64E-4380J-00</a> Holder Brush	<a href="#">Buy now</a>
31	<a href="#">64E-43891-00</a> Brush 1	<a href="#">Buy now</a>


## Power Trim & Tilt Assy 2



**B5**

Ref	Part	
32	<a href="#">97607-04310</a> Screw, pan head(6g8)	<a href="#">Buy now</a>
33	<a href="#">64E-4380F-00</a> Holder, brush 2	<a href="#">Buy now</a>
34	<a href="#">64E-43892-00</a> Breaker comp. (brush 2)	<a href="#">Buy now</a>
35	<a href="#">6G5-43865-00</a> O-ring	<a href="#">Buy now</a>
36	<a href="#">93102-08M43</a> Oil seal(6b0)	<a href="#">Buy now</a>
37	<a href="#">64E-43805-00</a> Armature assembly	<a href="#">Buy now</a>
38	<a href="#">64E-43843-10</a> Screw valve lock	<a href="#">Buy now</a>

# Remote Control Box




67H0100-9310

E1

Ref	Part	
1	<a href="#">703-48205-17</a> Remote control assembly (10p, ptt) <b>AP WITH PT/T SW.</b>	<a href="#">Buy now</a>
2	<a href="#">704-48207-23</a> Remote Control assembly <b>AP WITH PT/T SW.</b>	<a href="#">Buy now</a>
3	<a href="#">701-48320-50</a> Cable, Remote Control L=15F <b>UR</b>	<a href="#">Buy now</a>
3	<a href="#">701-48320-60</a> Cable, Remote Control L=16F <b>UR</b>	<a href="#">Buy now</a>
3	<a href="#">701-48320-80</a> Cable, Remote Control L=17F <b>UR</b>	<a href="#">Buy now</a>
3	<a href="#">701-48350-00</a> Cable, Remote Control L=21F <b>UR</b>	<a href="#">Buy now</a>
3	<a href="#">701-48350-20</a> Cable, Remote Control L=23F <b>UR</b>	<a href="#">Buy now</a>


# Repair Kit 1



E5

Ref	Part	
1	<a href="#">68F-W0001-00</a> Power head gasket kit	<a href="#">Buy now</a>
2	<a href="#">65L-13645-00</a> Gasket, manifold 1	<a href="#">Buy now</a>
3	<a href="#">65L-13646-00</a> Gasket, manifold 2	<a href="#">Buy now</a>
4	<a href="#">61A-13621-A0</a> Gasket, valve seat	<a href="#">Buy now</a>
5	<a href="#">65L-14483-00</a> Gasket	<a href="#">Buy now</a>
6	<a href="#">90430-14115</a> Gasket (663)	<a href="#">Buy now</a>
7	<a href="#">68F-11381-00</a> Gasket 1	<a href="#">Buy now</a>
8	<a href="#">68F-41114-00</a> Gasket, exhaust outer cover	<a href="#">Buy now</a>
9	<a href="#">6G5-11382-A1</a> Gasket 2	<a href="#">Buy now</a>
10	<a href="#">68F-11181-00</a> Gasket, cylinder head 1	<a href="#">Buy now</a>
11	<a href="#">68F-11193-01</a> Gasket, head cover 1	<a href="#">Buy now</a>
12	<a href="#">688-12414-A1</a> Gasket, cover	<a href="#">Buy now</a>
13	<a href="#">93102-40M14</a> Oil seal(61a)	<a href="#">Buy now</a>
14	<a href="#">93211-04001</a> O-ring	<a href="#">Buy now</a>
15	<a href="#">93102-35M61</a> Oil seal	<a href="#">Buy now</a>


## Repair Kit 1



E5


Ref	Part	
16	<a href="#">93101-22M15</a> Oil seal (6e5)	<a href="#">Buy now</a>
17	<a href="#">93210-74M35</a> O-ring (6e5)	<a href="#">Buy now</a>
18	<a href="#">68F-45113-00</a> Gasket, upper casing	<a href="#">Buy now</a>

## Repair Kit 2



Ref	Part	
1	<a href="#">6G5-W0001-C1</a> Lower unit gasket kit	<a href="#">Buy now</a>
2	<a href="#">6G5-41134-A1</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
3	<a href="#">6G5-45114-A1</a> Gasket, upper casing	<a href="#">Buy now</a>
4	<a href="#">6E5-41135-A0</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
5	<a href="#">90430-08020</a> Gasket	<a href="#">Buy now</a>
6	<a href="#">6E5-45123-00</a> Gasket, muffler	<a href="#">Buy now</a>
7	<a href="#">6E5-44365-00</a> Damper, water seal 1	<a href="#">Buy now</a>
8	<a href="#">6E5-44366-00</a> Damper, water seal 2	<a href="#">Buy now</a>
9	<a href="#">93210-58144</a> O-ring(47x)	<a href="#">Buy now</a>
10	<a href="#">93106-09014</a> Oil seal	<a href="#">Buy now</a>
11	<a href="#">93210-86M38</a> O-ring (6e5)	<a href="#">Buy now</a>
12	<a href="#">93210-37160</a> O-ring (6g8)	<a href="#">Buy now</a>
13	<a href="#">6E5-44315-A0</a> Gasket,water pump	<a href="#">Buy now</a>
14	<a href="#">93101-28M16</a> Oil seal (6e5)	<a href="#">Buy now</a>
15	<a href="#">93210-55M14</a> O-ring (70e)	<a href="#">Buy now</a>


## Repair Kit 2



Ref	Part	
16	<a href="#">93210-97M55</a> O-ring (6g5)	<a href="#">Buy now</a>
17	<a href="#">93101-30M17</a> Oil seal (6e5)	<a href="#">Buy now</a>
18	<a href="#">61A-W0078-A3</a> Water pump repair kit	<a href="#">Buy now</a>
19	<a href="#">61A-44322-02</a> Insert, cartridge	<a href="#">Buy now</a>
22	<a href="#">6E5-44352-01</a> Impeller	<a href="#">Buy now</a>
23	<a href="#">6G5-44323-00</a> Outer plate, cartridge	<a href="#">Buy now</a>
25	<a href="#">93606-12019</a> Pin, dowel (614)	<a href="#">Buy now</a>
26	<a href="#">90119-08M14</a> Bolt, with washer	<a href="#">Buy now</a>
27	<a href="#">90280-04M05</a> Key, woodruff (6e5)	<a href="#">Buy now</a>
28	<a href="#">61A-W0078-2A</a> Chrome pump kit	<a href="#">Buy now</a>
29	<a href="#">6R3-44322-42</a> Insert, cartridge	<a href="#">Buy now</a>
30	<a href="#">6G5-44323-40</a> Outer plate, cartridge	<a href="#">Buy now</a>

E6


# Starting Motor



**F3**

Ref	Part	
1	<a href="#">68F-81800-01</a> Starting motor assembly	<a href="#">Buy now</a>
2	<a href="#">67F-81850-00</a> Armature assembly	<a href="#">Buy now</a>
3	<a href="#">67F-81810-00</a> Stator assembly	<a href="#">Buy now</a>
4	<a href="#">68F-81840-00</a> Brush holder assembly	<a href="#">Buy now</a>
5	<a href="#">67F-81801-00</a> Brush set	<a href="#">Buy now</a>
6	<a href="#">67F-81813-00</a> Spring, brush	<a href="#">Buy now</a>
7	<a href="#">68F-81820-00</a> Rear bracket assembly	<a href="#">Buy now</a>
8	<a href="#">67F-81808-00</a> Pinion assembly	<a href="#">Buy now</a>
9	<a href="#">67F-81857-00</a> Pinion stopper set	<a href="#">Buy now</a>
10	<a href="#">67F-81807-00</a> Gear assembly, starting motor	<a href="#">Buy now</a>
11	<a href="#">67F-81832-00</a> Clutch, over run	<a href="#">Buy now</a>
12	<a href="#">67F-81836-00</a> Shaft, pinion	<a href="#">Buy now</a>
13	<a href="#">67F-81821-00</a> Bracket, center 1	<a href="#">Buy now</a>
14	<a href="#">67F-81841-00</a> Bearing	<a href="#">Buy now</a>
15	<a href="#">67F-81891-00</a> Gear, ring	<a href="#">Buy now</a>


# Starting Motor



**F3**

Ref	Part	
16	<a href="#">67F-8183R-00</a> Gasket	<a href="#">Buy now</a>
17	<a href="#">67F-81830-00</a> Bracket, center 2	<a href="#">Buy now</a>
18	<a href="#">67F-8183T-00</a> Gear, Idler	<a href="#">Buy now</a>
19	<a href="#">67F-81809-00</a> Washer kit	<a href="#">Buy now</a>
20	<a href="#">67F-81842-00</a> Cover	<a href="#">Buy now</a>
21	<a href="#">67F-81839-00</a> Lever assembly	<a href="#">Buy now</a>
22	<a href="#">68F-81941-01</a> Starter Relay assembly	<a href="#">Buy now</a>
23	<a href="#">67F-81869-00</a> Cover, dust	<a href="#">Buy now</a>
24	<a href="#">6K7-81826-10</a> Bolt	<a href="#">Buy now</a>
25	<a href="#">67F-81828-00</a> Bolt 2	<a href="#">Buy now</a>
26	<a href="#">67F-81846-00</a> Screw	<a href="#">Buy now</a>
27	<a href="#">90179-08003</a> Nut	<a href="#">Buy now</a>
28	<a href="#">68F-81925-00</a> Terminal	<a href="#">Buy now</a>
29	<a href="#">68F-82582-00</a> Cover, wire harness	<a href="#">Buy now</a>
30	<a href="#">97013-08045</a> Bolt	<a href="#">Buy now</a>


# Starting Motor



Ref	Part	
31	<a href="#">92903-08600</a> Washer, plain (663)	<a href="#">Buy now</a>

F3

# Steering Guide Attachment 1




67H0100-9290

D6

Ref	Part	
1	<a href="#">6E5-61350-02</a> Steering guide attachment kit AP	<a href="#">Buy now</a>
2	<a href="#">6E5-61351-01</a> Rod, steering link	<a href="#">Buy now</a>
3	<a href="#">90387-10M61</a> Collar (6e5)	<a href="#">Buy now</a>
4	<a href="#">90560-12M01</a> Spacer (6e5)	<a href="#">Buy now</a>
5	<a href="#">6E5-61355-00</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">90185-09M01</a> Nut, nylon (663)	<a href="#">Buy now</a>
7	<a href="#">90201-10M20</a> Washer, plate (663)	<a href="#">Buy now</a>
8	<a href="#">6E5-43145-01</a> Cap, clamp bracket	<a href="#">Buy now</a>
9	<a href="#">93210-16275</a> O-ring	<a href="#">Buy now</a>

## Steering Guide Attachment 2




67H0100-0300

D7


Ref	Part	
1	<a href="#">6E5-61301-01</a> Tie bar assembly (l:600-800mm) AP	<a href="#">Buy now</a>
2	<a href="#">6E5-61313-00</a> Adjuster	<a href="#">Buy now</a>
3	<a href="#">6E5-61311-11</a> Tie bar	<a href="#">Buy now</a>
4	<a href="#">6E5-61315-00</a> Tie bar, 2	<a href="#">Buy now</a>
5	<a href="#">6E5-61303-00</a> Steering axle comp.	<a href="#">Buy now</a>
6	<a href="#">90170-14M06</a> Nut (6e5)	<a href="#">Buy now</a>
7	<a href="#">95380-14700</a> Nut (6e5)	<a href="#">Buy now</a>
8	<a href="#">90201-10M76</a> Washer, plate (6e5)	<a href="#">Buy now</a>
9	<a href="#">90101-09M70</a> Bolt (6e5)	<a href="#">Buy now</a>
10	<a href="#">90170-09M05</a> Nut, hexagon (6e5)	<a href="#">Buy now</a>
11	<a href="#">90185-09M01</a> Nut, nylon (663)	<a href="#">Buy now</a>

# Switch. Panel



Ref	Part	
1	<a href="#">6K1-82570-07</a> Panel switch assembly <b>AP</b>	<a href="#">Buy now</a>
2	<a href="#">6K1-82571-01</a> Plate, panel switch	<a href="#">Buy now</a>
3	<a href="#">6K1-82510-06</a> Main switch assembly	<a href="#">Buy now</a>
4	<a href="#">703-82577-00</a> Cap, key	<a href="#">Buy now</a>
5	<a href="#">6K1-82575-00</a> Engine stop switch assembly	<a href="#">Buy now</a>
6	<a href="#">682-82556-00</a> Lanyard, stop switch	<a href="#">Buy now</a>
7	<a href="#">6K1-83614-01</a> Bracket	<a href="#">Buy now</a>
8	<a href="#">98980-05010</a> Screw, bind(6k1)	<a href="#">Buy now</a>
23	<a href="#">92990-05100</a> Ybs67-5 washer, spring <b>AP</b>	<a href="#">Buy now</a>
21	<a href="#">95380-05600</a> Nut, hexagon (663) <b>AP</b>	<a href="#">Buy now</a>
11	<a href="#">688-83383-11</a> Buzzer	<a href="#">Buy now</a>
12	<a href="#">6K1-85830-01</a> Control unit assembly	<a href="#">Buy now</a>
13	<a href="#">98980-06020</a> Screw, bind (j17)	<a href="#">Buy now</a>
14	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
15	<a href="#">92990-06100</a> Washer(6a1)	<a href="#">Buy now</a>


# Switch. Panel



Ref	Part	
16	<a href="#">92990-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
17	<a href="#">6K1-81980-00</a> Diode assembly	<a href="#">Buy now</a>
18	<a href="#">6K1-8258A-40</a> Extension, wire harness AP	<a href="#">Buy now</a>
19	<a href="#">61B-8258A-01</a> Extension, wire harness AP	<a href="#">Buy now</a>
20	<a href="#">90149-05M05</a> Screw(6k0) AP	<a href="#">Buy now</a>
22	<a href="#">92990-05600</a> Washer, plain (646) AP	<a href="#">Buy now</a>

E4


# Top Cowling



A4

Ref	Part	
1	<a href="#">68F-42610-50-4D</a> Top cowling assembly	<a href="#">Buy now</a>
1	<a href="#">68H-42610-50-4D</a> Top Cowling assembly	<a href="#">Buy now</a>
1	<a href="#">68L-42610-50-4D</a> Top cowling assembly	<a href="#">Buy now</a>
2	<a href="#">68F-42647-01-94</a> Holder, clamp band	<a href="#">Buy now</a>
3	<a href="#">68F-42648-01-94</a> Holder, clamp band	<a href="#">Buy now</a>
4	<a href="#">92990-06100</a> Washer(6a1)	<a href="#">Buy now</a>
5	<a href="#">95380-06600</a> Nut(661)	<a href="#">Buy now</a>
6	<a href="#">68F-42663-00</a> Damper 2	<a href="#">Buy now</a>
7	<a href="#">68F-42651-00</a> Hook	<a href="#">Buy now</a>
8	<a href="#">67F-42652-00</a> Hook	<a href="#">Buy now</a>
9	<a href="#">97095-06016</a> Bolt, hexagon deep recess	<a href="#">Buy now</a>
10	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
11	<a href="#">68F-42619-00</a> Damper, form	<a href="#">Buy now</a>
12	<a href="#">68F-42613-00-4D</a> Molding, air duct	<a href="#">Buy now</a>
13	<a href="#">90179-06M24</a> Nut(6j8)	<a href="#">Buy now</a>


## Top Cowling



A4


Ref	Part	
14	<a href="#">68F-42662-00</a> Damper	<a href="#">Buy now</a>
15	<a href="#">68F-42677-50</a> Graphic, front	<a href="#">Buy now</a>
15	<a href="#">68H-42677-50</a> Graphic, front	<a href="#">Buy now</a>
15	<a href="#">68L-42677-50</a> Graphic, front	<a href="#">Buy now</a>
16	<a href="#">68F-42687-10</a> Emblem, rear	<a href="#">Buy now</a>
17	<a href="#">68F-W0070-50</a> Graphic set	<a href="#">Buy now</a>
18	<a href="#">68F-42681-50</a> Mark, cowling	<a href="#">Buy now</a>
19	<a href="#">68F-42682-50</a> Mark, cowling	<a href="#">Buy now</a>
20	<a href="#">68F-42678-50</a> Graphic, rear	<a href="#">Buy now</a>
20	<a href="#">68H-42678-50</a> Graphic, front	<a href="#">Buy now</a>
20	<a href="#">68L-42678-50</a> Graphic, Rear	<a href="#">Buy now</a>
21	<a href="#">68F-42677-60</a> Graphic, front	<a href="#">Buy now</a>
22	<a href="#">67F-13448-00</a> Cap	<a href="#">Buy now</a>
23	<a href="#">68F-13434-00</a> Label, Caution	<a href="#">Buy now</a>

# Upper Casing



Ref	Part	
1	<a href="#">6E5-45111-02-8D</a> Casing, upper <b>L</b>	<a href="#">Buy now</a>
1	<a href="#">6E5-45111-23-8D</a> Casing, upper <b>X</b>	<a href="#">Buy now</a>
2	<a href="#">6R3-42791-41</a> Mark 1	<a href="#">Buy now</a>
3	<a href="#">6R3-42792-41</a> Mark	<a href="#">Buy now</a>
4	<a href="#">6E5-45155-00</a> Cap	<a href="#">Buy now</a>
5	<a href="#">97095-06010</a> Bolt	<a href="#">Buy now</a>
6	<a href="#">92995-06600</a> Washer, plain (646)	<a href="#">Buy now</a>
7	<a href="#">93608-12M05</a> Pin, dowel b (6e5)	<a href="#">Buy now</a>
8	<a href="#">90119-08027</a> Bolt, with washer	<a href="#">Buy now</a>
9	<a href="#">6G5-41137-11-94</a> Guide, exhaust <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
10	<a href="#">6E5-42724-00</a> Grommet	<a href="#">Buy now</a>
11	<a href="#">6G5-12581-00</a> Joint, hose	<a href="#">Buy now</a>
13	<a href="#">68F-45113-00</a> Gasket, upper casing	<a href="#">Buy now</a>
14	<a href="#">90119-08M79</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
15	<a href="#">97095-08045</a> Bolt, hexagon	<a href="#">Buy now</a>


# Upper Casing



B7

Ref	Part	
16	<a href="#">92995-08100</a> Ybs67-8 washer, spring	<a href="#">Buy now</a>
17	<a href="#">95380-08700</a> Nut(661)	<a href="#">Buy now</a>
19	<a href="#">6H1-11372-00</a> Nipple, hose <b>FLUSHING KIT</b>	<a href="#">Buy now</a>
20	<a href="#">6G5-41131-01-5B</a> Manifold, ext. 1	<a href="#">Buy now</a>
21	<a href="#">6G5-45114-A1</a> Gasket, upper casing	<a href="#">Buy now</a>
22	<a href="#">97095-08030</a> Bolt, hexagon (fj1)	<a href="#">Buy now</a>
23	<a href="#">92995-08600</a> Washer, plain (663)	<a href="#">Buy now</a>
24	<a href="#">64D-41132-00-5B</a> Manifold, exhaust	<a href="#">Buy now</a>
25	<a href="#">6G5-41134-A1</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
28	<a href="#">6E5-14711-01-5B</a> Muffler 1	<a href="#">Buy now</a>
29	<a href="#">6E5-14737-00</a> Damper, muffler	<a href="#">Buy now</a>
30	<a href="#">90183-05M02</a> Nut, spring (6e5)	<a href="#">Buy now</a>
31	<a href="#">6E5-45123-00</a> Gasket, muffler	<a href="#">Buy now</a>
32	<a href="#">6E5-41135-A0</a> Gasket, exhaust manifold	<a href="#">Buy now</a>
35	<a href="#">6E5-45318-00</a> Bushing, drive shaft 3	<a href="#">Buy now</a>
	X	


## Upper Casing



Ref	Part	
36	<a href="#">93420-36M01</a> Circlip (6a0) X	<a href="#">Buy now</a>
37	<a href="#">64D-14721-20-5B</a> Muffler 2 X	<a href="#">Buy now</a>
38	<a href="#">64D-45123-00</a> Gasket, muffler X	<a href="#">Buy now</a>
39	<a href="#">64D-45375-00</a> Damper, seal X	<a href="#">Buy now</a>

**B7**


## Vapor Separator 1



B6

Ref	Part	
1	<a href="#">68F-13784-00</a> Cover, pump	<a href="#">Buy now</a>
2	<a href="#">68F-24216-00</a> Stay	<a href="#">Buy now</a>
3	<a href="#">68F-24473-00</a> Screw	<a href="#">Buy now</a>
4	<a href="#">66K-14980-00</a> Body, float chamber	<a href="#">Buy now</a>
5	<a href="#">68F-14182-01</a> Cover, float chamber	<a href="#">Buy now</a>
6	<a href="#">65L-14546-00</a> Valve, needle	<a href="#">Buy now</a>
7	<a href="#">66K-14985-00</a> Float	<a href="#">Buy now</a>
8	<a href="#">66K-14548-01</a> Pin, float arm	<a href="#">Buy now</a>
9	<a href="#">66K-14984-00</a> Gasket, float chamber	<a href="#">Buy now</a>
10	<a href="#">65L-14125-00</a> Screw	<a href="#">Buy now</a>
11	<a href="#">68F-13906-00</a> Regulator, pressure	<a href="#">Buy now</a>
12	<a href="#">66K-14239-00</a> Seal	<a href="#">Buy now</a>
13	<a href="#">66K-14325-01</a> Screw, pan head	<a href="#">Buy now</a>
14	<a href="#">66K-14163-00</a> Spacer	<a href="#">Buy now</a>
15	<a href="#">65L-13905-00</a> Filter comp	<a href="#">Buy now</a>


## Vapor Separator 1



B6

Ref	Part	
16	<a href="#">68F-13971-00</a> Pipe, fuel 1	<a href="#">Buy now</a>
17	<a href="#">65L-24387-00</a> Clip	<a href="#">Buy now</a>
18	<a href="#">65L-14966-00</a> Cap	<a href="#">Buy now</a>
19	<a href="#">65L-24486-00</a> O-ring	<a href="#">Buy now</a>
20	<a href="#">68F-24251-00</a> Strainer 1	<a href="#">Buy now</a>
21	<a href="#">66K-14245-00</a> Screw, guide	<a href="#">Buy now</a>
22	<a href="#">68F-82509-00</a> Wire, sub lead	<a href="#">Buy now</a>
23	<a href="#">65L-14227-00</a> Washer	<a href="#">Buy now</a>
24	<a href="#">68F-13907-00</a> Fuel pump comp.	<a href="#">Buy now</a>
25	<a href="#">65L-14159-00</a> Clip	<a href="#">Buy now</a>
26	<a href="#">68F-13781-00</a> Damper, pump	<a href="#">Buy now</a>
27	<a href="#">68F-13844-00</a> Plate 2	<a href="#">Buy now</a>
28	<a href="#">68F-13915-00</a> Filter	<a href="#">Buy now</a>
29	<a href="#">65L-1416A-00</a> O-ring	<a href="#">Buy now</a>
30	<a href="#">66K-14271-00</a> Insulator	<a href="#">Buy now</a>


# Vapor Separator 1



**B6**

Ref	Part	
31	<a href="#">65L-8182A-00</a> Nut	<a href="#">Buy now</a>
32	<a href="#">65L-8182K-00</a> Nut	<a href="#">Buy now</a>
33	<a href="#">65L-8182E-00</a> Washer	<a href="#">Buy now</a>
34	<a href="#">65L-8182F-00</a> Washer	<a href="#">Buy now</a>
35	<a href="#">68F-13843-00</a> Plate 1	<a href="#">Buy now</a>
36	<a href="#">65L-14147-00</a> O-ring	<a href="#">Buy now</a>
37	<a href="#">68F-14274-00</a> Connector	<a href="#">Buy now</a>
38	<a href="#">66K-24376-00</a> Pipe, joint 1	<a href="#">Buy now</a>
39	<a href="#">66K-24489-00</a> O-ring	<a href="#">Buy now</a>
40	<a href="#">68F-14271-00</a> Insulator	<a href="#">Buy now</a>
41	<a href="#">65L-14397-00</a> O-ring	<a href="#">Buy now</a>
42	<a href="#">65L-14992-00</a> Screw, drain	<a href="#">Buy now</a>
43	<a href="#">65L-14997-00</a> Seal	<a href="#">Buy now</a>
44	<a href="#">65L-24375-00</a> Grommet	<a href="#">Buy now</a>
45	<a href="#">65L-24397-00</a> Collar	<a href="#">Buy now</a>


## Vapor Separator 1



Ref	Part	
46	<a href="#">65L-24576-00</a> Washer	<a href="#">Buy now</a>
47	<a href="#">66K-24579-00</a> Washer 2	<a href="#">Buy now</a>
48	<a href="#">65L-24592-00</a> Bolt	<a href="#">Buy now</a>
49	<a href="#">65L-24169-00</a> Washer, lock	<a href="#">Buy now</a>
50	<a href="#">68F-82507-00</a> Wire, lead	<a href="#">Buy now</a>
51	<a href="#">66K-13542-00</a> Hose, vacuum sensing 1	<a href="#">Buy now</a>
52	<a href="#">66K-13544-00</a> Hose, Vacuum Sensing 2	<a href="#">Buy now</a>
53	<a href="#">66K-13532-00</a> Hose, vacuum sensing 3	<a href="#">Buy now</a>
54	<a href="#">65L-24461-00</a> Pipe.joint 4	<a href="#">Buy now</a>
55	<a href="#">66K-13533-00</a> Hose, vacuum sensing 4	<a href="#">Buy now</a>
56	<a href="#">65L-13898-00</a> Plate 4	<a href="#">Buy now</a>
57	<a href="#">65L-14565-00</a> Screw	<a href="#">Buy now</a>
58	<a href="#">90465-11M10</a> Clamp	<a href="#">Buy now</a>

B6

## Vapor Separator 2




  
68F2010-3070

**C2**

Ref	Part	
1	<a href="#">68F-13751-00</a> Body, throttle 1	<a href="#">Buy now</a>
2	<a href="#">65L-14527-00</a> Plate	<a href="#">Buy now</a>
3	<a href="#">65L-14565-00</a> Screw	<a href="#">Buy now</a>
4	<a href="#">65L-14334-00</a> Spring, air adjusting	<a href="#">Buy now</a>
5	<a href="#">65L-14523-00</a> Screw, stop	<a href="#">Buy now</a>
6	<a href="#">6K5-14592-00</a> Screw	<a href="#">Buy now</a>
7	<a href="#">90201-05552</a> Washer, plate(65j)	<a href="#">Buy now</a>
8	<a href="#">65L-14578-00</a> Collar	<a href="#">Buy now</a>
9	<a href="#">68F-13568-00</a> Stud	<a href="#">Buy now</a>
10	<a href="#">61A-85885-00</a> Throttle sensor assembly	<a href="#">Buy now</a>
11	<a href="#">6K7-85886-00</a> Bracket	<a href="#">Buy now</a>
12	<a href="#">97985-05212</a> Screw, with washer(6g7)	<a href="#">Buy now</a>
13	<a href="#">90387-05M00</a> Collar(6k7)	<a href="#">Buy now</a>
14	<a href="#">90480-10M23</a> Grommet(6k7)	<a href="#">Buy now</a>
15	<a href="#">65L-14596-00</a> Washer	<a href="#">Buy now</a>

## Vapor Separator 2



 FWD  
68F2010-3070

**C2**

Ref	Part	
16	<a href="#">97985-05330</a> Screw, with washer(61b)	<a href="#">Buy now</a>
17	<a href="#">65L-14573-00</a> Lever	<a href="#">Buy now</a>
18	<a href="#">65L-14579-00</a> Spring	<a href="#">Buy now</a>
19	<a href="#">65L-41217-00</a> Rod, accel. lever	<a href="#">Buy now</a>

# Disclaimer

This document is provided for convenience only. It is **not** an official Yamaha publication and is **not supplied, endorsed, or approved** by Yamaha Motor Co., Ltd.

Reasonable efforts are made to keep information accurate; however diagrams, part references, supersessions, descriptions, and applicability may contain errors or omissions. Specifications and part availability may change without notice.

You are responsible for confirming the correct parts for your engine (including model code, year, serial range, and any superseded part numbers) before ordering or fitting.